

INFINITI Function list

Note:

× Functions marked with × is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

| Vehicle | System | Read Fault Code | Clear Fault Code | Live Data | Special Func |
|---------------------------------------|----------------------|-----------------|------------------|-----------|------------------------|
| Infiniti EX35 camp:P8202 \ J50 \ 2008 | Air bag | × | × | × | |
| Infiniti EX35 camp:P8202 \ J50 \ 2008 | Transmission | × | × | × | 0059 |
| Infiniti EX35 camp:P8202 \ J50 \ 2008 | IPDM E/R | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Engine | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | ABS | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Meter/M&A | × | × | × | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2011-1- | BCM | × | × | | |
| Fuga hybrid \ HY51 \ 2011-1- | Air bag | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | ICC/ADAS | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | HVAC | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Transmission | × | × | × | 0059 |
| Fuga hybrid \ HY51 \ 2011-1- | Multi AV | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Motor control | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | EPS/DAST 3 | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | IPDM E/R | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Air pressure monitor | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Laser/radar | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Preocrash seatbelt | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Auto drive position | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Lane camera | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Adaptive light | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | CAN gateway | × | × | | |
| Fuga hybrid \ HY51 \ 2011-1- | EV/HEV | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Accele pedal ACT | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | HV battery | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Brake | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Side radar left | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Side radar right | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Head lamp levelizer | × | × | × | |
| Fuga hybrid \ HY51 \ 2011-1- | Sonar | × | × | × | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Fuga hybrid \ HY51 \ 2011-1- | Pop up hood | x | x | x | |
| Fuga hybrid \ HY51 \ 2011-1- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012 | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012 | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | ICC/ADAS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012 | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Laser/radar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Lane camera | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012 | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Side radar left | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Side radar right | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Head lamp levelizer | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | Pop up hood | x | x | x | |
| Fuga hybrid \ HY51 \ 2012 | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012-1- | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012-1- | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012-1- | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Fuga hybrid \ HY51 \ 2012-1- | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012-1- | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Head lamp levelizer | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | Sonar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-1- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012-4- | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012-4- | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | ICC/ADAS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012-4- | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Laser/radar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Lane camera | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012-4- | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Side radar left | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Side radar right | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | Sonar | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Fuga hybrid \ HY51 \ 2012-4- | Pop up hood | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-4- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012-5- | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012-5- | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | ICC/ADAS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012-5- | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Laser/radar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Lane camera | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012-5- | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Side radar left | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Side radar right | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Head lamp levelizer | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Sonar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | Pop up hood | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-5- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012-6- | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012-6- | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012-6- | Multi AV | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Fuga hybrid \ HY51 \ 2012-6- | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Laser/radar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012-6- | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Sonar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Lane camera | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Side radar left | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Side radar right | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-6- | Pop up hood | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2012-7- | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2012-7- | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2012-7- | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2012-7- | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | Head lamp levelizer | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Fuga hybrid \ HY51 \ 2012-7- | Sonar | x | x | x | |
| Fuga hybrid \ HY51 \ 2012-7- | VSP | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Engine | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | ABS | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Fuga hybrid \ HY51 \ 2013 | BCM | x | x | | |
| Fuga hybrid \ HY51 \ 2013 | Air bag | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | ICC/ADAS | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | HVAC | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Transmission | x | x | x | 0059 |
| Fuga hybrid \ HY51 \ 2013 | Multi AV | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Motor control | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | EPS/DAST 3 | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | IPDM E/R | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Air pressure monitor | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Laser/radar | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Precrash seatbelt | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Auto drive position | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Lane camera | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Adaptive light | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | CAN gateway | x | x | | |
| Fuga hybrid \ HY51 \ 2013 | EV/HEV | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Accele pedal ACT | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | HV battery | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Brake | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Side radar left | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Side radar right | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | Telematics | x | x | x | 0253 |
| Fuga hybrid \ HY51 \ 2013 | Sonar | x | x | x | |
| Fuga hybrid \ HY51 \ 2013 | VSP | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Engine | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | ABS | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI ESQ \ F15 \ 2014-7- | BCM | x | x | | |
| INFINITI ESQ \ F15 \ 2014-7- | Air bag | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | ICC/ADAS | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| INFINITI ESQ \ F15 \ 2014-7- | Transmission | x | x | x | 0113, 0076, 0059, 0083, 0100 |
| INFINITI ESQ \ F15 \ 2014-7- | Multi AV | x | x | x | 0280 |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| INFINITI ESQ \ F15 \ 2014-7- | EPS/DAST 3 | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | IPDM E/R | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Air pressure monitor | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | All mode AWD/4WD | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | CAN gateway | x | x | | |
| INFINITI ESQ \ F15 \ 2014-7- | E-SUS | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Side radar left | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Multi display | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Side radar right | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | PTC heater | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | EMCM | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | AVM | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Head lamp levelizer | x | x | x | |
| INFINITI ESQ \ F15 \ 2014-7- | Occupant detection | | | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Engine | x | x | x | 0145, 0064, 0148, 0124, 0188, 0187, 0021, 0189, 0166, 0104, 0016, 0190, 0018, 0017, 0012, 0011, 0014, 0107, 0013, 0210, 0086, 0007, 0112, 0278, 0176, 0010, 0026, 0206, 0185, 0006, 0262, 0005, 0023, 0306, 0009, 0327, 0095, 0205, 0069, 0097, 0220 |
| INFINITI ESQ \ F15 \ 2016-2- | ABS | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI ESQ \ F15 \ 2016-2- | BCM | x | x | | |
| INFINITI ESQ \ F15 \ 2016-2- | Air bag | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | ICC/ADAS | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| INFINITI ESQ \ F15 \ 2016-2- | Transmission | x | x | x | 0113, 0076, 0059, 0083, 0100 |
| INFINITI ESQ \ F15 \ 2016-2- | Multi AV | x | x | x | 0280 |
| INFINITI ESQ \ F15 \ 2016-2- | EPS/DAST 3 | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | IPDM E/R | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Air pressure monitor | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | All mode AWD/4WD | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | CAN gateway | x | x | | |
| INFINITI ESQ \ F15 \ 2016-2- | E-SUS | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Side radar left | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Multi display | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Side radar right | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | PTC heater | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | EMCM | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|------------------------|
| INFINITI ESQ \ F15 \ 2016-2- | AVM | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Head lamp levelizer | x | x | x | |
| INFINITI ESQ \ F15 \ 2016-2- | Occupant detection | | | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Engine | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | BCM | x | x | | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Air bag | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Preocrash seatbelt | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Lane camera | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2009-11- | Sonar | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Engine | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | BCM | x | x | | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Air bag | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Multi AV | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Preocrash seatbelt | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Auto drive position | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Lane camera | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Adaptive light | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Accele pedal ACT | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Head lamp levelizer | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-2- | Sonar | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Engine | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |

| | | | | | |
|------------------------------------|---------------------|---|---|---|------------------|
| Infiniti EX25-EX35 \ J50 \ 2011-7- | BCM | x | x | | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Air bag | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Multi AV | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Lane camera | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Adaptive light | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Side radar left | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Side radar right | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Head lamp levelizer | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2011-7- | Sonar | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Engine | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | ABS | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Meter/M&A | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | BCM | x | x | | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Air bag | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti EX25-EX35 \ J50 \ 2012-4- | Sonar | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Engine | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Meter/M&A | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | BCM | x | x | | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Multi AV | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Auto drive position | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Adaptive light | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Accele pedal ACT | x | x | x | |

| | | | | | |
|------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Air bag | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Head lamp levelizer | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2012-5- | Sonar | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Engine | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Meter/M&A | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | BCM | x | x | | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Air bag | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | ICC/ADAS | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Transmission | x | x | x | 0059 |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Multi AV | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | IPDM E/R | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Precrash seatbelt | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Auto drive position | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | All mode AWD/4WD | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Adaptive light | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Accele pedal ACT | x | x | x | |
| Infiniti EX25-EX37 \ J50 \ 2013-1- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2007-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2007-12- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2007-12- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2007-12- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2007-12- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2008 | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008 | Multi AV | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2008 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008 | Rearview camera | | | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008-1- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2008-1- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008-1- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-1- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008-12- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2008-12- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008-12- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-12- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008-4- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008-4- | BCM | x | x | | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2008-4- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008-4- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-4- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008-7- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2008-7- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008-7- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-7- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2008-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2008-9- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2008-9- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2008-9- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2008-9- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2009 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2009 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2009 | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2009 | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2009 | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2009-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2009-10- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2009-10- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2009-10- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Preocrash seatbelt | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-10- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2009-11- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2009-11- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Preocrash seatbelt | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-11- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2009-2- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2009-2- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2009-2- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2009-2- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-2- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2009-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2009-9- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2009-9- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2009-9- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Preocrash seatbelt | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2009-9- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2010 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2010 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2010 | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2010 | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2010 | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2010-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2010-11- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2010-11- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Preocrash seatbelt | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2010-11- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2011 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2011 | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2011 | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Auto drive position | x | x | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Side radar left | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Side radar right | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2011 | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2011-8- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2011-8- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Side radar left | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Side radar right | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | BSW/buzzer | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-8- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2011-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2011-9- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2011-9- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2011-9- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2011-9- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Engine | x | x | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2012 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2012 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35 \ J50 \ 2012 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2012 | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2012 | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Side radar left | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Side radar right | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | BSW/buzzer | x | x | x | |
| Infiniti EX35 \ J50 \ 2012 | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2012-9- | Meter/M&A | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2012-9- | Air bag | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2012-9- | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Side radar left | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Side radar right | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Head lamp levelizer | x | x | x | |
| Infiniti EX35 \ J50 \ 2012-9- | Sonar | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Engine | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35 \ J50 \ 2013 | Meter/M&A | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | BCM | x | x | | |
| Infiniti EX35 \ J50 \ 2013 | Air bag | | x | x | |
| Infiniti EX35 \ J50 \ 2013 | ICC/ADAS | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35 \ J50 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti EX35 \ J50 \ 2013 | Multi AV | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Auto drive position | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | All mode AWD/4WD | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Lane camera | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Adaptive light | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | CAN gateway | x | x | | |
| Infiniti EX35 \ J50 \ 2013 | Accele pedal ACT | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Side radar left | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Side radar right | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | BSW/buzzer | x | x | x | |
| Infiniti EX35 \ J50 \ 2013 | Sonar | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Engine | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | BCM | x | x | | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Air bag | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | ICC/ADAS | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Transmission | x | x | x | 0059 |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Multi AV | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | IPDM E/R | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Precrash seatbelt | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Auto drive position | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Lane camera | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Adaptive light | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Accele pedal ACT | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2009-6- | Sonar | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Engine | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | BCM | x | x | | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Air bag | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | ICC/ADAS | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Precrash seatbelt | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|--|
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Lane camera | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2010-11- | Sonar | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Engine | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | BCM | x | x | | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Air bag | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Precrash seatbelt | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Lane camera | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2011-8- | Sonar | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Engine | x | x | x | 0172, 0127, 0109, 0206, 0193, 0095, 0340, 0300 |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Meter/M&A | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | BCM | x | x | | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Precrash seatbelt | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Lane camera | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Accele pedal ACT | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Air bag | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2012-10- | Sonar | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Engine | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|--------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | BCM | x | x | | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Air bag | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | ICC/ADAS | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Transmission | x | x | x | 0059 |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Multi AV | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | IPDM E/R | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Precrash seatbelt | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Auto drive position | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Lane camera | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Adaptive light | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Accele pedal ACT | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Head lamp levelizer | x | x | x | |
| Infiniti EX35(DOM) \ J50 \ 2013-8- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Multi AV | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Precrash seatbelt | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Auto drive position | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Lane camera | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2009-7- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Multi AV | x | x | x | |

| | | | | | |
|--------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35-EX30d \ J50 \ 2010-10- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Precrash seatbelt | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Auto drive position | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Lane camera | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Side radar left | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Side radar right | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2010-10- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Lane camera | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Side radar left | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Side radar right | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-1- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Multi AV | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Auto drive position | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti EX35-EX30d \ J50 \ 2011-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Lane camera | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Side radar left | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Side radar right | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | BSW/buzzer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-11- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Lane camera | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Side radar left | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Side radar right | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | BSW/buzzer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Sonar | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Meter/M&A | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2011-8- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Engine | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Meter/M&A | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | BCM | x | x | | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Multi AV | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Air pressure monitor | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Auto drive position | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Lane camera | x | x | x | |

| | | | | | |
|--------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Adaptive light | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Side radar left | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Side radar right | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | BSW/buzzer | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Air bag | x | x | x | |
| Infiniti EX35-EX30d \ J50 \ 2012-11- | Sonar | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Engine | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | BCM | x | x | | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Air bag | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Lane camera | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Sonar | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Side radar left | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-1- | Side radar right | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Engine | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | BCM | x | x | | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Air bag | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Lane camera | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Head lamp levelizer | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti EX35-EX37 \ J50 \ 2011-10- | Sonar | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Engine | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Meter/M&A | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | BCM | x | x | | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Air bag | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Preocrash seatbelt | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | All mode AWD/4WD | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Lane camera | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Adaptive light | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Accele pedal ACT | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Side radar left | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Side radar right | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Head lamp levelizer | x | x | x | |
| Infiniti EX35-EX37 \ J50 \ 2012-12- | Sonar | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Engine | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX37 \ J50 \ 2008-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX37 \ J50 \ 2008-6- | BCM | x | x | | |
| Infiniti EX37 \ J50 \ 2008-6- | ICC/ADAS | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Transmission | x | x | x | 0059 |
| Infiniti EX37 \ J50 \ 2008-6- | Multi AV | x | x | x | 0280 |
| Infiniti EX37 \ J50 \ 2008-6- | IPDM E/R | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Air pressure monitor | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Auto drive position | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | All mode AWD/4WD | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Adaptive light | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Air bag | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Head lamp levelizer | x | x | x | |
| Infiniti EX37 \ J50 \ 2008-6- | Sonar | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Engine | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX37 \ J50 \ 2009-2- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti EX37 \ J50 \ 2009-2- | BCM | x | x | | |
| Infiniti EX37 \ J50 \ 2009-2- | ICC/ADAS | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------|
| Infiniti EX37 \ J50 \ 2009-2- | Transmission | x | x | x | 0059 |
| Infiniti EX37 \ J50 \ 2009-2- | Multi AV | x | x | x | 0280 |
| Infiniti EX37 \ J50 \ 2009-2- | IPDM E/R | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Air pressure monitor | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Auto drive position | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | All mode AWD/4WD | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Adaptive light | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Air bag | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Head lamp levelizer | x | x | x | |
| Infiniti EX37 \ J50 \ 2009-2- | Sonar | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Engine | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX37 \ J50 \ 2012-1- | Meter/M&A | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | BCM | x | x | | |
| Infiniti EX37 \ J50 \ 2012-1- | Transmission | x | x | x | 0059 |
| Infiniti EX37 \ J50 \ 2012-1- | Multi AV | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | IPDM E/R | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Auto drive position | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | All mode AWD/4WD | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Adaptive light | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Accele pedal ACT | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Telematics | x | x | x | 0253 |
| Infiniti EX37 \ J50 \ 2012-1- | Air bag | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Head lamp levelizer | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-1- | Sonar | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Engine | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX37 \ J50 \ 2012-11- | Meter/M&A | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | BCM | x | x | | |
| Infiniti EX37 \ J50 \ 2012-11- | Transmission | x | x | x | 0059 |
| Infiniti EX37 \ J50 \ 2012-11- | Multi AV | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | IPDM E/R | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Auto drive position | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | All mode AWD/4WD | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Lane camera | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Adaptive light | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Accele pedal ACT | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Side radar left | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Side radar right | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-11- | Air bag | x | x | x | |

| | | | | | |
|---------------------------------|----------------------|---|---|---|--|
| Infiniti EX37 \ J50 \ 2012-11- | Sonar | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Engine | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti EX37 \ J50 \ 2012-12- | Meter/M&A | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | BCM | x | x | | |
| Infiniti EX37 \ J50 \ 2012-12- | Air bag | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti EX37 \ J50 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Precrash seatbelt | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | All mode AWD/4WD | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Lane camera | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Adaptive light | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Accele pedal ACT | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Side radar left | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Side radar right | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Head lamp levelizer | x | x | x | |
| Infiniti EX37 \ J50 \ 2012-12- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2003 | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2003 | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Sonar | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2003 | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2003 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Rearview camera | | | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2003-6- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2003-6- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2004 | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2004 | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2004 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | HVAC | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2004-3- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2005 | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2005 | DIU | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2005 | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Head lamp levelizer | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-1- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-3- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2005-8- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2006 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2006 | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2006 | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | IPDM E/R | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2006 | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-11- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Air levelizer | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Rearview camera | | | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | S/blind camera | | | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-2- | Motor assist | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Meter/M&A | × | × | × | 0143, 0331 |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | BCM | × | × | | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Transmission | × | × | × | 0059 |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | IPDM E/R | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Intelligent key | × | × | × | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Auto drive position | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Engine | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | ABS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Air bag | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Head lamp levelizer | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | All mode AWD/4WD | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-7- | Rearview camera | | | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Engine | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | ABS | × | × | × | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Meter/M&A | × | × | × | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | BCM | × | × | | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Air bag | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | ICC/ADAS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | HVAC | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Transmission | × | × | × | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Multi AV | × | × | × | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | EPS/DAST 3 | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | IPDM E/R | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Air pressure monitor | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Intelligent key | × | × | × | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | DIU | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Auto slide door | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Auto drive position | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | All mode AWD/4WD | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | 4WAS(MAIN)/RAS/HICAS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Sonar | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Lane camera | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Adaptive light | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | AVM | × | × | × | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2006-9- | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2007 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2007 | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | HVAC | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX45 \ S50 \ 2007 | Multi AV | x | x | x | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2007 | EPS/DAST 3 | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2007 | DIU | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Auto slide door | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Sonar | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Lane camera | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Adaptive light | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2007 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Engine | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | ABS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-11- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | ABS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-4- | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | BCM | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Auto drive position | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | ABS | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Air bag | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Sonar | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti FX35-FX45 \ S50 \ 2007-6- | Rearview camera | | | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Engine | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Meter/M&A | × | × | × | 0143, 0331 |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | BCM | × | × | | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Transmission | × | × | × | 0059 |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | IPDM E/R | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Intelligent key | × | × | × | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Auto drive position | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | ABS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Air bag | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Head lamp levelizer | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | All mode AWD/4WD | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Sonar | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2007-7- | Rearview camera | | | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Engine | × | × | × | 0108, 0114, 0279, 0071, 0289, 0288, 0093, 0233, 0103, 0234, 0163, 0262, 0324, 0274, 0329, 0144, 0216, 0328 |
| Infiniti FX35-FX45 \ S50 \ 2008 | ABS | × | × | × | 0003, 0092, 0264 |
| Infiniti FX35-FX45 \ S50 \ 2008 | Meter/M&A | × | × | × | 0331, 0143 |
| Infiniti FX35-FX45 \ S50 \ 2008 | BCM | × | × | | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Air bag | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | ICC/ADAS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | HVAC | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Transmission | × | × | × | 0113, 0076, 0059, 0083, 0100 |
| Infiniti FX35-FX45 \ S50 \ 2008 | Multi AV | × | × | × | 0280 |
| Infiniti FX35-FX45 \ S50 \ 2008 | EPS/DAST 3 | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | IPDM E/R | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Air pressure monitor | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Intelligent key | × | × | × | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti FX35-FX45 \ S50 \ 2008 | DIU | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Auto slide door | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Auto drive position | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | All mode AWD/4WD | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | 4WAS(MAIN)/RAS/HICAS | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Sonar | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Lane camera | × | × | × | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Adaptive light | × | × | × | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------------------|
| Infiniti FX35-FX45 \ S50 \ 2008 | AVM | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Difference lock | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Nats immu | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Smart entrance | x | x | | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Air levelizer | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Rearview camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | S/blind camera | | | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Motor assist | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Engine | x | x | x | |
| Infiniti FX35-FX45 \ S50 \ 2008 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-11- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Air pressure monitor | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2008-5- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2009 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2009 | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2009 | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Preocrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009 | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009 | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Air bag | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2009-11- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-11- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Sonar | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2009-9- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2010 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2010 | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2010 | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010 | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010 | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2010-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-11- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Preocrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-12- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Air bag | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2010-3- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2010-3- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2011 | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011 | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Head lamp levelizer | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2011 | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011 | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-1- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2011-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-10- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-12- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Multi AV | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2011-4- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-4- | Rearview camera | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-7- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX35-FX50 \ S51 \ 2011-9- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Preocrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2011-9- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2012 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX35-FX50 \ S51 \ 2012 | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2012 | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Preocrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012 | Occupant detection | | | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------|
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | AVM | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-11- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Auto back door | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------|
| Infiniti FX35-FX50 \ S51 \ 2012-5- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | AVM | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-5- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | AVM | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-6- | Occupant detection | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Engine | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | BCM | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Air bag | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | ICC/ADAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Multi AV | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | IPDM E/R | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------|
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Precrash seatbelt | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Sonar | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Lane camera | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Adaptive light | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | CAN gateway | x | x | | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Auto back door | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | E-SUS | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Telematics | x | x | x | 0253 |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | AVM | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Total illum C/U | | | x | |
| Infiniti FX35-FX50 \ S51 \ 2012-8- | Occupant detection | | | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Engine | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Meter/M&A | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | BCM | x | x | | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Transmission | x | x | x | 0059 |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Multi AV | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | IPDM E/R | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Air pressure monitor | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Auto drive position | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | All mode AWD/4WD | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | CAN gateway | x | x | | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Auto back door | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | E-SUS | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Accele pedal ACT | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | AVM | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Air bag | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Head lamp levelizer | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Sonar | x | x | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Total illum C/U | | | x | |
| Infiniti FX35-FX50-FX30d \ S51 \ 2011-9- | Occupant detection | | | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Engine | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------|
| Infiniti FX37 \ S51 \ 2012-1- | Meter/M&A | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | BCM | x | x | | |
| Infiniti FX37 \ S51 \ 2012-1- | Transmission | x | x | x | 0059 |
| Infiniti FX37 \ S51 \ 2012-1- | Multi AV | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | IPDM E/R | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Air pressure monitor | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Auto drive position | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Adaptive light | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | CAN gateway | x | x | | |
| Infiniti FX37 \ S51 \ 2012-1- | Auto back door | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | E-SUS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | AVM | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Air bag | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Head lamp levelizer | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Sonar | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-1- | Total illum C/U | | | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Engine | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37 \ S51 \ 2012-10- | Meter/M&A | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | BCM | x | x | | |
| Infiniti FX37 \ S51 \ 2012-10- | Air bag | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti FX37 \ S51 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Air pressure monitor | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Precrash seatbelt | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Sonar | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Lane camera | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | CAN gateway | x | x | | |
| Infiniti FX37 \ S51 \ 2012-10- | Auto back door | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | E-SUS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Accele pedal ACT | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | AVM | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-10- | Total illum C/U | | | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------|
| Infiniti FX37 \ S51 \ 2012-10- | Occupant detection | | | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Engine | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | ABS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Meter/M&A | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | BCM | x | x | | |
| Infiniti FX37 \ S51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti FX37 \ S51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti FX37 \ S51 \ 2012-6- | Auto back door | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | E-SUS | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | AVM | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti FX37 \ S51 \ 2012-6- | Total illum C/U | | | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Engine | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37 \ S51 \ 2013-4- | Meter/M&A | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | BCM | x | x | | |
| Infiniti FX37 \ S51 \ 2013-4- | Air bag | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | ICC/ADAS | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Transmission | x | x | x | 0059 |
| Infiniti FX37 \ S51 \ 2013-4- | Multi AV | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | IPDM E/R | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Air pressure monitor | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Preocrash seatbelt | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Auto drive position | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Sonar | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Lane camera | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Adaptive light | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | CAN gateway | x | x | | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti FX37 \ S51 \ 2013-4- | Auto back door | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | E-SUS | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Accele pedal ACT | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | AVM | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Head lamp levelizer | x | x | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Total illum C/U | | | x | |
| Infiniti FX37 \ S51 \ 2013-4- | Occupant detection | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Engine | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | BCM | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Multi AV | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | CAN gateway | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | E-SUS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Air bag | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Sonar | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Total illum C/U | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2008-7- | Occupant detection | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Engine | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | BCM | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Multi AV | x | x | x | 0280 |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Adaptive light | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------|
| Infiniti FX37-FX50 \ S51 \ 2009-3- | CAN gateway | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | E-SUS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Air bag | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Sonar | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2009-3- | Total illum C/U | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Engine | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | BCM | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Lane camera | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | CAN gateway | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Auto back door | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | E-SUS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | AVM | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Air bag | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Sonar | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2012-12- | Total illum C/U | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Engine | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50 \ S51 \ 2013 | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | BCM | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Air bag | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50 \ S51 \ 2013 | Multi AV | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Preocrash seatbelt | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Auto drive position | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | All mode AWD/4WD | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti FX37-FX50 \ S51 \ 2013 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Sonar | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Lane camera | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Adaptive light | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | CAN gateway | x | x | | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Auto back door | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | E-SUS | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | AVM | x | x | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Total illum C/U | | | x | |
| Infiniti FX37-FX50 \ S51 \ 2013 | Occupant detection | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Multi AV | x | x | x | 0280 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Lane camera | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Total illum C/U | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2009-7- | Rearview camera | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Multi AV | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Lane camera | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Auto back door | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Total illum C/U | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Occupant detection | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Precrash seatbelt | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2010-12- | Rearview camera | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Multi AV | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Auto back door | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | AVM | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Total illum C/U | | | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-12- | Occupant detection | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Multi AV | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Lane camera | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Auto back door | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Total illum C/U | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2011-9- | Occupant detection | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Multi AV | x | x | x | 0280 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Preocrash seatbelt | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Lane camera | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------------|
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Auto back door | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | AVM | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Total illum C/U | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-10- | Occupant detection | | | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Engine | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Meter/M&A | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | BCM | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Auto back door | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | E-SUS | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | AVM | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti FX37-FX50-FX30d \ S51 \ 2012-6- | Total illum C/U | | | x | |
| Infiniti G20 \ CA33 \ 2002 | Engine | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ CA33 \ 2002 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ CA33 \ 2002 | BCM | x | x | | |
| Infiniti G20 \ CA33 \ 2002 | Air bag | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | HVAC | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti G20 \ CA33 \ 2002 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ CA33 \ 2002 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | IPDM E/R | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ CA33 \ 2002 | DIU | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Auto slide door | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Auto drive position | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Sonar | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Lane camera | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Adaptive light | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | AVM | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Difference lock | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Nats immu | x | x | | |
| Infiniti G20 \ CA33 \ 2002 | Smart entrance | x | x | | |
| Infiniti G20 \ CA33 \ 2002 | Air levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2002 | Rearview camera | | | x | |
| Infiniti G20 \ CA33 \ 2002 | S/blind camera | | | x | |
| Infiniti G20 \ CA33 \ 2002 | Motor assist | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Engine | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ CA33 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ CA33 \ 2003 | BCM | x | x | | |
| Infiniti G20 \ CA33 \ 2003 | Air bag | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | HVAC | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ CA33 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ CA33 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ CA33 \ 2003 | DIU | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Auto slide door | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti G20 \ CA33 \ 2003 | Auto drive position | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Sonar | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Lane camera | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Adaptive light | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | AVM | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Difference lock | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Nats immu | x | x | | |
| Infiniti G20 \ CA33 \ 2003 | Smart entrance | x | x | | |
| Infiniti G20 \ CA33 \ 2003 | Air levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2003 | Rearview camera | | | x | |
| Infiniti G20 \ CA33 \ 2003 | S/blind camera | | | x | |
| Infiniti G20 \ CA33 \ 2003 | Motor assist | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Engine | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ CA33 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ CA33 \ 2004 | BCM | x | x | | |
| Infiniti G20 \ CA33 \ 2004 | Air bag | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | HVAC | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ CA33 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ CA33 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ CA33 \ 2004 | DIU | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Auto slide door | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Auto drive position | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Sonar | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Lane camera | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Adaptive light | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | AVM | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Difference lock | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti G20 \ CA33 \ 2004 | Nats immu | x | x | | |
| Infiniti G20 \ CA33 \ 2004 | Smart entrance | x | x | | |
| Infiniti G20 \ CA33 \ 2004 | Air levelizer | x | x | x | |
| Infiniti G20 \ CA33 \ 2004 | Rearview camera | | | x | |
| Infiniti G20 \ CA33 \ 2004 | S/blind camera | | | x | |
| Infiniti G20 \ CA33 \ 2004 | Motor assist | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Engine | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ P11 \ 1999 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ P11 \ 1999 | BCM | x | x | | |
| Infiniti G20 \ P11 \ 1999 | Air bag | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | HVAC | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ P11 \ 1999 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ P11 \ 1999 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | IPDM E/R | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ P11 \ 1999 | DIU | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Auto slide door | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Auto drive position | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Sonar | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Lane camera | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Adaptive light | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | AVM | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Difference lock | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Nats immu | x | x | | |
| Infiniti G20 \ P11 \ 1999 | Smart entrance | x | x | | |
| Infiniti G20 \ P11 \ 1999 | Air levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 1999 | Rearview camera | | | x | |
| Infiniti G20 \ P11 \ 1999 | S/blind camera | | | x | |
| Infiniti G20 \ P11 \ 1999 | Motor assist | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Engine | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ P11 \ 2000 | Meter/M&A | x | x | x | 0331, 0143 |

| | | | | | |
|---------------------------|----------------------|---|---|---|--|
| Infiniti G20 \ P11 \ 2000 | BCM | x | x | | |
| Infiniti G20 \ P11 \ 2000 | Air bag | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | HVAC | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ P11 \ 2000 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ P11 \ 2000 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | IPDM E/R | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ P11 \ 2000 | DIU | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Auto slide door | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Auto drive position | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Sonar | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Lane camera | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Adaptive light | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | AVM | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Difference lock | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Nats immu | x | x | | |
| Infiniti G20 \ P11 \ 2000 | Smart entrance | x | x | | |
| Infiniti G20 \ P11 \ 2000 | Air levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2000 | Rearview camera | | | x | |
| Infiniti G20 \ P11 \ 2000 | S/blind camera | | | x | |
| Infiniti G20 \ P11 \ 2000 | Motor assist | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Engine | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ P11 \ 2001 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ P11 \ 2001 | BCM | x | x | | |
| Infiniti G20 \ P11 \ 2001 | Air bag | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | HVAC | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ P11 \ 2001 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ P11 \ 2001 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | IPDM E/R | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Air pressure monitor | x | x | x | |

| | | | | | |
|---------------------------|----------------------|---|---|---|--|
| Infiniti G20 \ P11 \ 2001 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ P11 \ 2001 | DIU | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Auto slide door | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Auto drive position | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Sonar | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Lane camera | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Adaptive light | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | AVM | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Difference lock | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Nats immu | x | x | | |
| Infiniti G20 \ P11 \ 2001 | Smart entrance | x | x | | |
| Infiniti G20 \ P11 \ 2001 | Air levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2001 | Rearview camera | | | x | |
| Infiniti G20 \ P11 \ 2001 | S/blind camera | | | x | |
| Infiniti G20 \ P11 \ 2001 | Motor assist | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Engine | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G20 \ P11 \ 2002 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G20 \ P11 \ 2002 | BCM | x | x | | |
| Infiniti G20 \ P11 \ 2002 | Air bag | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | ICC/ADAS | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | HVAC | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G20 \ P11 \ 2002 | Multi AV | x | x | x | 0280 |
| Infiniti G20 \ P11 \ 2002 | EPS/DAST 3 | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | IPDM E/R | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Air pressure monitor | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G20 \ P11 \ 2002 | DIU | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Auto slide door | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Auto drive position | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | All mode AWD/4WD | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Sonar | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti G20 \ P11 \ 2002 | Lane camera | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Adaptive light | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | AVM | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Head lamp levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Difference lock | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Nats immu | x | x | | |
| Infiniti G20 \ P11 \ 2002 | Smart entrance | x | x | | |
| Infiniti G20 \ P11 \ 2002 | Air levelizer | x | x | x | |
| Infiniti G20 \ P11 \ 2002 | Rearview camera | | | x | |
| Infiniti G20 \ P11 \ 2002 | S/blind camera | | | x | |
| Infiniti G20 \ P11 \ 2002 | Motor assist | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2009-11- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Precrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Head lamp levelizer | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------|
| Infiniti G25-G37 Sedan \ V36 \ 2010-11- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Preocrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2010-12- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Preocrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011 | Pop up hood | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | ICC/ADAS | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------|
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-1- | Pop up hood | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Accele pedal ACT | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-10- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Precrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Air bag | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-6- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | 4WAS(front) | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2011-8- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Preocrash seatbelt | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012 | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Meter/M&A | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Auto drive position | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------------|
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-10- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-4- | Sonar | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Engine | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Meter/M&A | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | BCM | x | x | | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Transmission | x | x | x | 0059 |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Multi AV | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | IPDM E/R | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Auto drive position | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | All mode AWD/4WD | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Adaptive light | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | ABS | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Air bag | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Head lamp levelizer | x | x | x | |
| Infiniti G25-G37 Sedan \ V36 \ 2012-7- | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2003 | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |

| | | | | | |
|----------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2003 | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2003 | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2004 | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2004 | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Auto slide door | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2004 | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2004 | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2005 | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2005 | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Difference lock | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2005 | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005 | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-1- | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Meter/M&A | x | x | x | 0331, 0143 |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2005-4- | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-4- | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Air pressure monitor | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-5- | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Sonar | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2005-8- | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2006 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2006 | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2006 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2006 | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Rearview camera | | | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2006 | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2006 | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | HVAC | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2006-7- | Motor assist | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Engine | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 Coupe \ CV35 \ 2007 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 Coupe \ CV35 \ 2007 | BCM | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Air bag | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | ICC/ADAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | HVAC | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|--|
| Infiniti G35 Coupe \ CV35 \ 2007 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 Coupe \ CV35 \ 2007 | Multi AV | x | x | x | 0280 |
| Infiniti G35 Coupe \ CV35 \ 2007 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | IPDM E/R | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Air pressure monitor | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 Coupe \ CV35 \ 2007 | DIU | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Auto slide door | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Auto drive position | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Sonar | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Lane camera | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Adaptive light | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | AVM | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Head lamp levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Difference lock | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Nats immu | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Smart entrance | x | x | | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Air levelizer | x | x | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Rearview camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | S/blind camera | | | x | |
| Infiniti G35 Coupe \ CV35 \ 2007 | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2003 | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2003 | DIU | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2003 | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003 | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003 | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003 | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003 | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2003-1- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2003-1- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2003-1- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2003-1- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2003-1- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Head lamp levelizer | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2003-1- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003-1- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2003-10- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2003-10- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2003-10- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2003-10- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2003-10- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2003-10- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2004 | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2004 | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004 | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004 | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2004 | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2004 | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2004-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2004-8- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2004-8- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2004-8- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | IPDM E/R | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2004-8- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2004-8- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2004-8- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2005 | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2005 | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2005 | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005 | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005 | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005 | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005 | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2005-1- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2005-1- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2005-1- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2005-1- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2005-1- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Air levelizer | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2005-1- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-1- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2005-5- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2005-5- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2005-5- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2005-5- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2005-5- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-5- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2005-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2005-8- | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | ICC/ADAS | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|--|
| Infiniti G35 sedan \ V35 \ 2005-8- | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2005-8- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2005-8- | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti G35 sedan \ V35 \ 2005-8- | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2005-8- | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Engine | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G35 sedan \ V35 \ 2006 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti G35 sedan \ V35 \ 2006 | BCM | x | x | | |
| Infiniti G35 sedan \ V35 \ 2006 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | HVAC | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti G35 sedan \ V35 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V35 \ 2006 | EPS/DAST 3 | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G35 sedan \ V35 \ 2006 | DIU | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Auto slide door | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Sonar | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Lane camera | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | AVM | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Difference lock | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Nats immu | x | x | | |
| Infiniti G35 sedan \ V35 \ 2006 | Smart entrance | x | x | | |
| Infiniti G35 sedan \ V35 \ 2006 | Air levelizer | x | x | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Rearview camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2006 | S/blind camera | | | x | |
| Infiniti G35 sedan \ V35 \ 2006 | Motor assist | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2006-12- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2006-12- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti G35 sedan \ V36 \ 2006-7- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2006-7- | Multi AV | x | x | x | 0280 |
| Infiniti G35 sedan \ V36 \ 2006-7- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Intelligent key | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Precrash seatbelt | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Engine | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G35 sedan \ V36 \ 2006-7- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-7- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2006-8- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2006-8- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2006-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2007 | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2007 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2007 | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | 4WAS(front) | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2007-10- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2007-10- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Head lamp levelizer | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti G35 sedan \ V36 \ 2007-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-10- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2007-12- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2007-12- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-12- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2007-5- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2007-5- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-5- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2007-7- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2007-7- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | Head lamp levelizer | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2007-7- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G35 sedan \ V36 \ 2007-7- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G35 sedan \ V36 \ 2008 | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2008 | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2008 | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Precrash seatbelt | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | 4WAS(front) | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008 | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti G35 sedan \ V36 \ 2008-1- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2008-1- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | IPDM E/R | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Intelligent key | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Precrash seatbelt | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-1- | Rearview camera | | | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Engine | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti G35 sedan \ V36 \ 2008-8- | BCM | x | x | | |
| Infiniti G35 sedan \ V36 \ 2008-8- | ICC/ADAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Transmission | x | x | x | 0059 |
| Infiniti G35 sedan \ V36 \ 2008-8- | Multi AV | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | IPDM E/R | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------------|
| Infiniti G35 sedan \ V36 \ 2008-8- | Air pressure monitor | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Intelligent key | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Precrash seatbelt | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Auto drive position | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Adaptive light | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | ABS | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Air bag | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Sonar | x | x | x | |
| Infiniti G35 sedan \ V36 \ 2008-8- | Rearview camera | | | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2009 | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2009 | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2009 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | 4WAS(front) | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009 | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-11- | Sonar | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-2- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-5- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Adaptive light | x | x | x | |

| | | | | | |
|---|---------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2009-6- | 4WAS(front) | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2009-6- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G37 Convertible \ HV36 \ 2010 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2010 | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2010 | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2010 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010 | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-1- | ABS | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-11- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2010-12- | Meter/M&A | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2011 | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Transmission | x | x | x | 0059 |

| | | | | | |
|--|----------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2011 | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2011 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | 4WAS(front) | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011 | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | IPDM E/R | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-10- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Engine | x | x | x | 0095, 0109, 0172, 0206, 0340 |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-12- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2011-8- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2012 | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | ICC/ADAS | x | x | x | |

| | | | | | |
|--|---------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012 | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012 | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Meter/M&A | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-1- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-10- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Engine | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-12- | Pop up hood | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Meter/M&A | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-3- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | ABS | x | x | x | |

| | | | | | |
|---|---------------------|---|---|---|------------------------------|
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-4- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Meter/M&A | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2012-8- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Meter/M&A | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2013 | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2013 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Adaptive light | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013 | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Engine | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | BCM | x | x | | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Air bag | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Multi AV | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Auto drive position | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Adaptive light | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------|
| Infiniti G37 Convertible \ HV36 \ 2013-1- | ABS | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Sonar | x | x | x | |
| Infiniti G37 Convertible \ HV36 \ 2013-1- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-11- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-6- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2007-7- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-10- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | BCM | x | x | | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2008-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-12- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-5- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | ABS | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-6- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2008-8- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2009 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2009 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | IPDM E/R | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2009-11- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2010 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2010 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010 | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Sonar | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-1- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-11- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2010-12- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2011 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2011 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | IPDM E/R | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2011 | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011 | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | ABS | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-10- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2011-8- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012 | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | IPDM E/R | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Coupe \ CV36 \ 2012-1- | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-10- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Preocrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Adaptive light | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2012-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Meter/M&A | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-3- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Meter/M&A | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-4- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Transmission | x | x | x | 0059 |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-7- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2012-8- | Pop up hood | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Meter/M&A | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2013 | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Adaptive light | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Coupe \ CV36 \ 2013 | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013 | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Engine | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | BCM | x | x | | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Air bag | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Multi AV | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Auto drive position | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Adaptive light | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | ABS | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Sonar | x | x | x | |
| Infiniti G37 Coupe \ CV36 \ 2013-1- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2008-10- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-10- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2008-12- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Transmission | x | x | x | 0059 |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Sedan \ V36 \ 2008-12- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Sedan \ V36 \ 2008-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-12- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2008-7- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Sedan \ V36 \ 2008-7- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-7- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2008-8- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | 4WAS(front) | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti G37 Sedan \ V36 \ 2008-8- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2008-8- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2009 | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2009 | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2009 | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Sedan \ V36 \ 2009 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009 | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2009-11- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2009-11- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2010 | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2010 | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | ICC/ADAS | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti G37 Sedan \ V36 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2010 | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti G37 Sedan \ V36 \ 2010 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010 | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2010-1- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Multi AV | x | x | x | 0280 |
| Infiniti G37 Sedan \ V36 \ 2010-1- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-1- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Adaptive light | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti G37 Sedan \ V36 \ 2010-11- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-11- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2010-12- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2010-12- | Precrash seatbelt | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti G37 Sedan \ V36 \ 2011-10- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2011-10- | Pop up hood | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------|
| Infiniti G37 Sedan \ V36 \ 2012-3- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Meter/M&A | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-3- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Meter/M&A | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Transmission | x | x | x | 0059 |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Laser/radar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | 4WAS(front) | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Head lamp levelizer | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Sonar | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2012-9- | Pop up hood | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Engine | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Meter/M&A | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | BCM | x | x | | |
| Infiniti G37 Sedan \ V36 \ 2013 | Air bag | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Transmission | x | x | x | 0059 |

| | | | | | |
|---------------------------------|----------------------|---|---|---|--|
| Infiniti G37 Sedan \ V36 \ 2013 | Multi AV | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Precrash seatbelt | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Auto drive position | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | All mode AWD/4WD | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Adaptive light | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | ABS | x | x | x | |
| Infiniti G37 Sedan \ V36 \ 2013 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Engine | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 1996 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 1996 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 1996 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 1996 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 1996 | EPS/DAST 3 | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 1996 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | All mode AWD/4WD | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 1996 | Smart entrance | x | x | | |
| Infiniti I30 \ CA32 \ 1996 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1996 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 1996 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 1996 | Motor assist | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Engine | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I30 \ CA32 \ 1997 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 1997 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 1997 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 1997 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 1997 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 1997 | EPS/DAST 3 | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 1997 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | All mode AWD/4WD | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 1997 | Smart entrance | x | x | | |
| Infiniti I30 \ CA32 \ 1997 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1997 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 1997 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 1997 | Motor assist | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Engine | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 1998 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 1998 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 1998 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 1998 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 1998 | EPS/DAST 3 | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I30 \ CA32 \ 1998 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 1998 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | All mode AWD/4WD | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 1998 | Smart entrance | x | x | | |
| Infiniti I30 \ CA32 \ 1998 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1998 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 1998 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 1998 | Motor assist | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Engine | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 1999 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 1999 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 1999 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 1999 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 1999 | EPS/DAST 3 | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 1999 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | All mode AWD/4WD | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I30 \ CA32 \ 1999 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 1999 | Smart entrance | x | x | | |
| Infiniti I30 \ CA32 \ 1999 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 1999 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 1999 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 1999 | Motor assist | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Engine | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 2000 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 2000 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 2000 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 2000 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 2000 | EPS/DAST 3 | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 2000 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | All mode AWD/4WD | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 2000 | Smart entrance | x | x | | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I30 \ CA32 \ 2000 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 2000 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 2000 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 2000 | Motor assist | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Engine | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I30 \ CA32 \ 2001 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I30 \ CA32 \ 2001 | BCM | x | x | | |
| Infiniti I30 \ CA32 \ 2001 | Air bag | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | ICC/ADAS | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | HVAC | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I30 \ CA32 \ 2001 | Multi AV | x | x | x | 0280 |
| Infiniti I30 \ CA32 \ 2001 | EPS/DAST 3 | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | IPDM E/R | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Air pressure monitor | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I30 \ CA32 \ 2001 | DIU | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Auto slide door | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Auto drive position | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | All mode AWD/4WD | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Sonar | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Lane camera | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Adaptive light | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | AVM | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Head lamp levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Difference lock | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Nats immu | x | x | | |
| Infiniti I30 \ CA32 \ 2001 | Smart entrance | x | x | | |
| Infiniti I30 \ CA32 \ 2001 | Air levelizer | x | x | x | |
| Infiniti I30 \ CA32 \ 2001 | Rearview camera | | | x | |
| Infiniti I30 \ CA32 \ 2001 | S/blind camera | | | x | |
| Infiniti I30 \ CA32 \ 2001 | Motor assist | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Engine | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I35 \ CA33 \ 2002 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I35 \ CA33 \ 2002 | BCM | x | x | | |
| Infiniti I35 \ CA33 \ 2002 | Air bag | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I35 \ CA33 \ 2002 | ICC/ADAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | HVAC | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I35 \ CA33 \ 2002 | Multi AV | x | x | x | 0280 |
| Infiniti I35 \ CA33 \ 2002 | EPS/DAST 3 | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | IPDM E/R | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Air pressure monitor | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I35 \ CA33 \ 2002 | DIU | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Auto slide door | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Auto drive position | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | All mode AWD/4WD | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Sonar | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Lane camera | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Adaptive light | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | AVM | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Head lamp levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Difference lock | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Nats immu | x | x | | |
| Infiniti I35 \ CA33 \ 2002 | Smart entrance | x | x | | |
| Infiniti I35 \ CA33 \ 2002 | Air levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2002 | Rearview camera | | | x | |
| Infiniti I35 \ CA33 \ 2002 | S/blind camera | | | x | |
| Infiniti I35 \ CA33 \ 2002 | Motor assist | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Engine | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I35 \ CA33 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I35 \ CA33 \ 2003 | BCM | x | x | | |
| Infiniti I35 \ CA33 \ 2003 | Air bag | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | HVAC | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I35 \ CA33 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti I35 \ CA33 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Air pressure monitor | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti I35 \ CA33 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I35 \ CA33 \ 2003 | DIU | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Auto slide door | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Auto drive position | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Sonar | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Lane camera | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Adaptive light | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | AVM | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Difference lock | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Nats immu | x | x | | |
| Infiniti I35 \ CA33 \ 2003 | Smart entrance | x | x | | |
| Infiniti I35 \ CA33 \ 2003 | Air levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2003 | Rearview camera | | | x | |
| Infiniti I35 \ CA33 \ 2003 | S/blind camera | | | x | |
| Infiniti I35 \ CA33 \ 2003 | Motor assist | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Engine | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti I35 \ CA33 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti I35 \ CA33 \ 2004 | BCM | x | x | | |
| Infiniti I35 \ CA33 \ 2004 | Air bag | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | HVAC | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti I35 \ CA33 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti I35 \ CA33 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti I35 \ CA33 \ 2004 | DIU | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Auto slide door | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Auto drive position | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Sonar | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti I35 \ CA33 \ 2004 | Lane camera | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Adaptive light | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | AVM | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Difference lock | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Nats immu | x | x | | |
| Infiniti I35 \ CA33 \ 2004 | Smart entrance | x | x | | |
| Infiniti I35 \ CA33 \ 2004 | Air levelizer | x | x | x | |
| Infiniti I35 \ CA33 \ 2004 | Rearview camera | | | x | |
| Infiniti I35 \ CA33 \ 2004 | S/blind camera | | | x | |
| Infiniti I35 \ CA33 \ 2004 | Motor assist | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2012-10- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2012-10- | Air bag | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Transmission | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2012-10- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-10- | Occupant detection | | | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2012-11- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2012-11- | Air bag | | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti JX35 \ L50 \ 2012-11- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Transmission | x | x | x | 0059, 0118 |
| Infiniti JX35 \ L50 \ 2012-11- | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2012-11- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-11- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2012-5- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2012-5- | Air bag | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Transmission | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2012-5- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | AVM | x | x | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti JX35 \ L50 \ 2012-5- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-5- | Occupant detection | | | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2012-8- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2012-8- | Air bag | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Transmission | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2012-8- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Telematics | x | x | x | 0253 |
| Infiniti JX35 \ L50 \ 2012-8- | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-8- | Occupant detection | | | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2012-9- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2012-9- | Air bag | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Transmission | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Auto drive position | x | x | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|--|
| Infiniti JX35 \ L50 \ 2012-9- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2012-9- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Occupant detection | | | x | |
| Infiniti JX35 \ L50 \ 2012-9- | Transmission | x | x | x | 0059, 0118 |
| Infiniti JX35 \ L50 \ 2013 | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2013 | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2013 | Air bag | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Transmission | x | x | x | 0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150 |
| Infiniti JX35 \ L50 \ 2013 | Multi AV | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Preocrash seatbelt | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2013 | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Telematics | x | x | x | 0253 |
| Infiniti JX35 \ L50 \ 2013 | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2013 | Occupant detection | | | x | |
| Infiniti JX35 \ L50 \ 2013 | Transmission | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti JX35 \ L50 \ 2013-1- | Engine | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | ABS | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti JX35 \ L50 \ 2013-1- | BCM | x | x | | |
| Infiniti JX35 \ L50 \ 2013-1- | Air bag | | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | ICC/ADAS | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | HVAC | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Transmission | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Multi AV | x | x | x | 0280 |
| Infiniti JX35 \ L50 \ 2013-1- | EPS/DAST 3 | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | IPDM E/R | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Laser/radar | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Preocrash seatbelt | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Auto drive position | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | All mode AWD/4WD | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Sonar | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Lane camera | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | CAN gateway | x | x | | |
| Infiniti JX35 \ L50 \ 2013-1- | Auto back door | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Accele pedal ACT | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Side radar left | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Side radar right | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | AVM | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Head lamp levelizer | x | x | x | |
| Infiniti JX35 \ L50 \ 2013-1- | Occupant detection | | | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2010-5- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Preocrash seatbelt | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Auto drive position | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M25-M37 \ Y51 \ 2010-5- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | E-SUS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-5- | Pop up hood | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2010-9- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Preocrash seatbelt | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | E-SUS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2010-9- | Sonar | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M25-M37 \ Y51 \ 2010-9- | Pop up hood | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2011-1- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | E-SUS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-1- | Pop up hood | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2011-4- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Air pressure monitor | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M25-M37 \ Y51 \ 2011-4- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Precrash seatbelt | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | E-SUS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-4- | Pop up hood | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2011-7- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2011-7- | Sonar | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M25-M37 \ Y51 \ 2012-12- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2012-12- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-12- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2012-3- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Precrash seatbelt | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Lane camera | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M25-M37 \ Y51 \ 2012-3- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Telematics | x | x | x | 0253 |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-3- | Pop up hood | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2012-4- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | Sonar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-4- | AVM | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Engine | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | ABS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37 \ Y51 \ 2012-6- | BCM | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | ICC/ADAS | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M25-M37 \ Y51 \ 2012-6- | HVAC | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Laser/radar | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | 4WAS(front) | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Side radar left | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Side radar right | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37 \ Y51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Engine | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | ABS | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | BCM | x | x | | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Air bag | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | ICC/ADAS | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | HVAC | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Transmission | x | x | x | 0059 |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Multi AV | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Motor control | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | EPS/DAST 3 | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | IPDM E/R | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Air pressure monitor | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Laser/radar | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Preocrash seatbelt | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Auto drive position | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Lane camera | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Adaptive light | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | CAN gateway | x | x | | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | EV/HEV | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Accele pedal ACT | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------|
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | HV battery | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Side radar left | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Side radar right | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | EMCM | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Head lamp levelizer | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Sonar | x | x | x | |
| Infiniti M25-M37-M56 \ Y51 \ 2012-7- | Pop up hood | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2005-4- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2005-4- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2005-5- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2005-5- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2005-5- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2006 | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2006 | ICC/ADAS | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------|
| Infiniti M35-M45 \ Y50 \ 2006 | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2006 | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006 | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2006-10- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2006-10- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-10- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2006-7- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2006-7- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | ABS | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------|
| Infiniti M35-M45 \ Y50 \ 2006-7- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2006-7- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2007 | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2007 | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2007 | Multi AV | x | x | x | 0280 |
| Infiniti M35-M45 \ Y50 \ 2007 | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Preocrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007 | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2007-11- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2007-11- | Rearview camera | | | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2008 | BCM | x | x | | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------|
| Infiniti M35-M45 \ Y50 \ 2008 | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2008 | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008 | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2008-1- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | Rearview camera | | | x | |
| Infiniti M35-M45 \ Y50 \ 2008-1- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2008-10- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Air pressure monitor | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------|
| Infiniti M35-M45 \ Y50 \ 2008-10- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-10- | Rearview camera | | | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2008-11- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-11- | Rearview camera | | | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2008-8- | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------|
| Infiniti M35-M45 \ Y50 \ 2008-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2008-8- | Rearview camera | | | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2009 | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2009 | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2009 | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2009 | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Engine | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Meter/M&A | x | x | x | 0143, 0331 |
| Infiniti M35-M45 \ Y50 \ 2010 | BCM | x | x | | |
| Infiniti M35-M45 \ Y50 \ 2010 | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y50 \ 2010 | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Intelligent key | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Precrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | ABS | x | x | x | |
| Infiniti M35-M45 \ Y50 \ 2010 | Air bag | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M35-M45 \ Y51 \ 2013-9- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M35-M45 \ Y51 \ 2013-9- | BCM | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | HVAC | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Laser/radar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Preocrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | CAN gateway | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | 4WAS(front) | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Telematics | x | x | x | 0253 |
| Infiniti M35-M45 \ Y51 \ 2013-9- | EMCM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | AVM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M35-M45 \ Y51 \ 2014-10- | BCM | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | HVAC | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M35-M45 \ Y51 \ 2014-10- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Laser/radar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Preocrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | CAN gateway | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Pop up hood | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | 4WAS(front) | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | E-SUS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Accele pedal ACT | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Side radar left | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Side radar right | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | EMCM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | BSW/buzzer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | AVM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | FSCM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-10- | Head lamp levelizer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M35-M45 \ Y51 \ 2014-5- | BCM | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | HVAC | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Preocrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Adaptive light | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M35-M45 \ Y51 \ 2014-5- | CAN gateway | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | 4WAS(front) | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti M35-M45 \ Y51 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | AVM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Engine | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | ABS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M35-M45 \ Y51 \ 2015-7- | BCM | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Air bag | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | ICC/ADAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | HVAC | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Transmission | x | x | x | 0059 |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Multi AV | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | EPS/DAST 3 | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | IPDM E/R | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Air pressure monitor | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Laser/radar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Preocrash seatbelt | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Auto drive position | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Sonar | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Lane camera | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Adaptive light | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | CAN gateway | x | x | | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Pop up hood | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | 4WAS(front) | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Accele pedal ACT | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Side radar left | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Side radar right | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti M35-M45 \ Y51 \ 2015-7- | PTC heater | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | EMCM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | BSW/buzzer | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M35-M45 \ Y51 \ 2015-7- | AVM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | FSCM | x | x | x | |
| Infiniti M35-M45 \ Y51 \ 2015-7- | Head lamp levelizer | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Engine | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | ABS | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37 \ Y51 \ 2012-2- | BCM | x | x | | |
| Infiniti M37 \ Y51 \ 2012-2- | Air bag | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | ICC/ADAS | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | HVAC | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Transmission | x | x | x | 0059 |
| Infiniti M37 \ Y51 \ 2012-2- | Multi AV | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | IPDM E/R | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Air pressure monitor | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Laser/radar | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Auto drive position | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | All mode AWD/4WD | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Adaptive light | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | CAN gateway | x | x | | |
| Infiniti M37 \ Y51 \ 2012-2- | Accele pedal ACT | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Head lamp levelizer | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-2- | Sonar | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Engine | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | ABS | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37 \ Y51 \ 2012-4- | BCM | x | x | | |
| Infiniti M37 \ Y51 \ 2012-4- | Air bag | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | ICC/ADAS | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | HVAC | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti M37 \ Y51 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Air pressure monitor | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Laser/radar | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | CAN gateway | x | x | | |
| Infiniti M37 \ Y51 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Head lamp levelizer | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37 \ Y51 \ 2012-4- | Sonar | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Lane camera | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | 4WAS(front) | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Side radar left | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Side radar right | x | x | x | |
| Infiniti M37 \ Y51 \ 2012-4- | Telematics | x | x | x | 0253 |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Engine | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | ABS | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M30d \ Y51 \ 2012-6- | BCM | x | x | | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | HVAC | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | EPS/DAST 3 | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Laser/radar | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | 4WAS(front) | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Side radar left | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Side radar right | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti M37-M30d \ Y51 \ 2012-6- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2010-5- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | ICC/ADAS | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M37-M56 \ Y51 \ 2010-5- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | E-SUS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-5- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2010-8- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Lane camera | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M37-M56 \ Y51 \ 2010-8- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | E-SUS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2010-8- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011 | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011 | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011 | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M37-M56 \ Y51 \ 2011 | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Preocrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011 | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | E-SUS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011 | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | ABS | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M37-M56 \ Y51 \ 2011-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011-1- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | E-SUS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-1- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011-10- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56 \ Y51 \ 2011-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-10- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011-3- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Motor control | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | EPS/DAST 3 | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | EV/HEV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | HV battery | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-3- | VSP | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56 \ Y51 \ 2011-5- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011-5- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Preocrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-5- | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2011-8- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Preocrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56 \ Y51 \ 2011-8- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2011-8- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2012 | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012 | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2012 | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Motor control | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | EPS/DAST 3 | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012 | EV/HEV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | HV battery | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | Pop up hood | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012 | VSP | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2012-6- | BCM | x | x | | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56 \ Y51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2012-7- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Accele pedal ACT | x | x | x | |

| | | | | | |
|----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56 \ Y51 \ 2012-7- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-7- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2012-9- | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Laser/radar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2012-9- | Sonar | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Engine | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | ABS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56 \ Y51 \ 2013 | BCM | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2013 | Air bag | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | HVAC | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti M37-M56 \ Y51 \ 2013 | Multi AV | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | IPDM E/R | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Air pressure monitor | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Laser/radar | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti M37-M56 \ Y51 \ 2013 | Auto drive position | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Lane camera | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Adaptive light | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | CAN gateway | x | x | | |
| Infiniti M37-M56 \ Y51 \ 2013 | 4WAS(front) | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Side radar left | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Side radar right | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Telematics | x | x | x | 0253 |
| Infiniti M37-M56 \ Y51 \ 2013 | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56 \ Y51 \ 2013 | Sonar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | ABS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Preocrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Lane camera | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Adaptive light | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | E-SUS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Side radar left | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Side radar right | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Sonar | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56-M30d \ Y51 \ 2010-4- | Pop up hood | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | ABS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Adaptive light | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Sonar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-3- | Pop up hood | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | ABS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Motor control | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Lane camera | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Adaptive light | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | EV/HEV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | HV battery | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Side radar left | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Side radar right | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Sonar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | Pop up hood | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | VSP | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2011-4- | E-SUS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | ABS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Lane camera | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Side radar left | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Side radar right | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Sonar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-4- | Pop up hood | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | ABS | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Lane camera | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Adaptive light | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | 4WAS(front) | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Side radar left | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Side radar right | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Sonar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-6- | Pop up hood | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Engine | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | ABS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | BCM | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Air bag | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | ICC/ADAS | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | HVAC | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Transmission | x | x | x | 0059 |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Multi AV | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | IPDM E/R | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Air pressure monitor | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Laser/radar | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Precrash seatbelt | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Auto drive position | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | All mode AWD/4WD | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Lane camera | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Adaptive light | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|--|
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | CAN gateway | x | x | | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Accele pedal ACT | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Side radar left | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Side radar right | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Head lamp levelizer | x | x | x | |
| Infiniti M37-M56-M30d \ Y51 \ 2012-7- | Sonar | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Engine | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti M45 \ Y34 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti M45 \ Y34 \ 2003 | BCM | x | x | | |
| Infiniti M45 \ Y34 \ 2003 | Air bag | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | HVAC | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti M45 \ Y34 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti M45 \ Y34 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti M45 \ Y34 \ 2003 | DIU | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Auto slide door | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Auto drive position | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Sonar | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Lane camera | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Adaptive light | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | AVM | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Difference lock | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Nats immu | x | x | | |
| Infiniti M45 \ Y34 \ 2003 | Smart entrance | x | x | | |
| Infiniti M45 \ Y34 \ 2003 | Air levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2003 | Rearview camera | | | x | |
| Infiniti M45 \ Y34 \ 2003 | S/blind camera | | | x | |
| Infiniti M45 \ Y34 \ 2003 | Motor assist | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Engine | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti M45 \ Y34 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |

| | | | | | |
|---------------------------|----------------------|---|---|---|--|
| Infiniti M45 \ Y34 \ 2004 | BCM | x | x | | |
| Infiniti M45 \ Y34 \ 2004 | Air bag | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | HVAC | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti M45 \ Y34 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti M45 \ Y34 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti M45 \ Y34 \ 2004 | DIU | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Auto slide door | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Auto drive position | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Sonar | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Lane camera | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Adaptive light | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | AVM | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Difference lock | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Nats immu | x | x | | |
| Infiniti M45 \ Y34 \ 2004 | Smart entrance | x | x | | |
| Infiniti M45 \ Y34 \ 2004 | Air levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2004 | Rearview camera | | | x | |
| Infiniti M45 \ Y34 \ 2004 | S/blind camera | | | x | |
| Infiniti M45 \ Y34 \ 2004 | Motor assist | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Engine | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti M45 \ Y34 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti M45 \ Y34 \ 2005 | BCM | x | x | | |
| Infiniti M45 \ Y34 \ 2005 | Air bag | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | HVAC | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti M45 \ Y34 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti M45 \ Y34 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Air pressure monitor | x | x | x | |

| | | | | | |
|-------------------------------|-------------------------|---|---|---|--|
| Infiniti M45 \ Y34 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti M45 \ Y34 \ 2005 | DIU | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Auto slide door | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Auto drive position | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Sonar | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Lane camera | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Adaptive light | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | AVM | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Difference lock | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Nats immu | x | x | | |
| Infiniti M45 \ Y34 \ 2005 | Smart entrance | x | x | | |
| Infiniti M45 \ Y34 \ 2005 | Air levelizer | x | x | x | |
| Infiniti M45 \ Y34 \ 2005 | Rearview camera | | | x | |
| Infiniti M45 \ Y34 \ 2005 | S/blind camera | | | x | |
| Infiniti M45 \ Y34 \ 2005 | Motor assist | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Engine | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | ABS | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI Q30 \ H15 \ 2015-11- | BCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Air bag | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI Q30 \ H15 \ 2015-11- | Transmission | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Multi AV | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | EHS/PKB | | x | x | 0111 |
| INFINITI Q30 \ H15 \ 2015-11- | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI Q30 \ H15 \ 2015-11- | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI Q30 \ H15 \ 2015-11- | Intelligent key | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Auto drive position | x | x | x | 0180 |
| INFINITI Q30 \ H15 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | CAN gateway | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Shift | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | ANC | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | AVM | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | FSCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Door Module Front Left | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Door Module Front Right | | x | x | |

| | | | | | |
|-------------------------------|---|---|---|---|------------------------|
| INFINITI Q30 \ H15 \ 2015-11- | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Intrusion Siren | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Seat Control Module Passenger* | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Light/Rain Sensor Module* | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Trailer Module* | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Occupant Classification Module4 | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Standalone DISTRONIC Sensor* | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Parking assist | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | SCCM | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Steering Wheel Switch Pad | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Forward Collision Warning** | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | LED Control Unit Front Right | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | LED Control Unit Front Left | | | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Multi Purpose Camera | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | CPC(central powertrain controller) | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Head Lamp Interface right | | x | x | |
| INFINITI Q30 \ H15 \ 2015-11- | Head Lamp Interface left | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Engine | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | ABS | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI Q30 \ H15 \ 2016-1- | BCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Air bag | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI Q30 \ H15 \ 2016-1- | Transmission | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | EHS/PKB | | x | x | 0111 |
| INFINITI Q30 \ H15 \ 2016-1- | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI Q30 \ H15 \ 2016-1- | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI Q30 \ H15 \ 2016-1- | Intelligent key | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Auto drive position | x | x | x | 0180 |
| INFINITI Q30 \ H15 \ 2016-1- | All mode AWD/4WD | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | CAN gateway | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Shift | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | ANC | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | AVM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | FSCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Door Module Front Left | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Door Module Front Right | | x | x | |

| | | | | | |
|------------------------------|---|---|---|---|------------------------|
| INFINITI Q30 \ H15 \ 2016-1- | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Intrusion Siren | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Seat Control Module Passenger* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Light/Rain Sensor Module* | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Trailer Module* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Occupant Classification Module4 | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Standalone DISTRONIC Sensor* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Parking assist | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | SCCM | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Steering Wheel Switch Pad | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Forward Collision Warning** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | LED Control Unit Front Right | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | LED Control Unit Front Left | | | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Multi Purpose Camera | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | CPC(central powertrain controller) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Head Lamp Interface right | | x | x | |
| INFINITI Q30 \ H15 \ 2016-1- | Head Lamp Interface left | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Engine | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | ABS | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI Q30 \ H15 \ 2016-4- | BCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Air bag | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI Q30 \ H15 \ 2016-4- | Transmission | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Multi AV | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | EHS/PKB | | x | x | 0111 |
| INFINITI Q30 \ H15 \ 2016-4- | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI Q30 \ H15 \ 2016-4- | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI Q30 \ H15 \ 2016-4- | Intelligent key | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Auto drive position | x | x | x | 0180 |
| INFINITI Q30 \ H15 \ 2016-4- | All mode AWD/4WD | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | CAN gateway | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Shift | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | ANC | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | AVM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | FSCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Door Module Front Left | | x | x | |

| | | | | | |
|------------------------------|---|---|---|---|------------------------|
| INFINITI Q30 \ H15 \ 2016-4- | Door Module Front Right | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Intrusion Siren | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Seat Control Module Passenger* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Light/Rain Sensor Module* | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Trailer Module* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Occupant Classification Module4 | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Standalone DISTRONIC Sensor* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Parking assist | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | SCCM | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Steering Wheel Switch Pad | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Forward Collision Warning** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | LED Control Unit Front Right | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | LED Control Unit Front Left | | | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Multi Purpose Camera | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | CPC(central powertrain controller) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Head Lamp Interface right | | x | x | |
| INFINITI Q30 \ H15 \ 2016-4- | Head Lamp Interface left | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Engine | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | ABS | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI Q30 \ H15 \ 2016-5- | BCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Air bag | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI Q30 \ H15 \ 2016-5- | Transmission | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | EHS/PKB | | x | x | 0111 |
| INFINITI Q30 \ H15 \ 2016-5- | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI Q30 \ H15 \ 2016-5- | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI Q30 \ H15 \ 2016-5- | Intelligent key | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Auto drive position | x | x | x | 0180 |
| INFINITI Q30 \ H15 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | CAN gateway | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Shift | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | ANC | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | AVM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | FSCM | x | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Door Module Front Left | | x | x | |

| | | | | | |
|------------------------------|---|---|---|---|--|
| INFINITI Q30 \ H15 \ 2016-5- | Door Module Front Right | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Intrusion Siren | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Seat Control Module Passenger* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Light/Rain Sensor Module* | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Trailer Module* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Occupant Classification Module4 | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Standalone DISTRONIC Sensor* | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Parking assist | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | SCCM | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Steering Wheel Switch Pad | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Forward Collision Warning** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | LED Control Unit Front Right | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | LED Control Unit Front Left | | | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Multi Purpose Camera | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | CPC(central powertrain controller) | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Head Lamp Interface right | | x | x | |
| INFINITI Q30 \ H15 \ 2016-5- | Head Lamp Interface left | | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2001-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2001-8- | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2001-8- | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2001-8- | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2001-8- | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2001-8- | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2001-8- | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2001-8- | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2001-8- | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2001-8- | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2001-8- | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2002 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2002 | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2002 | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2002 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2002 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2002 | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2002 | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2002 | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2002 | Air levelizer | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2002 | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2002 | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2002 | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2002-9- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2002-9- | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2002-9- | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2002-9- | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2002-9- | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2002-9- | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2002-9- | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2002-9- | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2002-9- | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2002-9- | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2003 | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2003 | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | ICC/ADAS | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2003 | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2003 | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2003 | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2003 | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2003 | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2003 | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2003 | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2003-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2003-8- | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2003-8- | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2003-8- | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2003-8- | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2003-8- | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2003-8- | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2003-8- | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2003-8- | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2003-8- | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2004 | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2004 | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2004 | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | AVM | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2004 | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2004 | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2004 | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2004 | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2004 | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2004-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2004-8- | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2004-8- | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2004-8- | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2004-8- | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2004-8- | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2004-8- | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2004-8- | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2004-8- | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2004-8- | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Engine | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2005 | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2005 | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2005 | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2005 | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2005 | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2005 | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2005 | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2005 | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2005-11- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2005-11- | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2005-11- | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2005-11- | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2005-11- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2005-11- | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2005-11- | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2005-11- | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2005-11- | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2005-11- | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2005-11- | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ 2006 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ 2006 | BCM | x | x | | |
| Infiniti Q45 \ F50 \ 2006 | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ 2006 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ 2006 | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ 2006 | Smart entrance | x | x | | |
| Infiniti Q45 \ F50 \ 2006 | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ 2006 | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ 2006 | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ 2006 | Motor assist | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Engine | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ F50 \ All Year | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ F50 \ All Year | BCM | x | x | | |
| Infiniti Q45 \ F50 \ All Year | Air bag | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | HVAC | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ F50 \ All Year | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ F50 \ All Year | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | IPDM E/R | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ F50 \ All Year | DIU | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Auto slide door | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Auto drive position | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Sonar | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Lane camera | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Adaptive light | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | AVM | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Difference lock | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Nats immu | x | x | | |
| Infiniti Q45 \ F50 \ All Year | Smart entrance | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ F50 \ All Year | Air levelizer | x | x | x | |
| Infiniti Q45 \ F50 \ All Year | Rearview camera | | | x | |
| Infiniti Q45 \ F50 \ All Year | S/blind camera | | | x | |
| Infiniti Q45 \ F50 \ All Year | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 1995 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 1995 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 1995 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 1995 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 1995 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 1995 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 1995 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 1995 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1995 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 1995 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 1995 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 1996 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 1996 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 1996 | Air bag | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ FY33 \ 1996 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 1996 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 1996 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 1996 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 1996 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 1996 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1996 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 1996 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 1996 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 1997 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 1997 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 1997 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 1997 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 1997 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Air pressure monitor | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ FY33 \ 1997 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 1997 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 1997 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 1997 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1997 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 1997 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 1997 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 1998 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 1998 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 1998 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 1998 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 1998 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 1998 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Sonar | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ FY33 \ 1998 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 1998 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 1998 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1998 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 1998 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 1998 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 1999 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 1999 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 1999 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 1999 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 1999 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 1999 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 1999 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 1999 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 1999 | Rearview camera | | | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ FY33 \ 1999 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 1999 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 2000 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 2000 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 2000 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | HVAC | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 2000 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 2000 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 2000 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 2000 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 2000 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 2000 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 2000 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 2000 | Motor assist | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Engine | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti Q45 \ FY33 \ 2001 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti Q45 \ FY33 \ 2001 | BCM | x | x | | |
| Infiniti Q45 \ FY33 \ 2001 | Air bag | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | ICC/ADAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | HVAC | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|--|
| Infiniti Q45 \ FY33 \ 2001 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti Q45 \ FY33 \ 2001 | Multi AV | x | x | x | 0280 |
| Infiniti Q45 \ FY33 \ 2001 | EPS/DAST 3 | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | IPDM E/R | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Air pressure monitor | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti Q45 \ FY33 \ 2001 | DIU | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Auto slide door | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Auto drive position | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | All mode AWD/4WD | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Sonar | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Lane camera | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Adaptive light | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | AVM | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Head lamp levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Difference lock | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Nats immu | x | x | | |
| Infiniti Q45 \ FY33 \ 2001 | Smart entrance | x | x | | |
| Infiniti Q45 \ FY33 \ 2001 | Air levelizer | x | x | x | |
| Infiniti Q45 \ FY33 \ 2001 | Rearview camera | | | x | |
| Infiniti Q45 \ FY33 \ 2001 | S/blind camera | | | x | |
| Infiniti Q45 \ FY33 \ 2001 | Motor assist | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Auto drive position | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Charger/PD module | x | x | x | 0065 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-10- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Preocrash seatbelt | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Charger/PD module | x | x | x | 0065 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-6- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Air pressure monitor | x | x | x | |

| | | | | | |
|--------------------------------------|---------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Charger/PD module | x | x | x | 0065 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-7- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Charger/PD module | x | x | x | 0065 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2013-9- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Motor control | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014 | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | IPDM E/R | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Charger/PD module | x | x | x | 0065 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2014-1- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | EPS/DAST 3 | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Shift | x | x | x | 0204 |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | 4WAS(front) | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | E-SUS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015 | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Transmission | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | FSCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2015-5- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Transmission | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Transmission | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Motor control | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-2- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | FSCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-3- | Transmission | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | HVAC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Transmission | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Multi AV | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | FSCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Occupant detection | | | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-5- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Engine | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | ABS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | BCM | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Air bag | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | ICC/ADAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | HVAC | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Transmission | x | x | x | 0059 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Multi AV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Motor control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | IPDM E/R | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Air pressure monitor | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Laser/radar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Auto drive position | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Sonar | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Lane camera | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Adaptive light | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | CAN gateway | x | x | | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | EV/HEV | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Pop up hood | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | HV battery | x | x | x | 0251 |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Brake | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Side radar left | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | VSP | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | ANC | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Side radar right | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | EMCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | BSW/buzzer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | AVM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Chassis control | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | DAST 1 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | DAST 2 | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | FSCM | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 Hybrid \ HV37 \ 2016-6- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2013-10- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2013-10- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | ICC/ADAS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2013-10- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2013-10- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2013-10- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2013-10- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2013-10- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-10- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2013-12- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2013-12- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Transmission | x | x | x | 0059 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2013-12- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2013-12- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2013-12- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2013-12- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | PMAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-12- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2013-6- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2013-6- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | HVAC | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2013-6- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2013-6- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2013-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2013-6- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2013-6- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2013-6- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-6- | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2013-9- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2013-9- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | ICC/ADAS | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2013-9- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2013-9- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2013-9- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2013-9- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | PMAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2014 | BCM | x | x | | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2014 | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2014 | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2014 | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2014 | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2014-1- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2014-1- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2014-1- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2014-1- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2014-1- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2014-1- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2014-1- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | PMAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-1- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2014-5- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2014-5- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2014-5- | Multi AV | x | x | x | 0280 |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2014-5- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2014-5- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2015 | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2015 | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2015 | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | EPS/DAST 3 | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2015 | Shift | x | x | x | 0204 |
| Infiniti Q50 \ V37 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015 | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2015-3- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2015-3- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2015-3- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Air pressure monitor | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q50 \ V37 \ 2015-3- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2015-3- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-3- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2015-3- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2015-5- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2015-5- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2015-5- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2015-5- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Preocrash seatbelt | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q50 \ V37 \ 2015-5- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2015-5- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | E-SUS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2015-5- | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2015-5- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-5- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2015-6- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2015-6- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2015-6- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Motor control | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Preocrash seatbelt | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q50 \ V37 \ 2015-6- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2015-6- | EV/HEV | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | HV battery | x | x | x | 0251 |
| Infiniti Q50 \ V37 \ 2015-6- | Brake | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2015-6- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2015-6- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2016 | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2016 | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2016 | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2016 | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Laser/radar | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2016 | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2016 | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2016 | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2016 | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016 | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2016-3- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2016-3- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2016-3- | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Motor control | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Preocrash seatbelt | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q50 \ V37 \ 2016-3- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2016-3- | EV/HEV | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | HV battery | x | x | x | 0251 |
| Infiniti Q50 \ V37 \ 2016-3- | Brake | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | VSP | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2016-3- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-3- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2016-5- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2016-5- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2016-5- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2016-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Laser/radar | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q50 \ V37 \ 2016-5- | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2016-5- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-5- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2016-5- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2016-6- | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2016-6- | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2016-6- | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2016-6- | Multi AV | x | x | x | 0280 |
| Infiniti Q50 \ V37 \ 2016-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Preocrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|--|
| Infiniti Q50 \ V37 \ 2016-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2016-6- | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q50 \ V37 \ 2016-6- | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2016-6- | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2017 | Engine | x | x | x | 0237, 0060, 0237, 0248, 0249, 0267, 0232, 0310, 0060, 0195, 0274, 0196, 0294, 0295, 0296, 0224, 0290, 0087, 0291, 0152 |
| Infiniti Q50 \ V37 \ 2017 | ABS | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Meter/M&A | x | x | x | 0143 |
| Infiniti Q50 \ V37 \ 2017 | BCM | x | x | | |
| Infiniti Q50 \ V37 \ 2017 | Air bag | | x | x | |
| Infiniti Q50 \ V37 \ 2017 | ICC/ADAS | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | HVAC | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Transmission | x | x | x | 0250, 0309, 0231, 0059, 0237, 0250 |
| Infiniti Q50 \ V37 \ 2017 | Multi AV | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | EPS/DAST 3 | x | x | x | 0088, 0089 |
| Infiniti Q50 \ V37 \ 2017 | IPDM E/R | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Air pressure monitor | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Laser/radar | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Precrash seatbelt | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Auto drive position | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | All mode AWD/4WD | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------|
| Infiniti Q50 \ V37 \ 2017 | Sonar | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Lane camera | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Adaptive light | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | CAN gateway | x | x | | |
| Infiniti Q50 \ V37 \ 2017 | Pop up hood | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | 4WAS(front) | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Accele pedal ACT | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Side radar left | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | ANC | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Side radar right | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Telematics | x | x | x | 0253 |
| Infiniti Q50 \ V37 \ 2017 | EMCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | BSW/buzzer | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | AVM | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Chassis control | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | DAST 1 | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | DAST 2 | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q50 \ V37 \ 2017 | FSCM | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Head lamp levelizer | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Occupant detection | | | x | |
| Infiniti Q50 \ V37 \ 2017 | Engine | x | x | x | |
| Infiniti Q50 \ V37 \ 2017 | Transmission | x | x | x | 0059 |
| Infiniti Q50 \ V37 \ 2017 | EPS/DAST 3 | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Engine | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Meter/M&A | x | x | x | 0143 |
| INFINITI Q50L \ V37 \ 2014-10- | BCM | x | x | | |
| INFINITI Q50L \ V37 \ 2014-10- | Air bag | | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | ICC/ADAS | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | HVAC | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Transmission | x | x | x | 0059 |
| INFINITI Q50L \ V37 \ 2014-10- | Multi AV | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | EPS/DAST 3 | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | IPDM E/R | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Air pressure monitor | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Laser/radar | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Preocrash seatbelt | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Auto drive position | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | All mode AWD/4WD | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------|
| INFINITI Q50L \ V37 \ 2014-10- | Sonar | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Lane camera | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Adaptive light | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | CAN gateway | x | x | | |
| INFINITI Q50L \ V37 \ 2014-10- | E-SUS | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Accele pedal ACT | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Side radar left | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | ANC | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Side radar right | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Telematics | x | x | x | 0253 |
| INFINITI Q50L \ V37 \ 2014-10- | BSW/buzzer | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | AVM | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Chassis control | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | DAST 1 | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | DAST 2 | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | HIGH BEAM ASSIST | | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | FSCM | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Head lamp levelizer | x | x | x | |
| INFINITI Q50L \ V37 \ 2014-10- | Occupant detection | | | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Engine | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | ABS | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Meter/M&A | x | x | x | 0143 |
| INFINITI Q50L \ V37 \ 2015-3- | BCM | x | x | | |
| INFINITI Q50L \ V37 \ 2015-3- | Air bag | | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | ICC/ADAS | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | HVAC | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Transmission | x | x | x | 0059 |
| INFINITI Q50L \ V37 \ 2015-3- | Multi AV | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | EPS/DAST 3 | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | IPDM E/R | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Air pressure monitor | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Laser/radar | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Preocrash seatbelt | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Auto drive position | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | All mode AWD/4WD | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Sonar | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Lane camera | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Adaptive light | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | CAN gateway | x | x | | |

| | | | | | |
|---|---------------------|---|---|---|------------------------------|
| INFINITI Q50L \ V37 \ 2015-3- | Pop up hood | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Accele pedal ACT | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Side radar left | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | ANC | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Side radar right | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Telematics | x | x | x | 0253 |
| INFINITI Q50L \ V37 \ 2015-3- | EMCM | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | BSW/buzzer | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | AVM | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Chassis control | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | DAST 1 | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | DAST 2 | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | HIGH BEAM ASSIST | | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | FSCM | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Head lamp levelizer | x | x | x | |
| INFINITI Q50L \ V37 \ 2015-3- | Occupant detection | | | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-7- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | IPDM E/R | x | x | x | |

| | | | | | |
|---|---------------------|---|---|---|------------------------------|
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-8- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2014 | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014 | Pop up hood | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------|
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Air pressure monitor | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | AVM | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | Laser/radar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-3- | E-SUS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | E-SUS | x | x | x | |

| | | | | | |
|---|----------------------|---|---|---|------------------------------|
| Infiniti Q60 convertible \ HV36 \ 2014-5- | AVM | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Air pressure monitor | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Laser/radar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | E-SUS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | AVM | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | ABS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2014-6- | Pop up hood | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Engine | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 convertible \ HV36 \ 2015 | BCM | x | x | | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Air bag | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti Q60 convertible \ HV36 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Convertible roof | x | x | x | 0131, 0242, 0243, 0244, 0304 |
| Infiniti Q60 convertible \ HV36 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | ABS | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------|
| Infiniti Q60 convertible \ HV36 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Sonar | x | x | x | |
| Infiniti Q60 convertible \ HV36 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2006-12- | All mode AWD/4WD | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Preocrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-6- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Preocrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Adaptive light | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 coupe \ CV36 \ 2013-7- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-7- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-8- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Engine | x | x | x | |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 coupe \ CV36 \ 2014 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2014 | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014 | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Air pressure monitor | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Laser/radar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | All mode AWD/4WD | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | E-SUS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | AVM | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-1- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |

| | | | | | |
|-------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 coupe \ CV36 \ 2014-3- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Air pressure monitor | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | All mode AWD/4WD | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | AVM | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | Laser/radar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-3- | E-SUS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | 4WAS(front) | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | E-SUS | x | x | x | |

| | | | | | |
|-------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti Q60 coupe \ CV36 \ 2014-5- | AVM | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Engine | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 coupe \ CV36 \ 2015 | BCM | x | x | | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Air bag | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti Q60 coupe \ CV36 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | ABS | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Sonar | x | x | x | |
| Infiniti Q60 coupe \ CV36 \ 2015 | Pop up hood | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Engine | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| INFINITI Q60 Sedan \ V36 \ 2015 | BCM | x | x | | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Air bag | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | ICC/ADAS | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Transmission | x | x | x | 0059 |
| INFINITI Q60 Sedan \ V36 \ 2015 | Multi AV | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | IPDM E/R | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Precrash seatbelt | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Auto drive position | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | All mode AWD/4WD | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Adaptive light | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | ABS | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Head lamp levelizer | x | x | x | |
| INFINITI Q60 Sedan \ V36 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Engine | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | ABS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 \ CV37 \ 2016-7- | BCM | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 \ CV37 \ 2016-7- | Air bag | | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | ICC/ADAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | HVAC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Transmission | x | x | x | 0059 |
| Infiniti Q60 \ CV37 \ 2016-7- | Multi AV | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | IPDM E/R | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Air pressure monitor | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Laser/radar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Precrash seatbelt | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Auto drive position | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Sonar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Lane camera | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Adaptive light | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | CAN gateway | x | x | | |
| Infiniti Q60 \ CV37 \ 2016-7- | Pop up hood | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Side radar left | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | ANC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Side radar right | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Telematics | x | x | x | 0253 |
| Infiniti Q60 \ CV37 \ 2016-7- | EMCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | AVM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Chassis control | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | DAST 1 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | DAST 2 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | FSCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-7- | Occupant detection | | | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Engine | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | ABS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 \ CV37 \ 2016-8- | BCM | x | x | | |
| Infiniti Q60 \ CV37 \ 2016-8- | Air bag | | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | ICC/ADAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | HVAC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Transmission | x | x | x | 0059 |
| Infiniti Q60 \ CV37 \ 2016-8- | Multi AV | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 \ CV37 \ 2016-8- | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | IPDM E/R | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Air pressure monitor | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Laser/radar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Preocrash seatbelt | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Auto drive position | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Sonar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Lane camera | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Adaptive light | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | CAN gateway | x | x | | |
| Infiniti Q60 \ CV37 \ 2016-8- | Pop up hood | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Accele pedal ACT | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Side radar left | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | ANC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Side radar right | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | EMCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | AVM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Chassis control | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | DAST 1 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | DAST 2 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | FSCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Head lamp levelizer | x | x | x | |
| Infiniti Q60 \ CV37 \ 2016-8- | Occupant detection | | | x | |
| Infiniti Q60 \ CV37 \ 2017 | Engine | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | ABS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti Q60 \ CV37 \ 2017 | BCM | x | x | | |
| Infiniti Q60 \ CV37 \ 2017 | Air bag | | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | ICC/ADAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | HVAC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Transmission | x | x | x | 0059 |
| Infiniti Q60 \ CV37 \ 2017 | Multi AV | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | EPS/DAST 3 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | IPDM E/R | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Air pressure monitor | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Laser/radar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Preocrash seatbelt | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Auto drive position | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q60 \ CV37 \ 2017 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Sonar | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Lane camera | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Adaptive light | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | CAN gateway | x | x | | |
| Infiniti Q60 \ CV37 \ 2017 | Pop up hood | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Accele pedal ACT | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Side radar left | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | ANC | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Side radar right | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Telematics | x | x | x | 0253 |
| Infiniti Q60 \ CV37 \ 2017 | EMCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | AVM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Chassis control | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | DAST 1 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | DAST 2 | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | HIGH BEAM ASSIST | | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | FSCM | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Head lamp levelizer | x | x | x | |
| Infiniti Q60 \ CV37 \ 2017 | Occupant detection | | | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Multi AV | x | x | x | 0280 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Adaptive light | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | CAN gateway | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | ANC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | FSCM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-7- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | HV battery | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Brake | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Multi AV | x | x | x | 0280 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | CAN gateway | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | ANC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2013-9- | FSCM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Telematics | x | x | x | 0253 |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014 | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | 4WAS(front) | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | E-SUS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-10- | EMCM | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | 4WAS(front) | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Transmission | x | x | x | 0059 |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | All mode AWD/4WD | x | x | x | 0245, 0311 |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | 4WAS(front) | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | E-SUS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Transmission | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-11- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Transmission | x | x | x | 0059 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | 4WAS(front) | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | E-SUS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | EMCM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Transmission | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | CAN gateway | x | x | | |

| | | | | | |
|--------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | 4WAS(front) | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | VSP | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2015-6- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Engine | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | ABS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | BCM | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Air bag | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | HVAC | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Transmission | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Multi AV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Motor control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Laser/radar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Precrash seatbelt | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Auto drive position | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Sonar | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Lane camera | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Adaptive light | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | CAN gateway | x | x | | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | EV/HEV | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Pop up hood | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | HV battery | x | x | x | 0251 |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Brake | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Side radar left | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | VSP | x | x | x | |

| | | | | | |
|-----------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Side radar right | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | AVM | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Chassis control | x | x | x | |
| Infiniti Q70 Hybrid \ HY51 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2013-11- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2013-11- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2013-11- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | CAN gateway | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2013-11- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-11- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2013-7- | BCM | x | x | | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2013-7- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2013-7- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | CAN gateway | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2013-7- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-7- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2013-9- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2013-9- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Auto drive position | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | CAN gateway | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2013-9- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2013-9- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014 | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2014 | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2014 | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2014 | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Telematics | x | x | x | 0253 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014 | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2014-10- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-10- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2014-10- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-10- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | FSCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-10- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2014-11- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2014-11- | BCM | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2014-11- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2014-11- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-11- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2014-11- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-11- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2014-5- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-5- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Laser/radar | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2014-5- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-5- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-5- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2014-7- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-7- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2014-7- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2014-7- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Telematics | x | x | x | 0253 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2014-7- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2014-7- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015 | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015 | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015 | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015 | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015 | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-10- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-10- | Air bag | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q70 \ Y51 \ 2015-10- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-10- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-10- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q70 \ Y51 \ 2015-10- | PTC heater | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | FSCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-10- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-11- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-11- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-11- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Air pressure monitor | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q70 \ Y51 \ 2015-11- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-11- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q70 \ Y51 \ 2015-11- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2015-11- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-11- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-2- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-2- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-2- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | CAN gateway | x | x | | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2015-2- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2015-2- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-2- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-3- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-3- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-3- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-3- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-3- | Head lamp levelizer | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2015-4- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-4- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-4- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-4- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-4- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-4- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2015-4- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-5- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-5- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Transmission | x | x | x | 0059 |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2015-5- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-5- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | E-SUS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2015-5- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-5- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2015-7- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-7- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2015-7- | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|------------------------------|----------------------|---|---|---|------------------------------|
| Infiniti Q70 \ Y51 \ 2015-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2015-7- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | ADCM | x | x | x | 0015, 0257, 0314, 0315, 0316 |
| Infiniti Q70 \ Y51 \ 2015-7- | PTC heater | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | EMCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | FSCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2015-7- | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2016 | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2016 | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2016 | Multi AV | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Preocrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2016 | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Side radar left | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti Q70 \ Y51 \ 2016 | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti Q70 \ Y51 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Engine | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | ABS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti Q70 \ Y51 \ 2016-5- | BCM | x | x | | |
| Infiniti Q70 \ Y51 \ 2016-5- | Air bag | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | ICC/ADAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | HVAC | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Transmission | x | x | x | 0059 |
| Infiniti Q70 \ Y51 \ 2016-5- | Multi AV | x | x | x | 0280 |
| Infiniti Q70 \ Y51 \ 2016-5- | EPS/DAST 3 | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | IPDM E/R | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Air pressure monitor | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Laser/radar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Precrash seatbelt | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Auto drive position | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Sonar | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Lane camera | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Adaptive light | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | CAN gateway | x | x | | |
| Infiniti Q70 \ Y51 \ 2016-5- | Pop up hood | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | 4WAS(front) | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Accele pedal ACT | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Side radar left | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Side radar right | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | BSW/buzzer | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | AVM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | FSCM | x | x | x | |
| Infiniti Q70 \ Y51 \ 2016-5- | Head lamp levelizer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Engine | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | ABS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | BCM | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Air bag | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------|
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | ICC/ADAS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | HVAC | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Transmission | x | x | x | 0059 |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Multi AV | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Motor control | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | EPS/DAST 3 | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | IPDM E/R | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Air pressure monitor | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Laser/radar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Precrash seatbelt | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Auto drive position | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | All mode AWD/4WD | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Sonar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Lane camera | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Adaptive light | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | CAN gateway | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | EV/HEV | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | 4WAS(front) | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | E-SUS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Accele pedal ACT | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | HV battery | x | x | x | 0251 |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Brake | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Side radar left | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | VSP | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Side radar right | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Telematics | x | x | x | 0253 |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | BSW/buzzer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | AVM | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Head lamp levelizer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2014-7- | Pop up hood | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Engine | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | ABS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | BCM | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Air bag | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | ICC/ADAS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | HVAC | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Transmission | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Multi AV | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------|
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Motor control | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | EPS/DAST 3 | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | IPDM E/R | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Air pressure monitor | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Laser/radar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Precrash seatbelt | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Auto drive position | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Sonar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Lane camera | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Adaptive light | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | CAN gateway | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | EV/HEV | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Pop up hood | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Accele pedal ACT | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | HV battery | x | x | x | 0251 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Brake | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Side radar left | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | VSP | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Side radar right | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Telematics | x | x | x | 0253 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | BSW/buzzer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | AVM | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-11- | Head lamp levelizer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Engine | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | ABS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | BCM | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Air bag | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | ICC/ADAS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | HVAC | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Transmission | x | x | x | 0059 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Multi AV | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Motor control | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | EPS/DAST 3 | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | IPDM E/R | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Air pressure monitor | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Laser/radar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Precrash seatbelt | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Auto drive position | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | All mode AWD/4WD | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Sonar | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Lane camera | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Adaptive light | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | CAN gateway | x | x | | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | EV/HEV | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Pop up hood | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | 4WAS(front) | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | E-SUS | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Accele pedal ACT | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | HV battery | x | x | x | 0251 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Brake | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Side radar left | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | VSP | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Side radar right | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Telematics | x | x | x | 0253 |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | EMCM | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | BSW/buzzer | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | AVM | x | x | x | |
| INFINITI Q70L Hybrid \ HY51 \ 2015-2- | Head lamp levelizer | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Engine | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | ABS | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| INFINITI Q70L \ HGY51 \ 2013-10- | BCM | x | x | | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Air bag | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | ICC/ADAS | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | HVAC | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Transmission | x | x | x | 0059 |
| INFINITI Q70L \ HGY51 \ 2013-10- | Multi AV | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Motor control | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | EPS/DAST 3 | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | IPDM E/R | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Air pressure monitor | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Laser/radar | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Precrash seatbelt | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Auto drive position | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | All mode AWD/4WD | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Lane camera | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Adaptive light | x | x | x | |

| | | | | | |
|----------------------------------|---|---|---|---|------------------------|
| INFINITI Q70L \ HGY51 \ 2013-10- | CAN gateway | x | x | | |
| INFINITI Q70L \ HGY51 \ 2013-10- | EV/HEV | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Accele pedal ACT | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | HV battery | x | x | x | 0251 |
| INFINITI Q70L \ HGY51 \ 2013-10- | Brake | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | VSP | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Head lamp levelizer | x | x | x | |
| INFINITI Q70L \ HGY51 \ 2013-10- | Pop up hood | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Engine | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | ABS | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI QX30 \ H15 \ 2016-4- | BCM | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Air bag | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI QX30 \ H15 \ 2016-4- | Transmission | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | EHS/PKB | | x | x | 0111 |
| INFINITI QX30 \ H15 \ 2016-4- | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI QX30 \ H15 \ 2016-4- | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI QX30 \ H15 \ 2016-4- | Intelligent key | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Auto drive position | x | x | x | 0180 |
| INFINITI QX30 \ H15 \ 2016-4- | All mode AWD/4WD | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | CAN gateway | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Shift | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | ANC | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | AVM | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | FSCM | x | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Door Module Front Left | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Door Module Front Right | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Intrusion Siren | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Seat Control Module Passenger* | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Light/Rain Sensor Module* | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Trailer Module* | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Occupant Classification Module4 | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Standalone Distronic Sensor* | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Parking assist | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | SCCM | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Steering Wheel Switch Pad | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Forward Collision Warning** | | x | x | |

| | | | | | |
|-------------------------------|---|---|---|---|------------------------|
| INFINITI QX30 \ H15 \ 2016-4- | LED Control Unit Front Right | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | LED Control Unit Front Left | | | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Multi Purpose Camera | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | CPC(central powertrain controller) | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Head Lamp Interface right | | x | x | |
| INFINITI QX30 \ H15 \ 2016-4- | Head Lamp Interface left | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Engine | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | ABS | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Meter/M&A | x | x | x | 0202, 0286, 0292, 0301 |
| INFINITI QX30 \ H15 \ 2017 | BCM | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Air bag | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | HVAC | x | x | x | 0051, 0181, 0246, 0293 |
| INFINITI QX30 \ H15 \ 2017 | Transmission | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | EHS/PKB | | x | x | 0111 |
| INFINITI QX30 \ H15 \ 2017 | EPS/DAST 3 | x | x | x | 0084, 0235, 0246 |
| INFINITI QX30 \ H15 \ 2017 | Air pressure monitor | x | x | x | 0141, 0261 |
| INFINITI QX30 \ H15 \ 2017 | Intelligent key | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Auto drive position | x | x | x | 0180 |
| INFINITI QX30 \ H15 \ 2017 | All mode AWD/4WD | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | CAN gateway | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Shift | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | ANC | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | AVM | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | FSCM | x | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Door Module Front Left | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Door Module Front Right | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Vehicle Theft Alarm Sensor Module | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Intrusion Siren | | | x | |
| INFINITI QX30 \ H15 \ 2017 | Seat Control Module Passenger* | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Light/Rain Sensor Module* | | | x | |
| INFINITI QX30 \ H15 \ 2017 | Electronic Ignition Switch (With Central Gateway) | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Trailer Module* | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Occupant Classification Module4 | | | x | |
| INFINITI QX30 \ H15 \ 2017 | Standalone Distronic Sensor* | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Parking assist | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | SCCM | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Steering Wheel Switch Pad | | | x | |
| INFINITI QX30 \ H15 \ 2017 | Forward Collision Warning** | | x | x | |

| | | | | | |
|----------------------------|------------------------------------|---|---|---|--|
| INFINITI QX30 \ H15 \ 2017 | LED Control Unit Front Right | | | x | |
| INFINITI QX30 \ H15 \ 2017 | LED Control Unit Front Left | | | x | |
| INFINITI QX30 \ H15 \ 2017 | Blind Spot Monitoring - Master** | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Blind Spot Monitoring - Slave** | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Multi Purpose Camera | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | CPC(central powertrain controller) | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Head Lamp Interface right | | x | x | |
| INFINITI QX30 \ H15 \ 2017 | Head Lamp Interface left | | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 1997 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 1997 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 1997 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 1997 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 1997 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 1997 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 1997 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 1997 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1997 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 1997 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 1997 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Engine | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti QX4 \ JR50 \ 1998 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 1998 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 1998 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 1998 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 1998 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 1998 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 1998 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 1998 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 1998 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1998 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 1998 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 1998 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 1999 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 1999 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 1999 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 1999 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 1999 | EPS/DAST 3 | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti QX4 \ JR50 \ 1999 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 1999 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 1999 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 1999 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 1999 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 1999 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 1999 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 2000 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 2000 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 2000 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 2000 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 2000 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 2000 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | All mode AWD/4WD | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti QX4 \ JR50 \ 2000 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 2000 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 2000 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2000 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 2000 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 2000 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 2001 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 2001 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 2001 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 2001 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 2001 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 2001 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 2001 | Smart entrance | x | x | | |

| | | | | | |
|----------------------------|----------------------|---|---|---|--|
| Infiniti QX4 \ JR50 \ 2001 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2001 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 2001 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 2001 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 2002 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 2002 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 2002 | Air bag | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 2002 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 2002 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 2002 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 2002 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 2002 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2002 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 2002 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 2002 | Motor assist | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Engine | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX4 \ JR50 \ 2003 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX4 \ JR50 \ 2003 | BCM | x | x | | |
| Infiniti QX4 \ JR50 \ 2003 | Air bag | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX4 \ JR50 \ 2003 | ICC/ADAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | HVAC | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX4 \ JR50 \ 2003 | Multi AV | x | x | x | 0280 |
| Infiniti QX4 \ JR50 \ 2003 | EPS/DAST 3 | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | IPDM E/R | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Air pressure monitor | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX4 \ JR50 \ 2003 | DIU | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Auto slide door | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Auto drive position | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | All mode AWD/4WD | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Sonar | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Lane camera | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Adaptive light | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | AVM | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Head lamp levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Difference lock | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Nats immu | x | x | | |
| Infiniti QX4 \ JR50 \ 2003 | Smart entrance | x | x | | |
| Infiniti QX4 \ JR50 \ 2003 | Air levelizer | x | x | x | |
| Infiniti QX4 \ JR50 \ 2003 | Rearview camera | | | x | |
| Infiniti QX4 \ JR50 \ 2003 | S/blind camera | | | x | |
| Infiniti QX4 \ JR50 \ 2003 | Motor assist | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2013-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2013-6- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2013-6- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2013-6- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Adaptive light | x | x | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2013-6- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2013-6- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2013-6- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-6- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2013-7- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2013-7- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2013-7- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2013-7- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2013-7- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2013-7- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2013-7- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-7- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2013-8- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2013-8- | BCM | x | x | | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2013-8- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2013-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2013-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2013-8- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-8- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2013-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2013-9- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2013-9- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2013-9- | Head lamp levelizer | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2013-9- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2014 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2014 | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2014 | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2014 | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014 | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2014-12- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2014-12- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2014-12- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2014-12- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2014-12- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Adaptive light | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2014-12- | CAN gateway | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2014-12- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-12- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2014-4- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2014-4- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2014-4- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2014-4- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2014-4- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-4- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2014-4- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2014-4- | CAN gateway | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2014-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2014-5- | BCM | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2014-5- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-5- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2014-5- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2014-5- | CAN gateway | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2014-7- | Meter/M&A | x | x | x | 0143, 0330, 0197, 0331 |
| Infiniti QX50 \ J50 \ 2014-7- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2014-7- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2014-7- | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2014-7- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Sonar | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2014-7- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | CAN gateway | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2014-7- | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2014-7- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2015 | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2015 | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2015 | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti QX50 \ J50 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2015-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2015-11- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2015-11- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2015-11- | Multi AV | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2015-11- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-11- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2015-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2015-12- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2015-12- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2015-12- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2015-12- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX50 \ J50 \ 2016 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2016 | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2016 | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2016 | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2016-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2016-1- | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2016-1- | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | ICC/ADAS | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2016-1- | Multi AV | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | EPS/DAST 3 | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Laser/radar | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Precrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Accele pedal ACT | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX50 \ J50 \ 2016-1- | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2016-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Engine | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX50 \ J50 \ 2017 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX50 \ J50 \ 2017 | BCM | x | x | | |
| Infiniti QX50 \ J50 \ 2017 | Air bag | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Transmission | x | x | x | 0059 |
| Infiniti QX50 \ J50 \ 2017 | Multi AV | x | x | x | 0280 |
| Infiniti QX50 \ J50 \ 2017 | IPDM E/R | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Air pressure monitor | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Preocrash seatbelt | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Auto drive position | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | All mode AWD/4WD | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Sonar | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Lane camera | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Adaptive light | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Accele pedal ACT | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Side radar left | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Side radar right | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | BSW/buzzer | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | AVM | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Head lamp levelizer | x | x | x | |
| Infiniti QX50 \ J50 \ 2017 | Occupant detection | | | x | |
| Infiniti QX56 \ JA60 \ 2004 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2004 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2004 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2004 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2004 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2004 | EPS/DAST 3 | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |

| | | | | | |
|---------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2004 | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | AVM | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2004 | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2004 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2004 | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2004 | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2004-10- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2004-10- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2004-10- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2004-10- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2004-10- | EPS/DAST 3 | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2004-10- | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | AVM | x | x | x | |

| | | | | | |
|---------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2004-10- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2004-10- | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2004-10- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2004-10- | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2005 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2005 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2005 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2005 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2005 | EPS/DAST 3 | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2005 | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | AVM | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2005 | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2005 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2005 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2005 | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2005 | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Engine | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2006 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2006 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2006 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2006 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2006 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2006 | EPS/DAST 3 | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2006 | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | AVM | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2006 | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2006 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2006 | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2006 | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2006-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2006-8- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2006-8- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2006-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2006-8- | EPS/DAST 3 | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2006-8- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2006-8- | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | AVM | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2006-8- | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2006-8- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2006-8- | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX56 \ JA60 \ 2007 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2007 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2007 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Transmission | x | x | x | 0076, 0059, 0100, 0083, 0059, 0113 |
| Infiniti QX56 \ JA60 \ 2007 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2007 | EPS/DAST 3 | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2007 | DIU | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Auto slide door | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | All mode AWD/4WD | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2007 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Lane camera | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Adaptive light | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | AVM | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Nats immu | x | x | | |
| Infiniti QX56 \ JA60 \ 2007 | Smart entrance | x | x | | |
| Infiniti QX56 \ JA60 \ 2007 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2007 | S/blind camera | | | x | |
| Infiniti QX56 \ JA60 \ 2007 | Motor assist | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2007-7- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2007-7- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2007-7- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2007-7- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2007-7- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-7- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2007-8- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2007-8- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2007-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2007-8- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |

| | | | | | |
|--------------------------------|---------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2007-8- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2007-8- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2008 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2008 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2008 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2008 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2008 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2008 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2008-4- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2008-4- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2008-4- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2008-4- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2008-4- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Difference lock | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2008-4- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2008-4- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2009 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2009 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2009 | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2009 | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2009 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2009 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2009-4- | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2009-4- | HVAC | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2009-4- | Multi AV | x | x | x | 0280 |
| Infiniti QX56 \ JA60 \ 2009-4- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Intelligent key | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2009-4- | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2010 | Engine | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Meter/M&A | x | x | x | 0331, 0143 |
| Infiniti QX56 \ JA60 \ 2010 | BCM | x | x | | |
| Infiniti QX56 \ JA60 \ 2010 | HVAC | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ JA60 \ 2010 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ JA60 \ 2010 | Multi AV | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Intelligent key | x | x | x | 0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344 |
| Infiniti QX56 \ JA60 \ 2010 | Auto drive position | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | ABS | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Air bag | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Difference lock | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Sonar | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Air levelizer | x | x | x | |
| Infiniti QX56 \ JA60 \ 2010 | Rearview camera | | | x | |
| Infiniti QX56 \ JA60 \ 2010 | S/blind camera | | | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX56 \ Z62 \ 2010-3- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-3- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | HVAC | x | x | x | 0027, 0297, 0024, 0308, 0229, 0228, 0285, 0151, 0140, 0048, 0098, 0067 |
| Infiniti QX56 \ Z62 \ 2010-3- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2010-3- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-3- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Sonar | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2010-3- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | Rearview camera | | | x | |
| Infiniti QX56 \ Z62 \ 2010-3- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2010-5- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX56 \ Z62 \ 2010-5- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-5- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2010-5- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2010-5- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-5- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2010-5- | Rearview camera | | | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX56 \ Z62 \ 2010-6- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-6- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2010-6- | Transmission | x | x | x | 0059 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2010-6- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2010-6- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2010-6- | Rearview camera | | | x | |
| Infiniti QX56 \ Z62 \ 2011 | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX56 \ Z62 \ 2011 | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2011 | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2011 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2011 | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2011 | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | E-SUS | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2011 | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011 | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2011 | Rearview camera | | | x | |
| Infiniti QX56 \ Z62 \ 2011 | HVAC | x | x | x | 0027, 0297, 0024, 0308, 0229, 0228, 0285, 0151, 0140, 0048, 0098, 0067 |
| Infiniti QX56 \ Z62 \ 2011-10- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX56 \ Z62 \ 2011-10- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-10- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2011-10- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2011-10- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-10- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-10- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2011-7- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-7- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2011-7- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2011-7- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-7- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-7- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2011-8- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-8- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2011-8- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2011-8- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2011-8- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Side radar right | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2011-8- | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2011-8- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2011-8- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012 | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012 | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012 | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012 | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012 | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012 | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-1- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-1- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-1- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Air pressure monitor | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2012-1- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-1- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Transmission | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012-1- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-1- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-10- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-10- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-10- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012-10- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-10- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Accele pedal ACT | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2012-10- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2012-10- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-10- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-11- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-11- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-11- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012-11- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-11- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-11- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-3- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-3- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-3- | Transmission | x | x | x | 0059 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2012-3- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-3- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-3- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-4- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-4- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-4- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012-4- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-4- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Side radar right | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2012-4- | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2012-4- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-4- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2012-8- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-8- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2012-8- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2012-8- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2012-8- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2012-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2013 | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2013 | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2013 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2013 | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | IPDM E/R | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2013 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2013 | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2013 | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Difference lock | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013 | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2013-1- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2013-1- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2013-1- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2013-1- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2013-1- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | E-SUS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2013-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2013-1- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-1- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX56 \ Z62 \ 2013-2- | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2013-2- | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2013-2- | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2013-2- | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Precrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2013-2- | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Difference lock | x | x | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | Occupant detection | | | x | |
| Infiniti QX56 \ Z62 \ 2013-2- | SVT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Engine | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | ABS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |

| | | | | | |
|--|----------------------|---|---|---|--|
| Infiniti QX56 \ Z62 \ 2014 | BCM | x | x | | |
| Infiniti QX56 \ Z62 \ 2014 | Air bag | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX56 \ Z62 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti QX56 \ Z62 \ 2014 | Multi AV | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Laser/radar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Sonar | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Adaptive light | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | CAN gateway | x | x | | |
| Infiniti QX56 \ Z62 \ 2014 | Auto back door | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | E-SUS | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Side radar left | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Side radar right | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti QX56 \ Z62 \ 2014 | AVM | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Difference lock | x | x | x | |
| Infiniti QX56 \ Z62 \ 2014 | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Multi AV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Laser/radar | x | x | x | |

| | | | | | |
|--|---------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2013-11- | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Multi AV | x | x | x | 0280 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | HV battery | x | x | x | |

| | | | | | |
|--|----------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2014 | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2014 | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014 | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Multi AV | x | x | x | 0280 |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | BSW/buzzer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | Air pressure monitor | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | ANC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | HIGH BEAM ASSIST | | x | x | |

| | | | | | |
|--|---------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2014-10- | PMAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Multi AV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-4- | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Multi AV | x | x | x | 0280 |

| | | | | | |
|---------------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | BSW/buzzer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2014-9- | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 hybrid \ HL50 \ 2015 | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Multi AV | x | x | x | 0280 |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2015 | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Lane camera | x | x | x | |

| | | | | | |
|------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2015 | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2015 | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 hybrid \ HL50 \ 2016 | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Multi AV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | ANC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Side radar right | x | x | x | |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2016 | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016 | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Multi AV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Air pressure monitor | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | ANC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | PTC heater | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Occupant detection | | | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-1- | Telematics | x | x | x | 0253 |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Engine | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | ABS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |

| | | | | | |
|---------------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | BCM | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Air bag | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | ICC/ADAS | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | HVAC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Transmission | x | x | x | 0059 |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Motor control | x | x | x | 0238 |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | IPDM E/R | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Air pressure monitor | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Laser/radar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Auto drive position | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Sonar | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Lane camera | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | CAN gateway | x | x | | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | EV/HEV | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Auto back door | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | HV battery | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Side radar left | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | VSP | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | ANC | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Side radar right | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | AVM | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 hybrid \ HL50 \ 2016-8- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2013-11- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2013-11- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | IPDM E/R | x | x | x | |

| | | | | | |
|--------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2013-11- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2013-11- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-11- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2013-7- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2013-7- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Multi AV | x | x | x | 0280 |
| Infiniti QX60 \ L50 \ 2013-7- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2013-7- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2013-7- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2013-7- | Occupant detection | | | x | |

| | | | | | |
|-------------------------------|---------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2014 | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX60 \ L50 \ 2014 | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2014 | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Multi AV | x | x | x | 0280 |
| Infiniti QX60 \ L50 \ 2014 | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2014 | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2014 | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2014 | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2014-1- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2014-1- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Multi AV | x | x | x | 0280 |
| Infiniti QX60 \ L50 \ 2014-1- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Preocrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2014-1- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2014-1- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2014-1- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-1- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX60 \ L50 \ 2014-12- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2014-12- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2014-12- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | BSW/buzzer | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2014-12- | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-12- | VSP | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2014-12- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2014-9- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2014-9- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2014-9- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2014-9- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | VSP | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2014-9- | BSW/buzzer | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2014-9- | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2015 | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2015 | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Multi AV | x | x | x | 0280 |
| Infiniti QX60 \ L50 \ 2015 | EPS/DAST 3 | x | x | x | |

| | | | | | |
|----------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2015 | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2015 | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2016 | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2016 | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2016 | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2016 | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | ANC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Side radar right | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2016 | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2016 | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2016-1- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2016-1- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Transmission | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2016-1- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | ANC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2016-1- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2016-5- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2016-5- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2016-5- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Transmission | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX60 \ L50 \ 2016-5- | Multi AV | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | CAN gateway | x | x | | |
| Infiniti QX60 \ L50 \ 2016-5- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | ANC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Telematics | x | x | x | 0253 |
| Infiniti QX60 \ L50 \ 2016-5- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-5- | Occupant detection | | | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Engine | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | ABS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX60 \ L50 \ 2016-8- | BCM | x | x | | |
| Infiniti QX60 \ L50 \ 2016-8- | Air bag | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | ICC/ADAS | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | HVAC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Transmission | x | x | x | 0059 |
| Infiniti QX60 \ L50 \ 2016-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX60 \ L50 \ 2016-8- | Motor control | x | x | x | 0238 |
| Infiniti QX60 \ L50 \ 2016-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | IPDM E/R | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Air pressure monitor | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Laser/radar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Auto drive position | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Sonar | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Lane camera | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | CAN gateway | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX60 \ L50 \ 2016-8- | EV/HEV | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Auto back door | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | HV battery | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Side radar left | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | VSP | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | ANC | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Side radar right | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | AVM | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX60 \ L50 \ 2016-8- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2013-5- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2013-5- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2013-5- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2013-5- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2013-5- | Multi AV | x | x | x | 0280 |
| Infiniti QX70 \ S51 \ 2013-5- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2013-7- | Engine | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2013-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2013-7- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2013-7- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2013-7- | Multi AV | x | x | x | 0280 |
| Infiniti QX70 \ S51 \ 2013-7- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2013-7- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2013-7- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2013-7- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2013-9- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2013-9- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2013-9- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Sonar | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2013-9- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2013-9- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2013-9- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2014 | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2014 | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2014 | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2014 | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2014 | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2014 | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2014 | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2014-3- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2014-3- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | ICC/ADAS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2014-3- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2014-3- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2014-3- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Side radar left | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Side radar right | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2014-3- | BSW/buzzer | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2014-3- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-3- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2014-5- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2014-5- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2014-5- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | All mode AWD/4WD | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2014-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2014-5- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Side radar left | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Side radar right | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2014-5- | BSW/buzzer | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2014-5- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2015 | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2015 | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015 | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015 | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015 | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015 | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015 | Occupant detection | | | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2015-10- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2015-10- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015-10- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015-10- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015-10- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | 4WAS(front) | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Side radar left | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Side radar right | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015-10- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2015-3- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015-3- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015-3- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | IPDM E/R | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2015-3- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015-3- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | 4WAS(front) | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2015-3- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015-3- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2015-5- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015-5- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015-5- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015-5- | Auto back door | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2015-5- | 4WAS(front) | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Telematics | x | x | x | 0253 |
| Infiniti QX70 \ S51 \ 2015-5- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015-5- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2015-6- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015-6- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015-6- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015-6- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | 4WAS(front) | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Side radar left | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Side radar right | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015-6- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | ABS | x | x | x | 0003, 0092, 0264 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------|
| Infiniti QX70 \ S51 \ 2015-8- | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2015-8- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2015-8- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2015-8- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2015-8- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2016 | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2016 | Meter/M&A | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2016 | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2016 | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Lane camera | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX70 \ S51 \ 2016 | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2016 | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | 4WAS(front) | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2016 | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2016 | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2016-5- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX70 \ S51 \ 2016-5- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2016-5- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2016-5- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2016-5- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2016-5- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2016-7- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX70 \ S51 \ 2016-7- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2016-7- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2016-7- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2016-7- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2016-7- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2016-8- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX70 \ S51 \ 2016-8- | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2016-8- | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2016-8- | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | 4WAS(MAIN)/RAS/HICAS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|------------------------|
| Infiniti QX70 \ S51 \ 2016-8- | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2016-8- | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2016-8- | Occupant detection | | | x | |
| Infiniti QX70 \ S51 \ 2017 | Engine | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | ABS | x | x | x | 0003, 0092, 0264 |
| Infiniti QX70 \ S51 \ 2017 | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX70 \ S51 \ 2017 | BCM | x | x | | |
| Infiniti QX70 \ S51 \ 2017 | Air bag | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | ICC/ADAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Transmission | x | x | x | 0059 |
| Infiniti QX70 \ S51 \ 2017 | Multi AV | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | EPS/DAST 3 | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | IPDM E/R | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Air pressure monitor | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Laser/radar | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Preocrash seatbelt | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Auto drive position | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | All mode AWD/4WD | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | 4WAS(MAIN)/RAS/HICAS | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Sonar | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Lane camera | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Adaptive light | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | CAN gateway | x | x | | |
| Infiniti QX70 \ S51 \ 2017 | Auto back door | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | E-SUS | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Accele pedal ACT | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | AVM | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Head lamp levelizer | x | x | x | |
| Infiniti QX70 \ S51 \ 2017 | Total illum C/U | | | x | |
| Infiniti QX70 \ S51 \ 2017 | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | ABS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2013-6- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2013-6- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2013-6- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2013-6- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2013-6- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2013-6- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2013-6- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2013-6- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-6- | SVT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2013-8- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2013-8- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2013-8- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2013-8- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | IPDM E/R | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2013-8- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2013-8- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2013-8- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2013-8- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2014 | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2014 | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2014 | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2014 | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2014 | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2014 | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | E-SUS | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2014 | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2014 | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014 | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2014-1- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-1- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2014-1- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2014-1- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-1- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2014-1- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-1- | Occupant detection | | | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2014-11- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Meter/M&A | x | x | x | 0331, 0330, 0197, 0143 |
| Infiniti QX80 \ Z62 \ 2014-11- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-11- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2014-11- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2014-11- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Motor control | x | x | x | 0238 |
| Infiniti QX80 \ Z62 \ 2014-11- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-11- | EV/HEV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | HV battery | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | VSP | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-11- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2014-8- | BCM | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2014-8- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2014-8- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2014-8- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-8- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2014-8- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-8- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2014-9- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-9- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2014-9- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2014-9- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | IPDM E/R | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2014-9- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2014-9- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2014-9- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2014-9- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2015 | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2015 | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2015 | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2015 | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2015 | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Lane camera | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2015 | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2015 | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2015 | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015 | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2015-10- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-10- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2015-10- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2015-10- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-10- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | 4WAS(front) | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Side radar left | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2015-10- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2015-10- | Meter/M&A | x | x | x | 0143, 0331, 0330, 0197, 0143, 0331 |
| Infiniti QX80 \ Z62 \ 2015-10- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2015-11- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Meter/M&A | x | x | x | 0143, 0331, 0330, 0197, 0143, 0331 |
| Infiniti QX80 \ Z62 \ 2015-11- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-11- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2015-11- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2015-11- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2015-11- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-11- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | 4WAS(front) | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Head lamp levelizer | x | x | x | |

| | | | | | |
|--------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2015-11- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-11- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Meter/M&A | x | x | x | 0143, 0331, 0330, 0197, 0143, 0331 |
| Infiniti QX80 \ Z62 \ 2015-12- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-12- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2015-12- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2015-12- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2015-12- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-12- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | 4WAS(front) | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-12- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Meter/M&A | x | x | x | 0143, 0331, 0330, 0197, 0143, 0331 |
| Infiniti QX80 \ Z62 \ 2015-8- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-8- | Air bag | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2015-8- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2015-8- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2015-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2015-8- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2015-8- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | 4WAS(front) | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2015-8- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2016 | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Meter/M&A | x | x | x | 0143, 0331, 0330, 0197, 0143, 0331 |
| Infiniti QX80 \ Z62 \ 2016 | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2016 | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | HVAC | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2016 | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2016 | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Air pressure monitor | x | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2016 | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2016 | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2016 | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016 | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2016-2- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2016-2- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2016-2- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2016-2- | Multi AV | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | EPS/DAST 3 | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Preocrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | CAN gateway | x | x | | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2016-2- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Telematics | x | x | x | 0253 |
| Infiniti QX80 \ Z62 \ 2016-2- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-2- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2016-8- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2016-8- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2016-8- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2016-8- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2016-8- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2016-8- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | HIGH BEAM ASSIST | | x | x | |

| | | | | | |
|-------------------------------|----------------------|---|---|---|--|
| Infiniti QX80 \ Z62 \ 2016-8- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2016-8- | Air levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Engine | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | ABS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Meter/M&A | x | x | x | 0143, 0197, 0330, 0331 |
| Infiniti QX80 \ Z62 \ 2016-9- | BCM | x | x | | |
| Infiniti QX80 \ Z62 \ 2016-9- | Air bag | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | ICC/ADAS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | HVAC | x | x | x | 0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308 |
| Infiniti QX80 \ Z62 \ 2016-9- | Transmission | x | x | x | 0059 |
| Infiniti QX80 \ Z62 \ 2016-9- | Multi AV | x | x | x | 0280 |
| Infiniti QX80 \ Z62 \ 2016-9- | IPDM E/R | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Air pressure monitor | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Laser/radar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Precrash seatbelt | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Auto drive position | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | All mode AWD/4WD | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Sonar | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Lane camera | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Adaptive light | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | CAN gateway | x | x | | |
| Infiniti QX80 \ Z62 \ 2016-9- | Auto back door | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | E-SUS | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Accele pedal ACT | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Side radar left | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Side radar right | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | BSW/buzzer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | AVM | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | HIGH BEAM ASSIST | | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Head lamp levelizer | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Difference lock | x | x | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Occupant detection | | | x | |
| Infiniti QX80 \ Z62 \ 2016-9- | Air levelizer | x | x | x | |

Special Function Table

| | |
|------|---------------------|
| 0001 | ACCELERATION SENSOR |
|------|---------------------|

| | |
|------|--|
| 0002 | ACCUMULATOR PRESSURE DECREASES |
| 0003 | ACT OR DEACT ROLLER BENCH TEST MODE |
| 0004 | ACTIVATE EVAP SYSTEM |
| 0005 | ADAPTIVES AFTER REGENERATING PF |
| 0006 | ADAPTIVES ON AIR INTAKE FLAP MALFUNCTION |
| 0007 | AFTER CAMSHAFT POS SENSOR REPLACEMENT |
| 0008 | AFTER CLUCH PEDAL SWITCH REPLACEMENT |
| 0009 | AFTER CRANKSHAFT POS SENSOR REPLACEMENT |
| 0010 | AFTER DPF REGENERATION |
| 0011 | AFTER DPF REPLACEMENT |
| 0012 | AFTER FUEL INJECTOR REPLACEMENT |
| 0013 | AFTER FUEL RAIL PRESSURE SENSOR REPLACEMENT |
| 0014 | AFTER HIGH PRESSURE FUEL PUMP REPLACEMENT |
| 0015 | AFTER PRESSURE LINE REPLACEMENT |
| 0016 | AFTER TC SOLENOID VALVE REPLACEMENT |
| 0017 | AFTER TURBOCHARGER REPLACEMENT |
| 0018 | AFTR ELECTRIC THRRTL CNTRL ACTUATOR RPLCMNT |
| 0019 | AIR BLEEDING |
| 0020 | AIR DAMPER VALVE PROGRAMMING |
| 0021 | AIR DAMPER VALVE PROGRAMMING(R044) |
| 0022 | AIR DAMPER VALVE PROGRAMMING(R088) |
| 0023 | AIR FLOW METER PROGRAMMING |
| 0024 | AIR FLOW REDUCTION SETTING |
| 0025 | AIR FLOWMETER PROGRAMMING |
| 0026 | AIR FUEL RATIO SENSOR |
| 0027 | AIR INLET CHANGE SETTING |
| 0028 | AIR PATH PROGRAMMING |
| 0029 | ALTERNATOR SETPOINT VOLTAGE |
| 0030 | ANALOGIC DISPLAY FUEL GAUGE CALIBRATION |
| 0031 | ANSWER BACK FUNCTION |
| 0032 | AUTO RElock TIMER |
| 0033 | AUTO-ADAPTIVES |
| 0034 | AVERAGE AIR TEMPERATURE |
| 0035 | Adaptives after replacing cabin filter |
| 0036 | Adaptives on etc actuator malfunction |
| 0037 | After p/filter regen with diag tool |
| 0038 | After particle filter regeneration with the diag tool. |
| 0039 | After replacement of the p/filter |
| 0040 | After replacement of the particle filter |
| 0041 | Alcohol level prog. |

| | |
|------|---|
| 0042 | Answer back with i-key Unlock |
| 0043 | Answer back with i-key lock |
| 0044 | BATTERY CORROSION COUNTER |
| 0045 | BATTERY CYCLE COUNTER |
| 0046 | BATTERY CYCLE COUNTER ESTIMATED |
| 0047 | BATTERY CYCLE COUNTER MEMORISED |
| 0048 | BLOW SET |
| 0049 | BRAKE OPERATION |
| 0050 | BRAKE RELEASE |
| 0051 | BREAKING IN OF REFRIGERANT COMPRESSOR |
| 0052 | Backup of instrument panel data for injection |
| 0053 | Battery gradual cap loss data clear |
| 0054 | Bld hyd unit brk circ |
| 0055 | Bleed hydraulic unit and braking circuits |
| 0056 | Brake PRESSURE OFFSET SENSOR |
| 0057 | CALCULATE BATTERY WEAR COUNTERS(R011) |
| 0058 | CALCULATE BATTERY WEAR COUNTERS(S006) |
| 0059 | CALIB DATA |
| 0060 | CAMSHAFT REFERENCE ADAPTATION |
| 0061 | CAMSHAFT SENSOR PROGRAMMING |
| 0062 | CARAVAN TOWING DISTANCE |
| 0063 | CATALYTIC CONVERTER |
| 0064 | CC/SL PRGRM |
| 0065 | CHARGE CURRENT LIMITATION HISTORY |
| 0066 | CHECKING A KEY |
| 0067 | CLEAN SW SET |
| 0068 | CLTH INI CLOSE POS |
| 0069 | CLUTCH PEDAL END STROKE |
| 0070 | CLUTCH SENSOR RESET |
| 0071 | CML B/DCHRG CRNT CLEAR |
| 0072 | COMPUTER CALIBRATION |
| 0073 | COMPUTER INITIALISATION |
| 0074 | COMPUTER REINITIALISATION |
| 0075 | CONFIRM KEY FOB ID |
| 0076 | CONFORM CVTF DETERIORTN |
| 0077 | CORROSION BATTERY COUNTER ESTIMATED |
| 0078 | CORROSION BATTERY COUNTER MEMORISED |
| 0079 | CYLINDER 1 INJECTOR CODE |
| 0080 | CYLINDER 2 INJECTOR CODE |
| 0081 | CYLINDER 3 INJECTOR CODE |

| | |
|------|--|
| 0082 | CYLINDER 4 INJECTOR CODE |
| 0083 | Calib data |
| 0084 | Calibration of EPS torque sensor |
| 0085 | Clutch Point |
| 0086 | Commercial VHCL idle SPD mod |
| 0087 | Control deviation charge air system |
| 0088 | DAST CALIBRATION (MODE1) |
| 0089 | DAST CALIBRATION (MODE2) |
| 0090 | DATA CLEAR FOR REPLACING CPU A |
| 0091 | DATA CLEAR FOR REPLACING CPU B |
| 0092 | DECEL G SEN CALIBRATION |
| 0093 | DECREMENT IDLE SPEED |
| 0094 | DIFF EXH PRES. SEN |
| 0095 | DPF DATA CLEAR |
| 0096 | DPF REGENERATION |
| 0097 | DPF RELATIVE PRESSURE SENSOR |
| 0098 | Door motor starting position reset |
| 0099 | E/O CC/SL PRGRM |
| 0100 | ECO MODE RESET FUNCTION |
| 0101 | ECU MEMORY |
| 0102 | EEPROM CLEAR CONFIRM |
| 0103 | EGR ADAPTIVES |
| 0104 | EGR BYPASS PROGRAMMING |
| 0105 | EGR PROGRAMMING |
| 0106 | EGR VALVE |
| 0107 | EGR VALVE PROGRAMMING |
| 0108 | EGR control valve closed position learning |
| 0109 | EGR/V LEARN CLR |
| 0110 | ELECTRIC O.P. AIR BLEEDING |
| 0111 | ELECTRICAL CONTACT ACTUATORS/BRAKE CLEARANCE SETTING |
| 0112 | ENGINE ADAPTIVES |
| 0113 | ENGINE Brake ADJ. |
| 0114 | ENGINE COOLANT BYPASS VALVE |
| 0115 | ENGINE START BY I-KEY |
| 0116 | ERASE COMPUTER MEMORY |
| 0117 | ERASE LEARNING VALUE |
| 0118 | ERASE MEMORY DATA |
| 0119 | ERASE OVERHEAT COUNTER |
| 0120 | ERS INCRRCT CRNKNG CNTR |
| 0121 | ESP A-RECN THRSH |

| | |
|------|--|
| 0122 | ESP SENSOR PROGRAMMING |
| 0123 | EXHAUST AIR FLAP PROGRAMMING |
| 0124 | EXHAUST FLAP LOW SETTING |
| 0125 | EXHAUST FUEL INJECTOR CIRCUIT |
| 0126 | EXHAUST THROTTLE VALVE PROGRAMMING |
| 0127 | Exh fuel inj data clear |
| 0128 | FAST IDLE SPEED MODIFICATION |
| 0129 | FAULT MEMORY |
| 0130 | FINISH BRAKE PAD REPLACEMENT |
| 0131 | FLIPPER DOOR |
| 0132 | FLYWHEEL TARGET PROGRAMMING (R061) |
| 0133 | FLYWHEEL TARGET PROGRAMMING (R065) |
| 0134 | FLYWHEEL TARGET PROGRAMMING (R102) |
| 0135 | FLYWHEEL TARGET PROGRAMMING (R103) |
| 0136 | FLYWHEEL TARGET PROGRAMMING (R104) |
| 0137 | FLYWHEEL TARGET PROGRAMMING (R105) |
| 0138 | FLYWHEEL TARGET PROGRAMMING (R106) |
| 0139 | FLYWHL TGT PG |
| 0140 | FRE MEMORY SET |
| 0141 | FRONT OR REAR SENSOR LOCALIZATION WAS UNSUCCESSFUL |
| 0142 | FUEL GAUGE CALIBRATION |
| 0143 | FUEL METER DIAGNOSIS(ANALOG POINTER) |
| 0144 | FUEL PRESSURE RELEASE |
| 0145 | FUEL PUMP PROGRAMMING |
| 0146 | FUEL RAIL PRESS LIMITING INJCTN COUNTR CLEAR |
| 0147 | FUEL RAIL PRESSURE TEST |
| 0148 | FUEL SPLY PREV |
| 0149 | FWD CLUTCH POINT LEARNING |
| 0150 | G SENSOR CALIBRATION |
| 0151 | GAS SENSOR ADJUSTMENT |
| 0152 | H/P FUEL PUMP TOTAL STARTS COUNTER CLEAR |
| 0153 | H/p fuel pump initial starts counter reset |
| 0154 | H/p fuel pump total starts counter reset |
| 0155 | HANDS-FREE CARD READING |
| 0156 | HAZARD ANSWER BACK |
| 0157 | HIGH PRESSURE PUMP COUNTER |
| 0158 | HIGH PRESSURE PUMP COUNTER (V344) |
| 0159 | HIGH PRESSURE TURBINE BYPASS SOLENOID VALVE |
| 0160 | HILL START |
| 0161 | HP TURBINE BYPASS SOL VLV PROGRAMMING |

| | |
|------|---|
| 0162 | High pressure fuel circuit fault finding |
| 0163 | INCREMENT IDLE SPEED |
| 0164 | INHIBIT EVAP SYSTEM |
| 0165 | INITIALIZATION POSITION ADJUSTMENT |
| 0166 | INJECTION PUMP ADAPTATIVES |
| 0167 | INJECTION PUMP ADAPTATIVES (R077) |
| 0168 | INJECTOR ADAPTIVES |
| 0169 | INLET FLAP |
| 0170 | KEYLESS FUNCTION |
| 0171 | LCD DISPLAY FUEL GAUGE CALIBRATION |
| 0172 | LEARNING |
| 0173 | LONGITUDINAL ACCELERATION SENSOR |
| 0174 | LONGITUDINAL ACCELERATION SENSOR OFFSET |
| 0175 | Low batt of key fob warn |
| 0176 | Low pressure egr valve programming |
| 0177 | MANIFOLD PRESSURE SENSOR PROGRAMMING |
| 0178 | MEMORISATION OF SPEEDS |
| 0179 | MULTIPLEXED NETWORK CONFIGURATION |
| 0180 | NORMALIZATION |
| 0181 | NORMALIZATION OF ACTUATOR MOTORS |
| 0182 | NOTE OIL WEAR COUNTER |
| 0183 | NOX SENSOR 1 DATA CLEAR |
| 0184 | NOX SENSOR 2 DATA CLEAR |
| 0185 | NOX TRAP |
| 0186 | NUMBER OF STARTING |
| 0187 | NUMBER OF STARTING 1 |
| 0188 | NUMBER OF STARTING 2 |
| 0189 | NUMBER OF STARTING 3 |
| 0190 | NUMBER OF STARTING 4 |
| 0191 | NUMBER OF STARTING CYCLES |
| 0192 | NUMBER OF STARTING CYCLES (V343) |
| 0193 | OC DATA CLEAR |
| 0194 | OIL CHG INT(km) |
| 0195 | OPE TIME BASIC DIAG TEMP SEN UPSTREAM SCR CAT |
| 0196 | OPR TIME BASIC DIAG SCR CATALYSTIC CONVRTR |
| 0197 | OUTSIDE AIR TEMPERATURE DIAGNOSIS |
| 0198 | OXIDATION CATALYST DATA CLEAR |
| 0199 | Oil change interval in months |
| 0200 | Oil change range: in km |
| 0201 | Oil change range:current value in months |

| | |
|------|--|
| 0202 | Oil grade factor |
| 0203 | Oil service and odometry miles - km |
| 0204 | P position learning value clear |
| 0205 | P/FLT DIFF PRS SEN |
| 0206 | P062F EXCLUSIVE FUNCTION |
| 0207 | POWER SLIDE DOOR DELAY |
| 0208 | PREHEATER UNIT |
| 0209 | PRES REG ADAPTIVE |
| 0210 | PRESSURE REGULATION ADAPTIVES |
| 0211 | PRESSURE SENSOR CALIBRATION |
| 0212 | PRGRM REINITIALIZE |
| 0213 | PROGRAM CLUTCH OPEN POSITION |
| 0214 | PROGRAM REINITIALIZE |
| 0215 | PROGRAM SLIP POINT |
| 0216 | PROGRAMMED VALUES |
| 0217 | PROGRAMMING REINITIALISATION |
| 0218 | PROGRAMMING THE HANDS-FREE CARD |
| 0219 | PROGRAMMING THROTTLE LIMITS |
| 0220 | PRPR RICH SEN PROG |
| 0221 | PUMP PRESSURE REGULATOR TYPE |
| 0222 | PUMP lock/Unlock |
| 0223 | Programming selection/engaging zones |
| 0224 | Qk tch in zero qunty calib val while driving |
| 0225 | RAIL PRESSURE SENSOR ADAPTIVES |
| 0226 | RAIL PRS SEN ADAPTIVES |
| 0227 | READ VIN |
| 0228 | REAR TEMP SET CORRECT |
| 0229 | REC MEMORY SET |
| 0230 | REGULATION WASTE GATE |
| 0231 | REMOVE ADAPTATIONS VALUE OF SHIFT OPERATIONS |
| 0232 | REPLACE DIESEL PARTICULATE FILTER |
| 0233 | RESET INJCTR ADAPTATIVE |
| 0234 | RESET PUMP FORCEFEEDING |
| 0235 | RESETTING CENTER POSITION OF STEERING |
| 0236 | RESETTING INTERNAL PROTECTION |
| 0237 | RESETTING OF ADAPTION VALUES |
| 0238 | RESOLVER OFFSET |
| 0239 | RESTART THE COMPUTER |
| 0240 | REVERSING CAMERA CALIBRATION |
| 0241 | RICHNESS REGULATION PROGRAMMING |

| | |
|------|--|
| 0242 | ROOF LATCH |
| 0243 | ROOF STATE RESET |
| 0244 | ROOF/TRUNK/PARCEL SHELF |
| 0245 | RPS OFFSET LEARNING VALUE CLEAR |
| 0246 | Re learning |
| 0247 | Reset |
| 0248 | Reset of contamination level of air filter |
| 0249 | Reset of learned values of cmsft hall SEN |
| 0250 | Reverse gear reset of adaption values |
| 0251 | SAVE BATTERY INFORMATION DATA |
| 0252 | SAVE COMPUTER DATA |
| 0253 | SAVE VIN DATA |
| 0254 | SCR CAT AMOUNT OF UREA ADSORPT DATA CLEAR |
| 0255 | SCR CATALYST DATA CLEAR |
| 0256 | SCR CATALYST TEMP SENSOR 1 DATA CLEAR |
| 0257 | SCR MALFUNCTION HISTORY RESET |
| 0258 | SELECTIVE Unlock FUNCTION |
| 0259 | SENSOR CONFIGURATION |
| 0260 | SERVIC REGENERATION |
| 0261 | SET AUTOLOCATION DISABLE |
| 0262 | SPEED LIMITER |
| 0263 | SPEEDO INDEX |
| 0264 | ST ANGLE SENSOR ADJUSTMENT |
| 0265 | START BRAKE PAD REPLACEMENT |
| 0266 | STARTER OPERATION COUNTER CLEAR |
| 0267 | STATUS OF TEACH IN PROCESSES |
| 0268 | STEERING WHEEL ANGLE SENSOR |
| 0269 | STEERING WHL ANGLE SEN |
| 0270 | STOP AND START FUNCTION |
| 0271 | STORED ENERGY MANAGEMENT DATA |
| 0272 | STP FUEL SPLY PREV |
| 0273 | STROKE SENSOR CALIBRATION |
| 0274 | STRT OPRTN CNTR CLEAR |
| 0275 | SWIRL FLAP |
| 0276 | SWIRL FLAP PROGRAMMING |
| 0277 | SYSTEM MODE CHANGE |
| 0278 | Saving data for replc cpu |
| 0279 | Sc magnetic clutch engage count clear |
| 0280 | St ang sen adjustment |
| 0281 | Start obd test: catalytic converter |

| | |
|------|--|
| 0282 | Start obd test: o2 sensors |
| 0283 | Static Test |
| 0284 | Steering wheel angle offset sensor |
| 0285 | Stop/start system operation cond setting |
| 0286 | TABLE INITIALIZATION ASSYST |
| 0287 | TACHOMETRIC INDEX |
| 0288 | TARGET IDLE RPM ADJ |
| 0289 | TARGET IGN TIM ADJ |
| 0290 | TEACH IN AFTER REPLAC ADBLUE METERING VALVE |
| 0291 | TEACH IN BOOST PRESSURE POSITIONER |
| 0292 | TEACH IN COMBINATION METER |
| 0293 | TEACH IN OF ACTUATOR MOTORS |
| 0294 | TEACH IN OF CAMSHAFT POSITION |
| 0295 | TEACH IN OF DPF AFTER REPLACE OF CDI C/U |
| 0296 | TEACH IN OF SENSOR ROTOR ADAPTATION |
| 0297 | TEMP SET CORRECT |
| 0298 | THERMOPLUNGER |
| 0299 | THERMOPLUNGER PROGRAMMING |
| 0300 | TP POS LEARN CLR |
| 0301 | TRANSFER OF MANUFACTURER DEFAULT SETTINGS |
| 0302 | TRANSVERSE ACCELERATION OFFSET SENSOR |
| 0303 | TRUNK OPEN DELAY |
| 0304 | TRUNK OPENER |
| 0305 | TRUNK/GLASS HATCH OPEN |
| 0306 | TURBOCHARGER PROGRAMMING |
| 0307 | Take out from window warn |
| 0308 | Target evaporator temp upper limit setting |
| 0309 | Teach in of selection range sensor |
| 0310 | Teach in of throttle valve stop |
| 0311 | UNIT CHARACTERISTICS DATA |
| 0312 | UPDATE ODOMETER |
| 0313 | UREA INJECTOR DATA CLEAR |
| 0314 | UREA INJECTOR LEARNING VALUE CLEAR |
| 0315 | UREA PUMP LEARNINNG VALUE CLEAR |
| 0316 | UREA TANK UNIT ASSEMBLY LEARNING VALUE CLEAR |
| 0317 | Unlock COMPUTER |
| 0318 | Unlock INJECTOR CONTROL |
| 0319 | VACUUM PUMP |
| 0320 | VALVE CALIBRATION |
| 0321 | VALVE CHECK |

| | |
|------|--|
| 0322 | VARIABLE VALVE TIMING |
| 0323 | VEH. SPEED AT INITIALISATION |
| 0324 | VEHICLE FUNC PROG |
| 0325 | VEHICLE PARAMETERS |
| 0326 | VIN REGISTRATION |
| 0327 | VOLUME CONTROL VALVE LEARNING VALUE CLEAR |
| 0328 | Valve timing offset data clear |
| 0329 | Valve timing offset data writing |
| 0330 | W/L ON HISTORY |
| 0331 | WARNING LAMP DIAGNOSIS |
| 0332 | WRITE H/P FUEL PUMP TOTAL STARTS COUNT |
| 0333 | WRITE STARTER OPERATION COUNT |
| 0334 | Write date new clutch fitted |
| 0335 | Write date of after sales operation |
| 0336 | Write date of last after sales ope |
| 0337 | Write transmission oil change date |
| 0338 | Writing of instrument panel data for injection |
| 0339 | Wrte clth ini close pos |
| 0340 | ZFC VALUE RESET |
| 0341 | lock COMPUTER |
| 0342 | lock INJECTOR CONTROL |
| 0343 | lock INJECTOR CTRL |
| 0344 | lock/Unlock BY I-KEY |