

MITSUBISHI

Table of Contents

1	Vehicle models covered.....	1
2	Vehicle systems covered	10
3	Vehicle Special Function covered	12
4	Vehicle Coding Function covered	17

1 Vehicle models covered

Year	Model	Type
Up to 2005 MY	Most of Models	Most of Types
From 2006 MY	380	DL1A
From 2006 MY	ADVENTURE	VB2W
From 2006 MY	ASX	GA1W
From 2006 MY	ASX	GA2W
From 2006 MY	ASX	GA3W
From 2006 MY	ASX	GA6W
From 2006 MY	ASX	GA8W
From 2006 MY	ASX / OUTLANDER SPORT / RVR	GA1W
From 2006 MY	ASX / OUTLANDER SPORT / RVR	GA2W
From 2006 MY	ASX / OUTLANDER SPORT / RVR	GA3W
From 2006 MY	ASX / OUTLANDER SPORT / RVR	GA6W
From 2006 MY	ASX / OUTLANDER SPORT / RVR	GA8W
From 2006 MY	ATTRAGE	A13A
From 2006 MY	ATTRAGE / MIRAGE G4 / MIRAGE (A1#)	A13A
From 2006 MY	CHALLENGER (K9#)	K96W
From 2006 MY	CHALLENGER (KG#,KH#)	KG4W
From 2006 MY	CHALLENGER (KG#,KH#)	KH4W
From 2006 MY	CHARIOT	N83W
From 2006 MY	CHARIOT	N87W
From 2006 MY	COLT	ABA-Z23A
From 2006 MY	COLT	CBA-Z27A
From 2006 MY	COLT	CBA-Z27AG
From 2006 MY	COLT	DBA-Z21A
From 2006 MY	COLT	DBA-Z22A

Year	Model	Type
From 2006 MY	COLT	DBA-Z23A
From 2006 MY	COLT	DBA-Z23W
From 2006 MY	COLT	DBA-Z24A
From 2006 MY	COLT	DBA-Z24W
From 2006 MY	COLT	Z23A
From 2006 MY	COLT	Z27A
From 2006 MY	COLT CABRIOLET	Z36A
From 2006 MY	COLT CABRIOLET	Z37A
From 2006 MY	COLT CZC	Z36A
From 2006 MY	COLT CZC	Z37A
From 2006 MY	COLT PLUS	CBA-Z27W
From 2006 MY	COLT PLUS	CBA-Z27WG
From 2006 MY	COLT PLUS	DBA-Z21W
From 2006 MY	COLT PLUS	DBA-Z22W
From 2006 MY	COLT PLUS	DBA-Z23W
From 2006 MY	COLT PLUS	DBA-Z24W
From 2006 MY	COLT T120SS	U52T
From 2006 MY	COLT T120SS	U52W
From 2006 MY	COLT, COLT CZ3 / CZT	Z31A
From 2006 MY	COLT, COLT CZ3 / CZT	Z32A
From 2006 MY	COLT, COLT CZ3 / CZT	Z33A
From 2006 MY	COLT, COLT CZ3 / CZT	Z34A
From 2006 MY	COLT, COLT CZ3 / CZT	Z35A
From 2006 MY	COLT, COLT CZ3 / CZT	Z36A
From 2006 MY	COLT, COLT CZ3 / CZT	Z37A
From 2006 MY	COLT, COLT CZ3 / CZT	Z38A
From 2006 MY	COLT, COLT CZ3 / CZT	Z39A
From 2006 MY	COLT, COLT CZ3 / CZT	Z39V
From 2006 MY	COLT/COLT PLUS	Z21A
From 2006 MY	COLT/COLT PLUS	Z23A
From 2006 MY	COLT/COLT PLUS	Z23W
From 2006 MY	COLT/COLT PLUS	Z27A
From 2006 MY	COLT/COLT PLUS	Z27W
From 2006 MY	COLT/COLT PLUS	Z29W
From 2006 MY	DELICA D:5	CV4W
From 2006 MY	DELICA D:5	CV5W
From 2006 MY	DELICA D:5	DBA-CV2W
From 2006 MY	DELICA D:5	DBA-CV4W
From 2006 MY	DELICA D:5	DBA-CV5W
From 2006 MY	DELICA D:5	LDA-CV1W
From 2006 MY	DELICA Pick up	P14T
From 2006 MY	DELICA SPACE GEAR	GH-PD6W
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SK82LM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SK82MM

Year	Model	Type
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SK82TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SK82VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SKE6VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SKP2LM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SKP2MM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SKP2TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ABF-SKP2VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ADF-SKF2LM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ADF-SKF2MM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ADF-SKF2TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ADF-SKF2VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	ADF-SKF6VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KQ-SKF2TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KQ-SKF2VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF2LM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF2MM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF2TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF2VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF6MM
From 2006 MY	DELICA VAN / CARGO / TRUCK	KR-SKF6VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	TC-SK82LM
From 2006 MY	DELICA VAN / CARGO / TRUCK	TC-SK82MM
From 2006 MY	DELICA VAN / CARGO / TRUCK	TC-SK82TM
From 2006 MY	DELICA VAN / CARGO / TRUCK	TC-SK82VM
From 2006 MY	DELICA VAN / CARGO / TRUCK	TC-SKE6VM
From 2006 MY	DION	CR9W
From 2006 MY	ECLIPSE	DK2A
From 2006 MY	ECLIPSE	DK4A
From 2006 MY	ECLIPSE SPYDER	DK2A
From 2006 MY	ECLIPSE SPYDER	DK4A
From 2006 MY	EK-SPACE	DBA-B11A
From 2006 MY	EK-WAGON (B11W)	DBA-B11W
From 2006 MY	EK-WAGON (H81W)	CBA-H81W
From 2006 MY	EK-WAGON (H81W)	DBA-H81W
From 2006 MY	EK-WAGON (H82W)	CBA-H82W
From 2006 MY	EK-WAGON (H82W)	DBA-H82W
From 2006 MY	ENDEAVOR	D71W
From 2006 MY	ENDEAVOR	D81W
From 2006 MY	EXPRESS	PB4V
From 2006 MY	EXPRESS (PB#)	PB4V
From 2006 MY	EXPRESS / STAR WAGON (P0#,P1#)	P03V
From 2006 MY	EXPRESS / STAR WAGON (P0#,P1#)	P03W
From 2006 MY	EXPRESS / STAR WAGON (P0#,P1#)	P04V
From 2006 MY	EXPRESS / STAR WAGON (P0#,P1#)	P13V

Year	Model	Type
From 2006 MY	EXPRESS / STAR WAGON (P0#,P1#)	P14V
From 2006 MY	GALANT	DJ1A
From 2006 MY	GALANT	DJ3A
From 2006 MY	GALANT	DJ5A
From 2006 MY	GALANT	DM1A
From 2006 MY	GALANT (DJ#,DL#,DM#)	DJ1A
From 2006 MY	GALANT (DJ#,DL#,DM#)	DJ3A
From 2006 MY	GALANT (DJ#,DL#,DM#)	DJ6A
From 2006 MY	GALANT (DJ#,DL#,DM#)	DL1A
From 2006 MY	GALANT (DJ#,DL#,DM#)	DM1A
From 2006 MY	GALANT (EA#)	EA2A
From 2006 MY	GALANT (EA#)	EA5A
From 2006 MY	GALANT (EA#)	EA6A
From 2006 MY	GALANT (EA#)	EA7A
From 2006 MY	GALANT FORTIS	CBA-CY4A
From 2006 MY	GALANT FORTIS	DBA-CY3A
From 2006 MY	GALANT FORTIS	DBA-CY4A
From 2006 MY	GALANT FORTIS	DBA-CY6A
From 2006 MY	GALANT FORTIS SPORTBACK	CBA-CX4A
From 2006 MY	GALANT FORTIS SPORTBACK	DBA-CX3A
From 2006 MY	GALANT FORTIS SPORTBACK	DBA-CX4A
From 2006 MY	GALANT FORTIS SPORTBACK	DBA-CX6A
From 2006 MY	GRANDIS	DBA-NA4W
From 2006 MY	GRANDIS	NA4W
From 2006 MY	GRANDIS	NA8W
From 2006 MY	i	HA1W
From 2006 MY	i (アイ)	CBA-HA1W
From 2006 MY	i (アイ)	DBA-HA1W
From 2006 MY	i-MiEV	HA3V
From 2006 MY	i-MiEV	HA3W
From 2006 MY	i-MiEV	HA4V
From 2006 MY	i-MiEV	HA4W
From 2006 MY	i-MiEV	i-MiEV
From 2006 MY	i-MiEV	ZAA-HA3W
From 2006 MY	i-MiEV	ZAA-HA4W
From 2006 MY	L200 (K5#,K6#,K7#)	K62T
From 2006 MY	L200 (K5#,K6#,K7#)	K64T
From 2006 MY	L200 (K5#,K6#,K7#)	K65T
From 2006 MY	L200 (K5#,K6#,K7#)	K66T
From 2006 MY	L200 (K5#,K6#,K7#)	K67T
From 2006 MY	L200 (K5#,K6#,K7#)	K74T
From 2006 MY	L200 (K5#,K6#,K7#)	K75T
From 2006 MY	L200 (K5#,K6#,K7#)	K76T
From 2006 MY	L200 (K5#,K6#,K7#)	K77T

Year	Model	Type
From 2006 MY	L200 (K6#,K7#)	K64T
From 2006 MY	L200 (K6#,K7#)	K74T
From 2006 MY	L200 (K6#,K7#)	K75T
From 2006 MY	L200 (KA#,KB#)	KA4T
From 2006 MY	L200 (KA#,KB#)	KB4T
From 2006 MY	L300	P15V
From 2006 MY	L300 / DELICA Wagon	P03V
From 2006 MY	L300 / DELICA Wagon	P03W
From 2006 MY	L300 / DELICA Wagon	P04V
From 2006 MY	L300 / DELICA Wagon	P13V
From 2006 MY	L300 / DELICA Wagon	P13W
From 2006 MY	L300 / DELICA Wagon	P14V
From 2006 MY	L300 / DELICA Wagon	P14W
From 2006 MY	LANCER	CBA-CS5AZ
From 2006 MY	LANCER	CBA-CS6A
From 2006 MY	LANCER	CY4A
From 2006 MY	LANCER	CY5A
From 2006 MY	LANCER	DBA-CS2A
From 2006 MY	LANCER	GH-CT9A
From 2006 MY	LANCER	TA-CS5A
From 2006 MY	LANCER (CK#)	CK1A
From 2006 MY	LANCER (CK#)	CK3A
From 2006 MY	LANCER (CK#)	CK4A
From 2006 MY	LANCER (CK#)	CK5A
From 2006 MY	LANCER (CS#,CT#)	CS1A
From 2006 MY	LANCER (CS#,CT#)	CS2A
From 2006 MY	LANCER (CS#,CT#)	CS3A
From 2006 MY	LANCER (CS#,CT#)	CS5A
From 2006 MY	LANCER (CS#,CT#)	CS6A
From 2006 MY	LANCER (CS#,CT#)	CS7A
From 2006 MY	LANCER (CS#,CT#)	CS9A
From 2006 MY	LANCER (CS#,CT#)	CT9A
From 2006 MY	LANCER (CY#)	CY1A
From 2006 MY	LANCER (CY#)	CY2A
From 2006 MY	LANCER (CY#)	CY3A
From 2006 MY	LANCER (CY#)	CY4A
From 2006 MY	LANCER (CY#)	CY5A
From 2006 MY	LANCER (CY#)	CY6A
From 2006 MY	LANCER (CY#)	CY8A
From 2006 MY	LANCER (CY#)	CY9A
From 2006 MY	LANCER / LANCER EX (CY#)	CY1A
From 2006 MY	LANCER / LANCER EX (CY#)	CY2A
From 2006 MY	LANCER / LANCER EX (CY#)	CY3A
From 2006 MY	LANCER / LANCER EX (CY#)	CY4A

Year	Model	Type
From 2006 MY	LANCER / LANCER EX (CY#)	CY5A
From 2006 MY	LANCER / LANCER EX (CY#)	CY6A
From 2006 MY	LANCER / LANCER EX (CY#)	CY8A
From 2006 MY	LANCER CARGO	DBE-CS2V
From 2006 MY	LANCER EVOLUTION	CBA-CZ4A
From 2006 MY	LANCER EVOLUTION	CZ4A
From 2006 MY	LANCER SEDAN	CS6A
From 2006 MY	LANCER SEDAN	CS7A
From 2006 MY	LANCER SEDAN	CT9A
From 2006 MY	LANCER SPORTBACK	CX1A
From 2006 MY	LANCER SPORTBACK	CX2A
From 2006 MY	LANCER SPORTBACK	CX3A
From 2006 MY	LANCER SPORTBACK	CX4A
From 2006 MY	LANCER SPORTBACK	CX5A
From 2006 MY	LANCER SPORTBACK	CX6A
From 2006 MY	LANCER SPORTBACK	CX8A
From 2006 MY	LANCER SPORTBACK	CX9A
From 2006 MY	LANCER SPORTBACK (CS#)	CS7W
From 2006 MY	LANCER SPORTBACK (CX#)	CX4A
From 2006 MY	LANCER SPORTBACK (CX#)	CX5A
From 2006 MY	LANCER WAGON	CS3W
From 2006 MY	LANCER WAGON	CS7W
From 2006 MY	LANCER WAGON	CS9W
From 2006 MY	LANCER WAGON	DBA-CS2W
From 2006 MY	LANCER WAGON	GH-CT9W
From 2006 MY	LANCER WAGON	LA-CS5W
From 2006 MY	LANCER WAGON	TA-CS5W
From 2006 MY	MAVEN	UD1W
From 2006 MY	MINICA	CBA-H42A
From 2006 MY	MINICA	CBA-H47A
From 2006 MY	MINICA	DBA-H42A
From 2006 MY	MINICA	DBA-H47A
From 2006 MY	MINICA	GBD-H42V
From 2006 MY	MINICA	GBD-H47V
From 2006 MY	MINICA	HBD-H42V
From 2006 MY	MINICA	HBD-H47V
From 2006 MY	MINICAB / TOWNBOX	ABA-U61W
From 2006 MY	MINICAB / TOWNBOX	ABA-U62W
From 2006 MY	MINICAB / TOWNBOX	CBA-U61W
From 2006 MY	MINICAB / TOWNBOX	CBA-U62W
From 2006 MY	MINICAB / TOWNBOX	EBD-U61V
From 2006 MY	MINICAB / TOWNBOX	EBD-U62V
From 2006 MY	MINICAB / TOWNBOX	GBD-U61T
From 2006 MY	MINICAB / TOWNBOX	GBD-U62V

Year	Model	Type
From 2006 MY	MINICAB-MiEV	ZAB-U67V
From 2006 MY	MINICAB-MiEV	ZAB-U68T
From 2006 MY	MINICAB-MiEV	ZAB-U68V
From 2006 MY	MIRAGE	A03A
From 2006 MY	MIRAGE	DBA-A05A
From 2006 MY	MIRAGE (A0#)	A03A
From 2006 MY	MIRAGE (A1#)	A13A
From 2006 MY	MIRAGE / SPACE STAR (A0#)	A03A
From 2006 MY	MONTERO	V77W
From 2006 MY	OUTLANDER (CU#)	CU2W
From 2006 MY	OUTLANDER (CU#)	CU4W
From 2006 MY	OUTLANDER (CU#)	CU5W
From 2006 MY	OUTLANDER (CW#)	CW1W
From 2006 MY	OUTLANDER (CW#)	CW4W
From 2006 MY	OUTLANDER (CW#)	CW5W
From 2006 MY	OUTLANDER (CW#)	CW6W
From 2006 MY	OUTLANDER (CW#)	CW7W
From 2006 MY	OUTLANDER (CW#)	CW8W
From 2006 MY	OUTLANDER (CW#)	DBA-CW4W
From 2006 MY	OUTLANDER (CW#)	DBA-CW5W
From 2006 MY	OUTLANDER (CW#)	DBA-CW6W
From 2006 MY	OUTLANDER (GF#)	DBA-GF7W
From 2006 MY	OUTLANDER (GF#)	DBA-GF8W
From 2006 MY	OUTLANDER (GF#)	GF2W
From 2006 MY	OUTLANDER (GF#)	GF3W
From 2006 MY	OUTLANDER (GF#)	GF4W
From 2006 MY	OUTLANDER (GF#)	GF6V
From 2006 MY	OUTLANDER (GF#)	GF6W
From 2006 MY	OUTLANDER (GF#)	GF7W
From 2006 MY	OUTLANDER (GF#)	GF8W
From 2006 MY	OUTLANDER / OUTLANDER EX (CW#)	CW4W
From 2006 MY	OUTLANDER / OUTLANDER EX (CW#)	CW5W
From 2006 MY	OUTLANDER / OUTLANDER EX (CW#)	CW6W
From 2006 MY	OUTLANDER / OUTLANDER EX (CW#)	DBA-CW4W
From 2006 MY	OUTLANDER SPORT / RVR	GA2W
From 2006 MY	OUTLANDER-PHEV	DLA-GG2W
From 2006 MY	OUTLANDER-PHEV	GG2W
From 2006 MY	PAJERO (V6#,V7#)	ABA-V77W
From 2006 MY	PAJERO (V6#,V7#)	LA-V63W
From 2006 MY	PAJERO (V6#,V7#)	LA-V73W
From 2006 MY	PAJERO (V7#)	V77W
From 2006 MY	PAJERO (V7#)	V78W
From 2006 MY	PAJERO (V8#,V9#)	ADC-V88W
From 2006 MY	PAJERO (V8#,V9#)	ADC-V98W

Year	Model	Type
From 2006 MY	PAJERO (V8#,V9#)	CBA-V83W
From 2006 MY	PAJERO (V8#,V9#)	CBA-V87W
From 2006 MY	PAJERO (V8#,V9#)	CBA-V93W
From 2006 MY	PAJERO (V8#,V9#)	CBA-V97W
From 2006 MY	PAJERO (V8#,V9#)	DBA-V83W
From 2006 MY	PAJERO (V8#,V9#)	DBA-V93W
From 2006 MY	PAJERO (V8#,V9#)	LDA-V88W
From 2006 MY	PAJERO (V8#,V9#)	LDA-V98W
From 2006 MY	PAJERO (V8#,V9#)	V87W
From 2006 MY	PAJERO (V8#,V9#)	V88W
From 2006 MY	PAJERO (V8#,V9#)	V97W
From 2006 MY	PAJERO (V8#,V9#)	V98W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V63W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V64W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V65W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V66W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V67W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V68W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V73W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V74W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V75W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V76W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V77W
From 2006 MY	PAJERO / MONTERO (V6#,V7#)	V78W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V83W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V85W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V86W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V87W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V88V
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V88W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V93W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V95W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V96W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V97W
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V98V
From 2006 MY	PAJERO / MONTERO (V8#,V9#)	V98W
From 2006 MY	PAJERO iO	TA-H76W
From 2006 MY	PAJERO iO	TA-H77W
From 2006 MY	PAJERO iO / PAJERO TR4	H72W
From 2006 MY	PAJERO iO / PAJERO TR4	H77W
From 2006 MY	PAJERO MINI	ABA-H53A
From 2006 MY	PAJERO MINI	ABA-H58A
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K85W

Year	Model	Type
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K86W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K94W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K95W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K96W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K97W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K8#,K9#)	K99W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K9#)	K94W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (K9#)	K96W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (KH#)	KG4W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (KH#)	KH4W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (KH#)	KH6W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (KH#)	KH8W
From 2006 MY	PAJERO SPORT / MONTERO SPORT (KH#)	KH9W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KG4W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KG5W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KG6W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KH4W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KH6W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KH8W
From 2006 MY	PAJERO SPORT / NATIVA / MONTERO SPORT / CHALLENGER (KG#,KH#)	KH9W
From 2006 MY	RVR	DBA-GA3W
From 2006 MY	RVR	DBA-GA4W
From 2006 MY	SPACE STAR	A03A
From 2006 MY	SPACE STAR	A05A
From 2006 MY	TOPPO	CBA-H82A
From 2006 MY	TOPPO	DBA-H82A
From 2006 MY	TRITON	ABF-KB9T
From 2006 MY	TRITON (K6#,K7#)	K65T
From 2006 MY	TRITON (K6#,K7#)	K66T
From 2006 MY	TRITON (K6#,K7#)	K76T
From 2006 MY	TRITON (K6#,K7#)	K77T

Year	Model	Type
From 2006 MY	TRITON (KA#,KB#)	KA4T
From 2006 MY	TRITON (KA#,KB#)	KA5T
From 2006 MY	TRITON (KA#,KB#)	KA9T
From 2006 MY	TRITON (KA#,KB#)	KB4T
From 2006 MY	TRITON (KA#,KB#)	KB8T
From 2006 MY	TRITON (KA#,KB#)	KB9T
From 2006 MY	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	KA4T
From 2006 MY	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	KA5T
From 2006 MY	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	KA9T
From 2006 MY	TRITON / L200 / STRADA (KA#,KB#,KC#,KD#)	KB4T

2 Vehicle systems covered

System	DTC	Data List	Active Test	Special Func	Coding Func
MPI/GDI/DIESEL	X	X	X	X	X
IMMOBILIZER	X	X	X	X	X
AT/CVT/A-MT/TC-SST	X	X	X	X	X
SS4II	X	X	X	X	X
TCL/STABILITY CONTROL	X	X	X	X	X
AUTO CRUISE		X	X	X	X
4WS/Electric Power Steering	X	X	X	X	X
ABS/ASC/ASTC/WSS	X	X	X	X	X
AYC/ACD	X	X		X	
SRS-AIR BAG	X	X	X	X	X
Air Conditioner	X	X	X	X	
Lane Keep	X	X	X	X	
ETACS	X	X	X	X	X
KOS/IMMO/Keyless	X	X	X	X	X
EV/MiEV Remote System	X	X	X	X	
Compressor	X	X		X	
ACC/FCM	X	X		X	
KOS/OSS/IMMO/Keyless	X	X	X	X	X
DC/DC Converter	X	X		X	
TPMS	X	X		X	
Camera	X	X		X	
P LOCK		X		X	
Meter	X	X	X	X	X
Display	X	X	X	X	
Assist Battery				X	

System	DTC	Data List	Active Test	Special Func	Coding Func
Steering Angle Sensor				X	
PHEV	X	X	X	X	X
4WD	X	X		X	
AND	X			X	
AUDIO	X	X		X	
Multi Around Monitor	X	X	X	X	
RHT/Topstack	X	X	X	X	X
LIN	X	X		X	
Power Gate	X	X	X	X	
Keyless Operation	X	X	X	X	
KOS/IMMO/Keyless/TPMS	X	X	X	X	X
OCM	X	X		X	
SATELLITE RADIO	X			X	
HFM	X	X	X	X	
ELECTRIC SLIDE DOOR R	X	X	X	X	
ELECTRIC SLIDE DOOR L	X	X	X	X	
AFS/ACL/Leveling	X	X	X	X	X
Shift Lever	X	X	X	X	
CAN/LIN/SWS converter	X	X		X	
OBC	X	X		X	
BMU	X	X	X	X	
COMP&HTR	X	X	X	X	
EV-ECU	X	X	X	X	X
F-MCU	X	X		X	
R-MCU	X	X		X	X
GCU	X	X	X	X	
MCU	X	X	X	X	X
AWC	X	X		X	
Auto Stop & Go (AS&G)	X	X		X	
OSS	X	X	X	X	X
CORNER SENSOR/BACK SENSOR	X	X		X	
CMU1		X		X	
CMU2		X		X	
CMU3		X		X	
CMU4		X		X	
CMU5		X		X	
CMU6		X		X	
CMU7		X		X	
CMU8		X		X	
CMU9		X		X	
CMU10		X		X	
CMU11		X		X	
CMU12		X		X	

3 Vehicle Special Function covered

System	Special Function
MPI/GDI/DIESEL	ECU Information
MPI/GDI/DIESEL	Provisional DTCs
MPI/GDI/DIESEL	Learning
MPI/GDI/DIESEL	Test
MPI/GDI/DIESEL	INJ.ID Writing(Exchanging INJ.)
MPI/GDI/DIESEL	INJ.ID Writing(Exchanging ECU)
MPI/GDI/DIESEL	Injector ID Readout
MPI/GDI/DIESEL	Injector ID Initialization
MPI/GDI/DIESEL	Learned value reset
MPI/GDI/DIESEL	OBD test results (Mode \$06)
MPI/GDI/DIESEL	In-use Performance Tracking(ENH)
MPI/GDI/DIESEL	In-use Performance Tracking(OBD)
MPI/GDI/DIESEL	Timing chain maintenance
MPI/GDI/DIESEL	Ethanol forced learning mode
MPI/GDI/DIESEL	Initialization
MPI/GDI/DIESEL	DPF regeneration
MPI/GDI/DIESEL	Write learned value (Changed ECU)
MPI/GDI/DIESEL	Recall-Additive level correction
MPI/GDI/DIESEL	Reset
MPI/GDI/DIESEL	Engine Test
MPI/GDI/DIESEL	Starter counter writing
MPI/GDI/DIESEL	Starter counter initialization
IMMOBILIZER	Key registration
IMMOBILIZER	Master Key Search
IMMOBILIZER	Change Password
IMMOBILIZER	Engine ECU <=> ETACS Matching
IMMOBILIZER	ECU Information
IMMOBILIZER	Key Registration(using key)
IMMOBILIZER	Key Registration(Barcode No.)
IMMOBILIZER	ENG/EV KeyCode &Chass.No/VIN Reg
IMMOBILIZER	Key Code agreement confirmation
AT/CVT/A-MT/TC-SST	Clutch
AT/CVT/A-MT/TC-SST	Gear
AT/CVT/A-MT/TC-SST	ECU Information
AT/CVT/A-MT/TC-SST	Provisional DTCs
AT/CVT/A-MT/TC-SST	Emission Gas Mode
AT/CVT/A-MT/TC-SST	CVT oil degradation level
AT/CVT/A-MT/TC-SST	Electric oil pump air bleeding
AT/CVT/A-MT/TC-SST	Permit condition for AS&G

System	Special Function
AT/CVT/A-MT/TC-SST	Teach-In
AT/CVT/A-MT/TC-SST	Test
AT/CVT/A-MT/TC-SST	Learned value reset
AT/CVT/A-MT/TC-SST	Control valve learning mode
AT/CVT/A-MT/TC-SST	Calibration value reset
AT/CVT/A-MT/TC-SST	Write calibration value
AT/CVT/A-MT/TC-SST	Reset
AT/CVT/A-MT/TC-SST	Sensor calibration
SS4II	ECU Information
TCL/STABILITY CONTROL	ECU Information
AUTO CRUISE	ECU Information
4WS/Electric Power Steering	ECU Information
ABS/ASC/ASTC/WSS	ECU Information
ABS/ASC/ASTC/WSS	Emission Gas Mode
ABS/ASC/ASTC/WSS	SAS Calibration
ABS/ASC/ASTC/WSS	Yaw rate sensor type reset
ABS/ASC/ASTC/WSS	Sensor calibration
ABS/ASC/ASTC/WSS	Lateral G Sensor Calibration
ABS/ASC/ASTC/WSS	Valve pressure learning
ABS/ASC/ASTC/WSS	Chassis Dynamometer Test Mode
AYC/ACD	ECU Information
AYC/ACD	Sensor calibration
AYC/ACD	Air bleeding
AYC/ACD	Test
SRS-AIR BAG	SRS ECU Initialization
SRS-AIR BAG	ECU Information
SRS-AIR BAG	Seat Weight Sensor Accuracy Check
Air Conditioner	ECU Information
Air Conditioner	Reset
Air Conditioner	ELC.water heater test
Lane Keep	ECU Information
Lane Keep	Reset
Lane Keep	Learning
ETACS	ECU Information
ETACS	Customization
ETACS	Customization Information
ETACS	Customization Reset
ETACS	Security alarm
ETACS	Keyless ID Registration
ETACS	Keyless Reception Check
ETACS	HS initial position Clear
ETACS	HS initial position Learning
ETACS	Reset

System	Special Function
KOS/IMMO/Keyless	ECU Information
KOS/IMMO/Keyless	Comm. Test
KOS/IMMO/Keyless	Security appli. file generate
KOS/IMMO/Keyless	KOS key Registration
KOS/IMMO/Keyless	Change Password
KOS/IMMO/Keyless	Keyless ID Registration
KOS/IMMO/Keyless	Keyless Reception Check
KOS/IMMO/Keyless	Key Registration
KOS/IMMO/Keyless	Key Registration(Barcode No.)
KOS/IMMO/Keyless	ENG key code Reg.
KOS/IMMO/Keyless	ENG Key Code &Chassis No/VIN Reg
KOS/IMMO/Keyless	Keyless ID Reg.
EV/MiEV Remote System	ECU Information
EV/MiEV Remote System	Test
Compressor	ECU Information
ACC/FCM	ECU Information
ACC/FCM	Reset
ACC/FCM	Learning
KOS/OSS/IMMO/Keyless	ECU Information
KOS/OSS/IMMO/Keyless	Change Password
KOS/OSS/IMMO/Keyless	Keyless ID Registration
KOS/OSS/IMMO/Keyless	Keyless Reception Check
KOS/OSS/IMMO/Keyless	Key Registration
KOS/OSS/IMMO/Keyless	Key Registration(Barcode No.)
KOS/OSS/IMMO/Keyless	ENG key code Reg.
KOS/OSS/IMMO/Keyless	ENG Key Code &Chassis No/VIN Reg
KOS/OSS/IMMO/Keyless	Comm. Test
KOS/OSS/IMMO/Keyless	Security appli. file generate
KOS/OSS/IMMO/Keyless	KOS key Registration
KOS/OSS/IMMO/Keyless	Forced power supply output
KOS/OSS/IMMO/Keyless	Forced power supply output(stop)
KOS/OSS/IMMO/Keyless	Engine switch control
DC/DC Converter	ECU Information
TPMS	ECU Information
TPMS	Tyre pressure sensor ID registration
TPMS	Tyre Pressure Sensor ID Check
TPMS	Tyre PRS. Sensor ID Reg.(Set2)
Camera	ECU Information
P LOCK	ECU Information
Meter	ECU Information
Meter	Service reminder
Meter	Head lamp Auto leveling Diag mode
Meter	Test

System	Special Function
Meter	Turn-signal sound customization
Display	ECU Information
Assist Battery	ECU Information
Steering Angle Sensor	ECU Information
Steering Angle Sensor	SAS Calibration
PHEV	Test
PHEV	ECU Information
PHEV	Provisional DTCs
PHEV	Initialization
4WD	ECU Information
4WD	Test
AND	ECU Information
AUDIO	ECU Information
Multi Around Monitor	ECU Information
Multi Around Monitor	Write learned value (Changed ECU)
Multi Around Monitor	Front & Bird eye view display
Multi Around Monitor	Calibration marker range display
Multi Around Monitor	Calibration
RHT/Topstack	ECU Information
RHT/Topstack	Learning
RHT/Topstack	Function Test
LIN	Rain Sensor Adaptation
Power Gate	ECU Information
Keyless Operation	ECU Information
Keyless Operation	KOS key Registration
Keyless Operation	Steering lock unit Reg.
Keyless Operation	Comm. Test
Keyless Operation	KOS Customization
KOS/IMMO/Keyless/TPMS	ECU Information
KOS/IMMO/Keyless/TPMS	Change Password
KOS/IMMO/Keyless/TPMS	Key Registration(Barcode No.)
KOS/IMMO/Keyless/TPMS	Key & KOS key Reg.
KOS/IMMO/Keyless/TPMS	Steering lock unit Reg.
KOS/IMMO/Keyless/TPMS	Comm. Test
KOS/IMMO/Keyless/TPMS	ENG key code Reg.
KOS/IMMO/Keyless/TPMS	ENG Key Code &Chassis No/VIN Reg
KOS/IMMO/Keyless/TPMS	Security appli. file generate
KOS/IMMO/Keyless/TPMS	KOS key Registration
KOS/IMMO/Keyless/TPMS	Key(Barcode No.) & KOS key Reg.
KOS/IMMO/Keyless/TPMS	Key Registration
KOS/IMMO/Keyless/TPMS	Keyless ID Reg.
KOS/IMMO/Keyless/TPMS	Tyre pressure sensor ID registration
KOS/IMMO/Keyless/TPMS	Tyre Pressure Sensor ID Check

System	Special Function
KOS/IMMO/Keyless/TPMS	Tyre PRS. Sensor ID Reg.(Set2)
OCM	ECU Information
OCM	Zero Calibration & System Test
SATELLITE RADIO	ECU Information
HFM	ECU Information
ELECTRIC SLIDE DOOR R	ECU Information
ELECTRIC SLIDE DOOR L	ECU Information
AFS/ACL/Leveling	ECU Information
AFS/ACL/Leveling	HS initial position Clear
AFS/ACL/Leveling	HS initial position Learning
Shift Lever	ECU Information
CAN/LIN/SWS converter	ECU Information
CAN/LIN/SWS converter	Customization
CAN/LIN/SWS converter	Customization Information
CAN/LIN/SWS converter	Reset
OBC	ECU Information
BMU	ECU Information
BMU	Test
BMU	CMU ID numbering
BMU	Cell voltage smoothing
BMU	Write learned value (Changed ECU)
BMU	Reset
BMU	Battery capacity measure (Ready)
BMU	Battery capacity measure(Action)
BMU	Battery auto capacity measured
BMU	CMU support forced release
COMP&HTR	ECU Information
COMP&HTR	Reset
COMP&HTR	Temp. dial position adjustment
EV-ECU	ECU Information
EV-ECU	Initialization
F-MCU	ECU Information
R-MCU	ECU Information
GCU	ECU Information
MCU	ECU Information
MCU	Initial Phase Position Of Motor
AWC	ECU Information
AWC	Reset
AWC	Test
Auto Stop & Go (AS&G)	ECU Information
OSS	ECU Information
OSS	Forced power supply output
OSS	Forced power supply output(stop)

System	Special Function
CORNER SENSOR/BACK SENSOR	ECU Information
CMU1	ECU Information
CMU1	Reset
CMU2	ECU Information
CMU2	Reset
CMU3	ECU Information
CMU3	Reset
CMU4	ECU Information
CMU4	Reset
CMU5	ECU Information
CMU5	Reset
CMU6	ECU Information
CMU6	Reset
CMU7	ECU Information
CMU7	Reset
CMU8	ECU Information
CMU8	Reset
CMU9	ECU Information
CMU9	Reset
CMU10	ECU Information
CMU10	Reset
CMU11	ECU Information
CMU11	Reset
CMU12	ECU Information
CMU12	Reset

4 Vehicle Coding Function covered

System	Coding Function
MPI/GDI/DIESEL	On Vehicle Coding
MPI/GDI/DIESEL	Off Vehicle Coding
MPI/GDI/DIESEL	OnVehicle Chassis No/VIN Writing
MPI/GDI/DIESEL	OffVehicle Chassis No/VIN Writing
MPI/GDI/DIESEL	Coding Information
MPI/GDI/DIESEL	Chassis No/VIN Writing
MPI/GDI/DIESEL	Chassis No./VIN Information
MPI/GDI/DIESEL	Coding Information & Copy
MPI/GDI/DIESEL	Option Coding
MPI/GDI/DIESEL	Option Coding Information
MPI/GDI/DIESEL	Chassis No./VIN Writing

System	Coding Function
AT/CVT/A-MT/TC-SST	Chassis No./VIN Information
AT/CVT/A-MT/TC-SST	On Vehicle Coding
AT/CVT/A-MT/TC-SST	Coding Information & Copy
AT/CVT/A-MT/TC-SST	Chassis No./VIN Writing
4WS/Electric Power Steering	OnVehicle Chassis No/VIN Writing
4WS/Electric Power Steering	OffVehicle Chassis No/VIN Writing
4WS/Electric Power Steering	Coding Information
ABS/ASC/ASTC/WSS	OnVehicle Chassis No/VIN Writing
ABS/ASC/ASTC/WSS	OffVehicle Chassis No/VIN Writing
ABS/ASC/ASTC/WSS	Coding Information
ABS/ASC/ASTC/WSS	On Vehicle Coding
ABS/ASC/ASTC/WSS	Off Vehicle Coding
SRS-AIR BAG	Chassis No./VIN Information
SRS-AIR BAG	On Vehicle Coding
SRS-AIR BAG	Coding Information & Copy
SRS-AIR BAG	Chassis No./VIN Writing
ETACS	On Vehicle Coding
ETACS	Off Vehicle Coding
ETACS	OnVehicle Chassis No/VIN Writing
ETACS	OffVehicle Chassis No/VIN Writing
ETACS	Coding Information
ETACS	Chassis No./VIN Information
ETACS	Coding Information & Copy
ETACS	Option Coding
ETACS	Option Coding Information
ETACS	Chassis No./VIN Writing
KOS/IMMO/Keyless	Chassis No./VIN Writing
KOS/IMMO/Keyless	Chassis No./VIN Information
KOS/OSS/IMMO/Keyless	Chassis No./VIN Writing
KOS/OSS/IMMO/Keyless	Chassis No./VIN Information
Meter	On Vehicle Coding
Meter	Off Vehicle Coding
Meter	Coding Information
PHEV	Chassis No./VIN Information
PHEV	On Vehicle Coding
PHEV	Coding Information & Copy
PHEV	Option Coding
PHEV	Option Coding Information
PHEV	Chassis No./VIN Writing
RHT/Topstack	On Vehicle Coding
RHT/Topstack	Coding Information
KOS/IMMO/Keyless/TPMS	Chassis No./VIN Writing
KOS/IMMO/Keyless/TPMS	Chassis No./VIN Information

System	Coding Function
AFS/ACL/Leveling	Chassis No./VIN Information
AFS/ACL/Leveling	On Vehicle Coding
AFS/ACL/Leveling	Coding Information & Copy
AFS/ACL/Leveling	Chassis No./VIN Writing
EV-ECU	Chassis No./VIN Writing
EV-ECU	Chassis No./VIN Information
R-MCU	Chassis No./VIN Writing
R-MCU	Chassis No./VIN Information
MCU	Chassis No./VIN Writing
MCU	Chassis No./VIN Information
OSS	Chassis No./VIN Writing
OSS	Chassis No./VIN Information