

NISSAN Function list

Note:

× Functions marked with × is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

Vehicle	System	Read Fault Code	Clear Fault Code	Live Data	Special Func
*Murano camp:P8201 \ Z51 \ 2009	Air bag	×	×	×	
*Murano camp:P8201 \ Z51 \ 2009	Transmission		×	×	
*Murano camp:P8201 \ Z51 \ 2009	IPDM E/R		×	×	
350Z \ Z33 \ 2002-11~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2002-11~	ABS	×	×	×	0003, 0092, 0264
350Z \ Z33 \ 2002-11~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
350Z \ Z33 \ 2002-11~	BCM	×	×		
350Z \ Z33 \ 2002-11~	Air bag	×	×	×	
350Z \ Z33 \ 2002-11~	ICC/ADAS	×	×	×	
350Z \ Z33 \ 2002-11~	HVAC	×	×	×	
350Z \ Z33 \ 2002-11~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2002-11~	Multi AV	×	×	×	0280
350Z \ Z33 \ 2002-11~	EPS/DAST 3	×	×	×	
350Z \ Z33 \ 2002-11~	IPDM E/R	×	×	×	
350Z \ Z33 \ 2002-11~	Air pressure monitor	×	×	×	
350Z \ Z33 \ 2002-11~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2002-11~	DIU	×	×	×	
350Z \ Z33 \ 2002-11~	Auto slide door	×	×	×	
350Z \ Z33 \ 2002-11~	Auto drive position	×	×	×	
350Z \ Z33 \ 2002-11~	All mode AWD/4WD	×	×	×	
350Z \ Z33 \ 2002-11~	4WAS(MAIN)/RAS/HICAS	×	×	×	
350Z \ Z33 \ 2002-11~	Sonar	×	×	×	
350Z \ Z33 \ 2002-11~	Lane camera	×	×	×	
350Z \ Z33 \ 2002-11~	Adaptive light	×	×	×	
350Z \ Z33 \ 2002-11~	AVM		×	×	
350Z \ Z33 \ 2002-11~	Head lamp levelizer	×	×	×	
350Z \ Z33 \ 2002-11~	Difference lock	×	×	×	

350Z \ Z33 \ 2002-11~	Nats immu	x	x		
350Z \ Z33 \ 2002-11~	Smart entrance	x	x		
350Z \ Z33 \ 2002-11~	Air levelizer	x	x	x	
350Z \ Z33 \ 2002-11~	Rearview camera			x	
350Z \ Z33 \ 2002-11~	S/blind camera			x	
350Z \ Z33 \ 2002-11~	Motor assist	x	x	x	
350Z \ Z33 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2003	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2003	BCM	x	x		
350Z \ Z33 \ 2003	Air bag	x	x	x	
350Z \ Z33 \ 2003	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2003	HVAC	x	x	x	
350Z \ Z33 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2003	Multi AV	x	x	x	0280
350Z \ Z33 \ 2003	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2003	IPDM E/R	x	x	x	
350Z \ Z33 \ 2003	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2003	DIU	x	x	x	
350Z \ Z33 \ 2003	Auto slide door	x	x	x	
350Z \ Z33 \ 2003	Auto drive position	x	x	x	
350Z \ Z33 \ 2003	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2003	Sonar	x	x	x	
350Z \ Z33 \ 2003	Lane camera	x	x	x	
350Z \ Z33 \ 2003	Adaptive light	x	x	x	
350Z \ Z33 \ 2003	AVM		x	x	
350Z \ Z33 \ 2003	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2003	Difference lock	x	x	x	
350Z \ Z33 \ 2003	Nats immu	x	x		
350Z \ Z33 \ 2003	Smart entrance	x	x		
350Z \ Z33 \ 2003	Air levelizer	x	x	x	
350Z \ Z33 \ 2003	Rearview camera			x	
350Z \ Z33 \ 2003	S/blind camera			x	
350Z \ Z33 \ 2003	Motor assist	x	x	x	
350Z \ Z33 \ 2003-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

350Z \ Z33 \ 2003-11~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2003-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2003-11~	BCM	x	x		
350Z \ Z33 \ 2003-11~	Air bag	x	x	x	
350Z \ Z33 \ 2003-11~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2003-11~	HVAC	x	x	x	
350Z \ Z33 \ 2003-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2003-11~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2003-11~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2003-11~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2003-11~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2003-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2003-11~	DIU	x	x	x	
350Z \ Z33 \ 2003-11~	Auto slide door	x	x	x	
350Z \ Z33 \ 2003-11~	Auto drive position	x	x	x	
350Z \ Z33 \ 2003-11~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2003-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2003-11~	Sonar	x	x	x	
350Z \ Z33 \ 2003-11~	Lane camera	x	x	x	
350Z \ Z33 \ 2003-11~	Adaptive light	x	x	x	
350Z \ Z33 \ 2003-11~	AVM		x	x	
350Z \ Z33 \ 2003-11~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2003-11~	Difference lock	x	x	x	
350Z \ Z33 \ 2003-11~	Nats immu	x	x		
350Z \ Z33 \ 2003-11~	Smart entrance	x	x		
350Z \ Z33 \ 2003-11~	Air levelizer	x	x	x	
350Z \ Z33 \ 2003-11~	Rearview camera			x	
350Z \ Z33 \ 2003-11~	S/blind camera			x	
350Z \ Z33 \ 2003-11~	Motor assist	x	x	x	
350Z \ Z33 \ 2003-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2003-7~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2003-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2003-7~	BCM	x	x		
350Z \ Z33 \ 2003-7~	Air bag	x	x	x	
350Z \ Z33 \ 2003-7~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2003-7~	HVAC	x	x	x	
350Z \ Z33 \ 2003-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2003-7~	Multi AV	x	x	x	0280

350Z \ Z33 \ 2003-7~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2003-7~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2003-7~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2003-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2003-7~	DIU	x	x	x	
350Z \ Z33 \ 2003-7~	Auto slide door	x	x	x	
350Z \ Z33 \ 2003-7~	Auto drive position	x	x	x	
350Z \ Z33 \ 2003-7~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2003-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2003-7~	Sonar	x	x	x	
350Z \ Z33 \ 2003-7~	Lane camera	x	x	x	
350Z \ Z33 \ 2003-7~	Adaptive light	x	x	x	
350Z \ Z33 \ 2003-7~	AVM		x	x	
350Z \ Z33 \ 2003-7~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2003-7~	Difference lock	x	x	x	
350Z \ Z33 \ 2003-7~	Nats immu	x	x		
350Z \ Z33 \ 2003-7~	Smart entrance	x	x		
350Z \ Z33 \ 2003-7~	Air levelizer	x	x	x	
350Z \ Z33 \ 2003-7~	Rearview camera			x	
350Z \ Z33 \ 2003-7~	S/blind camera			x	
350Z \ Z33 \ 2003-7~	Motor assist	x	x	x	
350Z \ Z33 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2004	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2004	BCM	x	x		
350Z \ Z33 \ 2004	Air bag	x	x	x	
350Z \ Z33 \ 2004	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2004	HVAC	x	x	x	
350Z \ Z33 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2004	Multi AV	x	x	x	0280
350Z \ Z33 \ 2004	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2004	IPDM E/R	x	x	x	
350Z \ Z33 \ 2004	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2004	DIU	x	x	x	
350Z \ Z33 \ 2004	Auto slide door	x	x	x	

350Z \ Z33 \ 2004	Auto drive position	x	x	x	
350Z \ Z33 \ 2004	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2004	Sonar	x	x	x	
350Z \ Z33 \ 2004	Lane camera	x	x	x	
350Z \ Z33 \ 2004	Adaptive light	x	x	x	
350Z \ Z33 \ 2004	AVM		x	x	
350Z \ Z33 \ 2004	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2004	Difference lock	x	x	x	
350Z \ Z33 \ 2004	Nats immu	x	x		
350Z \ Z33 \ 2004	Smart entrance	x	x		
350Z \ Z33 \ 2004	Air levelizer	x	x	x	
350Z \ Z33 \ 2004	Rearview camera			x	
350Z \ Z33 \ 2004	S/blind camera			x	
350Z \ Z33 \ 2004	Motor assist	x	x	x	
350Z \ Z33 \ 2004-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2004-11~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2004-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2004-11~	BCM	x	x		
350Z \ Z33 \ 2004-11~	Air bag	x	x	x	
350Z \ Z33 \ 2004-11~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2004-11~	HVAC	x	x	x	
350Z \ Z33 \ 2004-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2004-11~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2004-11~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2004-11~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2004-11~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2004-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2004-11~	DIU	x	x	x	
350Z \ Z33 \ 2004-11~	Auto slide door	x	x	x	
350Z \ Z33 \ 2004-11~	Auto drive position	x	x	x	
350Z \ Z33 \ 2004-11~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2004-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2004-11~	Sonar	x	x	x	
350Z \ Z33 \ 2004-11~	Lane camera	x	x	x	
350Z \ Z33 \ 2004-11~	Adaptive light	x	x	x	
350Z \ Z33 \ 2004-11~	AVM		x	x	
350Z \ Z33 \ 2004-11~	Head lamp levelizer	x	x	x	

350Z \ Z33 \ 2004-11~	Difference lock	x	x	x	
350Z \ Z33 \ 2004-11~	Nats immu	x	x		
350Z \ Z33 \ 2004-11~	Smart entrance	x	x		
350Z \ Z33 \ 2004-11~	Air levelizer	x	x	x	
350Z \ Z33 \ 2004-11~	Rearview camera			x	
350Z \ Z33 \ 2004-11~	S/blind camera			x	
350Z \ Z33 \ 2004-11~	Motor assist	x	x	x	
350Z \ Z33 \ 2004-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2004-8~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2004-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2004-8~	BCM	x	x		
350Z \ Z33 \ 2004-8~	Air bag	x	x	x	
350Z \ Z33 \ 2004-8~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2004-8~	HVAC	x	x	x	
350Z \ Z33 \ 2004-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2004-8~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2004-8~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2004-8~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2004-8~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2004-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2004-8~	DIU	x	x	x	
350Z \ Z33 \ 2004-8~	Auto slide door	x	x	x	
350Z \ Z33 \ 2004-8~	Auto drive position	x	x	x	
350Z \ Z33 \ 2004-8~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2004-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2004-8~	Sonar	x	x	x	
350Z \ Z33 \ 2004-8~	Lane camera	x	x	x	
350Z \ Z33 \ 2004-8~	Adaptive light	x	x	x	
350Z \ Z33 \ 2004-8~	AVM		x	x	
350Z \ Z33 \ 2004-8~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2004-8~	Difference lock	x	x	x	
350Z \ Z33 \ 2004-8~	Nats immu	x	x		
350Z \ Z33 \ 2004-8~	Smart entrance	x	x		
350Z \ Z33 \ 2004-8~	Air levelizer	x	x	x	
350Z \ Z33 \ 2004-8~	Rearview camera			x	
350Z \ Z33 \ 2004-8~	S/blind camera			x	
350Z \ Z33 \ 2004-8~	Motor assist	x	x	x	

350Z \ Z33 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2005	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2005	BCM	x	x		
350Z \ Z33 \ 2005	Air bag	x	x	x	
350Z \ Z33 \ 2005	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2005	HVAC	x	x	x	
350Z \ Z33 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2005	Multi AV	x	x	x	0280
350Z \ Z33 \ 2005	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2005	IPDM E/R	x	x	x	
350Z \ Z33 \ 2005	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2005	DIU	x	x	x	
350Z \ Z33 \ 2005	Auto slide door	x	x	x	
350Z \ Z33 \ 2005	Auto drive position	x	x	x	
350Z \ Z33 \ 2005	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2005	Sonar	x	x	x	
350Z \ Z33 \ 2005	Lane camera	x	x	x	
350Z \ Z33 \ 2005	Adaptive light	x	x	x	
350Z \ Z33 \ 2005	AVM		x	x	
350Z \ Z33 \ 2005	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2005	Difference lock	x	x	x	
350Z \ Z33 \ 2005	Nats immu	x	x		
350Z \ Z33 \ 2005	Smart entrance	x	x		
350Z \ Z33 \ 2005	Air levelizer	x	x	x	
350Z \ Z33 \ 2005	Rearview camera			x	
350Z \ Z33 \ 2005	S/blind camera			x	
350Z \ Z33 \ 2005	Motor assist	x	x	x	
350Z \ Z33 \ 2005-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2005-10~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2005-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2005-10~	BCM	x	x		
350Z \ Z33 \ 2005-10~	Air bag	x	x	x	
350Z \ Z33 \ 2005-10~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2005-10~	HVAC	x	x	x	

350Z \ Z33 \ 2005-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2005-10~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2005-10~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2005-10~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2005-10~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2005-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2005-10~	DIU	x	x	x	
350Z \ Z33 \ 2005-10~	Auto slide door	x	x	x	
350Z \ Z33 \ 2005-10~	Auto drive position	x	x	x	
350Z \ Z33 \ 2005-10~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2005-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2005-10~	Sonar	x	x	x	
350Z \ Z33 \ 2005-10~	Lane camera	x	x	x	
350Z \ Z33 \ 2005-10~	Adaptive light	x	x	x	
350Z \ Z33 \ 2005-10~	AVM		x	x	
350Z \ Z33 \ 2005-10~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2005-10~	Difference lock	x	x	x	
350Z \ Z33 \ 2005-10~	Nats immu	x	x		
350Z \ Z33 \ 2005-10~	Smart entrance	x	x		
350Z \ Z33 \ 2005-10~	Air levelizer	x	x	x	
350Z \ Z33 \ 2005-10~	Rearview camera			x	
350Z \ Z33 \ 2005-10~	S/blind camera			x	
350Z \ Z33 \ 2005-10~	Motor assist	x	x	x	
350Z \ Z33 \ 2005-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2005-11~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2005-11~	BCM	x	x		
350Z \ Z33 \ 2005-11~	Air bag	x	x	x	
350Z \ Z33 \ 2005-11~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2005-11~	HVAC	x	x	x	
350Z \ Z33 \ 2005-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2005-11~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2005-11~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2005-11~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2005-11~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

350Z \ Z33 \ 2005-11~	DIU	x	x	x	
350Z \ Z33 \ 2005-11~	Auto slide door	x	x	x	
350Z \ Z33 \ 2005-11~	Auto drive position	x	x	x	
350Z \ Z33 \ 2005-11~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2005-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2005-11~	Sonar	x	x	x	
350Z \ Z33 \ 2005-11~	Lane camera	x	x	x	
350Z \ Z33 \ 2005-11~	Adaptive light	x	x	x	
350Z \ Z33 \ 2005-11~	AVM		x	x	
350Z \ Z33 \ 2005-11~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2005-11~	Difference lock	x	x	x	
350Z \ Z33 \ 2005-11~	Nats immu	x	x		
350Z \ Z33 \ 2005-11~	Smart entrance	x	x		
350Z \ Z33 \ 2005-11~	Air levelizer	x	x	x	
350Z \ Z33 \ 2005-11~	Rearview camera			x	
350Z \ Z33 \ 2005-11~	S/blind camera			x	
350Z \ Z33 \ 2005-11~	Motor assist	x	x	x	
350Z \ Z33 \ 2005-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2005-9~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2005-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2005-9~	BCM	x	x		
350Z \ Z33 \ 2005-9~	Air bag	x	x	x	
350Z \ Z33 \ 2005-9~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2005-9~	HVAC	x	x	x	
350Z \ Z33 \ 2005-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2005-9~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2005-9~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2005-9~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2005-9~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2005-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2005-9~	DIU	x	x	x	
350Z \ Z33 \ 2005-9~	Auto slide door	x	x	x	
350Z \ Z33 \ 2005-9~	Auto drive position	x	x	x	
350Z \ Z33 \ 2005-9~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2005-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2005-9~	Sonar	x	x	x	
350Z \ Z33 \ 2005-9~	Lane camera	x	x	x	
350Z \ Z33 \ 2005-9~	Adaptive light	x	x	x	

350Z \ Z33 \ 2005-9~	AVM		x	x	
350Z \ Z33 \ 2005-9~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2005-9~	Difference lock	x	x	x	
350Z \ Z33 \ 2005-9~	Nats immu	x	x		
350Z \ Z33 \ 2005-9~	Smart entrance	x	x		
350Z \ Z33 \ 2005-9~	Air levelizer	x	x	x	
350Z \ Z33 \ 2005-9~	Rearview camera			x	
350Z \ Z33 \ 2005-9~	S/blind camera			x	
350Z \ Z33 \ 2005-9~	Motor assist	x	x	x	
350Z \ Z33 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2006	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2006	BCM	x	x		
350Z \ Z33 \ 2006	Air bag	x	x	x	
350Z \ Z33 \ 2006	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2006	HVAC	x	x	x	
350Z \ Z33 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2006	Multi AV	x	x	x	0280
350Z \ Z33 \ 2006	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2006	IPDM E/R	x	x	x	
350Z \ Z33 \ 2006	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2006	DIU	x	x	x	
350Z \ Z33 \ 2006	Auto slide door	x	x	x	
350Z \ Z33 \ 2006	Auto drive position	x	x	x	
350Z \ Z33 \ 2006	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2006	Sonar	x	x	x	
350Z \ Z33 \ 2006	Lane camera	x	x	x	
350Z \ Z33 \ 2006	Adaptive light	x	x	x	
350Z \ Z33 \ 2006	AVM		x	x	
350Z \ Z33 \ 2006	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2006	Difference lock	x	x	x	
350Z \ Z33 \ 2006	Nats immu	x	x		
350Z \ Z33 \ 2006	Smart entrance	x	x		
350Z \ Z33 \ 2006	Air levelizer	x	x	x	
350Z \ Z33 \ 2006	Rearview camera			x	
350Z \ Z33 \ 2006	S/blind camera			x	

350Z \ Z33 \ 2006	Motor assist	x	x	x	
350Z \ Z33 \ 2006-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2006-1~	ABS	x	x	x	0003, 0092, 0264
350Z \ Z33 \ 2006-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
350Z \ Z33 \ 2006-1~	BCM	x	x		
350Z \ Z33 \ 2006-1~	Air bag	x	x	x	
350Z \ Z33 \ 2006-1~	ICC/ADAS	x	x	x	
350Z \ Z33 \ 2006-1~	HVAC	x	x	x	
350Z \ Z33 \ 2006-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
350Z \ Z33 \ 2006-1~	Multi AV	x	x	x	0280
350Z \ Z33 \ 2006-1~	EPS/DAST 3	x	x	x	
350Z \ Z33 \ 2006-1~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2006-1~	Air pressure monitor	x	x	x	
350Z \ Z33 \ 2006-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
350Z \ Z33 \ 2006-1~	DIU	x	x	x	
350Z \ Z33 \ 2006-1~	Auto slide door	x	x	x	
350Z \ Z33 \ 2006-1~	Auto drive position	x	x	x	
350Z \ Z33 \ 2006-1~	All mode AWD/4WD	x	x	x	
350Z \ Z33 \ 2006-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
350Z \ Z33 \ 2006-1~	Sonar	x	x	x	
350Z \ Z33 \ 2006-1~	Lane camera	x	x	x	
350Z \ Z33 \ 2006-1~	Adaptive light	x	x	x	
350Z \ Z33 \ 2006-1~	AVM		x	x	
350Z \ Z33 \ 2006-1~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2006-1~	Difference lock	x	x	x	
350Z \ Z33 \ 2006-1~	Nats immu	x	x		
350Z \ Z33 \ 2006-1~	Smart entrance	x	x		
350Z \ Z33 \ 2006-1~	Air levelizer	x	x	x	
350Z \ Z33 \ 2006-1~	Rearview camera			x	
350Z \ Z33 \ 2006-1~	S/blind camera			x	
350Z \ Z33 \ 2006-1~	Motor assist	x	x	x	
350Z \ Z33 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007	BCM	x	x		
350Z \ Z33 \ 2007	Air bag	x	x	x	
350Z \ Z33 \ 2007	HVAC	x	x	x	
350Z \ Z33 \ 2007	Transmission	x	x	x	

350Z \ Z33 \ 2007	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007	ABS	x	x	x	
350Z \ Z33 \ 2007	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2007-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007-1~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007-1~	BCM	x	x		
350Z \ Z33 \ 2007-1~	HVAC	x	x	x	
350Z \ Z33 \ 2007-1~	Transmission	x	x	x	
350Z \ Z33 \ 2007-1~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007-1~	ABS	x	x	x	
350Z \ Z33 \ 2007-1~	Air bag	x	x	x	
350Z \ Z33 \ 2007-1~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2007-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007-2~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007-2~	BCM	x	x		
350Z \ Z33 \ 2007-2~	HVAC	x	x	x	
350Z \ Z33 \ 2007-2~	Transmission	x	x	x	
350Z \ Z33 \ 2007-2~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007-2~	ABS	x	x	x	
350Z \ Z33 \ 2007-2~	Air bag	x	x	x	
350Z \ Z33 \ 2007-2~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2007-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007-3~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007-3~	BCM	x	x		
350Z \ Z33 \ 2007-3~	HVAC	x	x	x	
350Z \ Z33 \ 2007-3~	Transmission	x	x	x	
350Z \ Z33 \ 2007-3~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007-3~	ABS	x	x	x	
350Z \ Z33 \ 2007-3~	Air bag	x	x	x	
350Z \ Z33 \ 2007-3~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007-6~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007-6~	BCM	x	x		
350Z \ Z33 \ 2007-6~	HVAC	x	x	x	
350Z \ Z33 \ 2007-6~	Transmission	x	x	x	
350Z \ Z33 \ 2007-6~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007-6~	ABS	x	x	x	

350Z \ Z33 \ 2007-6~	Air bag	x	x	x	
350Z \ Z33 \ 2007-6~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2007-8~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2007-8~	BCM	x	x		
350Z \ Z33 \ 2007-8~	HVAC	x	x	x	
350Z \ Z33 \ 2007-8~	Transmission	x	x	x	
350Z \ Z33 \ 2007-8~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2007-8~	ABS	x	x	x	
350Z \ Z33 \ 2007-8~	Air bag	x	x	x	
350Z \ Z33 \ 2007-8~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2008	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2008	BCM	x	x		
350Z \ Z33 \ 2008	Air bag	x	x	x	
350Z \ Z33 \ 2008	HVAC	x	x	x	
350Z \ Z33 \ 2008	Transmission	x	x	x	
350Z \ Z33 \ 2008	IPDM E/R	x	x	x	
350Z \ Z33 \ 2008	ABS	x	x	x	
350Z \ Z33 \ 2008	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2008-6~	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2008-6~	BCM	x	x		
350Z \ Z33 \ 2008-6~	HVAC	x	x	x	
350Z \ Z33 \ 2008-6~	Transmission	x	x	x	
350Z \ Z33 \ 2008-6~	IPDM E/R	x	x	x	
350Z \ Z33 \ 2008-6~	ABS	x	x	x	
350Z \ Z33 \ 2008-6~	Air bag	x	x	x	
350Z \ Z33 \ 2008-6~	Head lamp levelizer	x	x	x	
350Z \ Z33 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
350Z \ Z33 \ 2009	Meter/M&A	x	x	x	0143, 0331
350Z \ Z33 \ 2009	BCM	x	x		
350Z \ Z33 \ 2009	Air bag	x	x	x	
350Z \ Z33 \ 2009	HVAC	x	x	x	
350Z \ Z33 \ 2009	Transmission	x	x	x	
350Z \ Z33 \ 2009	IPDM E/R	x	x	x	
350Z \ Z33 \ 2009	ABS	x	x	x	

350Z \ Z33 \ 2009	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2009-10~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2009-10~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2009-10~	BCM		x		
370Z Convertible \ HZ34 \ 2009-10~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2009-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2009-10~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2009-10~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2009-10~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2009-10~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2009-10~	E-SUS		x	x	
370Z Convertible \ HZ34 \ 2009-10~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2009-10~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2009-11~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2009-11~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2009-11~	BCM		x		
370Z Convertible \ HZ34 \ 2009-11~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2009-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2009-11~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2009-11~	Multi AV	x	x	x	
370Z Convertible \ HZ34 \ 2009-11~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2009-11~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2009-11~	E-SUS		x	x	
370Z Convertible \ HZ34 \ 2009-11~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2009-11~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2010	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2010	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2010	BCM		x		
370Z Convertible \ HZ34 \ 2010	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2010	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2010	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2010	Multi AV		x	x	

370Z Convertible \ HZ34 \ 2010	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2010	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2010	E-SUS		x	x	
370Z Convertible \ HZ34 \ 2010	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2010	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2010-11~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2010-11~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2010-11~	BCM		x		
370Z Convertible \ HZ34 \ 2010-11~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2010-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2010-11~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2010-11~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2010-11~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2010-11~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2010-11~	E-SUS		x	x	
370Z Convertible \ HZ34 \ 2010-11~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2010-11~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2010-12~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2010-12~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2010-12~	BCM		x		
370Z Convertible \ HZ34 \ 2010-12~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2010-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2010-12~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2010-12~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2010-12~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2010-12~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2010-12~	Auto drive position	x	x	x	
370Z Convertible \ HZ34 \ 2010-12~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2010-12~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2011	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2011	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2011	BCM		x		
370Z Convertible \ HZ34 \ 2011	Air bag	x	x	x	

370Z Convertible \ HZ34 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2011	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2011	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2011	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2011	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2011	E-SUS		x	x	
370Z Convertible \ HZ34 \ 2011	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2011	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012	BCM		x		
370Z Convertible \ HZ34 \ 2012	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-10~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-10~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-10~	BCM		x		
370Z Convertible \ HZ34 \ 2012-10~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-10~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-10~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-10~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-10~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-10~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-10~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-11~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-11~	BCM		x		
370Z Convertible \ HZ34 \ 2012-11~	Air bag	x	x	x	

370Z Convertible \ HZ34 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-11~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-11~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-11~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-11~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-11~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-11~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-12~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-12~	BCM		x		
370Z Convertible \ HZ34 \ 2012-12~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-12~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-12~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-12~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-12~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-12~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-12~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-5~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-5~	BCM		x		
370Z Convertible \ HZ34 \ 2012-5~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-5~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-5~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-5~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-5~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-5~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-5~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-8~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-8~	BCM		x		

370Z Convertible \ HZ34 \ 2012-8~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-8~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-8~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-8~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-8~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-8~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-8~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2012-9~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2012-9~	BCM		x		
370Z Convertible \ HZ34 \ 2012-9~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2012-9~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2012-9~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2012-9~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2012-9~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2012-9~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2012-9~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2013	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013	BCM		x		
370Z Convertible \ HZ34 \ 2013	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2013	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013-1~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2013-1~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013-1~	BCM		x		
370Z Convertible \ HZ34 \ 2013-1~	Air bag	x	x	x	

370Z Convertible \ HZ34 \ 2013-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013-1~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013-1~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2013-1~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013-1~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-1~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2013-1~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013-4~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2013-4~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013-4~	BCM		x		
370Z Convertible \ HZ34 \ 2013-4~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2013-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013-4~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013-4~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2013-4~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013-4~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-4~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2013-4~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013-7~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013-7~	BCM		x		
370Z Convertible \ HZ34 \ 2013-7~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2013-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013-7~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013-7~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2013-7~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013-7~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-7~	ABS	x	x	x	
370Z Convertible \ HZ34 \ 2013-7~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2013-7~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013-8~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2013-8~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013-8~	BCM		x		

370Z Convertible \ HZ34 \ 2013-8~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2013-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013-8~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013-8~	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2013-8~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013-8~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-8~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013-8~	AVM		x	x	
370Z Convertible \ HZ34 \ 2013-8~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2013-9~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2013-9~	BCM		x		
370Z Convertible \ HZ34 \ 2013-9~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2013-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2013-9~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2013-9~	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2013-9~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2013-9~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2013-9~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2013-9~	AVM		x	x	
370Z Convertible \ HZ34 \ 2013-9~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2014	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2014	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2014	BCM		x		
370Z Convertible \ HZ34 \ 2014	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2014	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2014	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2014	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2014	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2014	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2014	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

370Z Convertible \ HZ34 \ 2014-3~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2014-3~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2014-3~	BCM		x		
370Z Convertible \ HZ34 \ 2014-3~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2014-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2014-3~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2014-3~	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2014-3~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2014-3~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2014-3~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2014-3~	AVM		x	x	
370Z Convertible \ HZ34 \ 2014-3~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2014-7~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2014-7~	BCM		x		
370Z Convertible \ HZ34 \ 2014-7~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2014-7~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2014-7~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2014-7~	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2014-7~	Air pressure monitor		x	x	
370Z Convertible \ HZ34 \ 2014-7~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2014-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	AVM		x	x	
370Z Convertible \ HZ34 \ 2014-7~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2014-7~	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2014-7~	Sonar	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2014-9~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2014-9~	BCM		x		
370Z Convertible \ HZ34 \ 2014-9~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

370Z Convertible \ HZ34 \ 2014-9~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2014-9~	Multi AV	x	x	x	0280
370Z Convertible \ HZ34 \ 2014-9~	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2014-9~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2014-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	AVM		x	x	
370Z Convertible \ HZ34 \ 2014-9~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2014-9~	Sonar	x	x	x	
370Z Convertible \ HZ34 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2015	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2015	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2015	BCM		x		
370Z Convertible \ HZ34 \ 2015	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2015	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2015	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2015	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2015	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2015	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2015	4WAS(MAIN)/RAS/HICAS	x	x	x	
370Z Convertible \ HZ34 \ 2015	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2015	AVM		x	x	
370Z Convertible \ HZ34 \ 2015	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2015-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2015-4~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2015-4~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2015-4~	BCM		x		
370Z Convertible \ HZ34 \ 2015-4~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2015-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2015-4~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2015-4~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2015-4~	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2015-4~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2015-4~	Air pressure monitor		x	x	
370Z Convertible \ HZ34 \ 2015-4~	Convertible roof		x	x	

370Z Convertible \ HZ34 \ 2015-4~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2015-4~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2015-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2015-5~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2015-5~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2015-5~	BCM		x		
370Z Convertible \ HZ34 \ 2015-5~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2015-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2015-5~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2015-5~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2015-5~	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2015-5~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2015-5~	Air pressure monitor		x	x	
370Z Convertible \ HZ34 \ 2015-5~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2015-5~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2015-5~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2016	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2016	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2016	BCM		x		
370Z Convertible \ HZ34 \ 2016	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2016	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2016	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2016	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2016	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2016	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2016	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2016	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2016-7~	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2016-7~	BCM		x		
370Z Convertible \ HZ34 \ 2016-7~	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

370Z Convertible \ HZ34 \ 2016-7~	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2016-7~	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2016-7~	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2016-7~	Air pressure monitor		x	x	
370Z Convertible \ HZ34 \ 2016-7~	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2016-7~	Laser/radar		x	x	
370Z Convertible \ HZ34 \ 2016-7~	Auto drive position	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	Adaptive light	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	ANC		x	x	
370Z Convertible \ HZ34 \ 2016-7~	Head lamp levelizer	x	x	x	
370Z Convertible \ HZ34 \ 2016-7~	Occupant detection			x	
370Z Convertible \ HZ34 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z Convertible \ HZ34 \ 2017	ABS	x	x	x	0003, 0092, 0264
370Z Convertible \ HZ34 \ 2017	Meter/M&A		x	x	
370Z Convertible \ HZ34 \ 2017	BCM		x		
370Z Convertible \ HZ34 \ 2017	Air bag	x	x	x	
370Z Convertible \ HZ34 \ 2017	ICC/ADAS	x	x	x	
370Z Convertible \ HZ34 \ 2017	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z Convertible \ HZ34 \ 2017	Transmission		x	x	0059
370Z Convertible \ HZ34 \ 2017	Multi AV		x	x	
370Z Convertible \ HZ34 \ 2017	EPS/DAST 3	x	x	x	
370Z Convertible \ HZ34 \ 2017	IPDM E/R		x	x	
370Z Convertible \ HZ34 \ 2017	Convertible roof		x	x	
370Z Convertible \ HZ34 \ 2017	Adaptive light	x	x	x	
370Z Convertible \ HZ34 \ 2017	Pop up hood	x	x	x	
370Z Convertible \ HZ34 \ 2017	ANC		x	x	
370Z Convertible \ HZ34 \ 2017	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2008-10~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2008-10~	Meter/M&A		x	x	
370Z \ Z34 \ 2008-10~	BCM		x		
370Z \ Z34 \ 2008-10~	Air bag	x	x	x	
370Z \ Z34 \ 2008-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2008-10~	Transmission		x	x	0059
370Z \ Z34 \ 2008-10~	Multi AV	x	x	x	
370Z \ Z34 \ 2008-10~	IPDM E/R		x	x	

370Z \ Z34 \ 2008-10~	All mode AWD/4WD		x	x	
370Z \ Z34 \ 2008-10~	Telematics		x	x	
370Z \ Z34 \ 2008-10~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2008-10~	Pop up hood	x	x	x	
370Z \ Z34 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2009	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2009	Meter/M&A		x	x	
370Z \ Z34 \ 2009	BCM		x		
370Z \ Z34 \ 2009	Air bag	x	x	x	
370Z \ Z34 \ 2009	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2009	Transmission		x	x	0059
370Z \ Z34 \ 2009	Multi AV	x	x	x	
370Z \ Z34 \ 2009	IPDM E/R		x	x	
370Z \ Z34 \ 2009	All mode AWD/4WD		x	x	
370Z \ Z34 \ 2009	Telematics		x	x	
370Z \ Z34 \ 2009	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2009	Pop up hood	x	x	x	
370Z \ Z34 \ 2009-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2009-12~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2009-12~	Meter/M&A		x	x	
370Z \ Z34 \ 2009-12~	BCM		x		
370Z \ Z34 \ 2009-12~	Air bag	x	x	x	
370Z \ Z34 \ 2009-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2009-12~	Transmission		x	x	0059
370Z \ Z34 \ 2009-12~	Multi AV	x	x	x	
370Z \ Z34 \ 2009-12~	IPDM E/R		x	x	
370Z \ Z34 \ 2009-12~	Air pressure monitor	x	x	x	
370Z \ Z34 \ 2009-12~	Telematics		x	x	
370Z \ Z34 \ 2009-12~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2009-12~	Pop up hood	x	x	x	
370Z \ Z34 \ 2009-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2009-1~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2009-1~	Meter/M&A		x	x	
370Z \ Z34 \ 2009-1~	BCM		x		
370Z \ Z34 \ 2009-1~	Air bag	x	x	x	

370Z \ Z34 \ 2009-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2009-1~	Transmission		x	x	0059
370Z \ Z34 \ 2009-1~	Multi AV	x	x	x	
370Z \ Z34 \ 2009-1~	IPDM E/R		x	x	
370Z \ Z34 \ 2009-1~	Telematics		x	x	
370Z \ Z34 \ 2009-1~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2009-1~	Pop up hood	x	x	x	
370Z \ Z34 \ 2009-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2009-2~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2009-2~	Meter/M&A		x	x	
370Z \ Z34 \ 2009-2~	BCM		x		
370Z \ Z34 \ 2009-2~	Air bag	x	x	x	
370Z \ Z34 \ 2009-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2009-2~	Transmission		x	x	0059
370Z \ Z34 \ 2009-2~	Multi AV	x	x	x	
370Z \ Z34 \ 2009-2~	IPDM E/R		x	x	
370Z \ Z34 \ 2009-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
370Z \ Z34 \ 2009-2~	All mode AWD/4WD		x	x	
370Z \ Z34 \ 2009-2~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2009-2~	Pop up hood	x	x	x	
370Z \ Z34 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2009-8~	Meter/M&A		x	x	
370Z \ Z34 \ 2009-8~	BCM		x		
370Z \ Z34 \ 2009-8~	Air bag	x	x	x	
370Z \ Z34 \ 2009-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2009-8~	Transmission		x	x	0059
370Z \ Z34 \ 2009-8~	Multi AV	x	x	x	
370Z \ Z34 \ 2009-8~	IPDM E/R		x	x	
370Z \ Z34 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
370Z \ Z34 \ 2009-8~	All mode AWD/4WD		x	x	
370Z \ Z34 \ 2009-8~	Head lamp levelizer	x	x	x	

370Z \ Z34 \ 2009-8~	Pop up hood	x	x	x	
370Z \ Z34 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2010	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2010	Meter/M&A		x	x	
370Z \ Z34 \ 2010	BCM		x		
370Z \ Z34 \ 2010	Air bag	x	x	x	
370Z \ Z34 \ 2010	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2010	Transmission		x	x	0059
370Z \ Z34 \ 2010	Multi AV		x	x	
370Z \ Z34 \ 2010	IPDM E/R		x	x	
370Z \ Z34 \ 2010	Convertible roof		x	x	
370Z \ Z34 \ 2010	E-SUS		x	x	
370Z \ Z34 \ 2010	Telematics		x	x	
370Z \ Z34 \ 2010	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2010	Pop up hood	x	x	x	
370Z \ Z34 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2010-11~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2010-11~	Meter/M&A		x	x	
370Z \ Z34 \ 2010-11~	BCM		x		
370Z \ Z34 \ 2010-11~	Air bag	x	x	x	
370Z \ Z34 \ 2010-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2010-11~	Transmission		x	x	0059
370Z \ Z34 \ 2010-11~	Multi AV	x	x	x	
370Z \ Z34 \ 2010-11~	IPDM E/R		x	x	
370Z \ Z34 \ 2010-11~	Telematics		x	x	
370Z \ Z34 \ 2010-11~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2010-11~	Pop up hood	x	x	x	
370Z \ Z34 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2010-12~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2010-12~	Meter/M&A		x	x	
370Z \ Z34 \ 2010-12~	BCM		x		
370Z \ Z34 \ 2010-12~	Air bag	x	x	x	
370Z \ Z34 \ 2010-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2010-12~	Transmission		x	x	0059
370Z \ Z34 \ 2010-12~	Multi AV	x	x	x	

370Z \ Z34 \ 2010-12~	IPDM E/R		x	x	
370Z \ Z34 \ 2010-12~	Convertible roof		x	x	
370Z \ Z34 \ 2010-12~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2010-12~	Pop up hood	x	x	x	
370Z \ Z34 \ 2010-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2010-1~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2010-1~	Meter/M&A		x	x	
370Z \ Z34 \ 2010-1~	BCM		x		
370Z \ Z34 \ 2010-1~	Air bag	x	x	x	
370Z \ Z34 \ 2010-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2010-1~	Transmission		x	x	0059
370Z \ Z34 \ 2010-1~	Multi AV	x	x	x	
370Z \ Z34 \ 2010-1~	IPDM E/R		x	x	
370Z \ Z34 \ 2010-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
370Z \ Z34 \ 2010-1~	All mode AWD/4WD		x	x	
370Z \ Z34 \ 2010-1~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2010-1~	Pop up hood	x	x	x	
370Z \ Z34 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2011	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2011	Meter/M&A		x	x	
370Z \ Z34 \ 2011	BCM		x		
370Z \ Z34 \ 2011	Air bag	x	x	x	
370Z \ Z34 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2011	Transmission		x	x	0059
370Z \ Z34 \ 2011	Multi AV	x	x	x	
370Z \ Z34 \ 2011	IPDM E/R		x	x	
370Z \ Z34 \ 2011	Telematics		x	x	
370Z \ Z34 \ 2011	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2011	Pop up hood	x	x	x	
370Z \ Z34 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012	Meter/M&A		x	x	
370Z \ Z34 \ 2012	BCM		x		
370Z \ Z34 \ 2012	Air bag	x	x	x	

370Z \ Z34 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012	Transmission		x	x	0059
370Z \ Z34 \ 2012	Multi AV		x	x	
370Z \ Z34 \ 2012	IPDM E/R		x	x	
370Z \ Z34 \ 2012	Telematics		x	x	
370Z \ Z34 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-10~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-10~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-10~	BCM		x		
370Z \ Z34 \ 2012-10~	Air bag	x	x	x	
370Z \ Z34 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-10~	Transmission		x	x	0059
370Z \ Z34 \ 2012-10~	Multi AV		x	x	
370Z \ Z34 \ 2012-10~	IPDM E/R		x	x	
370Z \ Z34 \ 2012-10~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2012-10~	Pop up hood	x	x	x	
370Z \ Z34 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-11~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-11~	BCM		x		
370Z \ Z34 \ 2012-11~	Air bag	x	x	x	
370Z \ Z34 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-11~	Transmission		x	x	0059
370Z \ Z34 \ 2012-11~	Multi AV		x	x	
370Z \ Z34 \ 2012-11~	IPDM E/R		x	x	
370Z \ Z34 \ 2012-11~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2012-11~	Pop up hood	x	x	x	
370Z \ Z34 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-12~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-12~	BCM		x		
370Z \ Z34 \ 2012-12~	Air bag	x	x	x	
370Z \ Z34 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-12~	Transmission		x	x	0059

370Z \ Z34 \ 2012-12~	Multi AV		x	x	
370Z \ Z34 \ 2012-12~	IPDM E/R		x	x	
370Z \ Z34 \ 2012-12~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2012-12~	Pop up hood	x	x	x	
370Z \ Z34 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-5~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-5~	BCM		x		
370Z \ Z34 \ 2012-5~	Air bag	x	x	x	
370Z \ Z34 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-5~	Transmission		x	x	0059
370Z \ Z34 \ 2012-5~	Multi AV		x	x	
370Z \ Z34 \ 2012-5~	IPDM E/R		x	x	
370Z \ Z34 \ 2012-5~	Telematics		x	x	
370Z \ Z34 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-8~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-8~	BCM		x		
370Z \ Z34 \ 2012-8~	Air bag	x	x	x	
370Z \ Z34 \ 2012-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-8~	Transmission		x	x	0059
370Z \ Z34 \ 2012-8~	Multi AV		x	x	
370Z \ Z34 \ 2012-8~	IPDM E/R		x	x	
370Z \ Z34 \ 2012-8~	Telematics		x	x	
370Z \ Z34 \ 2012-8~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2012-8~	Pop up hood	x	x	x	
370Z \ Z34 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2012-9~	Meter/M&A		x	x	
370Z \ Z34 \ 2012-9~	BCM		x		
370Z \ Z34 \ 2012-9~	Air bag	x	x	x	
370Z \ Z34 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2012-9~	Transmission		x	x	0059
370Z \ Z34 \ 2012-9~	Multi AV		x	x	
370Z \ Z34 \ 2012-9~	IPDM E/R		x	x	

370Z \ Z34 \ 2012-9~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2012-9~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013	Meter/M&A		x	x	
370Z \ Z34 \ 2013	BCM		x		
370Z \ Z34 \ 2013	Air bag	x	x	x	
370Z \ Z34 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013	Transmission		x	x	0059
370Z \ Z34 \ 2013	Multi AV		x	x	
370Z \ Z34 \ 2013	IPDM E/R		x	x	
370Z \ Z34 \ 2013	Telematics		x	x	
370Z \ Z34 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-1~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-1~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-1~	BCM		x		
370Z \ Z34 \ 2013-1~	Air bag	x	x	x	
370Z \ Z34 \ 2013-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-1~	Transmission		x	x	0059
370Z \ Z34 \ 2013-1~	Multi AV		x	x	
370Z \ Z34 \ 2013-1~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-1~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2013-1~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-4~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-4~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-4~	BCM		x		
370Z \ Z34 \ 2013-4~	Air bag	x	x	x	
370Z \ Z34 \ 2013-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-4~	Transmission		x	x	0059
370Z \ Z34 \ 2013-4~	Multi AV		x	x	
370Z \ Z34 \ 2013-4~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-4~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2013-4~	Pop up hood	x	x	x	

370Z \ Z34 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-5~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-5~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-5~	BCM		x		
370Z \ Z34 \ 2013-5~	Air bag	x	x	x	
370Z \ Z34 \ 2013-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-5~	Transmission		x	x	0059
370Z \ Z34 \ 2013-5~	Multi AV	x	x	x	0280
370Z \ Z34 \ 2013-5~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-5~	Telematics		x	x	
370Z \ Z34 \ 2013-5~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2013-5~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-7~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-7~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-7~	BCM		x		
370Z \ Z34 \ 2013-7~	Air bag	x	x	x	
370Z \ Z34 \ 2013-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-7~	Transmission		x	x	0059
370Z \ Z34 \ 2013-7~	Multi AV		x	x	
370Z \ Z34 \ 2013-7~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-7~	Telematics		x	x	
370Z \ Z34 \ 2013-7~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2013-7~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-8~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-8~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-8~	BCM		x		
370Z \ Z34 \ 2013-8~	Air bag	x	x	x	
370Z \ Z34 \ 2013-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-8~	Transmission		x	x	0059
370Z \ Z34 \ 2013-8~	Multi AV	x	x	x	0280
370Z \ Z34 \ 2013-8~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-8~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013-8~	AVM		x	x	

370Z \ Z34 \ 2013-8~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2013-9~	Meter/M&A		x	x	
370Z \ Z34 \ 2013-9~	BCM		x		
370Z \ Z34 \ 2013-9~	Air bag	x	x	x	
370Z \ Z34 \ 2013-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2013-9~	Transmission		x	x	0059
370Z \ Z34 \ 2013-9~	Multi AV	x	x	x	0280
370Z \ Z34 \ 2013-9~	IPDM E/R		x	x	
370Z \ Z34 \ 2013-9~	Pop up hood	x	x	x	
370Z \ Z34 \ 2013-9~	AVM		x	x	
370Z \ Z34 \ 2013-9~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2014	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2014	Meter/M&A		x	x	
370Z \ Z34 \ 2014	BCM		x		
370Z \ Z34 \ 2014	Air bag	x	x	x	
370Z \ Z34 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2014	Transmission		x	x	0059
370Z \ Z34 \ 2014	Multi AV	x	x	x	0280
370Z \ Z34 \ 2014	IPDM E/R		x	x	
370Z \ Z34 \ 2014	Telematics		x	x	
370Z \ Z34 \ 2014	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2014	Pop up hood	x	x	x	
370Z \ Z34 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2014-6~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2014-6~	Meter/M&A		x	x	
370Z \ Z34 \ 2014-6~	BCM		x		
370Z \ Z34 \ 2014-6~	Air bag	x	x	x	
370Z \ Z34 \ 2014-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2014-6~	Transmission		x	x	0059
370Z \ Z34 \ 2014-6~	Multi AV		x	x	
370Z \ Z34 \ 2014-6~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2014-6~	IPDM E/R		x	x	

370Z \ Z34 \ 2014-6~	Pop up hood	x	x	x	
370Z \ Z34 \ 2014-6~	AVM		x	x	
370Z \ Z34 \ 2014-6~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2014-7~	Meter/M&A		x	x	
370Z \ Z34 \ 2014-7~	BCM		x		
370Z \ Z34 \ 2014-7~	Air bag	x	x	x	
370Z \ Z34 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2014-7~	Transmission		x	x	0059
370Z \ Z34 \ 2014-7~	Multi AV		x	x	
370Z \ Z34 \ 2014-7~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2014-7~	IPDM E/R		x	x	
370Z \ Z34 \ 2014-7~	Air pressure monitor		x	x	
370Z \ Z34 \ 2014-7~	Pop up hood	x	x	x	
370Z \ Z34 \ 2014-7~	AVM		x	x	
370Z \ Z34 \ 2014-7~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2014-7~	Multi AV	x	x	x	0280
370Z \ Z34 \ 2014-7~	Air pressure monitor	x	x	x	
370Z \ Z34 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2014-9~	Meter/M&A		x	x	
370Z \ Z34 \ 2014-9~	BCM		x		
370Z \ Z34 \ 2014-9~	Air bag	x	x	x	
370Z \ Z34 \ 2014-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2014-9~	Transmission		x	x	0059
370Z \ Z34 \ 2014-9~	Multi AV	x	x	x	0280
370Z \ Z34 \ 2014-9~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2014-9~	IPDM E/R		x	x	
370Z \ Z34 \ 2014-9~	Air pressure monitor	x	x	x	
370Z \ Z34 \ 2014-9~	Pop up hood	x	x	x	
370Z \ Z34 \ 2014-9~	AVM		x	x	
370Z \ Z34 \ 2014-9~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2015	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2015	Meter/M&A		x	x	

370Z \ Z34 \ 2015	BCM		×		
370Z \ Z34 \ 2015	Air bag	×	×	×	
370Z \ Z34 \ 2015	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2015	Transmission		×	×	0059
370Z \ Z34 \ 2015	Multi AV		×	×	
370Z \ Z34 \ 2015	EPS/DAST 3	×	×	×	
370Z \ Z34 \ 2015	IPDM E/R		×	×	
370Z \ Z34 \ 2015	Pop up hood	×	×	×	
370Z \ Z34 \ 2015	Telematics		×	×	
370Z \ Z34 \ 2015	AVM		×	×	
370Z \ Z34 \ 2015-2~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2015-2~	ABS	×	×	×	0003, 0092, 0264
370Z \ Z34 \ 2015-2~	Meter/M&A		×	×	
370Z \ Z34 \ 2015-2~	BCM		×		
370Z \ Z34 \ 2015-2~	Air bag	×	×	×	
370Z \ Z34 \ 2015-2~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2015-2~	Transmission		×	×	0059
370Z \ Z34 \ 2015-2~	Multi AV		×	×	
370Z \ Z34 \ 2015-2~	EPS/DAST 3	×	×	×	
370Z \ Z34 \ 2015-2~	IPDM E/R		×	×	
370Z \ Z34 \ 2015-2~	Pop up hood	×	×	×	
370Z \ Z34 \ 2015-2~	ANC		×	×	
370Z \ Z34 \ 2015-2~	Head lamp levelizer	×	×	×	
370Z \ Z34 \ 2015-4~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2015-4~	ABS	×	×	×	0003, 0092, 0264
370Z \ Z34 \ 2015-4~	Meter/M&A		×	×	
370Z \ Z34 \ 2015-4~	BCM		×		
370Z \ Z34 \ 2015-4~	Air bag	×	×	×	
370Z \ Z34 \ 2015-4~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2015-4~	Transmission		×	×	0059
370Z \ Z34 \ 2015-4~	Multi AV		×	×	
370Z \ Z34 \ 2015-4~	EPS/DAST 3	×	×	×	
370Z \ Z34 \ 2015-4~	IPDM E/R		×	×	
370Z \ Z34 \ 2015-4~	Air pressure monitor		×	×	
370Z \ Z34 \ 2015-4~	Pop up hood	×	×	×	
370Z \ Z34 \ 2015-4~	ANC		×	×	

370Z \ Z34 \ 2015-4~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2015-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2015-5~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2015-5~	Meter/M&A		x	x	
370Z \ Z34 \ 2015-5~	BCM		x		
370Z \ Z34 \ 2015-5~	Air bag	x	x	x	
370Z \ Z34 \ 2015-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2015-5~	Transmission		x	x	0059
370Z \ Z34 \ 2015-5~	Multi AV		x	x	
370Z \ Z34 \ 2015-5~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2015-5~	IPDM E/R		x	x	
370Z \ Z34 \ 2015-5~	Air pressure monitor		x	x	
370Z \ Z34 \ 2015-5~	Pop up hood	x	x	x	
370Z \ Z34 \ 2015-5~	ANC		x	x	
370Z \ Z34 \ 2015-5~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2016	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2016	Meter/M&A		x	x	
370Z \ Z34 \ 2016	BCM		x		
370Z \ Z34 \ 2016	Air bag	x	x	x	
370Z \ Z34 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2016	Transmission		x	x	0059
370Z \ Z34 \ 2016	Multi AV		x	x	
370Z \ Z34 \ 2016	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2016	IPDM E/R		x	x	
370Z \ Z34 \ 2016	Pop up hood	x	x	x	
370Z \ Z34 \ 2016	ANC		x	x	
370Z \ Z34 \ 2016	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2016-3~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2016-3~	Meter/M&A		x	x	
370Z \ Z34 \ 2016-3~	BCM		x		
370Z \ Z34 \ 2016-3~	Air bag	x	x	x	
370Z \ Z34 \ 2016-3~	ICC/ADAS	x	x	x	
370Z \ Z34 \ 2016-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

370Z \ Z34 \ 2016-3~	Transmission		x	x	0059
370Z \ Z34 \ 2016-3~	Multi AV		x	x	
370Z \ Z34 \ 2016-3~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2016-3~	IPDM E/R		x	x	
370Z \ Z34 \ 2016-3~	Air pressure monitor		x	x	
370Z \ Z34 \ 2016-3~	Convertible roof		x	x	
370Z \ Z34 \ 2016-3~	Auto drive position	x	x	x	
370Z \ Z34 \ 2016-3~	Adaptive light	x	x	x	
370Z \ Z34 \ 2016-3~	Pop up hood	x	x	x	
370Z \ Z34 \ 2016-3~	ANC		x	x	
370Z \ Z34 \ 2016-3~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2016-3~	Occupant detection			x	
370Z \ Z34 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2016-7~	Meter/M&A		x	x	
370Z \ Z34 \ 2016-7~	BCM		x		
370Z \ Z34 \ 2016-7~	Air bag	x	x	x	
370Z \ Z34 \ 2016-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2016-7~	Transmission		x	x	0059
370Z \ Z34 \ 2016-7~	Multi AV		x	x	
370Z \ Z34 \ 2016-7~	IPDM E/R		x	x	
370Z \ Z34 \ 2016-7~	Air pressure monitor		x	x	
370Z \ Z34 \ 2016-7~	Convertible roof		x	x	
370Z \ Z34 \ 2016-7~	Laser/radar		x	x	
370Z \ Z34 \ 2016-7~	Auto drive position	x	x	x	
370Z \ Z34 \ 2016-7~	Adaptive light	x	x	x	
370Z \ Z34 \ 2016-7~	Pop up hood	x	x	x	
370Z \ Z34 \ 2016-7~	ANC		x	x	
370Z \ Z34 \ 2016-7~	Head lamp levelizer	x	x	x	
370Z \ Z34 \ 2016-7~	Occupant detection			x	
370Z \ Z34 \ 2016-7~	ICC/ADAS	x	x	x	
370Z \ Z34 \ 2016-7~	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
370Z \ Z34 \ 2017	ABS	x	x	x	0003, 0092, 0264
370Z \ Z34 \ 2017	Meter/M&A		x	x	
370Z \ Z34 \ 2017	BCM		x		
370Z \ Z34 \ 2017	Air bag	x	x	x	
370Z \ Z34 \ 2017	ICC/ADAS	x	x	x	

370Z \ Z34 \ 2017	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
370Z \ Z34 \ 2017	Transmission		x	x	0059
370Z \ Z34 \ 2017	Multi AV		x	x	
370Z \ Z34 \ 2017	EPS/DAST 3	x	x	x	
370Z \ Z34 \ 2017	IPDM E/R		x	x	
370Z \ Z34 \ 2017	Convertible roof		x	x	
370Z \ Z34 \ 2017	Adaptive light	x	x	x	
370Z \ Z34 \ 2017	Pop up hood	x	x	x	
370Z \ Z34 \ 2017	ANC		x	x	
370Z \ Z34 \ 2017	Head lamp levelizer	x	x	x	
Ad van \ VY12 \ 2006-12~	ABS	x	x	x	
Ad van \ VY12 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Ad van \ VY12 \ 2006-12~	BCM	x	x		
Ad van \ VY12 \ 2006-12~	Transmission		x	x	
Ad van \ VY12 \ 2006-12~	EPS/DAST 3	x	x	x	
Ad van \ VY12 \ 2006-12~	IPDM E/R	x	x	x	
Ad van \ VY12 \ 2006-12~	E-4wd	x	x	x	
Ad van \ VY12 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Ad van \ VY12 \ 2006-12~	Engine	x	x	x	
Ad van \ VY12 \ 2006-12~	Air bag	x	x	x	
Ad van \ VY12 \ 2008-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Ad van \ VY12 \ 2008-11~	ABS	x	x	x	
Ad van \ VY12 \ 2008-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Ad van \ VY12 \ 2008-11~	BCM	x	x		
Ad van \ VY12 \ 2008-11~	Transmission		x	x	
Ad van \ VY12 \ 2008-11~	EPS/DAST 3	x	x	x	
Ad van \ VY12 \ 2008-11~	IPDM E/R	x	x	x	
Ad van \ VY12 \ 2008-11~	E-4wd	x	x	x	
Ad van \ VY12 \ 2008-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Ad van \ VY12 \ 2008-11~	Air bag	x	x	x	
Ad van \ VY12 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Ad van \ VY12 \ 2010-8~	ABS	x	x	x	
Ad van \ VY12 \ 2010-8~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Ad van \ VY12 \ 2010-8~	BCM	x	x		

Ad van \ VY12 \ 2010-8~	Transmission		x	x	
Ad van \ VY12 \ 2010-8~	EPS/DAST 3	x	x	x	
Ad van \ VY12 \ 2010-8~	IPDM E/R	x	x	x	
Ad van \ VY12 \ 2010-8~	E-4wd	x	x	x	
Ad van \ VY12 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Ad van \ VY12 \ 2010-8~	Adaptive light	x	x	x	
Ad van \ VY12 \ 2010-8~	Air bag	x	x	x	
Ad van \ VY12 \ 2010-8~	Rearview camera			x	
Ad van \ VY12 \ 2010-8~	S/blind camera			x	
Ad van \ VY12 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Ad van \ VY12 \ 2012-4~	ABS	x	x	x	
Ad van \ VY12 \ 2012-4~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Ad van \ VY12 \ 2012-4~	BCM	x	x		
Ad van \ VY12 \ 2012-4~	EPS/DAST 3	x	x	x	
Ad van \ VY12 \ 2012-4~	IPDM E/R	x	x	x	
Ad van \ VY12 \ 2012-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Ad van \ VY12 \ 2012-4~	Adaptive light	x	x	x	
Ad van \ VY12 \ 2012-4~	Air bag	x	x	x	
Ad van \ VY12 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Ad van \ VY12 \ 2013-4~	ABS	x	x	x	
Ad van \ VY12 \ 2013-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Ad van \ VY12 \ 2013-4~	BCM	x	x		
Ad van \ VY12 \ 2013-4~	Air bag	x	x	x	
Ad van \ VY12 \ 2013-4~	Transmission		x	x	
Ad van \ VY12 \ 2013-4~	Multi AV	x	x	x	0280
Ad van \ VY12 \ 2013-4~	EPS/DAST 3	x	x	x	
Ad van \ VY12 \ 2013-4~	IPDM E/R	x	x	x	
Ad van \ VY12 \ 2013-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Ad van \ VY12 \ 2013-4~	Adaptive light	x	x	x	
AD-AD expert \ VY12 \ 2016-1~	Engine	x	x	x	0108, 0144, 0114, 0279, 0289, 0288, 0233, 0103, 0234, 0209, 0278, 0071, 0262, 0274, 0329, 0328, 0216, 0212
AD-AD expert \ VY12 \ 2016-1~	ABS	x	x	x	

AD-AD expert \ VY12 \ 2016-1~	Meter/M&A		x	x	
AD-AD expert \ VY12 \ 2016-1~	BCM	x	x		
AD-AD expert \ VY12 \ 2016-1~	Air bag	x	x	x	
AD-AD expert \ VY12 \ 2016-1~	Transmission		x	x	
AD-AD expert \ VY12 \ 2016-1~	EPS/DAST 3	x	x	x	
AD-AD expert \ VY12 \ 2016-1~	IPDM E/R	x	x	x	
AD-AD expert \ VY12 \ 2016-1~	Laser/radar	x	x	x	
AD-AD expert \ VY12 \ 2016-1~	Adaptive light	x	x	x	
almera classic \ B10 \ 2006-4~	Meter/M&A		x	x	
almera classic \ B10 \ 2006-4~	Transmission		x	x	
almera classic \ B10 \ 2006-4~	Engine	x	x	x	
almera classic \ B10 \ 2006-4~	ABS	x	x	x	
almera classic \ B10 \ 2006-4~	Air bag		x	x	0317, 0341
Almera \ G15 \ 2012-11~	Engine	x	x	x	0241, 0064, 0112, 0148, 0061, 0219, 0217, 0282, 0281, 0168, 0220, 0041
Almera \ G15 \ 2012-11~	Transmission		x	x	0033, 0182, 0336, 0337
Almera \ G15 \ 2012-11~	ABS		x	x	0336, 0263, 0325, 0055
Almera \ G15 \ 2012-11~	BCM	x	x	x	
Almera \ G15 \ 2012-11~	Air bag		x	x	0317, 0341
Almera \ G15 \ 2016-6~	Engine	x	x	x	0241, 0064, 0112, 0148, 0061, 0219, 0217, 0282, 0281, 0168, 0220, 0041
Almera \ G15 \ 2016-6~	Transmission		x	x	0033, 0182, 0336, 0337
Almera \ G15 \ 2016-6~	ABS		x	x	0336, 0263, 0325, 0055
Almera \ G15 \ 2016-6~	BCM	x	x	x	
Almera \ G15 \ 2016-6~	Air bag		x	x	0317, 0341
Almera \ N15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Almera \ N15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N15 \ All Year	BCM	x	x		
Almera \ N15 \ All Year	Air bag	x	x	x	
Almera \ N15 \ All Year	ICC/ADAS	x	x	x	
Almera \ N15 \ All Year	HVAC	x	x	x	
Almera \ N15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Almera \ N15 \ All Year	Multi AV	x	x	x	0280
Almera \ N15 \ All Year	EPS/DAST 3	x	x	x	
Almera \ N15 \ All Year	IPDM E/R	x	x	x	
Almera \ N15 \ All Year	Air pressure monitor	x	x	x	
Almera \ N15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Almera \ N15 \ All Year	DIU	x	x	x	
Almera \ N15 \ All Year	Auto slide door	x	x	x	
Almera \ N15 \ All Year	Auto drive position	x	x	x	
Almera \ N15 \ All Year	All mode AWD/4WD	x	x	x	
Almera \ N15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Almera \ N15 \ All Year	Sonar	x	x	x	
Almera \ N15 \ All Year	Lane camera	x	x	x	
Almera \ N15 \ All Year	Adaptive light	x	x	x	
Almera \ N15 \ All Year	AVM		x	x	
Almera \ N15 \ All Year	Head lamp levelizer	x	x	x	
Almera \ N15 \ All Year	Difference lock	x	x	x	
Almera \ N15 \ All Year	Nats immu	x	x		
Almera \ N15 \ All Year	Smart entrance	x	x		
Almera \ N15 \ All Year	Air levelizer	x	x	x	
Almera \ N15 \ All Year	Rearview camera			x	
Almera \ N15 \ All Year	S/blind camera			x	
Almera \ N15 \ All Year	Motor assist	x	x	x	
Almera \ N16 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N16 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
Almera \ N16 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N16 \ 2009-8~	BCM	x	x		
Almera \ N16 \ 2009-8~	Air bag	x	x	x	
Almera \ N16 \ 2009-8~	ICC/ADAS	x	x	x	
Almera \ N16 \ 2009-8~	HVAC	x	x	x	
Almera \ N16 \ 2009-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Almera \ N16 \ 2009-8~	Multi AV	x	x	x	0280
Almera \ N16 \ 2009-8~	EPS/DAST 3	x	x	x	
Almera \ N16 \ 2009-8~	IPDM E/R	x	x	x	
Almera \ N16 \ 2009-8~	Air pressure monitor	x	x	x	
Almera \ N16 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Almera \ N16 \ 2009-8~	DIU	x	x	x	
Almera \ N16 \ 2009-8~	Auto slide door	x	x	x	
Almera \ N16 \ 2009-8~	Auto drive position	x	x	x	
Almera \ N16 \ 2009-8~	All mode AWD/4WD	x	x	x	
Almera \ N16 \ 2009-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Almera \ N16 \ 2009-8~	Sonar	x	x	x	
Almera \ N16 \ 2009-8~	Lane camera	x	x	x	
Almera \ N16 \ 2009-8~	Adaptive light	x	x	x	

Almera \ N16 \ 2009-8~	AVM		x	x	
Almera \ N16 \ 2009-8~	Head lamp levelizer	x	x	x	
Almera \ N16 \ 2009-8~	Difference lock	x	x	x	
Almera \ N16 \ 2009-8~	Nats immu	x	x		
Almera \ N16 \ 2009-8~	Smart entrance	x	x		
Almera \ N16 \ 2009-8~	Air levelizer	x	x	x	
Almera \ N16 \ 2009-8~	Rearview camera			x	
Almera \ N16 \ 2009-8~	S/blind camera			x	
Almera \ N16 \ 2009-8~	Motor assist	x	x	x	
Almera \ N16 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N16 \ All Year	ABS	x	x	x	0003, 0092, 0264
Almera \ N16 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N16 \ All Year	BCM	x	x		
Almera \ N16 \ All Year	Air bag	x	x	x	
Almera \ N16 \ All Year	ICC/ADAS	x	x	x	
Almera \ N16 \ All Year	HVAC	x	x	x	
Almera \ N16 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Almera \ N16 \ All Year	Multi AV	x	x	x	0280
Almera \ N16 \ All Year	EPS/DAST 3	x	x	x	
Almera \ N16 \ All Year	IPDM E/R	x	x	x	
Almera \ N16 \ All Year	Air pressure monitor	x	x	x	
Almera \ N16 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Almera \ N16 \ All Year	DIU	x	x	x	
Almera \ N16 \ All Year	Auto slide door	x	x	x	
Almera \ N16 \ All Year	Auto drive position	x	x	x	
Almera \ N16 \ All Year	All mode AWD/4WD	x	x	x	
Almera \ N16 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Almera \ N16 \ All Year	Sonar	x	x	x	
Almera \ N16 \ All Year	Lane camera	x	x	x	
Almera \ N16 \ All Year	Adaptive light	x	x	x	
Almera \ N16 \ All Year	AVM		x	x	
Almera \ N16 \ All Year	Head lamp levelizer	x	x	x	
Almera \ N16 \ All Year	Difference lock	x	x	x	
Almera \ N16 \ All Year	Nats immu	x	x		
Almera \ N16 \ All Year	Smart entrance	x	x		
Almera \ N16 \ All Year	Air levelizer	x	x	x	
Almera \ N16 \ All Year	Rearview camera			x	
Almera \ N16 \ All Year	S/blind camera			x	

Almera \ N16 \ All Year	Motor assist	x	x	x	
Almera \ N17 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2011-12~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2011-12~	BCM	x	x		
Almera \ N17 \ 2011-12~	Air bag	x	x	x	
Almera \ N17 \ 2011-12~	Transmission	x	x	x	
Almera \ N17 \ 2011-12~	Multi AV	x	x	x	0280
Almera \ N17 \ 2011-12~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2011-12~	IPDM E/R		x	x	
Almera \ N17 \ 2011-12~	Occupant detection			x	
Almera \ N17 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2011-9~	Meter/M&A		x	x	
Almera \ N17 \ 2011-9~	BCM		x		
Almera \ N17 \ 2011-9~	Air bag	x	x	x	
Almera \ N17 \ 2011-9~	Transmission		x	x	
Almera \ N17 \ 2011-9~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2011-9~	IPDM E/R		x	x	
Almera \ N17 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2012-3~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2012-3~	Meter/M&A		x	x	
Almera \ N17 \ 2012-3~	BCM		x		
Almera \ N17 \ 2012-3~	Transmission		x	x	
Almera \ N17 \ 2012-3~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2012-3~	IPDM E/R		x	x	
Almera \ N17 \ 2012-3~	Air bag	x	x	x	
Almera \ N17 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2012-9~	Meter/M&A		x	x	
Almera \ N17 \ 2012-9~	BCM		x		
Almera \ N17 \ 2012-9~	Air bag	x	x	x	
Almera \ N17 \ 2012-9~	Transmission		x	x	
Almera \ N17 \ 2012-9~	Multi AV	x	x	x	0280
Almera \ N17 \ 2012-9~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2012-9~	IPDM E/R		x	x	
Almera \ N17 \ 2012-9~	Occupant detection			x	

Almera \ N17 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2013-12~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2013-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2013-12~	BCM		x		
Almera \ N17 \ 2013-12~	Air bag	x	x	x	
Almera \ N17 \ 2013-12~	ICC/ADAS	x	x	x	
Almera \ N17 \ 2013-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Almera \ N17 \ 2013-12~	Multi AV	x	x	x	0280
Almera \ N17 \ 2013-12~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2013-12~	IPDM E/R		x	x	
Almera \ N17 \ 2013-12~	Laser/radar	x	x	x	
Almera \ N17 \ 2013-12~	Sonar	x	x	x	
Almera \ N17 \ 2013-12~	Accele pedal ACT		x	x	
Almera \ N17 \ 2013-12~	Side radar left		x	x	
Almera \ N17 \ 2013-12~	ANC		x	x	
Almera \ N17 \ 2013-12~	Side radar right		x	x	
Almera \ N17 \ 2013-12~	PTC heater		x	x	
Almera \ N17 \ 2013-12~	Telematics		x	x	0253
Almera \ N17 \ 2013-12~	AVM		x	x	
Almera \ N17 \ 2013-12~	Head lamp levelizer	x	x	x	
Almera \ N17 \ 2013-12~	Occupant detection			x	
Almera \ N17 \ 2014-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2014-10~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2014-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2014-10~	BCM		x		
Almera \ N17 \ 2014-10~	Air bag	x	x	x	
Almera \ N17 \ 2014-10~	Transmission		x	x	
Almera \ N17 \ 2014-10~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2014-10~	IPDM E/R		x	x	
Almera \ N17 \ 2014-10~	Occupant detection			x	
Almera \ N17 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2014-11~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2014-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2014-11~	BCM		x		
Almera \ N17 \ 2014-11~	Air bag	x	x	x	
Almera \ N17 \ 2014-11~	ICC/ADAS	x	x	x	

Almera \ N17 \ 2014-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Almera \ N17 \ 2014-11~	Multi AV	x	x	x	0280
Almera \ N17 \ 2014-11~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2014-11~	IPDM E/R		x	x	
Almera \ N17 \ 2014-11~	Laser/radar	x	x	x	
Almera \ N17 \ 2014-11~	Sonar	x	x	x	
Almera \ N17 \ 2014-11~	Accele pedal ACT		x	x	
Almera \ N17 \ 2014-11~	Side radar left		x	x	
Almera \ N17 \ 2014-11~	ANC		x	x	
Almera \ N17 \ 2014-11~	Side radar right		x	x	
Almera \ N17 \ 2014-11~	PTC heater		x	x	
Almera \ N17 \ 2014-11~	Telematics		x	x	0253
Almera \ N17 \ 2014-11~	AVM		x	x	
Almera \ N17 \ 2014-11~	Head lamp levelizer	x	x	x	
Almera \ N17 \ 2014-11~	Occupant detection			x	
Almera \ N17 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2014-2~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2014-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2014-2~	BCM		x		
Almera \ N17 \ 2014-2~	Air bag	x	x	x	
Almera \ N17 \ 2014-2~	ICC/ADAS	x	x	x	
Almera \ N17 \ 2014-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Almera \ N17 \ 2014-2~	Multi AV	x	x	x	0280
Almera \ N17 \ 2014-2~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2014-2~	IPDM E/R		x	x	
Almera \ N17 \ 2014-2~	Laser/radar	x	x	x	
Almera \ N17 \ 2014-2~	Sonar	x	x	x	
Almera \ N17 \ 2014-2~	Accele pedal ACT		x	x	
Almera \ N17 \ 2014-2~	Side radar left		x	x	
Almera \ N17 \ 2014-2~	ANC		x	x	
Almera \ N17 \ 2014-2~	Side radar right		x	x	
Almera \ N17 \ 2014-2~	PTC heater		x	x	
Almera \ N17 \ 2014-2~	Telematics		x	x	0253
Almera \ N17 \ 2014-2~	AVM		x	x	
Almera \ N17 \ 2014-2~	Head lamp levelizer	x	x	x	
Almera \ N17 \ 2014-2~	Occupant detection			x	
Almera \ N17 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Almera \ N17 \ 2014-6~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2014-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2014-6~	BCM		x		
Almera \ N17 \ 2014-6~	Air bag	x	x	x	
Almera \ N17 \ 2014-6~	ICC/ADAS	x	x	x	
Almera \ N17 \ 2014-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Almera \ N17 \ 2014-6~	Multi AV	x	x	x	0280
Almera \ N17 \ 2014-6~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2014-6~	IPDM E/R		x	x	
Almera \ N17 \ 2014-6~	Laser/radar	x	x	x	
Almera \ N17 \ 2014-6~	Sonar	x	x	x	
Almera \ N17 \ 2014-6~	Accele pedal ACT		x	x	
Almera \ N17 \ 2014-6~	Side radar left		x	x	
Almera \ N17 \ 2014-6~	ANC		x	x	
Almera \ N17 \ 2014-6~	Side radar right		x	x	
Almera \ N17 \ 2014-6~	PTC heater		x	x	
Almera \ N17 \ 2014-6~	Telematics		x	x	0253
Almera \ N17 \ 2014-6~	AVM		x	x	
Almera \ N17 \ 2014-6~	Head lamp levelizer	x	x	x	
Almera \ N17 \ 2014-6~	Occupant detection			x	
Almera \ N17 \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Almera \ N17 \ 2015-7~	ABS	x	x	x	0003, 0092, 0264
Almera \ N17 \ 2015-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Almera \ N17 \ 2015-7~	BCM		x		
Almera \ N17 \ 2015-7~	Air bag	x	x	x	
Almera \ N17 \ 2015-7~	ICC/ADAS	x	x	x	
Almera \ N17 \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Almera \ N17 \ 2015-7~	Multi AV	x	x	x	0280
Almera \ N17 \ 2015-7~	EPS/DAST 3	x	x	x	
Almera \ N17 \ 2015-7~	IPDM E/R		x	x	
Almera \ N17 \ 2015-7~	Laser/radar	x	x	x	
Almera \ N17 \ 2015-7~	Sonar	x	x	x	
Almera \ N17 \ 2015-7~	Accele pedal ACT		x	x	
Almera \ N17 \ 2015-7~	Side radar left		x	x	
Almera \ N17 \ 2015-7~	ANC		x	x	
Almera \ N17 \ 2015-7~	Side radar right		x	x	
Almera \ N17 \ 2015-7~	PTC heater		x	x	
Almera \ N17 \ 2015-7~	Telematics		x	x	0253

Almera \ N17 \ 2015-7~	AVM		x	x	
Almera \ N17 \ 2015-7~	Head lamp levelizer	x	x	x	
Almera \ N17 \ 2015-7~	Occupant detection			x	
Altima coupe \ L32 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2007	Meter/M&A		x	x	
Altima coupe \ L32 \ 2007	BCM		x		
Altima coupe \ L32 \ 2007	Air bag	x	x	x	
Altima coupe \ L32 \ 2007	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2007	Transmission	x	x	x	
Altima coupe \ L32 \ 2007	Multi AV	x	x	x	
Altima coupe \ L32 \ 2007	IPDM E/R		x	x	
Altima coupe \ L32 \ 2007	ABS	x	x	x	
Altima coupe \ L32 \ 2007	Rearview camera			x	
Altima coupe \ L32 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2008	Meter/M&A		x	x	
Altima coupe \ L32 \ 2008	BCM		x		
Altima coupe \ L32 \ 2008	Air bag	x	x	x	
Altima coupe \ L32 \ 2008	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2008	Transmission	x	x	x	
Altima coupe \ L32 \ 2008	Multi AV	x	x	x	
Altima coupe \ L32 \ 2008	IPDM E/R		x	x	
Altima coupe \ L32 \ 2008	ABS	x	x	x	
Altima coupe \ L32 \ 2008	Rearview camera			x	
Altima coupe \ L32 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2009	Meter/M&A		x	x	
Altima coupe \ L32 \ 2009	BCM		x		
Altima coupe \ L32 \ 2009	Air bag	x	x	x	
Altima coupe \ L32 \ 2009	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2009	Transmission	x	x	x	
Altima coupe \ L32 \ 2009	Multi AV	x	x	x	0280
Altima coupe \ L32 \ 2009	IPDM E/R		x	x	
Altima coupe \ L32 \ 2009	ABS	x	x	x	
Altima coupe \ L32 \ 2009	Sonar	x	x	x	
Altima coupe \ L32 \ 2009	Rearview camera			x	
Altima coupe \ L32 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2010	Meter/M&A		x	x	
Altima coupe \ L32 \ 2010	BCM		x		

Altima coupe \ L32 \ 2010	Air bag	x	x	x	
Altima coupe \ L32 \ 2010	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2010	Transmission	x	x	x	
Altima coupe \ L32 \ 2010	Multi AV	x	x	x	0280
Altima coupe \ L32 \ 2010	IPDM E/R		x	x	
Altima coupe \ L32 \ 2010	ABS	x	x	x	
Altima coupe \ L32 \ 2010	Sonar	x	x	x	
Altima coupe \ L32 \ 2010	Rearview camera			x	
Altima coupe \ L32 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2011	Meter/M&A		x	x	
Altima coupe \ L32 \ 2011	BCM		x		
Altima coupe \ L32 \ 2011	Air bag	x	x	x	
Altima coupe \ L32 \ 2011	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2011	Transmission	x	x	x	
Altima coupe \ L32 \ 2011	Multi AV	x	x	x	0280
Altima coupe \ L32 \ 2011	IPDM E/R		x	x	
Altima coupe \ L32 \ 2011	ABS	x	x	x	
Altima coupe \ L32 \ 2011	Sonar	x	x	x	
Altima coupe \ L32 \ 2011	Rearview camera			x	
Altima coupe \ L32 \ 2011	S/blind camera			x	
Altima coupe \ L32 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2012	Meter/M&A		x	x	
Altima coupe \ L32 \ 2012	BCM		x		
Altima coupe \ L32 \ 2012	Air bag	x	x	x	
Altima coupe \ L32 \ 2012	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2012	Transmission	x	x	x	
Altima coupe \ L32 \ 2012	Multi AV		x	x	
Altima coupe \ L32 \ 2012	IPDM E/R		x	x	
Altima coupe \ L32 \ 2012	Auto drive position	x	x	x	
Altima coupe \ L32 \ 2012	ABS	x	x	x	
Altima coupe \ L32 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima coupe \ L32 \ 2013	ABS	x	x	x	0003, 0092, 0264
Altima coupe \ L32 \ 2013	Meter/M&A		x	x	
Altima coupe \ L32 \ 2013	BCM		x		
Altima coupe \ L32 \ 2013	Air bag	x	x	x	
Altima coupe \ L32 \ 2013	HVAC		x	x	0048, 0140, 0229, 0297
Altima coupe \ L32 \ 2013	Transmission	x	x	x	
Altima coupe \ L32 \ 2013	Multi AV		x	x	

Altima coupe \ L32 \ 2013	IPDM E/R		x	x	
Altima coupe \ L32 \ 2013	Head lamp levelizer	x	x	x	
Altima hybrid \ HL32 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima hybrid \ HL32 \ 2007	ABS	x	x	x	
Altima hybrid \ HL32 \ 2007	Meter/M&A		x	x	
Altima hybrid \ HL32 \ 2007	BCM		x		
Altima hybrid \ HL32 \ 2007	Air bag	x	x	x	
Altima hybrid \ HL32 \ 2007	HVAC		x	x	0048, 0140, 0229, 0297
Altima hybrid \ HL32 \ 2007	Transmission		x	x	
Altima hybrid \ HL32 \ 2007	Multi AV	x	x	x	
Altima hybrid \ HL32 \ 2007	EPS/DAST 3		x	x	
Altima hybrid \ HL32 \ 2007	IPDM E/R		x	x	
Altima hybrid \ HL32 \ 2007	EV/HEV		x	x	
Altima hybrid \ HL32 \ 2007	Rearview camera			x	
Altima hybrid \ HL32 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima hybrid \ HL32 \ 2008	ABS	x	x	x	
Altima hybrid \ HL32 \ 2008	Meter/M&A		x	x	
Altima hybrid \ HL32 \ 2008	BCM		x		
Altima hybrid \ HL32 \ 2008	Air bag	x	x	x	
Altima hybrid \ HL32 \ 2008	HVAC		x	x	0048, 0140, 0229, 0297
Altima hybrid \ HL32 \ 2008	Transmission		x	x	
Altima hybrid \ HL32 \ 2008	Multi AV	x	x	x	
Altima hybrid \ HL32 \ 2008	EPS/DAST 3		x	x	
Altima hybrid \ HL32 \ 2008	IPDM E/R		x	x	
Altima hybrid \ HL32 \ 2008	EV/HEV		x	x	
Altima hybrid \ HL32 \ 2008	Rearview camera			x	
Altima hybrid \ HL32 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima hybrid \ HL32 \ 2009	ABS	x	x	x	
Altima hybrid \ HL32 \ 2009	Meter/M&A		x	x	
Altima hybrid \ HL32 \ 2009	BCM		x		
Altima hybrid \ HL32 \ 2009	Air bag	x	x	x	
Altima hybrid \ HL32 \ 2009	HVAC		x	x	0048, 0140, 0229, 0297
Altima hybrid \ HL32 \ 2009	Transmission		x	x	
Altima hybrid \ HL32 \ 2009	Multi AV	x	x	x	0280
Altima hybrid \ HL32 \ 2009	EPS/DAST 3		x	x	
Altima hybrid \ HL32 \ 2009	IPDM E/R		x	x	
Altima hybrid \ HL32 \ 2009	EV/HEV		x	x	
Altima hybrid \ HL32 \ 2009	Sonar	x	x	x	

Altima hybrid \ HL32 \ 2009	Rearview camera			x	
Altima hybrid \ HL32 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima hybrid \ HL32 \ 2010	ABS	x	x	x	
Altima hybrid \ HL32 \ 2010	Meter/M&A		x	x	
Altima hybrid \ HL32 \ 2010	BCM		x		
Altima hybrid \ HL32 \ 2010	Air bag	x	x	x	
Altima hybrid \ HL32 \ 2010	HVAC		x	x	0048, 0140, 0229, 0297
Altima hybrid \ HL32 \ 2010	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima hybrid \ HL32 \ 2010	Multi AV	x	x	x	0280
Altima hybrid \ HL32 \ 2010	EPS/DAST 3		x	x	
Altima hybrid \ HL32 \ 2010	IPDM E/R		x	x	
Altima hybrid \ HL32 \ 2010	EV/HEV		x	x	
Altima hybrid \ HL32 \ 2010	Head lamp levelizer	x	x	x	
Altima hybrid \ HL32 \ 2010	Sonar	x	x	x	
Altima hybrid \ HL32 \ 2010	Rearview camera			x	
Altima hybrid \ HL32 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima hybrid \ HL32 \ 2011	ABS	x	x	x	
Altima hybrid \ HL32 \ 2011	Meter/M&A		x	x	
Altima hybrid \ HL32 \ 2011	BCM		x		
Altima hybrid \ HL32 \ 2011	Air bag	x	x	x	
Altima hybrid \ HL32 \ 2011	HVAC		x	x	0048, 0140, 0229, 0297
Altima hybrid \ HL32 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima hybrid \ HL32 \ 2011	Multi AV	x	x	x	0280
Altima hybrid \ HL32 \ 2011	EPS/DAST 3		x	x	
Altima hybrid \ HL32 \ 2011	IPDM E/R		x	x	
Altima hybrid \ HL32 \ 2011	EV/HEV		x	x	
Altima hybrid \ HL32 \ 2011	Head lamp levelizer	x	x	x	
Altima hybrid \ HL32 \ 2011	Sonar	x	x	x	
Altima hybrid \ HL32 \ 2011	Rearview camera			x	
Altima hybrid \ HL32 \ 2011	S/blind camera			x	
Altima sedan \ L30 \ 1997	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L30 \ 1997	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L30 \ 1997	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L30 \ 1997	BCM	x	x		
Altima sedan \ L30 \ 1997	Air bag	x	x	x	
Altima sedan \ L30 \ 1997	ICC/ADAS	x	x	x	
Altima sedan \ L30 \ 1997	HVAC	x	x	x	
Altima sedan \ L30 \ 1997	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

Altima sedan \ L30 \ 1997	Multi AV	x	x	x	0280
Altima sedan \ L30 \ 1997	EPS/DAST 3	x	x	x	
Altima sedan \ L30 \ 1997	IPDM E/R	x	x	x	
Altima sedan \ L30 \ 1997	Air pressure monitor	x	x	x	
Altima sedan \ L30 \ 1997	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L30 \ 1997	DIU	x	x	x	
Altima sedan \ L30 \ 1997	Auto slide door	x	x	x	
Altima sedan \ L30 \ 1997	Auto drive position	x	x	x	
Altima sedan \ L30 \ 1997	All mode AWD/4WD	x	x	x	
Altima sedan \ L30 \ 1997	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L30 \ 1997	Sonar	x	x	x	
Altima sedan \ L30 \ 1997	Lane camera	x	x	x	
Altima sedan \ L30 \ 1997	Adaptive light	x	x	x	
Altima sedan \ L30 \ 1997	AVM		x	x	
Altima sedan \ L30 \ 1997	Head lamp levelizer	x	x	x	
Altima sedan \ L30 \ 1997	Difference lock	x	x	x	
Altima sedan \ L30 \ 1997	Nats immu	x	x		
Altima sedan \ L30 \ 1997	Smart entrance	x	x		
Altima sedan \ L30 \ 1997	Air levelizer	x	x	x	
Altima sedan \ L30 \ 1997	Rearview camera			x	
Altima sedan \ L30 \ 1997	S/blind camera			x	
Altima sedan \ L30 \ 1997	Motor assist	x	x	x	
Altima sedan \ L30 \ 1998	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L30 \ 1998	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L30 \ 1998	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L30 \ 1998	BCM	x	x		
Altima sedan \ L30 \ 1998	Air bag	x	x	x	
Altima sedan \ L30 \ 1998	ICC/ADAS	x	x	x	
Altima sedan \ L30 \ 1998	HVAC	x	x	x	
Altima sedan \ L30 \ 1998	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L30 \ 1998	Multi AV	x	x	x	0280
Altima sedan \ L30 \ 1998	EPS/DAST 3	x	x	x	
Altima sedan \ L30 \ 1998	IPDM E/R	x	x	x	
Altima sedan \ L30 \ 1998	Air pressure monitor	x	x	x	
Altima sedan \ L30 \ 1998	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L30 \ 1998	DIU	x	x	x	

Altima sedan \ L30 \ 1998	Auto slide door	x	x	x	
Altima sedan \ L30 \ 1998	Auto drive position	x	x	x	
Altima sedan \ L30 \ 1998	All mode AWD/4WD	x	x	x	
Altima sedan \ L30 \ 1998	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L30 \ 1998	Sonar	x	x	x	
Altima sedan \ L30 \ 1998	Lane camera	x	x	x	
Altima sedan \ L30 \ 1998	Adaptive light	x	x	x	
Altima sedan \ L30 \ 1998	AVM		x	x	
Altima sedan \ L30 \ 1998	Head lamp levelizer	x	x	x	
Altima sedan \ L30 \ 1998	Difference lock	x	x	x	
Altima sedan \ L30 \ 1998	Nats immu	x	x		
Altima sedan \ L30 \ 1998	Smart entrance	x	x		
Altima sedan \ L30 \ 1998	Air levelizer	x	x	x	
Altima sedan \ L30 \ 1998	Rearview camera			x	
Altima sedan \ L30 \ 1998	S/blind camera			x	
Altima sedan \ L30 \ 1998	Motor assist	x	x	x	
Altima sedan \ L30 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L30 \ 1999	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L30 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L30 \ 1999	BCM	x	x		
Altima sedan \ L30 \ 1999	Air bag	x	x	x	
Altima sedan \ L30 \ 1999	ICC/ADAS	x	x	x	
Altima sedan \ L30 \ 1999	HVAC	x	x	x	
Altima sedan \ L30 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L30 \ 1999	Multi AV	x	x	x	0280
Altima sedan \ L30 \ 1999	EPS/DAST 3	x	x	x	
Altima sedan \ L30 \ 1999	IPDM E/R	x	x	x	
Altima sedan \ L30 \ 1999	Air pressure monitor	x	x	x	
Altima sedan \ L30 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L30 \ 1999	DIU	x	x	x	
Altima sedan \ L30 \ 1999	Auto slide door	x	x	x	
Altima sedan \ L30 \ 1999	Auto drive position	x	x	x	
Altima sedan \ L30 \ 1999	All mode AWD/4WD	x	x	x	
Altima sedan \ L30 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L30 \ 1999	Sonar	x	x	x	
Altima sedan \ L30 \ 1999	Lane camera	x	x	x	
Altima sedan \ L30 \ 1999	Adaptive light	x	x	x	
Altima sedan \ L30 \ 1999	AVM		x	x	

Altima sedan \ L30 \ 1999	Head lamp levelizer	x	x	x	
Altima sedan \ L30 \ 1999	Difference lock	x	x	x	
Altima sedan \ L30 \ 1999	Nats immu	x	x		
Altima sedan \ L30 \ 1999	Smart entrance	x	x		
Altima sedan \ L30 \ 1999	Air levelizer	x	x	x	
Altima sedan \ L30 \ 1999	Rearview camera			x	
Altima sedan \ L30 \ 1999	S/blind camera			x	
Altima sedan \ L30 \ 1999	Motor assist	x	x	x	
Altima sedan \ L30 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L30 \ 2000	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L30 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L30 \ 2000	BCM	x	x		
Altima sedan \ L30 \ 2000	Air bag	x	x	x	
Altima sedan \ L30 \ 2000	ICC/ADAS	x	x	x	
Altima sedan \ L30 \ 2000	HVAC	x	x	x	
Altima sedan \ L30 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L30 \ 2000	Multi AV	x	x	x	0280
Altima sedan \ L30 \ 2000	EPS/DAST 3	x	x	x	
Altima sedan \ L30 \ 2000	IPDM E/R	x	x	x	
Altima sedan \ L30 \ 2000	Air pressure monitor	x	x	x	
Altima sedan \ L30 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L30 \ 2000	DIU	x	x	x	
Altima sedan \ L30 \ 2000	Auto slide door	x	x	x	
Altima sedan \ L30 \ 2000	Auto drive position	x	x	x	
Altima sedan \ L30 \ 2000	All mode AWD/4WD	x	x	x	
Altima sedan \ L30 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L30 \ 2000	Sonar	x	x	x	
Altima sedan \ L30 \ 2000	Lane camera	x	x	x	
Altima sedan \ L30 \ 2000	Adaptive light	x	x	x	
Altima sedan \ L30 \ 2000	AVM		x	x	
Altima sedan \ L30 \ 2000	Head lamp levelizer	x	x	x	
Altima sedan \ L30 \ 2000	Difference lock	x	x	x	
Altima sedan \ L30 \ 2000	Nats immu	x	x		
Altima sedan \ L30 \ 2000	Smart entrance	x	x		
Altima sedan \ L30 \ 2000	Air levelizer	x	x	x	
Altima sedan \ L30 \ 2000	Rearview camera			x	
Altima sedan \ L30 \ 2000	S/blind camera			x	
Altima sedan \ L30 \ 2000	Motor assist	x	x	x	

Altima sedan \ L31 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2001	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2001	BCM	x	x		
Altima sedan \ L31 \ 2001	Air bag	x	x	x	
Altima sedan \ L31 \ 2001	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2001	HVAC	x	x	x	
Altima sedan \ L31 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2001	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2001	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2001	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2001	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L31 \ 2001	DIU	x	x	x	
Altima sedan \ L31 \ 2001	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2001	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2001	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2001	Sonar	x	x	x	
Altima sedan \ L31 \ 2001	Lane camera	x	x	x	
Altima sedan \ L31 \ 2001	Adaptive light	x	x	x	
Altima sedan \ L31 \ 2001	AVM		x	x	
Altima sedan \ L31 \ 2001	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2001	Difference lock	x	x	x	
Altima sedan \ L31 \ 2001	Nats immu	x	x		
Altima sedan \ L31 \ 2001	Smart entrance	x	x		
Altima sedan \ L31 \ 2001	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2001	Rearview camera			x	
Altima sedan \ L31 \ 2001	S/blind camera			x	
Altima sedan \ L31 \ 2001	Motor assist	x	x	x	
Altima sedan \ L31 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2002	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2002	BCM	x	x		
Altima sedan \ L31 \ 2002	Air bag	x	x	x	
Altima sedan \ L31 \ 2002	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2002	HVAC	x	x	x	

Altima sedan \ L31 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2002	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2002	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2002	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2002	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L31 \ 2002	DIU	x	x	x	
Altima sedan \ L31 \ 2002	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2002	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2002	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2002	Sonar	x	x	x	
Altima sedan \ L31 \ 2002	Lane camera	x	x	x	
Altima sedan \ L31 \ 2002	Adaptive light	x	x	x	
Altima sedan \ L31 \ 2002	AVM		x	x	
Altima sedan \ L31 \ 2002	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2002	Difference lock	x	x	x	
Altima sedan \ L31 \ 2002	Nats immu	x	x		
Altima sedan \ L31 \ 2002	Smart entrance	x	x		
Altima sedan \ L31 \ 2002	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2002	Rearview camera			x	
Altima sedan \ L31 \ 2002	S/blind camera			x	
Altima sedan \ L31 \ 2002	Motor assist	x	x	x	
Altima sedan \ L31 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2003	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2003	BCM	x	x		
Altima sedan \ L31 \ 2003	Air bag	x	x	x	
Altima sedan \ L31 \ 2003	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2003	HVAC	x	x	x	
Altima sedan \ L31 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2003	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2003	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2003	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2003	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Altima sedan \ L31 \ 2003	DIU	x	x	x	
Altima sedan \ L31 \ 2003	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2003	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2003	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2003	Sonar	x	x	x	
Altima sedan \ L31 \ 2003	Lane camera	x	x	x	
Altima sedan \ L31 \ 2003	Adaptive light	x	x	x	
Altima sedan \ L31 \ 2003	AVM		x	x	
Altima sedan \ L31 \ 2003	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2003	Difference lock	x	x	x	
Altima sedan \ L31 \ 2003	Nats immu	x	x		
Altima sedan \ L31 \ 2003	Smart entrance	x	x		
Altima sedan \ L31 \ 2003	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2003	Rearview camera			x	
Altima sedan \ L31 \ 2003	S/blind camera			x	
Altima sedan \ L31 \ 2003	Motor assist	x	x	x	
Altima sedan \ L31 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2004	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2004	BCM	x	x		
Altima sedan \ L31 \ 2004	Air bag	x	x	x	
Altima sedan \ L31 \ 2004	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2004	HVAC	x	x	x	
Altima sedan \ L31 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2004	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2004	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2004	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2004	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L31 \ 2004	DIU	x	x	x	
Altima sedan \ L31 \ 2004	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2004	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2004	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2004	Sonar	x	x	x	
Altima sedan \ L31 \ 2004	Lane camera	x	x	x	
Altima sedan \ L31 \ 2004	Adaptive light	x	x	x	

Altima sedan \ L31 \ 2004	AVM		x	x	
Altima sedan \ L31 \ 2004	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2004	Difference lock	x	x	x	
Altima sedan \ L31 \ 2004	Nats immu	x	x		
Altima sedan \ L31 \ 2004	Smart entrance	x	x		
Altima sedan \ L31 \ 2004	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2004	Rearview camera			x	
Altima sedan \ L31 \ 2004	S/blind camera			x	
Altima sedan \ L31 \ 2004	Motor assist	x	x	x	
Altima sedan \ L31 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2005	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2005	BCM	x	x		
Altima sedan \ L31 \ 2005	Air bag	x	x	x	
Altima sedan \ L31 \ 2005	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2005	HVAC	x	x	x	
Altima sedan \ L31 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2005	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2005	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2005	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2005	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L31 \ 2005	DIU	x	x	x	
Altima sedan \ L31 \ 2005	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2005	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2005	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2005	Sonar	x	x	x	
Altima sedan \ L31 \ 2005	Lane camera	x	x	x	
Altima sedan \ L31 \ 2005	Adaptive light	x	x	x	
Altima sedan \ L31 \ 2005	AVM		x	x	
Altima sedan \ L31 \ 2005	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2005	Difference lock	x	x	x	
Altima sedan \ L31 \ 2005	Nats immu	x	x		
Altima sedan \ L31 \ 2005	Smart entrance	x	x		
Altima sedan \ L31 \ 2005	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2005	Rearview camera			x	
Altima sedan \ L31 \ 2005	S/blind camera			x	

Altima sedan \ L31 \ 2005	Motor assist	x	x	x	
Altima sedan \ L31 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L31 \ 2006	ABS	x	x	x	0003, 0092, 0264
Altima sedan \ L31 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima sedan \ L31 \ 2006	BCM	x	x		
Altima sedan \ L31 \ 2006	Air bag	x	x	x	
Altima sedan \ L31 \ 2006	ICC/ADAS	x	x	x	
Altima sedan \ L31 \ 2006	HVAC	x	x	x	
Altima sedan \ L31 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima sedan \ L31 \ 2006	Multi AV	x	x	x	0280
Altima sedan \ L31 \ 2006	EPS/DAST 3	x	x	x	
Altima sedan \ L31 \ 2006	IPDM E/R	x	x	x	
Altima sedan \ L31 \ 2006	Air pressure monitor	x	x	x	
Altima sedan \ L31 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima sedan \ L31 \ 2006	DIU	x	x	x	
Altima sedan \ L31 \ 2006	Auto slide door	x	x	x	
Altima sedan \ L31 \ 2006	Auto drive position	x	x	x	
Altima sedan \ L31 \ 2006	All mode AWD/4WD	x	x	x	
Altima sedan \ L31 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima sedan \ L31 \ 2006	Sonar	x	x	x	
Altima sedan \ L31 \ 2006	Lane camera	x	x	x	
Altima sedan \ L31 \ 2006	Adaptive light	x	x	x	
Altima sedan \ L31 \ 2006	AVM		x	x	
Altima sedan \ L31 \ 2006	Head lamp levelizer	x	x	x	
Altima sedan \ L31 \ 2006	Difference lock	x	x	x	
Altima sedan \ L31 \ 2006	Nats immu	x	x		
Altima sedan \ L31 \ 2006	Smart entrance	x	x		
Altima sedan \ L31 \ 2006	Air levelizer	x	x	x	
Altima sedan \ L31 \ 2006	Rearview camera			x	
Altima sedan \ L31 \ 2006	S/blind camera			x	
Altima sedan \ L31 \ 2006	Motor assist	x	x	x	
Altima sedan \ L32 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L32 \ 2007	Meter/M&A		x	x	
Altima sedan \ L32 \ 2007	BCM		x		
Altima sedan \ L32 \ 2007	Air bag	x	x	x	
Altima sedan \ L32 \ 2007	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2007	Transmission	x	x	x	

Altima sedan \ L32 \ 2007	Multi AV	x	x	x	
Altima sedan \ L32 \ 2007	IPDM E/R		x	x	
Altima sedan \ L32 \ 2007	ABS	x	x	x	
Altima sedan \ L32 \ 2007	Rearview camera			x	
Altima sedan \ L32 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L32 \ 2008	Meter/M&A		x	x	
Altima sedan \ L32 \ 2008	BCM		x		
Altima sedan \ L32 \ 2008	Air bag	x	x	x	
Altima sedan \ L32 \ 2008	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2008	Transmission	x	x	x	
Altima sedan \ L32 \ 2008	Multi AV	x	x	x	
Altima sedan \ L32 \ 2008	IPDM E/R		x	x	
Altima sedan \ L32 \ 2008	ABS	x	x	x	
Altima sedan \ L32 \ 2008	Rearview camera			x	
Altima sedan \ L32 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L32 \ 2009	Meter/M&A		x	x	
Altima sedan \ L32 \ 2009	BCM		x		
Altima sedan \ L32 \ 2009	Air bag	x	x	x	
Altima sedan \ L32 \ 2009	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2009	Transmission	x	x	x	
Altima sedan \ L32 \ 2009	Multi AV	x	x	x	0280
Altima sedan \ L32 \ 2009	IPDM E/R		x	x	
Altima sedan \ L32 \ 2009	ABS	x	x	x	
Altima sedan \ L32 \ 2009	Sonar	x	x	x	
Altima sedan \ L32 \ 2009	Rearview camera			x	
Altima sedan \ L32 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L32 \ 2010	Meter/M&A		x	x	
Altima sedan \ L32 \ 2010	BCM		x		
Altima sedan \ L32 \ 2010	Air bag	x	x	x	
Altima sedan \ L32 \ 2010	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2010	Transmission	x	x	x	
Altima sedan \ L32 \ 2010	Multi AV	x	x	x	0280
Altima sedan \ L32 \ 2010	IPDM E/R		x	x	
Altima sedan \ L32 \ 2010	ABS	x	x	x	
Altima sedan \ L32 \ 2010	Sonar	x	x	x	
Altima sedan \ L32 \ 2010	Rearview camera			x	
Altima sedan \ L32 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Altima sedan \ L32 \ 2011	Meter/M&A		x	x	
Altima sedan \ L32 \ 2011	BCM		x		
Altima sedan \ L32 \ 2011	Air bag	x	x	x	
Altima sedan \ L32 \ 2011	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2011	Transmission	x	x	x	
Altima sedan \ L32 \ 2011	Multi AV	x	x	x	0280
Altima sedan \ L32 \ 2011	IPDM E/R		x	x	
Altima sedan \ L32 \ 2011	ABS	x	x	x	
Altima sedan \ L32 \ 2011	Sonar	x	x	x	
Altima sedan \ L32 \ 2011	Rearview camera			x	
Altima sedan \ L32 \ 2011	S/blind camera			x	
Altima sedan \ L32 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L32 \ 2012	Meter/M&A		x	x	
Altima sedan \ L32 \ 2012	BCM		x		
Altima sedan \ L32 \ 2012	Air bag	x	x	x	
Altima sedan \ L32 \ 2012	HVAC		x	x	0048, 0140, 0229, 0297
Altima sedan \ L32 \ 2012	Transmission	x	x	x	
Altima sedan \ L32 \ 2012	Multi AV		x	x	
Altima sedan \ L32 \ 2012	IPDM E/R		x	x	
Altima sedan \ L32 \ 2012	Auto drive position	x	x	x	
Altima sedan \ L32 \ 2012	ABS	x	x	x	
Altima sedan \ L33 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L33 \ 2013	ABS	x	x	x	
Altima sedan \ L33 \ 2013	Meter/M&A		x	x	
Altima sedan \ L33 \ 2013	BCM		x		
Altima sedan \ L33 \ 2013	Air bag		x	x	
Altima sedan \ L33 \ 2013	HVAC		x	x	
Altima sedan \ L33 \ 2013	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima sedan \ L33 \ 2013	Multi AV		x	x	
Altima sedan \ L33 \ 2013	EPS/DAST 3		x	x	
Altima sedan \ L33 \ 2013	IPDM E/R		x	x	
Altima sedan \ L33 \ 2013	Auto drive position		x	x	
Altima sedan \ L33 \ 2013	Sonar		x	x	
Altima sedan \ L33 \ 2013	Lane camera		x	x	
Altima sedan \ L33 \ 2013	Side radar left		x	x	
Altima sedan \ L33 \ 2013	Side radar right		x	x	
Altima sedan \ L33 \ 2013	AVM		x	x	
Altima sedan \ L33 \ 2013	Occupant detection			x	

Altima sedan \ L33 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L33 \ 2014	ABS		x	x	
Altima sedan \ L33 \ 2014	Meter/M&A		x	x	
Altima sedan \ L33 \ 2014	BCM		x		
Altima sedan \ L33 \ 2014	Air bag		x	x	
Altima sedan \ L33 \ 2014	HVAC		x	x	
Altima sedan \ L33 \ 2014	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima sedan \ L33 \ 2014	Multi AV	x	x	x	0280
Altima sedan \ L33 \ 2014	EPS/DAST 3		x	x	
Altima sedan \ L33 \ 2014	IPDM E/R		x	x	
Altima sedan \ L33 \ 2014	Auto drive position		x	x	
Altima sedan \ L33 \ 2014	Sonar		x	x	
Altima sedan \ L33 \ 2014	AVM		x	x	
Altima sedan \ L33 \ 2014	Head lamp levelizer	x	x	x	
Altima sedan \ L33 \ 2014	Occupant detection			x	
Altima sedan \ L33 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L33 \ 2015	ABS	x	x	x	
Altima sedan \ L33 \ 2015	Meter/M&A		x	x	
Altima sedan \ L33 \ 2015	BCM		x		
Altima sedan \ L33 \ 2015	Air bag		x	x	
Altima sedan \ L33 \ 2015	HVAC		x	x	
Altima sedan \ L33 \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima sedan \ L33 \ 2015	Multi AV	x	x	x	0280
Altima sedan \ L33 \ 2015	EPS/DAST 3		x	x	
Altima sedan \ L33 \ 2015	IPDM E/R		x	x	
Altima sedan \ L33 \ 2015	Air pressure monitor		x	x	
Altima sedan \ L33 \ 2015	Auto drive position		x	x	
Altima sedan \ L33 \ 2015	Sonar		x	x	
Altima sedan \ L33 \ 2015	Side radar left		x	x	
Altima sedan \ L33 \ 2015	Side radar right		x	x	
Altima sedan \ L33 \ 2015	AVM		x	x	
Altima sedan \ L33 \ 2015	Head lamp levelizer	x	x	x	
Altima sedan \ L33 \ 2015	Occupant detection			x	
Altima sedan \ L33 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima sedan \ L33 \ 2016	ABS		x	x	
Altima sedan \ L33 \ 2016	Meter/M&A		x	x	

Altima sedan \ L33 \ 2016	BCM		x		
Altima sedan \ L33 \ 2016	Air bag		x	x	
Altima sedan \ L33 \ 2016	ICC/ADAS	x	x	x	
Altima sedan \ L33 \ 2016	HVAC		x	x	
Altima sedan \ L33 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima sedan \ L33 \ 2016	Multi AV	x	x	x	0280
Altima sedan \ L33 \ 2016	EPS/DAST 3		x	x	
Altima sedan \ L33 \ 2016	IPDM E/R		x	x	
Altima sedan \ L33 \ 2016	Air pressure monitor		x	x	
Altima sedan \ L33 \ 2016	Laser/radar		x	x	
Altima sedan \ L33 \ 2016	Auto drive position		x	x	
Altima sedan \ L33 \ 2016	Sonar		x	x	
Altima sedan \ L33 \ 2016	Side radar left		x	x	
Altima sedan \ L33 \ 2016	Side radar right		x	x	
Altima sedan \ L33 \ 2016	Telematics		x	x	0253
Altima sedan \ L33 \ 2016	AVM		x	x	
Altima sedan \ L33 \ 2016	Head lamp levelizer	x	x	x	
Altima sedan \ L33 \ 2016	Occupant detection			x	
Altima \ L30 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L30 \ All Year	ABS	x	x	x	0003, 0092, 0264
Altima \ L30 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima \ L30 \ All Year	BCM	x	x		
Altima \ L30 \ All Year	Air bag	x	x	x	
Altima \ L30 \ All Year	ICC/ADAS	x	x	x	
Altima \ L30 \ All Year	HVAC	x	x	x	
Altima \ L30 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima \ L30 \ All Year	Multi AV	x	x	x	0280
Altima \ L30 \ All Year	EPS/DAST 3	x	x	x	
Altima \ L30 \ All Year	IPDM E/R	x	x	x	
Altima \ L30 \ All Year	Air pressure monitor	x	x	x	
Altima \ L30 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima \ L30 \ All Year	DIU	x	x	x	
Altima \ L30 \ All Year	Auto slide door	x	x	x	
Altima \ L30 \ All Year	Auto drive position	x	x	x	
Altima \ L30 \ All Year	All mode AWD/4WD	x	x	x	
Altima \ L30 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima \ L30 \ All Year	Sonar	x	x	x	

Altima \ L30 \ All Year	Lane camera	x	x	x	
Altima \ L30 \ All Year	Adaptive light	x	x	x	
Altima \ L30 \ All Year	AVM		x	x	
Altima \ L30 \ All Year	Head lamp levelizer	x	x	x	
Altima \ L30 \ All Year	Difference lock	x	x	x	
Altima \ L30 \ All Year	Nats immu	x	x		
Altima \ L30 \ All Year	Smart entrance	x	x		
Altima \ L30 \ All Year	Air levelizer	x	x	x	
Altima \ L30 \ All Year	Rearview camera			x	
Altima \ L30 \ All Year	S/blind camera			x	
Altima \ L30 \ All Year	Motor assist	x	x	x	
Altima \ L31 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L31 \ All Year	ABS	x	x	x	0003, 0092, 0264
Altima \ L31 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Altima \ L31 \ All Year	BCM	x	x		
Altima \ L31 \ All Year	Air bag	x	x	x	
Altima \ L31 \ All Year	ICC/ADAS	x	x	x	
Altima \ L31 \ All Year	HVAC	x	x	x	
Altima \ L31 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima \ L31 \ All Year	Multi AV	x	x	x	0280
Altima \ L31 \ All Year	EPS/DAST 3	x	x	x	
Altima \ L31 \ All Year	IPDM E/R	x	x	x	
Altima \ L31 \ All Year	Air pressure monitor	x	x	x	
Altima \ L31 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Altima \ L31 \ All Year	DIU	x	x	x	
Altima \ L31 \ All Year	Auto slide door	x	x	x	
Altima \ L31 \ All Year	Auto drive position	x	x	x	
Altima \ L31 \ All Year	All mode AWD/4WD	x	x	x	
Altima \ L31 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima \ L31 \ All Year	Sonar	x	x	x	
Altima \ L31 \ All Year	Lane camera	x	x	x	
Altima \ L31 \ All Year	Adaptive light	x	x	x	
Altima \ L31 \ All Year	AVM		x	x	
Altima \ L31 \ All Year	Head lamp levelizer	x	x	x	
Altima \ L31 \ All Year	Difference lock	x	x	x	
Altima \ L31 \ All Year	Nats immu	x	x		
Altima \ L31 \ All Year	Smart entrance	x	x		
Altima \ L31 \ All Year	Air levelizer	x	x	x	

Altima \ L31 \ All Year	Rearview camera			x	
Altima \ L31 \ All Year	S/blind camera			x	
Altima \ L31 \ All Year	Motor assist	x	x	x	
Altima \ L32 \ 2006-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2006-10~	Meter/M&A		x	x	
Altima \ L32 \ 2006-10~	BCM		x		
Altima \ L32 \ 2006-10~	Air bag	x	x	x	
Altima \ L32 \ 2006-10~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2006-10~	Transmission	x	x	x	
Altima \ L32 \ 2006-10~	Multi AV	x	x	x	
Altima \ L32 \ 2006-10~	IPDM E/R		x	x	
Altima \ L32 \ 2006-10~	ABS	x	x	x	
Altima \ L32 \ 2006-10~	Rearview camera			x	
Altima \ L32 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2007-7~	Meter/M&A		x	x	
Altima \ L32 \ 2007-7~	BCM		x		
Altima \ L32 \ 2007-7~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2007-7~	Transmission	x	x	x	
Altima \ L32 \ 2007-7~	IPDM E/R		x	x	
Altima \ L32 \ 2007-7~	ABS	x	x	x	
Altima \ L32 \ 2007-7~	Air bag	x	x	x	
Altima \ L32 \ 2007-7~	Rearview camera			x	
Altima \ L32 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2008-12~	Meter/M&A		x	x	
Altima \ L32 \ 2008-12~	BCM		x		
Altima \ L32 \ 2008-12~	Air bag	x	x	x	
Altima \ L32 \ 2008-12~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2008-12~	Transmission	x	x	x	
Altima \ L32 \ 2008-12~	IPDM E/R		x	x	
Altima \ L32 \ 2008-12~	ABS	x	x	x	
Altima \ L32 \ 2008-12~	Sonar	x	x	x	
Altima \ L32 \ 2008-12~	Rearview camera			x	
Altima \ L32 \ 2008-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2008-7~	Meter/M&A		x	x	
Altima \ L32 \ 2008-7~	BCM		x		
Altima \ L32 \ 2008-7~	Air bag	x	x	x	
Altima \ L32 \ 2008-7~	HVAC		x	x	0048, 0140, 0229, 0297

Altima \ L32 \ 2008-7~	Transmission	x	x	x	
Altima \ L32 \ 2008-7~	Multi AV	x	x	x	0280
Altima \ L32 \ 2008-7~	IPDM E/R		x	x	
Altima \ L32 \ 2008-7~	ABS	x	x	x	
Altima \ L32 \ 2008-7~	Sonar	x	x	x	
Altima \ L32 \ 2008-7~	Rearview camera			x	
Altima \ L32 \ 2008-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2008-8~	Meter/M&A		x	x	
Altima \ L32 \ 2008-8~	BCM		x		
Altima \ L32 \ 2008-8~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2008-8~	Transmission	x	x	x	
Altima \ L32 \ 2008-8~	IPDM E/R		x	x	
Altima \ L32 \ 2008-8~	ABS	x	x	x	
Altima \ L32 \ 2008-8~	Air bag	x	x	x	
Altima \ L32 \ 2008-8~	Sonar	x	x	x	
Altima \ L32 \ 2008-8~	Rearview camera			x	
Altima \ L32 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2009-10~	ABS	x	x	x	
Altima \ L32 \ 2009-10~	Meter/M&A		x	x	
Altima \ L32 \ 2009-10~	BCM		x		
Altima \ L32 \ 2009-10~	Air bag	x	x	x	
Altima \ L32 \ 2009-10~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2009-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima \ L32 \ 2009-10~	Multi AV	x	x	x	0280
Altima \ L32 \ 2009-10~	EPS/DAST 3		x	x	
Altima \ L32 \ 2009-10~	IPDM E/R		x	x	
Altima \ L32 \ 2009-10~	EV/HEV		x	x	
Altima \ L32 \ 2009-10~	Head lamp levelizer	x	x	x	
Altima \ L32 \ 2009-10~	Sonar	x	x	x	
Altima \ L32 \ 2009-10~	Rearview camera			x	
Altima \ L32 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2010-9~	ABS	x	x	x	
Altima \ L32 \ 2010-9~	Meter/M&A		x	x	
Altima \ L32 \ 2010-9~	BCM		x		
Altima \ L32 \ 2010-9~	Air bag	x	x	x	
Altima \ L32 \ 2010-9~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2010-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Altima \ L32 \ 2010-9~	Multi AV	x	x	x	0280

Altima \ L32 \ 2010-9~	EPS/DAST 3		x	x	
Altima \ L32 \ 2010-9~	IPDM E/R		x	x	
Altima \ L32 \ 2010-9~	EV/HEV		x	x	
Altima \ L32 \ 2010-9~	Head lamp levelizer	x	x	x	
Altima \ L32 \ 2010-9~	Sonar	x	x	x	
Altima \ L32 \ 2010-9~	Rearview camera			x	
Altima \ L32 \ 2010-9~	S/blind camera			x	
Altima \ L32 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L32 \ 2011-8~	Meter/M&A		x	x	
Altima \ L32 \ 2011-8~	BCM		x		
Altima \ L32 \ 2011-8~	Air bag	x	x	x	
Altima \ L32 \ 2011-8~	HVAC		x	x	0048, 0140, 0229, 0297
Altima \ L32 \ 2011-8~	Transmission	x	x	x	
Altima \ L32 \ 2011-8~	IPDM E/R		x	x	
Altima \ L32 \ 2011-8~	ABS	x	x	x	
Altima \ L32 \ 2011-8~	Head lamp levelizer	x	x	x	
Altima \ L32 \ 2011-8~	Multi AV		x	x	
Altima \ L33 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2012-6~	ABS		x	x	
Altima \ L33 \ 2012-6~	Meter/M&A		x	x	
Altima \ L33 \ 2012-6~	BCM		x		
Altima \ L33 \ 2012-6~	Air bag		x	x	
Altima \ L33 \ 2012-6~	HVAC		x	x	
Altima \ L33 \ 2012-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2012-6~	Multi AV		x	x	
Altima \ L33 \ 2012-6~	EPS/DAST 3		x	x	
Altima \ L33 \ 2012-6~	IPDM E/R		x	x	
Altima \ L33 \ 2012-6~	Auto drive position		x	x	
Altima \ L33 \ 2012-6~	AVM		x	x	
Altima \ L33 \ 2012-6~	Occupant detection			x	
Altima \ L33 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2012-7~	ABS		x	x	
Altima \ L33 \ 2012-7~	Meter/M&A		x	x	
Altima \ L33 \ 2012-7~	BCM		x		
Altima \ L33 \ 2012-7~	Air bag		x	x	
Altima \ L33 \ 2012-7~	HVAC		x	x	

Altima \ L33 \ 2012-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2012-7~	Multi AV		x	x	
Altima \ L33 \ 2012-7~	EPS/DAST 3		x	x	
Altima \ L33 \ 2012-7~	IPDM E/R		x	x	
Altima \ L33 \ 2012-7~	Auto drive position		x	x	
Altima \ L33 \ 2012-7~	Sonar		x	x	
Altima \ L33 \ 2012-7~	AVM		x	x	
Altima \ L33 \ 2012-7~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2012-7~	Occupant detection			x	
Altima \ L33 \ 2012-7~	SVT	x	x	x	
Altima \ L33 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2012-8~	ABS		x	x	
Altima \ L33 \ 2012-8~	Meter/M&A		x	x	
Altima \ L33 \ 2012-8~	BCM		x		
Altima \ L33 \ 2012-8~	Air bag		x	x	
Altima \ L33 \ 2012-8~	HVAC		x	x	
Altima \ L33 \ 2012-8~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2012-8~	Multi AV		x	x	
Altima \ L33 \ 2012-8~	EPS/DAST 3		x	x	
Altima \ L33 \ 2012-8~	IPDM E/R		x	x	
Altima \ L33 \ 2012-8~	Auto drive position		x	x	
Altima \ L33 \ 2012-8~	Sonar		x	x	
Altima \ L33 \ 2012-8~	AVM		x	x	
Altima \ L33 \ 2012-8~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2012-8~	Occupant detection			x	
Altima \ L33 \ 2012-8~	SVT	x	x	x	
Altima \ L33 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2013-10~	ABS		x	x	
Altima \ L33 \ 2013-10~	Meter/M&A		x	x	
Altima \ L33 \ 2013-10~	BCM		x		
Altima \ L33 \ 2013-10~	Air bag		x	x	
Altima \ L33 \ 2013-10~	HVAC		x	x	
Altima \ L33 \ 2013-10~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2013-10~	Multi AV	x	x	x	0280
Altima \ L33 \ 2013-10~	EPS/DAST 3		x	x	
Altima \ L33 \ 2013-10~	IPDM E/R		x	x	

Altima \ L33 \ 2013-10~	Auto drive position		x	x	
Altima \ L33 \ 2013-10~	Sonar		x	x	
Altima \ L33 \ 2013-10~	AVM		x	x	
Altima \ L33 \ 2013-10~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2013-10~	Occupant detection			x	
Altima \ L33 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2013-11~	ABS		x	x	
Altima \ L33 \ 2013-11~	Meter/M&A		x	x	
Altima \ L33 \ 2013-11~	BCM		x		
Altima \ L33 \ 2013-11~	Air bag		x	x	
Altima \ L33 \ 2013-11~	HVAC		x	x	
Altima \ L33 \ 2013-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2013-11~	Multi AV	x	x	x	0280
Altima \ L33 \ 2013-11~	EPS/DAST 3		x	x	
Altima \ L33 \ 2013-11~	IPDM E/R		x	x	
Altima \ L33 \ 2013-11~	Auto drive position		x	x	
Altima \ L33 \ 2013-11~	Sonar		x	x	
Altima \ L33 \ 2013-11~	AVM		x	x	
Altima \ L33 \ 2013-11~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2013-11~	Occupant detection			x	
Altima \ L33 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2013-12~	ABS		x	x	
Altima \ L33 \ 2013-12~	Meter/M&A		x	x	
Altima \ L33 \ 2013-12~	BCM		x		
Altima \ L33 \ 2013-12~	Air bag		x	x	
Altima \ L33 \ 2013-12~	HVAC		x	x	
Altima \ L33 \ 2013-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2013-12~	Multi AV	x	x	x	0280
Altima \ L33 \ 2013-12~	EPS/DAST 3		x	x	
Altima \ L33 \ 2013-12~	IPDM E/R		x	x	
Altima \ L33 \ 2013-12~	Auto drive position		x	x	
Altima \ L33 \ 2013-12~	Sonar		x	x	
Altima \ L33 \ 2013-12~	AVM		x	x	
Altima \ L33 \ 2013-12~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2013-12~	Occupant detection			x	
Altima \ L33 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Altima \ L33 \ 2013-4~	ABS		x	x	
Altima \ L33 \ 2013-4~	Meter/M&A		x	x	
Altima \ L33 \ 2013-4~	BCM		x		
Altima \ L33 \ 2013-4~	Air bag		x	x	
Altima \ L33 \ 2013-4~	HVAC		x	x	
Altima \ L33 \ 2013-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2013-4~	Multi AV		x	x	
Altima \ L33 \ 2013-4~	EPS/DAST 3		x	x	
Altima \ L33 \ 2013-4~	IPDM E/R		x	x	
Altima \ L33 \ 2013-4~	Auto drive position		x	x	
Altima \ L33 \ 2013-4~	Sonar		x	x	
Altima \ L33 \ 2013-4~	AVM		x	x	
Altima \ L33 \ 2013-4~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2013-4~	Occupant detection			x	
Altima \ L33 \ 2013-4~	SVT	x	x	x	
Altima \ L33 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2013-7~	ABS		x	x	
Altima \ L33 \ 2013-7~	Meter/M&A		x	x	
Altima \ L33 \ 2013-7~	BCM		x		
Altima \ L33 \ 2013-7~	Air bag		x	x	
Altima \ L33 \ 2013-7~	HVAC		x	x	
Altima \ L33 \ 2013-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2013-7~	Multi AV	x	x	x	0280
Altima \ L33 \ 2013-7~	EPS/DAST 3		x	x	
Altima \ L33 \ 2013-7~	IPDM E/R		x	x	
Altima \ L33 \ 2013-7~	Auto drive position		x	x	
Altima \ L33 \ 2013-7~	Sonar		x	x	
Altima \ L33 \ 2013-7~	AVM		x	x	
Altima \ L33 \ 2013-7~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2013-7~	Occupant detection			x	
Altima \ L33 \ 2013-7~	SVT	x	x	x	
Altima \ L33 \ 2013-7~	Multi AV		x	x	
Altima \ L33 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2014-5~	ABS	x	x	x	
Altima \ L33 \ 2014-5~	Meter/M&A		x	x	
Altima \ L33 \ 2014-5~	BCM		x		
Altima \ L33 \ 2014-5~	Air bag		x	x	

Altima \ L33 \ 2014-5~	ICC/ADAS		x	x	
Altima \ L33 \ 2014-5~	HVAC		x	x	
Altima \ L33 \ 2014-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2014-5~	Multi AV	x	x	x	0280
Altima \ L33 \ 2014-5~	EPS/DAST 3		x	x	
Altima \ L33 \ 2014-5~	IPDM E/R		x	x	
Altima \ L33 \ 2014-5~	Air pressure monitor		x	x	
Altima \ L33 \ 2014-5~	Auto drive position		x	x	
Altima \ L33 \ 2014-5~	Sonar		x	x	
Altima \ L33 \ 2014-5~	Lane camera		x	x	
Altima \ L33 \ 2014-5~	Side radar left		x	x	
Altima \ L33 \ 2014-5~	Side radar right		x	x	
Altima \ L33 \ 2014-5~	Telematics		x	x	0253
Altima \ L33 \ 2014-5~	AVM		x	x	
Altima \ L33 \ 2014-5~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2014-5~	Occupant detection			x	
Altima \ L33 \ 2014-5~	SVT	x	x	x	
Altima \ L33 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2014-6~	ABS	x	x	x	
Altima \ L33 \ 2014-6~	Meter/M&A		x	x	
Altima \ L33 \ 2014-6~	BCM		x		
Altima \ L33 \ 2014-6~	Air bag		x	x	
Altima \ L33 \ 2014-6~	ICC/ADAS		x	x	
Altima \ L33 \ 2014-6~	HVAC		x	x	
Altima \ L33 \ 2014-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2014-6~	Multi AV	x	x	x	0280
Altima \ L33 \ 2014-6~	EPS/DAST 3		x	x	
Altima \ L33 \ 2014-6~	IPDM E/R		x	x	
Altima \ L33 \ 2014-6~	Air pressure monitor		x	x	
Altima \ L33 \ 2014-6~	Auto drive position		x	x	
Altima \ L33 \ 2014-6~	Sonar		x	x	
Altima \ L33 \ 2014-6~	Lane camera		x	x	
Altima \ L33 \ 2014-6~	Side radar left		x	x	
Altima \ L33 \ 2014-6~	Side radar right		x	x	
Altima \ L33 \ 2014-6~	Telematics		x	x	0253
Altima \ L33 \ 2014-6~	AVM		x	x	
Altima \ L33 \ 2014-6~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2014-6~	Occupant detection			x	

Altima \ L33 \ 2014-6~	SVT	x	x	x	
Altima \ L33 \ 2014-6~	ABS		x	x	
Altima \ L33 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2015-11~	ABS		x	x	
Altima \ L33 \ 2015-11~	Meter/M&A		x	x	
Altima \ L33 \ 2015-11~	BCM		x		
Altima \ L33 \ 2015-11~	Air bag		x	x	
Altima \ L33 \ 2015-11~	ICC/ADAS		x	x	
Altima \ L33 \ 2015-11~	HVAC		x	x	
Altima \ L33 \ 2015-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2015-11~	Multi AV	x	x	x	0280
Altima \ L33 \ 2015-11~	EPS/DAST 3		x	x	
Altima \ L33 \ 2015-11~	IPDM E/R		x	x	
Altima \ L33 \ 2015-11~	Air pressure monitor		x	x	
Altima \ L33 \ 2015-11~	Laser/radar		x	x	
Altima \ L33 \ 2015-11~	Auto drive position		x	x	
Altima \ L33 \ 2015-11~	Sonar		x	x	
Altima \ L33 \ 2015-11~	Side radar left		x	x	
Altima \ L33 \ 2015-11~	Side radar right		x	x	
Altima \ L33 \ 2015-11~	AVM		x	x	
Altima \ L33 \ 2015-11~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2015-11~	Occupant detection			x	
Altima \ L33 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2016-2~	ABS		x	x	
Altima \ L33 \ 2016-2~	Meter/M&A		x	x	
Altima \ L33 \ 2016-2~	BCM		x		
Altima \ L33 \ 2016-2~	Air bag		x	x	
Altima \ L33 \ 2016-2~	ICC/ADAS	x	x	x	
Altima \ L33 \ 2016-2~	HVAC		x	x	
Altima \ L33 \ 2016-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2016-2~	Multi AV	x	x	x	0280
Altima \ L33 \ 2016-2~	EPS/DAST 3		x	x	
Altima \ L33 \ 2016-2~	IPDM E/R		x	x	
Altima \ L33 \ 2016-2~	Air pressure monitor		x	x	
Altima \ L33 \ 2016-2~	Laser/radar		x	x	
Altima \ L33 \ 2016-2~	Auto drive position		x	x	
Altima \ L33 \ 2016-2~	Sonar		x	x	

Altima \ L33 \ 2016-2~	Side radar left		x	x	
Altima \ L33 \ 2016-2~	Side radar right		x	x	
Altima \ L33 \ 2016-2~	AVM		x	x	
Altima \ L33 \ 2016-2~	Chassis control		x	x	
Altima \ L33 \ 2016-2~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2016-2~	Occupant detection			x	
Altima \ L33 \ 2016-2~	Multi AV		x	x	
Altima \ L33 \ 2016-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Altima \ L33 \ 2016-9~	ABS		x	x	
Altima \ L33 \ 2016-9~	Meter/M&A		x	x	
Altima \ L33 \ 2016-9~	BCM		x		
Altima \ L33 \ 2016-9~	Air bag		x	x	
Altima \ L33 \ 2016-9~	ICC/ADAS	x	x	x	
Altima \ L33 \ 2016-9~	HVAC		x	x	
Altima \ L33 \ 2016-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Altima \ L33 \ 2016-9~	Multi AV	x	x	x	0280
Altima \ L33 \ 2016-9~	EPS/DAST 3		x	x	
Altima \ L33 \ 2016-9~	IPDM E/R		x	x	
Altima \ L33 \ 2016-9~	Air pressure monitor		x	x	
Altima \ L33 \ 2016-9~	Laser/radar		x	x	
Altima \ L33 \ 2016-9~	Auto drive position		x	x	
Altima \ L33 \ 2016-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Altima \ L33 \ 2016-9~	Sonar	x	x	x	
Altima \ L33 \ 2016-9~	4WAS(front)	x	x	x	
Altima \ L33 \ 2016-9~	Accele pedal ACT		x	x	
Altima \ L33 \ 2016-9~	Side radar left		x	x	
Altima \ L33 \ 2016-9~	Side radar right		x	x	
Altima \ L33 \ 2016-9~	Head lamp levelizer	x	x	x	
Altima \ L33 \ 2016-9~	Occupant detection			x	
ALTIMA-TEANA \ L33 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ALTIMA-TEANA \ L33 \ 2013-7~	ABS		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Meter/M&A		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	BCM		x		
ALTIMA-TEANA \ L33 \ 2013-7~	Air bag		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	HVAC		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
ALTIMA-TEANA \ L33 \ 2013-7~	Multi AV	x	x	x	0280

ALTIMA-TEANA \ L33 \ 2013-7~	EPS/DAST 3		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	IPDM E/R		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Auto drive position		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Sonar		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	AVM		x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Head lamp levelizer	x	x	x	
ALTIMA-TEANA \ L33 \ 2013-7~	Occupant detection			x	
ALTIMA-TEANA \ L33 \ 2013-7~	SVT	x	x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ALTIMA-TEANA \ L33 \ 2014-6~	ABS	x	x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Meter/M&A		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	BCM		x		
ALTIMA-TEANA \ L33 \ 2014-6~	Air bag		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	ICC/ADAS		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	HVAC		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
ALTIMA-TEANA \ L33 \ 2014-6~	Multi AV	x	x	x	0280
ALTIMA-TEANA \ L33 \ 2014-6~	EPS/DAST 3		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	IPDM E/R		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Air pressure monitor		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Auto drive position		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Sonar		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Lane camera		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Side radar left		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Side radar right		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Telematics		x	x	0253
ALTIMA-TEANA \ L33 \ 2014-6~	AVM		x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Head lamp levelizer	x	x	x	
ALTIMA-TEANA \ L33 \ 2014-6~	Occupant detection			x	
ALTIMA-TEANA \ L33 \ 2014-6~	SVT	x	x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ALTIMA-TEANA \ L33 \ 2016-2~	ABS		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Meter/M&A		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	BCM		x		
ALTIMA-TEANA \ L33 \ 2016-2~	Air bag		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	ICC/ADAS	x	x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	HVAC		x	x	

ALTIMA-TEANA \ L33 \ 2016-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
ALTIMA-TEANA \ L33 \ 2016-2~	Multi AV	x	x	x	0280
ALTIMA-TEANA \ L33 \ 2016-2~	EPS/DAST 3		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	IPDM E/R		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Air pressure monitor		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Laser/radar		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Auto drive position		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Sonar		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Side radar left		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Side radar right		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	AVM		x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Head lamp levelizer	x	x	x	
ALTIMA-TEANA \ L33 \ 2016-2~	Occupant detection			x	
Armada \ TA60 \ 2003-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2003-8~	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2003-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2003-8~	BCM	x	x		
Armada \ TA60 \ 2003-8~	Air bag	x	x	x	
Armada \ TA60 \ 2003-8~	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2003-8~	HVAC	x	x	x	
Armada \ TA60 \ 2003-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2003-8~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2003-8~	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2003-8~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2003-8~	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2003-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2003-8~	DIU	x	x	x	
Armada \ TA60 \ 2003-8~	Auto slide door	x	x	x	
Armada \ TA60 \ 2003-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2003-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2003-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2003-8~	Sonar	x	x	x	
Armada \ TA60 \ 2003-8~	Lane camera	x	x	x	
Armada \ TA60 \ 2003-8~	Adaptive light	x	x	x	
Armada \ TA60 \ 2003-8~	AVM		x	x	
Armada \ TA60 \ 2003-8~	Head lamp levelizer	x	x	x	
Armada \ TA60 \ 2003-8~	Difference lock	x	x	x	

Armada \ TA60 \ 2003-8~	Nats immu	x	x		
Armada \ TA60 \ 2003-8~	Smart entrance	x	x		
Armada \ TA60 \ 2003-8~	Air levelizer	x	x	x	
Armada \ TA60 \ 2003-8~	Rearview camera			x	
Armada \ TA60 \ 2003-8~	S/blind camera			x	
Armada \ TA60 \ 2003-8~	Motor assist	x	x	x	
Armada \ TA60 \ 2004-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2004-10~	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2004-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2004-10~	BCM	x	x		
Armada \ TA60 \ 2004-10~	Air bag	x	x	x	
Armada \ TA60 \ 2004-10~	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2004-10~	HVAC	x	x	x	
Armada \ TA60 \ 2004-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2004-10~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2004-10~	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2004-10~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2004-10~	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2004-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2004-10~	DIU	x	x	x	
Armada \ TA60 \ 2004-10~	Auto slide door	x	x	x	
Armada \ TA60 \ 2004-10~	Auto drive position	x	x	x	
Armada \ TA60 \ 2004-10~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2004-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2004-10~	Sonar	x	x	x	
Armada \ TA60 \ 2004-10~	Lane camera	x	x	x	
Armada \ TA60 \ 2004-10~	Adaptive light	x	x	x	
Armada \ TA60 \ 2004-10~	AVM		x	x	
Armada \ TA60 \ 2004-10~	Head lamp levelizer	x	x	x	
Armada \ TA60 \ 2004-10~	Difference lock	x	x	x	
Armada \ TA60 \ 2004-10~	Nats immu	x	x		
Armada \ TA60 \ 2004-10~	Smart entrance	x	x		
Armada \ TA60 \ 2004-10~	Air levelizer	x	x	x	
Armada \ TA60 \ 2004-10~	Rearview camera			x	
Armada \ TA60 \ 2004-10~	S/blind camera			x	
Armada \ TA60 \ 2004-10~	Motor assist	x	x	x	
Armada \ TA60 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Armada \ TA60 \ 2005	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2005	BCM	x	x		
Armada \ TA60 \ 2005	Air bag	x	x	x	
Armada \ TA60 \ 2005	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2005	HVAC	x	x	x	
Armada \ TA60 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2005	Multi AV	x	x	x	0280
Armada \ TA60 \ 2005	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2005	IPDM E/R	x	x	x	
Armada \ TA60 \ 2005	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2005	DIU	x	x	x	
Armada \ TA60 \ 2005	Auto slide door	x	x	x	
Armada \ TA60 \ 2005	Auto drive position	x	x	x	
Armada \ TA60 \ 2005	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2005	Sonar	x	x	x	
Armada \ TA60 \ 2005	Lane camera	x	x	x	
Armada \ TA60 \ 2005	Adaptive light	x	x	x	
Armada \ TA60 \ 2005	AVM		x	x	
Armada \ TA60 \ 2005	Head lamp levelizer	x	x	x	
Armada \ TA60 \ 2005	Difference lock	x	x	x	
Armada \ TA60 \ 2005	Nats immu	x	x		
Armada \ TA60 \ 2005	Smart entrance	x	x		
Armada \ TA60 \ 2005	Air levelizer	x	x	x	
Armada \ TA60 \ 2005	Rearview camera			x	
Armada \ TA60 \ 2005	S/blind camera			x	
Armada \ TA60 \ 2005	Motor assist	x	x	x	
Armada \ TA60 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2006	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2006	BCM	x	x		
Armada \ TA60 \ 2006	Air bag	x	x	x	
Armada \ TA60 \ 2006	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2006	HVAC	x	x	x	
Armada \ TA60 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2006	Multi AV	x	x	x	0280

Armada \ TA60 \ 2006	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2006	IPDM E/R	x	x	x	
Armada \ TA60 \ 2006	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2006	DIU	x	x	x	
Armada \ TA60 \ 2006	Auto slide door	x	x	x	
Armada \ TA60 \ 2006	Auto drive position	x	x	x	
Armada \ TA60 \ 2006	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2006	Sonar	x	x	x	
Armada \ TA60 \ 2006	Lane camera	x	x	x	
Armada \ TA60 \ 2006	Adaptive light	x	x	x	
Armada \ TA60 \ 2006	AVM		x	x	
Armada \ TA60 \ 2006	Head lamp levelizer	x	x	x	
Armada \ TA60 \ 2006	Difference lock	x	x	x	
Armada \ TA60 \ 2006	Nats immu	x	x		
Armada \ TA60 \ 2006	Smart entrance	x	x		
Armada \ TA60 \ 2006	Air levelizer	x	x	x	
Armada \ TA60 \ 2006	Rearview camera			x	
Armada \ TA60 \ 2006	S/blind camera			x	
Armada \ TA60 \ 2006	Motor assist	x	x	x	
Armada \ TA60 \ 2006-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2006-8~	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2006-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2006-8~	BCM	x	x		
Armada \ TA60 \ 2006-8~	Air bag	x	x	x	
Armada \ TA60 \ 2006-8~	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2006-8~	HVAC	x	x	x	
Armada \ TA60 \ 2006-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2006-8~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2006-8~	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2006-8~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2006-8~	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2006-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2006-8~	DIU	x	x	x	
Armada \ TA60 \ 2006-8~	Auto slide door	x	x	x	

Armada \ TA60 \ 2006-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2006-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2006-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2006-8~	Sonar	x	x	x	
Armada \ TA60 \ 2006-8~	Lane camera	x	x	x	
Armada \ TA60 \ 2006-8~	Adaptive light	x	x	x	
Armada \ TA60 \ 2006-8~	AVM		x	x	
Armada \ TA60 \ 2006-8~	Head lamp levelizer	x	x	x	
Armada \ TA60 \ 2006-8~	Difference lock	x	x	x	
Armada \ TA60 \ 2006-8~	Nats immu	x	x		
Armada \ TA60 \ 2006-8~	Smart entrance	x	x		
Armada \ TA60 \ 2006-8~	Air levelizer	x	x	x	
Armada \ TA60 \ 2006-8~	Rearview camera			x	
Armada \ TA60 \ 2006-8~	S/blind camera			x	
Armada \ TA60 \ 2006-8~	Motor assist	x	x	x	
Armada \ TA60 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2007	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2007	BCM	x	x		
Armada \ TA60 \ 2007	Air bag	x	x	x	
Armada \ TA60 \ 2007	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2007	HVAC	x	x	x	
Armada \ TA60 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Armada \ TA60 \ 2007	Multi AV	x	x	x	0280
Armada \ TA60 \ 2007	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2007	IPDM E/R	x	x	x	
Armada \ TA60 \ 2007	Air pressure monitor	x	x	x	
Armada \ TA60 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2007	DIU	x	x	x	
Armada \ TA60 \ 2007	Auto slide door	x	x	x	
Armada \ TA60 \ 2007	Auto drive position	x	x	x	
Armada \ TA60 \ 2007	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Armada \ TA60 \ 2007	Sonar	x	x	x	
Armada \ TA60 \ 2007	Lane camera	x	x	x	
Armada \ TA60 \ 2007	Adaptive light	x	x	x	
Armada \ TA60 \ 2007	AVM		x	x	
Armada \ TA60 \ 2007	Head lamp levelizer	x	x	x	

Armada \ TA60 \ 2007	Difference lock	x	x	x	
Armada \ TA60 \ 2007	Nats immu	x	x		
Armada \ TA60 \ 2007	Smart entrance	x	x		
Armada \ TA60 \ 2007	Air levelizer	x	x	x	
Armada \ TA60 \ 2007	Rearview camera			x	
Armada \ TA60 \ 2007	S/blind camera			x	
Armada \ TA60 \ 2007	Motor assist	x	x	x	
Armada \ TA60 \ 2007-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2007-4~	BCM	x	x		
Armada \ TA60 \ 2007-4~	HVAC	x	x	x	
Armada \ TA60 \ 2007-4~	Transmission	x	x	x	
Armada \ TA60 \ 2007-4~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2007-4~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2007-4~	Auto drive position	x	x	x	
Armada \ TA60 \ 2007-4~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2007-4~	ABS	x	x	x	
Armada \ TA60 \ 2007-4~	Air bag	x	x	x	
Armada \ TA60 \ 2007-4~	Difference lock	x	x	x	
Armada \ TA60 \ 2007-4~	Sonar	x	x	x	
Armada \ TA60 \ 2007-4~	Air levelizer	x	x	x	
Armada \ TA60 \ 2007-4~	Rearview camera			x	
Armada \ TA60 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2007-7~	BCM	x	x		
Armada \ TA60 \ 2007-7~	HVAC	x	x	x	
Armada \ TA60 \ 2007-7~	Transmission	x	x	x	
Armada \ TA60 \ 2007-7~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2007-7~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2007-7~	Auto drive position	x	x	x	
Armada \ TA60 \ 2007-7~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2007-7~	ABS	x	x	x	
Armada \ TA60 \ 2007-7~	Air bag	x	x	x	

Armada \ TA60 \ 2007-7~	Difference lock	x	x	x	
Armada \ TA60 \ 2007-7~	Sonar	x	x	x	
Armada \ TA60 \ 2007-7~	Air levelizer	x	x	x	
Armada \ TA60 \ 2007-7~	Rearview camera			x	
Armada \ TA60 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2008	BCM	x	x		
Armada \ TA60 \ 2008	HVAC	x	x	x	
Armada \ TA60 \ 2008	Transmission	x	x	x	
Armada \ TA60 \ 2008	Multi AV	x	x	x	0280
Armada \ TA60 \ 2008	IPDM E/R	x	x	x	
Armada \ TA60 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2008	Auto drive position	x	x	x	
Armada \ TA60 \ 2008	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2008	ABS	x	x	x	
Armada \ TA60 \ 2008	Air bag	x	x	x	
Armada \ TA60 \ 2008	Difference lock	x	x	x	
Armada \ TA60 \ 2008	Sonar	x	x	x	
Armada \ TA60 \ 2008	Air levelizer	x	x	x	
Armada \ TA60 \ 2008	Rearview camera			x	
Armada \ TA60 \ 2008-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2008-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2008-4~	BCM	x	x		
Armada \ TA60 \ 2008-4~	HVAC	x	x	x	
Armada \ TA60 \ 2008-4~	Transmission	x	x	x	
Armada \ TA60 \ 2008-4~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2008-4~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2008-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2008-4~	Auto drive position	x	x	x	
Armada \ TA60 \ 2008-4~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2008-4~	ABS	x	x	x	
Armada \ TA60 \ 2008-4~	Air bag	x	x	x	
Armada \ TA60 \ 2008-4~	Difference lock	x	x	x	
Armada \ TA60 \ 2008-4~	Sonar	x	x	x	
Armada \ TA60 \ 2008-4~	Air levelizer	x	x	x	

Armada \ TA60 \ 2008-4~	Rearview camera			x	
Armada \ TA60 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2009	BCM	x	x		
Armada \ TA60 \ 2009	HVAC	x	x	x	
Armada \ TA60 \ 2009	Transmission	x	x	x	
Armada \ TA60 \ 2009	Multi AV	x	x	x	0280
Armada \ TA60 \ 2009	IPDM E/R	x	x	x	
Armada \ TA60 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2009	Auto drive position	x	x	x	
Armada \ TA60 \ 2009	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2009	ABS	x	x	x	
Armada \ TA60 \ 2009	Air bag	x	x	x	
Armada \ TA60 \ 2009	Difference lock	x	x	x	
Armada \ TA60 \ 2009	Sonar	x	x	x	
Armada \ TA60 \ 2009	Air levelizer	x	x	x	
Armada \ TA60 \ 2009	Rearview camera			x	
Armada \ TA60 \ 2009-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2009-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2009-4~	BCM	x	x		
Armada \ TA60 \ 2009-4~	HVAC	x	x	x	
Armada \ TA60 \ 2009-4~	Transmission	x	x	x	
Armada \ TA60 \ 2009-4~	Multi AV	x	x	x	
Armada \ TA60 \ 2009-4~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2009-4~	Intelligent key	x	x	x	
Armada \ TA60 \ 2009-4~	Auto drive position	x	x	x	
Armada \ TA60 \ 2009-4~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2009-4~	ABS	x	x	x	
Armada \ TA60 \ 2009-4~	Air bag	x	x	x	
Armada \ TA60 \ 2009-4~	Difference lock	x	x	x	
Armada \ TA60 \ 2009-4~	Sonar	x	x	x	
Armada \ TA60 \ 2009-4~	Air levelizer	x	x	x	
Armada \ TA60 \ 2009-4~	Rearview camera			x	
Armada \ TA60 \ 2009-4~	S/blind camera			x	
Armada \ TA60 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Armada \ TA60 \ 2010	BCM	x	x		
Armada \ TA60 \ 2010	HVAC	x	x	x	
Armada \ TA60 \ 2010	Transmission	x	x	x	
Armada \ TA60 \ 2010	Multi AV	x	x	x	
Armada \ TA60 \ 2010	IPDM E/R	x	x	x	
Armada \ TA60 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2010	Auto drive position	x	x	x	
Armada \ TA60 \ 2010	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2010	ABS	x	x	x	
Armada \ TA60 \ 2010	Air bag	x	x	x	
Armada \ TA60 \ 2010	Difference lock	x	x	x	
Armada \ TA60 \ 2010	Sonar	x	x	x	
Armada \ TA60 \ 2010	Air levelizer	x	x	x	
Armada \ TA60 \ 2010	Rearview camera			x	
Armada \ TA60 \ 2010	S/blind camera			x	
Armada \ TA60 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2010-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2010-7~	BCM	x	x		
Armada \ TA60 \ 2010-7~	Air bag	x	x	x	
Armada \ TA60 \ 2010-7~	HVAC	x	x	x	
Armada \ TA60 \ 2010-7~	Transmission	x	x	x	
Armada \ TA60 \ 2010-7~	Multi AV	x	x	x	
Armada \ TA60 \ 2010-7~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2010-7~	Intelligent key	x	x	x	
Armada \ TA60 \ 2010-7~	Auto drive position	x	x	x	
Armada \ TA60 \ 2010-7~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2010-7~	ABS	x	x	x	
Armada \ TA60 \ 2010-7~	Difference lock	x	x	x	
Armada \ TA60 \ 2010-7~	Sonar	x	x	x	
Armada \ TA60 \ 2010-7~	Air levelizer	x	x	x	
Armada \ TA60 \ 2010-7~	Rearview camera			x	
Armada \ TA60 \ 2010-7~	S/blind camera			x	
Armada \ TA60 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2011	BCM	x	x		
Armada \ TA60 \ 2011	Air bag	x	x	x	
Armada \ TA60 \ 2011	HVAC	x	x	x	

Armada \ TA60 \ 2011	Transmission	x	x	x	
Armada \ TA60 \ 2011	Multi AV	x	x	x	
Armada \ TA60 \ 2011	IPDM E/R	x	x	x	
Armada \ TA60 \ 2011	Intelligent key	x	x	x	
Armada \ TA60 \ 2011	Auto drive position	x	x	x	
Armada \ TA60 \ 2011	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2011	ABS	x	x	x	
Armada \ TA60 \ 2011	Difference lock	x	x	x	
Armada \ TA60 \ 2011	Sonar	x	x	x	
Armada \ TA60 \ 2011	Air levelizer	x	x	x	
Armada \ TA60 \ 2011	Rearview camera			x	
Armada \ TA60 \ 2011	S/blind camera			x	
Armada \ TA60 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2011-8~	BCM	x	x		
Armada \ TA60 \ 2011-8~	Air bag	x	x	x	
Armada \ TA60 \ 2011-8~	HVAC	x	x	x	
Armada \ TA60 \ 2011-8~	Multi AV	x	x	x	
Armada \ TA60 \ 2011-8~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2011-8~	Intelligent key	x	x	x	
Armada \ TA60 \ 2011-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2011-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2011-8~	ABS	x	x	x	
Armada \ TA60 \ 2011-8~	Transmission	x	x	x	
Armada \ TA60 \ 2011-8~	Difference lock	x	x	x	
Armada \ TA60 \ 2011-8~	Sonar	x	x	x	
Armada \ TA60 \ 2011-8~	Air levelizer	x	x	x	
Armada \ TA60 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2012	BCM	x	x		
Armada \ TA60 \ 2012	Air bag	x	x	x	
Armada \ TA60 \ 2012	HVAC	x	x	x	
Armada \ TA60 \ 2012	Multi AV	x	x	x	
Armada \ TA60 \ 2012	IPDM E/R	x	x	x	
Armada \ TA60 \ 2012	Intelligent key	x	x	x	
Armada \ TA60 \ 2012	Auto drive position	x	x	x	
Armada \ TA60 \ 2012	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2012	ABS	x	x	x	
Armada \ TA60 \ 2012	Transmission	x	x	x	

Armada \ TA60 \ 2012	Difference lock	x	x	x	
Armada \ TA60 \ 2012	Sonar	x	x	x	
Armada \ TA60 \ 2012	Air levelizer	x	x	x	
Armada \ TA60 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2012-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2012-8~	BCM	x	x		
Armada \ TA60 \ 2012-8~	Air bag	x	x	x	
Armada \ TA60 \ 2012-8~	HVAC	x	x	x	
Armada \ TA60 \ 2012-8~	Multi AV		x	x	
Armada \ TA60 \ 2012-8~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2012-8~	Intelligent key	x	x	x	
Armada \ TA60 \ 2012-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2012-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2012-8~	Transmission	x	x	x	
Armada \ TA60 \ 2012-8~	Sonar	x	x	x	
Armada \ TA60 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2013	ABS	x	x	x	0003, 0092, 0264
Armada \ TA60 \ 2013	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2013	BCM	x	x		
Armada \ TA60 \ 2013	Air bag	x	x	x	
Armada \ TA60 \ 2013	HVAC	x	x	x	
Armada \ TA60 \ 2013	Multi AV		x	x	
Armada \ TA60 \ 2013	IPDM E/R	x	x	x	
Armada \ TA60 \ 2013	Intelligent key	x	x	x	
Armada \ TA60 \ 2013	Auto drive position	x	x	x	
Armada \ TA60 \ 2013	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2013	Transmission	x	x	x	
Armada \ TA60 \ 2013	Sonar	x	x	x	
Armada \ TA60 \ 2013	Air levelizer	x	x	x	
Armada \ TA60 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2013-8~	BCM	x	x		
Armada \ TA60 \ 2013-8~	Air bag	x	x	x	
Armada \ TA60 \ 2013-8~	HVAC	x	x	x	
Armada \ TA60 \ 2013-8~	Multi AV		x	x	
Armada \ TA60 \ 2013-8~	IPDM E/R	x	x	x	

Armada \ TA60 \ 2013-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2013-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2013-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2013-8~	ABS	x	x	x	
Armada \ TA60 \ 2013-8~	Transmission	x	x	x	
Armada \ TA60 \ 2013-8~	Sonar	x	x	x	
Armada \ TA60 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2014	ABS	x	x	x	
Armada \ TA60 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2014	BCM	x	x		
Armada \ TA60 \ 2014	Air bag	x	x	x	
Armada \ TA60 \ 2014	HVAC	x	x	x	
Armada \ TA60 \ 2014	Multi AV		x	x	
Armada \ TA60 \ 2014	IPDM E/R	x	x	x	
Armada \ TA60 \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2014	Auto drive position	x	x	x	
Armada \ TA60 \ 2014	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2014	Transmission	x	x	x	
Armada \ TA60 \ 2014	Difference lock	x	x	x	
Armada \ TA60 \ 2014	Sonar	x	x	x	
Armada \ TA60 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2014-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2014-8~	BCM	x	x		
Armada \ TA60 \ 2014-8~	Air bag	x	x	x	
Armada \ TA60 \ 2014-8~	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2014-8~	HVAC	x	x	x	
Armada \ TA60 \ 2014-8~	Multi AV	x	x	x	0280
Armada \ TA60 \ 2014-8~	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2014-8~	IPDM E/R	x	x	x	
Armada \ TA60 \ 2014-8~	Laser/radar	x	x	x	
Armada \ TA60 \ 2014-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2014-8~	Auto drive position	x	x	x	
Armada \ TA60 \ 2014-8~	Sonar	x	x	x	

Armada \ TA60 \ 2014-8~	AVM		x	x	
Armada \ TA60 \ 2014-8~	ABS	x	x	x	
Armada \ TA60 \ 2014-8~	Transmission	x	x	x	
Armada \ TA60 \ 2014-8~	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2014-8~	Difference lock	x	x	x	
Armada \ TA60 \ 2014-8~	Air levelizer	x	x	x	
Armada \ TA60 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ TA60 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Armada \ TA60 \ 2015	BCM	x	x		
Armada \ TA60 \ 2015	Air bag	x	x	x	
Armada \ TA60 \ 2015	ICC/ADAS	x	x	x	
Armada \ TA60 \ 2015	HVAC	x	x	x	
Armada \ TA60 \ 2015	Multi AV	x	x	x	0280
Armada \ TA60 \ 2015	EPS/DAST 3	x	x	x	
Armada \ TA60 \ 2015	IPDM E/R	x	x	x	
Armada \ TA60 \ 2015	Laser/radar	x	x	x	
Armada \ TA60 \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Armada \ TA60 \ 2015	Auto drive position	x	x	x	
Armada \ TA60 \ 2015	All mode AWD/4WD	x	x	x	
Armada \ TA60 \ 2015	Sonar	x	x	x	
Armada \ TA60 \ 2015	AVM		x	x	
Armada \ TA60 \ 2015	ABS	x	x	x	
Armada \ TA60 \ 2015	Transmission	x	x	x	
Armada \ TA60 \ 2015	Difference lock	x	x	x	
Armada \ TA60 \ 2015	Air levelizer	x	x	x	
Armada \ Y62 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Armada \ Y62 \ 2017	ABS		x	x	
Armada \ Y62 \ 2017	Meter/M&A		x	x	
Armada \ Y62 \ 2017	BCM		x		
Armada \ Y62 \ 2017	Air bag	x	x	x	
Armada \ Y62 \ 2017	ICC/ADAS		x	x	
Armada \ Y62 \ 2017	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Armada \ Y62 \ 2017	Transmission	x	x	x	0059
Armada \ Y62 \ 2017	Multi AV		x	x	
Armada \ Y62 \ 2017	IPDM E/R		x	x	
Armada \ Y62 \ 2017	Air pressure monitor		x	x	

Armada \ Y62 \ 2017	Laser/radar		x	x	
Armada \ Y62 \ 2017	Precrash seatbelt		x	x	
Armada \ Y62 \ 2017	Auto drive position	x	x	x	
Armada \ Y62 \ 2017	All mode AWD/4WD	x	x	x	
Armada \ Y62 \ 2017	Sonar		x	x	
Armada \ Y62 \ 2017	Lane camera		x	x	
Armada \ Y62 \ 2017	Adaptive light	x	x	x	
Armada \ Y62 \ 2017	CAN gateway		x		
Armada \ Y62 \ 2017	Auto back door		x	x	
Armada \ Y62 \ 2017	E-SUS		x	x	
Armada \ Y62 \ 2017	Accele pedal ACT		x	x	
Armada \ Y62 \ 2017	Side radar left		x	x	
Armada \ Y62 \ 2017	Side radar right		x	x	
Armada \ Y62 \ 2017	AVM		x	x	
Armada \ Y62 \ 2017	Head lamp levelizer	x	x	x	
Armada \ Y62 \ 2017	Difference lock	x	x	x	
Armada \ Y62 \ 2017	Occupant detection			x	
Armada \ Y62 \ 2017	Air levelizer	x	x	x	
Atlas \ F24 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atlas \ F24 \ 2007-5~	Meter/M&A	x	x	x	0143, 0331
Atlas \ F24 \ 2007-5~	BCM	x	x		
Atlas \ F24 \ 2007-5~	Transmission	x	x	x	
Atlas \ F24 \ 2007-5~	EHS/PKB		x	x	
Atlas \ F24 \ 2007-5~	IPDM E/R	x	x	x	
Atlas \ F24 \ 2007-5~	ABS	x	x	x	
Atlas \ F24 \ 2007-5~	Air bag	x	x	x	
Atlas \ F24 \ 2007-5~	All mode AWD/4WD	x	x	x	
Atlas \ F24 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atlas \ F24 \ 2010-2~	Meter/M&A	x	x	x	0143, 0331
Atlas \ F24 \ 2010-2~	BCM	x	x		
Atlas \ F24 \ 2010-2~	Transmission	x	x	x	
Atlas \ F24 \ 2010-2~	EHS/PKB		x	x	
Atlas \ F24 \ 2010-2~	IPDM E/R	x	x	x	
Atlas \ F24 \ 2010-2~	ABS	x	x	x	
Atlas \ F24 \ 2010-2~	Air bag	x	x	x	
Atlas \ F24 \ 2010-2~	All mode AWD/4WD	x	x	x	
Atlas \ F24 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atlas \ F24 \ 2010-8~	Meter/M&A	x	x	x	0143, 0331

Atlas \ F24 \ 2010-8~	BCM	x	x		
Atlas \ F24 \ 2010-8~	Transmission	x	x	x	
Atlas \ F24 \ 2010-8~	EHS/PKB		x	x	
Atlas \ F24 \ 2010-8~	IPDM E/R	x	x	x	
Atlas \ F24 \ 2010-8~	ABS	x	x	x	
Atlas \ F24 \ 2010-8~	Air bag	x	x	x	
Atlas \ F24 \ 2010-8~	All mode AWD/4WD	x	x	x	
Atlas \ F24 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atlas \ F24 \ 2011-10~	ABS	x	x	x	0003, 0092, 0264
Atlas \ F24 \ 2011-10~	Meter/M&A	x	x	x	0143, 0331
Atlas \ F24 \ 2011-10~	BCM	x	x		
Atlas \ F24 \ 2011-10~	Transmission	x	x	x	
Atlas \ F24 \ 2011-10~	EHS/PKB		x	x	
Atlas \ F24 \ 2011-10~	EPS/DAST 3	x	x	x	
Atlas \ F24 \ 2011-10~	IPDM E/R	x	x	x	
Atlas \ F24 \ 2011-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Atlas \ F24 \ 2011-10~	All mode AWD/4WD	x	x	x	0245, 0311
Atlas \ F24 \ 2011-10~	Air bag	x	x	x	
Atlas \ F24 \ 2011-10~	Difference lock	x	x	x	
Atlas \ F24 \ 2015-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atlas \ F24 \ 2015-2~	ABS	x	x	x	0003, 0092, 0264
Atlas \ F24 \ 2015-2~	Meter/M&A	x	x	x	0143, 0331
Atlas \ F24 \ 2015-2~	BCM	x	x		
Atlas \ F24 \ 2015-2~	Transmission	x	x	x	
Atlas \ F24 \ 2015-2~	EHS/PKB		x	x	
Atlas \ F24 \ 2015-2~	EPS/DAST 3	x	x	x	
Atlas \ F24 \ 2015-2~	IPDM E/R	x	x	x	
Atlas \ F24 \ 2015-2~	Intelligent key	x	x	x	0075, 0115, 0043, 0042, 0032, 0156, 0258, 0207, 0175, 0218, 0344, 0307, 0305, 0170, 0303, 0155, 0031
Atlas \ F24 \ 2015-2~	All mode AWD/4WD	x	x	x	0245, 0311
Atlas \ F24 \ 2015-2~	Air bag	x	x	x	
Atlas \ F24 \ 2015-2~	Difference lock	x	x	x	
Atleon \ TK0 \ 1999-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon \ TK0 \ 1999-10~	ABS	x	x	x	0003, 0092, 0264
Atleon \ TK0 \ 1999-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Atleon \ TK0 \ 1999-10~	BCM	x	x		
Atleon \ TK0 \ 1999-10~	Air bag	x	x	x	
Atleon \ TK0 \ 1999-10~	ICC/ADAS	x	x	x	
Atleon \ TK0 \ 1999-10~	HVAC	x	x	x	
Atleon \ TK0 \ 1999-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Atleon \ TK0 \ 1999-10~	Multi AV	x	x	x	0280
Atleon \ TK0 \ 1999-10~	EPS/DAST 3	x	x	x	
Atleon \ TK0 \ 1999-10~	IPDM E/R	x	x	x	
Atleon \ TK0 \ 1999-10~	Air pressure monitor	x	x	x	
Atleon \ TK0 \ 1999-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Atleon \ TK0 \ 1999-10~	DIU	x	x	x	
Atleon \ TK0 \ 1999-10~	Auto slide door	x	x	x	
Atleon \ TK0 \ 1999-10~	Auto drive position	x	x	x	
Atleon \ TK0 \ 1999-10~	All mode AWD/4WD	x	x	x	
Atleon \ TK0 \ 1999-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Atleon \ TK0 \ 1999-10~	Sonar	x	x	x	
Atleon \ TK0 \ 1999-10~	Lane camera	x	x	x	
Atleon \ TK0 \ 1999-10~	Adaptive light	x	x	x	
Atleon \ TK0 \ 1999-10~	AVM		x	x	
Atleon \ TK0 \ 1999-10~	Head lamp levelizer	x	x	x	
Atleon \ TK0 \ 1999-10~	Difference lock	x	x	x	
Atleon \ TK0 \ 1999-10~	Nats immu	x	x		
Atleon \ TK0 \ 1999-10~	Smart entrance	x	x		
Atleon \ TK0 \ 1999-10~	Air levelizer	x	x	x	
Atleon \ TK0 \ 1999-10~	Rearview camera			x	
Atleon \ TK0 \ 1999-10~	S/blind camera			x	
Atleon \ TK0 \ 1999-10~	Motor assist	x	x	x	
Atleon \ TK0 \ 2001-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon \ TK0 \ 2001-5~	ABS	x	x	x	0003, 0092, 0264
Atleon \ TK0 \ 2001-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Atleon \ TK0 \ 2001-5~	BCM	x	x		
Atleon \ TK0 \ 2001-5~	Air bag	x	x	x	
Atleon \ TK0 \ 2001-5~	ICC/ADAS	x	x	x	
Atleon \ TK0 \ 2001-5~	HVAC	x	x	x	
Atleon \ TK0 \ 2001-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Atleon \ TK0 \ 2001-5~	Multi AV	x	x	x	0280
Atleon \ TK0 \ 2001-5~	EPS/DAST 3	x	x	x	
Atleon \ TK0 \ 2001-5~	IPDM E/R	x	x	x	

Atleon \ TK0 \ 2001-5~	Air pressure monitor	x	x	x	
Atleon \ TK0 \ 2001-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Atleon \ TK0 \ 2001-5~	DIU	x	x	x	
Atleon \ TK0 \ 2001-5~	Auto slide door	x	x	x	
Atleon \ TK0 \ 2001-5~	Auto drive position	x	x	x	
Atleon \ TK0 \ 2001-5~	All mode AWD/4WD	x	x	x	
Atleon \ TK0 \ 2001-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Atleon \ TK0 \ 2001-5~	Sonar	x	x	x	
Atleon \ TK0 \ 2001-5~	Lane camera	x	x	x	
Atleon \ TK0 \ 2001-5~	Adaptive light	x	x	x	
Atleon \ TK0 \ 2001-5~	AVM		x	x	
Atleon \ TK0 \ 2001-5~	Head lamp levelizer	x	x	x	
Atleon \ TK0 \ 2001-5~	Difference lock	x	x	x	
Atleon \ TK0 \ 2001-5~	Nats immu	x	x		
Atleon \ TK0 \ 2001-5~	Smart entrance	x	x		
Atleon \ TK0 \ 2001-5~	Air levelizer	x	x	x	
Atleon \ TK0 \ 2001-5~	Rearview camera			x	
Atleon \ TK0 \ 2001-5~	S/blind camera			x	
Atleon \ TK0 \ 2001-5~	Motor assist	x	x	x	
Atleon \ TK0 \ 2004-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon \ TK0 \ 2004-1~	ABS	x	x	x	0003, 0092, 0264
Atleon \ TK0 \ 2004-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Atleon \ TK0 \ 2004-1~	BCM	x	x		
Atleon \ TK0 \ 2004-1~	Air bag	x	x	x	
Atleon \ TK0 \ 2004-1~	ICC/ADAS	x	x	x	
Atleon \ TK0 \ 2004-1~	HVAC	x	x	x	
Atleon \ TK0 \ 2004-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Atleon \ TK0 \ 2004-1~	Multi AV	x	x	x	0280
Atleon \ TK0 \ 2004-1~	EPS/DAST 3	x	x	x	
Atleon \ TK0 \ 2004-1~	IPDM E/R	x	x	x	
Atleon \ TK0 \ 2004-1~	Air pressure monitor	x	x	x	
Atleon \ TK0 \ 2004-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Atleon \ TK0 \ 2004-1~	DIU	x	x	x	
Atleon \ TK0 \ 2004-1~	Auto slide door	x	x	x	
Atleon \ TK0 \ 2004-1~	Auto drive position	x	x	x	
Atleon \ TK0 \ 2004-1~	All mode AWD/4WD	x	x	x	

Atleon \ TK0 \ 2004-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Atleon \ TK0 \ 2004-1~	Sonar	x	x	x	
Atleon \ TK0 \ 2004-1~	Lane camera	x	x	x	
Atleon \ TK0 \ 2004-1~	Adaptive light	x	x	x	
Atleon \ TK0 \ 2004-1~	AVM		x	x	
Atleon \ TK0 \ 2004-1~	Head lamp levelizer	x	x	x	
Atleon \ TK0 \ 2004-1~	Difference lock	x	x	x	
Atleon \ TK0 \ 2004-1~	Nats immu	x	x		
Atleon \ TK0 \ 2004-1~	Smart entrance	x	x		
Atleon \ TK0 \ 2004-1~	Air levelizer	x	x	x	
Atleon \ TK0 \ 2004-1~	Rearview camera			x	
Atleon \ TK0 \ 2004-1~	S/blind camera			x	
Atleon \ TK0 \ 2004-1~	Motor assist	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2006-6~	Engine		x	x	
Atleon(except for ZD30) \ TK0 \ 2006-6~	Meter/M&A	x	x	x	0143, 0331
Atleon(except for ZD30) \ TK0 \ 2006-6~	Transmission	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2006-6~	ABS	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2006-6~	Air bag	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2006-6~	Smart entrance	x	x		
Atleon(except for ZD30) \ TK0 \ 2010-11~	Engine		x	x	
Atleon(except for ZD30) \ TK0 \ 2010-11~	Meter/M&A	x	x	x	0143, 0331
Atleon(except for ZD30) \ TK0 \ 2010-11~	Transmission	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2010-11~	ABS	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2010-11~	Air bag	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2010-11~	Smart entrance	x	x		
Atleon(except for ZD30) \ TK0 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon(except for ZD30) \ TK0 \ 2012-7~	Meter/M&A		x	x	
Atleon(except for ZD30) \ TK0 \ 2012-7~	Transmission	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2012-7~	ABS	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2012-7~	Air bag	x	x	x	
Atleon(except for ZD30) \ TK0 \ 2012-7~	Smart entrance	x	x		
Atleon(ZD30) \ TK0 \ 2006-8~	Engine		x	x	
Atleon(ZD30) \ TK0 \ 2006-8~	Meter/M&A	x	x	x	0143, 0331
Atleon(ZD30) \ TK0 \ 2006-8~	Transmission	x	x	x	
Atleon(ZD30) \ TK0 \ 2006-8~	ABS	x	x	x	
Atleon(ZD30) \ TK0 \ 2006-8~	Air bag	x	x	x	
Atleon(ZD30) \ TK0 \ 2006-8~	Smart entrance	x	x		
Atleon(ZD30) \ TK0 \ 2010-11~	Engine		x	x	
Atleon(ZD30) \ TK0 \ 2010-11~	Meter/M&A	x	x	x	0143, 0331
Atleon(ZD30) \ TK0 \ 2010-11~	Transmission	x	x	x	

Atleon(ZD30) \ TK0 \ 2010-11~	ABS	x	x	x	
Atleon(ZD30) \ TK0 \ 2010-11~	Air bag	x	x	x	
Atleon(ZD30) \ TK0 \ 2010-11~	Smart entrance	x	x		
Atleon(ZD30) \ TK0 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon(ZD30) \ TK0 \ 2011-10~	Meter/M&A	x	x	x	0143, 0331
Atleon(ZD30) \ TK0 \ 2011-10~	Transmission	x	x	x	
Atleon(ZD30) \ TK0 \ 2011-10~	ABS	x	x	x	
Atleon(ZD30) \ TK0 \ 2011-10~	Air bag	x	x	x	
Atleon(ZD30) \ TK0 \ 2011-10~	Smart entrance	x	x		
Atleon(ZD30) \ TK0 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Atleon(ZD30) \ TK0 \ 2012-7~	Meter/M&A		x	x	
Atleon(ZD30) \ TK0 \ 2012-7~	Transmission	x	x	x	
Atleon(ZD30) \ TK0 \ 2012-7~	ABS	x	x	x	
Atleon(ZD30) \ TK0 \ 2012-7~	Air bag	x	x	x	
Atleon(ZD30) \ TK0 \ 2012-7~	Smart entrance	x	x		
Avenir \ W11 \ All Year	Engine	x	x	x	0163, 0209, 0278, 0262, 0324, 0216, 0093, 0233, 0103, 0234, 0212
Avenir \ W11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Avenir \ W11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Avenir \ W11 \ All Year	BCM	x	x		
Avenir \ W11 \ All Year	Air bag	x	x	x	
Avenir \ W11 \ All Year	ICC/ADAS	x	x	x	
Avenir \ W11 \ All Year	HVAC	x	x	x	
Avenir \ W11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Avenir \ W11 \ All Year	Multi AV	x	x	x	0280
Avenir \ W11 \ All Year	EPS/DAST 3	x	x	x	
Avenir \ W11 \ All Year	IPDM E/R	x	x	x	
Avenir \ W11 \ All Year	Air pressure monitor	x	x	x	
Avenir \ W11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Avenir \ W11 \ All Year	DIU	x	x	x	
Avenir \ W11 \ All Year	Auto slide door	x	x	x	
Avenir \ W11 \ All Year	Auto drive position	x	x	x	
Avenir \ W11 \ All Year	All mode AWD/4WD	x	x	x	
Avenir \ W11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Avenir \ W11 \ All Year	Sonar	x	x	x	
Avenir \ W11 \ All Year	Lane camera	x	x	x	
Avenir \ W11 \ All Year	Adaptive light	x	x	x	

Avenir \ W11 \ All Year	AVM		x	x	
Avenir \ W11 \ All Year	Head lamp levelizer	x	x	x	
Avenir \ W11 \ All Year	Difference lock	x	x	x	
Avenir \ W11 \ All Year	Nats immu	x	x		
Avenir \ W11 \ All Year	Smart entrance	x	x		
Avenir \ W11 \ All Year	Air levelizer	x	x	x	
Avenir \ W11 \ All Year	Rearview camera			x	
Avenir \ W11 \ All Year	S/blind camera			x	
Avenir \ W11 \ All Year	Motor assist	x	x	x	
Bassara \ JU30 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Bassara \ JU30 \ All Year	ABS	x	x	x	0003, 0092, 0264
Bassara \ JU30 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Bassara \ JU30 \ All Year	BCM	x	x		
Bassara \ JU30 \ All Year	Air bag	x	x	x	
Bassara \ JU30 \ All Year	ICC/ADAS	x	x	x	
Bassara \ JU30 \ All Year	HVAC	x	x	x	
Bassara \ JU30 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Bassara \ JU30 \ All Year	Multi AV	x	x	x	0280
Bassara \ JU30 \ All Year	EPS/DAST 3	x	x	x	
Bassara \ JU30 \ All Year	IPDM E/R	x	x	x	
Bassara \ JU30 \ All Year	Air pressure monitor	x	x	x	
Bassara \ JU30 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Bassara \ JU30 \ All Year	DIU	x	x	x	
Bassara \ JU30 \ All Year	Auto slide door	x	x	x	
Bassara \ JU30 \ All Year	Auto drive position	x	x	x	
Bassara \ JU30 \ All Year	All mode AWD/4WD	x	x	x	
Bassara \ JU30 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Bassara \ JU30 \ All Year	Sonar	x	x	x	
Bassara \ JU30 \ All Year	Lane camera	x	x	x	
Bassara \ JU30 \ All Year	Adaptive light	x	x	x	
Bassara \ JU30 \ All Year	AVM		x	x	
Bassara \ JU30 \ All Year	Head lamp levelizer	x	x	x	
Bassara \ JU30 \ All Year	Difference lock	x	x	x	
Bassara \ JU30 \ All Year	Nats immu	x	x		
Bassara \ JU30 \ All Year	Smart entrance	x	x		
Bassara \ JU30 \ All Year	Air levelizer	x	x	x	
Bassara \ JU30 \ All Year	Rearview camera			x	
Bassara \ JU30 \ All Year	S/blind camera			x	

Bassara \ JU30 \ All Year	Motor assist	x	x	x	
Bluebird \ U13 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Bluebird \ U13 \ All Year	ABS	x	x	x	0003, 0092, 0264
Bluebird \ U13 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Bluebird \ U13 \ All Year	BCM	x	x		
Bluebird \ U13 \ All Year	Air bag	x	x	x	
Bluebird \ U13 \ All Year	ICC/ADAS	x	x	x	
Bluebird \ U13 \ All Year	HVAC	x	x	x	
Bluebird \ U13 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Bluebird \ U13 \ All Year	Multi AV	x	x	x	0280
Bluebird \ U13 \ All Year	EPS/DAST 3	x	x	x	
Bluebird \ U13 \ All Year	IPDM E/R	x	x	x	
Bluebird \ U13 \ All Year	Air pressure monitor	x	x	x	
Bluebird \ U13 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Bluebird \ U13 \ All Year	DIU	x	x	x	
Bluebird \ U13 \ All Year	Auto slide door	x	x	x	
Bluebird \ U13 \ All Year	Auto drive position	x	x	x	
Bluebird \ U13 \ All Year	All mode AWD/4WD	x	x	x	
Bluebird \ U13 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Bluebird \ U13 \ All Year	Sonar	x	x	x	
Bluebird \ U13 \ All Year	Lane camera	x	x	x	
Bluebird \ U13 \ All Year	Adaptive light	x	x	x	
Bluebird \ U13 \ All Year	AVM		x	x	
Bluebird \ U13 \ All Year	Head lamp levelizer	x	x	x	
Bluebird \ U13 \ All Year	Difference lock	x	x	x	
Bluebird \ U13 \ All Year	Nats immu	x	x		
Bluebird \ U13 \ All Year	Smart entrance	x	x		
Bluebird \ U13 \ All Year	Air levelizer	x	x	x	
Bluebird \ U13 \ All Year	Rearview camera			x	
Bluebird \ U13 \ All Year	S/blind camera			x	
Bluebird \ U13 \ All Year	Motor assist	x	x	x	
Bluebird \ U14 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Bluebird \ U14 \ All Year	ABS	x	x	x	0003, 0092, 0264
Bluebird \ U14 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Bluebird \ U14 \ All Year	BCM	x	x		
Bluebird \ U14 \ All Year	Air bag	x	x	x	
Bluebird \ U14 \ All Year	ICC/ADAS	x	x	x	

Bluebird \ U14 \ All Year	HVAC	x	x	x	
Bluebird \ U14 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Bluebird \ U14 \ All Year	Multi AV	x	x	x	0280
Bluebird \ U14 \ All Year	EPS/DAST 3	x	x	x	
Bluebird \ U14 \ All Year	IPDM E/R	x	x	x	
Bluebird \ U14 \ All Year	Air pressure monitor	x	x	x	
Bluebird \ U14 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Bluebird \ U14 \ All Year	DIU	x	x	x	
Bluebird \ U14 \ All Year	Auto slide door	x	x	x	
Bluebird \ U14 \ All Year	Auto drive position	x	x	x	
Bluebird \ U14 \ All Year	All mode AWD/4WD	x	x	x	
Bluebird \ U14 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Bluebird \ U14 \ All Year	Sonar	x	x	x	
Bluebird \ U14 \ All Year	Lane camera	x	x	x	
Bluebird \ U14 \ All Year	Adaptive light	x	x	x	
Bluebird \ U14 \ All Year	AVM		x	x	
Bluebird \ U14 \ All Year	Head lamp levelizer	x	x	x	
Bluebird \ U14 \ All Year	Difference lock	x	x	x	
Bluebird \ U14 \ All Year	Nats immu	x	x		
Bluebird \ U14 \ All Year	Smart entrance	x	x		
Bluebird \ U14 \ All Year	Air levelizer	x	x	x	
Bluebird \ U14 \ All Year	Rearview camera			x	
Bluebird \ U14 \ All Year	S/blind camera			x	
Bluebird \ U14 \ All Year	Motor assist	x	x	x	
C27 \ C27 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
C27 \ C27 \ 2016-7~	ABS		x	x	
C27 \ C27 \ 2016-7~	Meter/M&A		x	x	
C27 \ C27 \ 2016-7~	BCM		x		
C27 \ C27 \ 2016-7~	Air bag		x	x	
C27 \ C27 \ 2016-7~	ICC/ADAS		x	x	
C27 \ C27 \ 2016-7~	HVAC		x	x	
C27 \ C27 \ 2016-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
C27 \ C27 \ 2016-7~	Multi AV	x	x	x	0280
C27 \ C27 \ 2016-7~	EHS/PKB		x	x	
C27 \ C27 \ 2016-7~	EPS/DAST 3		x	x	
C27 \ C27 \ 2016-7~	IPDM E/R		x	x	
C27 \ C27 \ 2016-7~	Auto slide door		x	x	

C27 \ C27 \ 2016-7~	All mode AWD/4WD		x	x	
C27 \ C27 \ 2016-7~	Sonar		x	x	
C27 \ C27 \ 2016-7~	Lane camera		x	x	
C27 \ C27 \ 2016-7~	Auto slide door right		x	x	
C27 \ C27 \ 2016-7~	CAN gateway		x	x	
C27 \ C27 \ 2016-7~	Side radar left		x	x	
C27 \ C27 \ 2016-7~	Side radar right		x	x	
C27 \ C27 \ 2016-7~	AVM		x	x	
C27 \ C27 \ 2016-7~	Chassis control		x	x	
Cabstar (China product) \ F24 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar (China product) \ F24 \ 2012-7~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Cabstar (China product) \ F24 \ 2012-7~	BCM	x	x		
Cabstar (China product) \ F24 \ 2012-7~	Transmission	x	x	x	
Cabstar (China product) \ F24 \ 2012-7~	EHS/PKB		x	x	
Cabstar (China product) \ F24 \ 2012-7~	IPDM E/R	x	x	x	
Cabstar (China product) \ F24 \ 2012-7~	ABS	x	x	x	
Cabstar (China product) \ F24 \ 2012-7~	Air bag	x	x	x	
Cabstar (China product) \ F24 \ 2012-7~	All mode AWD/4WD	x	x	x	
Cabstar (China product) \ F24 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar (China product) \ F24 \ 2012-9~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Cabstar (China product) \ F24 \ 2012-9~	BCM	x	x		
Cabstar (China product) \ F24 \ 2012-9~	Transmission	x	x	x	
Cabstar (China product) \ F24 \ 2012-9~	EHS/PKB		x	x	
Cabstar (China product) \ F24 \ 2012-9~	IPDM E/R	x	x	x	
Cabstar (China product) \ F24 \ 2012-9~	ABS	x	x	x	
Cabstar (China product) \ F24 \ 2012-9~	Air bag	x	x	x	
Cabstar (China product) \ F24 \ 2012-9~	All mode AWD/4WD	x	x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar (EURO product) \ F24 \ 2012-3~	Meter/M&A	x	x	x	0143, 0331
Cabstar (EURO product) \ F24 \ 2012-3~	BCM	x	x		
Cabstar (EURO product) \ F24 \ 2012-3~	Transmission	x	x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	EHS/PKB		x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	IPDM E/R	x	x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	ABS	x	x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	Air bag	x	x	x	
Cabstar (EURO product) \ F24 \ 2012-3~	All mode AWD/4WD	x	x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Cabstar (EURO product) \ F24 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
Cabstar (EURO product) \ F24 \ 2016-7~	Meter/M&A	x	x	x	0143, 0331
Cabstar (EURO product) \ F24 \ 2016-7~	BCM		x		
Cabstar (EURO product) \ F24 \ 2016-7~	ICC/ADAS		x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Transmission	x	x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Multi AV	x	x	x	0280
Cabstar (EURO product) \ F24 \ 2016-7~	IPDM E/R		x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Lane camera		x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	ADCM		x	x	0090, 0313, 0198, 0183, 0184, 0255, 0091, 0256, 0254, 0095
Cabstar (EURO product) \ F24 \ 2016-7~	PTC heater		x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	FSCM		x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Air bag	x	x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	All mode AWD/4WD	x	x	x	
Cabstar (EURO product) \ F24 \ 2016-7~	Difference lock	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar E \ TL0 \ 1998-11~	ABS	x	x	x	0003, 0092, 0264
Cabstar E \ TL0 \ 1998-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cabstar E \ TL0 \ 1998-11~	BCM	x	x		
Cabstar E \ TL0 \ 1998-11~	Air bag	x	x	x	
Cabstar E \ TL0 \ 1998-11~	ICC/ADAS	x	x	x	
Cabstar E \ TL0 \ 1998-11~	HVAC	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cabstar E \ TL0 \ 1998-11~	Multi AV	x	x	x	0280
Cabstar E \ TL0 \ 1998-11~	EPS/DAST 3	x	x	x	
Cabstar E \ TL0 \ 1998-11~	IPDM E/R	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Air pressure monitor	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cabstar E \ TL0 \ 1998-11~	DIU	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Auto slide door	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Auto drive position	x	x	x	
Cabstar E \ TL0 \ 1998-11~	All mode AWD/4WD	x	x	x	
Cabstar E \ TL0 \ 1998-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Sonar	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Lane camera	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Adaptive light	x	x	x	
Cabstar E \ TL0 \ 1998-11~	AVM		x	x	
Cabstar E \ TL0 \ 1998-11~	Head lamp levelizer	x	x	x	

Cabstar E \ TL0 \ 1998-11~	Difference lock	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Nats immu	x	x		
Cabstar E \ TL0 \ 1998-11~	Smart entrance	x	x		
Cabstar E \ TL0 \ 1998-11~	Air levelizer	x	x	x	
Cabstar E \ TL0 \ 1998-11~	Rearview camera			x	
Cabstar E \ TL0 \ 1998-11~	S/blind camera			x	
Cabstar E \ TL0 \ 1998-11~	Motor assist	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar E \ TL0 \ 2001-5~	ABS	x	x	x	0003, 0092, 0264
Cabstar E \ TL0 \ 2001-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cabstar E \ TL0 \ 2001-5~	BCM	x	x		
Cabstar E \ TL0 \ 2001-5~	Air bag	x	x	x	
Cabstar E \ TL0 \ 2001-5~	ICC/ADAS	x	x	x	
Cabstar E \ TL0 \ 2001-5~	HVAC	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cabstar E \ TL0 \ 2001-5~	Multi AV	x	x	x	0280
Cabstar E \ TL0 \ 2001-5~	EPS/DAST 3	x	x	x	
Cabstar E \ TL0 \ 2001-5~	IPDM E/R	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Air pressure monitor	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cabstar E \ TL0 \ 2001-5~	DIU	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Auto slide door	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Auto drive position	x	x	x	
Cabstar E \ TL0 \ 2001-5~	All mode AWD/4WD	x	x	x	
Cabstar E \ TL0 \ 2001-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Sonar	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Lane camera	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Adaptive light	x	x	x	
Cabstar E \ TL0 \ 2001-5~	AVM		x	x	
Cabstar E \ TL0 \ 2001-5~	Head lamp levelizer	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Difference lock	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Nats immu	x	x		
Cabstar E \ TL0 \ 2001-5~	Smart entrance	x	x		
Cabstar E \ TL0 \ 2001-5~	Air levelizer	x	x	x	
Cabstar E \ TL0 \ 2001-5~	Rearview camera			x	
Cabstar E \ TL0 \ 2001-5~	S/blind camera			x	
Cabstar E \ TL0 \ 2001-5~	Motor assist	x	x	x	

Cabstar \ F24 \ 2006-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2006-9~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2006-9~	BCM	x	x		
Cabstar \ F24 \ 2006-9~	Transmission	x	x	x	
Cabstar \ F24 \ 2006-9~	EHS/PKB		x	x	
Cabstar \ F24 \ 2006-9~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2006-9~	ABS	x	x	x	
Cabstar \ F24 \ 2006-9~	Air bag	x	x	x	
Cabstar \ F24 \ 2006-9~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2007-10~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2007-10~	BCM	x	x		
Cabstar \ F24 \ 2007-10~	Transmission		x	x	
Cabstar \ F24 \ 2007-10~	EHS/PKB		x	x	
Cabstar \ F24 \ 2007-10~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2007-10~	ABS	x	x	x	
Cabstar \ F24 \ 2007-10~	Air bag	x	x	x	
Cabstar \ F24 \ 2007-10~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2007-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2007-2~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Cabstar \ F24 \ 2007-2~	BCM	x	x		
Cabstar \ F24 \ 2007-2~	Transmission		x	x	
Cabstar \ F24 \ 2007-2~	EHS/PKB		x	x	
Cabstar \ F24 \ 2007-2~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2007-2~	ABS	x	x	x	
Cabstar \ F24 \ 2007-2~	Air bag	x	x	x	
Cabstar \ F24 \ 2008-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2008-1~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2008-1~	BCM	x	x		
Cabstar \ F24 \ 2008-1~	Transmission	x	x	x	
Cabstar \ F24 \ 2008-1~	EHS/PKB		x	x	
Cabstar \ F24 \ 2008-1~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2008-1~	ABS	x	x	x	
Cabstar \ F24 \ 2008-1~	Air bag	x	x	x	
Cabstar \ F24 \ 2009-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2009-3~	Meter/M&A	x	x	x	0143, 0331

Cabstar \ F24 \ 2009-3~	BCM	x	x		
Cabstar \ F24 \ 2009-3~	Transmission	x	x	x	
Cabstar \ F24 \ 2009-3~	EHS/PKB		x	x	
Cabstar \ F24 \ 2009-3~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2009-3~	ABS	x	x	x	
Cabstar \ F24 \ 2009-3~	Air bag	x	x	x	
Cabstar \ F24 \ 2009-3~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2009-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2009-4~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Cabstar \ F24 \ 2009-4~	BCM	x	x		
Cabstar \ F24 \ 2009-4~	Transmission	x	x	x	
Cabstar \ F24 \ 2009-4~	EHS/PKB		x	x	
Cabstar \ F24 \ 2009-4~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2009-4~	ABS	x	x	x	
Cabstar \ F24 \ 2009-4~	Air bag	x	x	x	
Cabstar \ F24 \ 2009-4~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2011-11~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2011-11~	BCM	x	x		
Cabstar \ F24 \ 2011-11~	Transmission	x	x	x	
Cabstar \ F24 \ 2011-11~	EHS/PKB		x	x	
Cabstar \ F24 \ 2011-11~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2011-11~	ABS	x	x	x	
Cabstar \ F24 \ 2011-11~	Air bag	x	x	x	
Cabstar \ F24 \ 2011-11~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2011-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2011-7~	Meter/M&A	x	x	x	0143, 0331, 0330, 0197, 0143, 0331
Cabstar \ F24 \ 2011-7~	BCM	x	x		
Cabstar \ F24 \ 2011-7~	Transmission	x	x	x	
Cabstar \ F24 \ 2011-7~	EHS/PKB		x	x	
Cabstar \ F24 \ 2011-7~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2011-7~	ABS	x	x	x	
Cabstar \ F24 \ 2011-7~	Air bag	x	x	x	
Cabstar \ F24 \ 2011-7~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2011-9~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2011-9~	BCM	x	x		

Cabstar \ F24 \ 2011-9~	Transmission	x	x	x	
Cabstar \ F24 \ 2011-9~	EHS/PKB		x	x	
Cabstar \ F24 \ 2011-9~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2011-9~	ABS	x	x	x	
Cabstar \ F24 \ 2011-9~	Air bag	x	x	x	
Cabstar \ F24 \ 2011-9~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2012-3~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2012-3~	BCM	x	x		
Cabstar \ F24 \ 2012-3~	Transmission	x	x	x	
Cabstar \ F24 \ 2012-3~	EHS/PKB		x	x	
Cabstar \ F24 \ 2012-3~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2012-3~	ABS	x	x	x	
Cabstar \ F24 \ 2012-3~	Air bag	x	x	x	
Cabstar \ F24 \ 2012-3~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2012-5~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2012-5~	BCM	x	x		
Cabstar \ F24 \ 2012-5~	Transmission	x	x	x	
Cabstar \ F24 \ 2012-5~	EHS/PKB		x	x	
Cabstar \ F24 \ 2012-5~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2012-5~	Intelligent key		x	x	
Cabstar \ F24 \ 2012-5~	ABS	x	x	x	
Cabstar \ F24 \ 2012-5~	Air bag	x	x	x	
Cabstar \ F24 \ 2012-5~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2012-5~	Difference lock	x	x	x	
Cabstar \ F24 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2013-12~	ABS	x	x	x	0003, 0092, 0264
Cabstar \ F24 \ 2013-12~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2013-12~	BCM	x	x		
Cabstar \ F24 \ 2013-12~	ICC/ADAS		x	x	
Cabstar \ F24 \ 2013-12~	Transmission	x	x	x	
Cabstar \ F24 \ 2013-12~	Multi AV	x	x	x	0280
Cabstar \ F24 \ 2013-12~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Cabstar \ F24 \ 2013-12~	EPS/DAST 3	x	x	x	
Cabstar \ F24 \ 2013-12~	IPDM E/R	x	x	x	

Cabstar \ F24 \ 2013-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cabstar \ F24 \ 2013-12~	Lane camera		x	x	
Cabstar \ F24 \ 2013-12~	EMCM	x	x	x	
Cabstar \ F24 \ 2013-12~	BSW/buzzer		x	x	
Cabstar \ F24 \ 2013-12~	AVM		x	x	
Cabstar \ F24 \ 2013-12~	Air bag	x	x	x	
Cabstar \ F24 \ 2013-12~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2013-12~	Difference lock	x	x	x	
Cabstar \ F24 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
Cabstar \ F24 \ 2014-9~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2014-9~	BCM	x	x		
Cabstar \ F24 \ 2014-9~	ICC/ADAS		x	x	
Cabstar \ F24 \ 2014-9~	Transmission	x	x	x	
Cabstar \ F24 \ 2014-9~	Multi AV	x	x	x	0280
Cabstar \ F24 \ 2014-9~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Cabstar \ F24 \ 2014-9~	EPS/DAST 3	x	x	x	
Cabstar \ F24 \ 2014-9~	IPDM E/R	x	x	x	
Cabstar \ F24 \ 2014-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cabstar \ F24 \ 2014-9~	Lane camera		x	x	
Cabstar \ F24 \ 2014-9~	EMCM	x	x	x	
Cabstar \ F24 \ 2014-9~	BSW/buzzer		x	x	
Cabstar \ F24 \ 2014-9~	AVM		x	x	
Cabstar \ F24 \ 2014-9~	Air bag	x	x	x	
Cabstar \ F24 \ 2014-9~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2014-9~	Difference lock	x	x	x	
Cabstar \ F24 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ F24 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
Cabstar \ F24 \ 2016-7~	Meter/M&A	x	x	x	0143, 0331
Cabstar \ F24 \ 2016-7~	BCM		x		
Cabstar \ F24 \ 2016-7~	ICC/ADAS		x	x	
Cabstar \ F24 \ 2016-7~	Transmission	x	x	x	
Cabstar \ F24 \ 2016-7~	Multi AV	x	x	x	0280
Cabstar \ F24 \ 2016-7~	IPDM E/R		x	x	

Cabstar \ F24 \ 2016-7~	Lane camera		x	x	
Cabstar \ F24 \ 2016-7~	ADCM		x	x	0090, 0313, 0198, 0183, 0184, 0255, 0091, 0256, 0254, 0095
Cabstar \ F24 \ 2016-7~	PTC heater		x	x	
Cabstar \ F24 \ 2016-7~	FSCM		x	x	
Cabstar \ F24 \ 2016-7~	Air bag	x	x	x	
Cabstar \ F24 \ 2016-7~	All mode AWD/4WD	x	x	x	
Cabstar \ F24 \ 2016-7~	Difference lock	x	x	x	
Cabstar \ TL0 \ 2003-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cabstar \ TL0 \ 2003-12~	ABS	x	x	x	0003, 0092, 0264
Cabstar \ TL0 \ 2003-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cabstar \ TL0 \ 2003-12~	BCM	x	x		
Cabstar \ TL0 \ 2003-12~	Air bag	x	x	x	
Cabstar \ TL0 \ 2003-12~	ICC/ADAS	x	x	x	
Cabstar \ TL0 \ 2003-12~	HVAC	x	x	x	
Cabstar \ TL0 \ 2003-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cabstar \ TL0 \ 2003-12~	Multi AV	x	x	x	0280
Cabstar \ TL0 \ 2003-12~	EPS/DAST 3	x	x	x	
Cabstar \ TL0 \ 2003-12~	IPDM E/R	x	x	x	
Cabstar \ TL0 \ 2003-12~	Air pressure monitor	x	x	x	
Cabstar \ TL0 \ 2003-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cabstar \ TL0 \ 2003-12~	DIU	x	x	x	
Cabstar \ TL0 \ 2003-12~	Auto slide door	x	x	x	
Cabstar \ TL0 \ 2003-12~	Auto drive position	x	x	x	
Cabstar \ TL0 \ 2003-12~	All mode AWD/4WD	x	x	x	
Cabstar \ TL0 \ 2003-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cabstar \ TL0 \ 2003-12~	Sonar	x	x	x	
Cabstar \ TL0 \ 2003-12~	Lane camera	x	x	x	
Cabstar \ TL0 \ 2003-12~	Adaptive light	x	x	x	
Cabstar \ TL0 \ 2003-12~	AVM		x	x	
Cabstar \ TL0 \ 2003-12~	Head lamp levelizer	x	x	x	
Cabstar \ TL0 \ 2003-12~	Difference lock	x	x	x	
Cabstar \ TL0 \ 2003-12~	Nats immu	x	x		
Cabstar \ TL0 \ 2003-12~	Smart entrance	x	x		
Cabstar \ TL0 \ 2003-12~	Air levelizer	x	x	x	
Cabstar \ TL0 \ 2003-12~	Rearview camera			x	
Cabstar \ TL0 \ 2003-12~	S/blind camera			x	
Cabstar \ TL0 \ 2003-12~	Motor assist	x	x	x	

Caravan \ E25 \ 2001-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2001-11~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2001-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2001-11~	BCM	x	x		
Caravan \ E25 \ 2001-11~	Air bag	x	x	x	
Caravan \ E25 \ 2001-11~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2001-11~	HVAC	x	x	x	
Caravan \ E25 \ 2001-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2001-11~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2001-11~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2001-11~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2001-11~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2001-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2001-11~	DIU	x	x	x	
Caravan \ E25 \ 2001-11~	Auto slide door	x	x	x	
Caravan \ E25 \ 2001-11~	Auto drive position	x	x	x	
Caravan \ E25 \ 2001-11~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2001-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2001-11~	Sonar	x	x	x	
Caravan \ E25 \ 2001-11~	Lane camera	x	x	x	
Caravan \ E25 \ 2001-11~	Adaptive light	x	x	x	
Caravan \ E25 \ 2001-11~	AVM		x	x	
Caravan \ E25 \ 2001-11~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2001-11~	Difference lock	x	x	x	
Caravan \ E25 \ 2001-11~	Nats immu	x	x		
Caravan \ E25 \ 2001-11~	Smart entrance	x	x		
Caravan \ E25 \ 2001-11~	Air levelizer	x	x	x	
Caravan \ E25 \ 2001-11~	Rearview camera			x	
Caravan \ E25 \ 2001-11~	S/blind camera			x	
Caravan \ E25 \ 2001-11~	Motor assist	x	x	x	
Caravan \ E25 \ 2001-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2001-4~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2001-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2001-4~	BCM	x	x		
Caravan \ E25 \ 2001-4~	Air bag	x	x	x	
Caravan \ E25 \ 2001-4~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2001-4~	HVAC	x	x	x	

Caravan \ E25 \ 2001-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2001-4~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2001-4~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2001-4~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2001-4~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2001-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2001-4~	DIU	x	x	x	
Caravan \ E25 \ 2001-4~	Auto slide door	x	x	x	
Caravan \ E25 \ 2001-4~	Auto drive position	x	x	x	
Caravan \ E25 \ 2001-4~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2001-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2001-4~	Sonar	x	x	x	
Caravan \ E25 \ 2001-4~	Lane camera	x	x	x	
Caravan \ E25 \ 2001-4~	Adaptive light	x	x	x	
Caravan \ E25 \ 2001-4~	AVM		x	x	
Caravan \ E25 \ 2001-4~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2001-4~	Difference lock	x	x	x	
Caravan \ E25 \ 2001-4~	Nats immu	x	x		
Caravan \ E25 \ 2001-4~	Smart entrance	x	x		
Caravan \ E25 \ 2001-4~	Air levelizer	x	x	x	
Caravan \ E25 \ 2001-4~	Rearview camera			x	
Caravan \ E25 \ 2001-4~	S/blind camera			x	
Caravan \ E25 \ 2001-4~	Motor assist	x	x	x	
Caravan \ E25 \ 2002-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2002-9~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2002-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2002-9~	BCM	x	x		
Caravan \ E25 \ 2002-9~	Air bag	x	x	x	
Caravan \ E25 \ 2002-9~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2002-9~	HVAC	x	x	x	
Caravan \ E25 \ 2002-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2002-9~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2002-9~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2002-9~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2002-9~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2002-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Caravan \ E25 \ 2002-9~	DIU	x	x	x	
Caravan \ E25 \ 2002-9~	Auto slide door	x	x	x	
Caravan \ E25 \ 2002-9~	Auto drive position	x	x	x	
Caravan \ E25 \ 2002-9~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2002-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2002-9~	Sonar	x	x	x	
Caravan \ E25 \ 2002-9~	Lane camera	x	x	x	
Caravan \ E25 \ 2002-9~	Adaptive light	x	x	x	
Caravan \ E25 \ 2002-9~	AVM		x	x	
Caravan \ E25 \ 2002-9~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2002-9~	Difference lock	x	x	x	
Caravan \ E25 \ 2002-9~	Nats immu	x	x		
Caravan \ E25 \ 2002-9~	Smart entrance	x	x		
Caravan \ E25 \ 2002-9~	Air levelizer	x	x	x	
Caravan \ E25 \ 2002-9~	Rearview camera			x	
Caravan \ E25 \ 2002-9~	S/blind camera			x	
Caravan \ E25 \ 2002-9~	Motor assist	x	x	x	
Caravan \ E25 \ 2003-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2003-5~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2003-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2003-5~	BCM	x	x		
Caravan \ E25 \ 2003-5~	Air bag	x	x	x	
Caravan \ E25 \ 2003-5~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2003-5~	HVAC	x	x	x	
Caravan \ E25 \ 2003-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2003-5~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2003-5~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2003-5~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2003-5~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2003-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2003-5~	DIU	x	x	x	
Caravan \ E25 \ 2003-5~	Auto slide door	x	x	x	
Caravan \ E25 \ 2003-5~	Auto drive position	x	x	x	
Caravan \ E25 \ 2003-5~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2003-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2003-5~	Sonar	x	x	x	
Caravan \ E25 \ 2003-5~	Lane camera	x	x	x	
Caravan \ E25 \ 2003-5~	Adaptive light	x	x	x	

Caravan \ E25 \ 2003-5~	AVM		x	x	
Caravan \ E25 \ 2003-5~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2003-5~	Difference lock	x	x	x	
Caravan \ E25 \ 2003-5~	Nats immu	x	x		
Caravan \ E25 \ 2003-5~	Smart entrance	x	x		
Caravan \ E25 \ 2003-5~	Air levelizer	x	x	x	
Caravan \ E25 \ 2003-5~	Rearview camera			x	
Caravan \ E25 \ 2003-5~	S/blind camera			x	
Caravan \ E25 \ 2003-5~	Motor assist	x	x	x	
Caravan \ E25 \ 2004-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2004-8~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2004-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2004-8~	BCM	x	x		
Caravan \ E25 \ 2004-8~	Air bag	x	x	x	
Caravan \ E25 \ 2004-8~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2004-8~	HVAC	x	x	x	
Caravan \ E25 \ 2004-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2004-8~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2004-8~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2004-8~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2004-8~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2004-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2004-8~	DIU	x	x	x	
Caravan \ E25 \ 2004-8~	Auto slide door	x	x	x	
Caravan \ E25 \ 2004-8~	Auto drive position	x	x	x	
Caravan \ E25 \ 2004-8~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2004-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2004-8~	Sonar	x	x	x	
Caravan \ E25 \ 2004-8~	Lane camera	x	x	x	
Caravan \ E25 \ 2004-8~	Adaptive light	x	x	x	
Caravan \ E25 \ 2004-8~	AVM		x	x	
Caravan \ E25 \ 2004-8~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2004-8~	Difference lock	x	x	x	
Caravan \ E25 \ 2004-8~	Nats immu	x	x		
Caravan \ E25 \ 2004-8~	Smart entrance	x	x		
Caravan \ E25 \ 2004-8~	Air levelizer	x	x	x	
Caravan \ E25 \ 2004-8~	Rearview camera			x	
Caravan \ E25 \ 2004-8~	S/blind camera			x	

Caravan \ E25 \ 2004-8~	Motor assist	x	x	x	
Caravan \ E25 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2005-12~	BCM	x	x		
Caravan \ E25 \ 2005-12~	Air bag	x	x	x	
Caravan \ E25 \ 2005-12~	ICC/ADAS	x	x	x	
Caravan \ E25 \ 2005-12~	HVAC	x	x	x	
Caravan \ E25 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2005-12~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2005-12~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2005-12~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2005-12~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2005-12~	DIU	x	x	x	
Caravan \ E25 \ 2005-12~	Auto slide door	x	x	x	
Caravan \ E25 \ 2005-12~	Auto drive position	x	x	x	
Caravan \ E25 \ 2005-12~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2005-12~	Sonar	x	x	x	
Caravan \ E25 \ 2005-12~	Lane camera	x	x	x	
Caravan \ E25 \ 2005-12~	Adaptive light	x	x	x	
Caravan \ E25 \ 2005-12~	AVM		x	x	
Caravan \ E25 \ 2005-12~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2005-12~	Difference lock	x	x	x	
Caravan \ E25 \ 2005-12~	Nats immu	x	x		
Caravan \ E25 \ 2005-12~	Smart entrance	x	x		
Caravan \ E25 \ 2005-12~	Air levelizer	x	x	x	
Caravan \ E25 \ 2005-12~	Rearview camera			x	
Caravan \ E25 \ 2005-12~	S/blind camera			x	
Caravan \ E25 \ 2005-12~	Motor assist	x	x	x	
Caravan \ E25 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2007-8~	ABS	x	x	x	0003, 0092, 0264
Caravan \ E25 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Caravan \ E25 \ 2007-8~	BCM	x	x		
Caravan \ E25 \ 2007-8~	Air bag	x	x	x	
Caravan \ E25 \ 2007-8~	ICC/ADAS	x	x	x	

Caravan \ E25 \ 2007-8~	HVAC	x	x	x	
Caravan \ E25 \ 2007-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Caravan \ E25 \ 2007-8~	Multi AV	x	x	x	0280
Caravan \ E25 \ 2007-8~	EPS/DAST 3	x	x	x	
Caravan \ E25 \ 2007-8~	IPDM E/R	x	x	x	
Caravan \ E25 \ 2007-8~	Air pressure monitor	x	x	x	
Caravan \ E25 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Caravan \ E25 \ 2007-8~	DIU	x	x	x	
Caravan \ E25 \ 2007-8~	Auto slide door	x	x	x	
Caravan \ E25 \ 2007-8~	Auto drive position	x	x	x	
Caravan \ E25 \ 2007-8~	All mode AWD/4WD	x	x	x	
Caravan \ E25 \ 2007-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Caravan \ E25 \ 2007-8~	Sonar	x	x	x	
Caravan \ E25 \ 2007-8~	Lane camera	x	x	x	
Caravan \ E25 \ 2007-8~	Adaptive light	x	x	x	
Caravan \ E25 \ 2007-8~	AVM		x	x	
Caravan \ E25 \ 2007-8~	Head lamp levelizer	x	x	x	
Caravan \ E25 \ 2007-8~	Difference lock	x	x	x	
Caravan \ E25 \ 2007-8~	Nats immu	x	x		
Caravan \ E25 \ 2007-8~	Smart entrance	x	x		
Caravan \ E25 \ 2007-8~	Air levelizer	x	x	x	
Caravan \ E25 \ 2007-8~	Rearview camera			x	
Caravan \ E25 \ 2007-8~	S/blind camera			x	
Caravan \ E25 \ 2007-8~	Motor assist	x	x	x	
Caravan \ E25 \ 2009-1~	Engine	x	x	x	
Caravan \ E25 \ 2009-1~	Transmission	x	x	x	
Caravan \ E25 \ 2009-1~	ABS	x	x	x	
Caravan \ E25 \ 2009-1~	Air bag	x	x	x	
Caravan \ E25 \ 2009-1~	Rearview camera			x	
Caravan \ E25 \ 2009-1~	S/blind camera			x	
Caravan \ E25 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Caravan \ E25 \ 2010-8~	ABS	x	x	x	
Caravan \ E25 \ 2010-8~	Air bag	x	x	x	
Caravan \ E25 \ 2010-8~	Transmission	x	x	x	
Caravan \ E25 \ 2010-8~	Smart entrance	x	x		
Caravan \ E25 \ 2010-8~	Rearview camera			x	
Caravan \ E25 \ 2010-8~	S/blind camera			x	

Cedric taxi \ Y31 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric taxi \ Y31 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric taxi \ Y31 \ 2011-12~	ABS	x	x	x	
Cedric taxi \ Y31 \ 2011-12~	Air bag	x	x	x	
Cedric taxi \ Y31 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric taxi \ Y31 \ 2013-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric taxi \ Y31 \ 2013-4~	All mode AWD/4WD		x	x	
Cedric taxi \ Y31 \ 2013-4~	ABS	x	x	x	
Cedric taxi \ Y31 \ 2013-4~	Air bag	x	x	x	
Cedric taxi \ Y31 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric taxi \ Y31 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cedric taxi \ Y31 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric taxi \ Y31 \ All Year	BCM	x	x		
Cedric taxi \ Y31 \ All Year	Air bag	x	x	x	
Cedric taxi \ Y31 \ All Year	ICC/ADAS	x	x	x	
Cedric taxi \ Y31 \ All Year	HVAC	x	x	x	
Cedric taxi \ Y31 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric taxi \ Y31 \ All Year	Multi AV	x	x	x	0280
Cedric taxi \ Y31 \ All Year	EPS/DAST 3	x	x	x	
Cedric taxi \ Y31 \ All Year	IPDM E/R	x	x	x	
Cedric taxi \ Y31 \ All Year	Air pressure monitor	x	x	x	
Cedric taxi \ Y31 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric taxi \ Y31 \ All Year	DIU	x	x	x	
Cedric taxi \ Y31 \ All Year	Auto slide door	x	x	x	
Cedric taxi \ Y31 \ All Year	Auto drive position	x	x	x	
Cedric taxi \ Y31 \ All Year	All mode AWD/4WD	x	x	x	
Cedric taxi \ Y31 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric taxi \ Y31 \ All Year	Sonar	x	x	x	
Cedric taxi \ Y31 \ All Year	Lane camera	x	x	x	
Cedric taxi \ Y31 \ All Year	Adaptive light	x	x	x	
Cedric taxi \ Y31 \ All Year	AVM		x	x	
Cedric taxi \ Y31 \ All Year	Head lamp levelizer	x	x	x	
Cedric taxi \ Y31 \ All Year	Difference lock	x	x	x	
Cedric taxi \ Y31 \ All Year	Nats immu	x	x		
Cedric taxi \ Y31 \ All Year	Smart entrance	x	x		
Cedric taxi \ Y31 \ All Year	Air levelizer	x	x	x	

Cedric taxi \ Y31 \ All Year	Rearview camera			x	
Cedric taxi \ Y31 \ All Year	S/blind camera			x	
Cedric taxi \ Y31 \ All Year	Motor assist	x	x	x	
Cedric \ Y31 \ 1995-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 1995-8~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 1995-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 1995-8~	BCM	x	x		
Cedric \ Y31 \ 1995-8~	Air bag	x	x	x	
Cedric \ Y31 \ 1995-8~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 1995-8~	HVAC	x	x	x	
Cedric \ Y31 \ 1995-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 1995-8~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 1995-8~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 1995-8~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 1995-8~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 1995-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 1995-8~	DIU	x	x	x	
Cedric \ Y31 \ 1995-8~	Auto slide door	x	x	x	
Cedric \ Y31 \ 1995-8~	Auto drive position	x	x	x	
Cedric \ Y31 \ 1995-8~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 1995-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 1995-8~	Sonar	x	x	x	
Cedric \ Y31 \ 1995-8~	Lane camera	x	x	x	
Cedric \ Y31 \ 1995-8~	Adaptive light	x	x	x	
Cedric \ Y31 \ 1995-8~	AVM		x	x	
Cedric \ Y31 \ 1995-8~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 1995-8~	Difference lock	x	x	x	
Cedric \ Y31 \ 1995-8~	Nats immu	x	x		
Cedric \ Y31 \ 1995-8~	Smart entrance	x	x		
Cedric \ Y31 \ 1995-8~	Air levelizer	x	x	x	
Cedric \ Y31 \ 1995-8~	Rearview camera			x	
Cedric \ Y31 \ 1995-8~	S/blind camera			x	
Cedric \ Y31 \ 1995-8~	Motor assist	x	x	x	
Cedric \ Y31 \ 1996-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 1996-9~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 1996-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 1996-9~	BCM	x	x		

Cedric \ Y31 \ 1996-9~	Air bag	x	x	x	
Cedric \ Y31 \ 1996-9~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 1996-9~	HVAC	x	x	x	
Cedric \ Y31 \ 1996-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 1996-9~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 1996-9~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 1996-9~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 1996-9~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 1996-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 1996-9~	DIU	x	x	x	
Cedric \ Y31 \ 1996-9~	Auto slide door	x	x	x	
Cedric \ Y31 \ 1996-9~	Auto drive position	x	x	x	
Cedric \ Y31 \ 1996-9~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 1996-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 1996-9~	Sonar	x	x	x	
Cedric \ Y31 \ 1996-9~	Lane camera	x	x	x	
Cedric \ Y31 \ 1996-9~	Adaptive light	x	x	x	
Cedric \ Y31 \ 1996-9~	AVM		x	x	
Cedric \ Y31 \ 1996-9~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 1996-9~	Difference lock	x	x	x	
Cedric \ Y31 \ 1996-9~	Nats immu	x	x		
Cedric \ Y31 \ 1996-9~	Smart entrance	x	x		
Cedric \ Y31 \ 1996-9~	Air levelizer	x	x	x	
Cedric \ Y31 \ 1996-9~	Rearview camera			x	
Cedric \ Y31 \ 1996-9~	S/blind camera			x	
Cedric \ Y31 \ 1996-9~	Motor assist	x	x	x	
Cedric \ Y31 \ 1998-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 1998-6~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 1998-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 1998-6~	BCM	x	x		
Cedric \ Y31 \ 1998-6~	Air bag	x	x	x	
Cedric \ Y31 \ 1998-6~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 1998-6~	HVAC	x	x	x	
Cedric \ Y31 \ 1998-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 1998-6~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 1998-6~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 1998-6~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 1998-6~	Air pressure monitor	x	x	x	

Cedric \ Y31 \ 1998-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 1998-6~	DIU	x	x	x	
Cedric \ Y31 \ 1998-6~	Auto slide door	x	x	x	
Cedric \ Y31 \ 1998-6~	Auto drive position	x	x	x	
Cedric \ Y31 \ 1998-6~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 1998-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 1998-6~	Sonar	x	x	x	
Cedric \ Y31 \ 1998-6~	Lane camera	x	x	x	
Cedric \ Y31 \ 1998-6~	Adaptive light	x	x	x	
Cedric \ Y31 \ 1998-6~	AVM		x	x	
Cedric \ Y31 \ 1998-6~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 1998-6~	Difference lock	x	x	x	
Cedric \ Y31 \ 1998-6~	Nats immu	x	x		
Cedric \ Y31 \ 1998-6~	Smart entrance	x	x		
Cedric \ Y31 \ 1998-6~	Air levelizer	x	x	x	
Cedric \ Y31 \ 1998-6~	Rearview camera			x	
Cedric \ Y31 \ 1998-6~	S/blind camera			x	
Cedric \ Y31 \ 1998-6~	Motor assist	x	x	x	
Cedric \ Y31 \ 1999-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 1999-8~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 1999-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 1999-8~	BCM	x	x		
Cedric \ Y31 \ 1999-8~	Air bag	x	x	x	
Cedric \ Y31 \ 1999-8~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 1999-8~	HVAC	x	x	x	
Cedric \ Y31 \ 1999-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 1999-8~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 1999-8~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 1999-8~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 1999-8~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 1999-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 1999-8~	DIU	x	x	x	
Cedric \ Y31 \ 1999-8~	Auto slide door	x	x	x	
Cedric \ Y31 \ 1999-8~	Auto drive position	x	x	x	
Cedric \ Y31 \ 1999-8~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 1999-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Cedric \ Y31 \ 1999-8~	Sonar	x	x	x	
Cedric \ Y31 \ 1999-8~	Lane camera	x	x	x	
Cedric \ Y31 \ 1999-8~	Adaptive light	x	x	x	
Cedric \ Y31 \ 1999-8~	AVM		x	x	
Cedric \ Y31 \ 1999-8~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 1999-8~	Difference lock	x	x	x	
Cedric \ Y31 \ 1999-8~	Nats immu	x	x		
Cedric \ Y31 \ 1999-8~	Smart entrance	x	x		
Cedric \ Y31 \ 1999-8~	Air levelizer	x	x	x	
Cedric \ Y31 \ 1999-8~	Rearview camera			x	
Cedric \ Y31 \ 1999-8~	S/blind camera			x	
Cedric \ Y31 \ 1999-8~	Motor assist	x	x	x	
Cedric \ Y31 \ 2004-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2004-1~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 2004-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 2004-1~	BCM	x	x		
Cedric \ Y31 \ 2004-1~	Air bag	x	x	x	
Cedric \ Y31 \ 2004-1~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 2004-1~	HVAC	x	x	x	
Cedric \ Y31 \ 2004-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 2004-1~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 2004-1~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 2004-1~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 2004-1~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 2004-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 2004-1~	DIU	x	x	x	
Cedric \ Y31 \ 2004-1~	Auto slide door	x	x	x	
Cedric \ Y31 \ 2004-1~	Auto drive position	x	x	x	
Cedric \ Y31 \ 2004-1~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 2004-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 2004-1~	Sonar	x	x	x	
Cedric \ Y31 \ 2004-1~	Lane camera	x	x	x	
Cedric \ Y31 \ 2004-1~	Adaptive light	x	x	x	
Cedric \ Y31 \ 2004-1~	AVM		x	x	
Cedric \ Y31 \ 2004-1~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 2004-1~	Difference lock	x	x	x	
Cedric \ Y31 \ 2004-1~	Nats immu	x	x		
Cedric \ Y31 \ 2004-1~	Smart entrance	x	x		

Cedric \ Y31 \ 2004-1~	Air levelizer	x	x	x	
Cedric \ Y31 \ 2004-1~	Rearview camera			x	
Cedric \ Y31 \ 2004-1~	S/blind camera			x	
Cedric \ Y31 \ 2004-1~	Motor assist	x	x	x	
Cedric \ Y31 \ 2005-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2005-11~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 2005-11~	BCM	x	x		
Cedric \ Y31 \ 2005-11~	Air bag	x	x	x	
Cedric \ Y31 \ 2005-11~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 2005-11~	HVAC	x	x	x	
Cedric \ Y31 \ 2005-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 2005-11~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 2005-11~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 2005-11~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 2005-11~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 2005-11~	DIU	x	x	x	
Cedric \ Y31 \ 2005-11~	Auto slide door	x	x	x	
Cedric \ Y31 \ 2005-11~	Auto drive position	x	x	x	
Cedric \ Y31 \ 2005-11~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 2005-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 2005-11~	Sonar	x	x	x	
Cedric \ Y31 \ 2005-11~	Lane camera	x	x	x	
Cedric \ Y31 \ 2005-11~	Adaptive light	x	x	x	
Cedric \ Y31 \ 2005-11~	AVM		x	x	
Cedric \ Y31 \ 2005-11~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 2005-11~	Difference lock	x	x	x	
Cedric \ Y31 \ 2005-11~	Nats immu	x	x		
Cedric \ Y31 \ 2005-11~	Smart entrance	x	x		
Cedric \ Y31 \ 2005-11~	Air levelizer	x	x	x	
Cedric \ Y31 \ 2005-11~	Rearview camera			x	
Cedric \ Y31 \ 2005-11~	S/blind camera			x	
Cedric \ Y31 \ 2005-11~	Motor assist	x	x	x	
Cedric \ Y31 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Cedric \ Y31 \ 2007-7~	BCM	x	x		
Cedric \ Y31 \ 2007-7~	Air bag	x	x	x	
Cedric \ Y31 \ 2007-7~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 2007-7~	HVAC	x	x	x	
Cedric \ Y31 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 2007-7~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 2007-7~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 2007-7~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 2007-7~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 2007-7~	DIU	x	x	x	
Cedric \ Y31 \ 2007-7~	Auto slide door	x	x	x	
Cedric \ Y31 \ 2007-7~	Auto drive position	x	x	x	
Cedric \ Y31 \ 2007-7~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 2007-7~	Sonar	x	x	x	
Cedric \ Y31 \ 2007-7~	Lane camera	x	x	x	
Cedric \ Y31 \ 2007-7~	Adaptive light	x	x	x	
Cedric \ Y31 \ 2007-7~	AVM		x	x	
Cedric \ Y31 \ 2007-7~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 2007-7~	Difference lock	x	x	x	
Cedric \ Y31 \ 2007-7~	Nats immu	x	x		
Cedric \ Y31 \ 2007-7~	Smart entrance	x	x		
Cedric \ Y31 \ 2007-7~	Air levelizer	x	x	x	
Cedric \ Y31 \ 2007-7~	Rearview camera			x	
Cedric \ Y31 \ 2007-7~	S/blind camera			x	
Cedric \ Y31 \ 2007-7~	Motor assist	x	x	x	
Cedric \ Y31 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 2009-8~	BCM	x	x		
Cedric \ Y31 \ 2009-8~	Air bag	x	x	x	
Cedric \ Y31 \ 2009-8~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 2009-8~	HVAC	x	x	x	
Cedric \ Y31 \ 2009-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 2009-8~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 2009-8~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 2009-8~	IPDM E/R	x	x	x	

Cedric \ Y31 \ 2009-8~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 2009-8~	DIU	x	x	x	
Cedric \ Y31 \ 2009-8~	Auto slide door	x	x	x	
Cedric \ Y31 \ 2009-8~	Auto drive position	x	x	x	
Cedric \ Y31 \ 2009-8~	All mode AWD/4WD	x	x	x	
Cedric \ Y31 \ 2009-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 2009-8~	Sonar	x	x	x	
Cedric \ Y31 \ 2009-8~	Lane camera	x	x	x	
Cedric \ Y31 \ 2009-8~	Adaptive light	x	x	x	
Cedric \ Y31 \ 2009-8~	AVM		x	x	
Cedric \ Y31 \ 2009-8~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 2009-8~	Difference lock	x	x	x	
Cedric \ Y31 \ 2009-8~	Nats immu	x	x		
Cedric \ Y31 \ 2009-8~	Smart entrance	x	x		
Cedric \ Y31 \ 2009-8~	Air levelizer	x	x	x	
Cedric \ Y31 \ 2009-8~	Rearview camera			x	
Cedric \ Y31 \ 2009-8~	S/blind camera			x	
Cedric \ Y31 \ 2009-8~	Motor assist	x	x	x	
Cedric \ Y31 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Cedric \ Y31 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 2010-8~	BCM	x	x		
Cedric \ Y31 \ 2010-8~	Air bag	x	x	x	
Cedric \ Y31 \ 2010-8~	ICC/ADAS	x	x	x	
Cedric \ Y31 \ 2010-8~	HVAC	x	x	x	
Cedric \ Y31 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric \ Y31 \ 2010-8~	Multi AV	x	x	x	0280
Cedric \ Y31 \ 2010-8~	EPS/DAST 3	x	x	x	
Cedric \ Y31 \ 2010-8~	IPDM E/R	x	x	x	
Cedric \ Y31 \ 2010-8~	Air pressure monitor	x	x	x	
Cedric \ Y31 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric \ Y31 \ 2010-8~	DIU	x	x	x	
Cedric \ Y31 \ 2010-8~	Auto slide door	x	x	x	
Cedric \ Y31 \ 2010-8~	Auto drive position	x	x	x	
Cedric \ Y31 \ 2010-8~	All mode AWD/4WD	x	x	x	

Cedric \ Y31 \ 2010-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric \ Y31 \ 2010-8~	Sonar	x	x	x	
Cedric \ Y31 \ 2010-8~	Lane camera	x	x	x	
Cedric \ Y31 \ 2010-8~	Adaptive light	x	x	x	
Cedric \ Y31 \ 2010-8~	AVM		x	x	
Cedric \ Y31 \ 2010-8~	Head lamp levelizer	x	x	x	
Cedric \ Y31 \ 2010-8~	Difference lock	x	x	x	
Cedric \ Y31 \ 2010-8~	Nats immu	x	x		
Cedric \ Y31 \ 2010-8~	Smart entrance	x	x		
Cedric \ Y31 \ 2010-8~	Air levelizer	x	x	x	
Cedric \ Y31 \ 2010-8~	Rearview camera			x	
Cedric \ Y31 \ 2010-8~	S/blind camera			x	
Cedric \ Y31 \ 2010-8~	Motor assist	x	x	x	
Cedric \ Y31 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric \ Y31 \ 2012-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric \ Y31 \ 2012-5~	ABS	x	x	x	
Cedric \ Y31 \ 2012-5~	Air bag	x	x	x	
Cedric-gloria \ Y33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric-gloria \ Y33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cedric-gloria \ Y33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric-gloria \ Y33 \ All Year	BCM	x	x		
Cedric-gloria \ Y33 \ All Year	Air bag	x	x	x	
Cedric-gloria \ Y33 \ All Year	ICC/ADAS	x	x	x	
Cedric-gloria \ Y33 \ All Year	HVAC	x	x	x	
Cedric-gloria \ Y33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric-gloria \ Y33 \ All Year	Multi AV	x	x	x	0280
Cedric-gloria \ Y33 \ All Year	EPS/DAST 3	x	x	x	
Cedric-gloria \ Y33 \ All Year	IPDM E/R	x	x	x	
Cedric-gloria \ Y33 \ All Year	Air pressure monitor	x	x	x	
Cedric-gloria \ Y33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric-gloria \ Y33 \ All Year	DIU	x	x	x	
Cedric-gloria \ Y33 \ All Year	Auto slide door	x	x	x	
Cedric-gloria \ Y33 \ All Year	Auto drive position	x	x	x	
Cedric-gloria \ Y33 \ All Year	All mode AWD/4WD	x	x	x	
Cedric-gloria \ Y33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric-gloria \ Y33 \ All Year	Sonar	x	x	x	
Cedric-gloria \ Y33 \ All Year	Lane camera	x	x	x	

Cedric-gloria \ Y33 \ All Year	Adaptive light	x	x	x	
Cedric-gloria \ Y33 \ All Year	AVM		x	x	
Cedric-gloria \ Y33 \ All Year	Head lamp levelizer	x	x	x	
Cedric-gloria \ Y33 \ All Year	Difference lock	x	x	x	
Cedric-gloria \ Y33 \ All Year	Nats immu	x	x		
Cedric-gloria \ Y33 \ All Year	Smart entrance	x	x		
Cedric-gloria \ Y33 \ All Year	Air levelizer	x	x	x	
Cedric-gloria \ Y33 \ All Year	Rearview camera			x	
Cedric-gloria \ Y33 \ All Year	S/blind camera			x	
Cedric-gloria \ Y33 \ All Year	Motor assist	x	x	x	
Cedric-gloria \ Y34 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cedric-gloria \ Y34 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cedric-gloria \ Y34 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cedric-gloria \ Y34 \ All Year	BCM	x	x		
Cedric-gloria \ Y34 \ All Year	Air bag	x	x	x	
Cedric-gloria \ Y34 \ All Year	ICC/ADAS	x	x	x	
Cedric-gloria \ Y34 \ All Year	HVAC	x	x	x	
Cedric-gloria \ Y34 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cedric-gloria \ Y34 \ All Year	Multi AV	x	x	x	0280
Cedric-gloria \ Y34 \ All Year	EPS/DAST 3	x	x	x	
Cedric-gloria \ Y34 \ All Year	IPDM E/R	x	x	x	
Cedric-gloria \ Y34 \ All Year	Air pressure monitor	x	x	x	
Cedric-gloria \ Y34 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cedric-gloria \ Y34 \ All Year	DIU	x	x	x	
Cedric-gloria \ Y34 \ All Year	Auto slide door	x	x	x	
Cedric-gloria \ Y34 \ All Year	Auto drive position	x	x	x	
Cedric-gloria \ Y34 \ All Year	All mode AWD/4WD	x	x	x	
Cedric-gloria \ Y34 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cedric-gloria \ Y34 \ All Year	Sonar	x	x	x	
Cedric-gloria \ Y34 \ All Year	Lane camera	x	x	x	
Cedric-gloria \ Y34 \ All Year	Adaptive light	x	x	x	
Cedric-gloria \ Y34 \ All Year	AVM		x	x	
Cedric-gloria \ Y34 \ All Year	Head lamp levelizer	x	x	x	
Cedric-gloria \ Y34 \ All Year	Difference lock	x	x	x	
Cedric-gloria \ Y34 \ All Year	Nats immu	x	x		
Cedric-gloria \ Y34 \ All Year	Smart entrance	x	x		
Cedric-gloria \ Y34 \ All Year	Air levelizer	x	x	x	
Cedric-gloria \ Y34 \ All Year	Rearview camera			x	

Cedric-gloria \ Y34 \ All Year	S/blind camera			x	
Cedric-gloria \ Y34 \ All Year	Motor assist	x	x	x	
Cefiro \ A32 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cefiro \ A32 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cefiro \ A32 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cefiro \ A32 \ All Year	BCM	x	x		
Cefiro \ A32 \ All Year	Air bag	x	x	x	
Cefiro \ A32 \ All Year	ICC/ADAS	x	x	x	
Cefiro \ A32 \ All Year	HVAC	x	x	x	
Cefiro \ A32 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cefiro \ A32 \ All Year	Multi AV	x	x	x	0280
Cefiro \ A32 \ All Year	EPS/DAST 3	x	x	x	
Cefiro \ A32 \ All Year	IPDM E/R	x	x	x	
Cefiro \ A32 \ All Year	Air pressure monitor	x	x	x	
Cefiro \ A32 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cefiro \ A32 \ All Year	DIU	x	x	x	
Cefiro \ A32 \ All Year	Auto slide door	x	x	x	
Cefiro \ A32 \ All Year	Auto drive position	x	x	x	
Cefiro \ A32 \ All Year	All mode AWD/4WD	x	x	x	
Cefiro \ A32 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cefiro \ A32 \ All Year	Sonar	x	x	x	
Cefiro \ A32 \ All Year	Lane camera	x	x	x	
Cefiro \ A32 \ All Year	Adaptive light	x	x	x	
Cefiro \ A32 \ All Year	AVM		x	x	
Cefiro \ A32 \ All Year	Head lamp levelizer	x	x	x	
Cefiro \ A32 \ All Year	Difference lock	x	x	x	
Cefiro \ A32 \ All Year	Nats immu	x	x		
Cefiro \ A32 \ All Year	Smart entrance	x	x		
Cefiro \ A32 \ All Year	Air levelizer	x	x	x	
Cefiro \ A32 \ All Year	Rearview camera			x	
Cefiro \ A32 \ All Year	S/blind camera			x	
Cefiro \ A32 \ All Year	Motor assist	x	x	x	
Cefiro \ A33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cefiro \ A33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cefiro \ A33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cefiro \ A33 \ All Year	BCM	x	x		
Cefiro \ A33 \ All Year	Air bag	x	x	x	

Cefiro \ A33 \ All Year	ICC/ADAS	x	x	x	
Cefiro \ A33 \ All Year	HVAC	x	x	x	
Cefiro \ A33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cefiro \ A33 \ All Year	Multi AV	x	x	x	0280
Cefiro \ A33 \ All Year	EPS/DAST 3	x	x	x	
Cefiro \ A33 \ All Year	IPDM E/R	x	x	x	
Cefiro \ A33 \ All Year	Air pressure monitor	x	x	x	
Cefiro \ A33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cefiro \ A33 \ All Year	DIU	x	x	x	
Cefiro \ A33 \ All Year	Auto slide door	x	x	x	
Cefiro \ A33 \ All Year	Auto drive position	x	x	x	
Cefiro \ A33 \ All Year	All mode AWD/4WD	x	x	x	
Cefiro \ A33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cefiro \ A33 \ All Year	Sonar	x	x	x	
Cefiro \ A33 \ All Year	Lane camera	x	x	x	
Cefiro \ A33 \ All Year	Adaptive light	x	x	x	
Cefiro \ A33 \ All Year	AVM		x	x	
Cefiro \ A33 \ All Year	Head lamp levelizer	x	x	x	
Cefiro \ A33 \ All Year	Difference lock	x	x	x	
Cefiro \ A33 \ All Year	Nats immu	x	x		
Cefiro \ A33 \ All Year	Smart entrance	x	x		
Cefiro \ A33 \ All Year	Air levelizer	x	x	x	
Cefiro \ A33 \ All Year	Rearview camera			x	
Cefiro \ A33 \ All Year	S/blind camera			x	
Cefiro \ A33 \ All Year	Motor assist	x	x	x	
Cefiro \ J31 \ 2003-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cefiro \ J31 \ 2003-9~	ABS	x	x	x	0003, 0092, 0264
Cefiro \ J31 \ 2003-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cefiro \ J31 \ 2003-9~	BCM	x	x		
Cefiro \ J31 \ 2003-9~	Air bag	x	x	x	
Cefiro \ J31 \ 2003-9~	ICC/ADAS	x	x	x	
Cefiro \ J31 \ 2003-9~	HVAC	x	x	x	
Cefiro \ J31 \ 2003-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cefiro \ J31 \ 2003-9~	Multi AV	x	x	x	0280
Cefiro \ J31 \ 2003-9~	EPS/DAST 3	x	x	x	
Cefiro \ J31 \ 2003-9~	IPDM E/R	x	x	x	
Cefiro \ J31 \ 2003-9~	Air pressure monitor	x	x	x	

Cefiro \ J31 \ 2003-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cefiro \ J31 \ 2003-9~	DIU	x	x	x	
Cefiro \ J31 \ 2003-9~	Auto slide door	x	x	x	
Cefiro \ J31 \ 2003-9~	Auto drive position	x	x	x	
Cefiro \ J31 \ 2003-9~	All mode AWD/4WD	x	x	x	
Cefiro \ J31 \ 2003-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cefiro \ J31 \ 2003-9~	Sonar	x	x	x	
Cefiro \ J31 \ 2003-9~	Lane camera	x	x	x	
Cefiro \ J31 \ 2003-9~	Adaptive light	x	x	x	
Cefiro \ J31 \ 2003-9~	AVM		x	x	
Cefiro \ J31 \ 2003-9~	Head lamp levelizer	x	x	x	
Cefiro \ J31 \ 2003-9~	Difference lock	x	x	x	
Cefiro \ J31 \ 2003-9~	Nats immu	x	x		
Cefiro \ J31 \ 2003-9~	Smart entrance	x	x		
Cefiro \ J31 \ 2003-9~	Air levelizer	x	x	x	
Cefiro \ J31 \ 2003-9~	Rearview camera			x	
Cefiro \ J31 \ 2003-9~	S/blind camera			x	
Cefiro \ J31 \ 2003-9~	Motor assist	x	x	x	
Cefiro \ J31 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cefiro \ J31 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Cefiro \ J31 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cefiro \ J31 \ 2005-12~	BCM	x	x		
Cefiro \ J31 \ 2005-12~	Air bag	x	x	x	
Cefiro \ J31 \ 2005-12~	ICC/ADAS	x	x	x	
Cefiro \ J31 \ 2005-12~	HVAC	x	x	x	
Cefiro \ J31 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cefiro \ J31 \ 2005-12~	Multi AV	x	x	x	0280
Cefiro \ J31 \ 2005-12~	EPS/DAST 3	x	x	x	
Cefiro \ J31 \ 2005-12~	IPDM E/R	x	x	x	
Cefiro \ J31 \ 2005-12~	Air pressure monitor	x	x	x	
Cefiro \ J31 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cefiro \ J31 \ 2005-12~	DIU	x	x	x	
Cefiro \ J31 \ 2005-12~	Auto slide door	x	x	x	
Cefiro \ J31 \ 2005-12~	Auto drive position	x	x	x	
Cefiro \ J31 \ 2005-12~	All mode AWD/4WD	x	x	x	
Cefiro \ J31 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Cefiro \ J31 \ 2005-12~	Sonar	x	x	x	
Cefiro \ J31 \ 2005-12~	Lane camera	x	x	x	
Cefiro \ J31 \ 2005-12~	Adaptive light	x	x	x	
Cefiro \ J31 \ 2005-12~	AVM		x	x	
Cefiro \ J31 \ 2005-12~	Head lamp levelizer	x	x	x	
Cefiro \ J31 \ 2005-12~	Difference lock	x	x	x	
Cefiro \ J31 \ 2005-12~	Nats immu	x	x		
Cefiro \ J31 \ 2005-12~	Smart entrance	x	x		
Cefiro \ J31 \ 2005-12~	Air levelizer	x	x	x	
Cefiro \ J31 \ 2005-12~	Rearview camera			x	
Cefiro \ J31 \ 2005-12~	S/blind camera			x	
Cefiro \ J31 \ 2005-12~	Motor assist	x	x	x	
Cefiro \ J32 \ 2008-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cefiro \ J32 \ 2008-2~	ABS	x	x	x	0003, 0092, 0264
Cefiro \ J32 \ 2008-2~	Meter/M&A		x	x	
Cefiro \ J32 \ 2008-2~	BCM		x		
Cefiro \ J32 \ 2008-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Cefiro \ J32 \ 2008-2~	Transmission	x	x	x	
Cefiro \ J32 \ 2008-2~	Multi AV	x	x	x	
Cefiro \ J32 \ 2008-2~	IPDM E/R		x	x	
Cefiro \ J32 \ 2008-2~	Auto drive position		x	x	
Cefiro \ J32 \ 2008-2~	Adaptive light	x	x	x	
Cefiro \ J32 \ 2008-2~	Air bag	x	x	x	
Cefiro \ J32 \ 2008-2~	Head lamp levelizer	x	x	x	
Cefiro \ J32 \ 2008-2~	Sonar	x	x	x	
Cefiro \ J32 \ 2008-2~	Rearview camera			x	
Cima \ F50 \ 2001-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ 2001-12~	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ 2001-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ F50 \ 2001-12~	BCM	x	x		
Cima \ F50 \ 2001-12~	Air bag	x	x	x	
Cima \ F50 \ 2001-12~	ICC/ADAS	x	x	x	
Cima \ F50 \ 2001-12~	HVAC	x	x	x	
Cima \ F50 \ 2001-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ 2001-12~	Multi AV	x	x	x	0280
Cima \ F50 \ 2001-12~	EPS/DAST 3	x	x	x	
Cima \ F50 \ 2001-12~	IPDM E/R	x	x	x	
Cima \ F50 \ 2001-12~	Air pressure monitor	x	x	x	

Cima \ F50 \ 2001-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ 2001-12~	DIU	x	x	x	
Cima \ F50 \ 2001-12~	Auto slide door	x	x	x	
Cima \ F50 \ 2001-12~	Auto drive position	x	x	x	
Cima \ F50 \ 2001-12~	All mode AWD/4WD	x	x	x	
Cima \ F50 \ 2001-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ F50 \ 2001-12~	Sonar	x	x	x	
Cima \ F50 \ 2001-12~	Lane camera	x	x	x	
Cima \ F50 \ 2001-12~	Adaptive light	x	x	x	
Cima \ F50 \ 2001-12~	AVM		x	x	
Cima \ F50 \ 2001-12~	Head lamp levelizer	x	x	x	
Cima \ F50 \ 2001-12~	Difference lock	x	x	x	
Cima \ F50 \ 2001-12~	Nats immu	x	x		
Cima \ F50 \ 2001-12~	Smart entrance	x	x		
Cima \ F50 \ 2001-12~	Air levelizer	x	x	x	
Cima \ F50 \ 2001-12~	Rearview camera			x	
Cima \ F50 \ 2001-12~	S/blind camera			x	
Cima \ F50 \ 2001-12~	Motor assist	x	x	x	
Cima \ F50 \ 2001-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ 2001-1~	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ 2001-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ F50 \ 2001-1~	BCM	x	x		
Cima \ F50 \ 2001-1~	Air bag	x	x	x	
Cima \ F50 \ 2001-1~	ICC/ADAS	x	x	x	
Cima \ F50 \ 2001-1~	HVAC	x	x	x	
Cima \ F50 \ 2001-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ 2001-1~	Multi AV	x	x	x	0280
Cima \ F50 \ 2001-1~	EPS/DAST 3	x	x	x	
Cima \ F50 \ 2001-1~	IPDM E/R	x	x	x	
Cima \ F50 \ 2001-1~	Air pressure monitor	x	x	x	
Cima \ F50 \ 2001-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ 2001-1~	DIU	x	x	x	
Cima \ F50 \ 2001-1~	Auto slide door	x	x	x	
Cima \ F50 \ 2001-1~	Auto drive position	x	x	x	
Cima \ F50 \ 2001-1~	All mode AWD/4WD	x	x	x	
Cima \ F50 \ 2001-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Cima \ F50 \ 2001-1~	Sonar	x	x	x	
Cima \ F50 \ 2001-1~	Lane camera	x	x	x	
Cima \ F50 \ 2001-1~	Adaptive light	x	x	x	
Cima \ F50 \ 2001-1~	AVM		x	x	
Cima \ F50 \ 2001-1~	Head lamp levelizer	x	x	x	
Cima \ F50 \ 2001-1~	Difference lock	x	x	x	
Cima \ F50 \ 2001-1~	Nats immu	x	x		
Cima \ F50 \ 2001-1~	Smart entrance	x	x		
Cima \ F50 \ 2001-1~	Air levelizer	x	x	x	
Cima \ F50 \ 2001-1~	Rearview camera			x	
Cima \ F50 \ 2001-1~	S/blind camera			x	
Cima \ F50 \ 2001-1~	Motor assist	x	x	x	
Cima \ F50 \ 2003-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ 2003-8~	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ 2003-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ F50 \ 2003-8~	BCM	x	x		
Cima \ F50 \ 2003-8~	Air bag	x	x	x	
Cima \ F50 \ 2003-8~	ICC/ADAS	x	x	x	
Cima \ F50 \ 2003-8~	HVAC	x	x	x	
Cima \ F50 \ 2003-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ 2003-8~	Multi AV	x	x	x	0280
Cima \ F50 \ 2003-8~	EPS/DAST 3	x	x	x	
Cima \ F50 \ 2003-8~	IPDM E/R	x	x	x	
Cima \ F50 \ 2003-8~	Air pressure monitor	x	x	x	
Cima \ F50 \ 2003-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ 2003-8~	DIU	x	x	x	
Cima \ F50 \ 2003-8~	Auto slide door	x	x	x	
Cima \ F50 \ 2003-8~	Auto drive position	x	x	x	
Cima \ F50 \ 2003-8~	All mode AWD/4WD	x	x	x	
Cima \ F50 \ 2003-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ F50 \ 2003-8~	Sonar	x	x	x	
Cima \ F50 \ 2003-8~	Lane camera	x	x	x	
Cima \ F50 \ 2003-8~	Adaptive light	x	x	x	
Cima \ F50 \ 2003-8~	AVM		x	x	
Cima \ F50 \ 2003-8~	Head lamp levelizer	x	x	x	
Cima \ F50 \ 2003-8~	Difference lock	x	x	x	
Cima \ F50 \ 2003-8~	Nats immu	x	x		
Cima \ F50 \ 2003-8~	Smart entrance	x	x		

Cima \ F50 \ 2003-8~	Air levelizer	x	x	x	
Cima \ F50 \ 2003-8~	Rearview camera			x	
Cima \ F50 \ 2003-8~	S/blind camera			x	
Cima \ F50 \ 2003-8~	Motor assist	x	x	x	
Cima \ F50 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ F50 \ 2005-12~	BCM	x	x		
Cima \ F50 \ 2005-12~	Air bag	x	x	x	
Cima \ F50 \ 2005-12~	ICC/ADAS	x	x	x	
Cima \ F50 \ 2005-12~	HVAC	x	x	x	
Cima \ F50 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ 2005-12~	Multi AV	x	x	x	0280
Cima \ F50 \ 2005-12~	EPS/DAST 3	x	x	x	
Cima \ F50 \ 2005-12~	IPDM E/R	x	x	x	
Cima \ F50 \ 2005-12~	Air pressure monitor	x	x	x	
Cima \ F50 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ 2005-12~	DIU	x	x	x	
Cima \ F50 \ 2005-12~	Auto slide door	x	x	x	
Cima \ F50 \ 2005-12~	Auto drive position	x	x	x	
Cima \ F50 \ 2005-12~	All mode AWD/4WD	x	x	x	
Cima \ F50 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ F50 \ 2005-12~	Sonar	x	x	x	
Cima \ F50 \ 2005-12~	Lane camera	x	x	x	
Cima \ F50 \ 2005-12~	Adaptive light	x	x	x	
Cima \ F50 \ 2005-12~	AVM		x	x	
Cima \ F50 \ 2005-12~	Head lamp levelizer	x	x	x	
Cima \ F50 \ 2005-12~	Difference lock	x	x	x	
Cima \ F50 \ 2005-12~	Nats immu	x	x		
Cima \ F50 \ 2005-12~	Smart entrance	x	x		
Cima \ F50 \ 2005-12~	Air levelizer	x	x	x	
Cima \ F50 \ 2005-12~	Rearview camera			x	
Cima \ F50 \ 2005-12~	S/blind camera			x	
Cima \ F50 \ 2005-12~	Motor assist	x	x	x	
Cima \ F50 \ 2008-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ 2008-1~	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Cima \ F50 \ 2008-1~	BCM	x	x		
Cima \ F50 \ 2008-1~	Air bag	x	x	x	
Cima \ F50 \ 2008-1~	ICC/ADAS	x	x	x	
Cima \ F50 \ 2008-1~	HVAC	x	x	x	
Cima \ F50 \ 2008-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ 2008-1~	Multi AV	x	x	x	0280
Cima \ F50 \ 2008-1~	EPS/DAST 3	x	x	x	
Cima \ F50 \ 2008-1~	IPDM E/R	x	x	x	
Cima \ F50 \ 2008-1~	Air pressure monitor	x	x	x	
Cima \ F50 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ 2008-1~	DIU	x	x	x	
Cima \ F50 \ 2008-1~	Auto slide door	x	x	x	
Cima \ F50 \ 2008-1~	Auto drive position	x	x	x	
Cima \ F50 \ 2008-1~	All mode AWD/4WD	x	x	x	
Cima \ F50 \ 2008-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ F50 \ 2008-1~	Sonar	x	x	x	
Cima \ F50 \ 2008-1~	Lane camera	x	x	x	
Cima \ F50 \ 2008-1~	Adaptive light	x	x	x	
Cima \ F50 \ 2008-1~	AVM		x	x	
Cima \ F50 \ 2008-1~	Head lamp levelizer	x	x	x	
Cima \ F50 \ 2008-1~	Difference lock	x	x	x	
Cima \ F50 \ 2008-1~	Nats immu	x	x		
Cima \ F50 \ 2008-1~	Smart entrance	x	x		
Cima \ F50 \ 2008-1~	Air levelizer	x	x	x	
Cima \ F50 \ 2008-1~	Rearview camera			x	
Cima \ F50 \ 2008-1~	S/blind camera			x	
Cima \ F50 \ 2008-1~	Motor assist	x	x	x	
Cima \ F50 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ F50 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cima \ F50 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ F50 \ All Year	BCM	x	x		
Cima \ F50 \ All Year	Air bag	x	x	x	
Cima \ F50 \ All Year	ICC/ADAS	x	x	x	
Cima \ F50 \ All Year	HVAC	x	x	x	
Cima \ F50 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ F50 \ All Year	Multi AV	x	x	x	0280
Cima \ F50 \ All Year	EPS/DAST 3	x	x	x	
Cima \ F50 \ All Year	IPDM E/R	x	x	x	

Cima \ F50 \ All Year	Air pressure monitor	x	x	x	
Cima \ F50 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ F50 \ All Year	DIU	x	x	x	
Cima \ F50 \ All Year	Auto slide door	x	x	x	
Cima \ F50 \ All Year	Auto drive position	x	x	x	
Cima \ F50 \ All Year	All mode AWD/4WD	x	x	x	
Cima \ F50 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ F50 \ All Year	Sonar	x	x	x	
Cima \ F50 \ All Year	Lane camera	x	x	x	
Cima \ F50 \ All Year	Adaptive light	x	x	x	
Cima \ F50 \ All Year	AVM		x	x	
Cima \ F50 \ All Year	Head lamp levelizer	x	x	x	
Cima \ F50 \ All Year	Difference lock	x	x	x	
Cima \ F50 \ All Year	Nats immu	x	x		
Cima \ F50 \ All Year	Smart entrance	x	x		
Cima \ F50 \ All Year	Air levelizer	x	x	x	
Cima \ F50 \ All Year	Rearview camera			x	
Cima \ F50 \ All Year	S/blind camera			x	
Cima \ F50 \ All Year	Motor assist	x	x	x	
Cima \ FY33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ FY33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cima \ FY33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cima \ FY33 \ All Year	BCM	x	x		
Cima \ FY33 \ All Year	Air bag	x	x	x	
Cima \ FY33 \ All Year	ICC/ADAS	x	x	x	
Cima \ FY33 \ All Year	HVAC	x	x	x	
Cima \ FY33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cima \ FY33 \ All Year	Multi AV	x	x	x	0280
Cima \ FY33 \ All Year	EPS/DAST 3	x	x	x	
Cima \ FY33 \ All Year	IPDM E/R	x	x	x	
Cima \ FY33 \ All Year	Air pressure monitor	x	x	x	
Cima \ FY33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cima \ FY33 \ All Year	DIU	x	x	x	
Cima \ FY33 \ All Year	Auto slide door	x	x	x	
Cima \ FY33 \ All Year	Auto drive position	x	x	x	
Cima \ FY33 \ All Year	All mode AWD/4WD	x	x	x	

Cima \ FY33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cima \ FY33 \ All Year	Sonar	x	x	x	
Cima \ FY33 \ All Year	Lane camera	x	x	x	
Cima \ FY33 \ All Year	Adaptive light	x	x	x	
Cima \ FY33 \ All Year	AVM		x	x	
Cima \ FY33 \ All Year	Head lamp levelizer	x	x	x	
Cima \ FY33 \ All Year	Difference lock	x	x	x	
Cima \ FY33 \ All Year	Nats immu	x	x		
Cima \ FY33 \ All Year	Smart entrance	x	x		
Cima \ FY33 \ All Year	Air levelizer	x	x	x	
Cima \ FY33 \ All Year	Rearview camera			x	
Cima \ FY33 \ All Year	S/blind camera			x	
Cima \ FY33 \ All Year	Motor assist	x	x	x	
Cima \ HGY51 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cima \ HGY51 \ 2012-4~	ABS	x	x	x	
Cima \ HGY51 \ 2012-4~	Meter/M&A		x	x	
Cima \ HGY51 \ 2012-4~	BCM		x		
Cima \ HGY51 \ 2012-4~	Air bag	x	x	x	
Cima \ HGY51 \ 2012-4~	ICC/ADAS		x	x	
Cima \ HGY51 \ 2012-4~	HVAC		x	x	
Cima \ HGY51 \ 2012-4~	Transmission		x	x	0059
Cima \ HGY51 \ 2012-4~	Multi AV		x	x	
Cima \ HGY51 \ 2012-4~	Motor control		x	x	
Cima \ HGY51 \ 2012-4~	EPS/DAST 3		x	x	
Cima \ HGY51 \ 2012-4~	IPDM E/R		x	x	
Cima \ HGY51 \ 2012-4~	Air pressure monitor	x	x	x	
Cima \ HGY51 \ 2012-4~	Laser/radar	x	x	x	
Cima \ HGY51 \ 2012-4~	Precrash seatbelt		x	x	
Cima \ HGY51 \ 2012-4~	Auto drive position		x	x	
Cima \ HGY51 \ 2012-4~	Lane camera		x	x	
Cima \ HGY51 \ 2012-4~	Adaptive light	x	x	x	
Cima \ HGY51 \ 2012-4~	CAN gateway		x		
Cima \ HGY51 \ 2012-4~	EV/HEV		x	x	
Cima \ HGY51 \ 2012-4~	Accele pedal ACT		x	x	
Cima \ HGY51 \ 2012-4~	HV battery		x	x	
Cima \ HGY51 \ 2012-4~	Brake		x	x	
Cima \ HGY51 \ 2012-4~	Head lamp levelizer	x	x	x	
Cima \ HGY51 \ 2012-4~	Pop up hood	x	x	x	
Cima \ HGY51 \ 2012-4~	VSP	x	x	x	

Civilian \ W41 \ 1994-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 1994-4~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 1994-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 1994-4~	BCM	x	x		
Civilian \ W41 \ 1994-4~	Air bag	x	x	x	
Civilian \ W41 \ 1994-4~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 1994-4~	HVAC	x	x	x	
Civilian \ W41 \ 1994-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 1994-4~	Multi AV	x	x	x	0280
Civilian \ W41 \ 1994-4~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 1994-4~	IPDM E/R	x	x	x	
Civilian \ W41 \ 1994-4~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 1994-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 1994-4~	DIU	x	x	x	
Civilian \ W41 \ 1994-4~	Auto slide door	x	x	x	
Civilian \ W41 \ 1994-4~	Auto drive position	x	x	x	
Civilian \ W41 \ 1994-4~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 1994-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 1994-4~	Sonar	x	x	x	
Civilian \ W41 \ 1994-4~	Lane camera	x	x	x	
Civilian \ W41 \ 1994-4~	Adaptive light	x	x	x	
Civilian \ W41 \ 1994-4~	AVM		x	x	
Civilian \ W41 \ 1994-4~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 1994-4~	Difference lock	x	x	x	
Civilian \ W41 \ 1994-4~	Nats immu	x	x		
Civilian \ W41 \ 1994-4~	Smart entrance	x	x		
Civilian \ W41 \ 1994-4~	Air levelizer	x	x	x	
Civilian \ W41 \ 1994-4~	Rearview camera			x	
Civilian \ W41 \ 1994-4~	S/blind camera			x	
Civilian \ W41 \ 1994-4~	Motor assist	x	x	x	
Civilian \ W41 \ 1999-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 1999-11~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 1999-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 1999-11~	BCM	x	x		
Civilian \ W41 \ 1999-11~	Air bag	x	x	x	
Civilian \ W41 \ 1999-11~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 1999-11~	HVAC	x	x	x	

Civilian \ W41 \ 1999-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 1999-11~	Multi AV	x	x	x	0280
Civilian \ W41 \ 1999-11~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 1999-11~	IPDM E/R	x	x	x	
Civilian \ W41 \ 1999-11~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 1999-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 1999-11~	DIU	x	x	x	
Civilian \ W41 \ 1999-11~	Auto slide door	x	x	x	
Civilian \ W41 \ 1999-11~	Auto drive position	x	x	x	
Civilian \ W41 \ 1999-11~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 1999-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 1999-11~	Sonar	x	x	x	
Civilian \ W41 \ 1999-11~	Lane camera	x	x	x	
Civilian \ W41 \ 1999-11~	Adaptive light	x	x	x	
Civilian \ W41 \ 1999-11~	AVM		x	x	
Civilian \ W41 \ 1999-11~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 1999-11~	Difference lock	x	x	x	
Civilian \ W41 \ 1999-11~	Nats immu	x	x		
Civilian \ W41 \ 1999-11~	Smart entrance	x	x		
Civilian \ W41 \ 1999-11~	Air levelizer	x	x	x	
Civilian \ W41 \ 1999-11~	Rearview camera			x	
Civilian \ W41 \ 1999-11~	S/blind camera			x	
Civilian \ W41 \ 1999-11~	Motor assist	x	x	x	
Civilian \ W41 \ 1999-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 1999-2~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 1999-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 1999-2~	BCM	x	x		
Civilian \ W41 \ 1999-2~	Air bag	x	x	x	
Civilian \ W41 \ 1999-2~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 1999-2~	HVAC	x	x	x	
Civilian \ W41 \ 1999-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 1999-2~	Multi AV	x	x	x	0280
Civilian \ W41 \ 1999-2~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 1999-2~	IPDM E/R	x	x	x	
Civilian \ W41 \ 1999-2~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 1999-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Civilian \ W41 \ 1999-2~	DIU	x	x	x	
Civilian \ W41 \ 1999-2~	Auto slide door	x	x	x	
Civilian \ W41 \ 1999-2~	Auto drive position	x	x	x	
Civilian \ W41 \ 1999-2~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 1999-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 1999-2~	Sonar	x	x	x	
Civilian \ W41 \ 1999-2~	Lane camera	x	x	x	
Civilian \ W41 \ 1999-2~	Adaptive light	x	x	x	
Civilian \ W41 \ 1999-2~	AVM		x	x	
Civilian \ W41 \ 1999-2~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 1999-2~	Difference lock	x	x	x	
Civilian \ W41 \ 1999-2~	Nats immu	x	x		
Civilian \ W41 \ 1999-2~	Smart entrance	x	x		
Civilian \ W41 \ 1999-2~	Air levelizer	x	x	x	
Civilian \ W41 \ 1999-2~	Rearview camera			x	
Civilian \ W41 \ 1999-2~	S/blind camera			x	
Civilian \ W41 \ 1999-2~	Motor assist	x	x	x	
Civilian \ W41 \ 2000-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2000-2~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2000-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2000-2~	BCM	x	x		
Civilian \ W41 \ 2000-2~	Air bag	x	x	x	
Civilian \ W41 \ 2000-2~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2000-2~	HVAC	x	x	x	
Civilian \ W41 \ 2000-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2000-2~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2000-2~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2000-2~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2000-2~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2000-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2000-2~	DIU	x	x	x	
Civilian \ W41 \ 2000-2~	Auto slide door	x	x	x	
Civilian \ W41 \ 2000-2~	Auto drive position	x	x	x	
Civilian \ W41 \ 2000-2~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2000-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2000-2~	Sonar	x	x	x	
Civilian \ W41 \ 2000-2~	Lane camera	x	x	x	
Civilian \ W41 \ 2000-2~	Adaptive light	x	x	x	

Civilian \ W41 \ 2000-2~	AVM		x	x	
Civilian \ W41 \ 2000-2~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2000-2~	Difference lock	x	x	x	
Civilian \ W41 \ 2000-2~	Nats immu	x	x		
Civilian \ W41 \ 2000-2~	Smart entrance	x	x		
Civilian \ W41 \ 2000-2~	Air levelizer	x	x	x	
Civilian \ W41 \ 2000-2~	Rearview camera			x	
Civilian \ W41 \ 2000-2~	S/blind camera			x	
Civilian \ W41 \ 2000-2~	Motor assist	x	x	x	
Civilian \ W41 \ 2002-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2002-10~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2002-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2002-10~	BCM	x	x		
Civilian \ W41 \ 2002-10~	Air bag	x	x	x	
Civilian \ W41 \ 2002-10~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2002-10~	HVAC	x	x	x	
Civilian \ W41 \ 2002-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2002-10~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2002-10~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2002-10~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2002-10~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2002-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2002-10~	DIU	x	x	x	
Civilian \ W41 \ 2002-10~	Auto slide door	x	x	x	
Civilian \ W41 \ 2002-10~	Auto drive position	x	x	x	
Civilian \ W41 \ 2002-10~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2002-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2002-10~	Sonar	x	x	x	
Civilian \ W41 \ 2002-10~	Lane camera	x	x	x	
Civilian \ W41 \ 2002-10~	Adaptive light	x	x	x	
Civilian \ W41 \ 2002-10~	AVM		x	x	
Civilian \ W41 \ 2002-10~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2002-10~	Difference lock	x	x	x	
Civilian \ W41 \ 2002-10~	Nats immu	x	x		
Civilian \ W41 \ 2002-10~	Smart entrance	x	x		
Civilian \ W41 \ 2002-10~	Air levelizer	x	x	x	
Civilian \ W41 \ 2002-10~	Rearview camera			x	
Civilian \ W41 \ 2002-10~	S/blind camera			x	

Civilian \ W41 \ 2002-10~	Motor assist	x	x	x	
Civilian \ W41 \ 2002-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2002-11~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2002-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2002-11~	BCM	x	x		
Civilian \ W41 \ 2002-11~	Air bag	x	x	x	
Civilian \ W41 \ 2002-11~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2002-11~	HVAC	x	x	x	
Civilian \ W41 \ 2002-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2002-11~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2002-11~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2002-11~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2002-11~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2002-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2002-11~	DIU	x	x	x	
Civilian \ W41 \ 2002-11~	Auto slide door	x	x	x	
Civilian \ W41 \ 2002-11~	Auto drive position	x	x	x	
Civilian \ W41 \ 2002-11~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2002-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2002-11~	Sonar	x	x	x	
Civilian \ W41 \ 2002-11~	Lane camera	x	x	x	
Civilian \ W41 \ 2002-11~	Adaptive light	x	x	x	
Civilian \ W41 \ 2002-11~	AVM		x	x	
Civilian \ W41 \ 2002-11~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2002-11~	Difference lock	x	x	x	
Civilian \ W41 \ 2002-11~	Nats immu	x	x		
Civilian \ W41 \ 2002-11~	Smart entrance	x	x		
Civilian \ W41 \ 2002-11~	Air levelizer	x	x	x	
Civilian \ W41 \ 2002-11~	Rearview camera			x	
Civilian \ W41 \ 2002-11~	S/blind camera			x	
Civilian \ W41 \ 2002-11~	Motor assist	x	x	x	
Civilian \ W41 \ 2004-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2004-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2004-8~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2004-8~	ABS	x	x	x	
Civilian \ W41 \ 2004-8~	Transmission	x	x	x	
Civilian \ W41 \ 2004-8~	ABS	x	x	x	0003, 0092, 0264

Civilian \ W41 \ 2004-8~	BCM	x	x		
Civilian \ W41 \ 2004-8~	Air bag	x	x	x	
Civilian \ W41 \ 2004-8~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2004-8~	HVAC	x	x	x	
Civilian \ W41 \ 2004-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2004-8~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2004-8~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2004-8~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2004-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2004-8~	DIU	x	x	x	
Civilian \ W41 \ 2004-8~	Auto slide door	x	x	x	
Civilian \ W41 \ 2004-8~	Auto drive position	x	x	x	
Civilian \ W41 \ 2004-8~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2004-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2004-8~	Sonar	x	x	x	
Civilian \ W41 \ 2004-8~	Lane camera	x	x	x	
Civilian \ W41 \ 2004-8~	Adaptive light	x	x	x	
Civilian \ W41 \ 2004-8~	AVM		x	x	
Civilian \ W41 \ 2004-8~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2004-8~	Difference lock	x	x	x	
Civilian \ W41 \ 2004-8~	Nats immu	x	x		
Civilian \ W41 \ 2004-8~	Smart entrance	x	x		
Civilian \ W41 \ 2004-8~	Air levelizer	x	x	x	
Civilian \ W41 \ 2004-8~	Rearview camera			x	
Civilian \ W41 \ 2004-8~	S/blind camera			x	
Civilian \ W41 \ 2004-8~	Motor assist	x	x	x	
Civilian \ W41 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2004-9~	BCM	x	x		
Civilian \ W41 \ 2004-9~	Air bag	x	x	x	
Civilian \ W41 \ 2004-9~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2004-9~	HVAC	x	x	x	
Civilian \ W41 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2004-9~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2004-9~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2004-9~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2004-9~	Air pressure monitor	x	x	x	

Civilian \ W41 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2004-9~	DIU	x	x	x	
Civilian \ W41 \ 2004-9~	Auto slide door	x	x	x	
Civilian \ W41 \ 2004-9~	Auto drive position	x	x	x	
Civilian \ W41 \ 2004-9~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2004-9~	Sonar	x	x	x	
Civilian \ W41 \ 2004-9~	Lane camera	x	x	x	
Civilian \ W41 \ 2004-9~	Adaptive light	x	x	x	
Civilian \ W41 \ 2004-9~	AVM		x	x	
Civilian \ W41 \ 2004-9~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2004-9~	Difference lock	x	x	x	
Civilian \ W41 \ 2004-9~	Nats immu	x	x		
Civilian \ W41 \ 2004-9~	Smart entrance	x	x		
Civilian \ W41 \ 2004-9~	Air levelizer	x	x	x	
Civilian \ W41 \ 2004-9~	Rearview camera			x	
Civilian \ W41 \ 2004-9~	S/blind camera			x	
Civilian \ W41 \ 2004-9~	Motor assist	x	x	x	
Civilian \ W41 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2005-12~	BCM	x	x		
Civilian \ W41 \ 2005-12~	Air bag	x	x	x	
Civilian \ W41 \ 2005-12~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2005-12~	HVAC	x	x	x	
Civilian \ W41 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2005-12~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2005-12~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2005-12~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2005-12~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2005-12~	DIU	x	x	x	
Civilian \ W41 \ 2005-12~	Auto slide door	x	x	x	
Civilian \ W41 \ 2005-12~	Auto drive position	x	x	x	
Civilian \ W41 \ 2005-12~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Civilian \ W41 \ 2005-12~	Sonar	x	x	x	
Civilian \ W41 \ 2005-12~	Lane camera	x	x	x	
Civilian \ W41 \ 2005-12~	Adaptive light	x	x	x	
Civilian \ W41 \ 2005-12~	AVM		x	x	
Civilian \ W41 \ 2005-12~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2005-12~	Difference lock	x	x	x	
Civilian \ W41 \ 2005-12~	Nats immu	x	x		
Civilian \ W41 \ 2005-12~	Smart entrance	x	x		
Civilian \ W41 \ 2005-12~	Air levelizer	x	x	x	
Civilian \ W41 \ 2005-12~	Rearview camera			x	
Civilian \ W41 \ 2005-12~	S/blind camera			x	
Civilian \ W41 \ 2005-12~	Motor assist	x	x	x	
Civilian \ W41 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2007-7~	BCM	x	x		
Civilian \ W41 \ 2007-7~	Air bag	x	x	x	
Civilian \ W41 \ 2007-7~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2007-7~	HVAC	x	x	x	
Civilian \ W41 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2007-7~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2007-7~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2007-7~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2007-7~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2007-7~	DIU	x	x	x	
Civilian \ W41 \ 2007-7~	Auto slide door	x	x	x	
Civilian \ W41 \ 2007-7~	Auto drive position	x	x	x	
Civilian \ W41 \ 2007-7~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2007-7~	Sonar	x	x	x	
Civilian \ W41 \ 2007-7~	Lane camera	x	x	x	
Civilian \ W41 \ 2007-7~	Adaptive light	x	x	x	
Civilian \ W41 \ 2007-7~	AVM		x	x	
Civilian \ W41 \ 2007-7~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2007-7~	Difference lock	x	x	x	
Civilian \ W41 \ 2007-7~	Nats immu	x	x		
Civilian \ W41 \ 2007-7~	Smart entrance	x	x		

Civilian \ W41 \ 2007-7~	Air levelizer	x	x	x	
Civilian \ W41 \ 2007-7~	Rearview camera			x	
Civilian \ W41 \ 2007-7~	S/blind camera			x	
Civilian \ W41 \ 2007-7~	Motor assist	x	x	x	
Civilian \ W41 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2009-9~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2009-9~	BCM	x	x		
Civilian \ W41 \ 2009-9~	Air bag	x	x	x	
Civilian \ W41 \ 2009-9~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2009-9~	HVAC	x	x	x	
Civilian \ W41 \ 2009-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Civilian \ W41 \ 2009-9~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2009-9~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2009-9~	IPDM E/R	x	x	x	
Civilian \ W41 \ 2009-9~	Air pressure monitor	x	x	x	
Civilian \ W41 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Civilian \ W41 \ 2009-9~	DIU	x	x	x	
Civilian \ W41 \ 2009-9~	Auto slide door	x	x	x	
Civilian \ W41 \ 2009-9~	Auto drive position	x	x	x	
Civilian \ W41 \ 2009-9~	All mode AWD/4WD	x	x	x	
Civilian \ W41 \ 2009-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2009-9~	Sonar	x	x	x	
Civilian \ W41 \ 2009-9~	Lane camera	x	x	x	
Civilian \ W41 \ 2009-9~	Adaptive light	x	x	x	
Civilian \ W41 \ 2009-9~	AVM		x	x	
Civilian \ W41 \ 2009-9~	Head lamp levelizer	x	x	x	
Civilian \ W41 \ 2009-9~	Difference lock	x	x	x	
Civilian \ W41 \ 2009-9~	Nats immu	x	x		
Civilian \ W41 \ 2009-9~	Smart entrance	x	x		
Civilian \ W41 \ 2009-9~	Air levelizer	x	x	x	
Civilian \ W41 \ 2009-9~	Rearview camera			x	
Civilian \ W41 \ 2009-9~	S/blind camera			x	
Civilian \ W41 \ 2009-9~	Motor assist	x	x	x	
Civilian \ W41 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2011-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2011-5~	Multi AV	x	x	x	

Civilian \ W41 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2012-12~	ABS	x	x	x	
Civilian \ W41 \ 2012-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2012-12~	Multi AV	x	x	x	0280
Civilian \ W41 \ 2012-12~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2012-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2012-12~	E-SUS		x	x	
Civilian \ W41 \ 2012-12~	AVM		x	x	
Civilian \ W41 \ 2012-12~	Air bag	x	x	x	
Civilian \ W41 \ 2012-12~	Transmission	x	x	x	
Civilian \ W41 \ 2012-12~	Air levelizer	x	x	x	
Civilian \ W41 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2012-6~	ABS	x	x	x	
Civilian \ W41 \ 2012-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2012-6~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2012-6~	All mode AWD/4WD		x	x	
Civilian \ W41 \ 2012-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2012-6~	Air bag	x	x	x	
Civilian \ W41 \ 2012-6~	Transmission	x	x	x	
Civilian \ W41 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2015-11~	ABS	x	x	x	0003, 0092, 0264
Civilian \ W41 \ 2015-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2015-11~	ICC/ADAS	x	x	x	
Civilian \ W41 \ 2015-11~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2015-11~	Laser/radar	x	x	x	
Civilian \ W41 \ 2015-11~	4WAS(front)	x	x	x	
Civilian \ W41 \ 2015-11~	Accele pedal ACT		x	x	
Civilian \ W41 \ 2015-11~	Side radar left		x	x	
Civilian \ W41 \ 2015-11~	Side radar right		x	x	
Civilian \ W41 \ 2015-11~	Air levelizer	x	x	x	
Civilian \ W41 \ 2015-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Civilian \ W41 \ 2015-4~	ABS	x	x	x	
Civilian \ W41 \ 2015-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Civilian \ W41 \ 2015-4~	EPS/DAST 3	x	x	x	
Civilian \ W41 \ 2015-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Civilian \ W41 \ 2015-4~	Air levelizer	x	x	x	

Crew \ K30 \ 1996-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 1996-1~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 1996-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 1996-1~	BCM	x	x		
Crew \ K30 \ 1996-1~	Air bag	x	x	x	
Crew \ K30 \ 1996-1~	ICC/ADAS	x	x	x	
Crew \ K30 \ 1996-1~	HVAC	x	x	x	
Crew \ K30 \ 1996-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 1996-1~	Multi AV	x	x	x	0280
Crew \ K30 \ 1996-1~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 1996-1~	IPDM E/R	x	x	x	
Crew \ K30 \ 1996-1~	Air pressure monitor	x	x	x	
Crew \ K30 \ 1996-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 1996-1~	DIU	x	x	x	
Crew \ K30 \ 1996-1~	Auto slide door	x	x	x	
Crew \ K30 \ 1996-1~	Auto drive position	x	x	x	
Crew \ K30 \ 1996-1~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 1996-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 1996-1~	Sonar	x	x	x	
Crew \ K30 \ 1996-1~	Lane camera	x	x	x	
Crew \ K30 \ 1996-1~	Adaptive light	x	x	x	
Crew \ K30 \ 1996-1~	AVM		x	x	
Crew \ K30 \ 1996-1~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 1996-1~	Difference lock	x	x	x	
Crew \ K30 \ 1996-1~	Nats immu	x	x		
Crew \ K30 \ 1996-1~	Smart entrance	x	x		
Crew \ K30 \ 1996-1~	Air levelizer	x	x	x	
Crew \ K30 \ 1996-1~	Rearview camera			x	
Crew \ K30 \ 1996-1~	S/blind camera			x	
Crew \ K30 \ 1996-1~	Motor assist	x	x	x	
Crew \ K30 \ 1996-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 1996-9~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 1996-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 1996-9~	BCM	x	x		
Crew \ K30 \ 1996-9~	Air bag	x	x	x	
Crew \ K30 \ 1996-9~	ICC/ADAS	x	x	x	
Crew \ K30 \ 1996-9~	HVAC	x	x	x	

Crew \ K30 \ 1996-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 1996-9~	Multi AV	x	x	x	0280
Crew \ K30 \ 1996-9~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 1996-9~	IPDM E/R	x	x	x	
Crew \ K30 \ 1996-9~	Air pressure monitor	x	x	x	
Crew \ K30 \ 1996-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 1996-9~	DIU	x	x	x	
Crew \ K30 \ 1996-9~	Auto slide door	x	x	x	
Crew \ K30 \ 1996-9~	Auto drive position	x	x	x	
Crew \ K30 \ 1996-9~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 1996-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 1996-9~	Sonar	x	x	x	
Crew \ K30 \ 1996-9~	Lane camera	x	x	x	
Crew \ K30 \ 1996-9~	Adaptive light	x	x	x	
Crew \ K30 \ 1996-9~	AVM		x	x	
Crew \ K30 \ 1996-9~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 1996-9~	Difference lock	x	x	x	
Crew \ K30 \ 1996-9~	Nats immu	x	x		
Crew \ K30 \ 1996-9~	Smart entrance	x	x		
Crew \ K30 \ 1996-9~	Air levelizer	x	x	x	
Crew \ K30 \ 1996-9~	Rearview camera			x	
Crew \ K30 \ 1996-9~	S/blind camera			x	
Crew \ K30 \ 1996-9~	Motor assist	x	x	x	
Crew \ K30 \ 1998-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 1998-6~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 1998-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 1998-6~	BCM	x	x		
Crew \ K30 \ 1998-6~	Air bag	x	x	x	
Crew \ K30 \ 1998-6~	ICC/ADAS	x	x	x	
Crew \ K30 \ 1998-6~	HVAC	x	x	x	
Crew \ K30 \ 1998-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 1998-6~	Multi AV	x	x	x	0280
Crew \ K30 \ 1998-6~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 1998-6~	IPDM E/R	x	x	x	
Crew \ K30 \ 1998-6~	Air pressure monitor	x	x	x	
Crew \ K30 \ 1998-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Crew \ K30 \ 1998-6~	DIU	x	x	x	
Crew \ K30 \ 1998-6~	Auto slide door	x	x	x	
Crew \ K30 \ 1998-6~	Auto drive position	x	x	x	
Crew \ K30 \ 1998-6~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 1998-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 1998-6~	Sonar	x	x	x	
Crew \ K30 \ 1998-6~	Lane camera	x	x	x	
Crew \ K30 \ 1998-6~	Adaptive light	x	x	x	
Crew \ K30 \ 1998-6~	AVM		x	x	
Crew \ K30 \ 1998-6~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 1998-6~	Difference lock	x	x	x	
Crew \ K30 \ 1998-6~	Nats immu	x	x		
Crew \ K30 \ 1998-6~	Smart entrance	x	x		
Crew \ K30 \ 1998-6~	Air levelizer	x	x	x	
Crew \ K30 \ 1998-6~	Rearview camera			x	
Crew \ K30 \ 1998-6~	S/blind camera			x	
Crew \ K30 \ 1998-6~	Motor assist	x	x	x	
Crew \ K30 \ 1999-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 1999-8~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 1999-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 1999-8~	BCM	x	x		
Crew \ K30 \ 1999-8~	Air bag	x	x	x	
Crew \ K30 \ 1999-8~	ICC/ADAS	x	x	x	
Crew \ K30 \ 1999-8~	HVAC	x	x	x	
Crew \ K30 \ 1999-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 1999-8~	Multi AV	x	x	x	0280
Crew \ K30 \ 1999-8~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 1999-8~	IPDM E/R	x	x	x	
Crew \ K30 \ 1999-8~	Air pressure monitor	x	x	x	
Crew \ K30 \ 1999-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 1999-8~	DIU	x	x	x	
Crew \ K30 \ 1999-8~	Auto slide door	x	x	x	
Crew \ K30 \ 1999-8~	Auto drive position	x	x	x	
Crew \ K30 \ 1999-8~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 1999-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 1999-8~	Sonar	x	x	x	
Crew \ K30 \ 1999-8~	Lane camera	x	x	x	
Crew \ K30 \ 1999-8~	Adaptive light	x	x	x	

Crew \ K30 \ 1999-8~	AVM		x	x	
Crew \ K30 \ 1999-8~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 1999-8~	Difference lock	x	x	x	
Crew \ K30 \ 1999-8~	Nats immu	x	x		
Crew \ K30 \ 1999-8~	Smart entrance	x	x		
Crew \ K30 \ 1999-8~	Air levelizer	x	x	x	
Crew \ K30 \ 1999-8~	Rearview camera			x	
Crew \ K30 \ 1999-8~	S/blind camera			x	
Crew \ K30 \ 1999-8~	Motor assist	x	x	x	
Crew \ K30 \ 2002-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 2002-6~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 2002-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 2002-6~	BCM	x	x		
Crew \ K30 \ 2002-6~	Air bag	x	x	x	
Crew \ K30 \ 2002-6~	ICC/ADAS	x	x	x	
Crew \ K30 \ 2002-6~	HVAC	x	x	x	
Crew \ K30 \ 2002-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 2002-6~	Multi AV	x	x	x	0280
Crew \ K30 \ 2002-6~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 2002-6~	IPDM E/R	x	x	x	
Crew \ K30 \ 2002-6~	Air pressure monitor	x	x	x	
Crew \ K30 \ 2002-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 2002-6~	DIU	x	x	x	
Crew \ K30 \ 2002-6~	Auto slide door	x	x	x	
Crew \ K30 \ 2002-6~	Auto drive position	x	x	x	
Crew \ K30 \ 2002-6~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 2002-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 2002-6~	Sonar	x	x	x	
Crew \ K30 \ 2002-6~	Lane camera	x	x	x	
Crew \ K30 \ 2002-6~	Adaptive light	x	x	x	
Crew \ K30 \ 2002-6~	AVM		x	x	
Crew \ K30 \ 2002-6~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 2002-6~	Difference lock	x	x	x	
Crew \ K30 \ 2002-6~	Nats immu	x	x		
Crew \ K30 \ 2002-6~	Smart entrance	x	x		
Crew \ K30 \ 2002-6~	Air levelizer	x	x	x	
Crew \ K30 \ 2002-6~	Rearview camera			x	
Crew \ K30 \ 2002-6~	S/blind camera			x	

Crew \ K30 \ 2002-6~	Motor assist	x	x	x	
Crew \ K30 \ 2005-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 2005-11~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 2005-11~	BCM	x	x		
Crew \ K30 \ 2005-11~	Air bag	x	x	x	
Crew \ K30 \ 2005-11~	ICC/ADAS	x	x	x	
Crew \ K30 \ 2005-11~	HVAC	x	x	x	
Crew \ K30 \ 2005-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 2005-11~	Multi AV	x	x	x	0280
Crew \ K30 \ 2005-11~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 2005-11~	IPDM E/R	x	x	x	
Crew \ K30 \ 2005-11~	Air pressure monitor	x	x	x	
Crew \ K30 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 2005-11~	DIU	x	x	x	
Crew \ K30 \ 2005-11~	Auto slide door	x	x	x	
Crew \ K30 \ 2005-11~	Auto drive position	x	x	x	
Crew \ K30 \ 2005-11~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 2005-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 2005-11~	Sonar	x	x	x	
Crew \ K30 \ 2005-11~	Lane camera	x	x	x	
Crew \ K30 \ 2005-11~	Adaptive light	x	x	x	
Crew \ K30 \ 2005-11~	AVM		x	x	
Crew \ K30 \ 2005-11~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 2005-11~	Difference lock	x	x	x	
Crew \ K30 \ 2005-11~	Nats immu	x	x		
Crew \ K30 \ 2005-11~	Smart entrance	x	x		
Crew \ K30 \ 2005-11~	Air levelizer	x	x	x	
Crew \ K30 \ 2005-11~	Rearview camera			x	
Crew \ K30 \ 2005-11~	S/blind camera			x	
Crew \ K30 \ 2005-11~	Motor assist	x	x	x	
Crew \ K30 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Crew \ K30 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Crew \ K30 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Crew \ K30 \ 2007-7~	BCM	x	x		
Crew \ K30 \ 2007-7~	Air bag	x	x	x	
Crew \ K30 \ 2007-7~	ICC/ADAS	x	x	x	

Crew \ K30 \ 2007-7~	HVAC	x	x	x	
Crew \ K30 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Crew \ K30 \ 2007-7~	Multi AV	x	x	x	0280
Crew \ K30 \ 2007-7~	EPS/DAST 3	x	x	x	
Crew \ K30 \ 2007-7~	IPDM E/R	x	x	x	
Crew \ K30 \ 2007-7~	Air pressure monitor	x	x	x	
Crew \ K30 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Crew \ K30 \ 2007-7~	DIU	x	x	x	
Crew \ K30 \ 2007-7~	Auto slide door	x	x	x	
Crew \ K30 \ 2007-7~	Auto drive position	x	x	x	
Crew \ K30 \ 2007-7~	All mode AWD/4WD	x	x	x	
Crew \ K30 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Crew \ K30 \ 2007-7~	Sonar	x	x	x	
Crew \ K30 \ 2007-7~	Lane camera	x	x	x	
Crew \ K30 \ 2007-7~	Adaptive light	x	x	x	
Crew \ K30 \ 2007-7~	AVM		x	x	
Crew \ K30 \ 2007-7~	Head lamp levelizer	x	x	x	
Crew \ K30 \ 2007-7~	Difference lock	x	x	x	
Crew \ K30 \ 2007-7~	Nats immu	x	x		
Crew \ K30 \ 2007-7~	Smart entrance	x	x		
Crew \ K30 \ 2007-7~	Air levelizer	x	x	x	
Crew \ K30 \ 2007-7~	Rearview camera			x	
Crew \ K30 \ 2007-7~	S/blind camera			x	
Crew \ K30 \ 2007-7~	Motor assist	x	x	x	
Cube \ Z10 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z10 \ All Year	ABS	x	x	x	0003, 0092, 0264
Cube \ Z10 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z10 \ All Year	BCM	x	x		
Cube \ Z10 \ All Year	Air bag	x	x	x	
Cube \ Z10 \ All Year	ICC/ADAS	x	x	x	
Cube \ Z10 \ All Year	HVAC	x	x	x	
Cube \ Z10 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z10 \ All Year	Multi AV	x	x	x	0280
Cube \ Z10 \ All Year	EPS/DAST 3	x	x	x	
Cube \ Z10 \ All Year	IPDM E/R	x	x	x	
Cube \ Z10 \ All Year	Air pressure monitor	x	x	x	

Cube \ Z10 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube \ Z10 \ All Year	DIU	x	x	x	
Cube \ Z10 \ All Year	Auto slide door	x	x	x	
Cube \ Z10 \ All Year	Auto drive position	x	x	x	
Cube \ Z10 \ All Year	All mode AWD/4WD	x	x	x	
Cube \ Z10 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube \ Z10 \ All Year	Sonar	x	x	x	
Cube \ Z10 \ All Year	Lane camera	x	x	x	
Cube \ Z10 \ All Year	Adaptive light	x	x	x	
Cube \ Z10 \ All Year	AVM		x	x	
Cube \ Z10 \ All Year	Head lamp levelizer	x	x	x	
Cube \ Z10 \ All Year	Difference lock	x	x	x	
Cube \ Z10 \ All Year	Nats immu	x	x		
Cube \ Z10 \ All Year	Smart entrance	x	x		
Cube \ Z10 \ All Year	Air levelizer	x	x	x	
Cube \ Z10 \ All Year	Rearview camera			x	
Cube \ Z10 \ All Year	S/blind camera			x	
Cube \ Z10 \ All Year	Motor assist	x	x	x	
Cube \ Z11 \ 2002-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z11 \ 2002-10~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z11 \ 2002-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z11 \ 2002-10~	BCM	x	x		
Cube \ Z11 \ 2002-10~	Air bag	x	x	x	
Cube \ Z11 \ 2002-10~	ICC/ADAS	x	x	x	
Cube \ Z11 \ 2002-10~	HVAC	x	x	x	
Cube \ Z11 \ 2002-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z11 \ 2002-10~	Multi AV	x	x	x	0280
Cube \ Z11 \ 2002-10~	EPS/DAST 3	x	x	x	
Cube \ Z11 \ 2002-10~	IPDM E/R	x	x	x	
Cube \ Z11 \ 2002-10~	Air pressure monitor	x	x	x	
Cube \ Z11 \ 2002-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube \ Z11 \ 2002-10~	DIU	x	x	x	
Cube \ Z11 \ 2002-10~	Auto slide door	x	x	x	
Cube \ Z11 \ 2002-10~	Auto drive position	x	x	x	
Cube \ Z11 \ 2002-10~	All mode AWD/4WD	x	x	x	
Cube \ Z11 \ 2002-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Cube \ Z11 \ 2002-10~	Sonar	x	x	x	
Cube \ Z11 \ 2002-10~	Lane camera	x	x	x	
Cube \ Z11 \ 2002-10~	Adaptive light	x	x	x	
Cube \ Z11 \ 2002-10~	AVM		x	x	
Cube \ Z11 \ 2002-10~	Head lamp levelizer	x	x	x	
Cube \ Z11 \ 2002-10~	Difference lock	x	x	x	
Cube \ Z11 \ 2002-10~	Nats immu	x	x		
Cube \ Z11 \ 2002-10~	Smart entrance	x	x		
Cube \ Z11 \ 2002-10~	Air levelizer	x	x	x	
Cube \ Z11 \ 2002-10~	Rearview camera			x	
Cube \ Z11 \ 2002-10~	S/blind camera			x	
Cube \ Z11 \ 2002-10~	Motor assist	x	x	x	
Cube \ Z11 \ 2003-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z11 \ 2003-5~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z11 \ 2003-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z11 \ 2003-5~	BCM	x	x		
Cube \ Z11 \ 2003-5~	Air bag	x	x	x	
Cube \ Z11 \ 2003-5~	ICC/ADAS	x	x	x	
Cube \ Z11 \ 2003-5~	HVAC	x	x	x	
Cube \ Z11 \ 2003-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z11 \ 2003-5~	Multi AV	x	x	x	0280
Cube \ Z11 \ 2003-5~	EPS/DAST 3	x	x	x	
Cube \ Z11 \ 2003-5~	IPDM E/R	x	x	x	
Cube \ Z11 \ 2003-5~	Air pressure monitor	x	x	x	
Cube \ Z11 \ 2003-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube \ Z11 \ 2003-5~	DIU	x	x	x	
Cube \ Z11 \ 2003-5~	Auto slide door	x	x	x	
Cube \ Z11 \ 2003-5~	Auto drive position	x	x	x	
Cube \ Z11 \ 2003-5~	All mode AWD/4WD	x	x	x	
Cube \ Z11 \ 2003-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube \ Z11 \ 2003-5~	Sonar	x	x	x	
Cube \ Z11 \ 2003-5~	Lane camera	x	x	x	
Cube \ Z11 \ 2003-5~	Adaptive light	x	x	x	
Cube \ Z11 \ 2003-5~	AVM		x	x	
Cube \ Z11 \ 2003-5~	Head lamp levelizer	x	x	x	
Cube \ Z11 \ 2003-5~	Difference lock	x	x	x	
Cube \ Z11 \ 2003-5~	Nats immu	x	x		
Cube \ Z11 \ 2003-5~	Smart entrance	x	x		

Cube \ Z11 \ 2003-5~	Air levelizer	x	x	x	
Cube \ Z11 \ 2003-5~	Rearview camera			x	
Cube \ Z11 \ 2003-5~	S/blind camera			x	
Cube \ Z11 \ 2003-5~	Motor assist	x	x	x	
Cube \ Z11 \ 2005-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z11 \ 2005-5~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z11 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z11 \ 2005-5~	BCM	x	x		
Cube \ Z11 \ 2005-5~	Air bag	x	x	x	
Cube \ Z11 \ 2005-5~	ICC/ADAS	x	x	x	
Cube \ Z11 \ 2005-5~	HVAC	x	x	x	
Cube \ Z11 \ 2005-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z11 \ 2005-5~	Multi AV	x	x	x	0280
Cube \ Z11 \ 2005-5~	EPS/DAST 3	x	x	x	
Cube \ Z11 \ 2005-5~	IPDM E/R	x	x	x	
Cube \ Z11 \ 2005-5~	Air pressure monitor	x	x	x	
Cube \ Z11 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube \ Z11 \ 2005-5~	DIU	x	x	x	
Cube \ Z11 \ 2005-5~	Auto slide door	x	x	x	
Cube \ Z11 \ 2005-5~	Auto drive position	x	x	x	
Cube \ Z11 \ 2005-5~	All mode AWD/4WD	x	x	x	
Cube \ Z11 \ 2005-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube \ Z11 \ 2005-5~	Sonar	x	x	x	
Cube \ Z11 \ 2005-5~	Lane camera	x	x	x	
Cube \ Z11 \ 2005-5~	Adaptive light	x	x	x	
Cube \ Z11 \ 2005-5~	AVM		x	x	
Cube \ Z11 \ 2005-5~	Head lamp levelizer	x	x	x	
Cube \ Z11 \ 2005-5~	Difference lock	x	x	x	
Cube \ Z11 \ 2005-5~	Nats immu	x	x		
Cube \ Z11 \ 2005-5~	Smart entrance	x	x		
Cube \ Z11 \ 2005-5~	Air levelizer	x	x	x	
Cube \ Z11 \ 2005-5~	Rearview camera			x	
Cube \ Z11 \ 2005-5~	S/blind camera			x	
Cube \ Z11 \ 2005-5~	Motor assist	x	x	x	
Cube \ Z11 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z11 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Cube \ Z11 \ 2006-12~	BCM	x	x		
Cube \ Z11 \ 2006-12~	Air bag	x	x	x	
Cube \ Z11 \ 2006-12~	ICC/ADAS	x	x	x	
Cube \ Z11 \ 2006-12~	HVAC	x	x	x	
Cube \ Z11 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z11 \ 2006-12~	Multi AV	x	x	x	0280
Cube \ Z11 \ 2006-12~	EPS/DAST 3	x	x	x	
Cube \ Z11 \ 2006-12~	IPDM E/R	x	x	x	
Cube \ Z11 \ 2006-12~	Air pressure monitor	x	x	x	
Cube \ Z11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube \ Z11 \ 2006-12~	DIU	x	x	x	
Cube \ Z11 \ 2006-12~	Auto slide door	x	x	x	
Cube \ Z11 \ 2006-12~	Auto drive position	x	x	x	
Cube \ Z11 \ 2006-12~	All mode AWD/4WD	x	x	x	
Cube \ Z11 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube \ Z11 \ 2006-12~	Sonar	x	x	x	
Cube \ Z11 \ 2006-12~	Lane camera	x	x	x	
Cube \ Z11 \ 2006-12~	Adaptive light	x	x	x	
Cube \ Z11 \ 2006-12~	AVM		x	x	
Cube \ Z11 \ 2006-12~	Head lamp levelizer	x	x	x	
Cube \ Z11 \ 2006-12~	Difference lock	x	x	x	
Cube \ Z11 \ 2006-12~	Nats immu	x	x		
Cube \ Z11 \ 2006-12~	Smart entrance	x	x		
Cube \ Z11 \ 2006-12~	Air levelizer	x	x	x	
Cube \ Z11 \ 2006-12~	Rearview camera			x	
Cube \ Z11 \ 2006-12~	S/blind camera			x	
Cube \ Z11 \ 2006-12~	Motor assist	x	x	x	
Cube \ Z12 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2008-10~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2008-10~	Meter/M&A		x	x	
Cube \ Z12 \ 2008-10~	BCM		x		
Cube \ Z12 \ 2008-10~	Air bag	x	x	x	
Cube \ Z12 \ 2008-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2008-10~	Multi AV		x	x	
Cube \ Z12 \ 2008-10~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2008-10~	IPDM E/R		x	x	
Cube \ Z12 \ 2008-10~	E-4wd	x	x	x	
Cube \ Z12 \ 2008-10~	All mode AWD/4WD	x	x	x	0245, 0311

Cube \ Z12 \ 2008-10~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2008-10~	Sonar	x	x	x	
Cube \ Z12 \ 2008-10~	Occupant detection			x	
Cube \ Z12 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2009	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2009	Meter/M&A		x	x	
Cube \ Z12 \ 2009	BCM		x		
Cube \ Z12 \ 2009	Air bag	x	x	x	
Cube \ Z12 \ 2009	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2009	Multi AV		x	x	
Cube \ Z12 \ 2009	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2009	IPDM E/R		x	x	
Cube \ Z12 \ 2009	E-4wd	x	x	x	
Cube \ Z12 \ 2009	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2009	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2009	Sonar	x	x	x	
Cube \ Z12 \ 2009	Occupant detection			x	
Cube \ Z12 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2009-10~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2009-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z12 \ 2009-10~	BCM		x		
Cube \ Z12 \ 2009-10~	Air bag	x	x	x	
Cube \ Z12 \ 2009-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2009-10~	Multi AV		x	x	
Cube \ Z12 \ 2009-10~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2009-10~	IPDM E/R		x	x	
Cube \ Z12 \ 2009-10~	E-4wd	x	x	x	
Cube \ Z12 \ 2009-10~	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2009-10~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2009-10~	Sonar	x	x	x	
Cube \ Z12 \ 2009-10~	Occupant detection			x	
Cube \ Z12 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z12 \ 2009-8~	BCM		x		
Cube \ Z12 \ 2009-8~	Air bag	x	x	x	
Cube \ Z12 \ 2009-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2009-8~	Multi AV		x	x	

Cube \ Z12 \ 2009-8~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2009-8~	IPDM E/R		x	x	
Cube \ Z12 \ 2009-8~	E-4wd	x	x	x	
Cube \ Z12 \ 2009-8~	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2009-8~	PTC heater		x	x	
Cube \ Z12 \ 2009-8~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2009-8~	Sonar	x	x	x	
Cube \ Z12 \ 2009-8~	Occupant detection			x	
Cube \ Z12 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2010	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z12 \ 2010	BCM		x		
Cube \ Z12 \ 2010	Air bag	x	x	x	
Cube \ Z12 \ 2010	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2010	Multi AV		x	x	
Cube \ Z12 \ 2010	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2010	IPDM E/R		x	x	
Cube \ Z12 \ 2010	E-4wd	x	x	x	
Cube \ Z12 \ 2010	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2010	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2010	Sonar	x	x	x	
Cube \ Z12 \ 2010	Occupant detection			x	
Cube \ Z12 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2010-11~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2010-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z12 \ 2010-11~	BCM		x		
Cube \ Z12 \ 2010-11~	Air bag	x	x	x	
Cube \ Z12 \ 2010-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2010-11~	Multi AV		x	x	
Cube \ Z12 \ 2010-11~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2010-11~	IPDM E/R		x	x	
Cube \ Z12 \ 2010-11~	E-4wd	x	x	x	
Cube \ Z12 \ 2010-11~	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2010-11~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2010-11~	Sonar	x	x	x	
Cube \ Z12 \ 2010-11~	Occupant detection			x	
Cube \ Z12 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2011	ABS	x	x	x	0003, 0092, 0264

Cube \ Z12 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube \ Z12 \ 2011	BCM		x		
Cube \ Z12 \ 2011	Air bag	x	x	x	
Cube \ Z12 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2011	Multi AV		x	x	
Cube \ Z12 \ 2011	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2011	IPDM E/R		x	x	
Cube \ Z12 \ 2011	E-4wd	x	x	x	
Cube \ Z12 \ 2011	All mode AWD/4WD	x	x	x	0245, 0311
Cube \ Z12 \ 2011	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2011	Sonar	x	x	x	
Cube \ Z12 \ 2011	Occupant detection			x	
Cube \ Z12 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2011-11~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2011-11~	Meter/M&A		x	x	
Cube \ Z12 \ 2011-11~	BCM		x		
Cube \ Z12 \ 2011-11~	Air bag	x	x	x	
Cube \ Z12 \ 2011-11~	Transmission	x	x	x	
Cube \ Z12 \ 2011-11~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2011-11~	IPDM E/R		x	x	
Cube \ Z12 \ 2011-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2011-7~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2011-7~	Meter/M&A		x	x	0143
Cube \ Z12 \ 2011-7~	BCM		x		
Cube \ Z12 \ 2011-7~	Air bag	x	x	x	
Cube \ Z12 \ 2011-7~	Transmission	x	x	x	
Cube \ Z12 \ 2011-7~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2011-7~	IPDM E/R		x	x	
Cube \ Z12 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2012	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2012	Meter/M&A		x	x	
Cube \ Z12 \ 2012	BCM		x		
Cube \ Z12 \ 2012	Air bag	x	x	x	
Cube \ Z12 \ 2012	Transmission	x	x	x	
Cube \ Z12 \ 2012	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2012	IPDM E/R		x	x	
Cube \ Z12 \ 2012	Occupant detection			x	

Cube \ Z12 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2012-10~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2012-10~	Meter/M&A		x	x	
Cube \ Z12 \ 2012-10~	BCM		x		
Cube \ Z12 \ 2012-10~	Air bag	x	x	x	
Cube \ Z12 \ 2012-10~	Transmission	x	x	x	
Cube \ Z12 \ 2012-10~	Multi AV		x	x	
Cube \ Z12 \ 2012-10~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2012-10~	IPDM E/R		x	x	
Cube \ Z12 \ 2012-10~	E-4wd	x	x	x	
Cube \ Z12 \ 2012-10~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2012-9~	Meter/M&A		x	x	
Cube \ Z12 \ 2012-9~	BCM		x		
Cube \ Z12 \ 2012-9~	Air bag	x	x	x	
Cube \ Z12 \ 2012-9~	Transmission	x	x	x	
Cube \ Z12 \ 2012-9~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2012-9~	IPDM E/R		x	x	
Cube \ Z12 \ 2012-9~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2013	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2013	Meter/M&A		x	x	
Cube \ Z12 \ 2013	BCM		x		
Cube \ Z12 \ 2013	Air bag	x	x	x	
Cube \ Z12 \ 2013	Transmission	x	x	x	
Cube \ Z12 \ 2013	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2013	IPDM E/R		x	x	
Cube \ Z12 \ 2013	Occupant detection			x	
Cube \ Z12 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2013-10~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2013-10~	Meter/M&A		x	x	
Cube \ Z12 \ 2013-10~	BCM		x		
Cube \ Z12 \ 2013-10~	Air bag	x	x	x	
Cube \ Z12 \ 2013-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2013-10~	Multi AV	x	x	x	0280
Cube \ Z12 \ 2013-10~	EPS/DAST 3	x	x	x	

Cube \ Z12 \ 2013-10~	IPDM E/R		x	x	
Cube \ Z12 \ 2013-10~	Air pressure monitor		x	x	
Cube \ Z12 \ 2013-10~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2013-10~	Occupant detection			x	
Cube \ Z12 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2013-9~	Meter/M&A		x	x	
Cube \ Z12 \ 2013-9~	BCM		x		
Cube \ Z12 \ 2013-9~	Air bag	x	x	x	
Cube \ Z12 \ 2013-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2013-9~	Multi AV	x	x	x	0280
Cube \ Z12 \ 2013-9~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2013-9~	IPDM E/R		x	x	
Cube \ Z12 \ 2013-9~	E-4wd	x	x	x	
Cube \ Z12 \ 2013-9~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2013-9~	Occupant detection			x	
Cube \ Z12 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2014	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2014	Meter/M&A		x	x	
Cube \ Z12 \ 2014	BCM		x		
Cube \ Z12 \ 2014	Air bag	x	x	x	
Cube \ Z12 \ 2014	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2014	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2014	IPDM E/R		x	x	
Cube \ Z12 \ 2014	Brake		x	x	
Cube \ Z12 \ 2014	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2014	Occupant detection			x	
Cube \ Z12 \ 2014-9~	Engine	x	x	x	0278, 0340, 0233, 0103, 0234, 0172, 0209, 0206, 0109, 0011, 0262, 0216, 0010, 0095, 0212
Cube \ Z12 \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2014-9~	Meter/M&A		x	x	
Cube \ Z12 \ 2014-9~	BCM		x		
Cube \ Z12 \ 2014-9~	Air bag	x	x	x	
Cube \ Z12 \ 2014-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2014-9~	Multi AV	x	x	x	0280
Cube \ Z12 \ 2014-9~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2014-9~	IPDM E/R		x	x	
Cube \ Z12 \ 2014-9~	All mode AWD/4WD	x	x	x	0245, 0311

Cube \ Z12 \ 2014-9~	AVM		x	x	
Cube \ Z12 \ 2014-9~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2014-9~	Occupant detection			x	
Cube \ Z12 \ 2015-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube \ Z12 \ 2015-12~	ABS	x	x	x	0003, 0092, 0264
Cube \ Z12 \ 2015-12~	Meter/M&A		x	x	0143, 0197, 0330, 0331
Cube \ Z12 \ 2015-12~	BCM		x		
Cube \ Z12 \ 2015-12~	Air bag	x	x	x	
Cube \ Z12 \ 2015-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube \ Z12 \ 2015-12~	Multi AV	x	x	x	0280
Cube \ Z12 \ 2015-12~	EPS/DAST 3	x	x	x	
Cube \ Z12 \ 2015-12~	IPDM E/R		x	x	
Cube \ Z12 \ 2015-12~	E-4wd	x	x	x	
Cube \ Z12 \ 2015-12~	PTC heater		x	x	
Cube \ Z12 \ 2015-12~	Head lamp levelizer	x	x	x	
Cube \ Z12 \ 2015-12~	Occupant detection			x	
Cube3 \ GZ11 \ 2003-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube3 \ GZ11 \ 2003-9~	ABS	x	x	x	0003, 0092, 0264
Cube3 \ GZ11 \ 2003-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube3 \ GZ11 \ 2003-9~	BCM	x	x		
Cube3 \ GZ11 \ 2003-9~	Air bag	x	x	x	
Cube3 \ GZ11 \ 2003-9~	ICC/ADAS	x	x	x	
Cube3 \ GZ11 \ 2003-9~	HVAC	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube3 \ GZ11 \ 2003-9~	Multi AV	x	x	x	0280
Cube3 \ GZ11 \ 2003-9~	EPS/DAST 3	x	x	x	
Cube3 \ GZ11 \ 2003-9~	IPDM E/R	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Air pressure monitor	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube3 \ GZ11 \ 2003-9~	DIU	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Auto slide door	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Auto drive position	x	x	x	
Cube3 \ GZ11 \ 2003-9~	All mode AWD/4WD	x	x	x	
Cube3 \ GZ11 \ 2003-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Sonar	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Lane camera	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Adaptive light	x	x	x	

Cube3 \ GZ11 \ 2003-9~	AVM		x	x	
Cube3 \ GZ11 \ 2003-9~	Head lamp levelizer	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Difference lock	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Nats immu	x	x		
Cube3 \ GZ11 \ 2003-9~	Smart entrance	x	x		
Cube3 \ GZ11 \ 2003-9~	Air levelizer	x	x	x	
Cube3 \ GZ11 \ 2003-9~	Rearview camera			x	
Cube3 \ GZ11 \ 2003-9~	S/blind camera			x	
Cube3 \ GZ11 \ 2003-9~	Motor assist	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube3 \ GZ11 \ 2005-5~	ABS	x	x	x	0003, 0092, 0264
Cube3 \ GZ11 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube3 \ GZ11 \ 2005-5~	BCM	x	x		
Cube3 \ GZ11 \ 2005-5~	Air bag	x	x	x	
Cube3 \ GZ11 \ 2005-5~	ICC/ADAS	x	x	x	
Cube3 \ GZ11 \ 2005-5~	HVAC	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube3 \ GZ11 \ 2005-5~	Multi AV	x	x	x	0280
Cube3 \ GZ11 \ 2005-5~	EPS/DAST 3	x	x	x	
Cube3 \ GZ11 \ 2005-5~	IPDM E/R	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Air pressure monitor	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube3 \ GZ11 \ 2005-5~	DIU	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Auto slide door	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Auto drive position	x	x	x	
Cube3 \ GZ11 \ 2005-5~	All mode AWD/4WD	x	x	x	
Cube3 \ GZ11 \ 2005-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Sonar	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Lane camera	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Adaptive light	x	x	x	
Cube3 \ GZ11 \ 2005-5~	AVM		x	x	
Cube3 \ GZ11 \ 2005-5~	Head lamp levelizer	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Difference lock	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Nats immu	x	x		
Cube3 \ GZ11 \ 2005-5~	Smart entrance	x	x		
Cube3 \ GZ11 \ 2005-5~	Air levelizer	x	x	x	
Cube3 \ GZ11 \ 2005-5~	Rearview camera			x	
Cube3 \ GZ11 \ 2005-5~	S/blind camera			x	

Cube3 \ GZ11 \ 2005-5~	Motor assist	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Cube3 \ GZ11 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264
Cube3 \ GZ11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Cube3 \ GZ11 \ 2006-12~	BCM	x	x		
Cube3 \ GZ11 \ 2006-12~	Air bag	x	x	x	
Cube3 \ GZ11 \ 2006-12~	ICC/ADAS	x	x	x	
Cube3 \ GZ11 \ 2006-12~	HVAC	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Cube3 \ GZ11 \ 2006-12~	Multi AV	x	x	x	0280
Cube3 \ GZ11 \ 2006-12~	EPS/DAST 3	x	x	x	
Cube3 \ GZ11 \ 2006-12~	IPDM E/R	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Air pressure monitor	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Cube3 \ GZ11 \ 2006-12~	DIU	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Auto slide door	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Auto drive position	x	x	x	
Cube3 \ GZ11 \ 2006-12~	All mode AWD/4WD	x	x	x	
Cube3 \ GZ11 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Sonar	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Lane camera	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Adaptive light	x	x	x	
Cube3 \ GZ11 \ 2006-12~	AVM		x	x	
Cube3 \ GZ11 \ 2006-12~	Head lamp levelizer	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Difference lock	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Nats immu	x	x		
Cube3 \ GZ11 \ 2006-12~	Smart entrance	x	x		
Cube3 \ GZ11 \ 2006-12~	Air levelizer	x	x	x	
Cube3 \ GZ11 \ 2006-12~	Rearview camera			x	
Cube3 \ GZ11 \ 2006-12~	S/blind camera			x	
Cube3 \ GZ11 \ 2006-12~	Motor assist	x	x	x	
Datsun track \ D22 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Datsun track \ D22 \ All Year	ABS	x	x	x	0003, 0092, 0264
Datsun track \ D22 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Datsun track \ D22 \ All Year	BCM	x	x		
Datsun track \ D22 \ All Year	Air bag	x	x	x	
Datsun track \ D22 \ All Year	ICC/ADAS	x	x	x	

Datsun track \ D22 \ All Year	HVAC	x	x	x	
Datsun track \ D22 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Datsun track \ D22 \ All Year	Multi AV	x	x	x	0280
Datsun track \ D22 \ All Year	EPS/DAST 3	x	x	x	
Datsun track \ D22 \ All Year	IPDM E/R	x	x	x	
Datsun track \ D22 \ All Year	Air pressure monitor	x	x	x	
Datsun track \ D22 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Datsun track \ D22 \ All Year	DIU	x	x	x	
Datsun track \ D22 \ All Year	Auto slide door	x	x	x	
Datsun track \ D22 \ All Year	Auto drive position	x	x	x	
Datsun track \ D22 \ All Year	All mode AWD/4WD	x	x	x	
Datsun track \ D22 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Datsun track \ D22 \ All Year	Sonar	x	x	x	
Datsun track \ D22 \ All Year	Lane camera	x	x	x	
Datsun track \ D22 \ All Year	Adaptive light	x	x	x	
Datsun track \ D22 \ All Year	AVM		x	x	
Datsun track \ D22 \ All Year	Head lamp levelizer	x	x	x	
Datsun track \ D22 \ All Year	Difference lock	x	x	x	
Datsun track \ D22 \ All Year	Nats immu	x	x		
Datsun track \ D22 \ All Year	Smart entrance	x	x		
Datsun track \ D22 \ All Year	Air levelizer	x	x	x	
Datsun track \ D22 \ All Year	Rearview camera			x	
Datsun track \ D22 \ All Year	S/blind camera			x	
Datsun track \ D22 \ All Year	Motor assist	x	x	x	
Dualis \ J10 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Dualis \ J10 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2007-10~	BCM	x	x		
Dualis \ J10 \ 2007-10~	Transmission	x	x	x	
Dualis \ J10 \ 2007-10~	Multi AV	x	x	x	0280
Dualis \ J10 \ 2007-10~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2007-10~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2007-10~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2007-10~	ABS	x	x	x	
Dualis \ J10 \ 2007-10~	Air bag	x	x	x	
Dualis \ J10 \ 2007-10~	Head lamp levelizer	x	x	x	

Dualis \ J10 \ 2007-10~	Rearview camera			x	
Dualis \ J10 \ 2007-10~	S/blind camera			x	
Dualis \ J10 \ 2007-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2007-12~	BCM	x	x		
Dualis \ J10 \ 2007-12~	Transmission	x	x	x	
Dualis \ J10 \ 2007-12~	Multi AV	x	x	x	0280
Dualis \ J10 \ 2007-12~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2007-12~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2007-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2007-12~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2007-12~	Engine	x	x	x	
Dualis \ J10 \ 2007-12~	ABS	x	x	x	
Dualis \ J10 \ 2007-12~	Air bag	x	x	x	
Dualis \ J10 \ 2007-12~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2007-12~	Rearview camera			x	
Dualis \ J10 \ 2007-12~	S/blind camera			x	
Dualis \ J10 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2007-6~	BCM	x	x		
Dualis \ J10 \ 2007-6~	Transmission	x	x	x	
Dualis \ J10 \ 2007-6~	Multi AV	x	x	x	
Dualis \ J10 \ 2007-6~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2007-6~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2007-6~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2007-6~	Adaptive light	x	x	x	
Dualis \ J10 \ 2007-6~	Engine	x	x	x	
Dualis \ J10 \ 2007-6~	ABS	x	x	x	
Dualis \ J10 \ 2007-6~	Air bag	x	x	x	
Dualis \ J10 \ 2007-6~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2007-6~	Rearview camera			x	
Dualis \ J10 \ 2009-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Dualis \ J10 \ 2009-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2009-7~	BCM	x	x		
Dualis \ J10 \ 2009-7~	Transmission	x	x	x	
Dualis \ J10 \ 2009-7~	Multi AV	x	x	x	0280
Dualis \ J10 \ 2009-7~	EPS/DAST 3	x	x	x	

Dualis \ J10 \ 2009-7~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2009-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2009-7~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2009-7~	ABS	x	x	x	
Dualis \ J10 \ 2009-7~	Air bag	x	x	x	
Dualis \ J10 \ 2009-7~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2009-7~	Rearview camera			x	
Dualis \ J10 \ 2009-7~	S/blind camera			x	
Dualis \ J10 \ 2010-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Dualis \ J10 \ 2010-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2010-1~	BCM	x	x		
Dualis \ J10 \ 2010-1~	Transmission	x	x	x	
Dualis \ J10 \ 2010-1~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2010-1~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2010-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2010-1~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2010-1~	ABS	x	x	x	
Dualis \ J10 \ 2010-1~	Air bag	x	x	x	
Dualis \ J10 \ 2010-1~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2010-1~	Sonar	x	x	x	
Dualis \ J10 \ 2010-1~	Rearview camera			x	
Dualis \ J10 \ 2010-1~	S/blind camera			x	
Dualis \ J10 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Dualis \ J10 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2010-8~	BCM	x	x		
Dualis \ J10 \ 2010-8~	Transmission	x	x	x	
Dualis \ J10 \ 2010-8~	Multi AV		x	x	
Dualis \ J10 \ 2010-8~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2010-8~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2010-8~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2010-8~	AVM		x	x	
Dualis \ J10 \ 2010-8~	ABS	x	x	x	

Dualis \ J10 \ 2010-8~	Air bag	x	x	x	
Dualis \ J10 \ 2010-8~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Dualis \ J10 \ 2012-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2012-1~	BCM	x	x		
Dualis \ J10 \ 2012-1~	Transmission	x	x	x	
Dualis \ J10 \ 2012-1~	Multi AV		x	x	
Dualis \ J10 \ 2012-1~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2012-1~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2012-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2012-1~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2012-1~	EMCM	x	x	x	
Dualis \ J10 \ 2012-1~	AVM		x	x	
Dualis \ J10 \ 2012-1~	ABS	x	x	x	
Dualis \ J10 \ 2012-1~	Air bag	x	x	x	
Dualis \ J10 \ 2012-1~	Head lamp levelizer	x	x	x	
Dualis \ J10 \ 2012-6~	Engine	x	x	x	0107, 0126, 0109, 0064, 0148, 0099, 0020, 0340, 0166, 0103, 0172, 0191, 0252, 0193, 0011, 0216, 0036, 0086, 0153, 0212, 0112, 0139, 0276, 0275, 0177, 0176, 0233, 0234, 0154, 0209, 0278, 0206, 0262, 0023, 0260, 0226, 0010, 0094, 0095, 0220
Dualis \ J10 \ 2012-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Dualis \ J10 \ 2012-6~	BCM	x	x		
Dualis \ J10 \ 2012-6~	Transmission	x	x	x	0102
Dualis \ J10 \ 2012-6~	Multi AV		x	x	
Dualis \ J10 \ 2012-6~	EPS/DAST 3	x	x	x	
Dualis \ J10 \ 2012-6~	IPDM E/R	x	x	x	
Dualis \ J10 \ 2012-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Dualis \ J10 \ 2012-6~	All mode AWD/4WD	x	x	x	0245, 0311
Dualis \ J10 \ 2012-6~	AVM		x	x	
Dualis \ J10 \ 2012-6~	ABS	x	x	x	
Dualis \ J10 \ 2012-6~	Air bag	x	x	x	
Dualis \ J10 \ 2012-6~	Head lamp levelizer	x	x	x	

e-NV200 \ ME0 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
e-NV200 \ ME0 \ 2014-4~	ABS		x	x	
e-NV200 \ ME0 \ 2014-4~	Meter/M&A		x	x	0143
e-NV200 \ ME0 \ 2014-4~	BCM		x		
e-NV200 \ ME0 \ 2014-4~	Air bag		x	x	
e-NV200 \ ME0 \ 2014-4~	ICC/ADAS	x	x	x	
e-NV200 \ ME0 \ 2014-4~	HVAC		x	x	
e-NV200 \ ME0 \ 2014-4~	Multi AV		x	x	
e-NV200 \ ME0 \ 2014-4~	Motor control		x	x	
e-NV200 \ ME0 \ 2014-4~	EPS/DAST 3	x	x	x	
e-NV200 \ ME0 \ 2014-4~	IPDM E/R		x	x	
e-NV200 \ ME0 \ 2014-4~	Air pressure monitor		x	x	
e-NV200 \ ME0 \ 2014-4~	Shift		x	x	0204
e-NV200 \ ME0 \ 2014-4~	EV/HEV	x	x	x	0053
e-NV200 \ ME0 \ 2014-4~	HV battery		x	x	0251
e-NV200 \ ME0 \ 2014-4~	VSP		x	x	
e-NV200 \ ME0 \ 2014-4~	Charger/PD module		x	x	0065
e-NV200 \ ME0 \ 2014-4~	Telematics		x	x	0253
e-NV200 \ ME0 \ 2014-4~	HAS		x	x	0002, 0019, 0211, 0222, 0273, 0320, 0321
e-NV200 \ ME0 \ 2014-4~	AVM		x	x	
e-NV200 \ ME0 \ 2014-4~	Head lamp levelizer	x	x	x	
e-NV200 \ ME0 \ 2014-4~	Occupant detection			x	
e-NV200 \ ME0 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
e-NV200 \ ME0 \ 2014-6~	ABS		x	x	
e-NV200 \ ME0 \ 2014-6~	Meter/M&A		x	x	0143
e-NV200 \ ME0 \ 2014-6~	BCM		x		
e-NV200 \ ME0 \ 2014-6~	Air bag		x	x	
e-NV200 \ ME0 \ 2014-6~	ICC/ADAS	x	x	x	
e-NV200 \ ME0 \ 2014-6~	HVAC		x	x	
e-NV200 \ ME0 \ 2014-6~	Multi AV	x	x	x	0280
e-NV200 \ ME0 \ 2014-6~	EHS/PKB		x	x	
e-NV200 \ ME0 \ 2014-6~	Motor control		x	x	
e-NV200 \ ME0 \ 2014-6~	EPS/DAST 3	x	x	x	
e-NV200 \ ME0 \ 2014-6~	IPDM E/R		x	x	
e-NV200 \ ME0 \ 2014-6~	Air pressure monitor		x	x	
e-NV200 \ ME0 \ 2014-6~	EV/HEV	x	x	x	0053
e-NV200 \ ME0 \ 2014-6~	HV battery		x	x	0251
e-NV200 \ ME0 \ 2014-6~	VSP		x	x	

e-NV200 \ ME0 \ 2014-6~	Charger/PD module		x	x	0065
e-NV200 \ ME0 \ 2014-6~	Telematics		x	x	0253
e-NV200 \ ME0 \ 2014-6~	HAS		x	x	0002, 0019, 0211, 0222, 0273, 0320, 0321
e-NV200 \ ME0 \ 2014-6~	Head lamp levelizer	x	x	x	
e-NV200 \ ME0 \ 2014-6~	Occupant detection			x	
e-NV200 \ ME0 \ 2014-6~	Shift		x	x	0204
e-NV200 \ ME0 \ 2014-6~	EV/HEV		x	x	
e-NV200 \ ME0 \ 2014-6~	HV battery		x	x	
e-NV200 \ ME0 \ 2014-6~	Charger/PD module		x	x	
e-NV200 \ ME0 \ 2014-6~	AVM		x	x	
Elgrand \ E50 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E50 \ All Year	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E50 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E50 \ All Year	BCM	x	x		
Elgrand \ E50 \ All Year	Air bag	x	x	x	
Elgrand \ E50 \ All Year	ICC/ADAS	x	x	x	
Elgrand \ E50 \ All Year	HVAC	x	x	x	
Elgrand \ E50 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E50 \ All Year	Multi AV	x	x	x	0280
Elgrand \ E50 \ All Year	EPS/DAST 3	x	x	x	
Elgrand \ E50 \ All Year	IPDM E/R	x	x	x	
Elgrand \ E50 \ All Year	Air pressure monitor	x	x	x	
Elgrand \ E50 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E50 \ All Year	DIU	x	x	x	
Elgrand \ E50 \ All Year	Auto slide door	x	x	x	
Elgrand \ E50 \ All Year	Auto drive position	x	x	x	
Elgrand \ E50 \ All Year	All mode AWD/4WD	x	x	x	
Elgrand \ E50 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E50 \ All Year	Sonar	x	x	x	
Elgrand \ E50 \ All Year	Lane camera	x	x	x	
Elgrand \ E50 \ All Year	Adaptive light	x	x	x	
Elgrand \ E50 \ All Year	AVM		x	x	
Elgrand \ E50 \ All Year	Head lamp levelizer	x	x	x	
Elgrand \ E50 \ All Year	Difference lock	x	x	x	
Elgrand \ E50 \ All Year	Nats immu	x	x		
Elgrand \ E50 \ All Year	Smart entrance	x	x		
Elgrand \ E50 \ All Year	Air levelizer	x	x	x	

Elgrand \ E50 \ All Year	Rearview camera			x	
Elgrand \ E50 \ All Year	S/blind camera			x	
Elgrand \ E50 \ All Year	Motor assist	x	x	x	
Elgrand \ E51 \ 2002-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2002-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2002-5~	BCM	x	x		
Elgrand \ E51 \ 2002-5~	Air bag	x	x	x	
Elgrand \ E51 \ 2002-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2002-5~	Multi AV	x	x	x	
Elgrand \ E51 \ 2002-5~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2002-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2002-5~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2002-5~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2002-5~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2002-5~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2002-5~	ABS	x	x	x	
Elgrand \ E51 \ 2002-5~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2002-5~	Sonar	x	x	x	
Elgrand \ E51 \ 2002-5~	S/blind camera			x	
Elgrand \ E51 \ 2002-5~	Motor assist	x	x	x	
Elgrand \ E51 \ 2002-5~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2002-5~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2002-5~	HVAC	x	x	x	
Elgrand \ E51 \ 2002-5~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2002-5~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2002-5~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2002-5~	DIU	x	x	x	
Elgrand \ E51 \ 2002-5~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2002-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2002-5~	Lane camera	x	x	x	
Elgrand \ E51 \ 2002-5~	AVM		x	x	
Elgrand \ E51 \ 2002-5~	Difference lock	x	x	x	
Elgrand \ E51 \ 2002-5~	Nats immu	x	x		
Elgrand \ E51 \ 2002-5~	Smart entrance	x	x		
Elgrand \ E51 \ 2002-5~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2002-5~	Rearview camera			x	
Elgrand \ E51 \ 2003-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Elgrand \ E51 \ 2003-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2003-8~	BCM	x	x		
Elgrand \ E51 \ 2003-8~	Air bag	x	x	x	
Elgrand \ E51 \ 2003-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2003-8~	Multi AV	x	x	x	
Elgrand \ E51 \ 2003-8~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2003-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2003-8~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2003-8~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2003-8~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2003-8~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2003-8~	ABS	x	x	x	
Elgrand \ E51 \ 2003-8~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2003-8~	Sonar	x	x	x	
Elgrand \ E51 \ 2003-8~	S/blind camera			x	
Elgrand \ E51 \ 2003-8~	Motor assist	x	x	x	
Elgrand \ E51 \ 2003-8~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2003-8~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2003-8~	HVAC	x	x	x	
Elgrand \ E51 \ 2003-8~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2003-8~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2003-8~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2003-8~	DIU	x	x	x	
Elgrand \ E51 \ 2003-8~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2003-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2003-8~	Lane camera	x	x	x	
Elgrand \ E51 \ 2003-8~	AVM		x	x	
Elgrand \ E51 \ 2003-8~	Difference lock	x	x	x	
Elgrand \ E51 \ 2003-8~	Nats immu	x	x		
Elgrand \ E51 \ 2003-8~	Smart entrance	x	x		
Elgrand \ E51 \ 2003-8~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2003-8~	Rearview camera			x	
Elgrand \ E51 \ 2004-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2004-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2004-8~	BCM	x	x		
Elgrand \ E51 \ 2004-8~	Air bag	x	x	x	
Elgrand \ E51 \ 2004-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2004-8~	Multi AV	x	x	x	

Elgrand \ E51 \ 2004-8~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2004-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2004-8~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2004-8~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2004-8~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2004-8~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2004-8~	ABS	x	x	x	
Elgrand \ E51 \ 2004-8~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2004-8~	Sonar	x	x	x	
Elgrand \ E51 \ 2004-8~	S/blind camera			x	
Elgrand \ E51 \ 2004-8~	Motor assist	x	x	x	
Elgrand \ E51 \ 2004-8~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2004-8~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2004-8~	HVAC	x	x	x	
Elgrand \ E51 \ 2004-8~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2004-8~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2004-8~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2004-8~	DIU	x	x	x	
Elgrand \ E51 \ 2004-8~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2004-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2004-8~	Lane camera	x	x	x	
Elgrand \ E51 \ 2004-8~	AVM		x	x	
Elgrand \ E51 \ 2004-8~	Difference lock	x	x	x	
Elgrand \ E51 \ 2004-8~	Nats immu	x	x		
Elgrand \ E51 \ 2004-8~	Smart entrance	x	x		
Elgrand \ E51 \ 2004-8~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2004-8~	Rearview camera			x	
Elgrand \ E51 \ 2005-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2005-11~	BCM	x	x		
Elgrand \ E51 \ 2005-11~	Air bag	x	x	x	
Elgrand \ E51 \ 2005-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2005-11~	Multi AV	x	x	x	
Elgrand \ E51 \ 2005-11~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2005-11~	Auto slide door	x	x	x	

Elgrand \ E51 \ 2005-11~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2005-11~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2005-11~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2005-11~	ABS	x	x	x	
Elgrand \ E51 \ 2005-11~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2005-11~	Sonar	x	x	x	
Elgrand \ E51 \ 2005-11~	S/blind camera			x	
Elgrand \ E51 \ 2005-11~	Motor assist	x	x	x	
Elgrand \ E51 \ 2005-11~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2005-11~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2005-11~	HVAC	x	x	x	
Elgrand \ E51 \ 2005-11~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2005-11~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2005-11~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2005-11~	DIU	x	x	x	
Elgrand \ E51 \ 2005-11~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2005-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2005-11~	Lane camera	x	x	x	
Elgrand \ E51 \ 2005-11~	AVM		x	x	
Elgrand \ E51 \ 2005-11~	Difference lock	x	x	x	
Elgrand \ E51 \ 2005-11~	Nats immu	x	x		
Elgrand \ E51 \ 2005-11~	Smart entrance	x	x		
Elgrand \ E51 \ 2005-11~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2005-11~	Rearview camera			x	
Elgrand \ E51 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2006-12~	BCM	x	x		
Elgrand \ E51 \ 2006-12~	Air bag	x	x	x	
Elgrand \ E51 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2006-12~	Multi AV	x	x	x	
Elgrand \ E51 \ 2006-12~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2006-12~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2006-12~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2006-12~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2006-12~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2006-12~	ABS	x	x	x	
Elgrand \ E51 \ 2006-12~	Head lamp levelizer	x	x	x	

Elgrand \ E51 \ 2006-12~	Sonar	x	x	x	
Elgrand \ E51 \ 2006-12~	S/blind camera			x	
Elgrand \ E51 \ 2006-12~	Motor assist	x	x	x	
Elgrand \ E51 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2006-12~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2006-12~	HVAC	x	x	x	
Elgrand \ E51 \ 2006-12~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2006-12~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2006-12~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2006-12~	DIU	x	x	x	
Elgrand \ E51 \ 2006-12~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2006-12~	Lane camera	x	x	x	
Elgrand \ E51 \ 2006-12~	AVM		x	x	
Elgrand \ E51 \ 2006-12~	Difference lock	x	x	x	
Elgrand \ E51 \ 2006-12~	Nats immu	x	x		
Elgrand \ E51 \ 2006-12~	Smart entrance	x	x		
Elgrand \ E51 \ 2006-12~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2006-12~	Rearview camera			x	
Elgrand \ E51 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2007-6~	BCM	x	x		
Elgrand \ E51 \ 2007-6~	Air bag	x	x	x	
Elgrand \ E51 \ 2007-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2007-6~	Multi AV	x	x	x	
Elgrand \ E51 \ 2007-6~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2007-6~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2007-6~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2007-6~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2007-6~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2007-6~	ABS	x	x	x	
Elgrand \ E51 \ 2007-6~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2007-6~	Sonar	x	x	x	
Elgrand \ E51 \ 2007-6~	S/blind camera			x	
Elgrand \ E51 \ 2007-6~	Motor assist	x	x	x	
Elgrand \ E51 \ 2007-6~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2007-6~	ICC/ADAS	x	x	x	

Elgrand \ E51 \ 2007-6~	HVAC	x	x	x	
Elgrand \ E51 \ 2007-6~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2007-6~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2007-6~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2007-6~	DIU	x	x	x	
Elgrand \ E51 \ 2007-6~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2007-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2007-6~	Lane camera	x	x	x	
Elgrand \ E51 \ 2007-6~	AVM		x	x	
Elgrand \ E51 \ 2007-6~	Difference lock	x	x	x	
Elgrand \ E51 \ 2007-6~	Nats immu	x	x		
Elgrand \ E51 \ 2007-6~	Smart entrance	x	x		
Elgrand \ E51 \ 2007-6~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2007-6~	Rearview camera			x	
Elgrand \ E51 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2008-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2008-10~	BCM	x	x		
Elgrand \ E51 \ 2008-10~	Transmission	x	x	x	
Elgrand \ E51 \ 2008-10~	Multi AV	x	x	x	
Elgrand \ E51 \ 2008-10~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2008-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2008-10~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2008-10~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2008-10~	ABS	x	x	x	
Elgrand \ E51 \ 2008-10~	Air bag	x	x	x	
Elgrand \ E51 \ 2008-10~	Sonar	x	x	x	
Elgrand \ E51 \ 2008-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2008-9~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E51 \ 2008-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2008-9~	BCM	x	x		
Elgrand \ E51 \ 2008-9~	Air bag	x	x	x	
Elgrand \ E51 \ 2008-9~	ICC/ADAS	x	x	x	
Elgrand \ E51 \ 2008-9~	HVAC	x	x	x	
Elgrand \ E51 \ 2008-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E51 \ 2008-9~	Multi AV	x	x	x	0280
Elgrand \ E51 \ 2008-9~	EPS/DAST 3	x	x	x	
Elgrand \ E51 \ 2008-9~	IPDM E/R	x	x	x	

Elgrand \ E51 \ 2008-9~	Air pressure monitor	x	x	x	
Elgrand \ E51 \ 2008-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2008-9~	DIU	x	x	x	
Elgrand \ E51 \ 2008-9~	Auto slide door	x	x	x	
Elgrand \ E51 \ 2008-9~	Auto drive position	x	x	x	
Elgrand \ E51 \ 2008-9~	All mode AWD/4WD	x	x	x	
Elgrand \ E51 \ 2008-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Elgrand \ E51 \ 2008-9~	Sonar	x	x	x	
Elgrand \ E51 \ 2008-9~	Lane camera	x	x	x	
Elgrand \ E51 \ 2008-9~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2008-9~	AVM		x	x	
Elgrand \ E51 \ 2008-9~	Head lamp levelizer	x	x	x	
Elgrand \ E51 \ 2008-9~	Difference lock	x	x	x	
Elgrand \ E51 \ 2008-9~	Nats immu	x	x		
Elgrand \ E51 \ 2008-9~	Smart entrance	x	x		
Elgrand \ E51 \ 2008-9~	Air levelizer	x	x	x	
Elgrand \ E51 \ 2008-9~	Rearview camera			x	
Elgrand \ E51 \ 2008-9~	S/blind camera			x	
Elgrand \ E51 \ 2008-9~	Motor assist	x	x	x	
Elgrand \ E51 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E51 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E51 \ 2009-11~	BCM	x	x		
Elgrand \ E51 \ 2009-11~	Transmission	x	x	x	
Elgrand \ E51 \ 2009-11~	Multi AV	x	x	x	
Elgrand \ E51 \ 2009-11~	IPDM E/R	x	x	x	
Elgrand \ E51 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Elgrand \ E51 \ 2009-11~	Precrash seatbelt	x	x	x	
Elgrand \ E51 \ 2009-11~	Adaptive light	x	x	x	
Elgrand \ E51 \ 2009-11~	ABS	x	x	x	
Elgrand \ E51 \ 2009-11~	Air bag	x	x	x	
Elgrand \ E51 \ 2009-11~	Sonar	x	x	x	
Elgrand \ E52 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2010-7~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2010-7~	Meter/M&A		x	x	
Elgrand \ E52 \ 2010-7~	BCM		x		

Elgrand \ E52 \ 2010-7~	Air bag	x	x	x	
Elgrand \ E52 \ 2010-7~	ICC/ADAS		x	x	
Elgrand \ E52 \ 2010-7~	HVAC		x	x	
Elgrand \ E52 \ 2010-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E52 \ 2010-7~	Multi AV	x	x	x	
Elgrand \ E52 \ 2010-7~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2010-7~	IPDM E/R		x	x	
Elgrand \ E52 \ 2010-7~	Air pressure monitor	x	x	x	
Elgrand \ E52 \ 2010-7~	Laser/radar	x	x	x	
Elgrand \ E52 \ 2010-7~	Auto slide door		x	x	
Elgrand \ E52 \ 2010-7~	Precrash seatbelt		x	x	
Elgrand \ E52 \ 2010-7~	Auto drive position	x	x	x	
Elgrand \ E52 \ 2010-7~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2010-7~	4WAS(MAIN)/RAS/HICAS		x	x	
Elgrand \ E52 \ 2010-7~	Lane camera		x	x	
Elgrand \ E52 \ 2010-7~	Adaptive light	x	x	x	
Elgrand \ E52 \ 2010-7~	Auto slide door right		x	x	
Elgrand \ E52 \ 2010-7~	CAN gateway		x		
Elgrand \ E52 \ 2010-7~	Auto back door		x	x	
Elgrand \ E52 \ 2010-7~	4WAS(front)	x	x	x	
Elgrand \ E52 \ 2010-7~	E-SUS		x	x	
Elgrand \ E52 \ 2010-7~	Accele pedal ACT		x	x	
Elgrand \ E52 \ 2010-7~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2010-7~	Sonar	x	x	x	
Elgrand \ E52 \ 2010-7~	Pop up hood	x	x	x	
Elgrand \ E52 \ 2010-7~	Rearview camera			x	
Elgrand \ E52 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2010-8~	Meter/M&A		x	x	
Elgrand \ E52 \ 2010-8~	BCM		x		
Elgrand \ E52 \ 2010-8~	Air bag	x	x	x	
Elgrand \ E52 \ 2010-8~	ICC/ADAS		x	x	
Elgrand \ E52 \ 2010-8~	HVAC		x	x	
Elgrand \ E52 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E52 \ 2010-8~	Multi AV	x	x	x	
Elgrand \ E52 \ 2010-8~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2010-8~	IPDM E/R		x	x	
Elgrand \ E52 \ 2010-8~	Air pressure monitor	x	x	x	
Elgrand \ E52 \ 2010-8~	Laser/radar	x	x	x	
Elgrand \ E52 \ 2010-8~	Auto slide door		x	x	

Elgrand \ E52 \ 2010-8~	Precrash seatbelt		x	x	
Elgrand \ E52 \ 2010-8~	Auto drive position	x	x	x	
Elgrand \ E52 \ 2010-8~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2010-8~	4WAS(MAIN)/RAS/HICAS		x	x	
Elgrand \ E52 \ 2010-8~	Lane camera		x	x	
Elgrand \ E52 \ 2010-8~	Adaptive light	x	x	x	
Elgrand \ E52 \ 2010-8~	Auto slide door right		x	x	
Elgrand \ E52 \ 2010-8~	CAN gateway		x		
Elgrand \ E52 \ 2010-8~	Auto back door		x	x	
Elgrand \ E52 \ 2010-8~	4WAS(front)	x	x	x	
Elgrand \ E52 \ 2010-8~	E-SUS		x	x	
Elgrand \ E52 \ 2010-8~	Accele pedal ACT		x	x	
Elgrand \ E52 \ 2010-8~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2010-8~	Sonar	x	x	x	
Elgrand \ E52 \ 2010-8~	Pop up hood	x	x	x	
Elgrand \ E52 \ 2010-8~	Rearview camera			x	
Elgrand \ E52 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2011-11~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2011-11~	Meter/M&A		x	x	
Elgrand \ E52 \ 2011-11~	BCM		x		
Elgrand \ E52 \ 2011-11~	Air bag	x	x	x	
Elgrand \ E52 \ 2011-11~	Transmission	x	x	x	
Elgrand \ E52 \ 2011-11~	Multi AV		x	x	
Elgrand \ E52 \ 2011-11~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2011-11~	IPDM E/R		x	x	
Elgrand \ E52 \ 2011-11~	Air pressure monitor	x	x	x	
Elgrand \ E52 \ 2011-11~	Auto slide door		x	x	
Elgrand \ E52 \ 2011-11~	Auto drive position		x	x	
Elgrand \ E52 \ 2011-11~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2011-11~	Auto slide door right		x	x	
Elgrand \ E52 \ 2011-11~	CAN gateway		x		
Elgrand \ E52 \ 2011-11~	Auto back door		x	x	
Elgrand \ E52 \ 2011-11~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2011-11~	Sonar	x	x	x	
Elgrand \ E52 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2011-8~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2011-8~	Meter/M&A		x	x	
Elgrand \ E52 \ 2011-8~	BCM		x		
Elgrand \ E52 \ 2011-8~	Air bag	x	x	x	

Elgrand \ E52 \ 2011-8~	ICC/ADAS		x	x	
Elgrand \ E52 \ 2011-8~	HVAC		x	x	
Elgrand \ E52 \ 2011-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E52 \ 2011-8~	Multi AV	x	x	x	
Elgrand \ E52 \ 2011-8~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2011-8~	IPDM E/R		x	x	
Elgrand \ E52 \ 2011-8~	Auto slide door		x	x	
Elgrand \ E52 \ 2011-8~	Auto drive position		x	x	
Elgrand \ E52 \ 2011-8~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2011-8~	Sonar		x	x	
Elgrand \ E52 \ 2011-8~	Adaptive light	x	x	x	
Elgrand \ E52 \ 2011-8~	Auto slide door right		x	x	
Elgrand \ E52 \ 2011-8~	CAN gateway		x		
Elgrand \ E52 \ 2011-8~	Auto back door		x	x	
Elgrand \ E52 \ 2011-8~	Accele pedal ACT		x	x	
Elgrand \ E52 \ 2011-8~	AVM		x	x	
Elgrand \ E52 \ 2011-8~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2011-8~	Rearview camera			x	
Elgrand \ E52 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2012-11~	Meter/M&A		x	x	
Elgrand \ E52 \ 2012-11~	BCM		x		
Elgrand \ E52 \ 2012-11~	Air bag	x	x	x	
Elgrand \ E52 \ 2012-11~	HVAC		x	x	
Elgrand \ E52 \ 2012-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Elgrand \ E52 \ 2012-11~	Multi AV		x	x	
Elgrand \ E52 \ 2012-11~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2012-11~	IPDM E/R		x	x	
Elgrand \ E52 \ 2012-11~	Auto slide door		x	x	
Elgrand \ E52 \ 2012-11~	Auto drive position		x	x	
Elgrand \ E52 \ 2012-11~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2012-11~	Adaptive light	x	x	x	
Elgrand \ E52 \ 2012-11~	Auto slide door right		x	x	
Elgrand \ E52 \ 2012-11~	CAN gateway		x		
Elgrand \ E52 \ 2012-11~	Auto back door		x	x	
Elgrand \ E52 \ 2012-11~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2012-11~	Sonar	x	x	x	
Elgrand \ E52 \ 2012-11~	Occupant detection			x	

Elgrand \ E52 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2012-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E52 \ 2012-12~	BCM		x		
Elgrand \ E52 \ 2012-12~	Air bag	x	x	x	
Elgrand \ E52 \ 2012-12~	ICC/ADAS		x	x	
Elgrand \ E52 \ 2012-12~	HVAC		x	x	
Elgrand \ E52 \ 2012-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Elgrand \ E52 \ 2012-12~	Multi AV		x	x	
Elgrand \ E52 \ 2012-12~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2012-12~	IPDM E/R		x	x	
Elgrand \ E52 \ 2012-12~	Auto slide door		x	x	
Elgrand \ E52 \ 2012-12~	Auto drive position		x	x	
Elgrand \ E52 \ 2012-12~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2012-12~	Sonar		x	x	
Elgrand \ E52 \ 2012-12~	Adaptive light	x	x	x	
Elgrand \ E52 \ 2012-12~	Auto slide door right		x	x	
Elgrand \ E52 \ 2012-12~	CAN gateway		x		
Elgrand \ E52 \ 2012-12~	Auto back door		x	x	
Elgrand \ E52 \ 2012-12~	Accele pedal ACT		x	x	
Elgrand \ E52 \ 2012-12~	AVM		x	x	
Elgrand \ E52 \ 2012-12~	PMAS		x	x	
Elgrand \ E52 \ 2012-12~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Elgrand \ E52 \ 2013-12~	ABS	x	x	x	0003, 0092, 0264
Elgrand \ E52 \ 2013-12~	Meter/M&A	x	x	x	0143, 0330, 0197, 0143, 0331
Elgrand \ E52 \ 2013-12~	BCM		x		
Elgrand \ E52 \ 2013-12~	Air bag	x	x	x	
Elgrand \ E52 \ 2013-12~	ICC/ADAS		x	x	
Elgrand \ E52 \ 2013-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Elgrand \ E52 \ 2013-12~	Multi AV		x	x	
Elgrand \ E52 \ 2013-12~	EPS/DAST 3		x	x	
Elgrand \ E52 \ 2013-12~	IPDM E/R		x	x	
Elgrand \ E52 \ 2013-12~	Auto slide door		x	x	
Elgrand \ E52 \ 2013-12~	Auto drive position		x	x	
Elgrand \ E52 \ 2013-12~	All mode AWD/4WD		x	x	
Elgrand \ E52 \ 2013-12~	Sonar		x	x	
Elgrand \ E52 \ 2013-12~	Adaptive light	x	x	x	

Elgrand \ E52 \ 2013-12~	Auto slide door right		x	x	
Elgrand \ E52 \ 2013-12~	CAN gateway		x		
Elgrand \ E52 \ 2013-12~	Auto back door		x	x	
Elgrand \ E52 \ 2013-12~	AVM		x	x	
Elgrand \ E52 \ 2013-12~	PMAS		x	x	
Elgrand \ E52 \ 2013-12~	Head lamp levelizer	x	x	x	
Elgrand \ E52 \ 2013-12~	Occupant detection			x	
Elgrand \ E52 \ 2013-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Elgrand \ E52 \ 2013-12~	Sonar	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ELGRAND-QUEST \ E52 \ 2011-3~	ABS	x	x	x	0003, 0092, 0264
ELGRAND-QUEST \ E52 \ 2011-3~	Meter/M&A		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	BCM		x		
ELGRAND-QUEST \ E52 \ 2011-3~	Air bag	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	ICC/ADAS		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	HVAC		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
ELGRAND-QUEST \ E52 \ 2011-3~	Multi AV	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	EPS/DAST 3		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	IPDM E/R		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Air pressure monitor	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Laser/radar	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Auto slide door		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Precrash seatbelt		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Auto drive position	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	All mode AWD/4WD		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	4WAS(MAIN)/RAS/HICAS		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Lane camera		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Adaptive light	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Auto slide door right		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	CAN gateway		x		
ELGRAND-QUEST \ E52 \ 2011-3~	Auto back door		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	4WAS(front)	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	E-SUS		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Accele pedal ACT		x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Head lamp levelizer	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Sonar	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Pop up hood	x	x	x	
ELGRAND-QUEST \ E52 \ 2011-3~	Rearview camera			x	

ELGRAND-QUEST \ E52 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ELGRAND-QUEST \ E52 \ 2014-11~	ABS	x	x	x	0003, 0092, 0264
ELGRAND-QUEST \ E52 \ 2014-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
ELGRAND-QUEST \ E52 \ 2014-11~	BCM		x		
ELGRAND-QUEST \ E52 \ 2014-11~	Air bag	x	x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	ICC/ADAS		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
ELGRAND-QUEST \ E52 \ 2014-11~	Multi AV		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	EPS/DAST 3		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	IPDM E/R		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Laser/radar	x	x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Auto slide door		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Auto drive position		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	All mode AWD/4WD	x	x	x	0245, 0311
ELGRAND-QUEST \ E52 \ 2014-11~	Sonar	x	x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Adaptive light	x	x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Auto slide door right		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	CAN gateway		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Auto back door		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Side radar left		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Side radar right		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Telematics		x	x	0253
ELGRAND-QUEST \ E52 \ 2014-11~	BSW/buzzer		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	AVM		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	PMAS		x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Head lamp levelizer	x	x	x	
ELGRAND-QUEST \ E52 \ 2014-11~	Occupant detection			x	
ELGRAND-QUEST \ E52 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ELGRAND-QUEST \ E52 \ 2016-2~	ABS	x	x	x	0003, 0092, 0264
ELGRAND-QUEST \ E52 \ 2016-2~	Meter/M&A		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	BCM		x		
ELGRAND-QUEST \ E52 \ 2016-2~	Air bag	x	x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	ICC/ADAS	x	x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	HVAC		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
ELGRAND-QUEST \ E52 \ 2016-2~	Multi AV		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	EPS/DAST 3		x	x	

ELGRAND-QUEST \ E52 \ 2016-2~	IPDM E/R		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Auto slide door		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	All mode AWD/4WD		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Adaptive light	x	x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Auto slide door right		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Auto back door		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Side radar left		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Side radar right		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Telematics		x	x	0253
ELGRAND-QUEST \ E52 \ 2016-2~	AVM		x	x	
ELGRAND-QUEST \ E52 \ 2016-2~	Occupant detection			x	
Evalia \ M20(VM20) \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Evalia \ M20(VM20) \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
Evalia \ M20(VM20) \ 2012-6~	Meter/M&A		x	x	
Evalia \ M20(VM20) \ 2012-6~	BCM	x	x		
Evalia \ M20(VM20) \ 2012-6~	Air bag	x	x	x	
Evalia \ M20(VM20) \ 2012-6~	EPS/DAST 3	x	x	x	
Evalia \ M20(VM20) \ 2012-6~	IPDM E/R	x	x	x	
Evalia \ M20(VM20) \ 2012-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Evalia \ M20(VM20) \ 2012-6~	Auto slide door		x	x	
Evalia \ M20(VM20) \ 2012-6~	Occupant detection			x	
Evalia \ M20(VM20) \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Evalia \ M20(VM20) \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Evalia \ M20(VM20) \ 2012-8~	Meter/M&A		x	x	
Evalia \ M20(VM20) \ 2012-8~	BCM	x	x		
Evalia \ M20(VM20) \ 2012-8~	Air bag	x	x	x	
Evalia \ M20(VM20) \ 2012-8~	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Evalia \ M20(VM20) \ 2012-8~	Multi AV	x	x	x	0280
Evalia \ M20(VM20) \ 2012-8~	EPS/DAST 3	x	x	x	
Evalia \ M20(VM20) \ 2012-8~	IPDM E/R	x	x	x	
Evalia \ M20(VM20) \ 2012-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Evalia \ M20(VM20) \ 2012-8~	Auto slide door		x	x	
Evalia \ M20(VM20) \ 2012-8~	PTC heater		x	x	
Evalia \ M20(VM20) \ 2012-8~	Occupant detection			x	

Evalia \ M20(VM20) \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Evalia \ M20(VM20) \ 2014-3~	ABS	x	x	x	0003, 0092, 0264
Evalia \ M20(VM20) \ 2014-3~	Meter/M&A		x	x	
Evalia \ M20(VM20) \ 2014-3~	BCM	x	x		
Evalia \ M20(VM20) \ 2014-3~	Air bag	x	x	x	
Evalia \ M20(VM20) \ 2014-3~	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Evalia \ M20(VM20) \ 2014-3~	EPS/DAST 3	x	x	x	
Evalia \ M20(VM20) \ 2014-3~	IPDM E/R	x	x	x	
Evalia \ M20(VM20) \ 2014-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Evalia \ M20(VM20) \ 2014-3~	PTC heater		x	x	
Evalia \ M20(VM20) \ 2014-3~	Occupant detection			x	
Fairlady Z \ HZ34 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ HZ34 \ 2009-9~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ HZ34 \ 2009-9~	Meter/M&A		x	x	
Fairlady Z \ HZ34 \ 2009-9~	BCM		x		
Fairlady Z \ HZ34 \ 2009-9~	Air bag	x	x	x	
Fairlady Z \ HZ34 \ 2009-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ HZ34 \ 2009-9~	Transmission		x	x	0059
Fairlady Z \ HZ34 \ 2009-9~	Multi AV		x	x	
Fairlady Z \ HZ34 \ 2009-9~	IPDM E/R		x	x	
Fairlady Z \ HZ34 \ 2009-9~	Convertible roof		x	x	
Fairlady Z \ HZ34 \ 2009-9~	E-SUS		x	x	
Fairlady Z \ HZ34 \ 2009-9~	Head lamp levelizer	x	x	x	
Fairlady Z \ HZ34 \ 2009-9~	Pop up hood	x	x	x	
Fairlady Z \ HZ34 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ HZ34 \ 2010-10~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ HZ34 \ 2010-10~	Meter/M&A		x	x	
Fairlady Z \ HZ34 \ 2010-10~	BCM		x		
Fairlady Z \ HZ34 \ 2010-10~	Air bag	x	x	x	
Fairlady Z \ HZ34 \ 2010-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ HZ34 \ 2010-10~	Transmission		x	x	0059
Fairlady Z \ HZ34 \ 2010-10~	Multi AV		x	x	
Fairlady Z \ HZ34 \ 2010-10~	IPDM E/R		x	x	

Fairlady Z \ HZ34 \ 2010-10~	Convertible roof		x	x	
Fairlady Z \ HZ34 \ 2010-10~	E-SUS		x	x	
Fairlady Z \ HZ34 \ 2010-10~	Head lamp levelizer	x	x	x	
Fairlady Z \ HZ34 \ 2010-10~	Pop up hood	x	x	x	
Fairlady Z \ HZ34 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ HZ34 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ HZ34 \ 2012-6~	Meter/M&A		x	x	
Fairlady Z \ HZ34 \ 2012-6~	BCM		x		
Fairlady Z \ HZ34 \ 2012-6~	Air bag	x	x	x	
Fairlady Z \ HZ34 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ HZ34 \ 2012-6~	Transmission		x	x	0059
Fairlady Z \ HZ34 \ 2012-6~	Multi AV		x	x	
Fairlady Z \ HZ34 \ 2012-6~	IPDM E/R		x	x	
Fairlady Z \ HZ34 \ 2012-6~	Convertible roof		x	x	
Fairlady Z \ HZ34 \ 2012-6~	Head lamp levelizer	x	x	x	
Fairlady Z \ HZ34 \ 2012-6~	Pop up hood	x	x	x	
Fairlady Z \ HZ34 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ HZ34 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ HZ34 \ 2014-7~	Meter/M&A		x	x	
Fairlady Z \ HZ34 \ 2014-7~	BCM		x		
Fairlady Z \ HZ34 \ 2014-7~	Air bag	x	x	x	
Fairlady Z \ HZ34 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ HZ34 \ 2014-7~	Transmission		x	x	0059
Fairlady Z \ HZ34 \ 2014-7~	Multi AV		x	x	
Fairlady Z \ HZ34 \ 2014-7~	EPS/DAST 3	x	x	x	
Fairlady Z \ HZ34 \ 2014-7~	IPDM E/R		x	x	
Fairlady Z \ HZ34 \ 2014-7~	Convertible roof		x	x	
Fairlady Z \ HZ34 \ 2014-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fairlady Z \ HZ34 \ 2014-7~	Pop up hood	x	x	x	
Fairlady Z \ HZ34 \ 2014-7~	AVM		x	x	
Fairlady Z \ HZ34 \ 2014-7~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z33 \ 2002-7~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z33 \ 2002-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Fairlady Z \ Z33 \ 2002-7~	BCM	x	x		
Fairlady Z \ Z33 \ 2002-7~	Air bag	x	x	x	

Fairlady Z \ Z33 \ 2002-7~	ICC/ADAS	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	HVAC	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Fairlady Z \ Z33 \ 2002-7~	Multi AV	x	x	x	0280
Fairlady Z \ Z33 \ 2002-7~	EPS/DAST 3	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	IPDM E/R	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Air pressure monitor	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Fairlady Z \ Z33 \ 2002-7~	DIU	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Auto slide door	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Auto drive position	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	All mode AWD/4WD	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Sonar	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Lane camera	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Adaptive light	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	AVM		x	x	
Fairlady Z \ Z33 \ 2002-7~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Difference lock	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Nats immu	x	x		
Fairlady Z \ Z33 \ 2002-7~	Smart entrance	x	x		
Fairlady Z \ Z33 \ 2002-7~	Air levelizer	x	x	x	
Fairlady Z \ Z33 \ 2002-7~	Rearview camera			x	
Fairlady Z \ Z33 \ 2002-7~	S/blind camera			x	
Fairlady Z \ Z33 \ 2002-7~	Motor assist	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z33 \ 2003-10~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z33 \ 2003-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Fairlady Z \ Z33 \ 2003-10~	BCM	x	x		
Fairlady Z \ Z33 \ 2003-10~	Air bag	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	ICC/ADAS	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	HVAC	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Fairlady Z \ Z33 \ 2003-10~	Multi AV	x	x	x	0280
Fairlady Z \ Z33 \ 2003-10~	EPS/DAST 3	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	IPDM E/R	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Air pressure monitor	x	x	x	

Fairlady Z \ Z33 \ 2003-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Fairlady Z \ Z33 \ 2003-10~	DIU	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Auto slide door	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Auto drive position	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	All mode AWD/4WD	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Sonar	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Lane camera	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Adaptive light	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	AVM		x	x	
Fairlady Z \ Z33 \ 2003-10~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Difference lock	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Nats immu	x	x		
Fairlady Z \ Z33 \ 2003-10~	Smart entrance	x	x		
Fairlady Z \ Z33 \ 2003-10~	Air levelizer	x	x	x	
Fairlady Z \ Z33 \ 2003-10~	Rearview camera			x	
Fairlady Z \ Z33 \ 2003-10~	S/blind camera			x	
Fairlady Z \ Z33 \ 2003-10~	Motor assist	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z33 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z33 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Fairlady Z \ Z33 \ 2004-9~	BCM	x	x		
Fairlady Z \ Z33 \ 2004-9~	Air bag	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	ICC/ADAS	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	HVAC	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Fairlady Z \ Z33 \ 2004-9~	Multi AV	x	x	x	0280
Fairlady Z \ Z33 \ 2004-9~	EPS/DAST 3	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	IPDM E/R	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Air pressure monitor	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Fairlady Z \ Z33 \ 2004-9~	DIU	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Auto slide door	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Auto drive position	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	All mode AWD/4WD	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Fairlady Z \ Z33 \ 2004-9~	Sonar	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Lane camera	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Adaptive light	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	AVM		x	x	
Fairlady Z \ Z33 \ 2004-9~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Difference lock	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Nats immu	x	x		
Fairlady Z \ Z33 \ 2004-9~	Smart entrance	x	x		
Fairlady Z \ Z33 \ 2004-9~	Air levelizer	x	x	x	
Fairlady Z \ Z33 \ 2004-9~	Rearview camera			x	
Fairlady Z \ Z33 \ 2004-9~	S/blind camera			x	
Fairlady Z \ Z33 \ 2004-9~	Motor assist	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z33 \ 2005-9~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z33 \ 2005-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Fairlady Z \ Z33 \ 2005-9~	BCM	x	x		
Fairlady Z \ Z33 \ 2005-9~	Air bag	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	ICC/ADAS	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	HVAC	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Fairlady Z \ Z33 \ 2005-9~	Multi AV	x	x	x	0280
Fairlady Z \ Z33 \ 2005-9~	EPS/DAST 3	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	IPDM E/R	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Air pressure monitor	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Fairlady Z \ Z33 \ 2005-9~	DIU	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Auto slide door	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Auto drive position	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	All mode AWD/4WD	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Sonar	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Lane camera	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Adaptive light	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	AVM		x	x	
Fairlady Z \ Z33 \ 2005-9~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Difference lock	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Nats immu	x	x		
Fairlady Z \ Z33 \ 2005-9~	Smart entrance	x	x		

Fairlady Z \ Z33 \ 2005-9~	Air levelizer	x	x	x	
Fairlady Z \ Z33 \ 2005-9~	Rearview camera			x	
Fairlady Z \ Z33 \ 2005-9~	S/blind camera			x	
Fairlady Z \ Z33 \ 2005-9~	Motor assist	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z33 \ 2007-1~	Meter/M&A	x	x	x	0143, 0331
Fairlady Z \ Z33 \ 2007-1~	BCM	x	x		
Fairlady Z \ Z33 \ 2007-1~	HVAC	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	Transmission	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	IPDM E/R	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	ABS	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	Air bag	x	x	x	
Fairlady Z \ Z33 \ 2007-1~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2008-10~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2008-10~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2008-10~	BCM		x		
Fairlady Z \ Z34 \ 2008-10~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2008-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2008-10~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2008-10~	Multi AV	x	x	x	
Fairlady Z \ Z34 \ 2008-10~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2008-10~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2008-10~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2009-9~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2009-9~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2009-9~	BCM		x		
Fairlady Z \ Z34 \ 2009-9~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2009-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2009-9~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2009-9~	Multi AV		x	x	
Fairlady Z \ Z34 \ 2009-9~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2009-9~	Convertible roof		x	x	
Fairlady Z \ Z34 \ 2009-9~	E-SUS		x	x	
Fairlady Z \ Z34 \ 2009-9~	Telematics		x	x	

Fairlady Z \ Z34 \ 2009-9~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2009-9~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2010-10~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2010-10~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2010-10~	BCM		x		
Fairlady Z \ Z34 \ 2010-10~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2010-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2010-10~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2010-10~	Multi AV	x	x	x	
Fairlady Z \ Z34 \ 2010-10~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2010-10~	Telematics		x	x	
Fairlady Z \ Z34 \ 2010-10~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2010-10~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2012-6~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2012-6~	BCM		x		
Fairlady Z \ Z34 \ 2012-6~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2012-6~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2012-6~	Multi AV		x	x	
Fairlady Z \ Z34 \ 2012-6~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2012-6~	Telematics		x	x	
Fairlady Z \ Z34 \ 2012-6~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2012-6~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2014-7~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2014-7~	BCM		x		
Fairlady Z \ Z34 \ 2014-7~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2014-7~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2014-7~	Multi AV		x	x	
Fairlady Z \ Z34 \ 2014-7~	EPS/DAST 3	x	x	x	

Fairlady Z \ Z34 \ 2014-7~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2014-7~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2014-7~	Telematics		x	x	
Fairlady Z \ Z34 \ 2014-7~	AVM		x	x	
Fairlady Z \ Z34 \ 2014-7~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2015-6~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2015-6~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2015-6~	BCM		x		
Fairlady Z \ Z34 \ 2015-6~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2015-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2015-6~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2015-6~	Multi AV		x	x	
Fairlady Z \ Z34 \ 2015-6~	EPS/DAST 3	x	x	x	
Fairlady Z \ Z34 \ 2015-6~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2015-6~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2015-6~	ANC		x	x	
Fairlady Z \ Z34 \ 2015-6~	HIGH BEAM ASSIST	x	x	x	
Fairlady Z \ Z34 \ 2015-6~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fairlady Z \ Z34 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
Fairlady Z \ Z34 \ 2016-7~	Meter/M&A		x	x	
Fairlady Z \ Z34 \ 2016-7~	BCM		x		
Fairlady Z \ Z34 \ 2016-7~	Air bag	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Fairlady Z \ Z34 \ 2016-7~	Transmission		x	x	0059
Fairlady Z \ Z34 \ 2016-7~	Multi AV		x	x	
Fairlady Z \ Z34 \ 2016-7~	IPDM E/R		x	x	
Fairlady Z \ Z34 \ 2016-7~	Auto drive position	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	Adaptive light	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	Pop up hood	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	ANC		x	x	
Fairlady Z \ Z34 \ 2016-7~	Head lamp levelizer	x	x	x	
Fairlady Z \ Z34 \ 2016-7~	Occupant detection			x	
Frontier \ D22 \ 1998	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 1998	ABS	x	x	x	0003, 0092, 0264

Frontier \ D22 \ 1998	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 1998	BCM	x	x		
Frontier \ D22 \ 1998	Air bag	x	x	x	
Frontier \ D22 \ 1998	ICC/ADAS	x	x	x	
Frontier \ D22 \ 1998	HVAC	x	x	x	
Frontier \ D22 \ 1998	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 1998	Multi AV	x	x	x	0280
Frontier \ D22 \ 1998	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 1998	IPDM E/R	x	x	x	
Frontier \ D22 \ 1998	Air pressure monitor	x	x	x	
Frontier \ D22 \ 1998	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 1998	DIU	x	x	x	
Frontier \ D22 \ 1998	Auto slide door	x	x	x	
Frontier \ D22 \ 1998	Auto drive position	x	x	x	
Frontier \ D22 \ 1998	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 1998	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 1998	Sonar	x	x	x	
Frontier \ D22 \ 1998	Lane camera	x	x	x	
Frontier \ D22 \ 1998	Adaptive light	x	x	x	
Frontier \ D22 \ 1998	AVM		x	x	
Frontier \ D22 \ 1998	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 1998	Difference lock	x	x	x	
Frontier \ D22 \ 1998	Nats immu	x	x		
Frontier \ D22 \ 1998	Smart entrance	x	x		
Frontier \ D22 \ 1998	Air levelizer	x	x	x	
Frontier \ D22 \ 1998	Rearview camera			x	
Frontier \ D22 \ 1998	S/blind camera			x	
Frontier \ D22 \ 1998	Motor assist	x	x	x	
Frontier \ D22 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 1999	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 1999	BCM	x	x		
Frontier \ D22 \ 1999	Air bag	x	x	x	
Frontier \ D22 \ 1999	ICC/ADAS	x	x	x	
Frontier \ D22 \ 1999	HVAC	x	x	x	
Frontier \ D22 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 1999	Multi AV	x	x	x	0280
Frontier \ D22 \ 1999	EPS/DAST 3	x	x	x	

Frontier \ D22 \ 1999	IPDM E/R	x	x	x	
Frontier \ D22 \ 1999	Air pressure monitor	x	x	x	
Frontier \ D22 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 1999	DIU	x	x	x	
Frontier \ D22 \ 1999	Auto slide door	x	x	x	
Frontier \ D22 \ 1999	Auto drive position	x	x	x	
Frontier \ D22 \ 1999	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 1999	Sonar	x	x	x	
Frontier \ D22 \ 1999	Lane camera	x	x	x	
Frontier \ D22 \ 1999	Adaptive light	x	x	x	
Frontier \ D22 \ 1999	AVM		x	x	
Frontier \ D22 \ 1999	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 1999	Difference lock	x	x	x	
Frontier \ D22 \ 1999	Nats immu	x	x		
Frontier \ D22 \ 1999	Smart entrance	x	x		
Frontier \ D22 \ 1999	Air levelizer	x	x	x	
Frontier \ D22 \ 1999	Rearview camera			x	
Frontier \ D22 \ 1999	S/blind camera			x	
Frontier \ D22 \ 1999	Motor assist	x	x	x	
Frontier \ D22 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 2000	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 2000	BCM	x	x		
Frontier \ D22 \ 2000	Air bag	x	x	x	
Frontier \ D22 \ 2000	ICC/ADAS	x	x	x	
Frontier \ D22 \ 2000	HVAC	x	x	x	
Frontier \ D22 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 2000	Multi AV	x	x	x	0280
Frontier \ D22 \ 2000	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 2000	IPDM E/R	x	x	x	
Frontier \ D22 \ 2000	Air pressure monitor	x	x	x	
Frontier \ D22 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 2000	DIU	x	x	x	
Frontier \ D22 \ 2000	Auto slide door	x	x	x	
Frontier \ D22 \ 2000	Auto drive position	x	x	x	

Frontier \ D22 \ 2000	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 2000	Sonar	x	x	x	
Frontier \ D22 \ 2000	Lane camera	x	x	x	
Frontier \ D22 \ 2000	Adaptive light	x	x	x	
Frontier \ D22 \ 2000	AVM		x	x	
Frontier \ D22 \ 2000	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 2000	Difference lock	x	x	x	
Frontier \ D22 \ 2000	Nats immu	x	x		
Frontier \ D22 \ 2000	Smart entrance	x	x		
Frontier \ D22 \ 2000	Air levelizer	x	x	x	
Frontier \ D22 \ 2000	Rearview camera			x	
Frontier \ D22 \ 2000	S/blind camera			x	
Frontier \ D22 \ 2000	Motor assist	x	x	x	
Frontier \ D22 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 2001	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 2001	BCM	x	x		
Frontier \ D22 \ 2001	Air bag	x	x	x	
Frontier \ D22 \ 2001	ICC/ADAS	x	x	x	
Frontier \ D22 \ 2001	HVAC	x	x	x	
Frontier \ D22 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 2001	Multi AV	x	x	x	0280
Frontier \ D22 \ 2001	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 2001	IPDM E/R	x	x	x	
Frontier \ D22 \ 2001	Air pressure monitor	x	x	x	
Frontier \ D22 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 2001	DIU	x	x	x	
Frontier \ D22 \ 2001	Auto slide door	x	x	x	
Frontier \ D22 \ 2001	Auto drive position	x	x	x	
Frontier \ D22 \ 2001	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 2001	Sonar	x	x	x	
Frontier \ D22 \ 2001	Lane camera	x	x	x	
Frontier \ D22 \ 2001	Adaptive light	x	x	x	
Frontier \ D22 \ 2001	AVM		x	x	
Frontier \ D22 \ 2001	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 2001	Difference lock	x	x	x	

Frontier \ D22 \ 2001	Nats immu	x	x		
Frontier \ D22 \ 2001	Smart entrance	x	x		
Frontier \ D22 \ 2001	Air levelizer	x	x	x	
Frontier \ D22 \ 2001	Rearview camera			x	
Frontier \ D22 \ 2001	S/blind camera			x	
Frontier \ D22 \ 2001	Motor assist	x	x	x	
Frontier \ D22 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 2002	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 2002	BCM	x	x		
Frontier \ D22 \ 2002	Air bag	x	x	x	
Frontier \ D22 \ 2002	ICC/ADAS	x	x	x	
Frontier \ D22 \ 2002	HVAC	x	x	x	
Frontier \ D22 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 2002	Multi AV	x	x	x	0280
Frontier \ D22 \ 2002	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 2002	IPDM E/R	x	x	x	
Frontier \ D22 \ 2002	Air pressure monitor	x	x	x	
Frontier \ D22 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 2002	DIU	x	x	x	
Frontier \ D22 \ 2002	Auto slide door	x	x	x	
Frontier \ D22 \ 2002	Auto drive position	x	x	x	
Frontier \ D22 \ 2002	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 2002	Sonar	x	x	x	
Frontier \ D22 \ 2002	Lane camera	x	x	x	
Frontier \ D22 \ 2002	Adaptive light	x	x	x	
Frontier \ D22 \ 2002	AVM		x	x	
Frontier \ D22 \ 2002	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 2002	Difference lock	x	x	x	
Frontier \ D22 \ 2002	Nats immu	x	x		
Frontier \ D22 \ 2002	Smart entrance	x	x		
Frontier \ D22 \ 2002	Air levelizer	x	x	x	
Frontier \ D22 \ 2002	Rearview camera			x	
Frontier \ D22 \ 2002	S/blind camera			x	
Frontier \ D22 \ 2002	Motor assist	x	x	x	
Frontier \ D22 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Frontier \ D22 \ 2003	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 2003	BCM	x	x		
Frontier \ D22 \ 2003	Air bag	x	x	x	
Frontier \ D22 \ 2003	ICC/ADAS	x	x	x	
Frontier \ D22 \ 2003	HVAC	x	x	x	
Frontier \ D22 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 2003	Multi AV	x	x	x	0280
Frontier \ D22 \ 2003	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 2003	IPDM E/R	x	x	x	
Frontier \ D22 \ 2003	Air pressure monitor	x	x	x	
Frontier \ D22 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 2003	DIU	x	x	x	
Frontier \ D22 \ 2003	Auto slide door	x	x	x	
Frontier \ D22 \ 2003	Auto drive position	x	x	x	
Frontier \ D22 \ 2003	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 2003	Sonar	x	x	x	
Frontier \ D22 \ 2003	Lane camera	x	x	x	
Frontier \ D22 \ 2003	Adaptive light	x	x	x	
Frontier \ D22 \ 2003	AVM		x	x	
Frontier \ D22 \ 2003	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 2003	Difference lock	x	x	x	
Frontier \ D22 \ 2003	Nats immu	x	x		
Frontier \ D22 \ 2003	Smart entrance	x	x		
Frontier \ D22 \ 2003	Air levelizer	x	x	x	
Frontier \ D22 \ 2003	Rearview camera			x	
Frontier \ D22 \ 2003	S/blind camera			x	
Frontier \ D22 \ 2003	Motor assist	x	x	x	
Frontier \ D22 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D22 \ 2004	ABS	x	x	x	0003, 0092, 0264
Frontier \ D22 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D22 \ 2004	BCM	x	x		
Frontier \ D22 \ 2004	Air bag	x	x	x	
Frontier \ D22 \ 2004	ICC/ADAS	x	x	x	
Frontier \ D22 \ 2004	HVAC	x	x	x	
Frontier \ D22 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D22 \ 2004	Multi AV	x	x	x	0280

Frontier \ D22 \ 2004	EPS/DAST 3	x	x	x	
Frontier \ D22 \ 2004	IPDM E/R	x	x	x	
Frontier \ D22 \ 2004	Air pressure monitor	x	x	x	
Frontier \ D22 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D22 \ 2004	DIU	x	x	x	
Frontier \ D22 \ 2004	Auto slide door	x	x	x	
Frontier \ D22 \ 2004	Auto drive position	x	x	x	
Frontier \ D22 \ 2004	All mode AWD/4WD	x	x	x	
Frontier \ D22 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D22 \ 2004	Sonar	x	x	x	
Frontier \ D22 \ 2004	Lane camera	x	x	x	
Frontier \ D22 \ 2004	Adaptive light	x	x	x	
Frontier \ D22 \ 2004	AVM		x	x	
Frontier \ D22 \ 2004	Head lamp levelizer	x	x	x	
Frontier \ D22 \ 2004	Difference lock	x	x	x	
Frontier \ D22 \ 2004	Nats immu	x	x		
Frontier \ D22 \ 2004	Smart entrance	x	x		
Frontier \ D22 \ 2004	Air levelizer	x	x	x	
Frontier \ D22 \ 2004	Rearview camera			x	
Frontier \ D22 \ 2004	S/blind camera			x	
Frontier \ D22 \ 2004	Motor assist	x	x	x	
Frontier \ D40 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2005	ABS	x	x	x	0003, 0092, 0264
Frontier \ D40 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2005	BCM	x	x		
Frontier \ D40 \ 2005	Air bag	x	x	x	
Frontier \ D40 \ 2005	ICC/ADAS	x	x	x	
Frontier \ D40 \ 2005	HVAC	x	x	x	
Frontier \ D40 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D40 \ 2005	Multi AV	x	x	x	0280
Frontier \ D40 \ 2005	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2005	IPDM E/R	x	x	x	
Frontier \ D40 \ 2005	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2005	DIU	x	x	x	
Frontier \ D40 \ 2005	Auto slide door	x	x	x	

Frontier \ D40 \ 2005	Auto drive position	x	x	x	
Frontier \ D40 \ 2005	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D40 \ 2005	Sonar	x	x	x	
Frontier \ D40 \ 2005	Lane camera	x	x	x	
Frontier \ D40 \ 2005	Adaptive light	x	x	x	
Frontier \ D40 \ 2005	AVM		x	x	
Frontier \ D40 \ 2005	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2005	Difference lock	x	x	x	
Frontier \ D40 \ 2005	Nats immu	x	x		
Frontier \ D40 \ 2005	Smart entrance	x	x		
Frontier \ D40 \ 2005	Air levelizer	x	x	x	
Frontier \ D40 \ 2005	Rearview camera			x	
Frontier \ D40 \ 2005	S/blind camera			x	
Frontier \ D40 \ 2005	Motor assist	x	x	x	
Frontier \ D40 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2006	ABS	x	x	x	0003, 0092, 0264
Frontier \ D40 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2006	BCM	x	x		
Frontier \ D40 \ 2006	Air bag	x	x	x	
Frontier \ D40 \ 2006	ICC/ADAS	x	x	x	
Frontier \ D40 \ 2006	HVAC	x	x	x	
Frontier \ D40 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D40 \ 2006	Multi AV	x	x	x	0280
Frontier \ D40 \ 2006	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2006	IPDM E/R	x	x	x	
Frontier \ D40 \ 2006	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2006	DIU	x	x	x	
Frontier \ D40 \ 2006	Auto slide door	x	x	x	
Frontier \ D40 \ 2006	Auto drive position	x	x	x	
Frontier \ D40 \ 2006	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D40 \ 2006	Sonar	x	x	x	
Frontier \ D40 \ 2006	Lane camera	x	x	x	
Frontier \ D40 \ 2006	Adaptive light	x	x	x	
Frontier \ D40 \ 2006	AVM		x	x	
Frontier \ D40 \ 2006	Head lamp levelizer	x	x	x	

Frontier \ D40 \ 2006	Difference lock	x	x	x	
Frontier \ D40 \ 2006	Nats immu	x	x		
Frontier \ D40 \ 2006	Smart entrance	x	x		
Frontier \ D40 \ 2006	Air levelizer	x	x	x	
Frontier \ D40 \ 2006	Rearview camera			x	
Frontier \ D40 \ 2006	S/blind camera			x	
Frontier \ D40 \ 2006	Motor assist	x	x	x	
Frontier \ D40 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2007	ABS	x	x	x	0003, 0092, 0264
Frontier \ D40 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2007	BCM	x	x		
Frontier \ D40 \ 2007	Air bag	x	x	x	
Frontier \ D40 \ 2007	ICC/ADAS	x	x	x	
Frontier \ D40 \ 2007	HVAC	x	x	x	
Frontier \ D40 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D40 \ 2007	Multi AV	x	x	x	0280
Frontier \ D40 \ 2007	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2007	IPDM E/R	x	x	x	
Frontier \ D40 \ 2007	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2007	DIU	x	x	x	
Frontier \ D40 \ 2007	Auto slide door	x	x	x	
Frontier \ D40 \ 2007	Auto drive position	x	x	x	
Frontier \ D40 \ 2007	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D40 \ 2007	Sonar	x	x	x	
Frontier \ D40 \ 2007	Lane camera	x	x	x	
Frontier \ D40 \ 2007	Adaptive light	x	x	x	
Frontier \ D40 \ 2007	AVM		x	x	
Frontier \ D40 \ 2007	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2007	Difference lock	x	x	x	
Frontier \ D40 \ 2007	Nats immu	x	x		
Frontier \ D40 \ 2007	Smart entrance	x	x		
Frontier \ D40 \ 2007	Air levelizer	x	x	x	
Frontier \ D40 \ 2007	Rearview camera			x	
Frontier \ D40 \ 2007	S/blind camera			x	
Frontier \ D40 \ 2007	Motor assist	x	x	x	

Frontier \ D40 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2007-8~	BCM	x	x		
Frontier \ D40 \ 2007-8~	HVAC	x	x	x	
Frontier \ D40 \ 2007-8~	Transmission	x	x	x	
Frontier \ D40 \ 2007-8~	Multi AV	x	x	x	
Frontier \ D40 \ 2007-8~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2007-8~	Auto drive position	x	x	x	
Frontier \ D40 \ 2007-8~	ABS	x	x	x	
Frontier \ D40 \ 2007-8~	Air bag	x	x	x	
Frontier \ D40 \ 2007-8~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2008	ABS	x	x	x	0003, 0092, 0264
Frontier \ D40 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2008	BCM	x	x		
Frontier \ D40 \ 2008	Air bag	x	x	x	
Frontier \ D40 \ 2008	ICC/ADAS	x	x	x	
Frontier \ D40 \ 2008	HVAC	x	x	x	
Frontier \ D40 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier \ D40 \ 2008	Multi AV	x	x	x	0280
Frontier \ D40 \ 2008	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2008	IPDM E/R	x	x	x	
Frontier \ D40 \ 2008	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2008	DIU	x	x	x	
Frontier \ D40 \ 2008	Auto slide door	x	x	x	
Frontier \ D40 \ 2008	Auto drive position	x	x	x	
Frontier \ D40 \ 2008	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2008	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier \ D40 \ 2008	Sonar	x	x	x	
Frontier \ D40 \ 2008	Lane camera	x	x	x	
Frontier \ D40 \ 2008	Adaptive light	x	x	x	
Frontier \ D40 \ 2008	AVM		x	x	
Frontier \ D40 \ 2008	Head lamp levelizer	x	x	x	

Frontier \ D40 \ 2008	Difference lock	x	x	x	
Frontier \ D40 \ 2008	Nats immu	x	x		
Frontier \ D40 \ 2008	Smart entrance	x	x		
Frontier \ D40 \ 2008	Air levelizer	x	x	x	
Frontier \ D40 \ 2008	Rearview camera			x	
Frontier \ D40 \ 2008	S/blind camera			x	
Frontier \ D40 \ 2008	Motor assist	x	x	x	
Frontier \ D40 \ 2008-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2008-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2008-8~	BCM	x	x		
Frontier \ D40 \ 2008-8~	Air bag	x	x	x	
Frontier \ D40 \ 2008-8~	HVAC	x	x	x	
Frontier \ D40 \ 2008-8~	Transmission	x	x	x	
Frontier \ D40 \ 2008-8~	Multi AV	x	x	x	
Frontier \ D40 \ 2008-8~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2008-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2008-8~	Auto drive position	x	x	x	
Frontier \ D40 \ 2008-8~	ABS	x	x	x	
Frontier \ D40 \ 2008-8~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2008-8~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2008-8~	Difference lock	x	x	x	
Frontier \ D40 \ 2008-8~	SVT	x	x	x	
Frontier \ D40 \ 2008-8~	Rearview camera			x	
Frontier \ D40 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0282, 0252, 0216, 0103, 0233, 0281, 0234, 0212
Frontier \ D40 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2009	BCM	x	x		
Frontier \ D40 \ 2009	Air bag	x	x	x	
Frontier \ D40 \ 2009	HVAC	x	x	x	
Frontier \ D40 \ 2009	Transmission	x	x	x	
Frontier \ D40 \ 2009	Multi AV	x	x	x	
Frontier \ D40 \ 2009	IPDM E/R	x	x	x	
Frontier \ D40 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2009	Auto drive position	x	x	x	
Frontier \ D40 \ 2009	ABS	x	x	x	
Frontier \ D40 \ 2009	Head lamp levelizer	x	x	x	

Frontier \ D40 \ 2009	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2009	Difference lock	x	x	x	
Frontier \ D40 \ 2009	SVT	x	x	x	
Frontier \ D40 \ 2009	Rearview camera			x	
Frontier \ D40 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2009-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2009-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2009-7~	BCM	x	x		
Frontier \ D40 \ 2009-7~	HVAC	x	x	x	
Frontier \ D40 \ 2009-7~	Transmission	x	x	x	
Frontier \ D40 \ 2009-7~	Multi AV	x	x	x	
Frontier \ D40 \ 2009-7~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2009-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2009-7~	Auto drive position	x	x	x	
Frontier \ D40 \ 2009-7~	ABS	x	x	x	
Frontier \ D40 \ 2009-7~	Air bag	x	x	x	
Frontier \ D40 \ 2009-7~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2009-7~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2009-7~	Difference lock	x	x	x	
Frontier \ D40 \ 2009-7~	SVT	x	x	x	
Frontier \ D40 \ 2009-7~	Rearview camera			x	
Frontier \ D40 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2010	BCM	x	x		
Frontier \ D40 \ 2010	Air bag	x	x	x	
Frontier \ D40 \ 2010	HVAC	x	x	x	
Frontier \ D40 \ 2010	Transmission	x	x	x	0059
Frontier \ D40 \ 2010	Multi AV	x	x	x	
Frontier \ D40 \ 2010	IPDM E/R	x	x	x	
Frontier \ D40 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2010	Auto drive position	x	x	x	
Frontier \ D40 \ 2010	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2010	ABS	x	x	x	
Frontier \ D40 \ 2010	Head lamp levelizer	x	x	x	

Frontier \ D40 \ 2010	Difference lock	x	x	x	
Frontier \ D40 \ 2010	SVT	x	x	x	
Frontier \ D40 \ 2010	Rearview camera			x	
Frontier \ D40 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2010-10~	BCM	x	x		
Frontier \ D40 \ 2010-10~	Air bag	x	x	x	
Frontier \ D40 \ 2010-10~	HVAC	x	x	x	
Frontier \ D40 \ 2010-10~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2010-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2010-10~	Precrash seatbelt	x	x	x	
Frontier \ D40 \ 2010-10~	Auto drive position	x	x	x	
Frontier \ D40 \ 2010-10~	ABS	x	x	x	
Frontier \ D40 \ 2010-10~	Transmission	x	x	x	
Frontier \ D40 \ 2010-10~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2010-10~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2010-10~	Difference lock	x	x	x	
Frontier \ D40 \ 2010-10~	SVT	x	x	x	
Frontier \ D40 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2011	BCM	x	x		
Frontier \ D40 \ 2011	Air bag	x	x	x	
Frontier \ D40 \ 2011	HVAC	x	x	x	
Frontier \ D40 \ 2011	Transmission	x	x	x	0059
Frontier \ D40 \ 2011	Multi AV	x	x	x	
Frontier \ D40 \ 2011	IPDM E/R	x	x	x	
Frontier \ D40 \ 2011	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2011	Auto drive position	x	x	x	
Frontier \ D40 \ 2011	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2011	ABS	x	x	x	
Frontier \ D40 \ 2011	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2011	Difference lock	x	x	x	
Frontier \ D40 \ 2011	SVT	x	x	x	
Frontier \ D40 \ 2011	Rearview camera			x	

Frontier \ D40 \ 2011-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2011-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2011-1~	BCM	x	x		
Frontier \ D40 \ 2011-1~	HVAC	x	x	x	
Frontier \ D40 \ 2011-1~	Transmission	x	x	x	
Frontier \ D40 \ 2011-1~	Multi AV	x	x	x	
Frontier \ D40 \ 2011-1~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2011-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2011-1~	Auto drive position	x	x	x	
Frontier \ D40 \ 2011-1~	ABS	x	x	x	
Frontier \ D40 \ 2011-1~	Air bag	x	x	x	
Frontier \ D40 \ 2011-1~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2012	BCM	x	x		
Frontier \ D40 \ 2012	Air bag	x	x	x	
Frontier \ D40 \ 2012	HVAC	x	x	x	
Frontier \ D40 \ 2012	Multi AV		x	x	
Frontier \ D40 \ 2012	IPDM E/R	x	x	x	
Frontier \ D40 \ 2012	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2012	Auto drive position	x	x	x	
Frontier \ D40 \ 2012	ABS	x	x	x	
Frontier \ D40 \ 2012	Transmission	x	x	x	
Frontier \ D40 \ 2012	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2012	Difference lock	x	x	x	
Frontier \ D40 \ 2012	Rearview camera			x	
Frontier \ D40 \ 2012	S/blind camera			x	
Frontier \ D40 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2012-3~	BCM	x	x		
Frontier \ D40 \ 2012-3~	HVAC	x	x	x	
Frontier \ D40 \ 2012-3~	IPDM E/R	x	x	x	

Frontier \ D40 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2012-3~	Auto drive position	x	x	x	
Frontier \ D40 \ 2012-3~	ABS	x	x	x	
Frontier \ D40 \ 2012-3~	Air bag	x	x	x	
Frontier \ D40 \ 2012-3~	Transmission	x	x	x	
Frontier \ D40 \ 2012-3~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2012-3~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2012-3~	Difference lock	x	x	x	
Frontier \ D40 \ 2012-3~	Multi AV		x	x	
Frontier \ D40 \ 2012-3~	Rearview camera			x	
Frontier \ D40 \ 2012-3~	S/blind camera			x	
Frontier \ D40 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2013	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2013	BCM	x	x		
Frontier \ D40 \ 2013	Air bag	x	x	x	
Frontier \ D40 \ 2013	HVAC	x	x	x	
Frontier \ D40 \ 2013	Multi AV		x	x	
Frontier \ D40 \ 2013	IPDM E/R	x	x	x	
Frontier \ D40 \ 2013	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2013	Auto drive position	x	x	x	
Frontier \ D40 \ 2013	Sonar	x	x	x	
Frontier \ D40 \ 2013	ABS	x	x	x	
Frontier \ D40 \ 2013	Transmission	x	x	x	
Frontier \ D40 \ 2013	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2013	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2013	Rearview camera			x	
Frontier \ D40 \ 2013	S/blind camera			x	
Frontier \ D40 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2013-3~	ABS	x	x	x	
Frontier \ D40 \ 2013-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2013-3~	BCM	x	x		
Frontier \ D40 \ 2013-3~	Air bag	x	x	x	
Frontier \ D40 \ 2013-3~	HVAC	x	x	x	
Frontier \ D40 \ 2013-3~	Multi AV	x	x	x	0280
Frontier \ D40 \ 2013-3~	EPS/DAST 3	x	x	x	

Frontier \ D40 \ 2013-3~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2013-3~	Convertible roof		x	x	
Frontier \ D40 \ 2013-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2013-3~	Auto drive position	x	x	x	
Frontier \ D40 \ 2013-3~	Sonar	x	x	x	
Frontier \ D40 \ 2013-3~	Lane camera	x	x	x	
Frontier \ D40 \ 2013-3~	Transmission	x	x	x	
Frontier \ D40 \ 2013-3~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2013-3~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2013-3~	Difference lock	x	x	x	
Frontier \ D40 \ 2013-3~	SVT	x	x	x	
Frontier \ D40 \ 2013-3~	Rearview camera			x	
Frontier \ D40 \ 2013-3~	S/blind camera			x	
Frontier \ D40 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2014	BCM	x	x		
Frontier \ D40 \ 2014	Air bag	x	x	x	
Frontier \ D40 \ 2014	HVAC	x	x	x	
Frontier \ D40 \ 2014	Multi AV		x	x	
Frontier \ D40 \ 2014	IPDM E/R	x	x	x	
Frontier \ D40 \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2014	Auto drive position	x	x	x	
Frontier \ D40 \ 2014	ABS	x	x	x	
Frontier \ D40 \ 2014	Transmission	x	x	x	
Frontier \ D40 \ 2014	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2014	Rearview camera			x	
Frontier \ D40 \ 2014	S/blind camera			x	
Frontier \ D40 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2014-6~	ABS	x	x	x	
Frontier \ D40 \ 2014-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2014-6~	BCM	x	x		
Frontier \ D40 \ 2014-6~	Air bag	x	x	x	
Frontier \ D40 \ 2014-6~	HVAC	x	x	x	
Frontier \ D40 \ 2014-6~	Multi AV	x	x	x	0280
Frontier \ D40 \ 2014-6~	EPS/DAST 3	x	x	x	

Frontier \ D40 \ 2014-6~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2014-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2014-6~	Auto drive position	x	x	x	
Frontier \ D40 \ 2014-6~	Sonar	x	x	x	
Frontier \ D40 \ 2014-6~	AVM		x	x	
Frontier \ D40 \ 2014-6~	Transmission	x	x	x	
Frontier \ D40 \ 2014-6~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2014-6~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2014-6~	Difference lock	x	x	x	
Frontier \ D40 \ 2014-6~	SVT	x	x	x	
Frontier \ D40 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2015	BCM	x	x		
Frontier \ D40 \ 2015	Air bag	x	x	x	
Frontier \ D40 \ 2015	HVAC	x	x	x	
Frontier \ D40 \ 2015	Multi AV	x	x	x	0280
Frontier \ D40 \ 2015	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2015	IPDM E/R	x	x	x	
Frontier \ D40 \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier \ D40 \ 2015	Auto drive position	x	x	x	
Frontier \ D40 \ 2015	Sonar	x	x	x	
Frontier \ D40 \ 2015	AVM		x	x	
Frontier \ D40 \ 2015	ABS	x	x	x	
Frontier \ D40 \ 2015	Transmission	x	x	x	
Frontier \ D40 \ 2015	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2015	Difference lock	x	x	x	
Frontier \ D40 \ 2015-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2015-8~	ABS	x	x	x	
Frontier \ D40 \ 2015-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2015-8~	BCM	x	x		
Frontier \ D40 \ 2015-8~	Air bag	x	x	x	
Frontier \ D40 \ 2015-8~	ICC/ADAS	x	x	x	
Frontier \ D40 \ 2015-8~	HVAC	x	x	x	
Frontier \ D40 \ 2015-8~	Transmission	x	x	x	0059
Frontier \ D40 \ 2015-8~	Multi AV		x	x	

Frontier \ D40 \ 2015-8~	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2015-8~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2015-8~	Air pressure monitor		x	x	
Frontier \ D40 \ 2015-8~	Auto drive position	x	x	x	
Frontier \ D40 \ 2015-8~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2015-8~	Side radar left		x	x	
Frontier \ D40 \ 2015-8~	Side radar right		x	x	
Frontier \ D40 \ 2015-8~	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2015-8~	Difference lock	x	x	x	
Frontier \ D40 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2016	ABS	x	x	x	
Frontier \ D40 \ 2016	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2016	BCM	x	x		
Frontier \ D40 \ 2016	Air bag	x	x	x	
Frontier \ D40 \ 2016	HVAC	x	x	x	
Frontier \ D40 \ 2016	Transmission	x	x	x	0059
Frontier \ D40 \ 2016	Multi AV		x	x	
Frontier \ D40 \ 2016	EPS/DAST 3	x	x	x	
Frontier \ D40 \ 2016	IPDM E/R	x	x	x	
Frontier \ D40 \ 2016	Air pressure monitor		x	x	
Frontier \ D40 \ 2016	Auto drive position	x	x	x	
Frontier \ D40 \ 2016	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2016	Head lamp levelizer	x	x	x	
Frontier \ D40 \ 2016	Difference lock	x	x	x	
Frontier \ D40 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2016-7~	ABS	x	x	x	
Frontier \ D40 \ 2016-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2016-7~	BCM		x		
Frontier \ D40 \ 2016-7~	Air bag	x	x	x	
Frontier \ D40 \ 2016-7~	HVAC	x	x	x	
Frontier \ D40 \ 2016-7~	Transmission	x	x	x	0059
Frontier \ D40 \ 2016-7~	Multi AV	x	x	x	0280
Frontier \ D40 \ 2016-7~	IPDM E/R	x	x	x	
Frontier \ D40 \ 2016-7~	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2016-7~	Auto drive position	x	x	x	
Frontier \ D40 \ 2016-7~	AVM		x	x	
Frontier \ D40 \ 2016-7~	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2016-7~	Difference lock	x	x	x	

Frontier \ D40 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier \ D40 \ 2017	ABS	x	x	x	
Frontier \ D40 \ 2017	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier \ D40 \ 2017	BCM		x		
Frontier \ D40 \ 2017	Air bag	x	x	x	
Frontier \ D40 \ 2017	HVAC	x	x	x	
Frontier \ D40 \ 2017	Transmission	x	x	x	0059
Frontier \ D40 \ 2017	Multi AV	x	x	x	0280
Frontier \ D40 \ 2017	IPDM E/R	x	x	x	
Frontier \ D40 \ 2017	Air pressure monitor	x	x	x	
Frontier \ D40 \ 2017	Auto drive position	x	x	x	
Frontier \ D40 \ 2017	AVM		x	x	
Frontier \ D40 \ 2017	All mode AWD/4WD	x	x	x	
Frontier \ D40 \ 2017	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2006-12~	BCM	x	x		
Frontier-navara \ D40 \ 2006-12~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2006-12~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2006-12~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2006-12~	Precrash seatbelt	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2006-12~	ABS	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2006-12~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2006-12~	Rearview camera			x	
Frontier-navara \ D40 \ 2006-12~	S/blind camera			x	
Frontier-navara \ D40 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2007-10~	BCM	x	x		
Frontier-navara \ D40 \ 2007-10~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2007-10~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Transmission	x	x	x	

Frontier-navara \ D40 \ 2007-10~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2007-10~	Precrash seatbelt	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2007-10~	ABS	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2007-10~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2007-10~	Rearview camera			x	
Frontier-navara \ D40 \ 2007-10~	S/blind camera			x	
Frontier-navara \ D40 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2008-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2008-10~	BCM	x	x		
Frontier-navara \ D40 \ 2008-10~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2008-10~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2008-10~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2008-10~	Precrash seatbelt	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2008-10~	ABS	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2008-10~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2008-10~	Rearview camera			x	
Frontier-navara \ D40 \ 2008-10~	S/blind camera			x	
Frontier-navara \ D40 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2010-10~	BCM	x	x		
Frontier-navara \ D40 \ 2010-10~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2010-10~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2010-10~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2010-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Frontier-navara \ D40 \ 2010-10~	Precrash seatbelt	x	x	x	
Frontier-navara \ D40 \ 2010-10~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2010-10~	ABS	x	x	x	
Frontier-navara \ D40 \ 2010-10~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2010-10~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2010-10~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2010-10~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2010-10~	SVT	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2010-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2010-12~	BCM	x	x		
Frontier-navara \ D40 \ 2010-12~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2010-12~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2010-12~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2010-12~	Precrash seatbelt	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2010-12~	ABS	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2010-12~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2010-12~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2010-12~	SVT	x	x	x	
Frontier-navara \ D40 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2011-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2011-11~	BCM	x	x		
Frontier-navara \ D40 \ 2011-11~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2011-11~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2011-11~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2011-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2011-11~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2011-11~	ABS	x	x	x	
Frontier-navara \ D40 \ 2011-11~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2011-11~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2011-11~	Difference lock	x	x	x	

Frontier-navara \ D40 \ 2011-11~	Rearview camera			x	
Frontier-navara \ D40 \ 2011-11~	S/blind camera			x	
Frontier-navara \ D40 \ 2011-11~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2012-3~	BCM	x	x		
Frontier-navara \ D40 \ 2012-3~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2012-3~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2012-3~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2012-3~	ABS	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2012-3~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2012-3~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-navara \ D40 \ 2013-3~	ABS	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-navara \ D40 \ 2013-3~	BCM	x	x		
Frontier-navara \ D40 \ 2013-3~	Air bag	x	x	x	
Frontier-navara \ D40 \ 2013-3~	HVAC	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Multi AV	x	x	x	0280
Frontier-navara \ D40 \ 2013-3~	EPS/DAST 3	x	x	x	
Frontier-navara \ D40 \ 2013-3~	IPDM E/R	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Convertible roof		x	x	
Frontier-navara \ D40 \ 2013-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-navara \ D40 \ 2013-3~	Auto drive position	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Sonar	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Lane camera	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Transmission	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Head lamp levelizer	x	x	x	
Frontier-navara \ D40 \ 2013-3~	All mode AWD/4WD	x	x	x	
Frontier-navara \ D40 \ 2013-3~	Difference lock	x	x	x	
Frontier-navara \ D40 \ 2013-3~	SVT	x	x	x	

Frontier-navara \ D40 \ 2013-3~	Rearview camera			x	
Frontier-navara \ D40 \ 2013-3~	S/blind camera			x	
Frontier-pickup \ D22 \ 2008-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-pickup \ D22 \ 2008-3~	ABS	x	x	x	0003, 0092, 0264
Frontier-pickup \ D22 \ 2008-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-pickup \ D22 \ 2008-3~	BCM	x	x		
Frontier-pickup \ D22 \ 2008-3~	Air bag	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	ICC/ADAS	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	HVAC	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier-pickup \ D22 \ 2008-3~	Multi AV	x	x	x	0280
Frontier-pickup \ D22 \ 2008-3~	EPS/DAST 3	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	IPDM E/R	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Air pressure monitor	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-pickup \ D22 \ 2008-3~	DIU	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Auto slide door	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Auto drive position	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	All mode AWD/4WD	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Sonar	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Lane camera	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Adaptive light	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	AVM		x	x	
Frontier-pickup \ D22 \ 2008-3~	Head lamp levelizer	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Difference lock	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Nats immu	x	x		
Frontier-pickup \ D22 \ 2008-3~	Smart entrance	x	x		
Frontier-pickup \ D22 \ 2008-3~	Air levelizer	x	x	x	
Frontier-pickup \ D22 \ 2008-3~	Rearview camera			x	
Frontier-pickup \ D22 \ 2008-3~	S/blind camera			x	
Frontier-pickup \ D22 \ 2008-3~	Motor assist	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-pickup \ D22 \ 2009-11~	ABS	x	x	x	0003, 0092, 0264
Frontier-pickup \ D22 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-pickup \ D22 \ 2009-11~	BCM	x	x		
Frontier-pickup \ D22 \ 2009-11~	Air bag	x	x	x	

Frontier-pickup \ D22 \ 2009-11~	ICC/ADAS	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	HVAC	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier-pickup \ D22 \ 2009-11~	Multi AV	x	x	x	0280
Frontier-pickup \ D22 \ 2009-11~	EPS/DAST 3	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	IPDM E/R	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Air pressure monitor	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-pickup \ D22 \ 2009-11~	DIU	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Auto slide door	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Auto drive position	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	All mode AWD/4WD	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Sonar	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Lane camera	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Adaptive light	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	AVM		x	x	
Frontier-pickup \ D22 \ 2009-11~	Head lamp levelizer	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Difference lock	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Nats immu	x	x		
Frontier-pickup \ D22 \ 2009-11~	Smart entrance	x	x		
Frontier-pickup \ D22 \ 2009-11~	Air levelizer	x	x	x	
Frontier-pickup \ D22 \ 2009-11~	Rearview camera			x	
Frontier-pickup \ D22 \ 2009-11~	S/blind camera			x	
Frontier-pickup \ D22 \ 2009-11~	Motor assist	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-pickup \ D22 \ 2009-9~	BCM	x	x		
Frontier-pickup \ D22 \ 2009-9~	Transmission	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	IPDM E/R	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	Engine	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	Air bag	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	SVT	x	x	x	
Frontier-pickup \ D22 \ 2009-9~	Rearview camera			x	
Frontier-pickup \ D22 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-pickup \ D22 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
Frontier-pickup \ D22 \ 2012-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-pickup \ D22 \ 2012-9~	BCM	x	x		
Frontier-pickup \ D22 \ 2012-9~	Transmission	x	x	x	

Frontier-pickup \ D22 \ 2012-9~	EPS/DAST 3	x	x	x	
Frontier-pickup \ D22 \ 2012-9~	IPDM E/R	x	x	x	
Frontier-pickup \ D22 \ 2012-9~	Air bag	x	x	x	
Frontier-pickup \ D22 \ 2012-9~	Rearview camera			x	
Frontier-pickup \ D22 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Frontier-pickup \ D22 \ All Year	ABS	x	x	x	0003, 0092, 0264
Frontier-pickup \ D22 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Frontier-pickup \ D22 \ All Year	BCM	x	x		
Frontier-pickup \ D22 \ All Year	Air bag	x	x	x	
Frontier-pickup \ D22 \ All Year	ICC/ADAS	x	x	x	
Frontier-pickup \ D22 \ All Year	HVAC	x	x	x	
Frontier-pickup \ D22 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Frontier-pickup \ D22 \ All Year	Multi AV	x	x	x	0280
Frontier-pickup \ D22 \ All Year	EPS/DAST 3	x	x	x	
Frontier-pickup \ D22 \ All Year	IPDM E/R	x	x	x	
Frontier-pickup \ D22 \ All Year	Air pressure monitor	x	x	x	
Frontier-pickup \ D22 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Frontier-pickup \ D22 \ All Year	DIU	x	x	x	
Frontier-pickup \ D22 \ All Year	Auto slide door	x	x	x	
Frontier-pickup \ D22 \ All Year	Auto drive position	x	x	x	
Frontier-pickup \ D22 \ All Year	All mode AWD/4WD	x	x	x	
Frontier-pickup \ D22 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Frontier-pickup \ D22 \ All Year	Sonar	x	x	x	
Frontier-pickup \ D22 \ All Year	Lane camera	x	x	x	
Frontier-pickup \ D22 \ All Year	Adaptive light	x	x	x	
Frontier-pickup \ D22 \ All Year	AVM		x	x	
Frontier-pickup \ D22 \ All Year	Head lamp levelizer	x	x	x	
Frontier-pickup \ D22 \ All Year	Difference lock	x	x	x	
Frontier-pickup \ D22 \ All Year	Nats immu	x	x		
Frontier-pickup \ D22 \ All Year	Smart entrance	x	x		
Frontier-pickup \ D22 \ All Year	Air levelizer	x	x	x	
Frontier-pickup \ D22 \ All Year	Rearview camera			x	
Frontier-pickup \ D22 \ All Year	S/blind camera			x	
Frontier-pickup \ D22 \ All Year	Motor assist	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga hybrid \ HY51 \ 2010-10~	ABS	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	Meter/M&A		x	x	

Fuga hybrid \ HY51 \ 2010-10~	BCM		x		
Fuga hybrid \ HY51 \ 2010-10~	Air bag	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	ICC/ADAS		x	x	
Fuga hybrid \ HY51 \ 2010-10~	HVAC		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Transmission		x	x	0059
Fuga hybrid \ HY51 \ 2010-10~	Multi AV		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Motor control		x	x	
Fuga hybrid \ HY51 \ 2010-10~	EPS/DAST 3		x	x	
Fuga hybrid \ HY51 \ 2010-10~	IPDM E/R		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Air pressure monitor	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	Laser/radar	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	Precrash seatbelt		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Auto drive position		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Lane camera		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Adaptive light	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	CAN gateway		x		
Fuga hybrid \ HY51 \ 2010-10~	EV/HEV		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Accele pedal ACT		x	x	
Fuga hybrid \ HY51 \ 2010-10~	HV battery		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Brake		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Side radar left		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Side radar right		x	x	
Fuga hybrid \ HY51 \ 2010-10~	Head lamp levelizer	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	Pop up hood	x	x	x	
Fuga hybrid \ HY51 \ 2010-10~	VSP	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga hybrid \ HY51 \ 2012-2~	ABS	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	Meter/M&A		x	x	
Fuga hybrid \ HY51 \ 2012-2~	BCM		x		
Fuga hybrid \ HY51 \ 2012-2~	Air bag	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	ICC/ADAS		x	x	
Fuga hybrid \ HY51 \ 2012-2~	HVAC		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Transmission		x	x	0059
Fuga hybrid \ HY51 \ 2012-2~	Multi AV		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Motor control		x	x	
Fuga hybrid \ HY51 \ 2012-2~	EPS/DAST 3		x	x	
Fuga hybrid \ HY51 \ 2012-2~	IPDM E/R		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Air pressure monitor	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	Laser/radar	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	Precrash seatbelt		x	x	

Fuga hybrid \ HY51 \ 2012-2~	Auto drive position		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Lane camera		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Adaptive light	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	CAN gateway		x		
Fuga hybrid \ HY51 \ 2012-2~	EV/HEV		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Accele pedal ACT		x	x	
Fuga hybrid \ HY51 \ 2012-2~	HV battery		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Brake		x	x	
Fuga hybrid \ HY51 \ 2012-2~	Head lamp levelizer	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	Pop up hood	x	x	x	
Fuga hybrid \ HY51 \ 2012-2~	VSP	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga hybrid \ HY51 \ 2013-6~	ABS	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Meter/M&A		x	x	
Fuga hybrid \ HY51 \ 2013-6~	BCM		x		
Fuga hybrid \ HY51 \ 2013-6~	Air bag	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	ICC/ADAS		x	x	
Fuga hybrid \ HY51 \ 2013-6~	HVAC		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Transmission		x	x	0059
Fuga hybrid \ HY51 \ 2013-6~	Multi AV	x	x	x	0280
Fuga hybrid \ HY51 \ 2013-6~	Motor control		x	x	
Fuga hybrid \ HY51 \ 2013-6~	EPS/DAST 3		x	x	
Fuga hybrid \ HY51 \ 2013-6~	IPDM E/R		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Air pressure monitor	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Laser/radar	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Precrash seatbelt		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Auto drive position		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Lane camera		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Adaptive light	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	CAN gateway		x		
Fuga hybrid \ HY51 \ 2013-6~	EV/HEV		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Accele pedal ACT		x	x	
Fuga hybrid \ HY51 \ 2013-6~	HV battery		x	x	
Fuga hybrid \ HY51 \ 2013-6~	Brake		x	x	
Fuga hybrid \ HY51 \ 2013-6~	VSP	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Head lamp levelizer	x	x	x	
Fuga hybrid \ HY51 \ 2013-6~	Pop up hood	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga hybrid \ HY51 \ 2014-11~	ABS	x	x	x	

Fuga hybrid \ HY51 \ 2014-11~	Meter/M&A		x	x	
Fuga hybrid \ HY51 \ 2014-11~	BCM		x		
Fuga hybrid \ HY51 \ 2014-11~	Air bag	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	ICC/ADAS		x	x	
Fuga hybrid \ HY51 \ 2014-11~	HVAC		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Transmission		x	x	0059
Fuga hybrid \ HY51 \ 2014-11~	Multi AV		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Motor control		x	x	
Fuga hybrid \ HY51 \ 2014-11~	EPS/DAST 3		x	x	
Fuga hybrid \ HY51 \ 2014-11~	IPDM E/R		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Air pressure monitor	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	Laser/radar		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Precrash seatbelt		x	x	
Fuga hybrid \ HY51 \ 2014-11~	All mode AWD/4WD	x	x	x	0245, 0311
Fuga hybrid \ HY51 \ 2014-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	Sonar	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	Lane camera		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Adaptive light	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	CAN gateway		x		
Fuga hybrid \ HY51 \ 2014-11~	EV/HEV		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Pop up hood	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	4WAS(front)	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	E-SUS		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Accele pedal ACT		x	x	
Fuga hybrid \ HY51 \ 2014-11~	HV battery		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Brake		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Side radar left		x	x	
Fuga hybrid \ HY51 \ 2014-11~	VSP	x	x	x	
Fuga hybrid \ HY51 \ 2014-11~	Side radar right		x	x	
Fuga hybrid \ HY51 \ 2014-11~	BSW/buzzer		x	x	
Fuga hybrid \ HY51 \ 2014-11~	AVM		x	x	
Fuga hybrid \ HY51 \ 2014-11~	Head lamp levelizer	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga hybrid \ HY51 \ 2015-11~	ABS	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Meter/M&A		x	x	
Fuga hybrid \ HY51 \ 2015-11~	BCM		x		
Fuga hybrid \ HY51 \ 2015-11~	Air bag	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	ICC/ADAS		x	x	
Fuga hybrid \ HY51 \ 2015-11~	HVAC		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Transmission		x	x	

Fuga hybrid \ HY51 \ 2015-11~	Multi AV		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Motor control		x	x	
Fuga hybrid \ HY51 \ 2015-11~	EPS/DAST 3		x	x	
Fuga hybrid \ HY51 \ 2015-11~	IPDM E/R		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Air pressure monitor	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Laser/radar		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Precrash seatbelt		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Auto drive position		x	x	
Fuga hybrid \ HY51 \ 2015-11~	All mode AWD/4WD		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Sonar	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Lane camera		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Adaptive light	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	CAN gateway		x		
Fuga hybrid \ HY51 \ 2015-11~	EV/HEV		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Pop up hood	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Accele pedal ACT		x	x	
Fuga hybrid \ HY51 \ 2015-11~	HV battery		x	x	0251
Fuga hybrid \ HY51 \ 2015-11~	Brake		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Side radar left		x	x	
Fuga hybrid \ HY51 \ 2015-11~	VSP	x	x	x	
Fuga hybrid \ HY51 \ 2015-11~	Side radar right		x	x	
Fuga hybrid \ HY51 \ 2015-11~	BSW/buzzer		x	x	
Fuga hybrid \ HY51 \ 2015-11~	AVM		x	x	
Fuga hybrid \ HY51 \ 2015-11~	Head lamp levelizer	x	x	x	
Fuga \ Y50 \ 2004-10~	Meter/M&A	x	x	x	0143, 0331
Fuga \ Y50 \ 2004-10~	BCM	x	x		
Fuga \ Y50 \ 2004-10~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2004-10~	Transmission	x	x	x	
Fuga \ Y50 \ 2004-10~	Multi AV	x	x	x	0280
Fuga \ Y50 \ 2004-10~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2004-10~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2004-10~	Precrash seatbelt	x	x	x	
Fuga \ Y50 \ 2004-10~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2004-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fuga \ Y50 \ 2004-10~	Adaptive light	x	x	x	
Fuga \ Y50 \ 2004-10~	Engine	x	x	x	
Fuga \ Y50 \ 2004-10~	ABS	x	x	x	
Fuga \ Y50 \ 2004-10~	Air bag	x	x	x	
Fuga \ Y50 \ 2004-10~	All mode AWD/4WD	x	x	x	
Fuga \ Y50 \ 2005-3~	Meter/M&A	x	x	x	0143, 0331

Fuga \ Y50 \ 2005-3~	BCM	x	x		
Fuga \ Y50 \ 2005-3~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2005-3~	Transmission	x	x	x	
Fuga \ Y50 \ 2005-3~	Multi AV	x	x	x	0280
Fuga \ Y50 \ 2005-3~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2005-3~	Air pressure monitor	x	x	x	
Fuga \ Y50 \ 2005-3~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2005-3~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2005-3~	Engine	x	x	x	
Fuga \ Y50 \ 2005-3~	ABS	x	x	x	
Fuga \ Y50 \ 2005-3~	Air bag	x	x	x	
Fuga \ Y50 \ 2006-5~	Meter/M&A	x	x	x	0143, 0331
Fuga \ Y50 \ 2006-5~	BCM	x	x		
Fuga \ Y50 \ 2006-5~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2006-5~	Transmission	x	x	x	
Fuga \ Y50 \ 2006-5~	Multi AV	x	x	x	0280
Fuga \ Y50 \ 2006-5~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2006-5~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2006-5~	Precrash seatbelt	x	x	x	
Fuga \ Y50 \ 2006-5~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2006-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fuga \ Y50 \ 2006-5~	Adaptive light	x	x	x	
Fuga \ Y50 \ 2006-5~	Engine	x	x	x	
Fuga \ Y50 \ 2006-5~	ABS	x	x	x	
Fuga \ Y50 \ 2006-5~	Air bag	x	x	x	
Fuga \ Y50 \ 2006-5~	All mode AWD/4WD	x	x	x	
Fuga \ Y50 \ 2006-8~	Meter/M&A	x	x	x	0143, 0331
Fuga \ Y50 \ 2006-8~	BCM	x	x		
Fuga \ Y50 \ 2006-8~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2006-8~	Transmission	x	x	x	
Fuga \ Y50 \ 2006-8~	Multi AV	x	x	x	0280
Fuga \ Y50 \ 2006-8~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2006-8~	Air pressure monitor	x	x	x	
Fuga \ Y50 \ 2006-8~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2006-8~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2006-8~	Engine	x	x	x	
Fuga \ Y50 \ 2006-8~	ABS	x	x	x	
Fuga \ Y50 \ 2006-8~	Air bag	x	x	x	
Fuga \ Y50 \ 2006-8~	Head lamp levelizer	x	x	x	
Fuga \ Y50 \ 2007-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Fuga \ Y50 \ 2007-11~	Meter/M&A	x	x	x	0143, 0331
Fuga \ Y50 \ 2007-11~	BCM	x	x		
Fuga \ Y50 \ 2007-11~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2007-11~	Transmission	x	x	x	0059
Fuga \ Y50 \ 2007-11~	Multi AV	x	x	x	
Fuga \ Y50 \ 2007-11~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2007-11~	Air pressure monitor	x	x	x	
Fuga \ Y50 \ 2007-11~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2007-11~	Precrash seatbelt	x	x	x	
Fuga \ Y50 \ 2007-11~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2007-11~	All mode AWD/4WD	x	x	x	0245, 0311
Fuga \ Y50 \ 2007-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fuga \ Y50 \ 2007-11~	Adaptive light	x	x	x	
Fuga \ Y50 \ 2007-11~	Accele pedal ACT		x	x	
Fuga \ Y50 \ 2007-11~	ABS	x	x	x	
Fuga \ Y50 \ 2007-11~	Air bag	x	x	x	
Fuga \ Y50 \ 2007-11~	Sonar	x	x	x	
Fuga \ Y50 \ 2007-11~	Rearview camera			x	
Fuga \ Y50 \ 2007-11~	S/blind camera			x	
Fuga \ Y50 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga \ Y50 \ 2009-8~	Meter/M&A	x	x	x	0143, 0331
Fuga \ Y50 \ 2009-8~	BCM	x	x		
Fuga \ Y50 \ 2009-8~	ICC/ADAS	x	x	x	
Fuga \ Y50 \ 2009-8~	Transmission	x	x	x	0059
Fuga \ Y50 \ 2009-8~	Multi AV	x	x	x	
Fuga \ Y50 \ 2009-8~	IPDM E/R	x	x	x	
Fuga \ Y50 \ 2009-8~	Air pressure monitor	x	x	x	
Fuga \ Y50 \ 2009-8~	Intelligent key	x	x	x	
Fuga \ Y50 \ 2009-8~	Precrash seatbelt	x	x	x	
Fuga \ Y50 \ 2009-8~	Auto drive position	x	x	x	
Fuga \ Y50 \ 2009-8~	All mode AWD/4WD	x	x	x	0245, 0311
Fuga \ Y50 \ 2009-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Fuga \ Y50 \ 2009-8~	Adaptive light	x	x	x	
Fuga \ Y50 \ 2009-8~	Accele pedal ACT		x	x	
Fuga \ Y50 \ 2009-8~	ABS	x	x	x	
Fuga \ Y50 \ 2009-8~	Air bag	x	x	x	
Fuga \ Y50 \ 2009-8~	Sonar	x	x	x	
Fuga \ Y50 \ 2009-8~	Rearview camera			x	
Fuga \ Y50 \ 2009-8~	S/blind camera			x	

Fuga \ Y51 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga \ Y51 \ 2009-10~	ABS	x	x	x	
Fuga \ Y51 \ 2009-10~	Meter/M&A		x	x	
Fuga \ Y51 \ 2009-10~	BCM		x		
Fuga \ Y51 \ 2009-10~	Air bag	x	x	x	
Fuga \ Y51 \ 2009-10~	ICC/ADAS		x	x	
Fuga \ Y51 \ 2009-10~	HVAC		x	x	
Fuga \ Y51 \ 2009-10~	Transmission	x	x	x	0059
Fuga \ Y51 \ 2009-10~	Multi AV	x	x	x	
Fuga \ Y51 \ 2009-10~	IPDM E/R		x	x	
Fuga \ Y51 \ 2009-10~	Air pressure monitor	x	x	x	
Fuga \ Y51 \ 2009-10~	Laser/radar	x	x	x	
Fuga \ Y51 \ 2009-10~	Precrash seatbelt		x	x	
Fuga \ Y51 \ 2009-10~	Auto drive position	x	x	x	
Fuga \ Y51 \ 2009-10~	All mode AWD/4WD		x	x	
Fuga \ Y51 \ 2009-10~	4WAS(MAIN)/RAS/HICAS		x	x	
Fuga \ Y51 \ 2009-10~	Lane camera		x	x	
Fuga \ Y51 \ 2009-10~	Adaptive light	x	x	x	
Fuga \ Y51 \ 2009-10~	CAN gateway		x		
Fuga \ Y51 \ 2009-10~	4WAS(front)	x	x	x	
Fuga \ Y51 \ 2009-10~	E-SUS		x	x	
Fuga \ Y51 \ 2009-10~	Accele pedal ACT		x	x	
Fuga \ Y51 \ 2009-10~	Head lamp levelizer	x	x	x	
Fuga \ Y51 \ 2009-10~	Sonar	x	x	x	
Fuga \ Y51 \ 2009-10~	Pop up hood	x	x	x	
Fuga \ Y51 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga \ Y51 \ 2012-5~	ABS		x	x	
Fuga \ Y51 \ 2012-5~	Meter/M&A		x	x	
Fuga \ Y51 \ 2012-5~	BCM		x		
Fuga \ Y51 \ 2012-5~	Air bag	x	x	x	
Fuga \ Y51 \ 2012-5~	ICC/ADAS		x	x	
Fuga \ Y51 \ 2012-5~	HVAC		x	x	
Fuga \ Y51 \ 2012-5~	Transmission		x	x	0059
Fuga \ Y51 \ 2012-5~	Multi AV		x	x	
Fuga \ Y51 \ 2012-5~	IPDM E/R		x	x	
Fuga \ Y51 \ 2012-5~	Air pressure monitor	x	x	x	
Fuga \ Y51 \ 2012-5~	Laser/radar	x	x	x	
Fuga \ Y51 \ 2012-5~	Precrash seatbelt		x	x	
Fuga \ Y51 \ 2012-5~	Auto drive position		x	x	

Fuga \ Y51 \ 2012-5~	All mode AWD/4WD		x	x	
Fuga \ Y51 \ 2012-5~	4WAS(MAIN)/RAS/HICAS		x	x	
Fuga \ Y51 \ 2012-5~	Lane camera		x	x	
Fuga \ Y51 \ 2012-5~	Adaptive light	x	x	x	
Fuga \ Y51 \ 2012-5~	CAN gateway		x		
Fuga \ Y51 \ 2012-5~	4WAS(front)	x	x	x	
Fuga \ Y51 \ 2012-5~	Accele pedal ACT		x	x	
Fuga \ Y51 \ 2012-5~	Head lamp levelizer	x	x	x	
Fuga \ Y51 \ 2012-5~	Pop up hood	x	x	x	
Fuga \ Y51 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Fuga \ Y51 \ 2014-11~	ABS		x	x	
Fuga \ Y51 \ 2014-11~	Meter/M&A		x	x	
Fuga \ Y51 \ 2014-11~	BCM		x		
Fuga \ Y51 \ 2014-11~	Air bag	x	x	x	
Fuga \ Y51 \ 2014-11~	ICC/ADAS		x	x	
Fuga \ Y51 \ 2014-11~	HVAC		x	x	
Fuga \ Y51 \ 2014-11~	Transmission		x	x	0059
Fuga \ Y51 \ 2014-11~	Multi AV		x	x	
Fuga \ Y51 \ 2014-11~	EPS/DAST 3		x	x	
Fuga \ Y51 \ 2014-11~	IPDM E/R		x	x	
Fuga \ Y51 \ 2014-11~	Air pressure monitor	x	x	x	
Fuga \ Y51 \ 2014-11~	Laser/radar		x	x	
Fuga \ Y51 \ 2014-11~	Precrash seatbelt		x	x	
Fuga \ Y51 \ 2014-11~	Auto drive position		x	x	
Fuga \ Y51 \ 2014-11~	All mode AWD/4WD		x	x	
Fuga \ Y51 \ 2014-11~	4WAS(MAIN)/RAS/HICAS		x	x	
Fuga \ Y51 \ 2014-11~	Sonar	x	x	x	
Fuga \ Y51 \ 2014-11~	Lane camera		x	x	
Fuga \ Y51 \ 2014-11~	Adaptive light	x	x	x	
Fuga \ Y51 \ 2014-11~	CAN gateway		x		
Fuga \ Y51 \ 2014-11~	Pop up hood	x	x	x	
Fuga \ Y51 \ 2014-11~	4WAS(front)	x	x	x	
Fuga \ Y51 \ 2014-11~	E-SUS		x	x	
Fuga \ Y51 \ 2014-11~	Accele pedal ACT		x	x	
Fuga \ Y51 \ 2014-11~	Side radar left		x	x	
Fuga \ Y51 \ 2014-11~	Side radar right		x	x	
Fuga \ Y51 \ 2014-11~	EMCM	x	x	x	
Fuga \ Y51 \ 2014-11~	BSW/buzzer		x	x	
Fuga \ Y51 \ 2014-11~	AVM		x	x	
Fuga \ Y51 \ 2014-11~	Head lamp levelizer	x	x	x	

Fuga \ Y51 \ 2015-11~	Engine	×	×	×	0127, 0109, 0278, 0262, 0209, 0095, 0216, 0340, 0233, 0103, 0300, 0234, 0212
Fuga \ Y51 \ 2015-11~	ABS	×	×	×	
Fuga \ Y51 \ 2015-11~	Meter/M&A		×	×	
Fuga \ Y51 \ 2015-11~	BCM		×		
Fuga \ Y51 \ 2015-11~	Air bag	×	×	×	
Fuga \ Y51 \ 2015-11~	ICC/ADAS		×	×	
Fuga \ Y51 \ 2015-11~	HVAC		×	×	
Fuga \ Y51 \ 2015-11~	Transmission		×	×	0059
Fuga \ Y51 \ 2015-11~	Multi AV		×	×	
Fuga \ Y51 \ 2015-11~	EPS/DAST 3		×	×	
Fuga \ Y51 \ 2015-11~	IPDM E/R		×	×	
Fuga \ Y51 \ 2015-11~	Air pressure monitor	×	×	×	
Fuga \ Y51 \ 2015-11~	Laser/radar		×	×	
Fuga \ Y51 \ 2015-11~	Precrash seatbelt		×	×	
Fuga \ Y51 \ 2015-11~	Auto drive position		×	×	
Fuga \ Y51 \ 2015-11~	All mode AWD/4WD		×	×	
Fuga \ Y51 \ 2015-11~	4WAS(MAIN)/RAS/HICAS		×	×	
Fuga \ Y51 \ 2015-11~	Sonar	×	×	×	
Fuga \ Y51 \ 2015-11~	Lane camera		×	×	
Fuga \ Y51 \ 2015-11~	Adaptive light	×	×	×	
Fuga \ Y51 \ 2015-11~	CAN gateway		×		
Fuga \ Y51 \ 2015-11~	Pop up hood	×	×	×	
Fuga \ Y51 \ 2015-11~	4WAS(front)	×	×	×	
Fuga \ Y51 \ 2015-11~	Accele pedal ACT		×	×	
Fuga \ Y51 \ 2015-11~	Side radar left		×	×	
Fuga \ Y51 \ 2015-11~	Side radar right		×	×	
Fuga \ Y51 \ 2015-11~	BSW/buzzer		×	×	
Fuga \ Y51 \ 2015-11~	AVM		×	×	
Fuga \ Y51 \ 2015-11~	Head lamp levelizer	×	×	×	
Grand livina \ L10 \ 2011-3~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Grand livina \ L10 \ 2011-3~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Grand livina \ L10 \ 2011-3~	BCM	×	×		
Grand livina \ L10 \ 2011-3~	Transmission		×	×	
Grand livina \ L10 \ 2011-3~	EPS/DAST 3	×	×	×	
Grand livina \ L10 \ 2011-3~	IPDM E/R	×	×	×	
Grand livina \ L10 \ 2011-3~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Grand livina \ L10 \ 2011-3~	ABS	x	x	x	
Grand livina \ L10 \ 2011-3~	Air bag	x	x	x	
Grand livina \ L10 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Grand livina \ L10 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Grand livina \ L10 \ 2013-8~	BCM	x	x		
Grand livina \ L10 \ 2013-8~	Air bag	x	x	x	
Grand livina \ L10 \ 2013-8~	Transmission		x	x	
Grand livina \ L10 \ 2013-8~	EPS/DAST 3	x	x	x	
Grand livina \ L10 \ 2013-8~	IPDM E/R	x	x	x	
Grand livina \ L10 \ 2013-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Grand livina \ L10 \ 2013-8~	ABS	x	x	x	
Grand livina \ L10 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Grand livina \ L10 \ 2015-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Grand livina \ L10 \ 2015-6~	BCM		x		
Grand livina \ L10 \ 2015-6~	Transmission		x	x	
Grand livina \ L10 \ 2015-6~	EPS/DAST 3	x	x	x	
Grand livina \ L10 \ 2015-6~	IPDM E/R	x	x	x	
Grand livina \ L10 \ 2015-6~	ABS	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	ABS		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Meter/M&A		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	BCM		x		
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Air bag		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	ICC/ADAS		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	HVAC		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Transmission		x	x	0059
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Multi AV		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Motor control		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	EPS/DAST 3		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	IPDM E/R		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Air pressure monitor		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Laser/radar		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Precrash seatbelt		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Auto drive position		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	All mode AWD/4WD		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Sonar		x	x	

Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Lane camera		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Adaptive light		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	CAN gateway		x		
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	EV/HEV		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Pop up hood	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Accele pedal ACT		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	HV battery		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Brake		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Side radar left		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	VSP		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	ANC		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Side radar right		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	BSW/buzzer		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	AVM		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Chassis control		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	DAST 1		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	DAST 2		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	HIGH BEAM ASSIST	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Head lamp levelizer	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2013-10~	Occupant detection			x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Engine	x	x	x	0278, 0209, 0248, 0249, 0103, 0233, 0234, 0232, 0310, 0087, 0262, 0195, 0274, 0196, 0295, 0216, 0224, 0290, 0291, 0212, 0152
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	ABS		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Meter/M&A		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	BCM		x		
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Air bag		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	ICC/ADAS		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	HVAC		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Transmission		x	x	0250, 0309, 0231, 0059
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Multi AV		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Motor control		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	EPS/DAST 3	x	x	x	0088, 0089
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	IPDM E/R		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Air pressure monitor		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Laser/radar		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Precrash seatbelt		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Auto drive position		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	All mode AWD/4WD		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Sonar		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Lane camera		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Adaptive light		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	CAN gateway		x		
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	EV/HEV		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Pop up hood	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Accele pedal ACT		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	HV battery		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Brake		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Side radar left		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	VSP		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	ANC		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Side radar right		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	EMCM	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	BSW/buzzer		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	AVM		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Chassis control		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	DAST 1		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	DAST 2		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	HIGH BEAM ASSIST	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	FSCM		x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Head lamp levelizer	x	x	x	
Infiniti Q50 Hybrid \ HV37 \ 2016-3~	Occupant detection			x	
Juke (4WD) \ F15 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke (4WD) \ F15 \ 2010-7~	ABS	x	x	x	
Juke (4WD) \ F15 \ 2010-7~	Meter/M&A		x	x	
Juke (4WD) \ F15 \ 2010-7~	BCM		x		
Juke (4WD) \ F15 \ 2010-7~	Air bag	x	x	x	
Juke (4WD) \ F15 \ 2010-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke (4WD) \ F15 \ 2010-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke (4WD) \ F15 \ 2010-7~	Multi AV	x	x	x	0280
Juke (4WD) \ F15 \ 2010-7~	EPS/DAST 3	x	x	x	
Juke (4WD) \ F15 \ 2010-7~	IPDM E/R		x	x	
Juke (4WD) \ F15 \ 2010-7~	All mode AWD/4WD	x	x	x	0245, 0311
Juke (4WD) \ F15 \ 2010-7~	CAN gateway		x		
Juke (4WD) \ F15 \ 2010-7~	Multi display		x	x	
Juke (4WD) \ F15 \ 2010-7~	PTC heater		x	x	
Juke (4WD) \ F15 \ 2010-7~	EMCM	x	x	x	

Juke (4WD) \ F15 \ 2010-7~	Head lamp levelizer	x	x	x	
Juke (4WD) \ F15 \ 2010-7~	Sonar	x	x	x	
Juke (4WD) \ F15 \ 2010-7~	Occupant detection			x	
Juke (4WD) \ F15 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke (4WD) \ F15 \ 2011-11~	ABS	x	x	x	
Juke (4WD) \ F15 \ 2011-11~	Meter/M&A		x	x	
Juke (4WD) \ F15 \ 2011-11~	BCM		x		
Juke (4WD) \ F15 \ 2011-11~	Air bag	x	x	x	
Juke (4WD) \ F15 \ 2011-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke (4WD) \ F15 \ 2011-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke (4WD) \ F15 \ 2011-11~	Multi AV	x	x	x	0280
Juke (4WD) \ F15 \ 2011-11~	EPS/DAST 3	x	x	x	
Juke (4WD) \ F15 \ 2011-11~	IPDM E/R		x	x	
Juke (4WD) \ F15 \ 2011-11~	All mode AWD/4WD		x	x	
Juke (4WD) \ F15 \ 2011-11~	Multi display		x	x	
Juke (4WD) \ F15 \ 2011-11~	PTC heater		x	x	
Juke (4WD) \ F15 \ 2011-11~	Telematics		x	x	
Juke (4WD) \ F15 \ 2011-11~	EMCM	x	x	x	
Juke (4WD) \ F15 \ 2011-11~	Head lamp levelizer	x	x	x	
Juke (4WD) \ F15 \ 2011-11~	Occupant detection			x	
Juke (4WD) \ F15 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke (4WD) \ F15 \ 2014-5~	ABS	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke (4WD) \ F15 \ 2014-5~	BCM		x		
Juke (4WD) \ F15 \ 2014-5~	Air bag	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke (4WD) \ F15 \ 2014-5~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke (4WD) \ F15 \ 2014-5~	Multi AV	x	x	x	0280
Juke (4WD) \ F15 \ 2014-5~	EPS/DAST 3	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	IPDM E/R		x	x	
Juke (4WD) \ F15 \ 2014-5~	Air pressure monitor	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	All mode AWD/4WD		x	x	
Juke (4WD) \ F15 \ 2014-5~	E-SUS		x	x	
Juke (4WD) \ F15 \ 2014-5~	Multi display		x	x	
Juke (4WD) \ F15 \ 2014-5~	PTC heater		x	x	
Juke (4WD) \ F15 \ 2014-5~	Telematics		x	x	

Juke (4WD) \ F15 \ 2014-5~	EMCM	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	AVM		x	x	
Juke (4WD) \ F15 \ 2014-5~	Head lamp levelizer	x	x	x	
Juke (4WD) \ F15 \ 2014-5~	Occupant detection			x	
JUKE NISMO \ F15 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
JUKE NISMO \ F15 \ 2013	ABS	x	x	x	
JUKE NISMO \ F15 \ 2013	Meter/M&A		x	x	
JUKE NISMO \ F15 \ 2013	BCM		x		
JUKE NISMO \ F15 \ 2013	Air bag	x	x	x	
JUKE NISMO \ F15 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
JUKE NISMO \ F15 \ 2013	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
JUKE NISMO \ F15 \ 2013	EPS/DAST 3	x	x	x	
JUKE NISMO \ F15 \ 2013	IPDM E/R		x	x	
JUKE NISMO \ F15 \ 2013	All mode AWD/4WD		x	x	
JUKE NISMO \ F15 \ 2013	CAN gateway		x		
JUKE NISMO \ F15 \ 2013	Multi display		x	x	
JUKE NISMO \ F15 \ 2013	Telematics		x	x	
JUKE NISMO \ F15 \ 2013	Head lamp levelizer	x	x	x	
JUKE NISMO \ F15 \ 2013	Occupant detection			x	
JUKE NISMO \ F15 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
JUKE NISMO \ F15 \ 2014	ABS	x	x	x	
JUKE NISMO \ F15 \ 2014	Meter/M&A		x	x	
JUKE NISMO \ F15 \ 2014	BCM		x		
JUKE NISMO \ F15 \ 2014	Air bag	x	x	x	
JUKE NISMO \ F15 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
JUKE NISMO \ F15 \ 2014	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
JUKE NISMO \ F15 \ 2014	Multi AV	x	x	x	0280
JUKE NISMO \ F15 \ 2014	EPS/DAST 3	x	x	x	
JUKE NISMO \ F15 \ 2014	IPDM E/R		x	x	
JUKE NISMO \ F15 \ 2014	All mode AWD/4WD		x	x	
JUKE NISMO \ F15 \ 2014	E-SUS		x	x	
JUKE NISMO \ F15 \ 2014	Multi display		x	x	
JUKE NISMO \ F15 \ 2014	PTC heater		x	x	
JUKE NISMO \ F15 \ 2014	AVM		x	x	
JUKE NISMO \ F15 \ 2014	Head lamp levelizer	x	x	x	
JUKE NISMO \ F15 \ 2014	Occupant detection			x	

JUKE NISMO \ F15 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
JUKE NISMO \ F15 \ 2015	ABS	x	x	x	
JUKE NISMO \ F15 \ 2015	Meter/M&A		x	x	
JUKE NISMO \ F15 \ 2015	BCM		x		
JUKE NISMO \ F15 \ 2015	Air bag	x	x	x	
JUKE NISMO \ F15 \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
JUKE NISMO \ F15 \ 2015	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
JUKE NISMO \ F15 \ 2015	Multi AV		x	x	
JUKE NISMO \ F15 \ 2015	EPS/DAST 3	x	x	x	
JUKE NISMO \ F15 \ 2015	IPDM E/R		x	x	
JUKE NISMO \ F15 \ 2015	Air pressure monitor	x	x	x	
JUKE NISMO \ F15 \ 2015	All mode AWD/4WD		x	x	
JUKE NISMO \ F15 \ 2015	Multi display		x	x	
JUKE NISMO \ F15 \ 2015	PTC heater		x	x	
JUKE NISMO \ F15 \ 2015	Telematics		x	x	
JUKE NISMO \ F15 \ 2015	AVM		x	x	
JUKE NISMO \ F15 \ 2015	Head lamp levelizer	x	x	x	
JUKE NISMO \ F15 \ 2015	Occupant detection			x	
JUKE NISMO \ F15 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
JUKE NISMO \ F15 \ 2016	ABS	x	x	x	
JUKE NISMO \ F15 \ 2016	Meter/M&A		x	x	
JUKE NISMO \ F15 \ 2016	BCM		x		
JUKE NISMO \ F15 \ 2016	Air bag	x	x	x	
JUKE NISMO \ F15 \ 2016	ICC/ADAS	x	x	x	
JUKE NISMO \ F15 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
JUKE NISMO \ F15 \ 2016	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
JUKE NISMO \ F15 \ 2016	Multi AV	x	x	x	0280
JUKE NISMO \ F15 \ 2016	EPS/DAST 3	x	x	x	
JUKE NISMO \ F15 \ 2016	IPDM E/R		x	x	
JUKE NISMO \ F15 \ 2016	All mode AWD/4WD		x	x	
JUKE NISMO \ F15 \ 2016	E-SUS		x	x	
JUKE NISMO \ F15 \ 2016	Multi display		x	x	
JUKE NISMO \ F15 \ 2016	PTC heater		x	x	
JUKE NISMO \ F15 \ 2016	Telematics		x	x	
JUKE NISMO \ F15 \ 2016	AVM		x	x	

JUKE NISMO \ F15 \ 2016	Head lamp levelizer	x	x	x	
JUKE NISMO \ F15 \ 2016	Occupant detection			x	
Juke \ F15 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2010-10~	ABS	x	x	x	
Juke \ F15 \ 2010-10~	Meter/M&A		x	x	
Juke \ F15 \ 2010-10~	BCM		x		
Juke \ F15 \ 2010-10~	Air bag	x	x	x	
Juke \ F15 \ 2010-10~	HVAC		x	x	
Juke \ F15 \ 2010-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2010-10~	Multi AV		x	x	
Juke \ F15 \ 2010-10~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2010-10~	IPDM E/R		x	x	
Juke \ F15 \ 2010-10~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2010-10~	Multi display		x	x	
Juke \ F15 \ 2010-10~	PTC heater		x	x	
Juke \ F15 \ 2010-10~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2010-10~	Sonar	x	x	x	
Juke \ F15 \ 2010-10~	Occupant detection			x	
Juke \ F15 \ 2010-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2010-5~	ABS	x	x	x	
Juke \ F15 \ 2010-5~	Meter/M&A		x	x	
Juke \ F15 \ 2010-5~	BCM		x		
Juke \ F15 \ 2010-5~	Air bag	x	x	x	
Juke \ F15 \ 2010-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2010-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2010-5~	Multi AV		x	x	
Juke \ F15 \ 2010-5~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2010-5~	IPDM E/R		x	x	
Juke \ F15 \ 2010-5~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2010-5~	Multi display		x	x	
Juke \ F15 \ 2010-5~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2010-5~	Sonar	x	x	x	
Juke \ F15 \ 2010-5~	Occupant detection			x	
Juke \ F15 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2011	ABS	x	x	x	
Juke \ F15 \ 2011	Meter/M&A		x	x	
Juke \ F15 \ 2011	BCM		x		

Juke \ F15 \ 2011	Air bag	x	x	x	
Juke \ F15 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2011	Multi AV		x	x	
Juke \ F15 \ 2011	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2011	IPDM E/R		x	x	
Juke \ F15 \ 2011	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2011	Multi display		x	x	
Juke \ F15 \ 2011	PTC heater		x	x	
Juke \ F15 \ 2011	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2011	Sonar	x	x	x	
Juke \ F15 \ 2011	Occupant detection			x	
Juke \ F15 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2011-10~	ABS	x	x	x	
Juke \ F15 \ 2011-10~	Meter/M&A		x	x	
Juke \ F15 \ 2011-10~	BCM		x		
Juke \ F15 \ 2011-10~	Air bag	x	x	x	
Juke \ F15 \ 2011-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2011-10~	Transmission	x	x	x	
Juke \ F15 \ 2011-10~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2011-10~	IPDM E/R		x	x	
Juke \ F15 \ 2011-10~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2011-10~	Multi display		x	x	
Juke \ F15 \ 2011-10~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2011-5~	ABS	x	x	x	
Juke \ F15 \ 2011-5~	Meter/M&A		x	x	
Juke \ F15 \ 2011-5~	BCM		x		
Juke \ F15 \ 2011-5~	Air bag	x	x	x	
Juke \ F15 \ 2011-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2011-5~	Transmission	x	x	x	
Juke \ F15 \ 2011-5~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2011-5~	IPDM E/R		x	x	
Juke \ F15 \ 2011-5~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2011-5~	Multi display		x	x	
Juke \ F15 \ 2011-5~	Head lamp levelizer	x	x	x	

Juke \ F15 \ 2011-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2011-6~	ABS	x	x	x	
Juke \ F15 \ 2011-6~	Meter/M&A		x	x	
Juke \ F15 \ 2011-6~	BCM		x		
Juke \ F15 \ 2011-6~	Air bag	x	x	x	
Juke \ F15 \ 2011-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2011-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2011-6~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2011-6~	IPDM E/R		x	x	
Juke \ F15 \ 2011-6~	Multi display		x	x	
Juke \ F15 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2012	ABS	x	x	x	
Juke \ F15 \ 2012	Meter/M&A		x	x	
Juke \ F15 \ 2012	BCM		x		
Juke \ F15 \ 2012	Air bag	x	x	x	
Juke \ F15 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2012	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2012	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2012	IPDM E/R		x	x	
Juke \ F15 \ 2012	All mode AWD/4WD		x	x	
Juke \ F15 \ 2012	Multi display		x	x	
Juke \ F15 \ 2012	Telematics		x	x	
Juke \ F15 \ 2012	Occupant detection			x	
Juke \ F15 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2012-1~	ABS	x	x	x	
Juke \ F15 \ 2012-1~	Meter/M&A		x	x	
Juke \ F15 \ 2012-1~	BCM		x		
Juke \ F15 \ 2012-1~	Air bag	x	x	x	
Juke \ F15 \ 2012-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2012-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2012-1~	Multi AV	x	x	x	0280
Juke \ F15 \ 2012-1~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2012-1~	IPDM E/R		x	x	
Juke \ F15 \ 2012-1~	Air pressure monitor	x	x	x	

Juke \ F15 \ 2012-1~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2012-1~	Multi display		x	x	
Juke \ F15 \ 2012-1~	PTC heater		x	x	
Juke \ F15 \ 2012-1~	EMCM	x	x	x	
Juke \ F15 \ 2012-1~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2012-1~	Occupant detection			x	
Juke \ F15 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2012-5~	ABS	x	x	x	
Juke \ F15 \ 2012-5~	Meter/M&A		x	x	
Juke \ F15 \ 2012-5~	BCM		x		
Juke \ F15 \ 2012-5~	Air bag	x	x	x	
Juke \ F15 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2012-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2012-5~	Multi AV		x	x	
Juke \ F15 \ 2012-5~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2012-5~	IPDM E/R		x	x	
Juke \ F15 \ 2012-5~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2012-5~	Multi display		x	x	
Juke \ F15 \ 2012-5~	Telematics		x	x	
Juke \ F15 \ 2012-5~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2012-5~	Occupant detection			x	
Juke \ F15 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2012-6~	ABS	x	x	x	
Juke \ F15 \ 2012-6~	Meter/M&A		x	x	
Juke \ F15 \ 2012-6~	BCM		x		
Juke \ F15 \ 2012-6~	Air bag	x	x	x	
Juke \ F15 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2012-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2012-6~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2012-6~	IPDM E/R		x	x	
Juke \ F15 \ 2012-6~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2012-6~	Multi display		x	x	
Juke \ F15 \ 2012-6~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2012-6~	Occupant detection			x	
Juke \ F15 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2012-9~	ABS	x	x	x	

Juke \ F15 \ 2012-9~	Meter/M&A		x	x	
Juke \ F15 \ 2012-9~	BCM		x		
Juke \ F15 \ 2012-9~	Air bag	x	x	x	
Juke \ F15 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2012-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2012-9~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2012-9~	IPDM E/R		x	x	
Juke \ F15 \ 2012-9~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2012-9~	Multi display		x	x	
Juke \ F15 \ 2012-9~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013	ABS	x	x	x	
Juke \ F15 \ 2013	Meter/M&A		x	x	
Juke \ F15 \ 2013	BCM		x		
Juke \ F15 \ 2013	Air bag	x	x	x	
Juke \ F15 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2013	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013	IPDM E/R		x	x	
Juke \ F15 \ 2013	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013	CAN gateway		x		
Juke \ F15 \ 2013	Multi display		x	x	
Juke \ F15 \ 2013	Telematics		x	x	
Juke \ F15 \ 2013	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013	Occupant detection			x	
Juke \ F15 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-10~	ABS	x	x	x	
Juke \ F15 \ 2013-10~	Meter/M&A		x	x	
Juke \ F15 \ 2013-10~	BCM		x		
Juke \ F15 \ 2013-10~	Air bag	x	x	x	
Juke \ F15 \ 2013-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2013-10~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-10~	IPDM E/R		x	x	
Juke \ F15 \ 2013-10~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-10~	Multi display		x	x	

Juke \ F15 \ 2013-10~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-10~	Occupant detection			x	
Juke \ F15 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-11~	ABS	x	x	x	
Juke \ F15 \ 2013-11~	Meter/M&A		x	x	
Juke \ F15 \ 2013-11~	BCM		x		
Juke \ F15 \ 2013-11~	Air bag	x	x	x	
Juke \ F15 \ 2013-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2013-11~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-11~	IPDM E/R		x	x	
Juke \ F15 \ 2013-11~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-11~	Multi display		x	x	
Juke \ F15 \ 2013-11~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-11~	Occupant detection			x	
Juke \ F15 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-12~	ABS	x	x	x	
Juke \ F15 \ 2013-12~	Meter/M&A		x	x	
Juke \ F15 \ 2013-12~	BCM		x		
Juke \ F15 \ 2013-12~	Air bag	x	x	x	
Juke \ F15 \ 2013-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2013-12~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-12~	IPDM E/R		x	x	
Juke \ F15 \ 2013-12~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-12~	Multi display		x	x	
Juke \ F15 \ 2013-12~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-12~	Occupant detection			x	
Juke \ F15 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-1~	ABS	x	x	x	
Juke \ F15 \ 2013-1~	Meter/M&A		x	x	
Juke \ F15 \ 2013-1~	BCM		x		
Juke \ F15 \ 2013-1~	Air bag	x	x	x	

Juke \ F15 \ 2013-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2013-1~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-1~	IPDM E/R		x	x	
Juke \ F15 \ 2013-1~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-1~	Multi display		x	x	
Juke \ F15 \ 2013-1~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-1~	Occupant detection			x	
Juke \ F15 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-3~	ABS	x	x	x	
Juke \ F15 \ 2013-3~	Meter/M&A		x	x	
Juke \ F15 \ 2013-3~	BCM		x		
Juke \ F15 \ 2013-3~	Air bag	x	x	x	
Juke \ F15 \ 2013-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2013-3~	Multi AV		x	x	
Juke \ F15 \ 2013-3~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-3~	IPDM E/R		x	x	
Juke \ F15 \ 2013-3~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-3~	Multi display		x	x	
Juke \ F15 \ 2013-3~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-3~	Occupant detection			x	
Juke \ F15 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2013-8~	ABS	x	x	x	
Juke \ F15 \ 2013-8~	Meter/M&A		x	x	
Juke \ F15 \ 2013-8~	BCM		x		
Juke \ F15 \ 2013-8~	Air bag	x	x	x	
Juke \ F15 \ 2013-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2013-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke \ F15 \ 2013-8~	Multi AV	x	x	x	0280
Juke \ F15 \ 2013-8~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2013-8~	IPDM E/R		x	x	
Juke \ F15 \ 2013-8~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2013-8~	Multi display		x	x	
Juke \ F15 \ 2013-8~	PTC heater		x	x	
Juke \ F15 \ 2013-8~	Telematics		x	x	

Juke \ F15 \ 2013-8~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2013-8~	Occupant detection			x	
Juke \ F15 \ 2013-8~	Multi AV		x	x	
Juke \ F15 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014	ABS	x	x	x	
Juke \ F15 \ 2014	Meter/M&A		x	x	
Juke \ F15 \ 2014	BCM		x		
Juke \ F15 \ 2014	Air bag	x	x	x	
Juke \ F15 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014	Multi AV	x	x	x	0280
Juke \ F15 \ 2014	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014	IPDM E/R		x	x	
Juke \ F15 \ 2014	All mode AWD/4WD		x	x	
Juke \ F15 \ 2014	E-SUS		x	x	
Juke \ F15 \ 2014	Multi display		x	x	
Juke \ F15 \ 2014	PTC heater		x	x	
Juke \ F15 \ 2014	AVM		x	x	
Juke \ F15 \ 2014	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014	Occupant detection			x	
Juke \ F15 \ 2014-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014-10~	ABS	x	x	x	
Juke \ F15 \ 2014-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke \ F15 \ 2014-10~	BCM		x		
Juke \ F15 \ 2014-10~	Air bag	x	x	x	
Juke \ F15 \ 2014-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014-10~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014-10~	Multi AV	x	x	x	0280
Juke \ F15 \ 2014-10~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014-10~	IPDM E/R		x	x	
Juke \ F15 \ 2014-10~	Air pressure monitor	x	x	x	
Juke \ F15 \ 2014-10~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2014-10~	Adaptive light		x	x	
Juke \ F15 \ 2014-10~	CAN gateway		x		
Juke \ F15 \ 2014-10~	Multi display		x	x	

Juke \ F15 \ 2014-10~	PTC heater		x	x	
Juke \ F15 \ 2014-10~	EMCM	x	x	x	
Juke \ F15 \ 2014-10~	AVM		x	x	
Juke \ F15 \ 2014-10~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014-10~	Occupant detection			x	
Juke \ F15 \ 2014-10~	Multi AV		x	x	
Juke \ F15 \ 2014-10~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014-11~	ABS	x	x	x	
Juke \ F15 \ 2014-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke \ F15 \ 2014-11~	BCM		x		
Juke \ F15 \ 2014-11~	Air bag	x	x	x	
Juke \ F15 \ 2014-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014-11~	Multi AV	x	x	x	0280
Juke \ F15 \ 2014-11~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014-11~	IPDM E/R		x	x	
Juke \ F15 \ 2014-11~	Air pressure monitor	x	x	x	
Juke \ F15 \ 2014-11~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2014-11~	Adaptive light		x	x	
Juke \ F15 \ 2014-11~	CAN gateway		x		
Juke \ F15 \ 2014-11~	Multi display		x	x	
Juke \ F15 \ 2014-11~	PTC heater		x	x	
Juke \ F15 \ 2014-11~	EMCM	x	x	x	
Juke \ F15 \ 2014-11~	AVM		x	x	
Juke \ F15 \ 2014-11~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014-11~	Occupant detection			x	
Juke \ F15 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014-6~	ABS	x	x	x	
Juke \ F15 \ 2014-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke \ F15 \ 2014-6~	BCM		x		
Juke \ F15 \ 2014-6~	Air bag	x	x	x	
Juke \ F15 \ 2014-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014-6~	Multi AV	x	x	x	0280

Juke \ F15 \ 2014-6~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014-6~	IPDM E/R		x	x	
Juke \ F15 \ 2014-6~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2014-6~	E-SUS		x	x	
Juke \ F15 \ 2014-6~	Multi display		x	x	
Juke \ F15 \ 2014-6~	PTC heater		x	x	
Juke \ F15 \ 2014-6~	Telematics		x	x	
Juke \ F15 \ 2014-6~	AVM		x	x	
Juke \ F15 \ 2014-6~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014-6~	Occupant detection			x	
Juke \ F15 \ 2014-6~	Air pressure monitor	x	x	x	
Juke \ F15 \ 2014-6~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2014-6~	Adaptive light		x	x	
Juke \ F15 \ 2014-6~	CAN gateway		x		
Juke \ F15 \ 2014-6~	EMCM	x	x	x	
Juke \ F15 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014-7~	ABS	x	x	x	
Juke \ F15 \ 2014-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke \ F15 \ 2014-7~	BCM		x		
Juke \ F15 \ 2014-7~	Air bag	x	x	x	
Juke \ F15 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014-7~	Multi AV	x	x	x	0280
Juke \ F15 \ 2014-7~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014-7~	IPDM E/R		x	x	
Juke \ F15 \ 2014-7~	Air pressure monitor	x	x	x	
Juke \ F15 \ 2014-7~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2014-7~	Adaptive light		x	x	
Juke \ F15 \ 2014-7~	CAN gateway		x		
Juke \ F15 \ 2014-7~	Multi display		x	x	
Juke \ F15 \ 2014-7~	PTC heater		x	x	
Juke \ F15 \ 2014-7~	EMCM	x	x	x	
Juke \ F15 \ 2014-7~	AVM		x	x	
Juke \ F15 \ 2014-7~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014-7~	Occupant detection			x	
Juke \ F15 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2014-8~	ABS	x	x	x	

Juke \ F15 \ 2014-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke \ F15 \ 2014-8~	BCM		x		
Juke \ F15 \ 2014-8~	Air bag	x	x	x	
Juke \ F15 \ 2014-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2014-8~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2014-8~	Multi AV	x	x	x	0280
Juke \ F15 \ 2014-8~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2014-8~	IPDM E/R		x	x	
Juke \ F15 \ 2014-8~	Air pressure monitor	x	x	x	
Juke \ F15 \ 2014-8~	All mode AWD/4WD	x	x	x	0245, 0311
Juke \ F15 \ 2014-8~	Adaptive light		x	x	
Juke \ F15 \ 2014-8~	CAN gateway		x		
Juke \ F15 \ 2014-8~	Multi display		x	x	
Juke \ F15 \ 2014-8~	PTC heater		x	x	
Juke \ F15 \ 2014-8~	EMCM	x	x	x	
Juke \ F15 \ 2014-8~	AVM		x	x	
Juke \ F15 \ 2014-8~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2014-8~	Occupant detection			x	
Juke \ F15 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2015	ABS	x	x	x	
Juke \ F15 \ 2015	Meter/M&A		x	x	
Juke \ F15 \ 2015	BCM		x		
Juke \ F15 \ 2015	Air bag	x	x	x	
Juke \ F15 \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2015	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2015	Multi AV		x	x	
Juke \ F15 \ 2015	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2015	IPDM E/R		x	x	
Juke \ F15 \ 2015	Air pressure monitor	x	x	x	
Juke \ F15 \ 2015	All mode AWD/4WD		x	x	
Juke \ F15 \ 2015	Multi display		x	x	
Juke \ F15 \ 2015	PTC heater		x	x	
Juke \ F15 \ 2015	Telematics		x	x	
Juke \ F15 \ 2015	AVM		x	x	
Juke \ F15 \ 2015	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2015	Occupant detection			x	

Juke \ F15 \ 2015-10~	Engine	x	x	x	0145, 0064, 0148, 0124, 0188, 0187, 0021, 0189, 0166, 0103, 0104, 0016, 0190, 0018, 0017, 0012, 0011, 0014, 0107, 0013, 0216, 0210, 0212, 0007, 0278, 0112, 0176, 0233, 0234, 0209, 0026, 0185, 0262, 0006, 0023, 0005, 0306, 0009, 0327, 0205, 0069, 0097, 0220
Juke \ F15 \ 2015-10~	ABS	x	x	x	
Juke \ F15 \ 2015-10~	Meter/M&A		x	x	
Juke \ F15 \ 2015-10~	BCM		x		
Juke \ F15 \ 2015-10~	Air bag	x	x	x	
Juke \ F15 \ 2015-10~	ICC/ADAS	x	x	x	
Juke \ F15 \ 2015-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2015-10~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2015-10~	Multi AV		x	x	
Juke \ F15 \ 2015-10~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2015-10~	IPDM E/R		x	x	
Juke \ F15 \ 2015-10~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2015-10~	Lane camera		x	x	
Juke \ F15 \ 2015-10~	E-SUS		x	x	
Juke \ F15 \ 2015-10~	Side radar left		x	x	
Juke \ F15 \ 2015-10~	Multi display		x	x	
Juke \ F15 \ 2015-10~	Side radar right		x	x	
Juke \ F15 \ 2015-10~	PTC heater		x	x	
Juke \ F15 \ 2015-10~	Telematics		x	x	
Juke \ F15 \ 2015-10~	AVM		x	x	
Juke \ F15 \ 2015-10~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2015-10~	Occupant detection			x	
Juke \ F15 \ 2015-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2015-12~	ABS	x	x	x	
Juke \ F15 \ 2015-12~	Meter/M&A		x	x	
Juke \ F15 \ 2015-12~	BCM		x		
Juke \ F15 \ 2015-12~	Air bag	x	x	x	
Juke \ F15 \ 2015-12~	ICC/ADAS	x	x	x	
Juke \ F15 \ 2015-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

Juke \ F15 \ 2015-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2015-12~	Multi AV		x	x	
Juke \ F15 \ 2015-12~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2015-12~	IPDM E/R		x	x	
Juke \ F15 \ 2015-12~	Air pressure monitor		x	x	
Juke \ F15 \ 2015-12~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2015-12~	E-SUS		x	x	
Juke \ F15 \ 2015-12~	Multi display		x	x	
Juke \ F15 \ 2015-12~	PTC heater		x	x	
Juke \ F15 \ 2015-12~	AVM		x	x	
Juke \ F15 \ 2015-12~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2015-12~	Occupant detection			x	
Juke \ F15 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2015-9~	ABS	x	x	x	
Juke \ F15 \ 2015-9~	Meter/M&A		x	x	
Juke \ F15 \ 2015-9~	BCM		x		
Juke \ F15 \ 2015-9~	Air bag	x	x	x	
Juke \ F15 \ 2015-9~	ICC/ADAS	x	x	x	
Juke \ F15 \ 2015-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2015-9~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2015-9~	Multi AV		x	x	
Juke \ F15 \ 2015-9~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2015-9~	IPDM E/R		x	x	
Juke \ F15 \ 2015-9~	Air pressure monitor		x	x	
Juke \ F15 \ 2015-9~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2015-9~	E-SUS		x	x	
Juke \ F15 \ 2015-9~	Multi display		x	x	
Juke \ F15 \ 2015-9~	PTC heater		x	x	
Juke \ F15 \ 2015-9~	AVM		x	x	
Juke \ F15 \ 2015-9~	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2015-9~	Occupant detection			x	
Juke \ F15 \ 2015-9~	Multi AV	x	x	x	0280
Juke \ F15 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2016	ABS	x	x	x	
Juke \ F15 \ 2016	Meter/M&A		x	x	
Juke \ F15 \ 2016	BCM		x		

Juke \ F15 \ 2016	Air bag	x	x	x	
Juke \ F15 \ 2016	ICC/ADAS	x	x	x	
Juke \ F15 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2016	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2016	Multi AV	x	x	x	0280
Juke \ F15 \ 2016	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2016	IPDM E/R		x	x	
Juke \ F15 \ 2016	All mode AWD/4WD		x	x	
Juke \ F15 \ 2016	E-SUS		x	x	
Juke \ F15 \ 2016	Multi display		x	x	
Juke \ F15 \ 2016	PTC heater		x	x	
Juke \ F15 \ 2016	Telematics		x	x	
Juke \ F15 \ 2016	AVM		x	x	
Juke \ F15 \ 2016	Head lamp levelizer	x	x	x	
Juke \ F15 \ 2016	Occupant detection			x	
Juke \ F15 \ 2016-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2016-8~	ABS	x	x	x	
Juke \ F15 \ 2016-8~	Meter/M&A		x	x	
Juke \ F15 \ 2016-8~	BCM		x		
Juke \ F15 \ 2016-8~	Air bag	x	x	x	
Juke \ F15 \ 2016-8~	ICC/ADAS	x	x	x	
Juke \ F15 \ 2016-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2016-8~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2016-8~	EPS/DAST 3	x	x	x	
Juke \ F15 \ 2016-8~	IPDM E/R		x	x	
Juke \ F15 \ 2016-8~	Air pressure monitor		x	x	
Juke \ F15 \ 2016-8~	Laser/radar	x	x	x	
Juke \ F15 \ 2016-8~	All mode AWD/4WD		x	x	
Juke \ F15 \ 2016-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Juke \ F15 \ 2016-8~	4WAS(front)	x	x	x	
Juke \ F15 \ 2016-8~	E-SUS		x	x	
Juke \ F15 \ 2016-8~	Accele pedal ACT		x	x	
Juke \ F15 \ 2016-8~	Side radar left		x	x	
Juke \ F15 \ 2016-8~	Multi display		x	x	
Juke \ F15 \ 2016-8~	Side radar right		x	x	
Juke \ F15 \ 2016-8~	PTC heater		x	x	

Juke \ F15 \ 2016-8~	Occupant detection			×	
Juke \ F15 \ 2016-9~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke \ F15 \ 2016-9~	ABS	×	×	×	
Juke \ F15 \ 2016-9~	Meter/M&A		×	×	
Juke \ F15 \ 2016-9~	BCM		×		
Juke \ F15 \ 2016-9~	Air bag	×	×	×	
Juke \ F15 \ 2016-9~	ICC/ADAS	×	×	×	
Juke \ F15 \ 2016-9~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke \ F15 \ 2016-9~	Transmission	×	×	×	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke \ F15 \ 2016-9~	Multi AV		×	×	
Juke \ F15 \ 2016-9~	EPS/DAST 3	×	×	×	
Juke \ F15 \ 2016-9~	IPDM E/R		×	×	
Juke \ F15 \ 2016-9~	Laser/radar	×	×	×	
Juke \ F15 \ 2016-9~	All mode AWD/4WD		×	×	
Juke \ F15 \ 2016-9~	4WAS(MAIN)/RAS/HICAS	×	×	×	
Juke \ F15 \ 2016-9~	4WAS(front)	×	×	×	
Juke \ F15 \ 2016-9~	E-SUS		×	×	
Juke \ F15 \ 2016-9~	Accele pedal ACT		×	×	
Juke \ F15 \ 2016-9~	Side radar left		×	×	
Juke \ F15 \ 2016-9~	Multi display		×	×	
Juke \ F15 \ 2016-9~	Side radar right		×	×	
Juke \ F15 \ 2016-9~	PTC heater		×	×	
Juke \ F15 \ 2016-9~	Occupant detection			×	
Juke(2WD) \ F15 \ 2010-8~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2010-8~	ABS	×	×	×	
Juke(2WD) \ F15 \ 2010-8~	Meter/M&A		×	×	
Juke(2WD) \ F15 \ 2010-8~	BCM		×		
Juke(2WD) \ F15 \ 2010-8~	Air bag	×	×	×	
Juke(2WD) \ F15 \ 2010-8~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2010-8~	Transmission	×	×	×	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2010-8~	Multi AV	×	×	×	0280
Juke(2WD) \ F15 \ 2010-8~	EPS/DAST 3	×	×	×	
Juke(2WD) \ F15 \ 2010-8~	IPDM E/R		×	×	
Juke(2WD) \ F15 \ 2010-8~	All mode AWD/4WD	×	×	×	0245, 0311
Juke(2WD) \ F15 \ 2010-8~	CAN gateway		×		

Juke(2WD) \ F15 \ 2010-8~	Accele pedal ACT		x	x	
Juke(2WD) \ F15 \ 2010-8~	Multi display		x	x	
Juke(2WD) \ F15 \ 2010-8~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2010-8~	Telematics		x	x	
Juke(2WD) \ F15 \ 2010-8~	EMCM	x	x	x	
Juke(2WD) \ F15 \ 2010-8~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2010-8~	Sonar	x	x	x	
Juke(2WD) \ F15 \ 2010-8~	Occupant detection			x	
Juke(2WD) \ F15 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2011-8~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2011-8~	Meter/M&A		x	x	
Juke(2WD) \ F15 \ 2011-8~	BCM		x		
Juke(2WD) \ F15 \ 2011-8~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2011-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2011-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke(2WD) \ F15 \ 2011-8~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2011-8~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2011-8~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2011-8~	Multi display		x	x	
Juke(2WD) \ F15 \ 2011-8~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2011-8~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2011-8~	Occupant detection			x	
Juke(2WD) \ F15 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2012-5~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2012-5~	Meter/M&A		x	x	
Juke(2WD) \ F15 \ 2012-5~	BCM		x		
Juke(2WD) \ F15 \ 2012-5~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2012-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke(2WD) \ F15 \ 2012-5~	Multi AV	x	x	x	0280
Juke(2WD) \ F15 \ 2012-5~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2012-5~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2012-5~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2012-5~	Multi display		x	x	
Juke(2WD) \ F15 \ 2012-5~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2012-5~	Telematics		x	x	
Juke(2WD) \ F15 \ 2012-5~	EMCM	x	x	x	

Juke(2WD) \ F15 \ 2012-5~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2012-5~	Occupant detection			x	
Juke(2WD) \ F15 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2013-11~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2013-11~	Meter/M&A		x	x	
Juke(2WD) \ F15 \ 2013-11~	BCM		x		
Juke(2WD) \ F15 \ 2013-11~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2013-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2013-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2013-11~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2013-11~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2013-11~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2013-11~	Multi display		x	x	
Juke(2WD) \ F15 \ 2013-11~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2013-11~	Occupant detection			x	
Juke(2WD) \ F15 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2013-1~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2013-1~	Meter/M&A		x	x	
Juke(2WD) \ F15 \ 2013-1~	BCM		x		
Juke(2WD) \ F15 \ 2013-1~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2013-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2013-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Juke(2WD) \ F15 \ 2013-1~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2013-1~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2013-1~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2013-1~	Multi display		x	x	
Juke(2WD) \ F15 \ 2013-1~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2013-1~	Occupant detection			x	
Juke(2WD) \ F15 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2014-11~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke(2WD) \ F15 \ 2014-11~	BCM		x		
Juke(2WD) \ F15 \ 2014-11~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

Juke(2WD) \ F15 \ 2014-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2014-11~	Multi AV	x	x	x	0280
Juke(2WD) \ F15 \ 2014-11~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2014-11~	Air pressure monitor	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	All mode AWD/4WD	x	x	x	0245, 0311
Juke(2WD) \ F15 \ 2014-11~	Adaptive light		x	x	
Juke(2WD) \ F15 \ 2014-11~	CAN gateway		x		
Juke(2WD) \ F15 \ 2014-11~	Multi display		x	x	
Juke(2WD) \ F15 \ 2014-11~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2014-11~	EMCM	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	AVM		x	x	
Juke(2WD) \ F15 \ 2014-11~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2014-11~	Occupant detection			x	
Juke(2WD) \ F15 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2014-5~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke(2WD) \ F15 \ 2014-5~	BCM		x		
Juke(2WD) \ F15 \ 2014-5~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2014-5~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2014-5~	Multi AV	x	x	x	0280
Juke(2WD) \ F15 \ 2014-5~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2014-5~	Air pressure monitor	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2014-5~	E-SUS		x	x	
Juke(2WD) \ F15 \ 2014-5~	Multi display		x	x	
Juke(2WD) \ F15 \ 2014-5~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2014-5~	Telematics		x	x	
Juke(2WD) \ F15 \ 2014-5~	EMCM	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	AVM		x	x	
Juke(2WD) \ F15 \ 2014-5~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2014-5~	Occupant detection			x	
Juke(2WD) \ F15 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2014-6~	ABS	x	x	x	

Juke(2WD) \ F15 \ 2014-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Juke(2WD) \ F15 \ 2014-6~	BCM		x		
Juke(2WD) \ F15 \ 2014-6~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2014-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2014-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2014-6~	Multi AV	x	x	x	0280
Juke(2WD) \ F15 \ 2014-6~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2014-6~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2014-6~	Air pressure monitor	x	x	x	
Juke(2WD) \ F15 \ 2014-6~	All mode AWD/4WD	x	x	x	0245, 0311
Juke(2WD) \ F15 \ 2014-6~	Adaptive light		x	x	
Juke(2WD) \ F15 \ 2014-6~	CAN gateway		x		
Juke(2WD) \ F15 \ 2014-6~	Multi display		x	x	
Juke(2WD) \ F15 \ 2014-6~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2014-6~	EMCM	x	x	x	
Juke(2WD) \ F15 \ 2014-6~	AVM		x	x	
Juke(2WD) \ F15 \ 2014-6~	Head lamp levelizer	x	x	x	
Juke(2WD) \ F15 \ 2014-6~	Occupant detection			x	
Juke(2WD) \ F15 \ 2015-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Juke(2WD) \ F15 \ 2015-10~	ABS	x	x	x	
Juke(2WD) \ F15 \ 2015-10~	Meter/M&A		x	x	
Juke(2WD) \ F15 \ 2015-10~	BCM		x		
Juke(2WD) \ F15 \ 2015-10~	Air bag	x	x	x	
Juke(2WD) \ F15 \ 2015-10~	ICC/ADAS	x	x	x	
Juke(2WD) \ F15 \ 2015-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Juke(2WD) \ F15 \ 2015-10~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Juke(2WD) \ F15 \ 2015-10~	Multi AV		x	x	
Juke(2WD) \ F15 \ 2015-10~	EPS/DAST 3	x	x	x	
Juke(2WD) \ F15 \ 2015-10~	IPDM E/R		x	x	
Juke(2WD) \ F15 \ 2015-10~	Air pressure monitor		x	x	
Juke(2WD) \ F15 \ 2015-10~	All mode AWD/4WD		x	x	
Juke(2WD) \ F15 \ 2015-10~	E-SUS		x	x	
Juke(2WD) \ F15 \ 2015-10~	Multi display		x	x	
Juke(2WD) \ F15 \ 2015-10~	PTC heater		x	x	
Juke(2WD) \ F15 \ 2015-10~	AVM		x	x	
Juke(2WD) \ F15 \ 2015-10~	Head lamp levelizer	x	x	x	

Juke(2WD) \ F15 \ 2015-10~	Occupant detection			×	
KICKS \ P15 \ 2016-5~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
KICKS \ P15 \ 2016-5~	ABS		×	×	
KICKS \ P15 \ 2016-5~	Meter/M&A		×	×	
KICKS \ P15 \ 2016-5~	BCM		×		
KICKS \ P15 \ 2016-5~	Air bag		×	×	
KICKS \ P15 \ 2016-5~	ICC/ADAS	×	×	×	
KICKS \ P15 \ 2016-5~	HVAC		×	×	
KICKS \ P15 \ 2016-5~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
KICKS \ P15 \ 2016-5~	Multi AV	×	×	×	0280
KICKS \ P15 \ 2016-5~	EPS/DAST 3		×	×	
KICKS \ P15 \ 2016-5~	IPDM E/R		×	×	
KICKS \ P15 \ 2016-5~	Air pressure monitor		×	×	
KICKS \ P15 \ 2016-5~	Laser/radar	×	×	×	
KICKS \ P15 \ 2016-5~	Intelligent key		×	×	
KICKS \ P15 \ 2016-5~	Sonar		×	×	
KICKS \ P15 \ 2016-5~	CAN gateway		×		
KICKS \ P15 \ 2016-5~	Side radar left		×	×	
KICKS \ P15 \ 2016-5~	Side radar right		×	×	
KICKS \ P15 \ 2016-5~	AVM		×	×	
KICKS \ P15 \ 2016-5~	Chassis control		×	×	
KICKS \ P15 \ 2016-5~	Occupant detection			×	
KICKS \ P15 \ 2016-8~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
KICKS \ P15 \ 2016-8~	ABS		×	×	
KICKS \ P15 \ 2016-8~	Meter/M&A		×	×	
KICKS \ P15 \ 2016-8~	BCM		×		
KICKS \ P15 \ 2016-8~	Air bag		×	×	
KICKS \ P15 \ 2016-8~	ICC/ADAS		×	×	
KICKS \ P15 \ 2016-8~	HVAC		×	×	
KICKS \ P15 \ 2016-8~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
KICKS \ P15 \ 2016-8~	Multi AV	×	×	×	0280
KICKS \ P15 \ 2016-8~	EPS/DAST 3		×	×	
KICKS \ P15 \ 2016-8~	IPDM E/R		×	×	
KICKS \ P15 \ 2016-8~	Laser/radar		×	×	
KICKS \ P15 \ 2016-8~	Intelligent key		×	×	
KICKS \ P15 \ 2016-8~	Sonar		×	×	
KICKS \ P15 \ 2016-8~	CAN gateway		×		

KICKS \ P15 \ 2016-8~	Side radar left		x	x	
KICKS \ P15 \ 2016-8~	Side radar right		x	x	
KICKS \ P15 \ 2016-8~	AVM		x	x	
KICKS \ P15 \ 2016-8~	Chassis control		x	x	
Lafesta \ B30 \ 2004-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2004-12~	BCM	x	x		
Lafesta \ B30 \ 2004-12~	Transmission	x	x	x	
Lafesta \ B30 \ 2004-12~	Multi AV	x	x	x	0280
Lafesta \ B30 \ 2004-12~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2004-12~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2004-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2004-12~	Auto slide door	x	x	x	
Lafesta \ B30 \ 2004-12~	Engine	x	x	x	
Lafesta \ B30 \ 2004-12~	ABS	x	x	x	
Lafesta \ B30 \ 2004-12~	Air bag	x	x	x	
Lafesta \ B30 \ 2004-12~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2004-12~	Rearview camera			x	
Lafesta \ B30 \ 2004-12~	S/blind camera			x	
Lafesta \ B30 \ 2004-12~	Motor assist	x	x	x	
Lafesta \ B30 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2005-11~	BCM	x	x		
Lafesta \ B30 \ 2005-11~	Transmission	x	x	x	
Lafesta \ B30 \ 2005-11~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2005-11~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2005-11~	Auto slide door	x	x	x	
Lafesta \ B30 \ 2005-11~	Engine	x	x	x	
Lafesta \ B30 \ 2005-11~	ABS	x	x	x	
Lafesta \ B30 \ 2005-11~	Air bag	x	x	x	
Lafesta \ B30 \ 2005-11~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2005-11~	Rearview camera			x	
Lafesta \ B30 \ 2005-11~	S/blind camera			x	
Lafesta \ B30 \ 2005-11~	Motor assist	x	x	x	
Lafesta \ B30 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2005-12~	BCM	x	x		
Lafesta \ B30 \ 2005-12~	Transmission	x	x	x	
Lafesta \ B30 \ 2005-12~	Multi AV	x	x	x	0280

Lafesta \ B30 \ 2005-12~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2005-12~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2005-12~	Auto slide door	x	x	x	
Lafesta \ B30 \ 2005-12~	Engine	x	x	x	
Lafesta \ B30 \ 2005-12~	ABS	x	x	x	
Lafesta \ B30 \ 2005-12~	Air bag	x	x	x	
Lafesta \ B30 \ 2005-12~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2005-12~	Rearview camera			x	
Lafesta \ B30 \ 2005-12~	S/blind camera			x	
Lafesta \ B30 \ 2005-12~	Motor assist	x	x	x	
Lafesta \ B30 \ 2005-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2005-2~	BCM	x	x		
Lafesta \ B30 \ 2005-2~	Transmission	x	x	x	
Lafesta \ B30 \ 2005-2~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2005-2~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2005-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2005-2~	Auto slide door	x	x	x	
Lafesta \ B30 \ 2005-2~	Engine	x	x	x	
Lafesta \ B30 \ 2005-2~	ABS	x	x	x	
Lafesta \ B30 \ 2005-2~	Air bag	x	x	x	
Lafesta \ B30 \ 2005-2~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2005-2~	Rearview camera			x	
Lafesta \ B30 \ 2005-2~	S/blind camera			x	
Lafesta \ B30 \ 2005-2~	Motor assist	x	x	x	
Lafesta \ B30 \ 2007-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Lafesta \ B30 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2007-4~	BCM	x	x		
Lafesta \ B30 \ 2007-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Lafesta \ B30 \ 2007-4~	Multi AV	x	x	x	0280
Lafesta \ B30 \ 2007-4~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2007-4~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2007-4~	Auto slide door	x	x	x	

Lafesta \ B30 \ 2007-4~	ABS	x	x	x	
Lafesta \ B30 \ 2007-4~	Air bag	x	x	x	
Lafesta \ B30 \ 2007-4~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2007-4~	Rearview camera			x	
Lafesta \ B30 \ 2007-4~	S/blind camera			x	
Lafesta \ B30 \ 2007-4~	Motor assist	x	x	x	
Lafesta \ B30 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Lafesta \ B30 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Lafesta \ B30 \ 2010-8~	BCM	x	x		
Lafesta \ B30 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Lafesta \ B30 \ 2010-8~	Multi AV	x	x	x	0280
Lafesta \ B30 \ 2010-8~	EPS/DAST 3	x	x	x	
Lafesta \ B30 \ 2010-8~	IPDM E/R	x	x	x	
Lafesta \ B30 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Lafesta \ B30 \ 2010-8~	Auto slide door	x	x	x	
Lafesta \ B30 \ 2010-8~	ABS	x	x	x	
Lafesta \ B30 \ 2010-8~	Air bag	x	x	x	
Lafesta \ B30 \ 2010-8~	Head lamp levelizer	x	x	x	
Lafesta \ B30 \ 2010-8~	Rearview camera			x	
Lafesta \ B30 \ 2010-8~	S/blind camera			x	
Lafesta \ B30 \ 2010-8~	Motor assist	x	x	x	
LANNIA \ U15 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LANNIA \ U15 \ 2015-9~	ABS	x	x	x	
LANNIA \ U15 \ 2015-9~	Meter/M&A		x	x	0143
LANNIA \ U15 \ 2015-9~	BCM		x		
LANNIA \ U15 \ 2015-9~	Air bag	x	x	x	
LANNIA \ U15 \ 2015-9~	ICC/ADAS	x	x	x	
LANNIA \ U15 \ 2015-9~	Transmission		x	x	
LANNIA \ U15 \ 2015-9~	EPS/DAST 3	x	x	x	
LANNIA \ U15 \ 2015-9~	IPDM E/R		x	x	
LANNIA \ U15 \ 2015-9~	Air pressure monitor		x	x	
LANNIA \ U15 \ 2015-9~	Lane camera		x	x	
LANNIA \ U15 \ 2015-9~	Side radar left		x	x	
LANNIA \ U15 \ 2015-9~	Side radar right		x	x	
LATIO \ N17 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LATIO \ N17 \ 2012-7~	ABS	x	x	x	0003, 0092, 0264

LATIO \ N17 \ 2012-7~	Meter/M&A		x	x	
LATIO \ N17 \ 2012-7~	BCM		x		
LATIO \ N17 \ 2012-7~	Transmission		x	x	
LATIO \ N17 \ 2012-7~	EPS/DAST 3	x	x	x	
LATIO \ N17 \ 2012-7~	IPDM E/R		x	x	
LATIO \ N17 \ 2012-7~	Air bag	x	x	x	
LATIO \ N17 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LATIO \ N17 \ 2014-8~	ABS	x	x	x	
LATIO \ N17 \ 2014-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
LATIO \ N17 \ 2014-8~	BCM		x		
LATIO \ N17 \ 2014-8~	Air bag	x	x	x	
LATIO \ N17 \ 2014-8~	Transmission		x	x	0059, 0118
LATIO \ N17 \ 2014-8~	Multi AV	x	x	x	0280
LATIO \ N17 \ 2014-8~	EPS/DAST 3	x	x	x	
LATIO \ N17 \ 2014-8~	IPDM E/R		x	x	
LATIO \ N17 \ 2014-8~	Telematics		x	x	0253
LATIO \ N17 \ 2014-8~	AVM		x	x	
LATIO \ N17 \ 2014-8~	Occupant detection			x	
Laurel \ C35 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Laurel \ C35 \ All Year	ABS	x	x	x	0003, 0092, 0264
Laurel \ C35 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Laurel \ C35 \ All Year	BCM	x	x		
Laurel \ C35 \ All Year	Air bag	x	x	x	
Laurel \ C35 \ All Year	ICC/ADAS	x	x	x	
Laurel \ C35 \ All Year	HVAC	x	x	x	
Laurel \ C35 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Laurel \ C35 \ All Year	Multi AV	x	x	x	0280
Laurel \ C35 \ All Year	EPS/DAST 3	x	x	x	
Laurel \ C35 \ All Year	IPDM E/R	x	x	x	
Laurel \ C35 \ All Year	Air pressure monitor	x	x	x	
Laurel \ C35 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Laurel \ C35 \ All Year	DIU	x	x	x	
Laurel \ C35 \ All Year	Auto slide door	x	x	x	
Laurel \ C35 \ All Year	Auto drive position	x	x	x	
Laurel \ C35 \ All Year	All mode AWD/4WD	x	x	x	
Laurel \ C35 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Laurel \ C35 \ All Year	Sonar	x	x	x	

Laurel \ C35 \ All Year	Lane camera	x	x	x	
Laurel \ C35 \ All Year	Adaptive light	x	x	x	
Laurel \ C35 \ All Year	AVM		x	x	
Laurel \ C35 \ All Year	Head lamp levelizer	x	x	x	
Laurel \ C35 \ All Year	Difference lock	x	x	x	
Laurel \ C35 \ All Year	Nats immu	x	x		
Laurel \ C35 \ All Year	Smart entrance	x	x		
Laurel \ C35 \ All Year	Air levelizer	x	x	x	
Laurel \ C35 \ All Year	Rearview camera			x	
Laurel \ C35 \ All Year	S/blind camera			x	
Laurel \ C35 \ All Year	Motor assist	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	ABS	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Meter/M&A		x	x	0143
Leaf (pilot) \ ZE0(P) \ 2011-1~	BCM		x		
Leaf (pilot) \ ZE0(P) \ 2011-1~	Air bag	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	HVAC		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Transmission		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Multi AV		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	EHS/PKB		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Motor control		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	EPS/DAST 3	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	IPDM E/R		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Auto drive position		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Shift		x	x	0204
Leaf (pilot) \ ZE0(P) \ 2011-1~	EV/HEV	x	x	x	0053
Leaf (pilot) \ ZE0(P) \ 2011-1~	HV battery		x	x	0251
Leaf (pilot) \ ZE0(P) \ 2011-1~	Brake		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	Charger/PD module		x	x	0065
Leaf (pilot) \ ZE0(P) \ 2011-1~	Telematics		x	x	0253
Leaf (pilot) \ ZE0(P) \ 2011-1~	Head lamp levelizer	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-1~	VSP	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	ABS	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Meter/M&A		x	x	0143
Leaf (pilot) \ ZE0(P) \ 2011-4~	BCM		x		
Leaf (pilot) \ ZE0(P) \ 2011-4~	Air bag	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	HVAC		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Transmission		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Multi AV		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	EHS/PKB		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Motor control		x	x	

Leaf (pilot) \ ZE0(P) \ 2011-4~	EPS/DAST 3	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	IPDM E/R		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Auto drive position		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Shift		x	x	0204
Leaf (pilot) \ ZE0(P) \ 2011-4~	EV/HEV	x	x	x	0053
Leaf (pilot) \ ZE0(P) \ 2011-4~	HV battery		x	x	0251
Leaf (pilot) \ ZE0(P) \ 2011-4~	Brake		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	Charger/PD module		x	x	0065
Leaf (pilot) \ ZE0(P) \ 2011-4~	Telematics		x	x	0253
Leaf (pilot) \ ZE0(P) \ 2011-4~	Head lamp levelizer	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-4~	VSP	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	ABS	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Meter/M&A		x	x	0143
Leaf (pilot) \ ZE0(P) \ 2011-7~	BCM		x		
Leaf (pilot) \ ZE0(P) \ 2011-7~	Air bag	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	HVAC		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Transmission		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Multi AV		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	EHS/PKB		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Motor control		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	EPS/DAST 3	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	IPDM E/R		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Auto drive position		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Shift		x	x	0204
Leaf (pilot) \ ZE0(P) \ 2011-7~	EV/HEV	x	x	x	0053
Leaf (pilot) \ ZE0(P) \ 2011-7~	HV battery		x	x	0251
Leaf (pilot) \ ZE0(P) \ 2011-7~	Brake		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	Charger/PD module		x	x	0065
Leaf (pilot) \ ZE0(P) \ 2011-7~	Telematics		x	x	0253
Leaf (pilot) \ ZE0(P) \ 2011-7~	Head lamp levelizer	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-7~	VSP	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	ABS	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	Meter/M&A		x	x	0143
Leaf (pilot) \ ZE0(P) \ 2011-9~	BCM		x		
Leaf (pilot) \ ZE0(P) \ 2011-9~	Air bag	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	HVAC		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	Multi AV		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	EHS/PKB		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	Motor control		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	EPS/DAST 3	x	x	x	

Leaf (pilot) \ ZE0(P) \ 2011-9~	IPDM E/R		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	Shift		x	x	0204
Leaf (pilot) \ ZE0(P) \ 2011-9~	EV/HEV	x	x	x	0053
Leaf (pilot) \ ZE0(P) \ 2011-9~	HV battery		x	x	0251
Leaf (pilot) \ ZE0(P) \ 2011-9~	Brake		x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	Charger/PD module		x	x	0065
Leaf (pilot) \ ZE0(P) \ 2011-9~	Telematics		x	x	0253
Leaf (pilot) \ ZE0(P) \ 2011-9~	Head lamp levelizer	x	x	x	
Leaf (pilot) \ ZE0(P) \ 2011-9~	VSP	x	x	x	
Leaf \ ZE0 \ 2010-10~	ABS	x	x	x	
Leaf \ ZE0 \ 2010-10~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2010-10~	BCM		x		
Leaf \ ZE0 \ 2010-10~	Air bag	x	x	x	
Leaf \ ZE0 \ 2010-10~	HVAC		x	x	
Leaf \ ZE0 \ 2010-10~	Transmission		x	x	
Leaf \ ZE0 \ 2010-10~	Multi AV		x	x	
Leaf \ ZE0 \ 2010-10~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2010-10~	Motor control		x	x	
Leaf \ ZE0 \ 2010-10~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2010-10~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2010-10~	Shift		x	x	0204
Leaf \ ZE0 \ 2010-10~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2010-10~	HV battery		x	x	0251
Leaf \ ZE0 \ 2010-10~	Brake		x	x	
Leaf \ ZE0 \ 2010-10~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2010-10~	Telematics		x	x	0253
Leaf \ ZE0 \ 2010-10~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2010-10~	VSP	x	x	x	
Leaf \ ZE0 \ 2010-11~	ABS	x	x	x	
Leaf \ ZE0 \ 2010-11~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2010-11~	BCM		x		
Leaf \ ZE0 \ 2010-11~	Air bag	x	x	x	
Leaf \ ZE0 \ 2010-11~	HVAC		x	x	
Leaf \ ZE0 \ 2010-11~	Transmission		x	x	
Leaf \ ZE0 \ 2010-11~	Multi AV		x	x	
Leaf \ ZE0 \ 2010-11~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2010-11~	Motor control		x	x	
Leaf \ ZE0 \ 2010-11~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2010-11~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2010-11~	Shift		x	x	0204

Leaf \ ZE0 \ 2010-11~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2010-11~	HV battery		x	x	0251
Leaf \ ZE0 \ 2010-11~	Brake		x	x	
Leaf \ ZE0 \ 2010-11~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2010-11~	Telematics		x	x	0253
Leaf \ ZE0 \ 2010-11~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2010-11~	VSP	x	x	x	
Leaf \ ZE0 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Leaf \ ZE0 \ 2010-11~	Meter/M&A	x	x	x	0143, 0330, 0197, 0143, 0331
Leaf \ ZE0 \ 2010-11~	AVM		x	x	
Leaf \ ZE0 \ 2010-11~	Occupant detection			x	
Leaf \ ZE0 \ 2011	ABS	x	x	x	
Leaf \ ZE0 \ 2011	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2011	BCM		x		
Leaf \ ZE0 \ 2011	Air bag	x	x	x	
Leaf \ ZE0 \ 2011	HVAC		x	x	
Leaf \ ZE0 \ 2011	Transmission		x	x	
Leaf \ ZE0 \ 2011	Multi AV		x	x	
Leaf \ ZE0 \ 2011	EHS/PKB		x	x	
Leaf \ ZE0 \ 2011	Motor control		x	x	
Leaf \ ZE0 \ 2011	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2011	IPDM E/R		x	x	
Leaf \ ZE0 \ 2011	Shift		x	x	0204
Leaf \ ZE0 \ 2011	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2011	HV battery		x	x	0251
Leaf \ ZE0 \ 2011	Brake		x	x	
Leaf \ ZE0 \ 2011	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2011	Telematics		x	x	0253
Leaf \ ZE0 \ 2011	VSP	x	x	x	
Leaf \ ZE0 \ 2011-10~	ABS	x	x	x	
Leaf \ ZE0 \ 2011-10~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2011-10~	BCM		x		
Leaf \ ZE0 \ 2011-10~	Air bag	x	x	x	
Leaf \ ZE0 \ 2011-10~	HVAC		x	x	
Leaf \ ZE0 \ 2011-10~	Multi AV		x	x	
Leaf \ ZE0 \ 2011-10~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2011-10~	Motor control		x	x	
Leaf \ ZE0 \ 2011-10~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2011-10~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2011-10~	Shift		x	x	0204

Leaf \ ZE0 \ 2011-10~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2011-10~	HV battery		x	x	0251
Leaf \ ZE0 \ 2011-10~	Brake		x	x	
Leaf \ ZE0 \ 2011-10~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2011-10~	Telematics		x	x	0253
Leaf \ ZE0 \ 2011-10~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2011-10~	VSP	x	x	x	
Leaf \ ZE0 \ 2012	ABS	x	x	x	
Leaf \ ZE0 \ 2012	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2012	BCM		x		
Leaf \ ZE0 \ 2012	Air bag	x	x	x	
Leaf \ ZE0 \ 2012	HVAC		x	x	
Leaf \ ZE0 \ 2012	Multi AV		x	x	
Leaf \ ZE0 \ 2012	EHS/PKB		x	x	
Leaf \ ZE0 \ 2012	Motor control		x	x	
Leaf \ ZE0 \ 2012	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2012	IPDM E/R		x	x	
Leaf \ ZE0 \ 2012	Shift		x	x	0204
Leaf \ ZE0 \ 2012	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2012	HV battery		x	x	0251
Leaf \ ZE0 \ 2012	Brake		x	x	
Leaf \ ZE0 \ 2012	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2012	Telematics		x	x	0253
Leaf \ ZE0 \ 2012	VSP	x	x	x	
Leaf \ ZE0 \ 2012-10~	ABS	x	x	x	
Leaf \ ZE0 \ 2012-10~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2012-10~	BCM		x		
Leaf \ ZE0 \ 2012-10~	Air bag		x	x	
Leaf \ ZE0 \ 2012-10~	HVAC		x	x	
Leaf \ ZE0 \ 2012-10~	Multi AV		x	x	
Leaf \ ZE0 \ 2012-10~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2012-10~	Motor control		x	x	
Leaf \ ZE0 \ 2012-10~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2012-10~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2012-10~	Shift		x	x	0204
Leaf \ ZE0 \ 2012-10~	EV/HEV		x	x	
Leaf \ ZE0 \ 2012-10~	HV battery		x	x	
Leaf \ ZE0 \ 2012-10~	Brake		x	x	
Leaf \ ZE0 \ 2012-10~	VSP		x	x	
Leaf \ ZE0 \ 2012-10~	Charger/PD module		x	x	

Leaf \ ZE0 \ 2012-10~	Telematics		x	x	0253
Leaf \ ZE0 \ 2012-10~	AVM		x	x	
Leaf \ ZE0 \ 2012-10~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2012-12~	ABS	x	x	x	
Leaf \ ZE0 \ 2012-12~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2012-12~	BCM		x		
Leaf \ ZE0 \ 2012-12~	Air bag		x	x	
Leaf \ ZE0 \ 2012-12~	HVAC		x	x	
Leaf \ ZE0 \ 2012-12~	Multi AV		x	x	
Leaf \ ZE0 \ 2012-12~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2012-12~	Motor control		x	x	
Leaf \ ZE0 \ 2012-12~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2012-12~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2012-12~	Shift		x	x	0204
Leaf \ ZE0 \ 2012-12~	EV/HEV		x	x	
Leaf \ ZE0 \ 2012-12~	HV battery		x	x	
Leaf \ ZE0 \ 2012-12~	Brake		x	x	
Leaf \ ZE0 \ 2012-12~	VSP		x	x	
Leaf \ ZE0 \ 2012-12~	Charger/PD module		x	x	
Leaf \ ZE0 \ 2012-12~	Telematics		x	x	0253
Leaf \ ZE0 \ 2012-12~	AVM		x	x	
Leaf \ ZE0 \ 2012-12~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2012-12~	Occupant detection			x	
Leaf \ ZE0 \ 2012-4~	ABS	x	x	x	
Leaf \ ZE0 \ 2012-4~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2012-4~	BCM		x		
Leaf \ ZE0 \ 2012-4~	Air bag	x	x	x	
Leaf \ ZE0 \ 2012-4~	HVAC		x	x	
Leaf \ ZE0 \ 2012-4~	Multi AV		x	x	
Leaf \ ZE0 \ 2012-4~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2012-4~	Motor control		x	x	
Leaf \ ZE0 \ 2012-4~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2012-4~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2012-4~	Shift		x	x	0204
Leaf \ ZE0 \ 2012-4~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2012-4~	HV battery		x	x	0251
Leaf \ ZE0 \ 2012-4~	Brake		x	x	
Leaf \ ZE0 \ 2012-4~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2012-4~	Telematics		x	x	0253
Leaf \ ZE0 \ 2012-4~	Head lamp levelizer	x	x	x	

Leaf \ ZE0 \ 2012-4~	VSP	x	x	x	
Leaf \ ZE0 \ 2013	ABS	x	x	x	
Leaf \ ZE0 \ 2013	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2013	BCM		x		
Leaf \ ZE0 \ 2013	Air bag		x	x	
Leaf \ ZE0 \ 2013	HVAC		x	x	
Leaf \ ZE0 \ 2013	Multi AV		x	x	
Leaf \ ZE0 \ 2013	EHS/PKB		x	x	
Leaf \ ZE0 \ 2013	Motor control		x	x	
Leaf \ ZE0 \ 2013	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2013	IPDM E/R		x	x	
Leaf \ ZE0 \ 2013	Shift		x	x	0204
Leaf \ ZE0 \ 2013	EV/HEV		x	x	
Leaf \ ZE0 \ 2013	HV battery		x	x	
Leaf \ ZE0 \ 2013	Brake		x	x	
Leaf \ ZE0 \ 2013	VSP		x	x	
Leaf \ ZE0 \ 2013	Charger/PD module		x	x	
Leaf \ ZE0 \ 2013	Telematics		x	x	0253
Leaf \ ZE0 \ 2013	AVM		x	x	
Leaf \ ZE0 \ 2013	Occupant detection			x	
Leaf \ ZE0 \ 2013-2~	ABS	x	x	x	
Leaf \ ZE0 \ 2013-2~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2013-2~	BCM		x		
Leaf \ ZE0 \ 2013-2~	Air bag	x	x	x	
Leaf \ ZE0 \ 2013-2~	HVAC		x	x	
Leaf \ ZE0 \ 2013-2~	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2013-2~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2013-2~	Motor control		x	x	
Leaf \ ZE0 \ 2013-2~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2013-2~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2013-2~	Air pressure monitor		x	x	
Leaf \ ZE0 \ 2013-2~	Shift		x	x	0204
Leaf \ ZE0 \ 2013-2~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2013-2~	HV battery		x	x	0251
Leaf \ ZE0 \ 2013-2~	Brake		x	x	
Leaf \ ZE0 \ 2013-2~	VSP	x	x	x	
Leaf \ ZE0 \ 2013-2~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2013-2~	Telematics		x	x	0253
Leaf \ ZE0 \ 2013-2~	AVM		x	x	
Leaf \ ZE0 \ 2013-2~	Head lamp levelizer	x	x	x	

Leaf \ ZE0 \ 2013-2~	Difference lock	x	x	x	
Leaf \ ZE0 \ 2013-2~	Occupant detection			x	
Leaf \ ZE0 \ 2013-2~	Multi AV		x	x	
Leaf \ ZE0 \ 2013-2~	EV/HEV		x	x	
Leaf \ ZE0 \ 2013-2~	HV battery		x	x	
Leaf \ ZE0 \ 2013-2~	Charger/PD module		x	x	
Leaf \ ZE0 \ 2013-4~	ABS	x	x	x	
Leaf \ ZE0 \ 2013-4~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2013-4~	BCM		x		
Leaf \ ZE0 \ 2013-4~	Air bag		x	x	
Leaf \ ZE0 \ 2013-4~	HVAC		x	x	
Leaf \ ZE0 \ 2013-4~	Multi AV		x	x	
Leaf \ ZE0 \ 2013-4~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2013-4~	Motor control		x	x	
Leaf \ ZE0 \ 2013-4~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2013-4~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2013-4~	Shift		x	x	0204
Leaf \ ZE0 \ 2013-4~	EV/HEV		x	x	
Leaf \ ZE0 \ 2013-4~	HV battery		x	x	
Leaf \ ZE0 \ 2013-4~	Brake		x	x	
Leaf \ ZE0 \ 2013-4~	VSP		x	x	
Leaf \ ZE0 \ 2013-4~	Charger/PD module		x	x	
Leaf \ ZE0 \ 2013-4~	Telematics		x	x	0253
Leaf \ ZE0 \ 2013-4~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2013-8~	ABS	x	x	x	
Leaf \ ZE0 \ 2013-8~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2013-8~	BCM		x		
Leaf \ ZE0 \ 2013-8~	Air bag	x	x	x	
Leaf \ ZE0 \ 2013-8~	HVAC		x	x	
Leaf \ ZE0 \ 2013-8~	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2013-8~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2013-8~	Motor control		x	x	
Leaf \ ZE0 \ 2013-8~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2013-8~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2013-8~	Air pressure monitor		x	x	
Leaf \ ZE0 \ 2013-8~	Shift		x	x	0204
Leaf \ ZE0 \ 2013-8~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2013-8~	HV battery		x	x	0251
Leaf \ ZE0 \ 2013-8~	Brake		x	x	
Leaf \ ZE0 \ 2013-8~	VSP	x	x	x	

Leaf \ ZE0 \ 2013-8~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2013-8~	Telematics		x	x	0253
Leaf \ ZE0 \ 2013-8~	AVM		x	x	
Leaf \ ZE0 \ 2013-8~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2013-8~	Difference lock	x	x	x	
Leaf \ ZE0 \ 2013-8~	Occupant detection			x	
Leaf \ ZE0 \ 2013-9~	ABS	x	x	x	
Leaf \ ZE0 \ 2013-9~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2013-9~	BCM		x		
Leaf \ ZE0 \ 2013-9~	Air bag	x	x	x	
Leaf \ ZE0 \ 2013-9~	HVAC		x	x	
Leaf \ ZE0 \ 2013-9~	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2013-9~	Motor control		x	x	
Leaf \ ZE0 \ 2013-9~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2013-9~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2013-9~	Shift		x	x	0204
Leaf \ ZE0 \ 2013-9~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2013-9~	HV battery		x	x	0251
Leaf \ ZE0 \ 2013-9~	Brake		x	x	
Leaf \ ZE0 \ 2013-9~	VSP	x	x	x	
Leaf \ ZE0 \ 2013-9~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2013-9~	Telematics		x	x	0253
Leaf \ ZE0 \ 2013-9~	AVM		x	x	
Leaf \ ZE0 \ 2013-9~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2013-9~	Occupant detection			x	
Leaf \ ZE0 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Leaf \ ZE0 \ 2013-9~	Meter/M&A	x	x	x	0143, 0330, 0197, 0143, 0331
Leaf \ ZE0 \ 2013-9~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2014	ABS	x	x	x	
Leaf \ ZE0 \ 2014	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2014	BCM		x		
Leaf \ ZE0 \ 2014	Air bag	x	x	x	
Leaf \ ZE0 \ 2014	HVAC		x	x	
Leaf \ ZE0 \ 2014	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2014	Motor control		x	x	
Leaf \ ZE0 \ 2014	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2014	IPDM E/R		x	x	
Leaf \ ZE0 \ 2014	Shift		x	x	0204
Leaf \ ZE0 \ 2014	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2014	HV battery		x	x	0251

Leaf \ ZE0 \ 2014	Brake		x	x	
Leaf \ ZE0 \ 2014	VSP	x	x	x	
Leaf \ ZE0 \ 2014	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2014	Telematics		x	x	0253
Leaf \ ZE0 \ 2014	AVM		x	x	
Leaf \ ZE0 \ 2014	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2014	Occupant detection			x	
Leaf \ ZE0 \ 2014-11~	ABS	x	x	x	
Leaf \ ZE0 \ 2014-11~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2014-11~	BCM		x		
Leaf \ ZE0 \ 2014-11~	Air bag	x	x	x	
Leaf \ ZE0 \ 2014-11~	HVAC		x	x	
Leaf \ ZE0 \ 2014-11~	Multi AV		x	x	
Leaf \ ZE0 \ 2014-11~	Motor control		x	x	
Leaf \ ZE0 \ 2014-11~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2014-11~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2014-11~	Air pressure monitor	x	x	x	
Leaf \ ZE0 \ 2014-11~	Shift		x	x	0204
Leaf \ ZE0 \ 2014-11~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2014-11~	HV battery		x	x	0251
Leaf \ ZE0 \ 2014-11~	Brake		x	x	
Leaf \ ZE0 \ 2014-11~	VSP	x	x	x	
Leaf \ ZE0 \ 2014-11~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2014-11~	Telematics		x	x	0253
Leaf \ ZE0 \ 2014-11~	AVM		x	x	
Leaf \ ZE0 \ 2014-11~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2014-11~	Occupant detection			x	
Leaf \ ZE0 \ 2014-4~	ABS	x	x	x	
Leaf \ ZE0 \ 2014-4~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2014-4~	BCM		x		
Leaf \ ZE0 \ 2014-4~	Air bag	x	x	x	
Leaf \ ZE0 \ 2014-4~	HVAC		x	x	
Leaf \ ZE0 \ 2014-4~	Multi AV		x	x	
Leaf \ ZE0 \ 2014-4~	Motor control		x	x	
Leaf \ ZE0 \ 2014-4~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2014-4~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2014-4~	Shift		x	x	0204
Leaf \ ZE0 \ 2014-4~	EV/HEV		x	x	
Leaf \ ZE0 \ 2014-4~	HV battery		x	x	
Leaf \ ZE0 \ 2014-4~	Brake		x	x	

Leaf \ ZE0 \ 2014-4~	VSP	x	x	x	
Leaf \ ZE0 \ 2014-4~	Charger/PD module		x	x	
Leaf \ ZE0 \ 2014-4~	Telematics		x	x	0253
Leaf \ ZE0 \ 2014-4~	AVM		x	x	
Leaf \ ZE0 \ 2014-4~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2014-4~	Occupant detection			x	
Leaf \ ZE0 \ 2014-4~	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2014-4~	EHS/PKB		x	x	
Leaf \ ZE0 \ 2014-4~	Air pressure monitor		x	x	
Leaf \ ZE0 \ 2014-4~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2014-4~	HV battery		x	x	0251
Leaf \ ZE0 \ 2014-4~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2014-4~	Difference lock	x	x	x	
Leaf \ ZE0 \ 2014-4~	Air pressure monitor	x	x	x	
Leaf \ ZE0 \ 2015	ABS	x	x	x	
Leaf \ ZE0 \ 2015	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2015	BCM		x		
Leaf \ ZE0 \ 2015	Air bag	x	x	x	
Leaf \ ZE0 \ 2015	HVAC		x	x	
Leaf \ ZE0 \ 2015	Multi AV		x	x	
Leaf \ ZE0 \ 2015	Motor control		x	x	
Leaf \ ZE0 \ 2015	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2015	IPDM E/R		x	x	
Leaf \ ZE0 \ 2015	Shift		x	x	0204
Leaf \ ZE0 \ 2015	EV/HEV		x	x	
Leaf \ ZE0 \ 2015	HV battery		x	x	
Leaf \ ZE0 \ 2015	Brake		x	x	
Leaf \ ZE0 \ 2015	VSP	x	x	x	
Leaf \ ZE0 \ 2015	Charger/PD module		x	x	
Leaf \ ZE0 \ 2015	Telematics		x	x	0253
Leaf \ ZE0 \ 2015	AVM		x	x	
Leaf \ ZE0 \ 2015	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2015	Occupant detection			x	
Leaf \ ZE0 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Leaf \ ZE0 \ 2015-11~	ABS	x	x	x	
Leaf \ ZE0 \ 2015-11~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2015-11~	BCM		x		
Leaf \ ZE0 \ 2015-11~	Air bag	x	x	x	
Leaf \ ZE0 \ 2015-11~	ICC/ADAS	x	x	x	
Leaf \ ZE0 \ 2015-11~	HVAC		x	x	

Leaf \ ZE0 \ 2015-11~	Multi AV		x	x	
Leaf \ ZE0 \ 2015-11~	Motor control		x	x	
Leaf \ ZE0 \ 2015-11~	EPS/DAST 3		x	x	
Leaf \ ZE0 \ 2015-11~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2015-11~	Lane camera		x	x	
Leaf \ ZE0 \ 2015-11~	Shift		x	x	0204
Leaf \ ZE0 \ 2015-11~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2015-11~	HV battery		x	x	0251
Leaf \ ZE0 \ 2015-11~	Brake		x	x	
Leaf \ ZE0 \ 2015-11~	VSP	x	x	x	
Leaf \ ZE0 \ 2015-11~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2015-11~	Telematics		x	x	0253
Leaf \ ZE0 \ 2015-11~	AVM		x	x	
Leaf \ ZE0 \ 2015-11~	Chassis control		x	x	
Leaf \ ZE0 \ 2015-11~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2015-11~	Occupant detection			x	
Leaf \ ZE0 \ 2015-11~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2015-11~	Air pressure monitor		x	x	
Leaf \ ZE0 \ 2015-11~	Laser/radar	x	x	x	
Leaf \ ZE0 \ 2015-11~	4WAS(front)	x	x	x	
Leaf \ ZE0 \ 2015-11~	Accele pedal ACT		x	x	
Leaf \ ZE0 \ 2015-11~	Side radar left		x	x	
Leaf \ ZE0 \ 2015-11~	Side radar right		x	x	
Leaf \ ZE0 \ 2015-8~	ABS	x	x	x	
Leaf \ ZE0 \ 2015-8~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2015-8~	BCM	x	x		
Leaf \ ZE0 \ 2015-8~	Air bag	x	x	x	
Leaf \ ZE0 \ 2015-8~	HVAC		x	x	
Leaf \ ZE0 \ 2015-8~	Multi AV		x	x	
Leaf \ ZE0 \ 2015-8~	Motor control		x	x	
Leaf \ ZE0 \ 2015-8~	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2015-8~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2015-8~	Shift		x	x	0204
Leaf \ ZE0 \ 2015-8~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2015-8~	HV battery		x	x	0251
Leaf \ ZE0 \ 2015-8~	Brake		x	x	
Leaf \ ZE0 \ 2015-8~	VSP	x	x	x	
Leaf \ ZE0 \ 2015-8~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2015-8~	AVM		x	x	
Leaf \ ZE0 \ 2015-8~	Chassis control		x	x	

Leaf \ ZE0 \ 2015-8~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2015-8~	Occupant detection			x	
Leaf \ ZE0 \ 2016	ABS	x	x	x	
Leaf \ ZE0 \ 2016	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2016	BCM		x		
Leaf \ ZE0 \ 2016	Air bag	x	x	x	
Leaf \ ZE0 \ 2016	HVAC		x	x	
Leaf \ ZE0 \ 2016	Multi AV	x	x	x	0280
Leaf \ ZE0 \ 2016	Motor control		x	x	
Leaf \ ZE0 \ 2016	EPS/DAST 3	x	x	x	
Leaf \ ZE0 \ 2016	IPDM E/R		x	x	
Leaf \ ZE0 \ 2016	Auto drive position		x	x	
Leaf \ ZE0 \ 2016	Shift		x	x	0204
Leaf \ ZE0 \ 2016	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2016	HV battery		x	x	0251
Leaf \ ZE0 \ 2016	Brake		x	x	
Leaf \ ZE0 \ 2016	VSP	x	x	x	
Leaf \ ZE0 \ 2016	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2016	Telematics		x	x	0253
Leaf \ ZE0 \ 2016	AVM		x	x	
Leaf \ ZE0 \ 2016	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2016	Occupant detection			x	
Leaf \ ZE0 \ 2016-8~	Engine		x	x	
Leaf \ ZE0 \ 2016-8~	ABS	x	x	x	
Leaf \ ZE0 \ 2016-8~	Meter/M&A		x	x	0143
Leaf \ ZE0 \ 2016-8~	BCM		x		
Leaf \ ZE0 \ 2016-8~	Air bag	x	x	x	
Leaf \ ZE0 \ 2016-8~	ICC/ADAS	x	x	x	
Leaf \ ZE0 \ 2016-8~	HVAC		x	x	
Leaf \ ZE0 \ 2016-8~	Transmission		x	x	
Leaf \ ZE0 \ 2016-8~	Motor control		x	x	
Leaf \ ZE0 \ 2016-8~	EPS/DAST 3		x	x	
Leaf \ ZE0 \ 2016-8~	IPDM E/R		x	x	
Leaf \ ZE0 \ 2016-8~	Laser/radar	x	x	x	
Leaf \ ZE0 \ 2016-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Leaf \ ZE0 \ 2016-8~	Shift		x	x	0204
Leaf \ ZE0 \ 2016-8~	EV/HEV	x	x	x	0053
Leaf \ ZE0 \ 2016-8~	4WAS(front)	x	x	x	
Leaf \ ZE0 \ 2016-8~	Accele pedal ACT		x	x	
Leaf \ ZE0 \ 2016-8~	HV battery		x	x	0251

Leaf \ ZE0 \ 2016-8~	Brake		x	x	
Leaf \ ZE0 \ 2016-8~	Side radar left		x	x	
Leaf \ ZE0 \ 2016-8~	VSP	x	x	x	
Leaf \ ZE0 \ 2016-8~	Side radar right		x	x	
Leaf \ ZE0 \ 2016-8~	Charger/PD module		x	x	0065
Leaf \ ZE0 \ 2016-8~	FSCM		x	x	
Leaf \ ZE0 \ 2016-8~	Head lamp levelizer	x	x	x	
Leaf \ ZE0 \ 2016-8~	Occupant detection			x	
Leopard \ JY33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Leopard \ JY33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Leopard \ JY33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Leopard \ JY33 \ All Year	BCM	x	x		
Leopard \ JY33 \ All Year	Air bag	x	x	x	
Leopard \ JY33 \ All Year	ICC/ADAS	x	x	x	
Leopard \ JY33 \ All Year	HVAC	x	x	x	
Leopard \ JY33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Leopard \ JY33 \ All Year	Multi AV	x	x	x	0280
Leopard \ JY33 \ All Year	EPS/DAST 3	x	x	x	
Leopard \ JY33 \ All Year	IPDM E/R	x	x	x	
Leopard \ JY33 \ All Year	Air pressure monitor	x	x	x	
Leopard \ JY33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Leopard \ JY33 \ All Year	DIU	x	x	x	
Leopard \ JY33 \ All Year	Auto slide door	x	x	x	
Leopard \ JY33 \ All Year	Auto drive position	x	x	x	
Leopard \ JY33 \ All Year	All mode AWD/4WD	x	x	x	
Leopard \ JY33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Leopard \ JY33 \ All Year	Sonar	x	x	x	
Leopard \ JY33 \ All Year	Lane camera	x	x	x	
Leopard \ JY33 \ All Year	Adaptive light	x	x	x	
Leopard \ JY33 \ All Year	AVM		x	x	
Leopard \ JY33 \ All Year	Head lamp levelizer	x	x	x	
Leopard \ JY33 \ All Year	Difference lock	x	x	x	
Leopard \ JY33 \ All Year	Nats immu	x	x		
Leopard \ JY33 \ All Year	Smart entrance	x	x		
Leopard \ JY33 \ All Year	Air levelizer	x	x	x	
Leopard \ JY33 \ All Year	Rearview camera			x	
Leopard \ JY33 \ All Year	S/blind camera			x	
Leopard \ JY33 \ All Year	Motor assist	x	x	x	

Liberty \ M12 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Liberty \ M12 \ All Year	ABS	x	x	x	0003, 0092, 0264
Liberty \ M12 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Liberty \ M12 \ All Year	BCM	x	x		
Liberty \ M12 \ All Year	Air bag	x	x	x	
Liberty \ M12 \ All Year	ICC/ADAS	x	x	x	
Liberty \ M12 \ All Year	HVAC	x	x	x	
Liberty \ M12 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Liberty \ M12 \ All Year	Multi AV	x	x	x	0280
Liberty \ M12 \ All Year	EPS/DAST 3	x	x	x	
Liberty \ M12 \ All Year	IPDM E/R	x	x	x	
Liberty \ M12 \ All Year	Air pressure monitor	x	x	x	
Liberty \ M12 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Liberty \ M12 \ All Year	DIU	x	x	x	
Liberty \ M12 \ All Year	Auto slide door	x	x	x	
Liberty \ M12 \ All Year	Auto drive position	x	x	x	
Liberty \ M12 \ All Year	All mode AWD/4WD	x	x	x	
Liberty \ M12 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Liberty \ M12 \ All Year	Sonar	x	x	x	
Liberty \ M12 \ All Year	Lane camera	x	x	x	
Liberty \ M12 \ All Year	Adaptive light	x	x	x	
Liberty \ M12 \ All Year	AVM		x	x	
Liberty \ M12 \ All Year	Head lamp levelizer	x	x	x	
Liberty \ M12 \ All Year	Difference lock	x	x	x	
Liberty \ M12 \ All Year	Nats immu	x	x		
Liberty \ M12 \ All Year	Smart entrance	x	x		
Liberty \ M12 \ All Year	Air levelizer	x	x	x	
Liberty \ M12 \ All Year	Rearview camera			x	
Liberty \ M12 \ All Year	S/blind camera			x	
Liberty \ M12 \ All Year	Motor assist	x	x	x	
Livina geniss \ L10 \ 2006-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2006-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2006-10~	BCM	x	x		
Livina geniss \ L10 \ 2006-10~	Air bag	x	x	x	
Livina geniss \ L10 \ 2006-10~	Transmission		x	x	
Livina geniss \ L10 \ 2006-10~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2006-10~	IPDM E/R	x	x	x	

Livina geniss \ L10 \ 2006-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2006-10~	ABS	x	x	x	
Livina geniss \ L10 \ 2006-10~	Rearview camera			x	
Livina geniss \ L10 \ 2006-10~	S/blind camera			x	
Livina geniss \ L10 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2007-10~	BCM	x	x		
Livina geniss \ L10 \ 2007-10~	Air bag	x	x	x	
Livina geniss \ L10 \ 2007-10~	Transmission		x	x	
Livina geniss \ L10 \ 2007-10~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2007-10~	IPDM E/R	x	x	x	
Livina geniss \ L10 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2007-10~	ABS	x	x	x	
Livina geniss \ L10 \ 2007-10~	Rearview camera			x	
Livina geniss \ L10 \ 2007-10~	S/blind camera			x	
Livina geniss \ L10 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2007-5~	BCM	x	x		
Livina geniss \ L10 \ 2007-5~	Air bag	x	x	x	
Livina geniss \ L10 \ 2007-5~	Transmission		x	x	
Livina geniss \ L10 \ 2007-5~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2007-5~	IPDM E/R	x	x	x	
Livina geniss \ L10 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2007-5~	ABS	x	x	x	
Livina geniss \ L10 \ 2007-5~	Rearview camera			x	
Livina geniss \ L10 \ 2007-5~	S/blind camera			x	
Livina geniss \ L10 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2007-6~	BCM	x	x		
Livina geniss \ L10 \ 2007-6~	Air bag	x	x	x	
Livina geniss \ L10 \ 2007-6~	Transmission		x	x	
Livina geniss \ L10 \ 2007-6~	EPS/DAST 3	x	x	x	

Livina geniss \ L10 \ 2007-6~	IPDM E/R	x	x	x	
Livina geniss \ L10 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2007-6~	ABS	x	x	x	
Livina geniss \ L10 \ 2007-6~	Rearview camera			x	
Livina geniss \ L10 \ 2007-6~	S/blind camera			x	
Livina geniss \ L10 \ 2007-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2007-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2007-9~	BCM	x	x		
Livina geniss \ L10 \ 2007-9~	Air bag	x	x	x	
Livina geniss \ L10 \ 2007-9~	Transmission		x	x	
Livina geniss \ L10 \ 2007-9~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2007-9~	IPDM E/R	x	x	x	
Livina geniss \ L10 \ 2007-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2007-9~	ABS	x	x	x	
Livina geniss \ L10 \ 2007-9~	Rearview camera			x	
Livina geniss \ L10 \ 2007-9~	S/blind camera			x	
Livina geniss \ L10 \ 2008-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2008-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2008-3~	BCM	x	x		
Livina geniss \ L10 \ 2008-3~	Transmission		x	x	
Livina geniss \ L10 \ 2008-3~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2008-3~	IPDM E/R	x	x	x	
Livina geniss \ L10 \ 2008-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2008-3~	ABS	x	x	x	
Livina geniss \ L10 \ 2008-3~	Air bag	x	x	x	
Livina geniss \ L10 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2008-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2008-5~	BCM	x	x		
Livina geniss \ L10 \ 2008-5~	Air bag	x	x	x	
Livina geniss \ L10 \ 2008-5~	Transmission		x	x	
Livina geniss \ L10 \ 2008-5~	EPS/DAST 3	x	x	x	
Livina geniss \ L10 \ 2008-5~	IPDM E/R	x	x	x	

Livina geniss \ L10 \ 2008-5~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2008-5~	ABS	×	×	×	
Livina geniss \ L10 \ 2008-5~	Rearview camera			×	
Livina geniss \ L10 \ 2008-5~	S/blind camera			×	
Livina geniss \ L10 \ 2008-8~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2008-8~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2008-8~	BCM	×	×		
Livina geniss \ L10 \ 2008-8~	Transmission		×	×	
Livina geniss \ L10 \ 2008-8~	EPS/DAST 3	×	×	×	
Livina geniss \ L10 \ 2008-8~	IPDM E/R	×	×	×	
Livina geniss \ L10 \ 2008-8~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2008-8~	ABS	×	×	×	
Livina geniss \ L10 \ 2008-8~	Air bag	×	×	×	
Livina geniss \ L10 \ 2010-3~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina geniss \ L10 \ 2010-3~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Livina geniss \ L10 \ 2010-3~	BCM	×	×		
Livina geniss \ L10 \ 2010-3~	Transmission		×	×	
Livina geniss \ L10 \ 2010-3~	EPS/DAST 3	×	×	×	
Livina geniss \ L10 \ 2010-3~	IPDM E/R	×	×	×	
Livina geniss \ L10 \ 2010-3~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina geniss \ L10 \ 2010-3~	ABS	×	×	×	
Livina geniss \ L10 \ 2010-3~	Air bag	×	×	×	
LIVINA X-GEAR \ L11 \ 2014-2~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LIVINA X-GEAR \ L11 \ 2014-2~	Meter/M&A		×	×	
LIVINA X-GEAR \ L11 \ 2014-2~	BCM	×	×		
LIVINA X-GEAR \ L11 \ 2014-2~	Transmission		×	×	
LIVINA X-GEAR \ L11 \ 2014-2~	Multi AV	×	×	×	0280
LIVINA X-GEAR \ L11 \ 2014-2~	EPS/DAST 3	×	×	×	
LIVINA X-GEAR \ L11 \ 2014-2~	IPDM E/R	×	×	×	
LIVINA X-GEAR \ L11 \ 2014-2~	Air pressure monitor		×	×	

LIVINA X-GEAR \ L11 \ 2014-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
LIVINA X-GEAR \ L11 \ 2014-2~	ANC		x	x	
LIVINA X-GEAR \ L11 \ 2014-2~	HIGH BEAM ASSIST	x	x	x	
LIVINA X-GEAR \ L11 \ 2014-2~	ABS	x	x	x	
LIVINA X-GEAR \ L11 \ 2014-2~	Air bag	x	x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LIVINA X-GEAR \ L11 \ 2016-5~	Meter/M&A		x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	BCM	x	x		
LIVINA X-GEAR \ L11 \ 2016-5~	Transmission		x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	Multi AV	x	x	x	0280
LIVINA X-GEAR \ L11 \ 2016-5~	EPS/DAST 3	x	x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	IPDM E/R	x	x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	Air pressure monitor		x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
LIVINA X-GEAR \ L11 \ 2016-5~	ANC		x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	HIGH BEAM ASSIST	x	x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	ABS	x	x	x	
LIVINA X-GEAR \ L11 \ 2016-5~	Air bag	x	x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Meter/M&A		x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	BCM	x	x		
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Transmission		x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Multi AV	x	x	x	0280
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	EPS/DAST 3	x	x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	IPDM E/R	x	x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Air pressure monitor		x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	ANC		x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	HIGH BEAM ASSIST	x	x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	ABS	x	x	x	
LIVINA X-GEAR-GRAND LIVINA \ L11 \ 2013-5~	Air bag	x	x	x	
Livina \ L10 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Livina \ L10 \ 2012-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina \ L10 \ 2012-7~	BCM	x	x		
Livina \ L10 \ 2012-7~	EPS/DAST 3	x	x	x	
Livina \ L10 \ 2012-7~	IPDM E/R	x	x	x	
Livina \ L10 \ 2012-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina \ L10 \ 2012-7~	ABS	x	x	x	
Livina \ L10 \ 2012-7~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2007-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2007-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2007-2~	BCM	x	x		
Livina-grand livina \ L10 \ 2007-2~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2007-2~	Transmission		x	x	
Livina-grand livina \ L10 \ 2007-2~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2007-2~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2007-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2007-2~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2007-2~	Rearview camera			x	
Livina-grand livina \ L10 \ 2007-2~	S/blind camera			x	
Livina-grand livina \ L10 \ 2008-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2008-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2008-4~	BCM	x	x		
Livina-grand livina \ L10 \ 2008-4~	Transmission		x	x	
Livina-grand livina \ L10 \ 2008-4~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2008-4~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2008-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2008-4~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2008-4~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2009-11~	BCM	x	x		
Livina-grand livina \ L10 \ 2009-11~	Transmission		x	x	
Livina-grand livina \ L10 \ 2009-11~	EPS/DAST 3	x	x	x	

Livina-grand livina \ L10 \ 2009-11~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2009-11~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2009-11~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2009-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2009-1~	BCM	x	x		
Livina-grand livina \ L10 \ 2009-1~	Transmission		x	x	
Livina-grand livina \ L10 \ 2009-1~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2009-1~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	SVT	x	x	x	
Livina-grand livina \ L10 \ 2009-1~	Rearview camera			x	
Livina-grand livina \ L10 \ 2009-1~	S/blind camera			x	
Livina-grand livina \ L10 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2010-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2010-3~	BCM	x	x		
Livina-grand livina \ L10 \ 2010-3~	Transmission		x	x	
Livina-grand livina \ L10 \ 2010-3~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2010-3~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2010-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2010-3~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2010-3~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2011-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2011-6~	BCM	x	x		
Livina-grand livina \ L10 \ 2011-6~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2011-6~	IPDM E/R	x	x	x	

Livina-grand livina \ L10 \ 2011-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2011-6~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2011-6~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2011-6~	SVT	x	x	x	
Livina-grand livina \ L10 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-grand livina \ L10 \ 2012-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Livina-grand livina \ L10 \ 2012-1~	BCM	x	x		
Livina-grand livina \ L10 \ 2012-1~	Air bag	x	x	x	
Livina-grand livina \ L10 \ 2012-1~	Multi AV		x	x	
Livina-grand livina \ L10 \ 2012-1~	EPS/DAST 3	x	x	x	
Livina-grand livina \ L10 \ 2012-1~	IPDM E/R	x	x	x	
Livina-grand livina \ L10 \ 2012-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-grand livina \ L10 \ 2012-1~	ABS	x	x	x	
Livina-grand livina \ L10 \ 2012-1~	SVT	x	x	x	
Livina-livina c-gear \ L11 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-livina c-gear \ L11 \ 2012-11~	Meter/M&A		x	x	
Livina-livina c-gear \ L11 \ 2012-11~	BCM	x	x		
Livina-livina c-gear \ L11 \ 2012-11~	Transmission		x	x	
Livina-livina c-gear \ L11 \ 2012-11~	EPS/DAST 3	x	x	x	
Livina-livina c-gear \ L11 \ 2012-11~	IPDM E/R	x	x	x	
Livina-livina c-gear \ L11 \ 2012-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-livina c-gear \ L11 \ 2012-11~	ABS	x	x	x	
Livina-livina c-gear \ L11 \ 2012-11~	Air bag	x	x	x	
Livina-livina c-gear \ L11 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Livina-livina c-gear \ L11 \ 2014-8~	Meter/M&A		x	x	
Livina-livina c-gear \ L11 \ 2014-8~	BCM	x	x		
Livina-livina c-gear \ L11 \ 2014-8~	Transmission		x	x	
Livina-livina c-gear \ L11 \ 2014-8~	Multi AV	x	x	x	0280
Livina-livina c-gear \ L11 \ 2014-8~	EPS/DAST 3	x	x	x	
Livina-livina c-gear \ L11 \ 2014-8~	IPDM E/R	x	x	x	
Livina-livina c-gear \ L11 \ 2014-8~	Air pressure monitor		x	x	

Livina-livina c-gear \ L11 \ 2014-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Livina-livina c-gear \ L11 \ 2014-8~	ANC		x	x	
Livina-livina c-gear \ L11 \ 2014-8~	HIGH BEAM ASSIST	x	x	x	
Livina-livina c-gear \ L11 \ 2014-8~	ABS	x	x	x	
Livina-livina c-gear \ L11 \ 2014-8~	Air bag	x	x	x	
MARCH ACTIVE \ K13 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MARCH ACTIVE \ K13 \ 2014-4~	ABS	x	x	x	0003, 0092, 0264
MARCH ACTIVE \ K13 \ 2014-4~	Meter/M&A		x	x	
MARCH ACTIVE \ K13 \ 2014-4~	BCM		x		
MARCH ACTIVE \ K13 \ 2014-4~	Air bag	x	x	x	
MARCH ACTIVE \ K13 \ 2014-4~	Transmission		x	x	
MARCH ACTIVE \ K13 \ 2014-4~	EPS/DAST 3		x	x	
MARCH ACTIVE \ K13 \ 2014-4~	IPDM E/R		x	x	
MARCH ACTIVE \ K13 \ 2014-4~	BSW/buzzer		x	x	
MARCH ACTIVE \ K13 \ 2014-4~	Occupant detection			x	
MARCH ACTIVE \ K13 \ 2015-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MARCH ACTIVE \ K13 \ 2015-12~	ABS	x	x	x	0003, 0092, 0264
MARCH ACTIVE \ K13 \ 2015-12~	Meter/M&A		x	x	
MARCH ACTIVE \ K13 \ 2015-12~	BCM		x		
MARCH ACTIVE \ K13 \ 2015-12~	Air bag	x	x	x	
MARCH ACTIVE \ K13 \ 2015-12~	EPS/DAST 3	x	x	x	
MARCH ACTIVE \ K13 \ 2015-12~	IPDM E/R		x	x	
MARCH ACTIVE \ K13 \ 2015-12~	Occupant detection			x	
MARCH ACTIVE \ K13 \ 2015-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MARCH ACTIVE \ K13 \ 2015-1~	ABS	x	x	x	0003, 0092, 0264
MARCH ACTIVE \ K13 \ 2015-1~	Meter/M&A		x	x	
MARCH ACTIVE \ K13 \ 2015-1~	BCM		x		
MARCH ACTIVE \ K13 \ 2015-1~	Air bag	x	x	x	
MARCH ACTIVE \ K13 \ 2015-1~	EPS/DAST 3	x	x	x	
MARCH ACTIVE \ K13 \ 2015-1~	IPDM E/R		x	x	
MARCH ACTIVE \ K13 \ 2015-1~	Occupant detection			x	
MARCH ACTIVE \ K13 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MARCH ACTIVE \ K13 \ 2016-4~	ABS	x	x	x	0003, 0092, 0264
MARCH ACTIVE \ K13 \ 2016-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
MARCH ACTIVE \ K13 \ 2016-4~	BCM		x		

MARCH ACTIVE \ K13 \ 2016-4~	Air bag	x	x	x	
MARCH ACTIVE \ K13 \ 2016-4~	Transmission		x	x	
MARCH ACTIVE \ K13 \ 2016-4~	Multi AV	x	x	x	0280
MARCH ACTIVE \ K13 \ 2016-4~	EPS/DAST 3	x	x	x	
MARCH ACTIVE \ K13 \ 2016-4~	IPDM E/R		x	x	
MARCH ACTIVE \ K13 \ 2016-4~	Side radar left		x	x	
MARCH ACTIVE \ K13 \ 2016-4~	Side radar right		x	x	
MARCH ACTIVE \ K13 \ 2016-4~	PTC heater		x	x	
MARCH ACTIVE \ K13 \ 2016-4~	Occupant detection			x	
March \ K11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K11 \ All Year	ABS	x	x	x	0003, 0092, 0264
March \ K11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K11 \ All Year	BCM	x	x		
March \ K11 \ All Year	Air bag	x	x	x	
March \ K11 \ All Year	ICC/ADAS	x	x	x	
March \ K11 \ All Year	HVAC	x	x	x	
March \ K11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K11 \ All Year	Multi AV	x	x	x	0280
March \ K11 \ All Year	EPS/DAST 3	x	x	x	
March \ K11 \ All Year	IPDM E/R	x	x	x	
March \ K11 \ All Year	Air pressure monitor	x	x	x	
March \ K11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K11 \ All Year	DIU	x	x	x	
March \ K11 \ All Year	Auto slide door	x	x	x	
March \ K11 \ All Year	Auto drive position	x	x	x	
March \ K11 \ All Year	All mode AWD/4WD	x	x	x	
March \ K11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K11 \ All Year	Sonar	x	x	x	
March \ K11 \ All Year	Lane camera	x	x	x	
March \ K11 \ All Year	Adaptive light	x	x	x	
March \ K11 \ All Year	AVM		x	x	
March \ K11 \ All Year	Head lamp levelizer	x	x	x	
March \ K11 \ All Year	Difference lock	x	x	x	
March \ K11 \ All Year	Nats immu	x	x		
March \ K11 \ All Year	Smart entrance	x	x		
March \ K11 \ All Year	Air levelizer	x	x	x	
March \ K11 \ All Year	Rearview camera			x	
March \ K11 \ All Year	S/blind camera			x	

March \ K11 \ All Year	Motor assist	x	x	x	
March \ K12 \ 2002-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2002-2~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2002-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2002-2~	BCM	x	x		
March \ K12 \ 2002-2~	Air bag	x	x	x	
March \ K12 \ 2002-2~	ICC/ADAS	x	x	x	
March \ K12 \ 2002-2~	HVAC	x	x	x	
March \ K12 \ 2002-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2002-2~	Multi AV	x	x	x	0280
March \ K12 \ 2002-2~	EPS/DAST 3	x	x	x	
March \ K12 \ 2002-2~	IPDM E/R	x	x	x	
March \ K12 \ 2002-2~	Air pressure monitor	x	x	x	
March \ K12 \ 2002-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2002-2~	DIU	x	x	x	
March \ K12 \ 2002-2~	Auto slide door	x	x	x	
March \ K12 \ 2002-2~	Auto drive position	x	x	x	
March \ K12 \ 2002-2~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2002-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2002-2~	Sonar	x	x	x	
March \ K12 \ 2002-2~	Lane camera	x	x	x	
March \ K12 \ 2002-2~	Adaptive light	x	x	x	
March \ K12 \ 2002-2~	AVM		x	x	
March \ K12 \ 2002-2~	Head lamp levelizer	x	x	x	
March \ K12 \ 2002-2~	Difference lock	x	x	x	
March \ K12 \ 2002-2~	Nats immu	x	x		
March \ K12 \ 2002-2~	Smart entrance	x	x		
March \ K12 \ 2002-2~	Air levelizer	x	x	x	
March \ K12 \ 2002-2~	Rearview camera			x	
March \ K12 \ 2002-2~	S/blind camera			x	
March \ K12 \ 2002-2~	Motor assist	x	x	x	
March \ K12 \ 2002-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2002-7~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2002-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2002-7~	BCM	x	x		
March \ K12 \ 2002-7~	Air bag	x	x	x	
March \ K12 \ 2002-7~	ICC/ADAS	x	x	x	

March \ K12 \ 2002-7~	HVAC	x	x	x	
March \ K12 \ 2002-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2002-7~	Multi AV	x	x	x	0280
March \ K12 \ 2002-7~	EPS/DAST 3	x	x	x	
March \ K12 \ 2002-7~	IPDM E/R	x	x	x	
March \ K12 \ 2002-7~	Air pressure monitor	x	x	x	
March \ K12 \ 2002-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2002-7~	DIU	x	x	x	
March \ K12 \ 2002-7~	Auto slide door	x	x	x	
March \ K12 \ 2002-7~	Auto drive position	x	x	x	
March \ K12 \ 2002-7~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2002-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2002-7~	Sonar	x	x	x	
March \ K12 \ 2002-7~	Lane camera	x	x	x	
March \ K12 \ 2002-7~	Adaptive light	x	x	x	
March \ K12 \ 2002-7~	AVM		x	x	
March \ K12 \ 2002-7~	Head lamp levelizer	x	x	x	
March \ K12 \ 2002-7~	Difference lock	x	x	x	
March \ K12 \ 2002-7~	Nats immu	x	x		
March \ K12 \ 2002-7~	Smart entrance	x	x		
March \ K12 \ 2002-7~	Air levelizer	x	x	x	
March \ K12 \ 2002-7~	Rearview camera			x	
March \ K12 \ 2002-7~	S/blind camera			x	
March \ K12 \ 2002-7~	Motor assist	x	x	x	
March \ K12 \ 2003-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2003-6~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2003-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2003-6~	BCM	x	x		
March \ K12 \ 2003-6~	Air bag	x	x	x	
March \ K12 \ 2003-6~	ICC/ADAS	x	x	x	
March \ K12 \ 2003-6~	HVAC	x	x	x	
March \ K12 \ 2003-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2003-6~	Multi AV	x	x	x	0280
March \ K12 \ 2003-6~	EPS/DAST 3	x	x	x	
March \ K12 \ 2003-6~	IPDM E/R	x	x	x	
March \ K12 \ 2003-6~	Air pressure monitor	x	x	x	

March \ K12 \ 2003-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2003-6~	DIU	x	x	x	
March \ K12 \ 2003-6~	Auto slide door	x	x	x	
March \ K12 \ 2003-6~	Auto drive position	x	x	x	
March \ K12 \ 2003-6~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2003-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2003-6~	Sonar	x	x	x	
March \ K12 \ 2003-6~	Lane camera	x	x	x	
March \ K12 \ 2003-6~	Adaptive light	x	x	x	
March \ K12 \ 2003-6~	AVM		x	x	
March \ K12 \ 2003-6~	Head lamp levelizer	x	x	x	
March \ K12 \ 2003-6~	Difference lock	x	x	x	
March \ K12 \ 2003-6~	Nats immu	x	x		
March \ K12 \ 2003-6~	Smart entrance	x	x		
March \ K12 \ 2003-6~	Air levelizer	x	x	x	
March \ K12 \ 2003-6~	Rearview camera			x	
March \ K12 \ 2003-6~	S/blind camera			x	
March \ K12 \ 2003-6~	Motor assist	x	x	x	
March \ K12 \ 2003-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2003-7~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2003-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2003-7~	BCM	x	x		
March \ K12 \ 2003-7~	Air bag	x	x	x	
March \ K12 \ 2003-7~	ICC/ADAS	x	x	x	
March \ K12 \ 2003-7~	HVAC	x	x	x	
March \ K12 \ 2003-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2003-7~	Multi AV	x	x	x	0280
March \ K12 \ 2003-7~	EPS/DAST 3	x	x	x	
March \ K12 \ 2003-7~	IPDM E/R	x	x	x	
March \ K12 \ 2003-7~	Air pressure monitor	x	x	x	
March \ K12 \ 2003-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2003-7~	DIU	x	x	x	
March \ K12 \ 2003-7~	Auto slide door	x	x	x	
March \ K12 \ 2003-7~	Auto drive position	x	x	x	
March \ K12 \ 2003-7~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2003-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	

March \ K12 \ 2003-7~	Sonar	x	x	x	
March \ K12 \ 2003-7~	Lane camera	x	x	x	
March \ K12 \ 2003-7~	Adaptive light	x	x	x	
March \ K12 \ 2003-7~	AVM		x	x	
March \ K12 \ 2003-7~	Head lamp levelizer	x	x	x	
March \ K12 \ 2003-7~	Difference lock	x	x	x	
March \ K12 \ 2003-7~	Nats immu	x	x		
March \ K12 \ 2003-7~	Smart entrance	x	x		
March \ K12 \ 2003-7~	Air levelizer	x	x	x	
March \ K12 \ 2003-7~	Rearview camera			x	
March \ K12 \ 2003-7~	S/blind camera			x	
March \ K12 \ 2003-7~	Motor assist	x	x	x	
March \ K12 \ 2004-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2004-4~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2004-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2004-4~	BCM	x	x		
March \ K12 \ 2004-4~	Air bag	x	x	x	
March \ K12 \ 2004-4~	ICC/ADAS	x	x	x	
March \ K12 \ 2004-4~	HVAC	x	x	x	
March \ K12 \ 2004-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2004-4~	Multi AV	x	x	x	0280
March \ K12 \ 2004-4~	EPS/DAST 3	x	x	x	
March \ K12 \ 2004-4~	IPDM E/R	x	x	x	
March \ K12 \ 2004-4~	Air pressure monitor	x	x	x	
March \ K12 \ 2004-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2004-4~	DIU	x	x	x	
March \ K12 \ 2004-4~	Auto slide door	x	x	x	
March \ K12 \ 2004-4~	Auto drive position	x	x	x	
March \ K12 \ 2004-4~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2004-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2004-4~	Sonar	x	x	x	
March \ K12 \ 2004-4~	Lane camera	x	x	x	
March \ K12 \ 2004-4~	Adaptive light	x	x	x	
March \ K12 \ 2004-4~	AVM		x	x	
March \ K12 \ 2004-4~	Head lamp levelizer	x	x	x	
March \ K12 \ 2004-4~	Difference lock	x	x	x	
March \ K12 \ 2004-4~	Nats immu	x	x		
March \ K12 \ 2004-4~	Smart entrance	x	x		

March \ K12 \ 2004-4~	Air levelizer	x	x	x	
March \ K12 \ 2004-4~	Rearview camera			x	
March \ K12 \ 2004-4~	S/blind camera			x	
March \ K12 \ 2004-4~	Motor assist	x	x	x	
March \ K12 \ 2005-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2005-10~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2005-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2005-10~	BCM	x	x		
March \ K12 \ 2005-10~	Air bag	x	x	x	
March \ K12 \ 2005-10~	ICC/ADAS	x	x	x	
March \ K12 \ 2005-10~	HVAC	x	x	x	
March \ K12 \ 2005-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2005-10~	Multi AV	x	x	x	0280
March \ K12 \ 2005-10~	EPS/DAST 3	x	x	x	
March \ K12 \ 2005-10~	IPDM E/R	x	x	x	
March \ K12 \ 2005-10~	Air pressure monitor	x	x	x	
March \ K12 \ 2005-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2005-10~	DIU	x	x	x	
March \ K12 \ 2005-10~	Auto slide door	x	x	x	
March \ K12 \ 2005-10~	Auto drive position	x	x	x	
March \ K12 \ 2005-10~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2005-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2005-10~	Sonar	x	x	x	
March \ K12 \ 2005-10~	Lane camera	x	x	x	
March \ K12 \ 2005-10~	Adaptive light	x	x	x	
March \ K12 \ 2005-10~	AVM		x	x	
March \ K12 \ 2005-10~	Head lamp levelizer	x	x	x	
March \ K12 \ 2005-10~	Difference lock	x	x	x	
March \ K12 \ 2005-10~	Nats immu	x	x		
March \ K12 \ 2005-10~	Smart entrance	x	x		
March \ K12 \ 2005-10~	Air levelizer	x	x	x	
March \ K12 \ 2005-10~	Rearview camera			x	
March \ K12 \ 2005-10~	S/blind camera			x	
March \ K12 \ 2005-10~	Motor assist	x	x	x	
March \ K12 \ 2005-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2005-8~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2005-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

March \ K12 \ 2005-8~	BCM	x	x		
March \ K12 \ 2005-8~	Air bag	x	x	x	
March \ K12 \ 2005-8~	ICC/ADAS	x	x	x	
March \ K12 \ 2005-8~	HVAC	x	x	x	
March \ K12 \ 2005-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2005-8~	Multi AV	x	x	x	0280
March \ K12 \ 2005-8~	EPS/DAST 3	x	x	x	
March \ K12 \ 2005-8~	IPDM E/R	x	x	x	
March \ K12 \ 2005-8~	Air pressure monitor	x	x	x	
March \ K12 \ 2005-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2005-8~	DIU	x	x	x	
March \ K12 \ 2005-8~	Auto slide door	x	x	x	
March \ K12 \ 2005-8~	Auto drive position	x	x	x	
March \ K12 \ 2005-8~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2005-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2005-8~	Sonar	x	x	x	
March \ K12 \ 2005-8~	Lane camera	x	x	x	
March \ K12 \ 2005-8~	Adaptive light	x	x	x	
March \ K12 \ 2005-8~	AVM		x	x	
March \ K12 \ 2005-8~	Head lamp levelizer	x	x	x	
March \ K12 \ 2005-8~	Difference lock	x	x	x	
March \ K12 \ 2005-8~	Nats immu	x	x		
March \ K12 \ 2005-8~	Smart entrance	x	x		
March \ K12 \ 2005-8~	Air levelizer	x	x	x	
March \ K12 \ 2005-8~	Rearview camera			x	
March \ K12 \ 2005-8~	S/blind camera			x	
March \ K12 \ 2005-8~	Motor assist	x	x	x	
March \ K12 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2007-5~	BCM	x	x		
March \ K12 \ 2007-5~	Air bag	x	x	x	
March \ K12 \ 2007-5~	ICC/ADAS	x	x	x	
March \ K12 \ 2007-5~	HVAC	x	x	x	
March \ K12 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2007-5~	Multi AV	x	x	x	0280
March \ K12 \ 2007-5~	EPS/DAST 3	x	x	x	
March \ K12 \ 2007-5~	IPDM E/R	x	x	x	

March \ K12 \ 2007-5~	Air pressure monitor	x	x	x	
March \ K12 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2007-5~	DIU	x	x	x	
March \ K12 \ 2007-5~	Auto slide door	x	x	x	
March \ K12 \ 2007-5~	Auto drive position	x	x	x	
March \ K12 \ 2007-5~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2007-5~	Sonar	x	x	x	
March \ K12 \ 2007-5~	Lane camera	x	x	x	
March \ K12 \ 2007-5~	Adaptive light	x	x	x	
March \ K12 \ 2007-5~	AVM		x	x	
March \ K12 \ 2007-5~	Head lamp levelizer	x	x	x	
March \ K12 \ 2007-5~	Difference lock	x	x	x	
March \ K12 \ 2007-5~	Nats immu	x	x		
March \ K12 \ 2007-5~	Smart entrance	x	x		
March \ K12 \ 2007-5~	Air levelizer	x	x	x	
March \ K12 \ 2007-5~	Rearview camera			x	
March \ K12 \ 2007-5~	S/blind camera			x	
March \ K12 \ 2007-5~	Motor assist	x	x	x	
March \ K12 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2007-6~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2007-6~	BCM	x	x		
March \ K12 \ 2007-6~	Air bag	x	x	x	
March \ K12 \ 2007-6~	ICC/ADAS	x	x	x	
March \ K12 \ 2007-6~	HVAC	x	x	x	
March \ K12 \ 2007-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2007-6~	Multi AV	x	x	x	0280
March \ K12 \ 2007-6~	EPS/DAST 3	x	x	x	
March \ K12 \ 2007-6~	IPDM E/R	x	x	x	
March \ K12 \ 2007-6~	Air pressure monitor	x	x	x	
March \ K12 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2007-6~	DIU	x	x	x	
March \ K12 \ 2007-6~	Auto slide door	x	x	x	
March \ K12 \ 2007-6~	Auto drive position	x	x	x	
March \ K12 \ 2007-6~	All mode AWD/4WD	x	x	x	

March \ K12 \ 2007-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2007-6~	Sonar	x	x	x	
March \ K12 \ 2007-6~	Lane camera	x	x	x	
March \ K12 \ 2007-6~	Adaptive light	x	x	x	
March \ K12 \ 2007-6~	AVM		x	x	
March \ K12 \ 2007-6~	Head lamp levelizer	x	x	x	
March \ K12 \ 2007-6~	Difference lock	x	x	x	
March \ K12 \ 2007-6~	Nats immu	x	x		
March \ K12 \ 2007-6~	Smart entrance	x	x		
March \ K12 \ 2007-6~	Air levelizer	x	x	x	
March \ K12 \ 2007-6~	Rearview camera			x	
March \ K12 \ 2007-6~	S/blind camera			x	
March \ K12 \ 2007-6~	Motor assist	x	x	x	
March \ K12 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K12 \ 2008-5~	ABS	x	x	x	0003, 0092, 0264
March \ K12 \ 2008-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K12 \ 2008-5~	BCM	x	x		
March \ K12 \ 2008-5~	Air bag	x	x	x	
March \ K12 \ 2008-5~	ICC/ADAS	x	x	x	
March \ K12 \ 2008-5~	HVAC	x	x	x	
March \ K12 \ 2008-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K12 \ 2008-5~	Multi AV	x	x	x	0280
March \ K12 \ 2008-5~	EPS/DAST 3	x	x	x	
March \ K12 \ 2008-5~	IPDM E/R	x	x	x	
March \ K12 \ 2008-5~	Air pressure monitor	x	x	x	
March \ K12 \ 2008-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March \ K12 \ 2008-5~	DIU	x	x	x	
March \ K12 \ 2008-5~	Auto slide door	x	x	x	
March \ K12 \ 2008-5~	Auto drive position	x	x	x	
March \ K12 \ 2008-5~	All mode AWD/4WD	x	x	x	
March \ K12 \ 2008-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March \ K12 \ 2008-5~	Sonar	x	x	x	
March \ K12 \ 2008-5~	Lane camera	x	x	x	
March \ K12 \ 2008-5~	Adaptive light	x	x	x	
March \ K12 \ 2008-5~	AVM		x	x	
March \ K12 \ 2008-5~	Head lamp levelizer	x	x	x	
March \ K12 \ 2008-5~	Difference lock	x	x	x	
March \ K12 \ 2008-5~	Nats immu	x	x		

March \ K12 \ 2008-5~	Smart entrance	x	x		
March \ K12 \ 2008-5~	Air levelizer	x	x	x	
March \ K12 \ 2008-5~	Rearview camera			x	
March \ K12 \ 2008-5~	S/blind camera			x	
March \ K12 \ 2008-5~	Motor assist	x	x	x	
March \ K13 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-10~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March \ K13 \ 2010-10~	BCM		x		
March \ K13 \ 2010-10~	Air bag	x	x	x	
March \ K13 \ 2010-10~	Transmission		x	x	
March \ K13 \ 2010-10~	Multi AV	x	x	x	0280
March \ K13 \ 2010-10~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-10~	IPDM E/R		x	x	
March \ K13 \ 2010-10~	E-4wd	x	x	x	
March \ K13 \ 2010-10~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-10~	Sonar	x	x	x	
March \ K13 \ 2010-10~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-10~	Occupant detection			x	
March \ K13 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-2~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-2~	Meter/M&A		x	x	
March \ K13 \ 2010-2~	BCM		x		
March \ K13 \ 2010-2~	Air bag	x	x	x	
March \ K13 \ 2010-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K13 \ 2010-2~	Multi AV		x	x	
March \ K13 \ 2010-2~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-2~	IPDM E/R		x	x	
March \ K13 \ 2010-2~	E-4wd	x	x	x	
March \ K13 \ 2010-2~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-2~	Sonar	x	x	x	
March \ K13 \ 2010-2~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-2~	Occupant detection			x	
March \ K13 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-3~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-3~	Meter/M&A		x	x	
March \ K13 \ 2010-3~	BCM		x		
March \ K13 \ 2010-3~	Air bag	x	x	x	

March \ K13 \ 2010-3~	Transmission	x	x	x	
March \ K13 \ 2010-3~	Multi AV		x	x	
March \ K13 \ 2010-3~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-3~	IPDM E/R		x	x	
March \ K13 \ 2010-3~	E-4wd	x	x	x	
March \ K13 \ 2010-3~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-3~	Sonar	x	x	x	
March \ K13 \ 2010-3~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-3~	Occupant detection			x	
March \ K13 \ 2010-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-5~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-5~	Meter/M&A		x	x	
March \ K13 \ 2010-5~	BCM		x		
March \ K13 \ 2010-5~	Air bag	x	x	x	
March \ K13 \ 2010-5~	Transmission		x	x	
March \ K13 \ 2010-5~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-5~	IPDM E/R		x	x	
March \ K13 \ 2010-5~	Occupant detection			x	
March \ K13 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-7~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-7~	Meter/M&A		x	x	
March \ K13 \ 2010-7~	BCM		x		
March \ K13 \ 2010-7~	Air bag	x	x	x	
March \ K13 \ 2010-7~	Transmission		x	x	
March \ K13 \ 2010-7~	Multi AV		x	x	
March \ K13 \ 2010-7~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-7~	IPDM E/R		x	x	
March \ K13 \ 2010-7~	E-4wd	x	x	x	
March \ K13 \ 2010-7~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-7~	Sonar	x	x	x	
March \ K13 \ 2010-7~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-7~	Occupant detection			x	
March \ K13 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-8~	Meter/M&A		x	x	
March \ K13 \ 2010-8~	BCM		x		
March \ K13 \ 2010-8~	Air bag	x	x	x	
March \ K13 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

March \ K13 \ 2010-8~	Multi AV		x	x	
March \ K13 \ 2010-8~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-8~	IPDM E/R		x	x	
March \ K13 \ 2010-8~	E-4wd	x	x	x	
March \ K13 \ 2010-8~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-8~	Sonar	x	x	x	
March \ K13 \ 2010-8~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-8~	Occupant detection			x	
March \ K13 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2010-9~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2010-9~	Meter/M&A		x	x	
March \ K13 \ 2010-9~	BCM		x		
March \ K13 \ 2010-9~	Air bag	x	x	x	
March \ K13 \ 2010-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K13 \ 2010-9~	Multi AV		x	x	
March \ K13 \ 2010-9~	EPS/DAST 3	x	x	x	
March \ K13 \ 2010-9~	IPDM E/R		x	x	
March \ K13 \ 2010-9~	E-4wd	x	x	x	
March \ K13 \ 2010-9~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2010-9~	Sonar	x	x	x	
March \ K13 \ 2010-9~	Head lamp levelizer	x	x	x	
March \ K13 \ 2010-9~	Occupant detection			x	
March \ K13 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2011-10~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2011-10~	Meter/M&A		x	x	
March \ K13 \ 2011-10~	BCM		x		
March \ K13 \ 2011-10~	Air bag	x	x	x	
March \ K13 \ 2011-10~	Transmission		x	x	
March \ K13 \ 2011-10~	EPS/DAST 3	x	x	x	
March \ K13 \ 2011-10~	IPDM E/R		x	x	
March \ K13 \ 2011-10~	Sonar	x	x	x	
March \ K13 \ 2011-10~	Occupant detection			x	
March \ K13 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2011-11~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2011-11~	Meter/M&A		x	x	
March \ K13 \ 2011-11~	BCM		x		
March \ K13 \ 2011-11~	Air bag	x	x	x	
March \ K13 \ 2011-11~	ICC/ADAS	x	x	x	

March \ K13 \ 2011-11~	Transmission		x	x	
March \ K13 \ 2011-11~	Multi AV	x	x	x	0280
March \ K13 \ 2011-11~	EPS/DAST 3	x	x	x	
March \ K13 \ 2011-11~	IPDM E/R		x	x	
March \ K13 \ 2011-11~	Air pressure monitor		x	x	
March \ K13 \ 2011-11~	Sonar	x	x	x	
March \ K13 \ 2011-11~	Occupant detection			x	
March \ K13 \ 2011-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2011-2~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2011-2~	Meter/M&A		x	x	
March \ K13 \ 2011-2~	BCM		x		
March \ K13 \ 2011-2~	Air bag	x	x	x	
March \ K13 \ 2011-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March \ K13 \ 2011-2~	Multi AV		x	x	
March \ K13 \ 2011-2~	EPS/DAST 3	x	x	x	
March \ K13 \ 2011-2~	IPDM E/R		x	x	
March \ K13 \ 2011-2~	E-4wd	x	x	x	
March \ K13 \ 2011-2~	All mode AWD/4WD	x	x	x	0245, 0311
March \ K13 \ 2011-2~	Sonar	x	x	x	
March \ K13 \ 2011-2~	Head lamp levelizer	x	x	x	
March \ K13 \ 2011-2~	Occupant detection			x	
March \ K13 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2012-5~	Meter/M&A		x	x	
March \ K13 \ 2012-5~	BCM		x		
March \ K13 \ 2012-5~	Air bag	x	x	x	
March \ K13 \ 2012-5~	Transmission		x	x	
March \ K13 \ 2012-5~	EPS/DAST 3	x	x	x	
March \ K13 \ 2012-5~	IPDM E/R		x	x	
March \ K13 \ 2012-5~	Occupant detection			x	
March \ K13 \ 2012-5~	SVT	x	x	x	
March \ K13 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2013-3~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2013-3~	Meter/M&A		x	x	
March \ K13 \ 2013-3~	BCM		x		
March \ K13 \ 2013-3~	Air bag	x	x	x	
March \ K13 \ 2013-3~	Transmission		x	x	
March \ K13 \ 2013-3~	EPS/DAST 3	x	x	x	

March \ K13 \ 2013-3~	IPDM E/R		x	x	
March \ K13 \ 2013-3~	Sonar	x	x	x	
March \ K13 \ 2013-3~	Occupant detection			x	
March \ K13 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2013-4~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2013-4~	Meter/M&A		x	x	
March \ K13 \ 2013-4~	BCM		x		
March \ K13 \ 2013-4~	Air bag	x	x	x	
March \ K13 \ 2013-4~	Transmission		x	x	
March \ K13 \ 2013-4~	Multi AV	x	x	x	0280
March \ K13 \ 2013-4~	EPS/DAST 3	x	x	x	
March \ K13 \ 2013-4~	IPDM E/R		x	x	
March \ K13 \ 2013-4~	E-4wd	x	x	x	
March \ K13 \ 2013-4~	Telematics		x	x	
March \ K13 \ 2013-4~	Occupant detection			x	
March \ K13 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2013-9~	Meter/M&A		x	x	
March \ K13 \ 2013-9~	BCM		x		
March \ K13 \ 2013-9~	Air bag	x	x	x	
March \ K13 \ 2013-9~	Transmission		x	x	
March \ K13 \ 2013-9~	Multi AV	x	x	x	0280
March \ K13 \ 2013-9~	EPS/DAST 3	x	x	x	
March \ K13 \ 2013-9~	IPDM E/R		x	x	
March \ K13 \ 2013-9~	Sonar	x	x	x	
March \ K13 \ 2013-9~	Lane camera		x	x	
March \ K13 \ 2013-9~	AVM		x	x	
March \ K13 \ 2013-9~	Occupant detection			x	
March \ K13 \ 2013-9~	SVT	x	x	x	
March \ K13 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March \ K13 \ 2015-3~	ABS	x	x	x	0003, 0092, 0264
March \ K13 \ 2015-3~	Meter/M&A		x	x	
March \ K13 \ 2015-3~	BCM		x		
March \ K13 \ 2015-3~	Air bag	x	x	x	
March \ K13 \ 2015-3~	Transmission		x	x	
March \ K13 \ 2015-3~	Multi AV		x	x	
March \ K13 \ 2015-3~	EPS/DAST 3	x	x	x	
March \ K13 \ 2015-3~	IPDM E/R		x	x	

March \ K13 \ 2015-3~	Occupant detection			x	
March-micra \ K11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K11 \ All Year	ABS	x	x	x	0003, 0092, 0264
March-micra \ K11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K11 \ All Year	BCM	x	x		
March-micra \ K11 \ All Year	Air bag	x	x	x	
March-micra \ K11 \ All Year	ICC/ADAS	x	x	x	
March-micra \ K11 \ All Year	HVAC	x	x	x	
March-micra \ K11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K11 \ All Year	Multi AV	x	x	x	0280
March-micra \ K11 \ All Year	EPS/DAST 3	x	x	x	
March-micra \ K11 \ All Year	IPDM E/R	x	x	x	
March-micra \ K11 \ All Year	Air pressure monitor	x	x	x	
March-micra \ K11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K11 \ All Year	DIU	x	x	x	
March-micra \ K11 \ All Year	Auto slide door	x	x	x	
March-micra \ K11 \ All Year	Auto drive position	x	x	x	
March-micra \ K11 \ All Year	All mode AWD/4WD	x	x	x	
March-micra \ K11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K11 \ All Year	Sonar	x	x	x	
March-micra \ K11 \ All Year	Lane camera	x	x	x	
March-micra \ K11 \ All Year	Adaptive light	x	x	x	
March-micra \ K11 \ All Year	AVM		x	x	
March-micra \ K11 \ All Year	Head lamp levelizer	x	x	x	
March-micra \ K11 \ All Year	Difference lock	x	x	x	
March-micra \ K11 \ All Year	Nats immu	x	x		
March-micra \ K11 \ All Year	Smart entrance	x	x		
March-micra \ K11 \ All Year	Air levelizer	x	x	x	
March-micra \ K11 \ All Year	Rearview camera			x	
March-micra \ K11 \ All Year	S/blind camera			x	
March-micra \ K11 \ All Year	Motor assist	x	x	x	
March-micra \ K12 \ 2002-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2002-7~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2002-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2002-7~	BCM	x	x		
March-micra \ K12 \ 2002-7~	Air bag	x	x	x	
March-micra \ K12 \ 2002-7~	ICC/ADAS	x	x	x	

March-micra \ K12 \ 2002-7~	HVAC	x	x	x	
March-micra \ K12 \ 2002-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2002-7~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2002-7~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2002-7~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2002-7~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2002-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2002-7~	DIU	x	x	x	
March-micra \ K12 \ 2002-7~	Auto slide door	x	x	x	
March-micra \ K12 \ 2002-7~	Auto drive position	x	x	x	
March-micra \ K12 \ 2002-7~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2002-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2002-7~	Sonar	x	x	x	
March-micra \ K12 \ 2002-7~	Lane camera	x	x	x	
March-micra \ K12 \ 2002-7~	Adaptive light	x	x	x	
March-micra \ K12 \ 2002-7~	AVM		x	x	
March-micra \ K12 \ 2002-7~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2002-7~	Difference lock	x	x	x	
March-micra \ K12 \ 2002-7~	Nats immu	x	x		
March-micra \ K12 \ 2002-7~	Smart entrance	x	x		
March-micra \ K12 \ 2002-7~	Air levelizer	x	x	x	
March-micra \ K12 \ 2002-7~	Rearview camera			x	
March-micra \ K12 \ 2002-7~	S/blind camera			x	
March-micra \ K12 \ 2002-7~	Motor assist	x	x	x	
March-micra \ K12 \ 2003-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2003-6~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2003-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2003-6~	BCM	x	x		
March-micra \ K12 \ 2003-6~	Air bag	x	x	x	
March-micra \ K12 \ 2003-6~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2003-6~	HVAC	x	x	x	
March-micra \ K12 \ 2003-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2003-6~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2003-6~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2003-6~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2003-6~	Air pressure monitor	x	x	x	

March-micra \ K12 \ 2003-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2003-6~	DIU	x	x	x	
March-micra \ K12 \ 2003-6~	Auto slide door	x	x	x	
March-micra \ K12 \ 2003-6~	Auto drive position	x	x	x	
March-micra \ K12 \ 2003-6~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2003-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2003-6~	Sonar	x	x	x	
March-micra \ K12 \ 2003-6~	Lane camera	x	x	x	
March-micra \ K12 \ 2003-6~	Adaptive light	x	x	x	
March-micra \ K12 \ 2003-6~	AVM		x	x	
March-micra \ K12 \ 2003-6~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2003-6~	Difference lock	x	x	x	
March-micra \ K12 \ 2003-6~	Nats immu	x	x		
March-micra \ K12 \ 2003-6~	Smart entrance	x	x		
March-micra \ K12 \ 2003-6~	Air levelizer	x	x	x	
March-micra \ K12 \ 2003-6~	Rearview camera			x	
March-micra \ K12 \ 2003-6~	S/blind camera			x	
March-micra \ K12 \ 2003-6~	Motor assist	x	x	x	
March-micra \ K12 \ 2004-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2004-4~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2004-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2004-4~	BCM	x	x		
March-micra \ K12 \ 2004-4~	Air bag	x	x	x	
March-micra \ K12 \ 2004-4~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2004-4~	HVAC	x	x	x	
March-micra \ K12 \ 2004-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2004-4~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2004-4~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2004-4~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2004-4~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2004-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2004-4~	DIU	x	x	x	
March-micra \ K12 \ 2004-4~	Auto slide door	x	x	x	
March-micra \ K12 \ 2004-4~	Auto drive position	x	x	x	
March-micra \ K12 \ 2004-4~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2004-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	

March-micra \ K12 \ 2004-4~	Sonar	x	x	x	
March-micra \ K12 \ 2004-4~	Lane camera	x	x	x	
March-micra \ K12 \ 2004-4~	Adaptive light	x	x	x	
March-micra \ K12 \ 2004-4~	AVM		x	x	
March-micra \ K12 \ 2004-4~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2004-4~	Difference lock	x	x	x	
March-micra \ K12 \ 2004-4~	Nats immu	x	x		
March-micra \ K12 \ 2004-4~	Smart entrance	x	x		
March-micra \ K12 \ 2004-4~	Air levelizer	x	x	x	
March-micra \ K12 \ 2004-4~	Rearview camera			x	
March-micra \ K12 \ 2004-4~	S/blind camera			x	
March-micra \ K12 \ 2004-4~	Motor assist	x	x	x	
March-micra \ K12 \ 2005-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2005-10~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2005-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2005-10~	BCM	x	x		
March-micra \ K12 \ 2005-10~	Air bag	x	x	x	
March-micra \ K12 \ 2005-10~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2005-10~	HVAC	x	x	x	
March-micra \ K12 \ 2005-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2005-10~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2005-10~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2005-10~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2005-10~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2005-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2005-10~	DIU	x	x	x	
March-micra \ K12 \ 2005-10~	Auto slide door	x	x	x	
March-micra \ K12 \ 2005-10~	Auto drive position	x	x	x	
March-micra \ K12 \ 2005-10~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2005-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2005-10~	Sonar	x	x	x	
March-micra \ K12 \ 2005-10~	Lane camera	x	x	x	
March-micra \ K12 \ 2005-10~	Adaptive light	x	x	x	
March-micra \ K12 \ 2005-10~	AVM		x	x	
March-micra \ K12 \ 2005-10~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2005-10~	Difference lock	x	x	x	
March-micra \ K12 \ 2005-10~	Nats immu	x	x		
March-micra \ K12 \ 2005-10~	Smart entrance	x	x		

March-micra \ K12 \ 2005-10~	Air levelizer	x	x	x	
March-micra \ K12 \ 2005-10~	Rearview camera			x	
March-micra \ K12 \ 2005-10~	S/blind camera			x	
March-micra \ K12 \ 2005-10~	Motor assist	x	x	x	
March-micra \ K12 \ 2006-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2006-3~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2006-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2006-3~	BCM	x	x		
March-micra \ K12 \ 2006-3~	Air bag	x	x	x	
March-micra \ K12 \ 2006-3~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2006-3~	HVAC	x	x	x	
March-micra \ K12 \ 2006-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2006-3~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2006-3~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2006-3~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2006-3~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2006-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2006-3~	DIU	x	x	x	
March-micra \ K12 \ 2006-3~	Auto slide door	x	x	x	
March-micra \ K12 \ 2006-3~	Auto drive position	x	x	x	
March-micra \ K12 \ 2006-3~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2006-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2006-3~	Sonar	x	x	x	
March-micra \ K12 \ 2006-3~	Lane camera	x	x	x	
March-micra \ K12 \ 2006-3~	Adaptive light	x	x	x	
March-micra \ K12 \ 2006-3~	AVM		x	x	
March-micra \ K12 \ 2006-3~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2006-3~	Difference lock	x	x	x	
March-micra \ K12 \ 2006-3~	Nats immu	x	x		
March-micra \ K12 \ 2006-3~	Smart entrance	x	x		
March-micra \ K12 \ 2006-3~	Air levelizer	x	x	x	
March-micra \ K12 \ 2006-3~	Rearview camera			x	
March-micra \ K12 \ 2006-3~	S/blind camera			x	
March-micra \ K12 \ 2006-3~	Motor assist	x	x	x	
March-micra \ K12 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2007-6~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

March-micra \ K12 \ 2007-6~	BCM	x	x		
March-micra \ K12 \ 2007-6~	Air bag	x	x	x	
March-micra \ K12 \ 2007-6~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2007-6~	HVAC	x	x	x	
March-micra \ K12 \ 2007-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2007-6~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2007-6~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2007-6~	IPDM E/R	x	x	x	
March-micra \ K12 \ 2007-6~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2007-6~	DIU	x	x	x	
March-micra \ K12 \ 2007-6~	Auto slide door	x	x	x	
March-micra \ K12 \ 2007-6~	Auto drive position	x	x	x	
March-micra \ K12 \ 2007-6~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2007-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2007-6~	Sonar	x	x	x	
March-micra \ K12 \ 2007-6~	Lane camera	x	x	x	
March-micra \ K12 \ 2007-6~	Adaptive light	x	x	x	
March-micra \ K12 \ 2007-6~	AVM		x	x	
March-micra \ K12 \ 2007-6~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2007-6~	Difference lock	x	x	x	
March-micra \ K12 \ 2007-6~	Nats immu	x	x		
March-micra \ K12 \ 2007-6~	Smart entrance	x	x		
March-micra \ K12 \ 2007-6~	Air levelizer	x	x	x	
March-micra \ K12 \ 2007-6~	Rearview camera			x	
March-micra \ K12 \ 2007-6~	S/blind camera			x	
March-micra \ K12 \ 2007-6~	Motor assist	x	x	x	
March-micra \ K12 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K12 \ 2008-5~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K12 \ 2008-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K12 \ 2008-5~	BCM	x	x		
March-micra \ K12 \ 2008-5~	Air bag	x	x	x	
March-micra \ K12 \ 2008-5~	ICC/ADAS	x	x	x	
March-micra \ K12 \ 2008-5~	HVAC	x	x	x	
March-micra \ K12 \ 2008-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K12 \ 2008-5~	Multi AV	x	x	x	0280
March-micra \ K12 \ 2008-5~	EPS/DAST 3	x	x	x	
March-micra \ K12 \ 2008-5~	IPDM E/R	x	x	x	

March-micra \ K12 \ 2008-5~	Air pressure monitor	x	x	x	
March-micra \ K12 \ 2008-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
March-micra \ K12 \ 2008-5~	DIU	x	x	x	
March-micra \ K12 \ 2008-5~	Auto slide door	x	x	x	
March-micra \ K12 \ 2008-5~	Auto drive position	x	x	x	
March-micra \ K12 \ 2008-5~	All mode AWD/4WD	x	x	x	
March-micra \ K12 \ 2008-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
March-micra \ K12 \ 2008-5~	Sonar	x	x	x	
March-micra \ K12 \ 2008-5~	Lane camera	x	x	x	
March-micra \ K12 \ 2008-5~	Adaptive light	x	x	x	
March-micra \ K12 \ 2008-5~	AVM		x	x	
March-micra \ K12 \ 2008-5~	Head lamp levelizer	x	x	x	
March-micra \ K12 \ 2008-5~	Difference lock	x	x	x	
March-micra \ K12 \ 2008-5~	Nats immu	x	x		
March-micra \ K12 \ 2008-5~	Smart entrance	x	x		
March-micra \ K12 \ 2008-5~	Air levelizer	x	x	x	
March-micra \ K12 \ 2008-5~	Rearview camera			x	
March-micra \ K12 \ 2008-5~	S/blind camera			x	
March-micra \ K12 \ 2008-5~	Motor assist	x	x	x	
March-micra \ K13 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2010-10~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K13 \ 2010-10~	BCM		x		
March-micra \ K13 \ 2010-10~	Air bag	x	x	x	
March-micra \ K13 \ 2010-10~	Transmission		x	x	
March-micra \ K13 \ 2010-10~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2010-10~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2010-10~	IPDM E/R		x	x	
March-micra \ K13 \ 2010-10~	E-4wd	x	x	x	
March-micra \ K13 \ 2010-10~	All mode AWD/4WD	x	x	x	0245, 0311
March-micra \ K13 \ 2010-10~	Sonar	x	x	x	
March-micra \ K13 \ 2010-10~	Head lamp levelizer	x	x	x	
March-micra \ K13 \ 2010-10~	Occupant detection			x	
March-micra \ K13 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2010-9~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2010-9~	Meter/M&A		x	x	
March-micra \ K13 \ 2010-9~	BCM		x		

March-micra \ K13 \ 2010-9~	Air bag	x	x	x	
March-micra \ K13 \ 2010-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
March-micra \ K13 \ 2010-9~	Multi AV		x	x	
March-micra \ K13 \ 2010-9~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2010-9~	IPDM E/R		x	x	
March-micra \ K13 \ 2010-9~	E-4wd	x	x	x	
March-micra \ K13 \ 2010-9~	All mode AWD/4WD	x	x	x	0245, 0311
March-micra \ K13 \ 2010-9~	Sonar	x	x	x	
March-micra \ K13 \ 2010-9~	Head lamp levelizer	x	x	x	
March-micra \ K13 \ 2010-9~	Occupant detection			x	
March-micra \ K13 \ 2011-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2011-2~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2011-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
March-micra \ K13 \ 2011-2~	BCM		x		
March-micra \ K13 \ 2011-2~	Air bag	x	x	x	
March-micra \ K13 \ 2011-2~	Transmission		x	x	
March-micra \ K13 \ 2011-2~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2011-2~	IPDM E/R		x	x	
March-micra \ K13 \ 2011-2~	Sonar	x	x	x	
March-micra \ K13 \ 2011-2~	Occupant detection			x	
March-micra \ K13 \ 2011-2~	SVT	x	x	x	
March-micra \ K13 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2011-8~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2011-8~	Meter/M&A		x	x	
March-micra \ K13 \ 2011-8~	BCM		x		
March-micra \ K13 \ 2011-8~	Air bag	x	x	x	
March-micra \ K13 \ 2011-8~	Transmission		x	x	
March-micra \ K13 \ 2011-8~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2011-8~	IPDM E/R		x	x	
March-micra \ K13 \ 2011-8~	Sonar	x	x	x	
March-micra \ K13 \ 2011-8~	Occupant detection			x	
March-micra \ K13 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2012-12~	Meter/M&A		x	x	
March-micra \ K13 \ 2012-12~	BCM		x		
March-micra \ K13 \ 2012-12~	Air bag	x	x	x	
March-micra \ K13 \ 2012-12~	Transmission		x	x	
March-micra \ K13 \ 2012-12~	EPS/DAST 3	x	x	x	

March-micra \ K13 \ 2012-12~	IPDM E/R		x	x	
March-micra \ K13 \ 2012-12~	Occupant detection			x	
March-micra \ K13 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2013-9~	Meter/M&A		x	x	
March-micra \ K13 \ 2013-9~	BCM		x		
March-micra \ K13 \ 2013-9~	Air bag	x	x	x	
March-micra \ K13 \ 2013-9~	Transmission		x	x	
March-micra \ K13 \ 2013-9~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2013-9~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2013-9~	IPDM E/R		x	x	
March-micra \ K13 \ 2013-9~	Sonar	x	x	x	
March-micra \ K13 \ 2013-9~	Lane camera		x	x	
March-micra \ K13 \ 2013-9~	AVM		x	x	
March-micra \ K13 \ 2013-9~	Occupant detection			x	
March-micra \ K13 \ 2013-9~	SVT	x	x	x	
March-micra \ K13 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2014-11~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2014-11~	Meter/M&A		x	x	
March-micra \ K13 \ 2014-11~	BCM		x		
March-micra \ K13 \ 2014-11~	Air bag	x	x	x	
March-micra \ K13 \ 2014-11~	Transmission		x	x	
March-micra \ K13 \ 2014-11~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2014-11~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2014-11~	IPDM E/R		x	x	
March-micra \ K13 \ 2014-11~	Sonar	x	x	x	
March-micra \ K13 \ 2014-11~	Lane camera		x	x	
March-micra \ K13 \ 2014-11~	AVM		x	x	
March-micra \ K13 \ 2014-11~	Occupant detection			x	
March-micra \ K13 \ 2014-11~	SVT	x	x	x	
March-micra \ K13 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2014-9~	Meter/M&A		x	x	
March-micra \ K13 \ 2014-9~	BCM		x		
March-micra \ K13 \ 2014-9~	Air bag	x	x	x	
March-micra \ K13 \ 2014-9~	Transmission		x	x	
March-micra \ K13 \ 2014-9~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2014-9~	EPS/DAST 3	x	x	x	

March-micra \ K13 \ 2014-9~	IPDM E/R		x	x	
March-micra \ K13 \ 2014-9~	Sonar	x	x	x	
March-micra \ K13 \ 2014-9~	Lane camera		x	x	
March-micra \ K13 \ 2014-9~	AVM		x	x	
March-micra \ K13 \ 2014-9~	Occupant detection			x	
March-micra \ K13 \ 2014-9~	SVT	x	x	x	
March-micra \ K13 \ 2015-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2015-12~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2015-12~	Meter/M&A		x	x	
March-micra \ K13 \ 2015-12~	BCM		x		
March-micra \ K13 \ 2015-12~	Air bag	x	x	x	
March-micra \ K13 \ 2015-12~	Transmission		x	x	
March-micra \ K13 \ 2015-12~	Multi AV		x	x	
March-micra \ K13 \ 2015-12~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2015-12~	IPDM E/R		x	x	
March-micra \ K13 \ 2015-12~	Occupant detection			x	
March-micra \ K13 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2015-3~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2015-3~	Meter/M&A		x	x	
March-micra \ K13 \ 2015-3~	BCM		x		
March-micra \ K13 \ 2015-3~	Air bag	x	x	x	
March-micra \ K13 \ 2015-3~	Transmission		x	x	
March-micra \ K13 \ 2015-3~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2015-3~	IPDM E/R		x	x	
March-micra \ K13 \ 2015-3~	Occupant detection			x	
March-micra \ K13 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2016-1~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2016-1~	Meter/M&A		x	x	
March-micra \ K13 \ 2016-1~	BCM		x		
March-micra \ K13 \ 2016-1~	Air bag	x	x	x	
March-micra \ K13 \ 2016-1~	Transmission		x	x	
March-micra \ K13 \ 2016-1~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2016-1~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2016-1~	IPDM E/R		x	x	
March-micra \ K13 \ 2016-1~	Sonar	x	x	x	
March-micra \ K13 \ 2016-1~	Lane camera		x	x	
March-micra \ K13 \ 2016-1~	AVM		x	x	
March-micra \ K13 \ 2016-1~	Occupant detection			x	

March-micra \ K13 \ 2016-1~	SVT	x	x	x	
March-micra \ K13 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
March-micra \ K13 \ 2016-4~	ABS	x	x	x	0003, 0092, 0264
March-micra \ K13 \ 2016-4~	Meter/M&A		x	x	
March-micra \ K13 \ 2016-4~	BCM		x		
March-micra \ K13 \ 2016-4~	Air bag	x	x	x	
March-micra \ K13 \ 2016-4~	ICC/ADAS	x	x	x	
March-micra \ K13 \ 2016-4~	Transmission		x	x	
March-micra \ K13 \ 2016-4~	Multi AV	x	x	x	0280
March-micra \ K13 \ 2016-4~	EPS/DAST 3	x	x	x	
March-micra \ K13 \ 2016-4~	IPDM E/R		x	x	
March-micra \ K13 \ 2016-4~	Air pressure monitor		x	x	
March-micra \ K13 \ 2016-4~	Sonar	x	x	x	
March-micra \ K13 \ 2016-4~	Occupant detection			x	
Maxima QX \ A32 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima QX \ A32 \ All Year	ABS	x	x	x	0003, 0092, 0264
Maxima QX \ A32 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima QX \ A32 \ All Year	BCM	x	x		
Maxima QX \ A32 \ All Year	Air bag	x	x	x	
Maxima QX \ A32 \ All Year	ICC/ADAS	x	x	x	
Maxima QX \ A32 \ All Year	HVAC	x	x	x	
Maxima QX \ A32 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima QX \ A32 \ All Year	Multi AV	x	x	x	0280
Maxima QX \ A32 \ All Year	EPS/DAST 3	x	x	x	
Maxima QX \ A32 \ All Year	IPDM E/R	x	x	x	
Maxima QX \ A32 \ All Year	Air pressure monitor	x	x	x	
Maxima QX \ A32 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima QX \ A32 \ All Year	DIU	x	x	x	
Maxima QX \ A32 \ All Year	Auto slide door	x	x	x	
Maxima QX \ A32 \ All Year	Auto drive position	x	x	x	
Maxima QX \ A32 \ All Year	All mode AWD/4WD	x	x	x	
Maxima QX \ A32 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima QX \ A32 \ All Year	Sonar	x	x	x	
Maxima QX \ A32 \ All Year	Lane camera	x	x	x	
Maxima QX \ A32 \ All Year	Adaptive light	x	x	x	
Maxima QX \ A32 \ All Year	AVM		x	x	
Maxima QX \ A32 \ All Year	Head lamp levelizer	x	x	x	

Maxima QX \ A32 \ All Year	Difference lock	x	x	x	
Maxima QX \ A32 \ All Year	Nats immu	x	x		
Maxima QX \ A32 \ All Year	Smart entrance	x	x		
Maxima QX \ A32 \ All Year	Air levelizer	x	x	x	
Maxima QX \ A32 \ All Year	Rearview camera			x	
Maxima QX \ A32 \ All Year	S/blind camera			x	
Maxima QX \ A32 \ All Year	Motor assist	x	x	x	
Maxima QX \ A33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima QX \ A33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Maxima QX \ A33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima QX \ A33 \ All Year	BCM	x	x		
Maxima QX \ A33 \ All Year	Air bag	x	x	x	
Maxima QX \ A33 \ All Year	ICC/ADAS	x	x	x	
Maxima QX \ A33 \ All Year	HVAC	x	x	x	
Maxima QX \ A33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima QX \ A33 \ All Year	Multi AV	x	x	x	0280
Maxima QX \ A33 \ All Year	EPS/DAST 3	x	x	x	
Maxima QX \ A33 \ All Year	IPDM E/R	x	x	x	
Maxima QX \ A33 \ All Year	Air pressure monitor	x	x	x	
Maxima QX \ A33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima QX \ A33 \ All Year	DIU	x	x	x	
Maxima QX \ A33 \ All Year	Auto slide door	x	x	x	
Maxima QX \ A33 \ All Year	Auto drive position	x	x	x	
Maxima QX \ A33 \ All Year	All mode AWD/4WD	x	x	x	
Maxima QX \ A33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima QX \ A33 \ All Year	Sonar	x	x	x	
Maxima QX \ A33 \ All Year	Lane camera	x	x	x	
Maxima QX \ A33 \ All Year	Adaptive light	x	x	x	
Maxima QX \ A33 \ All Year	AVM		x	x	
Maxima QX \ A33 \ All Year	Head lamp levelizer	x	x	x	
Maxima QX \ A33 \ All Year	Difference lock	x	x	x	
Maxima QX \ A33 \ All Year	Nats immu	x	x		
Maxima QX \ A33 \ All Year	Smart entrance	x	x		
Maxima QX \ A33 \ All Year	Air levelizer	x	x	x	
Maxima QX \ A33 \ All Year	Rearview camera			x	
Maxima QX \ A33 \ All Year	S/blind camera			x	
Maxima QX \ A33 \ All Year	Motor assist	x	x	x	

Maxima \ A33 \ 1998	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 1998	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 1998	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 1998	BCM	x	x		
Maxima \ A33 \ 1998	Air bag	x	x	x	
Maxima \ A33 \ 1998	ICC/ADAS	x	x	x	
Maxima \ A33 \ 1998	HVAC	x	x	x	
Maxima \ A33 \ 1998	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 1998	Multi AV	x	x	x	0280
Maxima \ A33 \ 1998	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 1998	IPDM E/R	x	x	x	
Maxima \ A33 \ 1998	Air pressure monitor	x	x	x	
Maxima \ A33 \ 1998	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ 1998	DIU	x	x	x	
Maxima \ A33 \ 1998	Auto slide door	x	x	x	
Maxima \ A33 \ 1998	Auto drive position	x	x	x	
Maxima \ A33 \ 1998	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 1998	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 1998	Sonar	x	x	x	
Maxima \ A33 \ 1998	Lane camera	x	x	x	
Maxima \ A33 \ 1998	Adaptive light	x	x	x	
Maxima \ A33 \ 1998	AVM		x	x	
Maxima \ A33 \ 1998	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 1998	Difference lock	x	x	x	
Maxima \ A33 \ 1998	Nats immu	x	x		
Maxima \ A33 \ 1998	Smart entrance	x	x		
Maxima \ A33 \ 1998	Air levelizer	x	x	x	
Maxima \ A33 \ 1998	Rearview camera			x	
Maxima \ A33 \ 1998	S/blind camera			x	
Maxima \ A33 \ 1998	Motor assist	x	x	x	
Maxima \ A33 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 1999	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 1999	BCM	x	x		
Maxima \ A33 \ 1999	Air bag	x	x	x	
Maxima \ A33 \ 1999	ICC/ADAS	x	x	x	
Maxima \ A33 \ 1999	HVAC	x	x	x	

Maxima \ A33 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 1999	Multi AV	x	x	x	0280
Maxima \ A33 \ 1999	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 1999	IPDM E/R	x	x	x	
Maxima \ A33 \ 1999	Air pressure monitor	x	x	x	
Maxima \ A33 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ 1999	DIU	x	x	x	
Maxima \ A33 \ 1999	Auto slide door	x	x	x	
Maxima \ A33 \ 1999	Auto drive position	x	x	x	
Maxima \ A33 \ 1999	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 1999	Sonar	x	x	x	
Maxima \ A33 \ 1999	Lane camera	x	x	x	
Maxima \ A33 \ 1999	Adaptive light	x	x	x	
Maxima \ A33 \ 1999	AVM		x	x	
Maxima \ A33 \ 1999	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 1999	Difference lock	x	x	x	
Maxima \ A33 \ 1999	Nats immu	x	x		
Maxima \ A33 \ 1999	Smart entrance	x	x		
Maxima \ A33 \ 1999	Air levelizer	x	x	x	
Maxima \ A33 \ 1999	Rearview camera			x	
Maxima \ A33 \ 1999	S/blind camera			x	
Maxima \ A33 \ 1999	Motor assist	x	x	x	
Maxima \ A33 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 2000	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 2000	BCM	x	x		
Maxima \ A33 \ 2000	Air bag	x	x	x	
Maxima \ A33 \ 2000	ICC/ADAS	x	x	x	
Maxima \ A33 \ 2000	HVAC	x	x	x	
Maxima \ A33 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 2000	Multi AV	x	x	x	0280
Maxima \ A33 \ 2000	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 2000	IPDM E/R	x	x	x	
Maxima \ A33 \ 2000	Air pressure monitor	x	x	x	
Maxima \ A33 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Maxima \ A33 \ 2000	DIU	x	x	x	
Maxima \ A33 \ 2000	Auto slide door	x	x	x	
Maxima \ A33 \ 2000	Auto drive position	x	x	x	
Maxima \ A33 \ 2000	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 2000	Sonar	x	x	x	
Maxima \ A33 \ 2000	Lane camera	x	x	x	
Maxima \ A33 \ 2000	Adaptive light	x	x	x	
Maxima \ A33 \ 2000	AVM		x	x	
Maxima \ A33 \ 2000	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 2000	Difference lock	x	x	x	
Maxima \ A33 \ 2000	Nats immu	x	x		
Maxima \ A33 \ 2000	Smart entrance	x	x		
Maxima \ A33 \ 2000	Air levelizer	x	x	x	
Maxima \ A33 \ 2000	Rearview camera			x	
Maxima \ A33 \ 2000	S/blind camera			x	
Maxima \ A33 \ 2000	Motor assist	x	x	x	
Maxima \ A33 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 2001	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 2001	BCM	x	x		
Maxima \ A33 \ 2001	Air bag	x	x	x	
Maxima \ A33 \ 2001	ICC/ADAS	x	x	x	
Maxima \ A33 \ 2001	HVAC	x	x	x	
Maxima \ A33 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 2001	Multi AV	x	x	x	0280
Maxima \ A33 \ 2001	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 2001	IPDM E/R	x	x	x	
Maxima \ A33 \ 2001	Air pressure monitor	x	x	x	
Maxima \ A33 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ 2001	DIU	x	x	x	
Maxima \ A33 \ 2001	Auto slide door	x	x	x	
Maxima \ A33 \ 2001	Auto drive position	x	x	x	
Maxima \ A33 \ 2001	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 2001	Sonar	x	x	x	
Maxima \ A33 \ 2001	Lane camera	x	x	x	
Maxima \ A33 \ 2001	Adaptive light	x	x	x	

Maxima \ A33 \ 2001	AVM		x	x	
Maxima \ A33 \ 2001	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 2001	Difference lock	x	x	x	
Maxima \ A33 \ 2001	Nats immu	x	x		
Maxima \ A33 \ 2001	Smart entrance	x	x		
Maxima \ A33 \ 2001	Air levelizer	x	x	x	
Maxima \ A33 \ 2001	Rearview camera			x	
Maxima \ A33 \ 2001	S/blind camera			x	
Maxima \ A33 \ 2001	Motor assist	x	x	x	
Maxima \ A33 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 2002	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 2002	BCM	x	x		
Maxima \ A33 \ 2002	Air bag	x	x	x	
Maxima \ A33 \ 2002	ICC/ADAS	x	x	x	
Maxima \ A33 \ 2002	HVAC	x	x	x	
Maxima \ A33 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 2002	Multi AV	x	x	x	0280
Maxima \ A33 \ 2002	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 2002	IPDM E/R	x	x	x	
Maxima \ A33 \ 2002	Air pressure monitor	x	x	x	
Maxima \ A33 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ 2002	DIU	x	x	x	
Maxima \ A33 \ 2002	Auto slide door	x	x	x	
Maxima \ A33 \ 2002	Auto drive position	x	x	x	
Maxima \ A33 \ 2002	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 2002	Sonar	x	x	x	
Maxima \ A33 \ 2002	Lane camera	x	x	x	
Maxima \ A33 \ 2002	Adaptive light	x	x	x	
Maxima \ A33 \ 2002	AVM		x	x	
Maxima \ A33 \ 2002	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 2002	Difference lock	x	x	x	
Maxima \ A33 \ 2002	Nats immu	x	x		
Maxima \ A33 \ 2002	Smart entrance	x	x		
Maxima \ A33 \ 2002	Air levelizer	x	x	x	
Maxima \ A33 \ 2002	Rearview camera			x	
Maxima \ A33 \ 2002	S/blind camera			x	

Maxima \ A33 \ 2002	Motor assist	x	x	x	
Maxima \ A33 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ 2003	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ 2003	BCM	x	x		
Maxima \ A33 \ 2003	Air bag	x	x	x	
Maxima \ A33 \ 2003	ICC/ADAS	x	x	x	
Maxima \ A33 \ 2003	HVAC	x	x	x	
Maxima \ A33 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ 2003	Multi AV	x	x	x	0280
Maxima \ A33 \ 2003	EPS/DAST 3	x	x	x	
Maxima \ A33 \ 2003	IPDM E/R	x	x	x	
Maxima \ A33 \ 2003	Air pressure monitor	x	x	x	
Maxima \ A33 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ 2003	DIU	x	x	x	
Maxima \ A33 \ 2003	Auto slide door	x	x	x	
Maxima \ A33 \ 2003	Auto drive position	x	x	x	
Maxima \ A33 \ 2003	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ 2003	Sonar	x	x	x	
Maxima \ A33 \ 2003	Lane camera	x	x	x	
Maxima \ A33 \ 2003	Adaptive light	x	x	x	
Maxima \ A33 \ 2003	AVM		x	x	
Maxima \ A33 \ 2003	Head lamp levelizer	x	x	x	
Maxima \ A33 \ 2003	Difference lock	x	x	x	
Maxima \ A33 \ 2003	Nats immu	x	x		
Maxima \ A33 \ 2003	Smart entrance	x	x		
Maxima \ A33 \ 2003	Air levelizer	x	x	x	
Maxima \ A33 \ 2003	Rearview camera			x	
Maxima \ A33 \ 2003	S/blind camera			x	
Maxima \ A33 \ 2003	Motor assist	x	x	x	
Maxima \ A33 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A33 \ All Year	ABS	x	x	x	0003, 0092, 0264
Maxima \ A33 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A33 \ All Year	BCM	x	x		
Maxima \ A33 \ All Year	Air bag	x	x	x	
Maxima \ A33 \ All Year	ICC/ADAS	x	x	x	

Maxima \ A33 \ All Year	HVAC	x	x	x	
Maxima \ A33 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A33 \ All Year	Multi AV	x	x	x	0280
Maxima \ A33 \ All Year	EPS/DAST 3	x	x	x	
Maxima \ A33 \ All Year	IPDM E/R	x	x	x	
Maxima \ A33 \ All Year	Air pressure monitor	x	x	x	
Maxima \ A33 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A33 \ All Year	DIU	x	x	x	
Maxima \ A33 \ All Year	Auto slide door	x	x	x	
Maxima \ A33 \ All Year	Auto drive position	x	x	x	
Maxima \ A33 \ All Year	All mode AWD/4WD	x	x	x	
Maxima \ A33 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A33 \ All Year	Sonar	x	x	x	
Maxima \ A33 \ All Year	Lane camera	x	x	x	
Maxima \ A33 \ All Year	Adaptive light	x	x	x	
Maxima \ A33 \ All Year	AVM		x	x	
Maxima \ A33 \ All Year	Head lamp levelizer	x	x	x	
Maxima \ A33 \ All Year	Difference lock	x	x	x	
Maxima \ A33 \ All Year	Nats immu	x	x		
Maxima \ A33 \ All Year	Smart entrance	x	x		
Maxima \ A33 \ All Year	Air levelizer	x	x	x	
Maxima \ A33 \ All Year	Rearview camera			x	
Maxima \ A33 \ All Year	S/blind camera			x	
Maxima \ A33 \ All Year	Motor assist	x	x	x	
Maxima \ A34 \ 2003-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2003-1~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2003-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2003-1~	BCM	x	x		
Maxima \ A34 \ 2003-1~	Air bag	x	x	x	
Maxima \ A34 \ 2003-1~	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2003-1~	HVAC	x	x	x	
Maxima \ A34 \ 2003-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2003-1~	Multi AV	x	x	x	0280
Maxima \ A34 \ 2003-1~	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2003-1~	IPDM E/R	x	x	x	
Maxima \ A34 \ 2003-1~	Air pressure monitor	x	x	x	

Maxima \ A34 \ 2003-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2003-1~	DIU	x	x	x	
Maxima \ A34 \ 2003-1~	Auto slide door	x	x	x	
Maxima \ A34 \ 2003-1~	Auto drive position	x	x	x	
Maxima \ A34 \ 2003-1~	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2003-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2003-1~	Sonar	x	x	x	
Maxima \ A34 \ 2003-1~	Lane camera	x	x	x	
Maxima \ A34 \ 2003-1~	Adaptive light	x	x	x	
Maxima \ A34 \ 2003-1~	AVM		x	x	
Maxima \ A34 \ 2003-1~	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2003-1~	Difference lock	x	x	x	
Maxima \ A34 \ 2003-1~	Nats immu	x	x		
Maxima \ A34 \ 2003-1~	Smart entrance	x	x		
Maxima \ A34 \ 2003-1~	Air levelizer	x	x	x	
Maxima \ A34 \ 2003-1~	Rearview camera			x	
Maxima \ A34 \ 2003-1~	S/blind camera			x	
Maxima \ A34 \ 2003-1~	Motor assist	x	x	x	
Maxima \ A34 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2004	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2004	BCM	x	x		
Maxima \ A34 \ 2004	Air bag	x	x	x	
Maxima \ A34 \ 2004	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2004	HVAC	x	x	x	
Maxima \ A34 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2004	Multi AV	x	x	x	0280
Maxima \ A34 \ 2004	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2004	IPDM E/R	x	x	x	
Maxima \ A34 \ 2004	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2004	DIU	x	x	x	
Maxima \ A34 \ 2004	Auto slide door	x	x	x	
Maxima \ A34 \ 2004	Auto drive position	x	x	x	
Maxima \ A34 \ 2004	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	

Maxima \ A34 \ 2004	Sonar	x	x	x	
Maxima \ A34 \ 2004	Lane camera	x	x	x	
Maxima \ A34 \ 2004	Adaptive light	x	x	x	
Maxima \ A34 \ 2004	AVM		x	x	
Maxima \ A34 \ 2004	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2004	Difference lock	x	x	x	
Maxima \ A34 \ 2004	Nats immu	x	x		
Maxima \ A34 \ 2004	Smart entrance	x	x		
Maxima \ A34 \ 2004	Air levelizer	x	x	x	
Maxima \ A34 \ 2004	Rearview camera			x	
Maxima \ A34 \ 2004	S/blind camera			x	
Maxima \ A34 \ 2004	Motor assist	x	x	x	
Maxima \ A34 \ 2004-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2004-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2004-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2004-8~	BCM	x	x		
Maxima \ A34 \ 2004-8~	Air bag	x	x	x	
Maxima \ A34 \ 2004-8~	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2004-8~	HVAC	x	x	x	
Maxima \ A34 \ 2004-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2004-8~	Multi AV	x	x	x	0280
Maxima \ A34 \ 2004-8~	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2004-8~	IPDM E/R	x	x	x	
Maxima \ A34 \ 2004-8~	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2004-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2004-8~	DIU	x	x	x	
Maxima \ A34 \ 2004-8~	Auto slide door	x	x	x	
Maxima \ A34 \ 2004-8~	Auto drive position	x	x	x	
Maxima \ A34 \ 2004-8~	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2004-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2004-8~	Sonar	x	x	x	
Maxima \ A34 \ 2004-8~	Lane camera	x	x	x	
Maxima \ A34 \ 2004-8~	Adaptive light	x	x	x	
Maxima \ A34 \ 2004-8~	AVM		x	x	
Maxima \ A34 \ 2004-8~	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2004-8~	Difference lock	x	x	x	
Maxima \ A34 \ 2004-8~	Nats immu	x	x		
Maxima \ A34 \ 2004-8~	Smart entrance	x	x		

Maxima \ A34 \ 2004-8~	Air levelizer	x	x	x	
Maxima \ A34 \ 2004-8~	Rearview camera			x	
Maxima \ A34 \ 2004-8~	S/blind camera			x	
Maxima \ A34 \ 2004-8~	Motor assist	x	x	x	
Maxima \ A34 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2005	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2005	BCM	x	x		
Maxima \ A34 \ 2005	Air bag	x	x	x	
Maxima \ A34 \ 2005	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2005	HVAC	x	x	x	
Maxima \ A34 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2005	Multi AV	x	x	x	0280
Maxima \ A34 \ 2005	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2005	IPDM E/R	x	x	x	
Maxima \ A34 \ 2005	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2005	DIU	x	x	x	
Maxima \ A34 \ 2005	Auto slide door	x	x	x	
Maxima \ A34 \ 2005	Auto drive position	x	x	x	
Maxima \ A34 \ 2005	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2005	Sonar	x	x	x	
Maxima \ A34 \ 2005	Lane camera	x	x	x	
Maxima \ A34 \ 2005	Adaptive light	x	x	x	
Maxima \ A34 \ 2005	AVM		x	x	
Maxima \ A34 \ 2005	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2005	Difference lock	x	x	x	
Maxima \ A34 \ 2005	Nats immu	x	x		
Maxima \ A34 \ 2005	Smart entrance	x	x		
Maxima \ A34 \ 2005	Air levelizer	x	x	x	
Maxima \ A34 \ 2005	Rearview camera			x	
Maxima \ A34 \ 2005	S/blind camera			x	
Maxima \ A34 \ 2005	Motor assist	x	x	x	
Maxima \ A34 \ 2005-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2005-1~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Maxima \ A34 \ 2005-1~	BCM	x	x		
Maxima \ A34 \ 2005-1~	Air bag	x	x	x	
Maxima \ A34 \ 2005-1~	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2005-1~	HVAC	x	x	x	
Maxima \ A34 \ 2005-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2005-1~	Multi AV	x	x	x	0280
Maxima \ A34 \ 2005-1~	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2005-1~	IPDM E/R	x	x	x	
Maxima \ A34 \ 2005-1~	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2005-1~	DIU	x	x	x	
Maxima \ A34 \ 2005-1~	Auto slide door	x	x	x	
Maxima \ A34 \ 2005-1~	Auto drive position	x	x	x	
Maxima \ A34 \ 2005-1~	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2005-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2005-1~	Sonar	x	x	x	
Maxima \ A34 \ 2005-1~	Lane camera	x	x	x	
Maxima \ A34 \ 2005-1~	Adaptive light	x	x	x	
Maxima \ A34 \ 2005-1~	AVM		x	x	
Maxima \ A34 \ 2005-1~	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2005-1~	Difference lock	x	x	x	
Maxima \ A34 \ 2005-1~	Nats immu	x	x		
Maxima \ A34 \ 2005-1~	Smart entrance	x	x		
Maxima \ A34 \ 2005-1~	Air levelizer	x	x	x	
Maxima \ A34 \ 2005-1~	Rearview camera			x	
Maxima \ A34 \ 2005-1~	S/blind camera			x	
Maxima \ A34 \ 2005-1~	Motor assist	x	x	x	
Maxima \ A34 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2006	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2006	BCM	x	x		
Maxima \ A34 \ 2006	Air bag	x	x	x	
Maxima \ A34 \ 2006	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2006	HVAC	x	x	x	
Maxima \ A34 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2006	Multi AV	x	x	x	0280
Maxima \ A34 \ 2006	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2006	IPDM E/R	x	x	x	

Maxima \ A34 \ 2006	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2006	DIU	x	x	x	
Maxima \ A34 \ 2006	Auto slide door	x	x	x	
Maxima \ A34 \ 2006	Auto drive position	x	x	x	
Maxima \ A34 \ 2006	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2006	Sonar	x	x	x	
Maxima \ A34 \ 2006	Lane camera	x	x	x	
Maxima \ A34 \ 2006	Adaptive light	x	x	x	
Maxima \ A34 \ 2006	AVM		x	x	
Maxima \ A34 \ 2006	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2006	Difference lock	x	x	x	
Maxima \ A34 \ 2006	Nats immu	x	x		
Maxima \ A34 \ 2006	Smart entrance	x	x		
Maxima \ A34 \ 2006	Air levelizer	x	x	x	
Maxima \ A34 \ 2006	Rearview camera			x	
Maxima \ A34 \ 2006	S/blind camera			x	
Maxima \ A34 \ 2006	Motor assist	x	x	x	
Maxima \ A34 \ 2006-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2006-5~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2006-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2006-5~	BCM	x	x		
Maxima \ A34 \ 2006-5~	Air bag	x	x	x	
Maxima \ A34 \ 2006-5~	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2006-5~	HVAC	x	x	x	
Maxima \ A34 \ 2006-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2006-5~	Multi AV	x	x	x	0280
Maxima \ A34 \ 2006-5~	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2006-5~	IPDM E/R	x	x	x	
Maxima \ A34 \ 2006-5~	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2006-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2006-5~	DIU	x	x	x	
Maxima \ A34 \ 2006-5~	Auto slide door	x	x	x	
Maxima \ A34 \ 2006-5~	Auto drive position	x	x	x	
Maxima \ A34 \ 2006-5~	All mode AWD/4WD	x	x	x	

Maxima \ A34 \ 2006-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2006-5~	Sonar	x	x	x	
Maxima \ A34 \ 2006-5~	Lane camera	x	x	x	
Maxima \ A34 \ 2006-5~	Adaptive light	x	x	x	
Maxima \ A34 \ 2006-5~	AVM		x	x	
Maxima \ A34 \ 2006-5~	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2006-5~	Difference lock	x	x	x	
Maxima \ A34 \ 2006-5~	Nats immu	x	x		
Maxima \ A34 \ 2006-5~	Smart entrance	x	x		
Maxima \ A34 \ 2006-5~	Air levelizer	x	x	x	
Maxima \ A34 \ 2006-5~	Rearview camera			x	
Maxima \ A34 \ 2006-5~	S/blind camera			x	
Maxima \ A34 \ 2006-5~	Motor assist	x	x	x	
Maxima \ A34 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2007	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2007	BCM	x	x		
Maxima \ A34 \ 2007	Air bag	x	x	x	
Maxima \ A34 \ 2007	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2007	HVAC	x	x	x	
Maxima \ A34 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2007	Multi AV	x	x	x	0280
Maxima \ A34 \ 2007	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2007	IPDM E/R	x	x	x	
Maxima \ A34 \ 2007	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2007	DIU	x	x	x	
Maxima \ A34 \ 2007	Auto slide door	x	x	x	
Maxima \ A34 \ 2007	Auto drive position	x	x	x	
Maxima \ A34 \ 2007	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2007	Sonar	x	x	x	
Maxima \ A34 \ 2007	Lane camera	x	x	x	
Maxima \ A34 \ 2007	Adaptive light	x	x	x	
Maxima \ A34 \ 2007	AVM		x	x	
Maxima \ A34 \ 2007	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2007	Difference lock	x	x	x	
Maxima \ A34 \ 2007	Nats immu	x	x		

Maxima \ A34 \ 2007	Smart entrance	x	x		
Maxima \ A34 \ 2007	Air levelizer	x	x	x	
Maxima \ A34 \ 2007	Rearview camera			x	
Maxima \ A34 \ 2007	S/blind camera			x	
Maxima \ A34 \ 2007	Motor assist	x	x	x	
Maxima \ A34 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A34 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2007-7~	BCM	x	x		
Maxima \ A34 \ 2007-7~	Air bag	x	x	x	
Maxima \ A34 \ 2007-7~	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2007-7~	HVAC	x	x	x	
Maxima \ A34 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2007-7~	Multi AV	x	x	x	0280
Maxima \ A34 \ 2007-7~	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2007-7~	IPDM E/R	x	x	x	
Maxima \ A34 \ 2007-7~	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2007-7~	DIU	x	x	x	
Maxima \ A34 \ 2007-7~	Auto slide door	x	x	x	
Maxima \ A34 \ 2007-7~	Auto drive position	x	x	x	
Maxima \ A34 \ 2007-7~	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2007-7~	Sonar	x	x	x	
Maxima \ A34 \ 2007-7~	Lane camera	x	x	x	
Maxima \ A34 \ 2007-7~	Adaptive light	x	x	x	
Maxima \ A34 \ 2007-7~	AVM		x	x	
Maxima \ A34 \ 2007-7~	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2007-7~	Difference lock	x	x	x	
Maxima \ A34 \ 2007-7~	Nats immu	x	x		
Maxima \ A34 \ 2007-7~	Smart entrance	x	x		
Maxima \ A34 \ 2007-7~	Air levelizer	x	x	x	
Maxima \ A34 \ 2007-7~	Rearview camera			x	
Maxima \ A34 \ 2007-7~	S/blind camera			x	
Maxima \ A34 \ 2007-7~	Motor assist	x	x	x	
Maxima \ A34 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A34 \ 2008	ABS	x	x	x	0003, 0092, 0264

Maxima \ A34 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A34 \ 2008	BCM	x	x		
Maxima \ A34 \ 2008	Air bag	x	x	x	
Maxima \ A34 \ 2008	ICC/ADAS	x	x	x	
Maxima \ A34 \ 2008	HVAC	x	x	x	
Maxima \ A34 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima \ A34 \ 2008	Multi AV	x	x	x	0280
Maxima \ A34 \ 2008	EPS/DAST 3	x	x	x	
Maxima \ A34 \ 2008	IPDM E/R	x	x	x	
Maxima \ A34 \ 2008	Air pressure monitor	x	x	x	
Maxima \ A34 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima \ A34 \ 2008	DIU	x	x	x	
Maxima \ A34 \ 2008	Auto slide door	x	x	x	
Maxima \ A34 \ 2008	Auto drive position	x	x	x	
Maxima \ A34 \ 2008	All mode AWD/4WD	x	x	x	
Maxima \ A34 \ 2008	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima \ A34 \ 2008	Sonar	x	x	x	
Maxima \ A34 \ 2008	Lane camera	x	x	x	
Maxima \ A34 \ 2008	Adaptive light	x	x	x	
Maxima \ A34 \ 2008	AVM		x	x	
Maxima \ A34 \ 2008	Head lamp levelizer	x	x	x	
Maxima \ A34 \ 2008	Difference lock	x	x	x	
Maxima \ A34 \ 2008	Nats immu	x	x		
Maxima \ A34 \ 2008	Smart entrance	x	x		
Maxima \ A34 \ 2008	Air levelizer	x	x	x	
Maxima \ A34 \ 2008	Rearview camera			x	
Maxima \ A34 \ 2008	S/blind camera			x	
Maxima \ A34 \ 2008	Motor assist	x	x	x	
Maxima \ A35 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2008-5~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2008-5~	Meter/M&A		x	x	
Maxima \ A35 \ 2008-5~	BCM		x		
Maxima \ A35 \ 2008-5~	Air bag	x	x	x	
Maxima \ A35 \ 2008-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2008-5~	Transmission	x	x	x	
Maxima \ A35 \ 2008-5~	Multi AV	x	x	x	
Maxima \ A35 \ 2008-5~	IPDM E/R	x	x	x	

Maxima \ A35 \ 2008-5~	Auto drive position		x	x	
Maxima \ A35 \ 2008-5~	Sonar	x	x	x	
Maxima \ A35 \ 2008-5~	Rearview camera			x	
Maxima \ A35 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2009	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2009	Meter/M&A		x	x	
Maxima \ A35 \ 2009	BCM		x		
Maxima \ A35 \ 2009	Air bag	x	x	x	
Maxima \ A35 \ 2009	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2009	Transmission	x	x	x	
Maxima \ A35 \ 2009	Multi AV	x	x	x	
Maxima \ A35 \ 2009	IPDM E/R	x	x	x	
Maxima \ A35 \ 2009	Auto drive position		x	x	
Maxima \ A35 \ 2009	Sonar	x	x	x	
Maxima \ A35 \ 2009	Rearview camera			x	
Maxima \ A35 \ 2009-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2009-7~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2009-7~	Meter/M&A		x	x	
Maxima \ A35 \ 2009-7~	BCM		x		
Maxima \ A35 \ 2009-7~	Air bag	x	x	x	
Maxima \ A35 \ 2009-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2009-7~	Transmission	x	x	x	
Maxima \ A35 \ 2009-7~	Multi AV	x	x	x	
Maxima \ A35 \ 2009-7~	IPDM E/R		x	x	
Maxima \ A35 \ 2009-7~	Auto drive position		x	x	
Maxima \ A35 \ 2009-7~	Sonar	x	x	x	
Maxima \ A35 \ 2009-7~	Rearview camera			x	
Maxima \ A35 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2009-8~	Meter/M&A		x	x	
Maxima \ A35 \ 2009-8~	BCM		x		
Maxima \ A35 \ 2009-8~	Air bag	x	x	x	
Maxima \ A35 \ 2009-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2009-8~	Transmission	x	x	x	
Maxima \ A35 \ 2009-8~	Multi AV	x	x	x	

Maxima \ A35 \ 2009-8~	IPDM E/R		x	x	
Maxima \ A35 \ 2009-8~	Auto drive position	x	x	x	
Maxima \ A35 \ 2009-8~	Rearview camera			x	
Maxima \ A35 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2010	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2010	Meter/M&A		x	x	
Maxima \ A35 \ 2010	BCM		x		
Maxima \ A35 \ 2010	Air bag	x	x	x	
Maxima \ A35 \ 2010	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2010	Transmission	x	x	x	
Maxima \ A35 \ 2010	Multi AV	x	x	x	
Maxima \ A35 \ 2010	IPDM E/R		x	x	
Maxima \ A35 \ 2010	Auto drive position	x	x	x	
Maxima \ A35 \ 2010	Rearview camera			x	
Maxima \ A35 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A35 \ 2010-8~	BCM		x		
Maxima \ A35 \ 2010-8~	Air bag	x	x	x	
Maxima \ A35 \ 2010-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2010-8~	Transmission	x	x	x	
Maxima \ A35 \ 2010-8~	Multi AV	x	x	x	
Maxima \ A35 \ 2010-8~	IPDM E/R		x	x	
Maxima \ A35 \ 2010-8~	Auto drive position	x	x	x	
Maxima \ A35 \ 2010-8~	Sonar	x	x	x	
Maxima \ A35 \ 2010-8~	Rearview camera			x	
Maxima \ A35 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2011	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A35 \ 2011	BCM		x		
Maxima \ A35 \ 2011	Air bag	x	x	x	
Maxima \ A35 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2011	Transmission	x	x	x	
Maxima \ A35 \ 2011	Multi AV	x	x	x	
Maxima \ A35 \ 2011	IPDM E/R		x	x	

Maxima \ A35 \ 2011	Auto drive position	x	x	x	
Maxima \ A35 \ 2011	Sonar	x	x	x	
Maxima \ A35 \ 2011	Rearview camera			x	
Maxima \ A35 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2011-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A35 \ 2011-8~	BCM		x		
Maxima \ A35 \ 2011-8~	Air bag	x	x	x	
Maxima \ A35 \ 2011-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2011-8~	Transmission	x	x	x	
Maxima \ A35 \ 2011-8~	Multi AV	x	x	x	
Maxima \ A35 \ 2011-8~	IPDM E/R		x	x	
Maxima \ A35 \ 2011-8~	Auto drive position		x	x	
Maxima \ A35 \ 2011-8~	Sonar	x	x	x	
Maxima \ A35 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2012	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima \ A35 \ 2012	BCM		x		
Maxima \ A35 \ 2012	Air bag	x	x	x	
Maxima \ A35 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2012	Transmission	x	x	x	
Maxima \ A35 \ 2012	Multi AV		x	x	
Maxima \ A35 \ 2012	IPDM E/R		x	x	
Maxima \ A35 \ 2012	Auto drive position		x	x	
Maxima \ A35 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2012-6~	Meter/M&A		x	x	
Maxima \ A35 \ 2012-6~	BCM		x		
Maxima \ A35 \ 2012-6~	Air bag	x	x	x	
Maxima \ A35 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2012-6~	Transmission	x	x	x	
Maxima \ A35 \ 2012-6~	IPDM E/R		x	x	
Maxima \ A35 \ 2012-6~	Auto drive position	x	x	x	
Maxima \ A35 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Maxima \ A35 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2012-8~	Meter/M&A		x	x	
Maxima \ A35 \ 2012-8~	BCM		x		
Maxima \ A35 \ 2012-8~	Air bag	x	x	x	
Maxima \ A35 \ 2012-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2012-8~	Transmission	x	x	x	
Maxima \ A35 \ 2012-8~	Multi AV		x	x	
Maxima \ A35 \ 2012-8~	IPDM E/R		x	x	
Maxima \ A35 \ 2012-8~	Auto drive position	x	x	x	
Maxima \ A35 \ 2012-8~	Sonar	x	x	x	
Maxima \ A35 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2013	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2013	Meter/M&A		x	x	
Maxima \ A35 \ 2013	BCM		x		
Maxima \ A35 \ 2013	Air bag	x	x	x	
Maxima \ A35 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2013	Transmission	x	x	x	
Maxima \ A35 \ 2013	Multi AV		x	x	
Maxima \ A35 \ 2013	IPDM E/R		x	x	
Maxima \ A35 \ 2013	Auto drive position	x	x	x	
Maxima \ A35 \ 2013	Sonar	x	x	x	
Maxima \ A35 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2013-8~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2013-8~	Meter/M&A		x	x	
Maxima \ A35 \ 2013-8~	BCM		x		
Maxima \ A35 \ 2013-8~	Air bag	x	x	x	
Maxima \ A35 \ 2013-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2013-8~	Transmission	x	x	x	
Maxima \ A35 \ 2013-8~	Multi AV	x	x	x	0280
Maxima \ A35 \ 2013-8~	EPS/DAST 3	x	x	x	
Maxima \ A35 \ 2013-8~	IPDM E/R		x	x	
Maxima \ A35 \ 2013-8~	Air pressure monitor	x	x	x	
Maxima \ A35 \ 2013-8~	Auto drive position	x	x	x	
Maxima \ A35 \ 2013-8~	Sonar	x	x	x	
Maxima \ A35 \ 2013-8~	AVM		x	x	

Maxima \ A35 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2014	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2014	Meter/M&A		x	x	
Maxima \ A35 \ 2014	BCM		x		
Maxima \ A35 \ 2014	Air bag	x	x	x	
Maxima \ A35 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2014	Transmission	x	x	x	
Maxima \ A35 \ 2014	Multi AV	x	x	x	0280
Maxima \ A35 \ 2014	EPS/DAST 3	x	x	x	
Maxima \ A35 \ 2014	IPDM E/R		x	x	
Maxima \ A35 \ 2014	Air pressure monitor	x	x	x	
Maxima \ A35 \ 2014	Auto drive position	x	x	x	
Maxima \ A35 \ 2014	Sonar	x	x	x	
Maxima \ A35 \ 2014	AVM		x	x	
Maxima \ A35 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2014-1~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2014-1~	Meter/M&A		x	x	
Maxima \ A35 \ 2014-1~	BCM		x		
Maxima \ A35 \ 2014-1~	Air bag	x	x	x	
Maxima \ A35 \ 2014-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2014-1~	Transmission	x	x	x	
Maxima \ A35 \ 2014-1~	Multi AV	x	x	x	0280
Maxima \ A35 \ 2014-1~	IPDM E/R		x	x	
Maxima \ A35 \ 2014-1~	Auto drive position	x	x	x	
Maxima \ A35 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A35 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
Maxima \ A35 \ 2014-7~	Meter/M&A		x	x	
Maxima \ A35 \ 2014-7~	BCM		x		
Maxima \ A35 \ 2014-7~	Air bag	x	x	x	
Maxima \ A35 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima \ A35 \ 2014-7~	Transmission	x	x	x	
Maxima \ A35 \ 2014-7~	Multi AV	x	x	x	0280
Maxima \ A35 \ 2014-7~	EPS/DAST 3	x	x	x	
Maxima \ A35 \ 2014-7~	IPDM E/R		x	x	
Maxima \ A35 \ 2014-7~	Air pressure monitor	x	x	x	

Maxima \ A35 \ 2014-7~	Auto drive position	x	x	x	
Maxima \ A35 \ 2014-7~	Sonar	x	x	x	
Maxima \ A35 \ 2014-7~	AVM		x	x	
Maxima \ A36 \ 2015-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A36 \ 2015-4~	ABS		x	x	
Maxima \ A36 \ 2015-4~	Meter/M&A		x	x	
Maxima \ A36 \ 2015-4~	BCM		x		
Maxima \ A36 \ 2015-4~	Air bag		x	x	
Maxima \ A36 \ 2015-4~	ICC/ADAS		x	x	
Maxima \ A36 \ 2015-4~	HVAC		x	x	
Maxima \ A36 \ 2015-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Maxima \ A36 \ 2015-4~	Multi AV		x	x	
Maxima \ A36 \ 2015-4~	EPS/DAST 3		x	x	
Maxima \ A36 \ 2015-4~	IPDM E/R		x	x	
Maxima \ A36 \ 2015-4~	Air pressure monitor		x	x	
Maxima \ A36 \ 2015-4~	Laser/radar	x	x	x	
Maxima \ A36 \ 2015-4~	Auto drive position		x	x	
Maxima \ A36 \ 2015-4~	Sonar		x	x	
Maxima \ A36 \ 2015-4~	Side radar left		x	x	
Maxima \ A36 \ 2015-4~	Side radar right		x	x	
Maxima \ A36 \ 2015-4~	AVM		x	x	
Maxima \ A36 \ 2015-4~	Chassis control		x	x	
Maxima \ A36 \ 2015-4~	Head lamp levelizer	x	x	x	
Maxima \ A36 \ 2015-4~	Occupant detection			x	
Maxima \ A36 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A36 \ 2015-6~	ABS		x	x	
Maxima \ A36 \ 2015-6~	Meter/M&A		x	x	
Maxima \ A36 \ 2015-6~	BCM		x		
Maxima \ A36 \ 2015-6~	Air bag		x	x	
Maxima \ A36 \ 2015-6~	ICC/ADAS		x	x	
Maxima \ A36 \ 2015-6~	HVAC		x	x	
Maxima \ A36 \ 2015-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Maxima \ A36 \ 2015-6~	Multi AV		x	x	
Maxima \ A36 \ 2015-6~	EPS/DAST 3		x	x	
Maxima \ A36 \ 2015-6~	IPDM E/R		x	x	
Maxima \ A36 \ 2015-6~	Air pressure monitor		x	x	
Maxima \ A36 \ 2015-6~	Laser/radar	x	x	x	

Maxima \ A36 \ 2015-6~	Auto drive position		x	x	
Maxima \ A36 \ 2015-6~	Sonar		x	x	
Maxima \ A36 \ 2015-6~	Side radar left		x	x	
Maxima \ A36 \ 2015-6~	Side radar right		x	x	
Maxima \ A36 \ 2015-6~	AVM		x	x	
Maxima \ A36 \ 2015-6~	Chassis control		x	x	
Maxima \ A36 \ 2015-6~	Head lamp levelizer	x	x	x	
Maxima \ A36 \ 2015-6~	Occupant detection			x	
Maxima \ A36 \ 2015-6~	ICC/ADAS	x	x	x	
Maxima \ A36 \ 2015-6~	Multi AV	x	x	x	0280
Maxima \ A36 \ 2015-6~	Lane camera		x	x	
Maxima \ A36 \ 2015-6~	Telematics		x	x	0253
Maxima \ A36 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A36 \ 2016	ABS		x	x	
Maxima \ A36 \ 2016	Meter/M&A		x	x	
Maxima \ A36 \ 2016	BCM		x		
Maxima \ A36 \ 2016	Air bag		x	x	
Maxima \ A36 \ 2016	ICC/ADAS		x	x	
Maxima \ A36 \ 2016	HVAC		x	x	
Maxima \ A36 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Maxima \ A36 \ 2016	Multi AV		x	x	
Maxima \ A36 \ 2016	EPS/DAST 3		x	x	
Maxima \ A36 \ 2016	IPDM E/R		x	x	
Maxima \ A36 \ 2016	Air pressure monitor		x	x	
Maxima \ A36 \ 2016	Laser/radar		x	x	
Maxima \ A36 \ 2016	Auto drive position		x	x	
Maxima \ A36 \ 2016	Sonar		x	x	
Maxima \ A36 \ 2016	Side radar left		x	x	
Maxima \ A36 \ 2016	Side radar right		x	x	
Maxima \ A36 \ 2016	Telematics		x	x	0253
Maxima \ A36 \ 2016	AVM		x	x	
Maxima \ A36 \ 2016	Chassis control		x	x	
Maxima \ A36 \ 2016	Head lamp levelizer	x	x	x	
Maxima \ A36 \ 2016	Occupant detection			x	
Maxima \ A36 \ 2016-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A36 \ 2016-5~	ABS		x	x	
Maxima \ A36 \ 2016-5~	Meter/M&A		x	x	
Maxima \ A36 \ 2016-5~	BCM		x		

Maxima \ A36 \ 2016-5~	Air bag		x	x	
Maxima \ A36 \ 2016-5~	ICC/ADAS		x	x	
Maxima \ A36 \ 2016-5~	HVAC		x	x	
Maxima \ A36 \ 2016-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Maxima \ A36 \ 2016-5~	Multi AV	x	x	x	0280
Maxima \ A36 \ 2016-5~	EPS/DAST 3		x	x	
Maxima \ A36 \ 2016-5~	IPDM E/R		x	x	
Maxima \ A36 \ 2016-5~	Laser/radar		x	x	
Maxima \ A36 \ 2016-5~	Auto drive position		x	x	
Maxima \ A36 \ 2016-5~	Sonar		x	x	
Maxima \ A36 \ 2016-5~	Side radar left		x	x	
Maxima \ A36 \ 2016-5~	Side radar right		x	x	
Maxima \ A36 \ 2016-5~	AVM		x	x	
Maxima \ A36 \ 2016-5~	Chassis control		x	x	
Maxima \ A36 \ 2016-5~	Head lamp levelizer	x	x	x	
Maxima \ A36 \ 2016-5~	Occupant detection			x	
Maxima \ A36 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima \ A36 \ 2017	ABS		x	x	
Maxima \ A36 \ 2017	Meter/M&A		x	x	
Maxima \ A36 \ 2017	BCM		x		
Maxima \ A36 \ 2017	Air bag		x	x	
Maxima \ A36 \ 2017	ICC/ADAS		x	x	
Maxima \ A36 \ 2017	HVAC		x	x	
Maxima \ A36 \ 2017	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Maxima \ A36 \ 2017	Multi AV	x	x	x	0280
Maxima \ A36 \ 2017	EPS/DAST 3		x	x	
Maxima \ A36 \ 2017	IPDM E/R		x	x	
Maxima \ A36 \ 2017	Laser/radar		x	x	
Maxima \ A36 \ 2017	Auto drive position		x	x	
Maxima \ A36 \ 2017	Sonar		x	x	
Maxima \ A36 \ 2017	Side radar left		x	x	
Maxima \ A36 \ 2017	Side radar right		x	x	
Maxima \ A36 \ 2017	Telematics		x	x	0253
Maxima \ A36 \ 2017	AVM		x	x	
Maxima \ A36 \ 2017	Chassis control		x	x	
Maxima \ A36 \ 2017	Head lamp levelizer	x	x	x	
Maxima \ A36 \ 2017	Occupant detection			x	

Maxima-Cefiro \ A33 \ 1999-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ A33 \ 1999-1~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ A33 \ 1999-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima-Cefiro \ A33 \ 1999-1~	BCM	x	x		
Maxima-Cefiro \ A33 \ 1999-1~	Air bag	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	ICC/ADAS	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	HVAC	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima-Cefiro \ A33 \ 1999-1~	Multi AV	x	x	x	0280
Maxima-Cefiro \ A33 \ 1999-1~	EPS/DAST 3	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	IPDM E/R	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Air pressure monitor	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima-Cefiro \ A33 \ 1999-1~	DIU	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Auto slide door	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Auto drive position	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	All mode AWD/4WD	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Sonar	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Lane camera	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Adaptive light	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	AVM		x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Difference lock	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Nats immu	x	x		
Maxima-Cefiro \ A33 \ 1999-1~	Smart entrance	x	x		
Maxima-Cefiro \ A33 \ 1999-1~	Air levelizer	x	x	x	
Maxima-Cefiro \ A33 \ 1999-1~	Rearview camera			x	
Maxima-Cefiro \ A33 \ 1999-1~	S/blind camera			x	
Maxima-Cefiro \ A33 \ 1999-1~	Motor assist	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J31 \ 2003-9~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J31 \ 2003-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima-Cefiro \ J31 \ 2003-9~	BCM	x	x		
Maxima-Cefiro \ J31 \ 2003-9~	Air bag	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	ICC/ADAS	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	HVAC	x	x	x	

Maxima-Cefiro \ J31 \ 2003-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima-Cefiro \ J31 \ 2003-9~	Multi AV	x	x	x	0280
Maxima-Cefiro \ J31 \ 2003-9~	EPS/DAST 3	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	IPDM E/R	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Air pressure monitor	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Maxima-Cefiro \ J31 \ 2003-9~	DIU	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Auto slide door	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Auto drive position	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	All mode AWD/4WD	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Sonar	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Lane camera	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Adaptive light	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	AVM		x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Difference lock	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Nats immu	x	x		
Maxima-Cefiro \ J31 \ 2003-9~	Smart entrance	x	x		
Maxima-Cefiro \ J31 \ 2003-9~	Air levelizer	x	x	x	
Maxima-Cefiro \ J31 \ 2003-9~	Rearview camera			x	
Maxima-Cefiro \ J31 \ 2003-9~	S/blind camera			x	
Maxima-Cefiro \ J31 \ 2003-9~	Motor assist	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J31 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J31 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Maxima-Cefiro \ J31 \ 2005-12~	BCM	x	x		
Maxima-Cefiro \ J31 \ 2005-12~	Air bag	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	ICC/ADAS	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	HVAC	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima-Cefiro \ J31 \ 2005-12~	Multi AV	x	x	x	0280
Maxima-Cefiro \ J31 \ 2005-12~	EPS/DAST 3	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	IPDM E/R	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Air pressure monitor	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Maxima-Cefiro \ J31 \ 2005-12~	DIU	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Auto slide door	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Auto drive position	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	All mode AWD/4WD	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Sonar	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Lane camera	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Adaptive light	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	AVM		x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Difference lock	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Nats immu	x	x		
Maxima-Cefiro \ J31 \ 2005-12~	Smart entrance	x	x		
Maxima-Cefiro \ J31 \ 2005-12~	Air levelizer	x	x	x	
Maxima-Cefiro \ J31 \ 2005-12~	Rearview camera			x	
Maxima-Cefiro \ J31 \ 2005-12~	S/blind camera			x	
Maxima-Cefiro \ J31 \ 2005-12~	Motor assist	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J32 \ 2008-2~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J32 \ 2008-2~	Meter/M&A		x	x	
Maxima-Cefiro \ J32 \ 2008-2~	BCM		x		
Maxima-Cefiro \ J32 \ 2008-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima-Cefiro \ J32 \ 2008-2~	Transmission	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Multi AV	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	IPDM E/R		x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Auto drive position		x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Adaptive light	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Air bag	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Sonar	x	x	x	
Maxima-Cefiro \ J32 \ 2008-2~	Rearview camera			x	
Maxima-Cefiro \ J32 \ 2009-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J32 \ 2009-1~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J32 \ 2009-1~	Meter/M&A		x	x	
Maxima-Cefiro \ J32 \ 2009-1~	BCM		x		
Maxima-Cefiro \ J32 \ 2009-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima-Cefiro \ J32 \ 2009-1~	Transmission	x	x	x	

Maxima-Cefiro \ J32 \ 2009-1~	Multi AV	x	x	x	
Maxima-Cefiro \ J32 \ 2009-1~	IPDM E/R		x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Auto drive position		x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Adaptive light	x	x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Air bag	x	x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Sonar	x	x	x	
Maxima-Cefiro \ J32 \ 2009-1~	Rearview camera			x	
Maxima-Cefiro \ J32 \ 2011-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J32 \ 2011-1~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J32 \ 2011-1~	Meter/M&A		x	x	
Maxima-Cefiro \ J32 \ 2011-1~	BCM		x		
Maxima-Cefiro \ J32 \ 2011-1~	HVAC		x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Transmission	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Multi AV	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	IPDM E/R		x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Auto drive position		x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Adaptive light	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Telematics		x	x	0253
Maxima-Cefiro \ J32 \ 2011-1~	Air bag	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Sonar	x	x	x	
Maxima-Cefiro \ J32 \ 2011-1~	Rearview camera			x	
Maxima-Cefiro \ J32 \ 2011-1~	S/blind camera			x	
Maxima-Cefiro \ J32 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Maxima-Cefiro \ J32 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Maxima-Cefiro \ J32 \ 2011-9~	Meter/M&A		x	x	
Maxima-Cefiro \ J32 \ 2011-9~	BCM		x		
Maxima-Cefiro \ J32 \ 2011-9~	Air bag	x	x	x	
Maxima-Cefiro \ J32 \ 2011-9~	ICC/ADAS	x	x	x	
Maxima-Cefiro \ J32 \ 2011-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Maxima-Cefiro \ J32 \ 2011-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Maxima-Cefiro \ J32 \ 2011-9~	Multi AV	x	x	x	0280
Maxima-Cefiro \ J32 \ 2011-9~	EPS/DAST 3	x	x	x	
Maxima-Cefiro \ J32 \ 2011-9~	IPDM E/R		x	x	
Maxima-Cefiro \ J32 \ 2011-9~	Auto drive position		x	x	
Maxima-Cefiro \ J32 \ 2011-9~	All mode AWD/4WD		x	x	
Maxima-Cefiro \ J32 \ 2011-9~	Sonar	x	x	x	

Maxima-Cefiro \ J32 \ 2011-9~	Adaptive light	x	x	x	
Maxima-Cefiro \ J32 \ 2011-9~	Head lamp levelizer	x	x	x	
Maxima-Cefiro \ J32 \ 2011-9~	Occupant detection			x	
Micra active \ K13 \ 2013-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra active \ K13 \ 2013-2~	ABS	x	x	x	0003, 0092, 0264
Micra active \ K13 \ 2013-2~	Meter/M&A		x	x	
Micra active \ K13 \ 2013-2~	BCM		x		
Micra active \ K13 \ 2013-2~	Air bag	x	x	x	
Micra active \ K13 \ 2013-2~	Transmission		x	x	
Micra active \ K13 \ 2013-2~	EPS/DAST 3		x	x	
Micra active \ K13 \ 2013-2~	IPDM E/R		x	x	
Micra active \ K13 \ 2013-2~	BSW/buzzer		x	x	
Micra active \ K13 \ 2013-2~	Occupant detection			x	
Micra C+C \ FK12 \ 2005-9~	Engine	x	x	x	
Micra C+C \ FK12 \ 2005-9~	ABS	x	x	x	
Micra C+C \ FK12 \ 2005-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra C+C \ FK12 \ 2005-9~	BCM	x	x		
Micra C+C \ FK12 \ 2005-9~	Air bag	x	x	x	
Micra C+C \ FK12 \ 2005-9~	Transmission	x	x	x	
Micra C+C \ FK12 \ 2005-9~	EPS/DAST 3	x	x	x	
Micra C+C \ FK12 \ 2005-9~	IPDM E/R	x	x	x	
Micra C+C \ FK12 \ 2005-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra C+C \ FK12 \ 2007-4~	ABS		x	x	
Micra C+C \ FK12 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra C+C \ FK12 \ 2007-4~	BCM	x	x		
Micra C+C \ FK12 \ 2007-4~	Transmission		x	x	
Micra C+C \ FK12 \ 2007-4~	EPS/DAST 3	x	x	x	
Micra C+C \ FK12 \ 2007-4~	IPDM E/R	x	x	x	
Micra C+C \ FK12 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra C+C \ FK12 \ 2007-4~	Engine	x	x	x	
Micra C+C \ FK12 \ 2007-4~	Air bag	x	x	x	
Micra C+C \ FK12 \ 2007-9~	Engine	x	x	x	
Micra C+C \ FK12 \ 2007-9~	ABS	x	x	x	
Micra C+C \ FK12 \ 2007-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra C+C \ FK12 \ 2007-9~	BCM	x	x		
Micra C+C \ FK12 \ 2007-9~	Air bag	x	x	x	

Micra C+C \ FK12 \ 2007-9~	Transmission	x	x	x	
Micra C+C \ FK12 \ 2007-9~	EPS/DAST 3	x	x	x	
Micra C+C \ FK12 \ 2007-9~	IPDM E/R	x	x	x	
Micra C+C \ FK12 \ 2007-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K11 \ 1993-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K11 \ 1993-1~	ABS	x	x	x	0003, 0092, 0264
Micra \ K11 \ 1993-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K11 \ 1993-1~	BCM	x	x		
Micra \ K11 \ 1993-1~	Air bag	x	x	x	
Micra \ K11 \ 1993-1~	ICC/ADAS	x	x	x	
Micra \ K11 \ 1993-1~	HVAC	x	x	x	
Micra \ K11 \ 1993-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Micra \ K11 \ 1993-1~	Multi AV	x	x	x	0280
Micra \ K11 \ 1993-1~	EPS/DAST 3	x	x	x	
Micra \ K11 \ 1993-1~	IPDM E/R	x	x	x	
Micra \ K11 \ 1993-1~	Air pressure monitor	x	x	x	
Micra \ K11 \ 1993-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K11 \ 1993-1~	DIU	x	x	x	
Micra \ K11 \ 1993-1~	Auto slide door	x	x	x	
Micra \ K11 \ 1993-1~	Auto drive position	x	x	x	
Micra \ K11 \ 1993-1~	All mode AWD/4WD	x	x	x	
Micra \ K11 \ 1993-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Micra \ K11 \ 1993-1~	Sonar	x	x	x	
Micra \ K11 \ 1993-1~	Lane camera	x	x	x	
Micra \ K11 \ 1993-1~	Adaptive light	x	x	x	
Micra \ K11 \ 1993-1~	AVM		x	x	
Micra \ K11 \ 1993-1~	Head lamp levelizer	x	x	x	
Micra \ K11 \ 1993-1~	Difference lock	x	x	x	
Micra \ K11 \ 1993-1~	Nats immu	x	x		
Micra \ K11 \ 1993-1~	Smart entrance	x	x		
Micra \ K11 \ 1993-1~	Air levelizer	x	x	x	
Micra \ K11 \ 1993-1~	Rearview camera			x	
Micra \ K11 \ 1993-1~	S/blind camera			x	
Micra \ K11 \ 1993-1~	Motor assist	x	x	x	
Micra \ K11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Micra \ K11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Micra \ K11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K11 \ All Year	BCM	x	x		
Micra \ K11 \ All Year	Air bag	x	x	x	
Micra \ K11 \ All Year	ICC/ADAS	x	x	x	
Micra \ K11 \ All Year	HVAC	x	x	x	
Micra \ K11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Micra \ K11 \ All Year	Multi AV	x	x	x	0280
Micra \ K11 \ All Year	EPS/DAST 3	x	x	x	
Micra \ K11 \ All Year	IPDM E/R	x	x	x	
Micra \ K11 \ All Year	Air pressure monitor	x	x	x	
Micra \ K11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K11 \ All Year	DIU	x	x	x	
Micra \ K11 \ All Year	Auto slide door	x	x	x	
Micra \ K11 \ All Year	Auto drive position	x	x	x	
Micra \ K11 \ All Year	All mode AWD/4WD	x	x	x	
Micra \ K11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Micra \ K11 \ All Year	Sonar	x	x	x	
Micra \ K11 \ All Year	Lane camera	x	x	x	
Micra \ K11 \ All Year	Adaptive light	x	x	x	
Micra \ K11 \ All Year	AVM		x	x	
Micra \ K11 \ All Year	Head lamp levelizer	x	x	x	
Micra \ K11 \ All Year	Difference lock	x	x	x	
Micra \ K11 \ All Year	Nats immu	x	x		
Micra \ K11 \ All Year	Smart entrance	x	x		
Micra \ K11 \ All Year	Air levelizer	x	x	x	
Micra \ K11 \ All Year	Rearview camera			x	
Micra \ K11 \ All Year	S/blind camera			x	
Micra \ K11 \ All Year	Motor assist	x	x	x	
Micra \ K12 \ 2002-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K12 \ 2002-11~	ABS	x	x	x	0003, 0092, 0264
Micra \ K12 \ 2002-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2002-11~	BCM	x	x		
Micra \ K12 \ 2002-11~	Air bag	x	x	x	
Micra \ K12 \ 2002-11~	ICC/ADAS	x	x	x	
Micra \ K12 \ 2002-11~	HVAC	x	x	x	
Micra \ K12 \ 2002-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Micra \ K12 \ 2002-11~	Multi AV	x	x	x	0280

Micra \ K12 \ 2002-11~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2002-11~	IPDM E/R	x	x	x	
Micra \ K12 \ 2002-11~	Air pressure monitor	x	x	x	
Micra \ K12 \ 2002-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2002-11~	DIU	x	x	x	
Micra \ K12 \ 2002-11~	Auto slide door	x	x	x	
Micra \ K12 \ 2002-11~	Auto drive position	x	x	x	
Micra \ K12 \ 2002-11~	All mode AWD/4WD	x	x	x	
Micra \ K12 \ 2002-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Micra \ K12 \ 2002-11~	Sonar	x	x	x	
Micra \ K12 \ 2002-11~	Lane camera	x	x	x	
Micra \ K12 \ 2002-11~	Adaptive light	x	x	x	
Micra \ K12 \ 2002-11~	AVM		x	x	
Micra \ K12 \ 2002-11~	Head lamp levelizer	x	x	x	
Micra \ K12 \ 2002-11~	Difference lock	x	x	x	
Micra \ K12 \ 2002-11~	Nats immu	x	x		
Micra \ K12 \ 2002-11~	Smart entrance	x	x		
Micra \ K12 \ 2002-11~	Air levelizer	x	x	x	
Micra \ K12 \ 2002-11~	Rearview camera			x	
Micra \ K12 \ 2002-11~	S/blind camera			x	
Micra \ K12 \ 2002-11~	Motor assist	x	x	x	
Micra \ K12 \ 2004-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K12 \ 2004-4~	ABS	x	x	x	0003, 0092, 0264
Micra \ K12 \ 2004-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2004-4~	BCM	x	x		
Micra \ K12 \ 2004-4~	Air bag	x	x	x	
Micra \ K12 \ 2004-4~	ICC/ADAS	x	x	x	
Micra \ K12 \ 2004-4~	HVAC	x	x	x	
Micra \ K12 \ 2004-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Micra \ K12 \ 2004-4~	Multi AV	x	x	x	0280
Micra \ K12 \ 2004-4~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2004-4~	IPDM E/R	x	x	x	
Micra \ K12 \ 2004-4~	Air pressure monitor	x	x	x	
Micra \ K12 \ 2004-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2004-4~	DIU	x	x	x	
Micra \ K12 \ 2004-4~	Auto slide door	x	x	x	

Micra \ K12 \ 2004-4~	Auto drive position	x	x	x	
Micra \ K12 \ 2004-4~	All mode AWD/4WD	x	x	x	
Micra \ K12 \ 2004-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Micra \ K12 \ 2004-4~	Sonar	x	x	x	
Micra \ K12 \ 2004-4~	Lane camera	x	x	x	
Micra \ K12 \ 2004-4~	Adaptive light	x	x	x	
Micra \ K12 \ 2004-4~	AVM		x	x	
Micra \ K12 \ 2004-4~	Head lamp levelizer	x	x	x	
Micra \ K12 \ 2004-4~	Difference lock	x	x	x	
Micra \ K12 \ 2004-4~	Nats immu	x	x		
Micra \ K12 \ 2004-4~	Smart entrance	x	x		
Micra \ K12 \ 2004-4~	Air levelizer	x	x	x	
Micra \ K12 \ 2004-4~	Rearview camera			x	
Micra \ K12 \ 2004-4~	S/blind camera			x	
Micra \ K12 \ 2004-4~	Motor assist	x	x	x	
Micra \ K12 \ 2005-5~	Engine	x	x	x	
Micra \ K12 \ 2005-5~	ABS	x	x	x	
Micra \ K12 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2005-5~	BCM	x	x		
Micra \ K12 \ 2005-5~	Air bag	x	x	x	
Micra \ K12 \ 2005-5~	Transmission	x	x	x	
Micra \ K12 \ 2005-5~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2005-5~	IPDM E/R	x	x	x	
Micra \ K12 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2006-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K12 \ 2006-3~	ABS	x	x	x	0003, 0092, 0264
Micra \ K12 \ 2006-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2006-3~	BCM	x	x		
Micra \ K12 \ 2006-3~	Air bag	x	x	x	
Micra \ K12 \ 2006-3~	ICC/ADAS	x	x	x	
Micra \ K12 \ 2006-3~	HVAC	x	x	x	
Micra \ K12 \ 2006-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Micra \ K12 \ 2006-3~	Multi AV	x	x	x	0280
Micra \ K12 \ 2006-3~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2006-3~	IPDM E/R	x	x	x	
Micra \ K12 \ 2006-3~	Air pressure monitor	x	x	x	

Micra \ K12 \ 2006-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2006-3~	DIU	x	x	x	
Micra \ K12 \ 2006-3~	Auto slide door	x	x	x	
Micra \ K12 \ 2006-3~	Auto drive position	x	x	x	
Micra \ K12 \ 2006-3~	All mode AWD/4WD	x	x	x	
Micra \ K12 \ 2006-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Micra \ K12 \ 2006-3~	Sonar	x	x	x	
Micra \ K12 \ 2006-3~	Lane camera	x	x	x	
Micra \ K12 \ 2006-3~	Adaptive light	x	x	x	
Micra \ K12 \ 2006-3~	AVM		x	x	
Micra \ K12 \ 2006-3~	Head lamp levelizer	x	x	x	
Micra \ K12 \ 2006-3~	Difference lock	x	x	x	
Micra \ K12 \ 2006-3~	Nats immu	x	x		
Micra \ K12 \ 2006-3~	Smart entrance	x	x		
Micra \ K12 \ 2006-3~	Air levelizer	x	x	x	
Micra \ K12 \ 2006-3~	Rearview camera			x	
Micra \ K12 \ 2006-3~	S/blind camera			x	
Micra \ K12 \ 2006-3~	Motor assist	x	x	x	
Micra \ K12 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K12 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2007-6~	BCM	x	x		
Micra \ K12 \ 2007-6~	Transmission		x	x	
Micra \ K12 \ 2007-6~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2007-6~	IPDM E/R	x	x	x	
Micra \ K12 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2007-6~	ABS	x	x	x	
Micra \ K12 \ 2007-6~	Air bag	x	x	x	
Micra \ K12 \ 2007-6~	Head lamp levelizer	x	x	x	
Micra \ K12 \ 2007-9~	Engine	x	x	x	
Micra \ K12 \ 2007-9~	ABS	x	x	x	
Micra \ K12 \ 2007-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2007-9~	BCM	x	x		
Micra \ K12 \ 2007-9~	Air bag	x	x	x	
Micra \ K12 \ 2007-9~	Transmission	x	x	x	
Micra \ K12 \ 2007-9~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2007-9~	IPDM E/R	x	x	x	

Micra \ K12 \ 2007-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K12 \ 2008-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K12 \ 2008-5~	BCM	x	x		
Micra \ K12 \ 2008-5~	Transmission		x	x	
Micra \ K12 \ 2008-5~	EPS/DAST 3	x	x	x	
Micra \ K12 \ 2008-5~	IPDM E/R	x	x	x	
Micra \ K12 \ 2008-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Micra \ K12 \ 2008-5~	ABS	x	x	x	
Micra \ K12 \ 2008-5~	Air bag	x	x	x	
Micra \ K12 \ 2008-5~	Head lamp levelizer	x	x	x	
Micra \ K13 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K13 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K13 \ 2010-8~	BCM		x		
Micra \ K13 \ 2010-8~	Air bag	x	x	x	
Micra \ K13 \ 2010-8~	Transmission		x	x	
Micra \ K13 \ 2010-8~	Multi AV	x	x	x	0280
Micra \ K13 \ 2010-8~	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2010-8~	IPDM E/R		x	x	
Micra \ K13 \ 2010-8~	Sonar	x	x	x	
Micra \ K13 \ 2010-8~	Occupant detection			x	
Micra \ K13 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K13 \ 2012-7~	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2012-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K13 \ 2012-7~	BCM		x		
Micra \ K13 \ 2012-7~	Air bag	x	x	x	
Micra \ K13 \ 2012-7~	Transmission		x	x	
Micra \ K13 \ 2012-7~	Multi AV	x	x	x	0280
Micra \ K13 \ 2012-7~	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2012-7~	IPDM E/R		x	x	
Micra \ K13 \ 2012-7~	Sonar	x	x	x	
Micra \ K13 \ 2012-7~	Occupant detection			x	

Micra \ K13 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K13 \ 2013-4~	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2013-4~	Meter/M&A		x	x	
Micra \ K13 \ 2013-4~	BCM		x		
Micra \ K13 \ 2013-4~	Air bag	x	x	x	
Micra \ K13 \ 2013-4~	Transmission		x	x	
Micra \ K13 \ 2013-4~	Multi AV	x	x	x	0280
Micra \ K13 \ 2013-4~	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2013-4~	IPDM E/R		x	x	
Micra \ K13 \ 2013-4~	Sonar	x	x	x	
Micra \ K13 \ 2013-4~	Lane camera		x	x	
Micra \ K13 \ 2013-4~	AVM		x	x	
Micra \ K13 \ 2013-4~	Occupant detection			x	
Micra \ K13 \ 2013-4~	SVT	x	x	x	
Micra \ K13 \ 2013-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K13 \ 2013-6~	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2013-6~	Meter/M&A		x	x	
Micra \ K13 \ 2013-6~	BCM		x		
Micra \ K13 \ 2013-6~	Air bag	x	x	x	
Micra \ K13 \ 2013-6~	Transmission		x	x	
Micra \ K13 \ 2013-6~	Multi AV	x	x	x	0280
Micra \ K13 \ 2013-6~	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2013-6~	IPDM E/R		x	x	
Micra \ K13 \ 2013-6~	Air pressure monitor	x	x	x	
Micra \ K13 \ 2013-6~	Sonar	x	x	x	
Micra \ K13 \ 2013-6~	Occupant detection			x	
Micra \ K13 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Micra \ K13 \ 2015	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2015	Meter/M&A		x	x	
Micra \ K13 \ 2015	BCM		x		
Micra \ K13 \ 2015	Air bag	x	x	x	
Micra \ K13 \ 2015	Transmission		x	x	
Micra \ K13 \ 2015	Multi AV	x	x	x	0280
Micra \ K13 \ 2015	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2015	IPDM E/R		x	x	
Micra \ K13 \ 2015	Occupant detection			x	
Micra \ K13 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Micra \ K13 \ 2016	ABS	x	x	x	0003, 0092, 0264
Micra \ K13 \ 2016	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Micra \ K13 \ 2016	BCM		x		
Micra \ K13 \ 2016	Air bag	x	x	x	
Micra \ K13 \ 2016	Multi AV		x	x	
Micra \ K13 \ 2016	EPS/DAST 3	x	x	x	
Micra \ K13 \ 2016	IPDM E/R		x	x	
Micra \ K13 \ 2016	Occupant detection			x	
Mistral \ R20 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Mistral \ R20 \ All Year	ABS	x	x	x	0003, 0092, 0264
Mistral \ R20 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Mistral \ R20 \ All Year	BCM	x	x		
Mistral \ R20 \ All Year	Air bag	x	x	x	
Mistral \ R20 \ All Year	ICC/ADAS	x	x	x	
Mistral \ R20 \ All Year	HVAC	x	x	x	
Mistral \ R20 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Mistral \ R20 \ All Year	Multi AV	x	x	x	0280
Mistral \ R20 \ All Year	EPS/DAST 3	x	x	x	
Mistral \ R20 \ All Year	IPDM E/R	x	x	x	
Mistral \ R20 \ All Year	Air pressure monitor	x	x	x	
Mistral \ R20 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Mistral \ R20 \ All Year	DIU	x	x	x	
Mistral \ R20 \ All Year	Auto slide door	x	x	x	
Mistral \ R20 \ All Year	Auto drive position	x	x	x	
Mistral \ R20 \ All Year	All mode AWD/4WD	x	x	x	
Mistral \ R20 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Mistral \ R20 \ All Year	Sonar	x	x	x	
Mistral \ R20 \ All Year	Lane camera	x	x	x	
Mistral \ R20 \ All Year	Adaptive light	x	x	x	
Mistral \ R20 \ All Year	AVM		x	x	
Mistral \ R20 \ All Year	Head lamp levelizer	x	x	x	
Mistral \ R20 \ All Year	Difference lock	x	x	x	
Mistral \ R20 \ All Year	Nats immu	x	x		
Mistral \ R20 \ All Year	Smart entrance	x	x		
Mistral \ R20 \ All Year	Air levelizer	x	x	x	
Mistral \ R20 \ All Year	Rearview camera			x	
Mistral \ R20 \ All Year	S/blind camera			x	
Mistral \ R20 \ All Year	Motor assist	x	x	x	

Murano (ZD engine) \ Z51 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano (ZD engine) \ Z51 \ 2010-12~	ABS	x	x	x	0003, 0092, 0264
Murano (ZD engine) \ Z51 \ 2010-12~	Meter/M&A		x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	BCM		x		
Murano (ZD engine) \ Z51 \ 2010-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano (ZD engine) \ Z51 \ 2010-12~	Transmission	x	x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Multi AV	x	x	x	0280
Murano (ZD engine) \ Z51 \ 2010-12~	IPDM E/R		x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Auto drive position		x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	All mode AWD/4WD		x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Auto back door		x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Air bag	x	x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Head lamp levelizer	x	x	x	
Murano (ZD engine) \ Z51 \ 2010-12~	Rearview camera			x	
Murano (ZD engine) \ Z51 \ 2010-12~	S/blind camera			x	
Murano cross cabriolet \ Z51 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano cross cabriolet \ Z51 \ 2011	ABS	x	x	x	0003, 0092, 0264
Murano cross cabriolet \ Z51 \ 2011	Meter/M&A		x	x	
Murano cross cabriolet \ Z51 \ 2011	BCM		x		
Murano cross cabriolet \ Z51 \ 2011	Air bag	x	x	x	
Murano cross cabriolet \ Z51 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano cross cabriolet \ Z51 \ 2011	Transmission	x	x	x	
Murano cross cabriolet \ Z51 \ 2011	Multi AV		x	x	
Murano cross cabriolet \ Z51 \ 2011	IPDM E/R		x	x	
Murano cross cabriolet \ Z51 \ 2011	Convertible roof		x	x	
Murano cross cabriolet \ Z51 \ 2011	Auto drive position		x	x	
Murano cross cabriolet \ Z51 \ 2011	All mode AWD/4WD		x	x	
Murano cross cabriolet \ Z51 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano cross cabriolet \ Z51 \ 2012	ABS	x	x	x	0003, 0092, 0264
Murano cross cabriolet \ Z51 \ 2012	Meter/M&A		x	x	
Murano cross cabriolet \ Z51 \ 2012	BCM		x		
Murano cross cabriolet \ Z51 \ 2012	Air bag	x	x	x	
Murano cross cabriolet \ Z51 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano cross cabriolet \ Z51 \ 2012	Transmission	x	x	x	
Murano cross cabriolet \ Z51 \ 2012	Multi AV		x	x	

Murano cross cabriolet \ Z51 \ 2012	IPDM E/R		x	x	
Murano cross cabriolet \ Z51 \ 2012	Convertible roof		x	x	
Murano cross cabriolet \ Z51 \ 2012	Auto drive position		x	x	
Murano cross cabriolet \ Z51 \ 2012	All mode AWD/4WD		x	x	
Murano cross cabriolet \ Z51 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano cross cabriolet \ Z51 \ 2013	Meter/M&A		x	x	
Murano cross cabriolet \ Z51 \ 2013	BCM		x		
Murano cross cabriolet \ Z51 \ 2013	Air bag		x	x	
Murano cross cabriolet \ Z51 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano cross cabriolet \ Z51 \ 2013	Transmission	x	x	x	
Murano cross cabriolet \ Z51 \ 2013	Multi AV		x	x	
Murano cross cabriolet \ Z51 \ 2013	IPDM E/R		x	x	
Murano cross cabriolet \ Z51 \ 2013	Convertible roof		x	x	
Murano cross cabriolet \ Z51 \ 2013	Auto drive position		x	x	
Murano cross cabriolet \ Z51 \ 2013	All mode AWD/4WD		x	x	
Murano cross cabriolet \ Z51 \ 2013	ABS	x	x	x	
Murano cross cabriolet \ Z51 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano cross cabriolet \ Z51 \ 2014	ABS	x	x	x	0003, 0092, 0264
Murano cross cabriolet \ Z51 \ 2014	Meter/M&A		x	x	
Murano cross cabriolet \ Z51 \ 2014	BCM		x		
Murano cross cabriolet \ Z51 \ 2014	Air bag	x	x	x	
Murano cross cabriolet \ Z51 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano cross cabriolet \ Z51 \ 2014	Transmission	x	x	x	
Murano cross cabriolet \ Z51 \ 2014	Multi AV		x	x	
Murano cross cabriolet \ Z51 \ 2014	IPDM E/R		x	x	
Murano cross cabriolet \ Z51 \ 2014	Convertible roof		x	x	
Murano cross cabriolet \ Z51 \ 2014	Auto drive position		x	x	
Murano cross cabriolet \ Z51 \ 2014	All mode AWD/4WD		x	x	
MURANO Hybrid \ HZ52 \ 2015-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MURANO Hybrid \ HZ52 \ 2015-5~	ABS	x	x	x	
MURANO Hybrid \ HZ52 \ 2015-5~	Meter/M&A		x	x	
MURANO Hybrid \ HZ52 \ 2015-5~	BCM		x		
MURANO Hybrid \ HZ52 \ 2015-5~	Air bag		x	x	
MURANO Hybrid \ HZ52 \ 2015-5~	ICC/ADAS	x	x	x	
MURANO Hybrid \ HZ52 \ 2015-5~	HVAC		x	x	

MURANO Hybrid \ HZ52 \ 2015-5~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
MURANO Hybrid \ HZ52 \ 2015-5~	Multi AV	×	×	×	0280
MURANO Hybrid \ HZ52 \ 2015-5~	Motor control		×	×	0238
MURANO Hybrid \ HZ52 \ 2015-5~	EPS/DAST 3		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	IPDM E/R		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Laser/radar	×	×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Auto drive position		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	All mode AWD/4WD		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Sonar		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Lane camera	×	×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	CAN gateway		×		
MURANO Hybrid \ HZ52 \ 2015-5~	EV/HEV		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Auto back door		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	HV battery		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Side radar left		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	VSP		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Side radar right		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Telematics		×	×	0253
MURANO Hybrid \ HZ52 \ 2015-5~	AVM		×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Head lamp levelizer	×	×	×	
MURANO Hybrid \ HZ52 \ 2015-5~	Occupant detection			×	
MURANO Hybrid \ HZ52 \ 2016-1~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MURANO Hybrid \ HZ52 \ 2016-1~	ABS	×	×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Meter/M&A		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	BCM		×		
MURANO Hybrid \ HZ52 \ 2016-1~	Air bag		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	ICC/ADAS	×	×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	HVAC		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Transmission		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Multi AV		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Motor control		×	×	0238
MURANO Hybrid \ HZ52 \ 2016-1~	EPS/DAST 3		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	IPDM E/R		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Air pressure monitor		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Laser/radar	×	×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Preocrash seatbelt		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Auto drive position		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	All mode AWD/4WD		×	×	
MURANO Hybrid \ HZ52 \ 2016-1~	Sonar		×	×	

MURANO Hybrid \ HZ52 \ 2016-1~	CAN gateway		x		
MURANO Hybrid \ HZ52 \ 2016-1~	EV/HEV		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	Auto back door		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	HV battery		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	Side radar left		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	VSP		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	Side radar right		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	AVM		x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	Head lamp levelizer	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-1~	Occupant detection			x	
MURANO Hybrid \ HZ52 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MURANO Hybrid \ HZ52 \ 2016-3~	ABS	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Meter/M&A	x	x	x	0143, 0197, 0331
MURANO Hybrid \ HZ52 \ 2016-3~	BCM		x		
MURANO Hybrid \ HZ52 \ 2016-3~	Air bag		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	ICC/ADAS	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	HVAC		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
MURANO Hybrid \ HZ52 \ 2016-3~	Multi AV	x	x	x	0280
MURANO Hybrid \ HZ52 \ 2016-3~	Motor control		x	x	0238
MURANO Hybrid \ HZ52 \ 2016-3~	EPS/DAST 3		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	IPDM E/R		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Air pressure monitor		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Laser/radar	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Precrash seatbelt		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Auto drive position		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	All mode AWD/4WD		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Sonar		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	CAN gateway		x		
MURANO Hybrid \ HZ52 \ 2016-3~	EV/HEV		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Auto back door		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	HV battery		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Brake		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Side radar left		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	VSP		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Side radar right		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	PTC heater		x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Telematics		x	x	0253
MURANO Hybrid \ HZ52 \ 2016-3~	AVM		x	x	

MURANO Hybrid \ HZ52 \ 2016-3~	Head lamp levelizer	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-3~	Occupant detection			x	
MURANO Hybrid \ HZ52 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MURANO Hybrid \ HZ52 \ 2016-4~	ABS	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Meter/M&A		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	BCM		x		
MURANO Hybrid \ HZ52 \ 2016-4~	Air bag		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	ICC/ADAS	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	HVAC		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Transmission		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Multi AV		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Motor control		x	x	0238
MURANO Hybrid \ HZ52 \ 2016-4~	EPS/DAST 3		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	IPDM E/R		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Air pressure monitor		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Laser/radar	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Precrash seatbelt		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Auto drive position		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	All mode AWD/4WD		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Sonar		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	CAN gateway		x		
MURANO Hybrid \ HZ52 \ 2016-4~	EV/HEV		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Auto back door		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	HV battery		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Side radar left		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	VSP		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Side radar right		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	AVM		x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Head lamp levelizer	x	x	x	
MURANO Hybrid \ HZ52 \ 2016-4~	Occupant detection			x	
MURANO Hybrid \ Z52 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
MURANO Hybrid \ Z52 \ 2016	ABS	x	x	x	
MURANO Hybrid \ Z52 \ 2016	Meter/M&A		x	x	
MURANO Hybrid \ Z52 \ 2016	BCM		x		
MURANO Hybrid \ Z52 \ 2016	Air bag		x	x	
MURANO Hybrid \ Z52 \ 2016	ICC/ADAS	x	x	x	
MURANO Hybrid \ Z52 \ 2016	HVAC		x	x	
MURANO Hybrid \ Z52 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150

MURANO Hybrid \ Z52 \ 2016	Multi AV		x	x	
MURANO Hybrid \ Z52 \ 2016	Motor control		x	x	0238
MURANO Hybrid \ Z52 \ 2016	EPS/DAST 3		x	x	
MURANO Hybrid \ Z52 \ 2016	IPDM E/R		x	x	
MURANO Hybrid \ Z52 \ 2016	Laser/radar		x	x	
MURANO Hybrid \ Z52 \ 2016	Auto drive position		x	x	
MURANO Hybrid \ Z52 \ 2016	All mode AWD/4WD		x	x	
MURANO Hybrid \ Z52 \ 2016	Sonar		x	x	
MURANO Hybrid \ Z52 \ 2016	CAN gateway		x		
MURANO Hybrid \ Z52 \ 2016	EV/HEV		x	x	
MURANO Hybrid \ Z52 \ 2016	Auto back door		x	x	
MURANO Hybrid \ Z52 \ 2016	HV battery		x	x	
MURANO Hybrid \ Z52 \ 2016	Side radar left		x	x	
MURANO Hybrid \ Z52 \ 2016	VSP		x	x	
MURANO Hybrid \ Z52 \ 2016	Side radar right		x	x	
MURANO Hybrid \ Z52 \ 2016	Telematics		x	x	0253
MURANO Hybrid \ Z52 \ 2016	AVM		x	x	
MURANO Hybrid \ Z52 \ 2016	Occupant detection			x	
Murano \ Z50 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2003	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2003	BCM	x	x		
Murano \ Z50 \ 2003	Air bag	x	x	x	
Murano \ Z50 \ 2003	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2003	HVAC	x	x	x	
Murano \ Z50 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2003	Multi AV	x	x	x	0280
Murano \ Z50 \ 2003	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2003	IPDM E/R	x	x	x	
Murano \ Z50 \ 2003	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2003	DIU	x	x	x	
Murano \ Z50 \ 2003	Auto slide door	x	x	x	
Murano \ Z50 \ 2003	Auto drive position	x	x	x	
Murano \ Z50 \ 2003	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2003	Sonar	x	x	x	
Murano \ Z50 \ 2003	Lane camera	x	x	x	

Murano \ Z50 \ 2003	Adaptive light	x	x	x	
Murano \ Z50 \ 2003	AVM		x	x	
Murano \ Z50 \ 2003	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2003	Difference lock	x	x	x	
Murano \ Z50 \ 2003	Nats immu	x	x		
Murano \ Z50 \ 2003	Smart entrance	x	x		
Murano \ Z50 \ 2003	Air levelizer	x	x	x	
Murano \ Z50 \ 2003	Rearview camera			x	
Murano \ Z50 \ 2003	S/blind camera			x	
Murano \ Z50 \ 2003	Motor assist	x	x	x	
Murano \ Z50 \ 2003-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2003-3~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2003-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2003-3~	BCM	x	x		
Murano \ Z50 \ 2003-3~	Air bag	x	x	x	
Murano \ Z50 \ 2003-3~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2003-3~	HVAC	x	x	x	
Murano \ Z50 \ 2003-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2003-3~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2003-3~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2003-3~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2003-3~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2003-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2003-3~	DIU	x	x	x	
Murano \ Z50 \ 2003-3~	Auto slide door	x	x	x	
Murano \ Z50 \ 2003-3~	Auto drive position	x	x	x	
Murano \ Z50 \ 2003-3~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2003-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2003-3~	Sonar	x	x	x	
Murano \ Z50 \ 2003-3~	Lane camera	x	x	x	
Murano \ Z50 \ 2003-3~	Adaptive light	x	x	x	
Murano \ Z50 \ 2003-3~	AVM		x	x	
Murano \ Z50 \ 2003-3~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2003-3~	Difference lock	x	x	x	
Murano \ Z50 \ 2003-3~	Nats immu	x	x		
Murano \ Z50 \ 2003-3~	Smart entrance	x	x		
Murano \ Z50 \ 2003-3~	Air levelizer	x	x	x	
Murano \ Z50 \ 2003-3~	Rearview camera			x	

Murano \ Z50 \ 2003-3~	S/blind camera			x	
Murano \ Z50 \ 2003-3~	Motor assist	x	x	x	
Murano \ Z50 \ 2003-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2003-4~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2003-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2003-4~	BCM	x	x		
Murano \ Z50 \ 2003-4~	Air bag	x	x	x	
Murano \ Z50 \ 2003-4~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2003-4~	HVAC	x	x	x	
Murano \ Z50 \ 2003-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2003-4~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2003-4~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2003-4~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2003-4~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2003-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2003-4~	DIU	x	x	x	
Murano \ Z50 \ 2003-4~	Auto slide door	x	x	x	
Murano \ Z50 \ 2003-4~	Auto drive position	x	x	x	
Murano \ Z50 \ 2003-4~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2003-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2003-4~	Sonar	x	x	x	
Murano \ Z50 \ 2003-4~	Lane camera	x	x	x	
Murano \ Z50 \ 2003-4~	Adaptive light	x	x	x	
Murano \ Z50 \ 2003-4~	AVM		x	x	
Murano \ Z50 \ 2003-4~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2003-4~	Difference lock	x	x	x	
Murano \ Z50 \ 2003-4~	Nats immu	x	x		
Murano \ Z50 \ 2003-4~	Smart entrance	x	x		
Murano \ Z50 \ 2003-4~	Air levelizer	x	x	x	
Murano \ Z50 \ 2003-4~	Rearview camera			x	
Murano \ Z50 \ 2003-4~	S/blind camera			x	
Murano \ Z50 \ 2003-4~	Motor assist	x	x	x	
Murano \ Z50 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2004	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2004	BCM	x	x		
Murano \ Z50 \ 2004	Air bag	x	x	x	

Murano \ Z50 \ 2004	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2004	HVAC	x	x	x	
Murano \ Z50 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2004	Multi AV	x	x	x	0280
Murano \ Z50 \ 2004	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2004	IPDM E/R	x	x	x	
Murano \ Z50 \ 2004	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2004	DIU	x	x	x	
Murano \ Z50 \ 2004	Auto slide door	x	x	x	
Murano \ Z50 \ 2004	Auto drive position	x	x	x	
Murano \ Z50 \ 2004	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2004	Sonar	x	x	x	
Murano \ Z50 \ 2004	Lane camera	x	x	x	
Murano \ Z50 \ 2004	Adaptive light	x	x	x	
Murano \ Z50 \ 2004	AVM		x	x	
Murano \ Z50 \ 2004	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2004	Difference lock	x	x	x	
Murano \ Z50 \ 2004	Nats immu	x	x		
Murano \ Z50 \ 2004	Smart entrance	x	x		
Murano \ Z50 \ 2004	Air levelizer	x	x	x	
Murano \ Z50 \ 2004	Rearview camera			x	
Murano \ Z50 \ 2004	S/blind camera			x	
Murano \ Z50 \ 2004	Motor assist	x	x	x	
Murano \ Z50 \ 2004-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2004-11~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2004-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2004-11~	BCM	x	x		
Murano \ Z50 \ 2004-11~	Air bag	x	x	x	
Murano \ Z50 \ 2004-11~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2004-11~	HVAC	x	x	x	
Murano \ Z50 \ 2004-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2004-11~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2004-11~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2004-11~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2004-11~	Air pressure monitor	x	x	x	

Murano \ Z50 \ 2004-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2004-11~	DIU	x	x	x	
Murano \ Z50 \ 2004-11~	Auto slide door	x	x	x	
Murano \ Z50 \ 2004-11~	Auto drive position	x	x	x	
Murano \ Z50 \ 2004-11~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2004-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2004-11~	Sonar	x	x	x	
Murano \ Z50 \ 2004-11~	Lane camera	x	x	x	
Murano \ Z50 \ 2004-11~	Adaptive light	x	x	x	
Murano \ Z50 \ 2004-11~	AVM		x	x	
Murano \ Z50 \ 2004-11~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2004-11~	Difference lock	x	x	x	
Murano \ Z50 \ 2004-11~	Nats immu	x	x		
Murano \ Z50 \ 2004-11~	Smart entrance	x	x		
Murano \ Z50 \ 2004-11~	Air levelizer	x	x	x	
Murano \ Z50 \ 2004-11~	Rearview camera			x	
Murano \ Z50 \ 2004-11~	S/blind camera			x	
Murano \ Z50 \ 2004-11~	Motor assist	x	x	x	
Murano \ Z50 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2004-9~	BCM	x	x		
Murano \ Z50 \ 2004-9~	Air bag	x	x	x	
Murano \ Z50 \ 2004-9~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2004-9~	HVAC	x	x	x	
Murano \ Z50 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2004-9~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2004-9~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2004-9~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2004-9~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2004-9~	DIU	x	x	x	
Murano \ Z50 \ 2004-9~	Auto slide door	x	x	x	
Murano \ Z50 \ 2004-9~	Auto drive position	x	x	x	
Murano \ Z50 \ 2004-9~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Murano \ Z50 \ 2004-9~	Sonar	x	x	x	
Murano \ Z50 \ 2004-9~	Lane camera	x	x	x	
Murano \ Z50 \ 2004-9~	Adaptive light	x	x	x	
Murano \ Z50 \ 2004-9~	AVM		x	x	
Murano \ Z50 \ 2004-9~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2004-9~	Difference lock	x	x	x	
Murano \ Z50 \ 2004-9~	Nats immu	x	x		
Murano \ Z50 \ 2004-9~	Smart entrance	x	x		
Murano \ Z50 \ 2004-9~	Air levelizer	x	x	x	
Murano \ Z50 \ 2004-9~	Rearview camera			x	
Murano \ Z50 \ 2004-9~	S/blind camera			x	
Murano \ Z50 \ 2004-9~	Motor assist	x	x	x	
Murano \ Z50 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2005	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2005	BCM	x	x		
Murano \ Z50 \ 2005	Air bag	x	x	x	
Murano \ Z50 \ 2005	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2005	HVAC	x	x	x	
Murano \ Z50 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2005	Multi AV	x	x	x	0280
Murano \ Z50 \ 2005	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2005	IPDM E/R	x	x	x	
Murano \ Z50 \ 2005	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2005	DIU	x	x	x	
Murano \ Z50 \ 2005	Auto slide door	x	x	x	
Murano \ Z50 \ 2005	Auto drive position	x	x	x	
Murano \ Z50 \ 2005	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2005	Sonar	x	x	x	
Murano \ Z50 \ 2005	Lane camera	x	x	x	
Murano \ Z50 \ 2005	Adaptive light	x	x	x	
Murano \ Z50 \ 2005	AVM		x	x	
Murano \ Z50 \ 2005	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2005	Difference lock	x	x	x	
Murano \ Z50 \ 2005	Nats immu	x	x		
Murano \ Z50 \ 2005	Smart entrance	x	x		

Murano \ Z50 \ 2005	Air levelizer	x	x	x	
Murano \ Z50 \ 2005	Rearview camera			x	
Murano \ Z50 \ 2005	S/blind camera			x	
Murano \ Z50 \ 2005	Motor assist	x	x	x	
Murano \ Z50 \ 2005-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2005-11~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2005-11~	BCM	x	x		
Murano \ Z50 \ 2005-11~	Air bag	x	x	x	
Murano \ Z50 \ 2005-11~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2005-11~	HVAC	x	x	x	
Murano \ Z50 \ 2005-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2005-11~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2005-11~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2005-11~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2005-11~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2005-11~	DIU	x	x	x	
Murano \ Z50 \ 2005-11~	Auto slide door	x	x	x	
Murano \ Z50 \ 2005-11~	Auto drive position	x	x	x	
Murano \ Z50 \ 2005-11~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2005-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2005-11~	Sonar	x	x	x	
Murano \ Z50 \ 2005-11~	Lane camera	x	x	x	
Murano \ Z50 \ 2005-11~	Adaptive light	x	x	x	
Murano \ Z50 \ 2005-11~	AVM		x	x	
Murano \ Z50 \ 2005-11~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2005-11~	Difference lock	x	x	x	
Murano \ Z50 \ 2005-11~	Nats immu	x	x		
Murano \ Z50 \ 2005-11~	Smart entrance	x	x		
Murano \ Z50 \ 2005-11~	Air levelizer	x	x	x	
Murano \ Z50 \ 2005-11~	Rearview camera			x	
Murano \ Z50 \ 2005-11~	S/blind camera			x	
Murano \ Z50 \ 2005-11~	Motor assist	x	x	x	
Murano \ Z50 \ 2005-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2005-5~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Murano \ Z50 \ 2005-5~	BCM	x	x		
Murano \ Z50 \ 2005-5~	Air bag	x	x	x	
Murano \ Z50 \ 2005-5~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2005-5~	HVAC	x	x	x	
Murano \ Z50 \ 2005-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2005-5~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2005-5~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2005-5~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2005-5~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2005-5~	DIU	x	x	x	
Murano \ Z50 \ 2005-5~	Auto slide door	x	x	x	
Murano \ Z50 \ 2005-5~	Auto drive position	x	x	x	
Murano \ Z50 \ 2005-5~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2005-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2005-5~	Sonar	x	x	x	
Murano \ Z50 \ 2005-5~	Lane camera	x	x	x	
Murano \ Z50 \ 2005-5~	Adaptive light	x	x	x	
Murano \ Z50 \ 2005-5~	AVM		x	x	
Murano \ Z50 \ 2005-5~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2005-5~	Difference lock	x	x	x	
Murano \ Z50 \ 2005-5~	Nats immu	x	x		
Murano \ Z50 \ 2005-5~	Smart entrance	x	x		
Murano \ Z50 \ 2005-5~	Air levelizer	x	x	x	
Murano \ Z50 \ 2005-5~	Rearview camera			x	
Murano \ Z50 \ 2005-5~	S/blind camera			x	
Murano \ Z50 \ 2005-5~	Motor assist	x	x	x	
Murano \ Z50 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2006	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2006	BCM	x	x		
Murano \ Z50 \ 2006	Air bag	x	x	x	
Murano \ Z50 \ 2006	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2006	HVAC	x	x	x	
Murano \ Z50 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2006	Multi AV	x	x	x	0280
Murano \ Z50 \ 2006	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2006	IPDM E/R	x	x	x	

Murano \ Z50 \ 2006	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2006	DIU	x	x	x	
Murano \ Z50 \ 2006	Auto slide door	x	x	x	
Murano \ Z50 \ 2006	Auto drive position	x	x	x	
Murano \ Z50 \ 2006	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2006	Sonar	x	x	x	
Murano \ Z50 \ 2006	Lane camera	x	x	x	
Murano \ Z50 \ 2006	Adaptive light	x	x	x	
Murano \ Z50 \ 2006	AVM		x	x	
Murano \ Z50 \ 2006	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2006	Difference lock	x	x	x	
Murano \ Z50 \ 2006	Nats immu	x	x		
Murano \ Z50 \ 2006	Smart entrance	x	x		
Murano \ Z50 \ 2006	Air levelizer	x	x	x	
Murano \ Z50 \ 2006	Rearview camera			x	
Murano \ Z50 \ 2006	S/blind camera			x	
Murano \ Z50 \ 2006	Motor assist	x	x	x	
Murano \ Z50 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2006-12~	BCM	x	x		
Murano \ Z50 \ 2006-12~	Air bag	x	x	x	
Murano \ Z50 \ 2006-12~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2006-12~	HVAC	x	x	x	
Murano \ Z50 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2006-12~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2006-12~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2006-12~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2006-12~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2006-12~	DIU	x	x	x	
Murano \ Z50 \ 2006-12~	Auto slide door	x	x	x	
Murano \ Z50 \ 2006-12~	Auto drive position	x	x	x	
Murano \ Z50 \ 2006-12~	All mode AWD/4WD	x	x	x	

Murano \ Z50 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2006-12~	Sonar	x	x	x	
Murano \ Z50 \ 2006-12~	Lane camera	x	x	x	
Murano \ Z50 \ 2006-12~	Adaptive light	x	x	x	
Murano \ Z50 \ 2006-12~	AVM		x	x	
Murano \ Z50 \ 2006-12~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2006-12~	Difference lock	x	x	x	
Murano \ Z50 \ 2006-12~	Nats immu	x	x		
Murano \ Z50 \ 2006-12~	Smart entrance	x	x		
Murano \ Z50 \ 2006-12~	Air levelizer	x	x	x	
Murano \ Z50 \ 2006-12~	Rearview camera			x	
Murano \ Z50 \ 2006-12~	S/blind camera			x	
Murano \ Z50 \ 2006-12~	Motor assist	x	x	x	
Murano \ Z50 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2007	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2007	BCM	x	x		
Murano \ Z50 \ 2007	Air bag	x	x	x	
Murano \ Z50 \ 2007	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2007	HVAC	x	x	x	
Murano \ Z50 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2007	Multi AV	x	x	x	0280
Murano \ Z50 \ 2007	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2007	IPDM E/R	x	x	x	
Murano \ Z50 \ 2007	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2007	DIU	x	x	x	
Murano \ Z50 \ 2007	Auto slide door	x	x	x	
Murano \ Z50 \ 2007	Auto drive position	x	x	x	
Murano \ Z50 \ 2007	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2007	Sonar	x	x	x	
Murano \ Z50 \ 2007	Lane camera	x	x	x	
Murano \ Z50 \ 2007	Adaptive light	x	x	x	
Murano \ Z50 \ 2007	AVM		x	x	
Murano \ Z50 \ 2007	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2007	Difference lock	x	x	x	
Murano \ Z50 \ 2007	Nats immu	x	x		

Murano \ Z50 \ 2007	Smart entrance	x	x		
Murano \ Z50 \ 2007	Air levelizer	x	x	x	
Murano \ Z50 \ 2007	Rearview camera			x	
Murano \ Z50 \ 2007	S/blind camera			x	
Murano \ Z50 \ 2007	Motor assist	x	x	x	
Murano \ Z50 \ 2007-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2007-3~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z50 \ 2007-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2007-3~	BCM	x	x		
Murano \ Z50 \ 2007-3~	Air bag	x	x	x	
Murano \ Z50 \ 2007-3~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2007-3~	HVAC	x	x	x	
Murano \ Z50 \ 2007-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2007-3~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2007-3~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2007-3~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2007-3~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2007-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2007-3~	DIU	x	x	x	
Murano \ Z50 \ 2007-3~	Auto slide door	x	x	x	
Murano \ Z50 \ 2007-3~	Auto drive position	x	x	x	
Murano \ Z50 \ 2007-3~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2007-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2007-3~	Sonar	x	x	x	
Murano \ Z50 \ 2007-3~	Lane camera	x	x	x	
Murano \ Z50 \ 2007-3~	Adaptive light	x	x	x	
Murano \ Z50 \ 2007-3~	AVM		x	x	
Murano \ Z50 \ 2007-3~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2007-3~	Difference lock	x	x	x	
Murano \ Z50 \ 2007-3~	Nats immu	x	x		
Murano \ Z50 \ 2007-3~	Smart entrance	x	x		
Murano \ Z50 \ 2007-3~	Air levelizer	x	x	x	
Murano \ Z50 \ 2007-3~	Rearview camera			x	
Murano \ Z50 \ 2007-3~	S/blind camera			x	
Murano \ Z50 \ 2007-3~	Motor assist	x	x	x	
Murano \ Z50 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z50 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264

Murano \ Z50 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Murano \ Z50 \ 2007-5~	BCM	x	x		
Murano \ Z50 \ 2007-5~	Air bag	x	x	x	
Murano \ Z50 \ 2007-5~	ICC/ADAS	x	x	x	
Murano \ Z50 \ 2007-5~	HVAC	x	x	x	
Murano \ Z50 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z50 \ 2007-5~	Multi AV	x	x	x	0280
Murano \ Z50 \ 2007-5~	EPS/DAST 3	x	x	x	
Murano \ Z50 \ 2007-5~	IPDM E/R	x	x	x	
Murano \ Z50 \ 2007-5~	Air pressure monitor	x	x	x	
Murano \ Z50 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Murano \ Z50 \ 2007-5~	DIU	x	x	x	
Murano \ Z50 \ 2007-5~	Auto slide door	x	x	x	
Murano \ Z50 \ 2007-5~	Auto drive position	x	x	x	
Murano \ Z50 \ 2007-5~	All mode AWD/4WD	x	x	x	
Murano \ Z50 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Murano \ Z50 \ 2007-5~	Sonar	x	x	x	
Murano \ Z50 \ 2007-5~	Lane camera	x	x	x	
Murano \ Z50 \ 2007-5~	Adaptive light	x	x	x	
Murano \ Z50 \ 2007-5~	AVM		x	x	
Murano \ Z50 \ 2007-5~	Head lamp levelizer	x	x	x	
Murano \ Z50 \ 2007-5~	Difference lock	x	x	x	
Murano \ Z50 \ 2007-5~	Nats immu	x	x		
Murano \ Z50 \ 2007-5~	Smart entrance	x	x		
Murano \ Z50 \ 2007-5~	Air levelizer	x	x	x	
Murano \ Z50 \ 2007-5~	Rearview camera			x	
Murano \ Z50 \ 2007-5~	S/blind camera			x	
Murano \ Z50 \ 2007-5~	Motor assist	x	x	x	
Murano \ Z51 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2007-10~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2007-10~	Meter/M&A		x	x	
Murano \ Z51 \ 2007-10~	BCM		x		
Murano \ Z51 \ 2007-10~	Air bag	x	x	x	
Murano \ Z51 \ 2007-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2007-10~	Transmission	x	x	x	
Murano \ Z51 \ 2007-10~	Multi AV	x	x	x	
Murano \ Z51 \ 2007-10~	IPDM E/R		x	x	

Murano \ Z51 \ 2007-10~	Auto drive position	x	x	x	
Murano \ Z51 \ 2007-10~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2007-10~	Auto back door		x	x	
Murano \ Z51 \ 2007-10~	Rearview camera			x	
Murano \ Z51 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2008-10~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2008-10~	Meter/M&A		x	x	
Murano \ Z51 \ 2008-10~	BCM		x		
Murano \ Z51 \ 2008-10~	Air bag	x	x	x	
Murano \ Z51 \ 2008-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2008-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z51 \ 2008-10~	Multi AV	x	x	x	
Murano \ Z51 \ 2008-10~	IPDM E/R		x	x	
Murano \ Z51 \ 2008-10~	Auto drive position		x	x	
Murano \ Z51 \ 2008-10~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2008-10~	Auto back door		x	x	
Murano \ Z51 \ 2008-10~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2008-10~	Sonar	x	x	x	
Murano \ Z51 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2008-12~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2008-12~	Meter/M&A		x	x	
Murano \ Z51 \ 2008-12~	BCM		x		
Murano \ Z51 \ 2008-12~	Air bag	x	x	x	
Murano \ Z51 \ 2008-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2008-12~	Transmission	x	x	x	
Murano \ Z51 \ 2008-12~	Multi AV	x	x	x	
Murano \ Z51 \ 2008-12~	IPDM E/R		x	x	
Murano \ Z51 \ 2008-12~	Auto drive position		x	x	
Murano \ Z51 \ 2008-12~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2008-12~	Auto back door		x	x	
Murano \ Z51 \ 2008-12~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2008-12~	Sonar	x	x	x	
Murano \ Z51 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2008-6~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2008-6~	Meter/M&A		x	x	
Murano \ Z51 \ 2008-6~	BCM		x		

Murano \ Z51 \ 2008-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2008-6~	Transmission	x	x	x	
Murano \ Z51 \ 2008-6~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2008-6~	IPDM E/R		x	x	
Murano \ Z51 \ 2008-6~	Auto drive position		x	x	
Murano \ Z51 \ 2008-6~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2008-6~	Auto back door		x	x	
Murano \ Z51 \ 2008-6~	Air bag	x	x	x	
Murano \ Z51 \ 2008-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z51 \ 2008-6~	Multi AV	x	x	x	
Murano \ Z51 \ 2008-6~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2008-6~	Sonar	x	x	x	
Murano \ Z51 \ 2008-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2008-8~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2008-8~	Meter/M&A		x	x	
Murano \ Z51 \ 2008-8~	BCM		x		
Murano \ Z51 \ 2008-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2008-8~	Transmission	x	x	x	
Murano \ Z51 \ 2008-8~	Multi AV	x	x	x	
Murano \ Z51 \ 2008-8~	IPDM E/R		x	x	
Murano \ Z51 \ 2008-8~	Auto drive position		x	x	
Murano \ Z51 \ 2008-8~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2008-8~	Auto back door		x	x	
Murano \ Z51 \ 2008-8~	Air bag	x	x	x	
Murano \ Z51 \ 2008-8~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2008-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z51 \ 2008-8~	Sonar	x	x	x	
Murano \ Z51 \ 2008-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2008-9~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2008-9~	Meter/M&A		x	x	
Murano \ Z51 \ 2008-9~	BCM		x		
Murano \ Z51 \ 2008-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2008-9~	Transmission	x	x	x	
Murano \ Z51 \ 2008-9~	Multi AV	x	x	x	
Murano \ Z51 \ 2008-9~	IPDM E/R		x	x	
Murano \ Z51 \ 2008-9~	Auto drive position		x	x	

Murano \ Z51 \ 2008-9~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2008-9~	Auto back door		x	x	
Murano \ Z51 \ 2008-9~	Air bag	x	x	x	
Murano \ Z51 \ 2008-9~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2008-9~	Sonar	x	x	x	
Murano \ Z51 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2009	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2009	Meter/M&A		x	x	
Murano \ Z51 \ 2009	BCM		x		
Murano \ Z51 \ 2009	Air bag	x	x	x	
Murano \ Z51 \ 2009	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2009	Transmission	x	x	x	
Murano \ Z51 \ 2009	Multi AV	x	x	x	
Murano \ Z51 \ 2009	IPDM E/R		x	x	
Murano \ Z51 \ 2009	Auto drive position	x	x	x	
Murano \ Z51 \ 2009	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2009	Auto back door		x	x	
Murano \ Z51 \ 2009	Rearview camera			x	
Murano \ Z51 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2010	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2010	Meter/M&A		x	x	
Murano \ Z51 \ 2010	BCM		x		
Murano \ Z51 \ 2010	Air bag	x	x	x	
Murano \ Z51 \ 2010	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2010	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z51 \ 2010	Multi AV	x	x	x	
Murano \ Z51 \ 2010	IPDM E/R		x	x	
Murano \ Z51 \ 2010	Auto drive position	x	x	x	
Murano \ Z51 \ 2010	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2010	Auto back door		x	x	
Murano \ Z51 \ 2010	Rearview camera			x	
Murano \ Z51 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2010-2~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2010-2~	Meter/M&A		x	x	
Murano \ Z51 \ 2010-2~	BCM		x		

Murano \ Z51 \ 2010-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2010-2~	Transmission	x	x	x	
Murano \ Z51 \ 2010-2~	Multi AV	x	x	x	
Murano \ Z51 \ 2010-2~	IPDM E/R		x	x	
Murano \ Z51 \ 2010-2~	Auto drive position		x	x	
Murano \ Z51 \ 2010-2~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2010-2~	Auto back door		x	x	
Murano \ Z51 \ 2010-2~	Air bag	x	x	x	
Murano \ Z51 \ 2010-2~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2010-2~	Sonar	x	x	x	
Murano \ Z51 \ 2010-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2010-5~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2010-5~	Meter/M&A		x	x	
Murano \ Z51 \ 2010-5~	BCM		x		
Murano \ Z51 \ 2010-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2010-5~	Transmission	x	x	x	
Murano \ Z51 \ 2010-5~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2010-5~	IPDM E/R		x	x	
Murano \ Z51 \ 2010-5~	Auto drive position		x	x	
Murano \ Z51 \ 2010-5~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2010-5~	Auto back door		x	x	
Murano \ Z51 \ 2010-5~	Air bag	x	x	x	
Murano \ Z51 \ 2010-5~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2010-5~	Rearview camera			x	
Murano \ Z51 \ 2010-5~	S/blind camera			x	
Murano \ Z51 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2010-8~	Meter/M&A		x	x	
Murano \ Z51 \ 2010-8~	BCM		x		
Murano \ Z51 \ 2010-8~	Air bag	x	x	x	
Murano \ Z51 \ 2010-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2010-8~	Transmission	x	x	x	
Murano \ Z51 \ 2010-8~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2010-8~	IPDM E/R		x	x	
Murano \ Z51 \ 2010-8~	Auto drive position		x	x	
Murano \ Z51 \ 2010-8~	All mode AWD/4WD		x	x	

Murano \ Z51 \ 2010-8~	Auto back door		x	x	
Murano \ Z51 \ 2010-8~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2010-8~	Rearview camera			x	
Murano \ Z51 \ 2010-8~	S/blind camera			x	
Murano \ Z51 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2011	Meter/M&A		x	x	
Murano \ Z51 \ 2011	BCM		x		
Murano \ Z51 \ 2011	Air bag	x	x	x	
Murano \ Z51 \ 2011	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Murano \ Z51 \ 2011	Multi AV	x	x	x	
Murano \ Z51 \ 2011	IPDM E/R		x	x	
Murano \ Z51 \ 2011	Convertible roof		x	x	
Murano \ Z51 \ 2011	Auto drive position	x	x	x	
Murano \ Z51 \ 2011	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011	Auto back door		x	x	
Murano \ Z51 \ 2011	Rearview camera			x	
Murano \ Z51 \ 2011	S/blind camera			x	
Murano \ Z51 \ 2011-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011-1~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2011-1~	Meter/M&A		x	x	
Murano \ Z51 \ 2011-1~	BCM		x		
Murano \ Z51 \ 2011-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011-1~	Transmission	x	x	x	
Murano \ Z51 \ 2011-1~	Multi AV		x	x	
Murano \ Z51 \ 2011-1~	IPDM E/R		x	x	
Murano \ Z51 \ 2011-1~	Auto drive position		x	x	
Murano \ Z51 \ 2011-1~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011-1~	Auto back door		x	x	
Murano \ Z51 \ 2011-1~	Air bag	x	x	x	
Murano \ Z51 \ 2011-1~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2011-1~	Rearview camera			x	
Murano \ Z51 \ 2011-1~	S/blind camera			x	
Murano \ Z51 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011-5~	ABS	x	x	x	0003, 0092, 0264

Murano \ Z51 \ 2011-5~	Meter/M&A		x	x	
Murano \ Z51 \ 2011-5~	BCM		x		
Murano \ Z51 \ 2011-5~	Air bag	x	x	x	
Murano \ Z51 \ 2011-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011-5~	Transmission	x	x	x	0059
Murano \ Z51 \ 2011-5~	Multi AV		x	x	
Murano \ Z51 \ 2011-5~	IPDM E/R		x	x	
Murano \ Z51 \ 2011-5~	Auto drive position		x	x	
Murano \ Z51 \ 2011-5~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011-5~	Auto back door		x	x	
Murano \ Z51 \ 2011-5~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2011-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011-7~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2011-7~	Meter/M&A		x	x	
Murano \ Z51 \ 2011-7~	BCM		x		
Murano \ Z51 \ 2011-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011-7~	Transmission	x	x	x	
Murano \ Z51 \ 2011-7~	Multi AV		x	x	
Murano \ Z51 \ 2011-7~	IPDM E/R		x	x	
Murano \ Z51 \ 2011-7~	Auto drive position		x	x	
Murano \ Z51 \ 2011-7~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011-7~	Auto back door		x	x	
Murano \ Z51 \ 2011-7~	Air bag	x	x	x	
Murano \ Z51 \ 2011-7~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011-8~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2011-8~	Meter/M&A		x	x	
Murano \ Z51 \ 2011-8~	BCM		x		
Murano \ Z51 \ 2011-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011-8~	Transmission	x	x	x	
Murano \ Z51 \ 2011-8~	Multi AV		x	x	
Murano \ Z51 \ 2011-8~	IPDM E/R		x	x	
Murano \ Z51 \ 2011-8~	Auto drive position		x	x	
Murano \ Z51 \ 2011-8~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011-8~	Auto back door		x	x	
Murano \ Z51 \ 2011-8~	Air bag	x	x	x	

Murano \ Z51 \ 2011-8~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2011-9~	Meter/M&A		x	x	
Murano \ Z51 \ 2011-9~	BCM		x		
Murano \ Z51 \ 2011-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2011-9~	Transmission	x	x	x	
Murano \ Z51 \ 2011-9~	Multi AV		x	x	
Murano \ Z51 \ 2011-9~	IPDM E/R		x	x	
Murano \ Z51 \ 2011-9~	Auto drive position		x	x	
Murano \ Z51 \ 2011-9~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2011-9~	Auto back door		x	x	
Murano \ Z51 \ 2011-9~	Air bag	x	x	x	
Murano \ Z51 \ 2011-9~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2011-9~	Sonar	x	x	x	
Murano \ Z51 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012	Meter/M&A		x	x	
Murano \ Z51 \ 2012	BCM		x		
Murano \ Z51 \ 2012	Air bag	x	x	x	
Murano \ Z51 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012	Transmission	x	x	x	
Murano \ Z51 \ 2012	Multi AV		x	x	
Murano \ Z51 \ 2012	IPDM E/R		x	x	
Murano \ Z51 \ 2012	Auto drive position		x	x	
Murano \ Z51 \ 2012	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012	Auto back door		x	x	
Murano \ Z51 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012-1~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012-1~	Meter/M&A		x	x	
Murano \ Z51 \ 2012-1~	BCM		x		
Murano \ Z51 \ 2012-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012-1~	Transmission	x	x	x	
Murano \ Z51 \ 2012-1~	Multi AV		x	x	
Murano \ Z51 \ 2012-1~	IPDM E/R		x	x	

Murano \ Z51 \ 2012-1~	Auto drive position		x	x	
Murano \ Z51 \ 2012-1~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012-1~	Auto back door		x	x	
Murano \ Z51 \ 2012-1~	Air bag	x	x	x	
Murano \ Z51 \ 2012-1~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2012-1~	Multi AV	x	x	x	
Murano \ Z51 \ 2012-1~	Accele pedal ACT		x	x	
Murano \ Z51 \ 2012-1~	Chassis control		x	x	
Murano \ Z51 \ 2012-1~	Occupant detection			x	
Murano \ Z51 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012-3~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012-3~	Meter/M&A		x	x	
Murano \ Z51 \ 2012-3~	BCM		x		
Murano \ Z51 \ 2012-3~	Air bag	x	x	x	
Murano \ Z51 \ 2012-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012-3~	Transmission	x	x	x	0059
Murano \ Z51 \ 2012-3~	Multi AV		x	x	
Murano \ Z51 \ 2012-3~	IPDM E/R		x	x	
Murano \ Z51 \ 2012-3~	Auto drive position		x	x	
Murano \ Z51 \ 2012-3~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012-3~	Auto back door		x	x	
Murano \ Z51 \ 2012-3~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012-5~	Meter/M&A		x	x	
Murano \ Z51 \ 2012-5~	BCM		x		
Murano \ Z51 \ 2012-5~	Air bag	x	x	x	
Murano \ Z51 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012-5~	Transmission	x	x	x	
Murano \ Z51 \ 2012-5~	Multi AV	x	x	x	
Murano \ Z51 \ 2012-5~	IPDM E/R		x	x	
Murano \ Z51 \ 2012-5~	Auto drive position		x	x	
Murano \ Z51 \ 2012-5~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012-5~	Auto back door		x	x	
Murano \ Z51 \ 2012-5~	Accele pedal ACT		x	x	
Murano \ Z51 \ 2012-5~	Chassis control		x	x	
Murano \ Z51 \ 2012-5~	Head lamp levelizer	x	x	x	

Murano \ Z51 \ 2012-5~	Occupant detection			x	
Murano \ Z51 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012-8~	Meter/M&A		x	x	
Murano \ Z51 \ 2012-8~	BCM		x		
Murano \ Z51 \ 2012-8~	Air bag		x	x	
Murano \ Z51 \ 2012-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012-8~	Transmission	x	x	x	
Murano \ Z51 \ 2012-8~	Multi AV		x	x	
Murano \ Z51 \ 2012-8~	IPDM E/R		x	x	
Murano \ Z51 \ 2012-8~	Auto drive position		x	x	
Murano \ Z51 \ 2012-8~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012-8~	Auto back door		x	x	
Murano \ Z51 \ 2012-8~	AVM		x	x	
Murano \ Z51 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2012-9~	Meter/M&A		x	x	
Murano \ Z51 \ 2012-9~	BCM		x		
Murano \ Z51 \ 2012-9~	Air bag	x	x	x	
Murano \ Z51 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2012-9~	Transmission	x	x	x	
Murano \ Z51 \ 2012-9~	Multi AV		x	x	
Murano \ Z51 \ 2012-9~	IPDM E/R		x	x	
Murano \ Z51 \ 2012-9~	Auto drive position		x	x	
Murano \ Z51 \ 2012-9~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2012-9~	Auto back door		x	x	
Murano \ Z51 \ 2012-9~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2012-9~	Occupant detection			x	
Murano \ Z51 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2013	Meter/M&A		x	x	
Murano \ Z51 \ 2013	BCM		x		
Murano \ Z51 \ 2013	Air bag		x	x	
Murano \ Z51 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013	Transmission	x	x	x	

Murano \ Z51 \ 2013	Multi AV		x	x	
Murano \ Z51 \ 2013	IPDM E/R		x	x	
Murano \ Z51 \ 2013	Auto drive position		x	x	
Murano \ Z51 \ 2013	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2013	Auto back door		x	x	
Murano \ Z51 \ 2013	AVM		x	x	
Murano \ Z51 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013-10~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2013-10~	Meter/M&A		x	x	
Murano \ Z51 \ 2013-10~	BCM		x		
Murano \ Z51 \ 2013-10~	Air bag	x	x	x	
Murano \ Z51 \ 2013-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013-10~	Transmission	x	x	x	
Murano \ Z51 \ 2013-10~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2013-10~	EPS/DAST 3	x	x	x	
Murano \ Z51 \ 2013-10~	IPDM E/R		x	x	
Murano \ Z51 \ 2013-10~	Air pressure monitor	x	x	x	
Murano \ Z51 \ 2013-10~	Auto drive position		x	x	
Murano \ Z51 \ 2013-10~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2013-10~	Auto back door		x	x	
Murano \ Z51 \ 2013-10~	Accele pedal ACT		x	x	
Murano \ Z51 \ 2013-10~	Telematics		x	x	0253
Murano \ Z51 \ 2013-10~	AVM		x	x	
Murano \ Z51 \ 2013-10~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2013-10~	Sonar	x	x	x	
Murano \ Z51 \ 2013-10~	Occupant detection			x	
Murano \ Z51 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013-11~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2013-11~	Meter/M&A		x	x	
Murano \ Z51 \ 2013-11~	BCM		x		
Murano \ Z51 \ 2013-11~	Air bag	x	x	x	
Murano \ Z51 \ 2013-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013-11~	Transmission	x	x	x	
Murano \ Z51 \ 2013-11~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2013-11~	EPS/DAST 3	x	x	x	
Murano \ Z51 \ 2013-11~	IPDM E/R		x	x	
Murano \ Z51 \ 2013-11~	Air pressure monitor	x	x	x	

Murano \ Z51 \ 2013-11~	Auto drive position		x	x	
Murano \ Z51 \ 2013-11~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2013-11~	Auto back door		x	x	
Murano \ Z51 \ 2013-11~	Accele pedal ACT		x	x	
Murano \ Z51 \ 2013-11~	Telematics		x	x	0253
Murano \ Z51 \ 2013-11~	AVM		x	x	
Murano \ Z51 \ 2013-11~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2013-11~	Sonar	x	x	x	
Murano \ Z51 \ 2013-11~	Occupant detection			x	
Murano \ Z51 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013-5~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2013-5~	Meter/M&A		x	x	
Murano \ Z51 \ 2013-5~	BCM		x		
Murano \ Z51 \ 2013-5~	Air bag		x	x	
Murano \ Z51 \ 2013-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013-5~	Transmission	x	x	x	
Murano \ Z51 \ 2013-5~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2013-5~	IPDM E/R		x	x	
Murano \ Z51 \ 2013-5~	Auto drive position		x	x	
Murano \ Z51 \ 2013-5~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2013-5~	Auto back door		x	x	
Murano \ Z51 \ 2013-5~	AVM		x	x	
Murano \ Z51 \ 2013-5~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2013-5~	Occupant detection			x	
Murano \ Z51 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013-8~	ABS	x	x	x	0003, 0092, 0264
Murano \ Z51 \ 2013-8~	Meter/M&A		x	x	
Murano \ Z51 \ 2013-8~	BCM		x		
Murano \ Z51 \ 2013-8~	Air bag	x	x	x	
Murano \ Z51 \ 2013-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013-8~	Transmission	x	x	x	
Murano \ Z51 \ 2013-8~	Multi AV		x	x	
Murano \ Z51 \ 2013-8~	IPDM E/R		x	x	
Murano \ Z51 \ 2013-8~	Auto drive position		x	x	
Murano \ Z51 \ 2013-8~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2013-8~	Auto back door		x	x	
Murano \ Z51 \ 2013-8~	Head lamp levelizer	x	x	x	

Murano \ Z51 \ 2013-8~	Occupant detection			×	
Murano \ Z51 \ 2013-9~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2013-9~	ABS	×	×	×	0003, 0092, 0264
Murano \ Z51 \ 2013-9~	Meter/M&A		×	×	
Murano \ Z51 \ 2013-9~	BCM		×		
Murano \ Z51 \ 2013-9~	Air bag	×	×	×	
Murano \ Z51 \ 2013-9~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2013-9~	Transmission	×	×	×	
Murano \ Z51 \ 2013-9~	Multi AV		×	×	
Murano \ Z51 \ 2013-9~	IPDM E/R		×	×	
Murano \ Z51 \ 2013-9~	Auto drive position		×	×	
Murano \ Z51 \ 2013-9~	All mode AWD/4WD		×	×	
Murano \ Z51 \ 2013-9~	Auto back door		×	×	
Murano \ Z51 \ 2013-9~	AVM		×	×	
Murano \ Z51 \ 2013-9~	Head lamp levelizer	×	×	×	
Murano \ Z51 \ 2013-9~	Occupant detection			×	
Murano \ Z51 \ 2014	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2014	ABS	×	×	×	0003, 0092, 0264
Murano \ Z51 \ 2014	Meter/M&A		×	×	
Murano \ Z51 \ 2014	BCM		×		
Murano \ Z51 \ 2014	Air bag	×	×	×	
Murano \ Z51 \ 2014	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2014	Transmission	×	×	×	
Murano \ Z51 \ 2014	Multi AV		×	×	
Murano \ Z51 \ 2014	IPDM E/R		×	×	
Murano \ Z51 \ 2014	Auto drive position		×	×	
Murano \ Z51 \ 2014	All mode AWD/4WD		×	×	
Murano \ Z51 \ 2014	Auto back door		×	×	
Murano \ Z51 \ 2014	AVM		×	×	
Murano \ Z51 \ 2014	Head lamp levelizer	×	×	×	
Murano \ Z51 \ 2014	Occupant detection			×	
Murano \ Z51 \ 2014-6~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z51 \ 2014-6~	ABS	×	×	×	0003, 0092, 0264
Murano \ Z51 \ 2014-6~	Meter/M&A		×	×	
Murano \ Z51 \ 2014-6~	BCM		×		
Murano \ Z51 \ 2014-6~	Air bag	×	×	×	

Murano \ Z51 \ 2014-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Murano \ Z51 \ 2014-6~	Transmission	x	x	x	
Murano \ Z51 \ 2014-6~	Multi AV		x	x	
Murano \ Z51 \ 2014-6~	EPS/DAST 3	x	x	x	
Murano \ Z51 \ 2014-6~	IPDM E/R		x	x	
Murano \ Z51 \ 2014-6~	Air pressure monitor		x	x	
Murano \ Z51 \ 2014-6~	Auto drive position		x	x	
Murano \ Z51 \ 2014-6~	All mode AWD/4WD		x	x	
Murano \ Z51 \ 2014-6~	Sonar	x	x	x	
Murano \ Z51 \ 2014-6~	Auto back door		x	x	
Murano \ Z51 \ 2014-6~	Telematics		x	x	0253
Murano \ Z51 \ 2014-6~	AVM		x	x	
Murano \ Z51 \ 2014-6~	Head lamp levelizer	x	x	x	
Murano \ Z51 \ 2014-6~	Occupant detection			x	
Murano \ Z51 \ 2014-6~	Multi AV	x	x	x	0280
Murano \ Z51 \ 2014-6~	Air pressure monitor	x	x	x	
Murano \ Z51 \ 2014-6~	Accele pedal ACT		x	x	
Murano \ Z52 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z52 \ 2015	ABS		x	x	
Murano \ Z52 \ 2015	Meter/M&A		x	x	
Murano \ Z52 \ 2015	BCM		x		
Murano \ Z52 \ 2015	Air bag		x	x	
Murano \ Z52 \ 2015	ICC/ADAS		x	x	
Murano \ Z52 \ 2015	HVAC		x	x	
Murano \ Z52 \ 2015	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Murano \ Z52 \ 2015	Multi AV		x	x	
Murano \ Z52 \ 2015	Motor control		x	x	0238
Murano \ Z52 \ 2015	EPS/DAST 3		x	x	
Murano \ Z52 \ 2015	IPDM E/R		x	x	
Murano \ Z52 \ 2015	Air pressure monitor		x	x	
Murano \ Z52 \ 2015	Laser/radar		x	x	
Murano \ Z52 \ 2015	Auto drive position		x	x	
Murano \ Z52 \ 2015	All mode AWD/4WD		x	x	
Murano \ Z52 \ 2015	Sonar	x	x	x	
Murano \ Z52 \ 2015	Lane camera	x	x	x	
Murano \ Z52 \ 2015	CAN gateway		x		
Murano \ Z52 \ 2015	EV/HEV		x	x	
Murano \ Z52 \ 2015	Auto back door		x	x	

Murano \ Z52 \ 2015	HV battery		x	x	
Murano \ Z52 \ 2015	Side radar left		x	x	
Murano \ Z52 \ 2015	VSP		x	x	
Murano \ Z52 \ 2015	Side radar right		x	x	
Murano \ Z52 \ 2015	Telematics		x	x	0253
Murano \ Z52 \ 2015	AVM		x	x	
Murano \ Z52 \ 2015	Head lamp levelizer	x	x	x	
Murano \ Z52 \ 2015	Occupant detection			x	
Murano \ Z52 \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z52 \ 2015-7~	ABS	x	x	x	
Murano \ Z52 \ 2015-7~	Meter/M&A		x	x	
Murano \ Z52 \ 2015-7~	BCM		x		
Murano \ Z52 \ 2015-7~	Air bag		x	x	
Murano \ Z52 \ 2015-7~	ICC/ADAS	x	x	x	
Murano \ Z52 \ 2015-7~	HVAC		x	x	
Murano \ Z52 \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Murano \ Z52 \ 2015-7~	Multi AV	x	x	x	0280
Murano \ Z52 \ 2015-7~	EPS/DAST 3		x	x	
Murano \ Z52 \ 2015-7~	IPDM E/R		x	x	
Murano \ Z52 \ 2015-7~	Air pressure monitor		x	x	
Murano \ Z52 \ 2015-7~	Laser/radar	x	x	x	
Murano \ Z52 \ 2015-7~	Auto drive position		x	x	
Murano \ Z52 \ 2015-7~	All mode AWD/4WD		x	x	
Murano \ Z52 \ 2015-7~	Sonar		x	x	
Murano \ Z52 \ 2015-7~	Lane camera	x	x	x	
Murano \ Z52 \ 2015-7~	CAN gateway		x	x	
Murano \ Z52 \ 2015-7~	Auto back door		x	x	
Murano \ Z52 \ 2015-7~	Side radar left		x	x	
Murano \ Z52 \ 2015-7~	Side radar right		x	x	
Murano \ Z52 \ 2015-7~	Telematics		x	x	0253
Murano \ Z52 \ 2015-7~	AVM		x	x	
Murano \ Z52 \ 2015-7~	Head lamp levelizer	x	x	x	
Murano \ Z52 \ 2015-7~	Occupant detection			x	
Murano \ Z52 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z52 \ 2016	ABS	x	x	x	
Murano \ Z52 \ 2016	Meter/M&A		x	x	
Murano \ Z52 \ 2016	BCM		x		
Murano \ Z52 \ 2016	Air bag		x	x	

Murano \ Z52 \ 2016	ICC/ADAS	x	x	x	
Murano \ Z52 \ 2016	HVAC		x	x	
Murano \ Z52 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Murano \ Z52 \ 2016	Multi AV		x	x	
Murano \ Z52 \ 2016	EPS/DAST 3		x	x	
Murano \ Z52 \ 2016	IPDM E/R		x	x	
Murano \ Z52 \ 2016	Air pressure monitor		x	x	
Murano \ Z52 \ 2016	Laser/radar		x	x	
Murano \ Z52 \ 2016	Auto drive position		x	x	
Murano \ Z52 \ 2016	All mode AWD/4WD		x	x	
Murano \ Z52 \ 2016	Sonar		x	x	
Murano \ Z52 \ 2016	CAN gateway		x		
Murano \ Z52 \ 2016	Auto back door		x	x	
Murano \ Z52 \ 2016	Side radar left		x	x	
Murano \ Z52 \ 2016	Side radar right		x	x	
Murano \ Z52 \ 2016	Telematics		x	x	0253
Murano \ Z52 \ 2016	AVM		x	x	
Murano \ Z52 \ 2016	Occupant detection			x	
Murano \ Z52 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z52 \ 2016-1~	ABS	x	x	x	
Murano \ Z52 \ 2016-1~	Meter/M&A		x	x	
Murano \ Z52 \ 2016-1~	BCM		x		
Murano \ Z52 \ 2016-1~	Air bag		x	x	
Murano \ Z52 \ 2016-1~	ICC/ADAS	x	x	x	
Murano \ Z52 \ 2016-1~	HVAC		x	x	
Murano \ Z52 \ 2016-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Murano \ Z52 \ 2016-1~	EPS/DAST 3		x	x	
Murano \ Z52 \ 2016-1~	IPDM E/R		x	x	
Murano \ Z52 \ 2016-1~	Air pressure monitor		x	x	
Murano \ Z52 \ 2016-1~	Laser/radar		x	x	
Murano \ Z52 \ 2016-1~	Auto drive position		x	x	
Murano \ Z52 \ 2016-1~	All mode AWD/4WD		x	x	
Murano \ Z52 \ 2016-1~	Sonar		x	x	
Murano \ Z52 \ 2016-1~	CAN gateway		x		
Murano \ Z52 \ 2016-1~	Auto back door		x	x	
Murano \ Z52 \ 2016-1~	Side radar left		x	x	
Murano \ Z52 \ 2016-1~	Side radar right		x	x	
Murano \ Z52 \ 2016-1~	AVM		x	x	

Murano \ Z52 \ 2016-1~	Head lamp levelizer	x	x	x	
Murano \ Z52 \ 2016-1~	Occupant detection			x	
Murano \ Z52 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Murano \ Z52 \ 2016-3~	ABS	x	x	x	
Murano \ Z52 \ 2016-3~	Meter/M&A		x	x	
Murano \ Z52 \ 2016-3~	BCM		x		
Murano \ Z52 \ 2016-3~	Air bag		x	x	
Murano \ Z52 \ 2016-3~	ICC/ADAS	x	x	x	
Murano \ Z52 \ 2016-3~	HVAC		x	x	
Murano \ Z52 \ 2016-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Murano \ Z52 \ 2016-3~	Multi AV	x	x	x	0280
Murano \ Z52 \ 2016-3~	EPS/DAST 3		x	x	
Murano \ Z52 \ 2016-3~	IPDM E/R		x	x	
Murano \ Z52 \ 2016-3~	Air pressure monitor		x	x	
Murano \ Z52 \ 2016-3~	Laser/radar	x	x	x	
Murano \ Z52 \ 2016-3~	Auto drive position		x	x	
Murano \ Z52 \ 2016-3~	All mode AWD/4WD		x	x	
Murano \ Z52 \ 2016-3~	Sonar		x	x	
Murano \ Z52 \ 2016-3~	Adaptive light		x	x	
Murano \ Z52 \ 2016-3~	CAN gateway		x		
Murano \ Z52 \ 2016-3~	Auto back door		x	x	
Murano \ Z52 \ 2016-3~	Side radar left		x	x	
Murano \ Z52 \ 2016-3~	Side radar right		x	x	
Murano \ Z52 \ 2016-3~	PTC heater		x	x	
Murano \ Z52 \ 2016-3~	Telematics		x	x	0253
Murano \ Z52 \ 2016-3~	AVM		x	x	
Murano \ Z52 \ 2016-3~	Head lamp levelizer	x	x	x	
Murano \ Z52 \ 2016-3~	Occupant detection			x	
Navara camp:P7266 \ D40 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara camp:P7266 \ D40 \ All Year	HVAC	x	x	x	
Navara camp:P7266 \ D40 \ All Year	Transmission		x	x	
Navara camp:P7266 \ D40 \ All Year	Auto drive position	x	x	x	
Navara camp:P7266 \ D40 \ All Year	ABS	x	x	x	
Navara camp:P7266 \ D40 \ All Year	Air bag	x	x	x	
Navara \ D40 \ 2005-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2005-1~	ABS	x	x	x	0003, 0092, 0264
Navara \ D40 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2005-1~	BCM	x	x		

Navara \ D40 \ 2005-1~	Air bag	x	x	x	
Navara \ D40 \ 2005-1~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2005-1~	HVAC	x	x	x	
Navara \ D40 \ 2005-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Navara \ D40 \ 2005-1~	Multi AV	x	x	x	0280
Navara \ D40 \ 2005-1~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2005-1~	IPDM E/R	x	x	x	
Navara \ D40 \ 2005-1~	Air pressure monitor	x	x	x	
Navara \ D40 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2005-1~	DIU	x	x	x	
Navara \ D40 \ 2005-1~	Auto slide door	x	x	x	
Navara \ D40 \ 2005-1~	Auto drive position	x	x	x	
Navara \ D40 \ 2005-1~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2005-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Navara \ D40 \ 2005-1~	Sonar	x	x	x	
Navara \ D40 \ 2005-1~	Lane camera	x	x	x	
Navara \ D40 \ 2005-1~	Adaptive light	x	x	x	
Navara \ D40 \ 2005-1~	AVM		x	x	
Navara \ D40 \ 2005-1~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2005-1~	Difference lock	x	x	x	
Navara \ D40 \ 2005-1~	Nats immu	x	x		
Navara \ D40 \ 2005-1~	Smart entrance	x	x		
Navara \ D40 \ 2005-1~	Air levelizer	x	x	x	
Navara \ D40 \ 2005-1~	Rearview camera			x	
Navara \ D40 \ 2005-1~	S/blind camera			x	
Navara \ D40 \ 2005-1~	Motor assist	x	x	x	
Navara \ D40 \ 2005-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2005-6~	ABS	x	x	x	0003, 0092, 0264
Navara \ D40 \ 2005-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2005-6~	BCM	x	x		
Navara \ D40 \ 2005-6~	Air bag	x	x	x	
Navara \ D40 \ 2005-6~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2005-6~	HVAC	x	x	x	
Navara \ D40 \ 2005-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Navara \ D40 \ 2005-6~	Multi AV	x	x	x	0280
Navara \ D40 \ 2005-6~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2005-6~	IPDM E/R	x	x	x	
Navara \ D40 \ 2005-6~	Air pressure monitor	x	x	x	

Navara \ D40 \ 2005-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2005-6~	DIU	x	x	x	
Navara \ D40 \ 2005-6~	Auto slide door	x	x	x	
Navara \ D40 \ 2005-6~	Auto drive position	x	x	x	
Navara \ D40 \ 2005-6~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2005-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Navara \ D40 \ 2005-6~	Sonar	x	x	x	
Navara \ D40 \ 2005-6~	Lane camera	x	x	x	
Navara \ D40 \ 2005-6~	Adaptive light	x	x	x	
Navara \ D40 \ 2005-6~	AVM		x	x	
Navara \ D40 \ 2005-6~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2005-6~	Difference lock	x	x	x	
Navara \ D40 \ 2005-6~	Nats immu	x	x		
Navara \ D40 \ 2005-6~	Smart entrance	x	x		
Navara \ D40 \ 2005-6~	Air levelizer	x	x	x	
Navara \ D40 \ 2005-6~	Rearview camera			x	
Navara \ D40 \ 2005-6~	S/blind camera			x	
Navara \ D40 \ 2005-6~	Motor assist	x	x	x	
Navara \ D40 \ 2006-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2006-7~	ABS	x	x	x	0003, 0092, 0264
Navara \ D40 \ 2006-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2006-7~	BCM	x	x		
Navara \ D40 \ 2006-7~	Air bag	x	x	x	
Navara \ D40 \ 2006-7~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2006-7~	HVAC	x	x	x	
Navara \ D40 \ 2006-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Navara \ D40 \ 2006-7~	Multi AV	x	x	x	0280
Navara \ D40 \ 2006-7~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2006-7~	IPDM E/R	x	x	x	
Navara \ D40 \ 2006-7~	Air pressure monitor	x	x	x	
Navara \ D40 \ 2006-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2006-7~	DIU	x	x	x	
Navara \ D40 \ 2006-7~	Auto slide door	x	x	x	
Navara \ D40 \ 2006-7~	Auto drive position	x	x	x	
Navara \ D40 \ 2006-7~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2006-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Navara \ D40 \ 2006-7~	Sonar	x	x	x	
Navara \ D40 \ 2006-7~	Lane camera	x	x	x	
Navara \ D40 \ 2006-7~	Adaptive light	x	x	x	
Navara \ D40 \ 2006-7~	AVM		x	x	
Navara \ D40 \ 2006-7~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2006-7~	Difference lock	x	x	x	
Navara \ D40 \ 2006-7~	Nats immu	x	x		
Navara \ D40 \ 2006-7~	Smart entrance	x	x		
Navara \ D40 \ 2006-7~	Air levelizer	x	x	x	
Navara \ D40 \ 2006-7~	Rearview camera			x	
Navara \ D40 \ 2006-7~	S/blind camera			x	
Navara \ D40 \ 2006-7~	Motor assist	x	x	x	
Navara \ D40 \ 2006-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2006-9~	ABS	x	x	x	0003, 0092, 0264
Navara \ D40 \ 2006-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2006-9~	BCM	x	x		
Navara \ D40 \ 2006-9~	Air bag	x	x	x	
Navara \ D40 \ 2006-9~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2006-9~	HVAC	x	x	x	
Navara \ D40 \ 2006-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Navara \ D40 \ 2006-9~	Multi AV	x	x	x	0280
Navara \ D40 \ 2006-9~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2006-9~	IPDM E/R	x	x	x	
Navara \ D40 \ 2006-9~	Air pressure monitor	x	x	x	
Navara \ D40 \ 2006-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2006-9~	DIU	x	x	x	
Navara \ D40 \ 2006-9~	Auto slide door	x	x	x	
Navara \ D40 \ 2006-9~	Auto drive position	x	x	x	
Navara \ D40 \ 2006-9~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2006-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Navara \ D40 \ 2006-9~	Sonar	x	x	x	
Navara \ D40 \ 2006-9~	Lane camera	x	x	x	
Navara \ D40 \ 2006-9~	Adaptive light	x	x	x	
Navara \ D40 \ 2006-9~	AVM		x	x	
Navara \ D40 \ 2006-9~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2006-9~	Difference lock	x	x	x	
Navara \ D40 \ 2006-9~	Nats immu	x	x		
Navara \ D40 \ 2006-9~	Smart entrance	x	x		

Navara \ D40 \ 2006-9~	Air levelizer	x	x	x	
Navara \ D40 \ 2006-9~	Rearview camera			x	
Navara \ D40 \ 2006-9~	S/blind camera			x	
Navara \ D40 \ 2006-9~	Motor assist	x	x	x	
Navara \ D40 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2007-10~	BCM	x	x		
Navara \ D40 \ 2007-10~	Air bag	x	x	x	
Navara \ D40 \ 2007-10~	HVAC	x	x	x	
Navara \ D40 \ 2007-10~	Transmission	x	x	x	
Navara \ D40 \ 2007-10~	IPDM E/R	x	x	x	
Navara \ D40 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2007-10~	Precrash seatbelt	x	x	x	
Navara \ D40 \ 2007-10~	Auto drive position	x	x	x	
Navara \ D40 \ 2007-10~	ABS	x	x	x	
Navara \ D40 \ 2007-10~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2007-10~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2007-10~	Difference lock	x	x	x	
Navara \ D40 \ 2007-10~	Rearview camera			x	
Navara \ D40 \ 2007-10~	S/blind camera			x	
Navara \ D40 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264
Navara \ D40 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2007-5~	BCM	x	x		
Navara \ D40 \ 2007-5~	Air bag	x	x	x	
Navara \ D40 \ 2007-5~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2007-5~	HVAC	x	x	x	
Navara \ D40 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Navara \ D40 \ 2007-5~	Multi AV	x	x	x	0280
Navara \ D40 \ 2007-5~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2007-5~	IPDM E/R	x	x	x	
Navara \ D40 \ 2007-5~	Air pressure monitor	x	x	x	
Navara \ D40 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2007-5~	DIU	x	x	x	
Navara \ D40 \ 2007-5~	Auto slide door	x	x	x	

Navara \ D40 \ 2007-5~	Auto drive position	x	x	x	
Navara \ D40 \ 2007-5~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Navara \ D40 \ 2007-5~	Sonar	x	x	x	
Navara \ D40 \ 2007-5~	Lane camera	x	x	x	
Navara \ D40 \ 2007-5~	Adaptive light	x	x	x	
Navara \ D40 \ 2007-5~	AVM		x	x	
Navara \ D40 \ 2007-5~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2007-5~	Difference lock	x	x	x	
Navara \ D40 \ 2007-5~	Nats immu	x	x		
Navara \ D40 \ 2007-5~	Smart entrance	x	x		
Navara \ D40 \ 2007-5~	Air levelizer	x	x	x	
Navara \ D40 \ 2007-5~	Rearview camera			x	
Navara \ D40 \ 2007-5~	S/blind camera			x	
Navara \ D40 \ 2007-5~	Motor assist	x	x	x	
Navara \ D40 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2007-8~	BCM	x	x		
Navara \ D40 \ 2007-8~	HVAC	x	x	x	
Navara \ D40 \ 2007-8~	Transmission	x	x	x	
Navara \ D40 \ 2007-8~	Multi AV	x	x	x	
Navara \ D40 \ 2007-8~	IPDM E/R	x	x	x	
Navara \ D40 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2007-8~	Auto drive position	x	x	x	
Navara \ D40 \ 2007-8~	ABS	x	x	x	
Navara \ D40 \ 2007-8~	Air bag	x	x	x	
Navara \ D40 \ 2007-8~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2010-10~	BCM	x	x		
Navara \ D40 \ 2010-10~	Air bag	x	x	x	
Navara \ D40 \ 2010-10~	HVAC	x	x	x	
Navara \ D40 \ 2010-10~	IPDM E/R	x	x	x	
Navara \ D40 \ 2010-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2010-10~	Preocrash seatbelt	x	x	x	

Navara \ D40 \ 2010-10~	Auto drive position	x	x	x	
Navara \ D40 \ 2010-10~	ABS	x	x	x	
Navara \ D40 \ 2010-10~	Transmission	x	x	x	
Navara \ D40 \ 2010-10~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2010-10~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2010-10~	Difference lock	x	x	x	
Navara \ D40 \ 2010-10~	SVT	x	x	x	
Navara \ D40 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2010-2~	ABS	x	x	x	
Navara \ D40 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2010-2~	BCM	x	x		
Navara \ D40 \ 2010-2~	Air bag	x	x	x	
Navara \ D40 \ 2010-2~	HVAC	x	x	x	
Navara \ D40 \ 2010-2~	Transmission	x	x	x	0059
Navara \ D40 \ 2010-2~	Multi AV	x	x	x	0280
Navara \ D40 \ 2010-2~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2010-2~	IPDM E/R	x	x	x	
Navara \ D40 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2010-2~	Auto drive position	x	x	x	
Navara \ D40 \ 2010-2~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2010-2~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2010-2~	Difference lock	x	x	x	
Navara \ D40 \ 2010-2~	Rearview camera			x	
Navara \ D40 \ 2010-2~	S/blind camera			x	
Navara \ D40 \ 2010-2~	SVT	x	x	x	
Navara \ D40 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2011-12~	BCM	x	x		
Navara \ D40 \ 2011-12~	Air bag	x	x	x	
Navara \ D40 \ 2011-12~	HVAC	x	x	x	
Navara \ D40 \ 2011-12~	Transmission	x	x	x	0059
Navara \ D40 \ 2011-12~	Multi AV		x	x	
Navara \ D40 \ 2011-12~	IPDM E/R	x	x	x	
Navara \ D40 \ 2011-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2011-12~	Auto drive position	x	x	x	

Navara \ D40 \ 2011-12~	ABS	x	x	x	
Navara \ D40 \ 2011-12~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2011-12~	Difference lock	x	x	x	
Navara \ D40 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2011-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2011-5~	BCM	x	x		
Navara \ D40 \ 2011-5~	Air bag	x	x	x	
Navara \ D40 \ 2011-5~	HVAC	x	x	x	
Navara \ D40 \ 2011-5~	IPDM E/R	x	x	x	
Navara \ D40 \ 2011-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2011-5~	Auto drive position	x	x	x	
Navara \ D40 \ 2011-5~	ABS	x	x	x	
Navara \ D40 \ 2011-5~	Transmission	x	x	x	
Navara \ D40 \ 2011-5~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2011-5~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2011-5~	Difference lock	x	x	x	
Navara \ D40 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2012-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2012-11~	BCM	x	x		
Navara \ D40 \ 2012-11~	Air bag	x	x	x	
Navara \ D40 \ 2012-11~	HVAC	x	x	x	
Navara \ D40 \ 2012-11~	Multi AV		x	x	
Navara \ D40 \ 2012-11~	IPDM E/R	x	x	x	
Navara \ D40 \ 2012-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2012-11~	Auto drive position	x	x	x	
Navara \ D40 \ 2012-11~	ABS	x	x	x	
Navara \ D40 \ 2012-11~	Transmission	x	x	x	
Navara \ D40 \ 2012-11~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2012-11~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2012-11~	Difference lock	x	x	x	
Navara \ D40 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2012-3~	BCM	x	x		
Navara \ D40 \ 2012-3~	HVAC	x	x	x	

Navara \ D40 \ 2012-3~	IPDM E/R	x	x	x	
Navara \ D40 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2012-3~	Auto drive position	x	x	x	
Navara \ D40 \ 2012-3~	ABS	x	x	x	
Navara \ D40 \ 2012-3~	Air bag	x	x	x	
Navara \ D40 \ 2012-3~	Transmission	x	x	x	
Navara \ D40 \ 2012-3~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2012-3~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2012-3~	Difference lock	x	x	x	
Navara \ D40 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2013-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2013-1~	BCM	x	x		
Navara \ D40 \ 2013-1~	Air bag	x	x	x	
Navara \ D40 \ 2013-1~	HVAC	x	x	x	
Navara \ D40 \ 2013-1~	Multi AV		x	x	
Navara \ D40 \ 2013-1~	IPDM E/R	x	x	x	
Navara \ D40 \ 2013-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2013-1~	Auto drive position	x	x	x	
Navara \ D40 \ 2013-1~	ABS	x	x	x	
Navara \ D40 \ 2013-1~	Transmission	x	x	x	
Navara \ D40 \ 2013-1~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2013-1~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2013-1~	Difference lock	x	x	x	
Navara \ D40 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2013-3~	ABS	x	x	x	
Navara \ D40 \ 2013-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2013-3~	BCM	x	x		
Navara \ D40 \ 2013-3~	Air bag	x	x	x	
Navara \ D40 \ 2013-3~	HVAC	x	x	x	
Navara \ D40 \ 2013-3~	Multi AV	x	x	x	0280
Navara \ D40 \ 2013-3~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2013-3~	IPDM E/R	x	x	x	
Navara \ D40 \ 2013-3~	Convertible roof		x	x	

Navara \ D40 \ 2013-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2013-3~	Auto drive position	x	x	x	
Navara \ D40 \ 2013-3~	Sonar	x	x	x	
Navara \ D40 \ 2013-3~	Lane camera	x	x	x	
Navara \ D40 \ 2013-3~	Transmission	x	x	x	
Navara \ D40 \ 2013-3~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2013-3~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2013-3~	Difference lock	x	x	x	
Navara \ D40 \ 2013-3~	SVT	x	x	x	
Navara \ D40 \ 2013-3~	Rearview camera			x	
Navara \ D40 \ 2013-3~	S/blind camera			x	
Navara \ D40 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2014-5~	ABS	x	x	x	
Navara \ D40 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2014-5~	BCM	x	x		
Navara \ D40 \ 2014-5~	Air bag	x	x	x	
Navara \ D40 \ 2014-5~	HVAC	x	x	x	
Navara \ D40 \ 2014-5~	EPS/DAST 3	x	x	x	
Navara \ D40 \ 2014-5~	IPDM E/R	x	x	x	
Navara \ D40 \ 2014-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Navara \ D40 \ 2014-5~	Auto drive position	x	x	x	
Navara \ D40 \ 2014-5~	Transmission	x	x	x	
Navara \ D40 \ 2014-5~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2014-5~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2014-5~	Difference lock	x	x	x	
Navara \ D40 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Navara \ D40 \ 2016-1~	ABS	x	x	x	
Navara \ D40 \ 2016-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Navara \ D40 \ 2016-1~	BCM	x	x		
Navara \ D40 \ 2016-1~	Air bag	x	x	x	
Navara \ D40 \ 2016-1~	ICC/ADAS	x	x	x	
Navara \ D40 \ 2016-1~	HVAC	x	x	x	
Navara \ D40 \ 2016-1~	Transmission	x	x	x	0059
Navara \ D40 \ 2016-1~	Multi AV		x	x	
Navara \ D40 \ 2016-1~	EPS/DAST 3	x	x	x	

Navara \ D40 \ 2016-1~	IPDM E/R	x	x	x	
Navara \ D40 \ 2016-1~	Air pressure monitor		x	x	
Navara \ D40 \ 2016-1~	Auto drive position	x	x	x	
Navara \ D40 \ 2016-1~	All mode AWD/4WD	x	x	x	
Navara \ D40 \ 2016-1~	Side radar left		x	x	
Navara \ D40 \ 2016-1~	Side radar right		x	x	
Navara \ D40 \ 2016-1~	Head lamp levelizer	x	x	x	
Navara \ D40 \ 2016-1~	Difference lock	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(SPA) \ D40 \ 2005-6~	ABS	x	x	x	0003, 0092, 0264
navara(SPA) \ D40 \ 2005-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(SPA) \ D40 \ 2005-6~	BCM	x	x		
navara(SPA) \ D40 \ 2005-6~	Air bag	x	x	x	
navara(SPA) \ D40 \ 2005-6~	ICC/ADAS	x	x	x	
navara(SPA) \ D40 \ 2005-6~	HVAC	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
navara(SPA) \ D40 \ 2005-6~	Multi AV	x	x	x	0280
navara(SPA) \ D40 \ 2005-6~	EPS/DAST 3	x	x	x	
navara(SPA) \ D40 \ 2005-6~	IPDM E/R	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Air pressure monitor	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(SPA) \ D40 \ 2005-6~	DIU	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Auto slide door	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Auto drive position	x	x	x	
navara(SPA) \ D40 \ 2005-6~	All mode AWD/4WD	x	x	x	
navara(SPA) \ D40 \ 2005-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Sonar	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Lane camera	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Adaptive light	x	x	x	
navara(SPA) \ D40 \ 2005-6~	AVM		x	x	
navara(SPA) \ D40 \ 2005-6~	Head lamp levelizer	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Difference lock	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Nats immu	x	x		
navara(SPA) \ D40 \ 2005-6~	Smart entrance	x	x		
navara(SPA) \ D40 \ 2005-6~	Air levelizer	x	x	x	
navara(SPA) \ D40 \ 2005-6~	Rearview camera			x	
navara(SPA) \ D40 \ 2005-6~	S/blind camera			x	
navara(SPA) \ D40 \ 2005-6~	Motor assist	x	x	x	

navara(SPA) \ D40 \ 2006-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(SPA) \ D40 \ 2006-9~	ABS	x	x	x	0003, 0092, 0264
navara(SPA) \ D40 \ 2006-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(SPA) \ D40 \ 2006-9~	BCM	x	x		
navara(SPA) \ D40 \ 2006-9~	Air bag	x	x	x	
navara(SPA) \ D40 \ 2006-9~	ICC/ADAS	x	x	x	
navara(SPA) \ D40 \ 2006-9~	HVAC	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
navara(SPA) \ D40 \ 2006-9~	Multi AV	x	x	x	0280
navara(SPA) \ D40 \ 2006-9~	EPS/DAST 3	x	x	x	
navara(SPA) \ D40 \ 2006-9~	IPDM E/R	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Air pressure monitor	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(SPA) \ D40 \ 2006-9~	DIU	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Auto slide door	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Auto drive position	x	x	x	
navara(SPA) \ D40 \ 2006-9~	All mode AWD/4WD	x	x	x	
navara(SPA) \ D40 \ 2006-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Sonar	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Lane camera	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Adaptive light	x	x	x	
navara(SPA) \ D40 \ 2006-9~	AVM		x	x	
navara(SPA) \ D40 \ 2006-9~	Head lamp levelizer	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Difference lock	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Nats immu	x	x		
navara(SPA) \ D40 \ 2006-9~	Smart entrance	x	x		
navara(SPA) \ D40 \ 2006-9~	Air levelizer	x	x	x	
navara(SPA) \ D40 \ 2006-9~	Rearview camera			x	
navara(SPA) \ D40 \ 2006-9~	S/blind camera			x	
navara(SPA) \ D40 \ 2006-9~	Motor assist	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(SPA) \ D40 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264
navara(SPA) \ D40 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(SPA) \ D40 \ 2007-5~	BCM	x	x		
navara(SPA) \ D40 \ 2007-5~	Air bag	x	x	x	
navara(SPA) \ D40 \ 2007-5~	ICC/ADAS	x	x	x	
navara(SPA) \ D40 \ 2007-5~	HVAC	x	x	x	

navara(SPA) \ D40 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
navara(SPA) \ D40 \ 2007-5~	Multi AV	x	x	x	0280
navara(SPA) \ D40 \ 2007-5~	EPS/DAST 3	x	x	x	
navara(SPA) \ D40 \ 2007-5~	IPDM E/R	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Air pressure monitor	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(SPA) \ D40 \ 2007-5~	DIU	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Auto slide door	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Auto drive position	x	x	x	
navara(SPA) \ D40 \ 2007-5~	All mode AWD/4WD	x	x	x	
navara(SPA) \ D40 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Sonar	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Lane camera	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Adaptive light	x	x	x	
navara(SPA) \ D40 \ 2007-5~	AVM		x	x	
navara(SPA) \ D40 \ 2007-5~	Head lamp levelizer	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Difference lock	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Nats immu	x	x		
navara(SPA) \ D40 \ 2007-5~	Smart entrance	x	x		
navara(SPA) \ D40 \ 2007-5~	Air levelizer	x	x	x	
navara(SPA) \ D40 \ 2007-5~	Rearview camera			x	
navara(SPA) \ D40 \ 2007-5~	S/blind camera			x	
navara(SPA) \ D40 \ 2007-5~	Motor assist	x	x	x	
navara(SPA) \ D40 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(SPA) \ D40 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(SPA) \ D40 \ 2010-2~	BCM	x	x		
navara(SPA) \ D40 \ 2010-2~	Air bag	x	x	x	
navara(SPA) \ D40 \ 2010-2~	HVAC	x	x	x	
navara(SPA) \ D40 \ 2010-2~	Transmission	x	x	x	0059
navara(SPA) \ D40 \ 2010-2~	Multi AV	x	x	x	
navara(SPA) \ D40 \ 2010-2~	IPDM E/R	x	x	x	
navara(SPA) \ D40 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(SPA) \ D40 \ 2010-2~	Auto drive position	x	x	x	
navara(SPA) \ D40 \ 2010-2~	ABS	x	x	x	
navara(SPA) \ D40 \ 2010-2~	Head lamp levelizer	x	x	x	
navara(SPA) \ D40 \ 2010-2~	All mode AWD/4WD	x	x	x	

navara(SPA) \ D40 \ 2010-2~	Difference lock	x	x	x	
navara(SPA) \ D40 \ 2010-2~	SVT	x	x	x	
navara(SPA) \ D40 \ 2010-2~	Rearview camera			x	
navara(THI) \ D40 \ 2007-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(THI) \ D40 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2007-10~	BCM	x	x		
navara(THI) \ D40 \ 2007-10~	Air bag	x	x	x	
navara(THI) \ D40 \ 2007-10~	HVAC	x	x	x	
navara(THI) \ D40 \ 2007-10~	Transmission	x	x	x	
navara(THI) \ D40 \ 2007-10~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2007-10~	Precrash seatbelt	x	x	x	
navara(THI) \ D40 \ 2007-10~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2007-10~	ABS	x	x	x	
navara(THI) \ D40 \ 2007-10~	Head lamp levelizer	x	x	x	
navara(THI) \ D40 \ 2007-10~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2007-10~	Difference lock	x	x	x	
navara(THI) \ D40 \ 2007-10~	Rearview camera			x	
navara(THI) \ D40 \ 2007-10~	S/blind camera			x	
navara(THI) \ D40 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(THI) \ D40 \ 2009-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2009-10~	BCM	x	x		
navara(THI) \ D40 \ 2009-10~	Air bag	x	x	x	
navara(THI) \ D40 \ 2009-10~	HVAC	x	x	x	
navara(THI) \ D40 \ 2009-10~	Transmission	x	x	x	0059
navara(THI) \ D40 \ 2009-10~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2009-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2009-10~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2009-10~	ABS	x	x	x	
navara(THI) \ D40 \ 2009-10~	Head lamp levelizer	x	x	x	
navara(THI) \ D40 \ 2009-10~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2009-10~	Difference lock	x	x	x	
navara(THI) \ D40 \ 2009-10~	Rearview camera			x	
navara(THI) \ D40 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

navara(THI) \ D40 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2011-12~	BCM	x	x		
navara(THI) \ D40 \ 2011-12~	HVAC	x	x	x	
navara(THI) \ D40 \ 2011-12~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2011-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2011-12~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2011-12~	ABS	x	x	x	
navara(THI) \ D40 \ 2011-12~	Air bag	x	x	x	
navara(THI) \ D40 \ 2011-12~	Transmission	x	x	x	
navara(THI) \ D40 \ 2011-12~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2011-12~	Difference lock	x	x	x	
navara(THI) \ D40 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(THI) \ D40 \ 2012-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2012-1~	BCM	x	x		
navara(THI) \ D40 \ 2012-1~	HVAC	x	x	x	
navara(THI) \ D40 \ 2012-1~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2012-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2012-1~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2012-1~	ABS	x	x	x	
navara(THI) \ D40 \ 2012-1~	Air bag	x	x	x	
navara(THI) \ D40 \ 2012-1~	Transmission	x	x	x	
navara(THI) \ D40 \ 2012-1~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(THI) \ D40 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2012-3~	BCM	x	x		
navara(THI) \ D40 \ 2012-3~	HVAC	x	x	x	
navara(THI) \ D40 \ 2012-3~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2012-3~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2012-3~	ABS	x	x	x	
navara(THI) \ D40 \ 2012-3~	Air bag	x	x	x	
navara(THI) \ D40 \ 2012-3~	Transmission	x	x	x	
navara(THI) \ D40 \ 2012-3~	Head lamp levelizer	x	x	x	

navara(THI) \ D40 \ 2012-3~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2012-3~	Difference lock	x	x	x	
navara(THI) \ D40 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
navara(THI) \ D40 \ 2013-3~	ABS	x	x	x	
navara(THI) \ D40 \ 2013-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
navara(THI) \ D40 \ 2013-3~	BCM	x	x		
navara(THI) \ D40 \ 2013-3~	Air bag	x	x	x	
navara(THI) \ D40 \ 2013-3~	HVAC	x	x	x	
navara(THI) \ D40 \ 2013-3~	Multi AV	x	x	x	0280
navara(THI) \ D40 \ 2013-3~	EPS/DAST 3	x	x	x	
navara(THI) \ D40 \ 2013-3~	IPDM E/R	x	x	x	
navara(THI) \ D40 \ 2013-3~	Convertible roof		x	x	
navara(THI) \ D40 \ 2013-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
navara(THI) \ D40 \ 2013-3~	Auto drive position	x	x	x	
navara(THI) \ D40 \ 2013-3~	Sonar	x	x	x	
navara(THI) \ D40 \ 2013-3~	Lane camera	x	x	x	
navara(THI) \ D40 \ 2013-3~	Transmission	x	x	x	
navara(THI) \ D40 \ 2013-3~	Head lamp levelizer	x	x	x	
navara(THI) \ D40 \ 2013-3~	All mode AWD/4WD	x	x	x	
navara(THI) \ D40 \ 2013-3~	Difference lock	x	x	x	
navara(THI) \ D40 \ 2013-3~	SVT	x	x	x	
navara(THI) \ D40 \ 2013-3~	Rearview camera			x	
navara(THI) \ D40 \ 2013-3~	S/blind camera			x	
NISSAN GT-R NISMO \ R35 \ 2014-11~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2014-11~	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2014-2~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2014-2~	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2014-6~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2014-6~	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2015	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2015	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2015-1~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2015-1~	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2016	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2016	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2016-4~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2016-4~	Sonar		x	x	
NISSAN GT-R NISMO \ R35 \ 2016-4~	Auto back door		x	x	

NISSAN GT-R NISMO \ R35 \ 2016-4~	E-SUS	x	x		
NISSAN GT-R NISMO \ R35 \ 2016-7~	BCM			x	
NISSAN GT-R NISMO \ R35 \ 2016-7~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2007-10~	BCM			x	
Nissan GT-R \ R35 \ 2007-10~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2008-12~	BCM			x	
Nissan GT-R \ R35 \ 2008-12~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2009	BCM			x	
Nissan GT-R \ R35 \ 2009	E-SUS	x	x		
Nissan GT-R \ R35 \ 2009-11~	BCM			x	
Nissan GT-R \ R35 \ 2009-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2009-12~	BCM			x	
Nissan GT-R \ R35 \ 2009-12~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2009-4~	BCM			x	
Nissan GT-R \ R35 \ 2009-4~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2010	BCM			x	
Nissan GT-R \ R35 \ 2010	E-SUS	x	x		
Nissan GT-R \ R35 \ 2010-10~	BCM			x	
Nissan GT-R \ R35 \ 2010-10~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2010-11~	BCM			x	
Nissan GT-R \ R35 \ 2010-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2011	BCM			x	
Nissan GT-R \ R35 \ 2011	E-SUS	x	x		
Nissan GT-R \ R35 \ 2011-10~	BCM			x	
Nissan GT-R \ R35 \ 2011-10~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2011-11~	BCM			x	
Nissan GT-R \ R35 \ 2011-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2011-1~	BCM			x	
Nissan GT-R \ R35 \ 2011-1~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2011-8~	BCM			x	
Nissan GT-R \ R35 \ 2011-8~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2012	BCM			x	
Nissan GT-R \ R35 \ 2012	E-SUS	x	x		
Nissan GT-R \ R35 \ 2012-11~	BCM			x	
Nissan GT-R \ R35 \ 2012-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2012-11~	Multi AV	x	x	x	
Nissan GT-R \ R35 \ 2012-1~	BCM			x	
Nissan GT-R \ R35 \ 2012-1~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2013	BCM			x	
Nissan GT-R \ R35 \ 2013	E-SUS	x	x		

Nissan GT-R \ R35 \ 2013-11~	BCM			x	
Nissan GT-R \ R35 \ 2013-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2014	BCM			x	
Nissan GT-R \ R35 \ 2014	E-SUS	x	x		
Nissan GT-R \ R35 \ 2014-11~	BCM			x	
Nissan GT-R \ R35 \ 2014-11~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2014-12~	BCM			x	
Nissan GT-R \ R35 \ 2014-12~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2015	BCM			x	
Nissan GT-R \ R35 \ 2015	E-SUS	x	x		
Nissan GT-R \ R35 \ 2015-1~	BCM			x	
Nissan GT-R \ R35 \ 2015-1~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2015-5~	BCM			x	
Nissan GT-R \ R35 \ 2015-5~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2016	BCM			x	
Nissan GT-R \ R35 \ 2016	E-SUS	x	x		
Nissan GT-R \ R35 \ 2016-4~	BCM			x	
Nissan GT-R \ R35 \ 2016-4~	Sonar		x	x	
Nissan GT-R \ R35 \ 2016-4~	Auto back door		x	x	
Nissan GT-R \ R35 \ 2016-4~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2016-5~	BCM			x	
Nissan GT-R \ R35 \ 2016-5~	Sonar		x	x	
Nissan GT-R \ R35 \ 2016-5~	Auto back door		x	x	
Nissan GT-R \ R35 \ 2016-5~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2016-6~	BCM			x	
Nissan GT-R \ R35 \ 2016-6~	E-SUS	x	x		
Nissan GT-R \ R35 \ 2017	BCM			x	
Nissan GT-R \ R35 \ 2017	E-SUS	x	x		
Nissan GT-R(GCC) \ R35 \ 2009-4~	BCM			x	
Nissan GT-R(GCC) \ R35 \ 2009-4~	E-SUS	x	x		
Nissan GT-R(US) \ R35 \ 2008-3~	BCM			x	
Nissan GT-R(US) \ R35 \ 2008-3~	E-SUS	x	x		
Note (CR14 engine) \ E11 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note (CR14 engine) \ E11 \ 2012-3~	ABS		x	x	
Note (CR14 engine) \ E11 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note (CR14 engine) \ E11 \ 2012-3~	BCM	x	x		
Note (CR14 engine) \ E11 \ 2012-3~	Air bag	x	x	x	
Note (CR14 engine) \ E11 \ 2012-3~	EPS/DAST 3	x	x	x	
Note (CR14 engine) \ E11 \ 2012-3~	IPDM E/R	x	x	x	

Note (CR14 engine) \ E11 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note (CR14 engine) \ E11 \ 2012-3~	Head lamp levelizer	x	x	x	
Note (CR14 engine) \ E11 \ 2012-3~	Sonar	x	x	x	
Note (K9K engine) \ E11 \ 2012-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note (K9K engine) \ E11 \ 2012-2~	ABS		x	x	
Note (K9K engine) \ E11 \ 2012-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note (K9K engine) \ E11 \ 2012-2~	BCM	x	x		
Note (K9K engine) \ E11 \ 2012-2~	Air bag	x	x	x	
Note (K9K engine) \ E11 \ 2012-2~	EPS/DAST 3	x	x	x	
Note (K9K engine) \ E11 \ 2012-2~	IPDM E/R	x	x	x	
Note (K9K engine) \ E11 \ 2012-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note (K9K engine) \ E11 \ 2012-2~	Head lamp levelizer	x	x	x	
Note (K9K engine) \ E11 \ 2012-2~	Sonar	x	x	x	
Note \ E11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2005-12~	BCM	x	x		
Note \ E11 \ 2005-12~	Transmission	x	x	x	
Note \ E11 \ 2005-12~	Multi AV	x	x	x	0280
Note \ E11 \ 2005-12~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2005-12~	IPDM E/R	x	x	x	
Note \ E11 \ 2005-12~	E-4wd	x	x	x	
Note \ E11 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2005-12~	Engine	x	x	x	
Note \ E11 \ 2005-12~	ABS	x	x	x	
Note \ E11 \ 2005-12~	Air bag	x	x	x	
Note \ E11 \ 2005-12~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2005-1~	BCM	x	x		
Note \ E11 \ 2005-1~	Transmission	x	x	x	
Note \ E11 \ 2005-1~	Multi AV	x	x	x	0280
Note \ E11 \ 2005-1~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2005-1~	IPDM E/R	x	x	x	
Note \ E11 \ 2005-1~	E-4wd	x	x	x	

Note \ E11 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2005-1~	Engine	x	x	x	
Note \ E11 \ 2005-1~	ABS	x	x	x	
Note \ E11 \ 2005-1~	Air bag	x	x	x	
Note \ E11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2006-12~	BCM	x	x		
Note \ E11 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Note \ E11 \ 2006-12~	Multi AV	x	x	x	
Note \ E11 \ 2006-12~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2006-12~	IPDM E/R	x	x	x	
Note \ E11 \ 2006-12~	E-4wd	x	x	x	
Note \ E11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2006-12~	Engine	x	x	x	
Note \ E11 \ 2006-12~	ABS	x	x	x	
Note \ E11 \ 2006-12~	Air bag	x	x	x	
Note \ E11 \ 2006-12~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2006-1~	Engine	x	x	x	
Note \ E11 \ 2006-1~	ABS	x	x	x	
Note \ E11 \ 2006-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2006-1~	BCM	x	x		
Note \ E11 \ 2006-1~	Transmission		x	x	
Note \ E11 \ 2006-1~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2006-1~	IPDM E/R	x	x	x	
Note \ E11 \ 2006-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2006-1~	Air bag	x	x	x	
Note \ E11 \ 2007-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E11 \ 2007-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2007-12~	BCM	x	x		
Note \ E11 \ 2007-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Note \ E11 \ 2007-12~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2007-12~	IPDM E/R	x	x	x	
Note \ E11 \ 2007-12~	E-4wd	x	x	x	

Note \ E11 \ 2007-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2007-12~	ABS	x	x	x	
Note \ E11 \ 2007-12~	Air bag	x	x	x	
Note \ E11 \ 2007-12~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2009-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E11 \ 2009-1~	ABS	x	x	x	
Note \ E11 \ 2009-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2009-1~	BCM	x	x		
Note \ E11 \ 2009-1~	Air bag	x	x	x	
Note \ E11 \ 2009-1~	Transmission		x	x	
Note \ E11 \ 2009-1~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2009-1~	IPDM E/R	x	x	x	
Note \ E11 \ 2009-1~	E-4wd	x	x	x	
Note \ E11 \ 2009-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2009-1~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2009-1~	Sonar	x	x	x	
Note \ E11 \ 2009-1~	Rearview camera			x	
Note \ E11 \ 2009-1~	S/blind camera			x	
Note \ E11 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E11 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2009-8~	BCM	x	x		
Note \ E11 \ 2009-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Note \ E11 \ 2009-8~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2009-8~	IPDM E/R	x	x	x	
Note \ E11 \ 2009-8~	E-4wd	x	x	x	
Note \ E11 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2009-8~	ABS	x	x	x	
Note \ E11 \ 2009-8~	Air bag	x	x	x	
Note \ E11 \ 2009-8~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E11 \ 2010-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2010-11~	BCM	x	x		

Note \ E11 \ 2010-11~	Air bag	x	x	x	
Note \ E11 \ 2010-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Note \ E11 \ 2010-11~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2010-11~	IPDM E/R	x	x	x	
Note \ E11 \ 2010-11~	E-4wd	x	x	x	
Note \ E11 \ 2010-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2010-11~	ABS	x	x	x	
Note \ E11 \ 2010-11~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2010-11~	Rearview camera			x	
Note \ E11 \ 2010-11~	S/blind camera			x	
Note \ E11 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0260, 0209, 0095, 0216, 0233, 0103, 0234, 0212
Note \ E11 \ 2012-5~	ABS		x	x	
Note \ E11 \ 2012-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Note \ E11 \ 2012-5~	BCM	x	x		
Note \ E11 \ 2012-5~	Air bag	x	x	x	
Note \ E11 \ 2012-5~	EPS/DAST 3	x	x	x	
Note \ E11 \ 2012-5~	IPDM E/R	x	x	x	
Note \ E11 \ 2012-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Note \ E11 \ 2012-5~	Head lamp levelizer	x	x	x	
Note \ E11 \ 2012-5~	Sonar	x	x	x	
Note \ E11 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2012-7~	ABS	x	x	x	
Note \ E12 \ 2012-7~	Meter/M&A		x	x	
Note \ E12 \ 2012-7~	BCM		x		
Note \ E12 \ 2012-7~	Transmission		x	x	
Note \ E12 \ 2012-7~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2012-7~	IPDM E/R		x	x	
Note \ E12 \ 2012-7~	E-4wd	x	x	x	
Note \ E12 \ 2012-7~	AVM		x	x	
Note \ E12 \ 2012-7~	Air bag	x	x	x	
Note \ E12 \ 2012-7~	Multi AV		x	x	
Note \ E12 \ 2012-7~	PTC heater		x	x	
Note \ E12 \ 2012-7~	Occupant detection			x	

Note \ E12 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2013-12~	ABS	x	x	x	
Note \ E12 \ 2013-12~	Meter/M&A		x	x	
Note \ E12 \ 2013-12~	BCM		x		
Note \ E12 \ 2013-12~	Air bag	x	x	x	
Note \ E12 \ 2013-12~	ICC/ADAS		x	x	
Note \ E12 \ 2013-12~	Transmission		x	x	
Note \ E12 \ 2013-12~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2013-12~	IPDM E/R		x	x	
Note \ E12 \ 2013-12~	E-4wd	x	x	x	
Note \ E12 \ 2013-12~	Sonar		x	x	
Note \ E12 \ 2013-12~	Lane camera		x	x	
Note \ E12 \ 2013-12~	PTC heater		x	x	
Note \ E12 \ 2013-12~	AVM		x	x	
Note \ E12 \ 2013-12~	Occupant detection			x	
Note \ E12 \ 2013-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2013-4~	ABS	x	x	x	
Note \ E12 \ 2013-4~	Meter/M&A		x	x	
Note \ E12 \ 2013-4~	BCM		x		
Note \ E12 \ 2013-4~	Air bag	x	x	x	
Note \ E12 \ 2013-4~	Transmission		x	x	
Note \ E12 \ 2013-4~	Multi AV		x	x	
Note \ E12 \ 2013-4~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2013-4~	IPDM E/R		x	x	
Note \ E12 \ 2013-4~	PTC heater		x	x	
Note \ E12 \ 2013-4~	AVM		x	x	
Note \ E12 \ 2013-4~	Occupant detection			x	
Note \ E12 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2013-8~	ABS	x	x	x	
Note \ E12 \ 2013-8~	Meter/M&A		x	x	
Note \ E12 \ 2013-8~	BCM		x		
Note \ E12 \ 2013-8~	Air bag	x	x	x	
Note \ E12 \ 2013-8~	Transmission		x	x	
Note \ E12 \ 2013-8~	Multi AV		x	x	
Note \ E12 \ 2013-8~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2013-8~	IPDM E/R		x	x	
Note \ E12 \ 2013-8~	Air pressure monitor		x	x	
Note \ E12 \ 2013-8~	PTC heater		x	x	

Note \ E12 \ 2013-8~	EMCM	x	x	x	
Note \ E12 \ 2013-8~	AVM		x	x	
Note \ E12 \ 2013-8~	Occupant detection			x	
Note \ E12 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2014-2~	ABS	x	x	x	
Note \ E12 \ 2014-2~	Meter/M&A		x	x	
Note \ E12 \ 2014-2~	BCM		x		
Note \ E12 \ 2014-2~	Air bag	x	x	x	
Note \ E12 \ 2014-2~	ICC/ADAS	x	x	x	
Note \ E12 \ 2014-2~	Transmission		x	x	
Note \ E12 \ 2014-2~	Multi AV		x	x	
Note \ E12 \ 2014-2~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2014-2~	IPDM E/R		x	x	
Note \ E12 \ 2014-2~	Air pressure monitor		x	x	
Note \ E12 \ 2014-2~	Sonar		x	x	
Note \ E12 \ 2014-2~	Side radar left		x	x	
Note \ E12 \ 2014-2~	Side radar right		x	x	
Note \ E12 \ 2014-2~	PTC heater		x	x	
Note \ E12 \ 2014-2~	EMCM	x	x	x	
Note \ E12 \ 2014-2~	AVM		x	x	
Note \ E12 \ 2014-2~	Occupant detection			x	
Note \ E12 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2014-4~	ABS	x	x	x	
Note \ E12 \ 2014-4~	Meter/M&A		x	x	
Note \ E12 \ 2014-4~	BCM		x		
Note \ E12 \ 2014-4~	Air bag	x	x	x	
Note \ E12 \ 2014-4~	Transmission		x	x	
Note \ E12 \ 2014-4~	Multi AV	x	x	x	0280
Note \ E12 \ 2014-4~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2014-4~	IPDM E/R		x	x	
Note \ E12 \ 2014-4~	Telematics		x	x	
Note \ E12 \ 2014-4~	AVM		x	x	
Note \ E12 \ 2014-4~	Occupant detection			x	
Note \ E12 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2014-9~	ABS	x	x	x	
Note \ E12 \ 2014-9~	Meter/M&A		x	x	
Note \ E12 \ 2014-9~	BCM		x		
Note \ E12 \ 2014-9~	Air bag	x	x	x	

Note \ E12 \ 2014-9~	ICC/ADAS		x	x	
Note \ E12 \ 2014-9~	Transmission		x	x	
Note \ E12 \ 2014-9~	Multi AV	x	x	x	0280
Note \ E12 \ 2014-9~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2014-9~	IPDM E/R		x	x	
Note \ E12 \ 2014-9~	E-4wd	x	x	x	
Note \ E12 \ 2014-9~	All mode AWD/4WD	x	x	x	0245, 0311
Note \ E12 \ 2014-9~	Sonar		x	x	
Note \ E12 \ 2014-9~	Lane camera	x	x	x	
Note \ E12 \ 2014-9~	Side radar left		x	x	
Note \ E12 \ 2014-9~	Side radar right		x	x	
Note \ E12 \ 2014-9~	PTC heater		x	x	
Note \ E12 \ 2014-9~	Telematics		x	x	
Note \ E12 \ 2014-9~	BSW/buzzer		x	x	
Note \ E12 \ 2014-9~	AVM		x	x	
Note \ E12 \ 2014-9~	Occupant detection			x	
Note \ E12 \ 2015-5~	Engine	x	x	x	0107, 0145, 0064, 0146, 0148, 0123, 0188, 0187, 0020, 0189, 0103, 0166, 0168, 0105, 0190, 0191, 0011, 0216, 0212, 0005, 0278, 0112, 0139, 0209, 0177, 0176, 0233, 0234, 0028, 0185, 0006, 0262, 0306, 0225, 0205, 0097, 0220
Note \ E12 \ 2015-5~	ABS	x	x	x	
Note \ E12 \ 2015-5~	Meter/M&A		x	x	
Note \ E12 \ 2015-5~	BCM		x		
Note \ E12 \ 2015-5~	Air bag	x	x	x	
Note \ E12 \ 2015-5~	ICC/ADAS	x	x	x	
Note \ E12 \ 2015-5~	Transmission		x	x	
Note \ E12 \ 2015-5~	Multi AV		x	x	
Note \ E12 \ 2015-5~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2015-5~	IPDM E/R		x	x	
Note \ E12 \ 2015-5~	E-4wd	x	x	x	
Note \ E12 \ 2015-5~	Sonar		x	x	
Note \ E12 \ 2015-5~	Lane camera		x	x	
Note \ E12 \ 2015-5~	Side radar left		x	x	
Note \ E12 \ 2015-5~	Side radar right		x	x	
Note \ E12 \ 2015-5~	PTC heater		x	x	
Note \ E12 \ 2015-5~	Telematics		x	x	
Note \ E12 \ 2015-5~	AVM		x	x	
Note \ E12 \ 2015-5~	Occupant detection			x	

Note \ E12 \ 2015-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2015-5~	Multi AV	x	x	x	0280
Note \ E12 \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Note \ E12 \ 2015-7~	ABS	x	x	x	
Note \ E12 \ 2015-7~	Meter/M&A		x	x	
Note \ E12 \ 2015-7~	BCM		x		
Note \ E12 \ 2015-7~	Air bag	x	x	x	
Note \ E12 \ 2015-7~	Transmission		x	x	
Note \ E12 \ 2015-7~	Multi AV	x	x	x	0280
Note \ E12 \ 2015-7~	EPS/DAST 3	x	x	x	
Note \ E12 \ 2015-7~	IPDM E/R		x	x	
Note \ E12 \ 2015-7~	Sonar		x	x	
Note \ E12 \ 2015-7~	Side radar left		x	x	
Note \ E12 \ 2015-7~	Side radar right		x	x	
Note \ E12 \ 2015-7~	PTC heater		x	x	
Note \ E12 \ 2015-7~	AVM		x	x	
Note \ E12 \ 2015-7~	Occupant detection			x	
NP200 \ U90 \ 2008-6~	Engine	x	x	x	0079, 0080, 0081, 0082, 0103, 0129, 0210, 0343
NP200 \ U90 \ 2008-6~	ABS		x	x	0336, 0263, 0325, 0055
NP200 \ U90 \ 2008-6~	BCM	x	x	x	0116
NP200 \ U90 \ 2008-6~	Air bag		x	x	0317, 0341
NP200 \ U90 \ 2008-6~	Transmission		x	x	
NP200 \ U90 \ 2008-6~	EPS/DAST 3		x	x	0335, 0072
NP300 NAVARA \ D23 \ 2014-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2014-10~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2014-10~	BCM		x		
NP300 NAVARA \ D23 \ 2014-10~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2014-10~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2014-10~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2014-10~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2014-10~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Laser/radar	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	Preocrash seatbelt		x	x	

NP300 NAVARA \ D23 \ 2014-10~	All mode AWD/4WD	x	x	x	0245, 0311
NP300 NAVARA \ D23 \ 2014-10~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	Lane camera	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	CAN gateway		x	x	
NP300 NAVARA \ D23 \ 2014-10~	E-SUS		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Side radar right		x	x	
NP300 NAVARA \ D23 \ 2014-10~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Telematics		x	x	0253
NP300 NAVARA \ D23 \ 2014-10~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	BSW/buzzer		x	x	
NP300 NAVARA \ D23 \ 2014-10~	AVM		x	x	
NP300 NAVARA \ D23 \ 2014-10~	PMAS		x	x	
NP300 NAVARA \ D23 \ 2014-10~	Head lamp levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2014-10~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2014-10~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2014-3~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2014-3~	BCM		x		
NP300 NAVARA \ D23 \ 2014-3~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2014-3~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2014-3~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2014-3~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2014-3~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2014-3~	Laser/radar	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Preocrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2014-3~	All mode AWD/4WD	x	x	x	0245, 0311
NP300 NAVARA \ D23 \ 2014-3~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Lane camera	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	CAN gateway		x	x	
NP300 NAVARA \ D23 \ 2014-3~	E-SUS		x	x	

NP300 NAVARA \ D23 \ 2014-3~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2014-3~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2014-3~	Side radar right		x	x	
NP300 NAVARA \ D23 \ 2014-3~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2014-3~	Telematics		x	x	0253
NP300 NAVARA \ D23 \ 2014-3~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	BSW/buzzer		x	x	
NP300 NAVARA \ D23 \ 2014-3~	AVM		x	x	
NP300 NAVARA \ D23 \ 2014-3~	PMAS		x	x	
NP300 NAVARA \ D23 \ 2014-3~	Head lamp levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2014-3~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2014-3~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2015-10~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2015-10~	BCM		x		
NP300 NAVARA \ D23 \ 2015-10~	Air bag	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2015-10~	Transmission		x	x	0076, 0117, 0113, 0149, 0110, 0059, 0150, 0085
NP300 NAVARA \ D23 \ 2015-10~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2015-10~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Laser/radar		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Precrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Auto drive position		x	x	
NP300 NAVARA \ D23 \ 2015-10~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	Sonar		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Lane camera		x	x	
NP300 NAVARA \ D23 \ 2015-10~	CAN gateway		x		
NP300 NAVARA \ D23 \ 2015-10~	Auto back door		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2015-10~	ANC		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Side radar right		x	x	
NP300 NAVARA \ D23 \ 2015-10~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2015-10~	EMCM	x	x	x	

NP300 NAVARA \ D23 \ 2015-10~	AVM		x	x	
NP300 NAVARA \ D23 \ 2015-10~	Head lamp levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2015-10~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2015-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2015-12~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2015-12~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2015-12~	BCM		x		
NP300 NAVARA \ D23 \ 2015-12~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2015-12~	ICC/ADAS		x	x	
NP300 NAVARA \ D23 \ 2015-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2015-12~	Transmission		x	x	0059
NP300 NAVARA \ D23 \ 2015-12~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2015-12~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2015-12~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2015-12~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2015-12~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2015-12~	Sonar		x	x	
NP300 NAVARA \ D23 \ 2015-12~	Lane camera		x	x	
NP300 NAVARA \ D23 \ 2015-12~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2015-12~	AVM		x	x	
NP300 NAVARA \ D23 \ 2015-12~	Head lamp levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2015-9~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2015-9~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2015-9~	BCM		x		
NP300 NAVARA \ D23 \ 2015-9~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2015-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2015-9~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2015-9~	Multi AV		x	x	
NP300 NAVARA \ D23 \ 2015-9~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2015-9~	Precrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2015-9~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2015-9~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2015-9~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2015-9~	E-SUS		x	x	
NP300 NAVARA \ D23 \ 2015-9~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2015-9~	AVM		x	x	

NP300 NAVARA \ D23 \ 2015-9~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2015-9~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2016-2~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2016-2~	BCM		x		
NP300 NAVARA \ D23 \ 2016-2~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2016-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2016-2~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2016-2~	Multi AV		x	x	
NP300 NAVARA \ D23 \ 2016-2~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Precrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2016-2~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	E-SUS		x	x	
NP300 NAVARA \ D23 \ 2016-2~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2016-2~	AVM		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2016-2~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2016-2~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Laser/radar	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	All mode AWD/4WD	x	x	x	0245, 0311
NP300 NAVARA \ D23 \ 2016-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	Lane camera	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	CAN gateway		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Side radar right		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Telematics		x	x	0253
NP300 NAVARA \ D23 \ 2016-2~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2016-2~	BSW/buzzer		x	x	
NP300 NAVARA \ D23 \ 2016-2~	PMAS		x	x	
NP300 NAVARA \ D23 \ 2016-2~	Head lamp levelizer	x	x	x	

NP300 NAVARA \ D23 \ 2016-7~	Engine	x	x	x	0107, 0063, 0145, 0064, 0148, 0188, 0187, 0020, 0189, 0103, 0167, 0190, 0270, 0192, 0107, 0216, 0035, 0212, 0006, 0278, 0112, 0158, 0233, 0234, 0029, 0209, 0161, 0025, 0262, 0306, 0205, 0220
NP300 NAVARA \ D23 \ 2016-7~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2016-7~	BCM		x		
NP300 NAVARA \ D23 \ 2016-7~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2016-7~	ICC/ADAS		x	x	
NP300 NAVARA \ D23 \ 2016-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2016-7~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2016-7~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2016-7~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Laser/radar		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Precrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2016-7~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Sonar		x	x	
NP300 NAVARA \ D23 \ 2016-7~	E-SUS		x	x	
NP300 NAVARA \ D23 \ 2016-7~	ADCM		x	x	
NP300 NAVARA \ D23 \ 2016-7~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2016-7~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	AVM		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2016-7~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2016-7~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Laser/radar	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	All mode AWD/4WD	x	x	x	0245, 0311
NP300 NAVARA \ D23 \ 2016-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	Lane camera	x	x	x	
NP300 NAVARA \ D23 \ 2016-7~	CAN gateway		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Side radar right		x	x	

NP300 NAVARA \ D23 \ 2016-7~	Telematics		x	x	0253
NP300 NAVARA \ D23 \ 2016-7~	BSW/buzzer		x	x	
NP300 NAVARA \ D23 \ 2016-7~	PMAS		x	x	
NP300 NAVARA \ D23 \ 2016-7~	Head lamp levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NP300 NAVARA \ D23 \ 2016-8~	ABS	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Meter/M&A		x	x	0143
NP300 NAVARA \ D23 \ 2016-8~	BCM		x		
NP300 NAVARA \ D23 \ 2016-8~	Air bag		x	x	
NP300 NAVARA \ D23 \ 2016-8~	ICC/ADAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NP300 NAVARA \ D23 \ 2016-8~	Transmission	x	x	x	0059
NP300 NAVARA \ D23 \ 2016-8~	Multi AV	x	x	x	0280
NP300 NAVARA \ D23 \ 2016-8~	EPS/DAST 3	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	IPDM E/R		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Laser/radar	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	All mode AWD/4WD		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Difference lock	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Sonar		x	x	
NP300 NAVARA \ D23 \ 2016-8~	E-SUS		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Accele pedal ACT		x	x	
NP300 NAVARA \ D23 \ 2016-8~	PTC heater		x	x	
NP300 NAVARA \ D23 \ 2016-8~	AVM		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Occupant detection			x	
NP300 NAVARA \ D23 \ 2016-8~	Air levelizer	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Precrash seatbelt		x	x	
NP300 NAVARA \ D23 \ 2016-8~	All mode AWD/4WD	x	x	x	0245, 0311
NP300 NAVARA \ D23 \ 2016-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Sonar	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	Lane camera	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	CAN gateway		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Side radar left		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Side radar right		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Telematics		x	x	0253
NP300 NAVARA \ D23 \ 2016-8~	EMCM	x	x	x	
NP300 NAVARA \ D23 \ 2016-8~	BSW/buzzer		x	x	
NP300 NAVARA \ D23 \ 2016-8~	PMAS		x	x	
NP300 NAVARA \ D23 \ 2016-8~	Head lamp levelizer	x	x	x	

NT500 \ G40 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NT500 \ G40 \ 2013-10~	ABS	x	x	x	0003, 0092, 0264
NT500 \ G40 \ 2013-10~	Meter/M&A	x	x	x	0143, 0331
NT500 \ G40 \ 2013-10~	BCM	x	x		
NT500 \ G40 \ 2013-10~	Transmission	x	x	x	
NT500 \ G40 \ 2013-10~	Multi AV	x	x	x	0280
NT500 \ G40 \ 2013-10~	EPS/DAST 3	x	x	x	
NT500 \ G40 \ 2013-10~	IPDM E/R		x	x	
NT500 \ G40 \ 2013-10~	Air pressure monitor	x	x	x	
NT500 \ G40 \ 2013-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NT500 \ G40 \ 2013-10~	All mode AWD/4WD	x	x	x	0245, 0311
NT500 \ G40 \ 2013-10~	E-SUS		x	x	
NT500 \ G40 \ 2013-10~	ADCM		x	x	0090, 0313, 0198, 0183, 0184, 0255, 0091, 0256, 0254, 0095
NT500 \ G40 \ 2013-10~	PTC heater		x	x	
NT500 \ G40 \ 2013-10~	Air bag	x	x	x	
NT500 \ G40 \ 2013-10~	Difference lock	x	x	x	
NT500 \ G40 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NT500 \ G40 \ 2014-6~	ABS	x	x	x	0003, 0092, 0264
NT500 \ G40 \ 2014-6~	Meter/M&A	x	x	x	0143, 0331
NT500 \ G40 \ 2014-6~	BCM	x	x		
NT500 \ G40 \ 2014-6~	ICC/ADAS		x	x	
NT500 \ G40 \ 2014-6~	Transmission	x	x	x	
NT500 \ G40 \ 2014-6~	Multi AV		x	x	
NT500 \ G40 \ 2014-6~	IPDM E/R		x	x	
NT500 \ G40 \ 2014-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NT500 \ G40 \ 2014-6~	Lane camera	x	x	x	
NT500 \ G40 \ 2014-6~	ADCM		x	x	0090, 0313, 0198, 0183, 0184, 0255, 0091, 0256, 0254, 0095
NT500 \ G40 \ 2014-6~	PTC heater		x	x	
NT500 \ G40 \ 2014-6~	BSW/buzzer		x	x	
NT500 \ G40 \ 2014-6~	Air bag	x	x	x	
NT500 \ G40 \ 2014-6~	Difference lock	x	x	x	
NT500 \ G40 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

NT500 \ G40 \ 2015-6~	ABS	x	x	x	0003, 0092, 0264
NT500 \ G40 \ 2015-6~	Meter/M&A	x	x	x	0143, 0331
NT500 \ G40 \ 2015-6~	BCM	x	x		
NT500 \ G40 \ 2015-6~	ICC/ADAS		x	x	
NT500 \ G40 \ 2015-6~	Transmission	x	x	x	
NT500 \ G40 \ 2015-6~	Multi AV		x	x	
NT500 \ G40 \ 2015-6~	IPDM E/R		x	x	
NT500 \ G40 \ 2015-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NT500 \ G40 \ 2015-6~	Lane camera	x	x	x	
NT500 \ G40 \ 2015-6~	ADCM		x	x	0090, 0313, 0198, 0183, 0184, 0255, 0091, 0256, 0254, 0095
NT500 \ G40 \ 2015-6~	PTC heater		x	x	
NT500 \ G40 \ 2015-6~	BSW/buzzer		x	x	
NT500 \ G40 \ 2015-6~	Air bag	x	x	x	
NT500 \ G40 \ 2015-6~	Difference lock	x	x	x	
NV \ F80 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2012	ABS	x	x	x	
NV \ F80 \ 2012	Meter/M&A		x	x	
NV \ F80 \ 2012	BCM	x	x		
NV \ F80 \ 2012	Air bag	x	x	x	
NV \ F80 \ 2012	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2012	IPDM E/R	x	x	x	
NV \ F80 \ 2012	Air pressure monitor	x	x	x	
NV \ F80 \ 2012	Intelligent key	x	x	x	
NV \ F80 \ 2012	Auto drive position	x	x	x	
NV \ F80 \ 2012	Transmission	x	x	x	
NV \ F80 \ 2012	Sonar	x	x	x	
NV \ F80 \ 2012	Rearview camera			x	
NV \ F80 \ 2012	S/blind camera			x	
NV \ F80 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2012-9~	ABS		x	x	
NV \ F80 \ 2012-9~	Meter/M&A		x	x	
NV \ F80 \ 2012-9~	BCM		x		
NV \ F80 \ 2012-9~	Air bag	x	x	x	
NV \ F80 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

NV \ F80 \ 2012-9~	IPDM E/R	x	x	x	
NV \ F80 \ 2012-9~	Air pressure monitor	x	x	x	
NV \ F80 \ 2012-9~	Transmission	x	x	x	
NV \ F80 \ 2012-9~	Difference lock	x	x	x	
NV \ F80 \ 2012-9~	Sonar	x	x	x	
NV \ F80 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2013	ABS	x	x	x	
NV \ F80 \ 2013	Meter/M&A		x	x	
NV \ F80 \ 2013	BCM	x	x		
NV \ F80 \ 2013	Air bag	x	x	x	
NV \ F80 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2013	IPDM E/R	x	x	x	
NV \ F80 \ 2013	Air pressure monitor	x	x	x	
NV \ F80 \ 2013	Intelligent key	x	x	x	
NV \ F80 \ 2013	Auto drive position	x	x	x	
NV \ F80 \ 2013	Transmission	x	x	x	
NV \ F80 \ 2013	Sonar	x	x	x	
NV \ F80 \ 2013	Rearview camera			x	
NV \ F80 \ 2013	S/blind camera			x	
NV \ F80 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2014	ABS	x	x	x	
NV \ F80 \ 2014	Meter/M&A		x	x	
NV \ F80 \ 2014	BCM		x		
NV \ F80 \ 2014	Air bag	x	x	x	
NV \ F80 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2014	IPDM E/R	x	x	x	
NV \ F80 \ 2014	Air pressure monitor	x	x	x	
NV \ F80 \ 2014	Transmission	x	x	x	
NV \ F80 \ 2014	Difference lock	x	x	x	
NV \ F80 \ 2014	Sonar	x	x	x	
NV \ F80 \ 2014-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2014-12~	ABS	x	x	x	
NV \ F80 \ 2014-12~	Meter/M&A		x	x	
NV \ F80 \ 2014-12~	BCM		x		
NV \ F80 \ 2014-12~	Air bag	x	x	x	

NV \ F80 \ 2014-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2014-12~	Multi AV		x	x	
NV \ F80 \ 2014-12~	IPDM E/R	x	x	x	
NV \ F80 \ 2014-12~	Air pressure monitor	x	x	x	
NV \ F80 \ 2014-12~	Transmission	x	x	x	
NV \ F80 \ 2014-12~	Head lamp levelizer	x	x	x	
NV \ F80 \ 2014-12~	Difference lock	x	x	x	
NV \ F80 \ 2014-12~	Sonar	x	x	x	
NV \ F80 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2014-1~	ABS	x	x	x	
NV \ F80 \ 2014-1~	Meter/M&A		x	x	
NV \ F80 \ 2014-1~	BCM		x		
NV \ F80 \ 2014-1~	Air bag	x	x	x	
NV \ F80 \ 2014-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2014-1~	IPDM E/R	x	x	x	
NV \ F80 \ 2014-1~	Air pressure monitor	x	x	x	
NV \ F80 \ 2014-1~	Transmission	x	x	x	
NV \ F80 \ 2014-1~	Head lamp levelizer	x	x	x	
NV \ F80 \ 2014-1~	Difference lock	x	x	x	
NV \ F80 \ 2014-1~	Sonar	x	x	x	
NV \ F80 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2015	ABS	x	x	x	
NV \ F80 \ 2015	Meter/M&A		x	x	
NV \ F80 \ 2015	BCM		x		
NV \ F80 \ 2015	Air bag	x	x	x	
NV \ F80 \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2015	Multi AV		x	x	
NV \ F80 \ 2015	IPDM E/R	x	x	x	
NV \ F80 \ 2015	Air pressure monitor	x	x	x	
NV \ F80 \ 2015	Transmission	x	x	x	
NV \ F80 \ 2015	Head lamp levelizer	x	x	x	
NV \ F80 \ 2015	Difference lock	x	x	x	
NV \ F80 \ 2015	Sonar	x	x	x	
NV \ F80 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2015-9~	ABS	x	x	x	

NV \ F80 \ 2015-9~	Meter/M&A		x	x	
NV \ F80 \ 2015-9~	BCM		x		
NV \ F80 \ 2015-9~	Air bag	x	x	x	
NV \ F80 \ 2015-9~	ICC/ADAS	x	x	x	
NV \ F80 \ 2015-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2015-9~	Transmission	x	x	x	0059
NV \ F80 \ 2015-9~	Multi AV	x	x	x	0280
NV \ F80 \ 2015-9~	EPS/DAST 3	x	x	x	
NV \ F80 \ 2015-9~	IPDM E/R	x	x	x	
NV \ F80 \ 2015-9~	Laser/radar	x	x	x	
NV \ F80 \ 2015-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
NV \ F80 \ 2015-9~	4WAS(front)	x	x	x	
NV \ F80 \ 2015-9~	E-SUS		x	x	
NV \ F80 \ 2015-9~	Accele pedal ACT		x	x	
NV \ F80 \ 2015-9~	Side radar left		x	x	
NV \ F80 \ 2015-9~	Side radar right		x	x	
NV \ F80 \ 2015-9~	AVM		x	x	
NV \ F80 \ 2015-9~	Head lamp levelizer	x	x	x	
NV \ F80 \ 2015-9~	Difference lock	x	x	x	
NV \ F80 \ 2015-9~	Sonar	x	x	x	
NV \ F80 \ 2015-9~	Occupant detection			x	
NV \ F80 \ 2015-9~	Air levelizer	x	x	x	
NV \ F80 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV \ F80 \ 2016	ABS	x	x	x	
NV \ F80 \ 2016	Meter/M&A		x	x	
NV \ F80 \ 2016	BCM	x	x		
NV \ F80 \ 2016	Air bag	x	x	x	
NV \ F80 \ 2016	ICC/ADAS	x	x	x	
NV \ F80 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV \ F80 \ 2016	Transmission	x	x	x	0059
NV \ F80 \ 2016	Multi AV	x	x	x	0280
NV \ F80 \ 2016	EPS/DAST 3	x	x	x	
NV \ F80 \ 2016	IPDM E/R	x	x	x	
NV \ F80 \ 2016	Laser/radar	x	x	x	
NV \ F80 \ 2016	4WAS(MAIN)/RAS/HICAS	x	x	x	
NV \ F80 \ 2016	4WAS(front)	x	x	x	
NV \ F80 \ 2016	E-SUS		x	x	
NV \ F80 \ 2016	Accele pedal ACT		x	x	

NV \ F80 \ 2016	Side radar left		x	x	
NV \ F80 \ 2016	Side radar right		x	x	
NV \ F80 \ 2016	AVM		x	x	
NV \ F80 \ 2016	Head lamp levelizer	x	x	x	
NV \ F80 \ 2016	Difference lock	x	x	x	
NV \ F80 \ 2016	Sonar	x	x	x	
NV \ F80 \ 2016	Occupant detection			x	
NV \ F80 \ 2016	Air levelizer	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 (EURO product) \ M20(VM20) \ 2010-2~	ABS	x	x	x	0003, 0092, 0264
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
NV200 (EURO product) \ M20(VM20) \ 2010-2~	BCM	x	x		
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Air bag	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Multi AV	x	x	x	0280
NV200 (EURO product) \ M20(VM20) \ 2010-2~	EPS/DAST 3	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	IPDM E/R	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Air pressure monitor		x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 (EURO product) \ M20(VM20) \ 2010-2~	PTC heater		x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	AVM		x	x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Occupant detection			x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	Rearview camera			x	
NV200 (EURO product) \ M20(VM20) \ 2010-2~	S/blind camera			x	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 (EURO product) \ M20(VM20) \ 2014-9~	ABS	x	x	x	0003, 0092, 0264
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
NV200 (EURO product) \ M20(VM20) \ 2014-9~	BCM	x	x		
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Air bag	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Multi AV	x	x	x	0280
NV200 (EURO product) \ M20(VM20) \ 2014-9~	EPS/DAST 3	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	IPDM E/R	x	x	x	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Air pressure monitor		x	x	

NV200 (EURO product) \ M20(VM20) \ 2014-9~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 (EURO product) \ M20(VM20) \ 2014-9~	PTC heater		×	×	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	AVM		×	×	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Occupant detection			×	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	Rearview camera			×	
NV200 (EURO product) \ M20(VM20) \ 2014-9~	S/blind camera			×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 (EURO product) \ M20(VM20) \ 2015-7~	ABS	×	×	×	0003, 0092, 0264
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Meter/M&A		×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	BCM	×	×		
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Air bag	×	×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Multi AV	×	×	×	0280
NV200 (EURO product) \ M20(VM20) \ 2015-7~	EPS/DAST 3	×	×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	IPDM E/R	×	×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Air pressure monitor		×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Auto slide door		×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	PTC heater		×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	AVM		×	×	
NV200 (EURO product) \ M20(VM20) \ 2015-7~	Occupant detection			×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 (JPN product) \ M20(VM20) \ 2009-7~	ABS	×	×	×	0003, 0092, 0264
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Meter/M&A		×	×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	BCM	×	×		
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059
NV200 (JPN product) \ M20(VM20) \ 2009-7~	EPS/DAST 3	×	×	×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	IPDM E/R	×	×	×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Air bag	×	×	×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	Rearview camera			×	
NV200 (JPN product) \ M20(VM20) \ 2009-7~	S/blind camera			×	

NV200 TAXI \ M20(VM20) \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 TAXI \ M20(VM20) \ 2014	ABS	x	x	x	0003, 0092, 0264
NV200 TAXI \ M20(VM20) \ 2014	Meter/M&A		x	x	
NV200 TAXI \ M20(VM20) \ 2014	BCM	x	x		
NV200 TAXI \ M20(VM20) \ 2014	Air bag	x	x	x	
NV200 TAXI \ M20(VM20) \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 TAXI \ M20(VM20) \ 2014	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
NV200 TAXI \ M20(VM20) \ 2014	Multi AV	x	x	x	0280
NV200 TAXI \ M20(VM20) \ 2014	EPS/DAST 3	x	x	x	
NV200 TAXI \ M20(VM20) \ 2014	IPDM E/R	x	x	x	
NV200 TAXI \ M20(VM20) \ 2014	Air pressure monitor	x	x	x	
NV200 TAXI \ M20(VM20) \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 TAXI \ M20(VM20) \ 2014	PTC heater		x	x	
NV200 TAXI \ M20(VM20) \ 2014	Occupant detection			x	
NV200 TAXI \ M20(VM20) \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 TAXI \ M20(VM20) \ 2015	ABS	x	x	x	0003, 0092, 0264
NV200 TAXI \ M20(VM20) \ 2015	Meter/M&A		x	x	
NV200 TAXI \ M20(VM20) \ 2015	BCM		x		
NV200 TAXI \ M20(VM20) \ 2015	Air bag	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 TAXI \ M20(VM20) \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 TAXI \ M20(VM20) \ 2015	EPS/DAST 3	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015	IPDM E/R	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 TAXI \ M20(VM20) \ 2015	Auto slide door		x	x	
NV200 TAXI \ M20(VM20) \ 2015	PTC heater		x	x	
NV200 TAXI \ M20(VM20) \ 2015	Occupant detection			x	
NV200 TAXI \ M20(VM20) \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 TAXI \ M20(VM20) \ 2015-3~	ABS	x	x	x	0003, 0092, 0264
NV200 TAXI \ M20(VM20) \ 2015-3~	Meter/M&A		x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	BCM	x	x		

NV200 TAXI \ M20(VM20) \ 2015-3~	Air bag	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 TAXI \ M20(VM20) \ 2015-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 TAXI \ M20(VM20) \ 2015-3~	EPS/DAST 3	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	IPDM E/R	x	x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 TAXI \ M20(VM20) \ 2015-3~	Auto slide door		x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	PTC heater		x	x	
NV200 TAXI \ M20(VM20) \ 2015-3~	Telematics		x	x	0253
NV200 TAXI \ M20(VM20) \ 2015-3~	Occupant detection			x	
NV200 TAXI \ M20(VM20) \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 TAXI \ M20(VM20) \ 2016	ABS	x	x	x	0003, 0092, 0264
NV200 TAXI \ M20(VM20) \ 2016	Meter/M&A		x	x	
NV200 TAXI \ M20(VM20) \ 2016	BCM		x		
NV200 TAXI \ M20(VM20) \ 2016	Air bag	x	x	x	
NV200 TAXI \ M20(VM20) \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 TAXI \ M20(VM20) \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 TAXI \ M20(VM20) \ 2016	Multi AV		x	x	
NV200 TAXI \ M20(VM20) \ 2016	EPS/DAST 3	x	x	x	
NV200 TAXI \ M20(VM20) \ 2016	IPDM E/R	x	x	x	
NV200 TAXI \ M20(VM20) \ 2016	Auto slide door		x	x	
NV200 TAXI \ M20(VM20) \ 2016	PTC heater		x	x	
NV200 TAXI \ M20(VM20) \ 2016	Head lamp levelizer	x	x	x	
NV200 TAXI \ M20(VM20) \ 2016	Occupant detection			x	
NV200 TAXI \ M20(VM20) \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 TAXI \ M20(VM20) \ 2017	ABS	x	x	x	0003, 0092, 0264
NV200 TAXI \ M20(VM20) \ 2017	Meter/M&A		x	x	
NV200 TAXI \ M20(VM20) \ 2017	BCM		x		
NV200 TAXI \ M20(VM20) \ 2017	Air bag	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	ICC/ADAS	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

NV200 TAXI \ M20(VM20) \ 2017	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
NV200 TAXI \ M20(VM20) \ 2017	Multi AV	x	x	x	0280
NV200 TAXI \ M20(VM20) \ 2017	EPS/DAST 3	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	IPDM E/R	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	Air pressure monitor	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	Laser/radar	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	Auto slide door		x	x	
NV200 TAXI \ M20(VM20) \ 2017	4WAS(MAIN)/RAS/HICAS	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	4WAS(front)	x	x	x	
NV200 TAXI \ M20(VM20) \ 2017	Accele pedal ACT		x	x	
NV200 TAXI \ M20(VM20) \ 2017	Side radar left		x	x	
NV200 TAXI \ M20(VM20) \ 2017	Side radar right		x	x	
NV200 TAXI \ M20(VM20) \ 2017	PTC heater		x	x	
NV200 TAXI \ M20(VM20) \ 2017	Occupant detection			x	
NV200 Vanette \ M20 \ 2009-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 Vanette \ M20 \ 2009-3~	ABS	x	x	x	0003, 0092, 0264
NV200 Vanette \ M20 \ 2009-3~	Meter/M&A		x	x	
NV200 Vanette \ M20 \ 2009-3~	BCM	x	x		
NV200 Vanette \ M20 \ 2009-3~	Air bag	x	x	x	
NV200 Vanette \ M20 \ 2009-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
NV200 Vanette \ M20 \ 2009-3~	EPS/DAST 3	x	x	x	
NV200 Vanette \ M20 \ 2009-3~	IPDM E/R	x	x	x	
NV200 Vanette \ M20 \ 2009-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 Vanette \ M20 \ 2009-3~	Auto slide door		x	x	
NV200 Vanette \ M20 \ 2009-3~	Rearview camera			x	
NV200 Vanette \ M20 \ 2009-3~	S/blind camera			x	
NV200 Vanette \ M20(VM20) \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 Vanette \ M20(VM20) \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
NV200 Vanette \ M20(VM20) \ 2012-5~	Meter/M&A		x	x	
NV200 Vanette \ M20(VM20) \ 2012-5~	BCM	x	x		
NV200 Vanette \ M20(VM20) \ 2012-5~	Air bag	x	x	x	
NV200 Vanette \ M20(VM20) \ 2012-5~	EPS/DAST 3	x	x	x	
NV200 Vanette \ M20(VM20) \ 2012-5~	IPDM E/R	x	x	x	
NV200 Vanette \ M20(VM20) \ 2012-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

NV200 Vanette \ M20(VM20) \ 2012-5~	Auto slide door		×	×	
NV200 Vanette \ M20(VM20) \ 2012-5~	Occupant detection			×	
NV200 Vanette \ M20(VM20) \ 2014-7~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 Vanette \ M20(VM20) \ 2014-7~	ABS	×	×	×	0003, 0092, 0264
NV200 Vanette \ M20(VM20) \ 2014-7~	Meter/M&A		×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	BCM	×	×		
NV200 Vanette \ M20(VM20) \ 2014-7~	Air bag	×	×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 Vanette \ M20(VM20) \ 2014-7~	Transmission	×	×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 Vanette \ M20(VM20) \ 2014-7~	EPS/DAST 3	×	×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	IPDM E/R	×	×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 Vanette \ M20(VM20) \ 2014-7~	Auto slide door		×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	PTC heater		×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	AVM		×	×	
NV200 Vanette \ M20(VM20) \ 2014-7~	Occupant detection			×	
NV200 Vanette \ M20(VM20) \ 2015-12~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 Vanette \ M20(VM20) \ 2015-12~	ABS	×	×	×	0003, 0092, 0264
NV200 Vanette \ M20(VM20) \ 2015-12~	Meter/M&A		×	×	0143, 0197, 0330, 0331
NV200 Vanette \ M20(VM20) \ 2015-12~	BCM	×	×		
NV200 Vanette \ M20(VM20) \ 2015-12~	Air bag	×	×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 Vanette \ M20(VM20) \ 2015-12~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 Vanette \ M20(VM20) \ 2015-12~	EPS/DAST 3	×	×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	IPDM E/R	×	×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 Vanette \ M20(VM20) \ 2015-12~	Auto slide door		×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	PTC heater		×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	Head lamp levelizer	×	×	×	
NV200 Vanette \ M20(VM20) \ 2015-12~	Occupant detection			×	
NV200 Vanette \ VM20 \ 2009-3~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

NV200 Vanette \ VM20 \ 2009-3~	ABS	x	x	x	0003, 0092, 0264
NV200 Vanette \ VM20 \ 2009-3~	Meter/M&A		x	x	
NV200 Vanette \ VM20 \ 2009-3~	BCM	x	x		
NV200 Vanette \ VM20 \ 2009-3~	Air bag	x	x	x	
NV200 Vanette \ VM20 \ 2009-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
NV200 Vanette \ VM20 \ 2009-3~	EPS/DAST 3	x	x	x	
NV200 Vanette \ VM20 \ 2009-3~	IPDM E/R	x	x	x	
NV200 Vanette \ VM20 \ 2009-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 Vanette \ VM20 \ 2009-3~	Auto slide door		x	x	
NV200 Vanette \ VM20 \ 2009-3~	Rearview camera			x	
NV200 Vanette \ VM20 \ 2009-3~	S/blind camera			x	
NV200 \ M20(VM20) \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2010-11~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2010-11~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2010-11~	BCM	x	x		
NV200 \ M20(VM20) \ 2010-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
NV200 \ M20(VM20) \ 2010-11~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2010-11~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2010-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2010-11~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2010-11~	Rearview camera			x	
NV200 \ M20(VM20) \ 2010-11~	S/blind camera			x	
NV200 \ M20(VM20) \ 2010-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2010-4~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2010-4~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2010-4~	BCM	x	x		
NV200 \ M20(VM20) \ 2010-4~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2010-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
NV200 \ M20(VM20) \ 2010-4~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2010-4~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2010-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2010-4~	Rearview camera			x	
NV200 \ M20(VM20) \ 2010-4~	S/blind camera			x	

NV200 \ M20(VM20) \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2011-12~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2011-12~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2011-12~	BCM	x	x		
NV200 \ M20(VM20) \ 2011-12~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2011-12~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2011-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2011-12~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2012-5~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2012-5~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2012-5~	BCM	x	x		
NV200 \ M20(VM20) \ 2012-5~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2012-5~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2012-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2012-5~	Accele pedal ACT		x	x	
NV200 \ M20(VM20) \ 2012-5~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2013	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2013	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2013	BCM	x	x		
NV200 \ M20(VM20) \ 2013	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 \ M20(VM20) \ 2013	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
NV200 \ M20(VM20) \ 2013	Multi AV	x	x	x	0280
NV200 \ M20(VM20) \ 2013	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2013	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2013	Air pressure monitor	x	x	x	
NV200 \ M20(VM20) \ 2013	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2013	PTC heater		x	x	

NV200 \ M20(VM20) \ 2013	Occupant detection			x	
NV200 \ M20(VM20) \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2013-12~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2013-12~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2013-12~	BCM	x	x		
NV200 \ M20(VM20) \ 2013-12~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2013-12~	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2013-12~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2013-12~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2013-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2013-12~	PTC heater		x	x	
NV200 \ M20(VM20) \ 2013-12~	Occupant detection			x	
NV200 \ M20(VM20) \ 2013-12~	Rearview camera			x	
NV200 \ M20(VM20) \ 2013-12~	S/blind camera			x	
NV200 \ M20(VM20) \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2013-1~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2013-1~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2013-1~	BCM	x	x		
NV200 \ M20(VM20) \ 2013-1~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2013-1~	Multi AV	x	x	x	0280
NV200 \ M20(VM20) \ 2013-1~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2013-1~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2013-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2013-1~	Occupant detection			x	
NV200 \ M20(VM20) \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2014	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2014	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2014	BCM	x	x		
NV200 \ M20(VM20) \ 2014	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2014	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2014	Multi AV	x	x	x	0280
NV200 \ M20(VM20) \ 2014	EPS/DAST 3	x	x	x	

NV200 \ M20(VM20) \ 2014	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2014	Air pressure monitor	x	x	x	
NV200 \ M20(VM20) \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2014	PTC heater		x	x	
NV200 \ M20(VM20) \ 2014	AVM		x	x	
NV200 \ M20(VM20) \ 2014	Occupant detection			x	
NV200 \ M20(VM20) \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2014-8~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2014-8~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2014-8~	BCM	x	x		
NV200 \ M20(VM20) \ 2014-8~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2014-8~	Transmission	x	x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2014-8~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2014-8~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2014-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2014-8~	PTC heater		x	x	
NV200 \ M20(VM20) \ 2014-8~	Occupant detection			x	
NV200 \ M20(VM20) \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2015	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2015	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2015	BCM	x	x		
NV200 \ M20(VM20) \ 2015	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 \ M20(VM20) \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2015	Multi AV	x	x	x	0280
NV200 \ M20(VM20) \ 2015	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2015	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2015	Air pressure monitor	x	x	x	
NV200 \ M20(VM20) \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
NV200 \ M20(VM20) \ 2015	AVM		x	x	

NV200 \ M20(VM20) \ 2015	Occupant detection			x	
NV200 \ M20(VM20) \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2015-7~	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2015-7~	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2015-7~	BCM	x	x		
NV200 \ M20(VM20) \ 2015-7~	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2015-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 \ M20(VM20) \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2015-7~	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2015-7~	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2015-7~	Air pressure monitor		x	x	
NV200 \ M20(VM20) \ 2015-7~	Auto slide door		x	x	
NV200 \ M20(VM20) \ 2015-7~	PTC heater		x	x	
NV200 \ M20(VM20) \ 2015-7~	Occupant detection			x	
NV200 \ M20(VM20) \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200 \ M20(VM20) \ 2016	ABS	x	x	x	0003, 0092, 0264
NV200 \ M20(VM20) \ 2016	Meter/M&A		x	x	
NV200 \ M20(VM20) \ 2016	BCM		x		
NV200 \ M20(VM20) \ 2016	Air bag	x	x	x	
NV200 \ M20(VM20) \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200 \ M20(VM20) \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200 \ M20(VM20) \ 2016	Multi AV		x	x	
NV200 \ M20(VM20) \ 2016	EPS/DAST 3	x	x	x	
NV200 \ M20(VM20) \ 2016	IPDM E/R	x	x	x	
NV200 \ M20(VM20) \ 2016	Auto slide door		x	x	
NV200 \ M20(VM20) \ 2016	PTC heater		x	x	
NV200 \ M20(VM20) \ 2016	Head lamp levelizer	x	x	x	
NV200 \ M20(VM20) \ 2016	Occupant detection			x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV200-EVALIA \ M20(VM20) \ 2015-7~	ABS	x	x	x	0003, 0092, 0264
NV200-EVALIA \ M20(VM20) \ 2015-7~	Meter/M&A		x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	BCM	x	x		
NV200-EVALIA \ M20(VM20) \ 2015-7~	Air bag	x	x	x	

NV200-EVALIA \ M20(VM20) \ 2015-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
NV200-EVALIA \ M20(VM20) \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
NV200-EVALIA \ M20(VM20) \ 2015-7~	EPS/DAST 3	x	x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	IPDM E/R	x	x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	Air pressure monitor		x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	Auto slide door		x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	PTC heater		x	x	
NV200-EVALIA \ M20(VM20) \ 2015-7~	Occupant detection			x	
NV350 caravan \ E26 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 caravan \ E26 \ 2012-4~	ABS	x	x	x	0003, 0092, 0264
NV350 caravan \ E26 \ 2012-4~	Meter/M&A		x	x	0143
NV350 caravan \ E26 \ 2012-4~	BCM		x		
NV350 caravan \ E26 \ 2012-4~	ICC/ADAS	x	x	x	
NV350 caravan \ E26 \ 2012-4~	Multi AV	x	x	x	0280
NV350 caravan \ E26 \ 2012-4~	EPS/DAST 3	x	x	x	
NV350 caravan \ E26 \ 2012-4~	IPDM E/R		x	x	
NV350 caravan \ E26 \ 2012-4~	Laser/radar		x	x	
NV350 caravan \ E26 \ 2012-4~	Auto slide door		x	x	
NV350 caravan \ E26 \ 2012-4~	PTC heater		x	x	
NV350 caravan \ E26 \ 2012-4~	Air bag	x	x	x	
NV350 caravan \ E26 \ 2012-4~	Transmission	x	x	x	
NV350 caravan \ E26 \ 2012-4~	Head lamp levelizer	x	x	x	
NV350 caravan \ E26 \ 2012-4~	Difference lock	x	x	x	
NV350 caravan \ E26 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 caravan \ E26 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
NV350 caravan \ E26 \ 2016-6~	Meter/M&A		x	x	0143
NV350 caravan \ E26 \ 2016-6~	BCM		x		
NV350 caravan \ E26 \ 2016-6~	ICC/ADAS	x	x	x	
NV350 caravan \ E26 \ 2016-6~	IPDM E/R		x	x	
NV350 caravan \ E26 \ 2016-6~	Laser/radar		x	x	
NV350 caravan \ E26 \ 2016-6~	Auto slide door		x	x	
NV350 caravan \ E26 \ 2016-6~	PTC heater		x	x	
NV350 caravan \ E26 \ 2016-6~	Air bag	x	x	x	
NV350 caravan \ E26 \ 2016-6~	Transmission	x	x	x	
NV350 caravan \ E26 \ 2016-6~	Head lamp levelizer	x	x	x	
NV350 caravan \ E26 \ 2016-6~	Difference lock	x	x	x	

NV350 urvan \ E26 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan \ E26 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan \ E26 \ 2012-6~	Meter/M&A		x	x	0143
NV350 urvan \ E26 \ 2012-6~	BCM		x		
NV350 urvan \ E26 \ 2012-6~	ICC/ADAS	x	x	x	
NV350 urvan \ E26 \ 2012-6~	Transmission	x	x	x	0059
NV350 urvan \ E26 \ 2012-6~	Multi AV	x	x	x	0280
NV350 urvan \ E26 \ 2012-6~	EPS/DAST 3	x	x	x	
NV350 urvan \ E26 \ 2012-6~	IPDM E/R		x	x	
NV350 urvan \ E26 \ 2012-6~	Laser/radar	x	x	x	
NV350 urvan \ E26 \ 2012-6~	Auto slide door		x	x	
NV350 urvan \ E26 \ 2012-6~	PTC heater		x	x	
NV350 urvan \ E26 \ 2012-6~	Air bag	x	x	x	
NV350 urvan \ E26 \ 2012-6~	Head lamp levelizer	x	x	x	
NV350 urvan \ E26 \ 2012-6~	Difference lock	x	x	x	
NV350 urvan \ E26 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan \ E26 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan \ E26 \ 2016-6~	Meter/M&A		x	x	0143
NV350 urvan \ E26 \ 2016-6~	BCM		x		
NV350 urvan \ E26 \ 2016-6~	ICC/ADAS	x	x	x	
NV350 urvan \ E26 \ 2016-6~	EPS/DAST 3	x	x	x	
NV350 urvan \ E26 \ 2016-6~	IPDM E/R		x	x	
NV350 urvan \ E26 \ 2016-6~	Laser/radar	x	x	x	
NV350 urvan \ E26 \ 2016-6~	Auto slide door		x	x	
NV350 urvan \ E26 \ 2016-6~	Accele pedal ACT		x	x	
NV350 urvan \ E26 \ 2016-6~	PTC heater		x	x	
NV350 urvan \ E26 \ 2016-6~	Air bag	x	x	x	
NV350 urvan \ E26 \ 2016-6~	Transmission	x	x	x	
NV350 urvan \ E26 \ 2016-6~	Head lamp levelizer	x	x	x	
NV350 urvan \ E26 \ 2016-6~	Difference lock	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	ABS	x	x	x	0003, 0092, 0264
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Meter/M&A		x	x	0143
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	BCM		x		
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	ICC/ADAS	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Transmission	x	x	x	0059
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	EPS/DAST 3	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	IPDM E/R		x	x	

NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Air pressure monitor	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Laser/radar	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Auto slide door		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Accele pedal ACT		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	PTC heater		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	AVM		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Air bag	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Head lamp levelizer	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2014-2~	Difference lock	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Meter/M&A		x	x	0143
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	BCM		x		
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	ICC/ADAS	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	EPS/DAST 3	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	IPDM E/R		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Laser/radar	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Auto slide door		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Accele pedal ACT		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	PTC heater		x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Air bag	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Transmission	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Head lamp levelizer	x	x	x	
NV350 URVAN-CARAVAN \ E26 \ 2016-6~	Difference lock	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan-NV350 \ E26 \ 2012-4~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan-NV350 \ E26 \ 2012-4~	Meter/M&A		x	x	0143
NV350 urvan-NV350 \ E26 \ 2012-4~	BCM		x		
NV350 urvan-NV350 \ E26 \ 2012-4~	ICC/ADAS	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Transmission	x	x	x	0059
NV350 urvan-NV350 \ E26 \ 2012-4~	Multi AV	x	x	x	0280
NV350 urvan-NV350 \ E26 \ 2012-4~	EPS/DAST 3	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	IPDM E/R		x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Laser/radar	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Auto slide door		x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	PTC heater		x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Air bag	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Head lamp levelizer	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-4~	Difference lock	x	x	x	

NV350 urvan-NV350 \ E26 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan-NV350 \ E26 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan-NV350 \ E26 \ 2012-6~	Meter/M&A		x	x	0143
NV350 urvan-NV350 \ E26 \ 2012-6~	BCM		x		
NV350 urvan-NV350 \ E26 \ 2012-6~	ICC/ADAS	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Transmission	x	x	x	0059
NV350 urvan-NV350 \ E26 \ 2012-6~	Multi AV	x	x	x	0280
NV350 urvan-NV350 \ E26 \ 2012-6~	EPS/DAST 3	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	IPDM E/R		x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Laser/radar	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Auto slide door		x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	PTC heater		x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Air bag	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Head lamp levelizer	x	x	x	
NV350 urvan-NV350 \ E26 \ 2012-6~	Difference lock	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan-NV350 \ E26 \ 2014-3~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan-NV350 \ E26 \ 2014-3~	Meter/M&A		x	x	0143
NV350 urvan-NV350 \ E26 \ 2014-3~	BCM		x		
NV350 urvan-NV350 \ E26 \ 2014-3~	ICC/ADAS	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Transmission	x	x	x	0059
NV350 urvan-NV350 \ E26 \ 2014-3~	EPS/DAST 3	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	IPDM E/R		x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Air pressure monitor	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Laser/radar	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Auto slide door		x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Accele pedal ACT		x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	PTC heater		x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	AVM		x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Air bag	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Head lamp levelizer	x	x	x	
NV350 urvan-NV350 \ E26 \ 2014-3~	Difference lock	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
NV350 urvan-NV350 \ E26 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
NV350 urvan-NV350 \ E26 \ 2016-6~	Meter/M&A		x	x	0143
NV350 urvan-NV350 \ E26 \ 2016-6~	BCM		x		
NV350 urvan-NV350 \ E26 \ 2016-6~	ICC/ADAS	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	EPS/DAST 3	x	x	x	

NV350 urvan-NV350 \ E26 \ 2016-6~	IPDM E/R		x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Laser/radar	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Auto slide door		x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Accele pedal ACT		x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	PTC heater		x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Air bag	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Transmission	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Head lamp levelizer	x	x	x	
NV350 urvan-NV350 \ E26 \ 2016-6~	Difference lock	x	x	x	
NV400 \ X62 \ 2011-9~	Engine		x	x	0107, 0079, 0145, 0064, 0128, 0148, 0188, 0187, 0020, 0189, 0021, 0166, 0104, 0190, 0191, 0252, 0011, 0125, 0082, 0034, 0080, 0035, 0081, 0210, 0112, 0139, 0275, 0028, 0025, 0006, 0262, 0023, 0306, 0225, 0010, 0205, 0097, 0220
NV400 \ X62 \ 2011-9~	ABS		x	x	0336, 0263, 0001, 0269, 0055
NV400 \ X62 \ 2011-9~	BCM		x	x	0271, 0066
NV400 \ X62 \ 2011-9~	Air bag		x	x	0317, 0341
NV400 \ X62 \ 2011-9~	Transmission		x	x	0178, 0213
NV400 \ X62 \ 2011-9~	Multi AV		x	x	0336, 0240
NV400 \ X62 \ 2011-9~	IPDM E/R		x	x	0078, 0073, 0077, 0188, 0187, 0236, 0189, 0044, 0336, 0190, 0191, 0252, 0186, 0046, 0047, 0045, 0057, 0058
NV400 \ X62 \ 2011-9~	Intelligent key		x	x	
NV400 \ X62 \ 2011-9~	CIU		x	x	
NV400 \ X62 \ 2011-9~	MM conn		x	x	0101, 0336
NV400 \ X62 \ 2011-9~	Cluster		x	x	0312, 0194, 0312, 0199, 0239, 0171, 0201, 0200, 0030
NV400 \ X62 \ 2011-9~	CHA		x	x	0074
NV400 \ X62 \ 2011-9~	Radio		x	x	
NV400 \ X62 \ 2011-9~	BAC	x	x	x	
NV400 \ X62 \ 2011-9~	Sonar		x	x	0062
NV400 \ X62 \ 2011-9~	Engine		x	x	0107, 0125, 0079, 0145, 0128, 0064, 0148, 0188, 0187, 0020, 0021, 0189, 0166, 0104, 0190, 0191, 0252, 0011, 0107, 0125, 0082, 0034, 0080, 0035, 0081, 0210, 0112, 0139, 0275, 0010, 0028, 0025, 0262, 0006, 0023, 0306, 0225, 0205, 0097, 0220
NV400 \ X62 \ 2011-9~	BCM		x	x	0271, 0066, 0271, 0066

NV400 \ X62 \ 2011-9~	IPDM E/R		×	×	0078, 0073, 0077, 0188, 0187, 0078, 0236, 0189, 0044, 0190, 0191, 0252, 0336, 0186, 0046, 0047, 0044, 0045, 0057, 0058
NV400 \ X62 \ 2011-9~	Cluster		×	×	0312, 0194, 0199, 0312, 0239, 0171, 0201, 0200, 0030, 0030
NV400 \ X62 \ 2014-5~	Engine		×	×	0125, 0079, 0145, 0128, 0064, 0148, 0188, 0187, 0020, 0189, 0021, 0166, 0104, 0190, 0191, 0107, 0082, 0034, 0080, 0035, 0081, 0210, 0148, 0112, 0139, 0275, 0028, 0025, 0262, 0006, 0023, 0306, 0225, 0205, 0097, 0220
NV400 \ X62 \ 2014-5~	ABS		×	×	0001, 0056, 0160, 0247, 0263, 0268, 0284, 0302, 0336
NV400 \ X62 \ 2014-5~	BCM		×	×	0066, 0271
NV400 \ X62 \ 2014-5~	Air bag		×	×	0317, 0341
NV400 \ X62 \ 2014-5~	Transmission		×	×	0178, 0213
NV400 \ X62 \ 2014-5~	Multi AV		×	×	0336, 0240
NV400 \ X62 \ 2014-5~	EPS/DAST 3		×	×	
NV400 \ X62 \ 2014-5~	IPDM E/R		×	×	0044, 0045, 0046, 0047, 0057, 0058, 0073, 0077, 0078, 0186, 0187, 0188, 0189, 0190, 0191, 0236, 0252
NV400 \ X62 \ 2014-5~	Air pressure monitor	×	×	×	
NV400 \ X62 \ 2014-5~	BAC	×	×	×	
NV400 \ X62 \ 2014-5~	Intelligent key		×	×	
NV400 \ X62 \ 2014-5~	ADCM		×	×	
NV400 \ X62 \ 2014-5~	CIU		×	×	
NV400 \ X62 \ 2014-5~	Cluster		×	×	0030, 0171, 0194, 0199, 0200, 0201, 0239, 0312
NV400 \ X62 \ 2014-5~	CHA		×	×	0074
NV400 \ X62 \ 2014-5~	Radio		×	×	
NV400 \ X62 \ 2014-5~	Sonar		×	×	0062
Paladin \ D22W \ 2003-3~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paladin \ D22W \ 2003-3~	ABS	×	×	×	0003, 0092, 0264
Paladin \ D22W \ 2003-3~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Paladin \ D22W \ 2003-3~	BCM	×	×		
Paladin \ D22W \ 2003-3~	Air bag	×	×	×	
Paladin \ D22W \ 2003-3~	ICC/ADAS	×	×	×	
Paladin \ D22W \ 2003-3~	HVAC	×	×	×	
Paladin \ D22W \ 2003-3~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059
Paladin \ D22W \ 2003-3~	Multi AV	×	×	×	0280

Paladin \ D22W \ 2003-3~	EPS/DAST 3	x	x	x	
Paladin \ D22W \ 2003-3~	IPDM E/R	x	x	x	
Paladin \ D22W \ 2003-3~	Air pressure monitor	x	x	x	
Paladin \ D22W \ 2003-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paladin \ D22W \ 2003-3~	DIU	x	x	x	
Paladin \ D22W \ 2003-3~	Auto slide door	x	x	x	
Paladin \ D22W \ 2003-3~	Auto drive position	x	x	x	
Paladin \ D22W \ 2003-3~	All mode AWD/4WD	x	x	x	
Paladin \ D22W \ 2003-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paladin \ D22W \ 2003-3~	Sonar	x	x	x	
Paladin \ D22W \ 2003-3~	Lane camera	x	x	x	
Paladin \ D22W \ 2003-3~	Adaptive light	x	x	x	
Paladin \ D22W \ 2003-3~	AVM		x	x	
Paladin \ D22W \ 2003-3~	Head lamp levelizer	x	x	x	
Paladin \ D22W \ 2003-3~	Difference lock	x	x	x	
Paladin \ D22W \ 2003-3~	Nats immu	x	x		
Paladin \ D22W \ 2003-3~	Smart entrance	x	x		
Paladin \ D22W \ 2003-3~	Air levelizer	x	x	x	
Paladin \ D22W \ 2003-3~	Rearview camera			x	
Paladin \ D22W \ 2003-3~	S/blind camera			x	
Paladin \ D22W \ 2003-3~	Motor assist	x	x	x	
Paladin \ D22W \ 2015-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paladin \ D22W \ 2015-4~	ABS	x	x	x	0003, 0092, 0264
Paladin \ D22W \ 2015-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paladin \ D22W \ 2015-4~	EPS/DAST 3	x	x	x	
Paladin \ D22W \ 2015-4~	Air bag	x	x	x	
Paramedic \ E50 \ 1998-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 1998-5~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 1998-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 1998-5~	BCM	x	x		
Paramedic \ E50 \ 1998-5~	Air bag	x	x	x	
Paramedic \ E50 \ 1998-5~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 1998-5~	HVAC	x	x	x	
Paramedic \ E50 \ 1998-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 1998-5~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 1998-5~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 1998-5~	IPDM E/R	x	x	x	

Paramedic \ E50 \ 1998-5~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 1998-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 1998-5~	DIU	x	x	x	
Paramedic \ E50 \ 1998-5~	Auto slide door	x	x	x	
Paramedic \ E50 \ 1998-5~	Auto drive position	x	x	x	
Paramedic \ E50 \ 1998-5~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 1998-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 1998-5~	Sonar	x	x	x	
Paramedic \ E50 \ 1998-5~	Lane camera	x	x	x	
Paramedic \ E50 \ 1998-5~	Adaptive light	x	x	x	
Paramedic \ E50 \ 1998-5~	AVM		x	x	
Paramedic \ E50 \ 1998-5~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 1998-5~	Difference lock	x	x	x	
Paramedic \ E50 \ 1998-5~	Nats immu	x	x		
Paramedic \ E50 \ 1998-5~	Smart entrance	x	x		
Paramedic \ E50 \ 1998-5~	Air levelizer	x	x	x	
Paramedic \ E50 \ 1998-5~	Rearview camera			x	
Paramedic \ E50 \ 1998-5~	S/blind camera			x	
Paramedic \ E50 \ 1998-5~	Motor assist	x	x	x	
Paramedic \ E50 \ 2001-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2001-8~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2001-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2001-8~	BCM	x	x		
Paramedic \ E50 \ 2001-8~	Air bag	x	x	x	
Paramedic \ E50 \ 2001-8~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2001-8~	HVAC	x	x	x	
Paramedic \ E50 \ 2001-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2001-8~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2001-8~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2001-8~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2001-8~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2001-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2001-8~	DIU	x	x	x	
Paramedic \ E50 \ 2001-8~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2001-8~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2001-8~	All mode AWD/4WD	x	x	x	

Paramedic \ E50 \ 2001-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2001-8~	Sonar	x	x	x	
Paramedic \ E50 \ 2001-8~	Lane camera	x	x	x	
Paramedic \ E50 \ 2001-8~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2001-8~	AVM		x	x	
Paramedic \ E50 \ 2001-8~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2001-8~	Difference lock	x	x	x	
Paramedic \ E50 \ 2001-8~	Nats immu	x	x		
Paramedic \ E50 \ 2001-8~	Smart entrance	x	x		
Paramedic \ E50 \ 2001-8~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2001-8~	Rearview camera			x	
Paramedic \ E50 \ 2001-8~	S/blind camera			x	
Paramedic \ E50 \ 2001-8~	Motor assist	x	x	x	
Paramedic \ E50 \ 2003-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2003-9~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2003-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2003-9~	BCM	x	x		
Paramedic \ E50 \ 2003-9~	Air bag	x	x	x	
Paramedic \ E50 \ 2003-9~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2003-9~	HVAC	x	x	x	
Paramedic \ E50 \ 2003-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2003-9~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2003-9~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2003-9~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2003-9~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2003-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2003-9~	DIU	x	x	x	
Paramedic \ E50 \ 2003-9~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2003-9~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2003-9~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2003-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2003-9~	Sonar	x	x	x	
Paramedic \ E50 \ 2003-9~	Lane camera	x	x	x	
Paramedic \ E50 \ 2003-9~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2003-9~	AVM		x	x	
Paramedic \ E50 \ 2003-9~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2003-9~	Difference lock	x	x	x	
Paramedic \ E50 \ 2003-9~	Nats immu	x	x		

Paramedic \ E50 \ 2003-9~	Smart entrance	x	x		
Paramedic \ E50 \ 2003-9~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2003-9~	Rearview camera			x	
Paramedic \ E50 \ 2003-9~	S/blind camera			x	
Paramedic \ E50 \ 2003-9~	Motor assist	x	x	x	
Paramedic \ E50 \ 2005-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2005-4~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2005-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2005-4~	BCM	x	x		
Paramedic \ E50 \ 2005-4~	Air bag	x	x	x	
Paramedic \ E50 \ 2005-4~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2005-4~	HVAC	x	x	x	
Paramedic \ E50 \ 2005-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2005-4~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2005-4~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2005-4~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2005-4~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2005-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2005-4~	DIU	x	x	x	
Paramedic \ E50 \ 2005-4~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2005-4~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2005-4~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2005-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2005-4~	Sonar	x	x	x	
Paramedic \ E50 \ 2005-4~	Lane camera	x	x	x	
Paramedic \ E50 \ 2005-4~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2005-4~	AVM		x	x	
Paramedic \ E50 \ 2005-4~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2005-4~	Difference lock	x	x	x	
Paramedic \ E50 \ 2005-4~	Nats immu	x	x		
Paramedic \ E50 \ 2005-4~	Smart entrance	x	x		
Paramedic \ E50 \ 2005-4~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2005-4~	Rearview camera			x	
Paramedic \ E50 \ 2005-4~	S/blind camera			x	
Paramedic \ E50 \ 2005-4~	Motor assist	x	x	x	
Paramedic \ E50 \ 2006-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2006-1~	ABS	x	x	x	0003, 0092, 0264

Paramedic \ E50 \ 2006-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2006-1~	BCM	x	x		
Paramedic \ E50 \ 2006-1~	Air bag	x	x	x	
Paramedic \ E50 \ 2006-1~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2006-1~	HVAC	x	x	x	
Paramedic \ E50 \ 2006-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2006-1~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2006-1~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2006-1~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2006-1~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2006-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2006-1~	DIU	x	x	x	
Paramedic \ E50 \ 2006-1~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2006-1~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2006-1~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2006-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2006-1~	Sonar	x	x	x	
Paramedic \ E50 \ 2006-1~	Lane camera	x	x	x	
Paramedic \ E50 \ 2006-1~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2006-1~	AVM		x	x	
Paramedic \ E50 \ 2006-1~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2006-1~	Difference lock	x	x	x	
Paramedic \ E50 \ 2006-1~	Nats immu	x	x		
Paramedic \ E50 \ 2006-1~	Smart entrance	x	x		
Paramedic \ E50 \ 2006-1~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2006-1~	Rearview camera			x	
Paramedic \ E50 \ 2006-1~	S/blind camera			x	
Paramedic \ E50 \ 2006-1~	Motor assist	x	x	x	
Paramedic \ E50 \ 2007-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2007-9~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2007-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2007-9~	BCM	x	x		
Paramedic \ E50 \ 2007-9~	Air bag	x	x	x	
Paramedic \ E50 \ 2007-9~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2007-9~	HVAC	x	x	x	
Paramedic \ E50 \ 2007-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2007-9~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2007-9~	EPS/DAST 3	x	x	x	

Paramedic \ E50 \ 2007-9~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2007-9~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2007-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2007-9~	DIU	x	x	x	
Paramedic \ E50 \ 2007-9~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2007-9~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2007-9~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2007-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2007-9~	Sonar	x	x	x	
Paramedic \ E50 \ 2007-9~	Lane camera	x	x	x	
Paramedic \ E50 \ 2007-9~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2007-9~	AVM		x	x	
Paramedic \ E50 \ 2007-9~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2007-9~	Difference lock	x	x	x	
Paramedic \ E50 \ 2007-9~	Nats immu	x	x		
Paramedic \ E50 \ 2007-9~	Smart entrance	x	x		
Paramedic \ E50 \ 2007-9~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2007-9~	Rearview camera			x	
Paramedic \ E50 \ 2007-9~	S/blind camera			x	
Paramedic \ E50 \ 2007-9~	Motor assist	x	x	x	
Paramedic \ E50 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2008-6~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2008-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2008-6~	BCM	x	x		
Paramedic \ E50 \ 2008-6~	Air bag	x	x	x	
Paramedic \ E50 \ 2008-6~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2008-6~	HVAC	x	x	x	
Paramedic \ E50 \ 2008-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2008-6~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2008-6~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2008-6~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2008-6~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2008-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2008-6~	DIU	x	x	x	
Paramedic \ E50 \ 2008-6~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2008-6~	Auto drive position	x	x	x	

Paramedic \ E50 \ 2008-6~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2008-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2008-6~	Sonar	x	x	x	
Paramedic \ E50 \ 2008-6~	Lane camera	x	x	x	
Paramedic \ E50 \ 2008-6~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2008-6~	AVM		x	x	
Paramedic \ E50 \ 2008-6~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2008-6~	Difference lock	x	x	x	
Paramedic \ E50 \ 2008-6~	Nats immu	x	x		
Paramedic \ E50 \ 2008-6~	Smart entrance	x	x		
Paramedic \ E50 \ 2008-6~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2008-6~	Rearview camera			x	
Paramedic \ E50 \ 2008-6~	S/blind camera			x	
Paramedic \ E50 \ 2008-6~	Motor assist	x	x	x	
Paramedic \ E50 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2010-8~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2010-8~	BCM	x	x		
Paramedic \ E50 \ 2010-8~	Air bag	x	x	x	
Paramedic \ E50 \ 2010-8~	ICC/ADAS	x	x	x	
Paramedic \ E50 \ 2010-8~	HVAC	x	x	x	
Paramedic \ E50 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Paramedic \ E50 \ 2010-8~	Multi AV	x	x	x	0280
Paramedic \ E50 \ 2010-8~	EPS/DAST 3	x	x	x	
Paramedic \ E50 \ 2010-8~	IPDM E/R	x	x	x	
Paramedic \ E50 \ 2010-8~	Air pressure monitor	x	x	x	
Paramedic \ E50 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Paramedic \ E50 \ 2010-8~	DIU	x	x	x	
Paramedic \ E50 \ 2010-8~	Auto slide door	x	x	x	
Paramedic \ E50 \ 2010-8~	Auto drive position	x	x	x	
Paramedic \ E50 \ 2010-8~	All mode AWD/4WD	x	x	x	
Paramedic \ E50 \ 2010-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Paramedic \ E50 \ 2010-8~	Sonar	x	x	x	
Paramedic \ E50 \ 2010-8~	Lane camera	x	x	x	
Paramedic \ E50 \ 2010-8~	Adaptive light	x	x	x	
Paramedic \ E50 \ 2010-8~	AVM		x	x	
Paramedic \ E50 \ 2010-8~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2010-8~	Difference lock	x	x	x	

Paramedic \ E50 \ 2010-8~	Nats immu	x	x		
Paramedic \ E50 \ 2010-8~	Smart entrance	x	x		
Paramedic \ E50 \ 2010-8~	Air levelizer	x	x	x	
Paramedic \ E50 \ 2010-8~	Rearview camera			x	
Paramedic \ E50 \ 2010-8~	S/blind camera			x	
Paramedic \ E50 \ 2010-8~	Motor assist	x	x	x	
Paramedic \ E50 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2012-7~	ABS	x	x	x	0003, 0092, 0264
Paramedic \ E50 \ 2012-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2012-7~	Air bag	x	x	x	
Paramedic \ E50 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Paramedic \ E50 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Paramedic \ E50 \ 2014-5~	Air bag	x	x	x	
Paramedic \ E50 \ 2014-5~	Transmission	x	x	x	
Paramedic \ E50 \ 2014-5~	Head lamp levelizer	x	x	x	
Paramedic \ E50 \ 2014-5~	Difference lock	x	x	x	
Pathfinder armada \ TA60 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder armada \ TA60 \ 2004	ABS	x	x	x	0003, 0092, 0264
Pathfinder armada \ TA60 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder armada \ TA60 \ 2004	BCM	x	x		
Pathfinder armada \ TA60 \ 2004	Air bag	x	x	x	
Pathfinder armada \ TA60 \ 2004	ICC/ADAS	x	x	x	
Pathfinder armada \ TA60 \ 2004	HVAC	x	x	x	
Pathfinder armada \ TA60 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder armada \ TA60 \ 2004	Multi AV	x	x	x	0280
Pathfinder armada \ TA60 \ 2004	EPS/DAST 3	x	x	x	
Pathfinder armada \ TA60 \ 2004	IPDM E/R	x	x	x	
Pathfinder armada \ TA60 \ 2004	Air pressure monitor	x	x	x	
Pathfinder armada \ TA60 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder armada \ TA60 \ 2004	DIU	x	x	x	
Pathfinder armada \ TA60 \ 2004	Auto slide door	x	x	x	
Pathfinder armada \ TA60 \ 2004	Auto drive position	x	x	x	
Pathfinder armada \ TA60 \ 2004	All mode AWD/4WD	x	x	x	
Pathfinder armada \ TA60 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder armada \ TA60 \ 2004	Sonar	x	x	x	
Pathfinder armada \ TA60 \ 2004	Lane camera	x	x	x	

Pathfinder armada \ TA60 \ 2004	Adaptive light	x	x	x	
Pathfinder armada \ TA60 \ 2004	AVM		x	x	
Pathfinder armada \ TA60 \ 2004	Head lamp levelizer	x	x	x	
Pathfinder armada \ TA60 \ 2004	Difference lock	x	x	x	
Pathfinder armada \ TA60 \ 2004	Nats immu	x	x		
Pathfinder armada \ TA60 \ 2004	Smart entrance	x	x		
Pathfinder armada \ TA60 \ 2004	Air levelizer	x	x	x	
Pathfinder armada \ TA60 \ 2004	Rearview camera			x	
Pathfinder armada \ TA60 \ 2004	S/blind camera			x	
Pathfinder armada \ TA60 \ 2004	Motor assist	x	x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2013-11~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	BCM		x		
Pathfinder hybrid \ HR52 \ 2013-11~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2013-11~	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2013-11~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Lane camera		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2013-11~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2013-11~	Air bag		x	x	
Pathfinder hybrid \ HR52 \ 2013-11~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Pathfinder hybrid \ HR52 \ 2014	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2014	BCM		x		
Pathfinder hybrid \ HR52 \ 2014	Air bag		x	x	
Pathfinder hybrid \ HR52 \ 2014	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2014	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2014	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2014	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2014	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2014	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2014	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2014	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2014	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2014	Lane camera		x	x	
Pathfinder hybrid \ HR52 \ 2014	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2014	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2014	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2014	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2014	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2014	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2014	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2014	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2014	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2014-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2014-12~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	BCM		x		
Pathfinder hybrid \ HR52 \ 2014-12~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2014-12~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2014-12~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2014-12~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	All mode AWD/4WD		x	x	

Pathfinder hybrid \ HR52 \ 2014-12~	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Lane camera	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2014-12~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2014-12~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2014-1~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	BCM		x		
Pathfinder hybrid \ HR52 \ 2014-1~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2014-1~	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2014-1~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Lane camera		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2014-1~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-1~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Pathfinder hybrid \ HR52 \ 2014-4~	ABS		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	BCM		x		
Pathfinder hybrid \ HR52 \ 2014-4~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2014-4~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2014-4~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2014-4~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Lane camera	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2014-4~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2014-4~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2014-9~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	BCM		x		
Pathfinder hybrid \ HR52 \ 2014-9~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2014-9~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2014-9~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2014-9~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	IPDM E/R		x	x	

Pathfinder hybrid \ HR52 \ 2014-9~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Lane camera	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2014-9~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2014-9~	Multi AV	x	x	x	
Pathfinder hybrid \ HR52 \ 2014-9~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2015	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2015	BCM		x		
Pathfinder hybrid \ HR52 \ 2015	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2015	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2015	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2015	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2015	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2015	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2015	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2015	Sonar	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	Lane camera	x	x	x	
Pathfinder hybrid \ HR52 \ 2015	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2015	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2015	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2015	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2015	Side radar left		x	x	

Pathfinder hybrid \ HR52 \ 2015	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2015	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2015	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2015	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2015	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2015-11~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	BCM		x		
Pathfinder hybrid \ HR52 \ 2015-11~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Transmission		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2015-11~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Precrash seatbelt		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2015-11~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-11~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2015-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2015-8~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	BCM		x		

Pathfinder hybrid \ HR52 \ 2015-8~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Transmission		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2015-8~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2015-8~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Precrash seatbelt		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2015-8~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2015-8~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2016	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2016	BCM		x		
Pathfinder hybrid \ HR52 \ 2016	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2016	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2016	Transmission		x	x	
Pathfinder hybrid \ HR52 \ 2016	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2016	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2016	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2016	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2016	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2016	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2016	Precrash seatbelt		x	x	

Pathfinder hybrid \ HR52 \ 2016	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2016	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2016	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2016	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2016	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2016	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2016	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2016	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2016	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2016	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2016	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2016	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2016	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2016	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2016	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2016-1~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	BCM		x		
Pathfinder hybrid \ HR52 \ 2016-1~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Multi AV		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2016-1~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Precrash seatbelt		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2016-1~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Side radar right		x	x	

Pathfinder hybrid \ HR52 \ 2016-1~	BSW/buzzer		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-1~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2016-6~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	BCM		x		
Pathfinder hybrid \ HR52 \ 2016-6~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	ICC/ADAS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Transmission		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2016-6~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2016-6~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Laser/radar	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Precrash seatbelt		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2016-6~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-6~	Occupant detection			x	
Pathfinder hybrid \ HR52 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder hybrid \ HR52 \ 2016-7~	ABS	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Meter/M&A		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	BCM		x		
Pathfinder hybrid \ HR52 \ 2016-7~	Air bag	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	ICC/ADAS	x	x	x	

Pathfinder hybrid \ HR52 \ 2016-7~	HVAC		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder hybrid \ HR52 \ 2016-7~	Multi AV	x	x	x	0280
Pathfinder hybrid \ HR52 \ 2016-7~	Motor control		x	x	0238
Pathfinder hybrid \ HR52 \ 2016-7~	EPS/DAST 3		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	IPDM E/R		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Air pressure monitor		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Laser/radar		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Precrash seatbelt		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Auto drive position		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	All mode AWD/4WD		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Sonar		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	CAN gateway		x		
Pathfinder hybrid \ HR52 \ 2016-7~	EV/HEV		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Auto back door		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	HV battery		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Side radar left		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	VSP		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	ANC		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Side radar right		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	AVM		x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Head lamp levelizer	x	x	x	
Pathfinder hybrid \ HR52 \ 2016-7~	Occupant detection			x	
Pathfinder \ R50 \ 1995	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1995	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1995	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1995	BCM	x	x		
Pathfinder \ R50 \ 1995	Air bag	x	x	x	
Pathfinder \ R50 \ 1995	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1995	HVAC	x	x	x	
Pathfinder \ R50 \ 1995	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1995	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1995	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1995	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1995	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1995	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 1995	DIU	x	x	x	

Pathfinder \ R50 \ 1995	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1995	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1995	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1995	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1995	Sonar	x	x	x	
Pathfinder \ R50 \ 1995	Lane camera	x	x	x	
Pathfinder \ R50 \ 1995	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1995	AVM		x	x	
Pathfinder \ R50 \ 1995	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1995	Difference lock	x	x	x	
Pathfinder \ R50 \ 1995	Nats immu	x	x		
Pathfinder \ R50 \ 1995	Smart entrance	x	x		
Pathfinder \ R50 \ 1995	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1995	Rearview camera			x	
Pathfinder \ R50 \ 1995	S/blind camera			x	
Pathfinder \ R50 \ 1995	Motor assist	x	x	x	
Pathfinder \ R50 \ 1995-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1995-1~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1995-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1995-1~	BCM	x	x		
Pathfinder \ R50 \ 1995-1~	Air bag	x	x	x	
Pathfinder \ R50 \ 1995-1~	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1995-1~	HVAC	x	x	x	
Pathfinder \ R50 \ 1995-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1995-1~	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1995-1~	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1995-1~	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1995-1~	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1995-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 1995-1~	DIU	x	x	x	
Pathfinder \ R50 \ 1995-1~	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1995-1~	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1995-1~	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1995-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1995-1~	Sonar	x	x	x	
Pathfinder \ R50 \ 1995-1~	Lane camera	x	x	x	
Pathfinder \ R50 \ 1995-1~	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1995-1~	AVM		x	x	

Pathfinder \ R50 \ 1995-1~	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1995-1~	Difference lock	x	x	x	
Pathfinder \ R50 \ 1995-1~	Nats immu	x	x		
Pathfinder \ R50 \ 1995-1~	Smart entrance	x	x		
Pathfinder \ R50 \ 1995-1~	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1995-1~	Rearview camera			x	
Pathfinder \ R50 \ 1995-1~	S/blind camera			x	
Pathfinder \ R50 \ 1995-1~	Motor assist	x	x	x	
Pathfinder \ R50 \ 1996	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1996	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1996	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1996	BCM	x	x		
Pathfinder \ R50 \ 1996	Air bag	x	x	x	
Pathfinder \ R50 \ 1996	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1996	HVAC	x	x	x	
Pathfinder \ R50 \ 1996	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1996	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1996	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1996	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1996	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1996	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 1996	DIU	x	x	x	
Pathfinder \ R50 \ 1996	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1996	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1996	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1996	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1996	Sonar	x	x	x	
Pathfinder \ R50 \ 1996	Lane camera	x	x	x	
Pathfinder \ R50 \ 1996	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1996	AVM		x	x	
Pathfinder \ R50 \ 1996	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1996	Difference lock	x	x	x	
Pathfinder \ R50 \ 1996	Nats immu	x	x		
Pathfinder \ R50 \ 1996	Smart entrance	x	x		
Pathfinder \ R50 \ 1996	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1996	Rearview camera			x	
Pathfinder \ R50 \ 1996	S/blind camera			x	
Pathfinder \ R50 \ 1996	Motor assist	x	x	x	

Pathfinder \ R50 \ 1997	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1997	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1997	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1997	BCM	x	x		
Pathfinder \ R50 \ 1997	Air bag	x	x	x	
Pathfinder \ R50 \ 1997	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1997	HVAC	x	x	x	
Pathfinder \ R50 \ 1997	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1997	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1997	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1997	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1997	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1997	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 1997	DIU	x	x	x	
Pathfinder \ R50 \ 1997	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1997	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1997	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1997	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1997	Sonar	x	x	x	
Pathfinder \ R50 \ 1997	Lane camera	x	x	x	
Pathfinder \ R50 \ 1997	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1997	AVM		x	x	
Pathfinder \ R50 \ 1997	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1997	Difference lock	x	x	x	
Pathfinder \ R50 \ 1997	Nats immu	x	x		
Pathfinder \ R50 \ 1997	Smart entrance	x	x		
Pathfinder \ R50 \ 1997	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1997	Rearview camera			x	
Pathfinder \ R50 \ 1997	S/blind camera			x	
Pathfinder \ R50 \ 1997	Motor assist	x	x	x	
Pathfinder \ R50 \ 1998	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1998	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1998	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1998	BCM	x	x		
Pathfinder \ R50 \ 1998	Air bag	x	x	x	
Pathfinder \ R50 \ 1998	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1998	HVAC	x	x	x	

Pathfinder \ R50 \ 1998	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1998	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1998	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1998	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1998	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1998	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 1998	DIU	x	x	x	
Pathfinder \ R50 \ 1998	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1998	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1998	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1998	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1998	Sonar	x	x	x	
Pathfinder \ R50 \ 1998	Lane camera	x	x	x	
Pathfinder \ R50 \ 1998	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1998	AVM		x	x	
Pathfinder \ R50 \ 1998	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1998	Difference lock	x	x	x	
Pathfinder \ R50 \ 1998	Nats immu	x	x		
Pathfinder \ R50 \ 1998	Smart entrance	x	x		
Pathfinder \ R50 \ 1998	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1998	Rearview camera			x	
Pathfinder \ R50 \ 1998	S/blind camera			x	
Pathfinder \ R50 \ 1998	Motor assist	x	x	x	
Pathfinder \ R50 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 1999	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 1999	BCM	x	x		
Pathfinder \ R50 \ 1999	Air bag	x	x	x	
Pathfinder \ R50 \ 1999	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 1999	HVAC	x	x	x	
Pathfinder \ R50 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 1999	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 1999	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 1999	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 1999	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Pathfinder \ R50 \ 1999	DIU	x	x	x	
Pathfinder \ R50 \ 1999	Auto slide door	x	x	x	
Pathfinder \ R50 \ 1999	Auto drive position	x	x	x	
Pathfinder \ R50 \ 1999	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 1999	Sonar	x	x	x	
Pathfinder \ R50 \ 1999	Lane camera	x	x	x	
Pathfinder \ R50 \ 1999	Adaptive light	x	x	x	
Pathfinder \ R50 \ 1999	AVM		x	x	
Pathfinder \ R50 \ 1999	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 1999	Difference lock	x	x	x	
Pathfinder \ R50 \ 1999	Nats immu	x	x		
Pathfinder \ R50 \ 1999	Smart entrance	x	x		
Pathfinder \ R50 \ 1999	Air levelizer	x	x	x	
Pathfinder \ R50 \ 1999	Rearview camera			x	
Pathfinder \ R50 \ 1999	S/blind camera			x	
Pathfinder \ R50 \ 1999	Motor assist	x	x	x	
Pathfinder \ R50 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 2000	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 2000	BCM	x	x		
Pathfinder \ R50 \ 2000	Air bag	x	x	x	
Pathfinder \ R50 \ 2000	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 2000	HVAC	x	x	x	
Pathfinder \ R50 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 2000	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 2000	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 2000	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 2000	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 2000	DIU	x	x	x	
Pathfinder \ R50 \ 2000	Auto slide door	x	x	x	
Pathfinder \ R50 \ 2000	Auto drive position	x	x	x	
Pathfinder \ R50 \ 2000	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 2000	Sonar	x	x	x	
Pathfinder \ R50 \ 2000	Lane camera	x	x	x	
Pathfinder \ R50 \ 2000	Adaptive light	x	x	x	

Pathfinder \ R50 \ 2000	AVM		x	x	
Pathfinder \ R50 \ 2000	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 2000	Difference lock	x	x	x	
Pathfinder \ R50 \ 2000	Nats immu	x	x		
Pathfinder \ R50 \ 2000	Smart entrance	x	x		
Pathfinder \ R50 \ 2000	Air levelizer	x	x	x	
Pathfinder \ R50 \ 2000	Rearview camera			x	
Pathfinder \ R50 \ 2000	S/blind camera			x	
Pathfinder \ R50 \ 2000	Motor assist	x	x	x	
Pathfinder \ R50 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 2001	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 2001	BCM	x	x		
Pathfinder \ R50 \ 2001	Air bag	x	x	x	
Pathfinder \ R50 \ 2001	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 2001	HVAC	x	x	x	
Pathfinder \ R50 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 2001	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 2001	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 2001	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 2001	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 2001	DIU	x	x	x	
Pathfinder \ R50 \ 2001	Auto slide door	x	x	x	
Pathfinder \ R50 \ 2001	Auto drive position	x	x	x	
Pathfinder \ R50 \ 2001	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 2001	Sonar	x	x	x	
Pathfinder \ R50 \ 2001	Lane camera	x	x	x	
Pathfinder \ R50 \ 2001	Adaptive light	x	x	x	
Pathfinder \ R50 \ 2001	AVM		x	x	
Pathfinder \ R50 \ 2001	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 2001	Difference lock	x	x	x	
Pathfinder \ R50 \ 2001	Nats immu	x	x		
Pathfinder \ R50 \ 2001	Smart entrance	x	x		
Pathfinder \ R50 \ 2001	Air levelizer	x	x	x	
Pathfinder \ R50 \ 2001	Rearview camera			x	
Pathfinder \ R50 \ 2001	S/blind camera			x	

Pathfinder \ R50 \ 2001	Motor assist	x	x	x	
Pathfinder \ R50 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 2002	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 2002	BCM	x	x		
Pathfinder \ R50 \ 2002	Air bag	x	x	x	
Pathfinder \ R50 \ 2002	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 2002	HVAC	x	x	x	
Pathfinder \ R50 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 2002	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 2002	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 2002	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 2002	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 2002	DIU	x	x	x	
Pathfinder \ R50 \ 2002	Auto slide door	x	x	x	
Pathfinder \ R50 \ 2002	Auto drive position	x	x	x	
Pathfinder \ R50 \ 2002	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 2002	Sonar	x	x	x	
Pathfinder \ R50 \ 2002	Lane camera	x	x	x	
Pathfinder \ R50 \ 2002	Adaptive light	x	x	x	
Pathfinder \ R50 \ 2002	AVM		x	x	
Pathfinder \ R50 \ 2002	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 2002	Difference lock	x	x	x	
Pathfinder \ R50 \ 2002	Nats immu	x	x		
Pathfinder \ R50 \ 2002	Smart entrance	x	x		
Pathfinder \ R50 \ 2002	Air levelizer	x	x	x	
Pathfinder \ R50 \ 2002	Rearview camera			x	
Pathfinder \ R50 \ 2002	S/blind camera			x	
Pathfinder \ R50 \ 2002	Motor assist	x	x	x	
Pathfinder \ R50 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 2003	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 2003	BCM	x	x		
Pathfinder \ R50 \ 2003	Air bag	x	x	x	
Pathfinder \ R50 \ 2003	ICC/ADAS	x	x	x	

Pathfinder \ R50 \ 2003	HVAC	x	x	x	
Pathfinder \ R50 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 2003	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 2003	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 2003	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 2003	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 2003	DIU	x	x	x	
Pathfinder \ R50 \ 2003	Auto slide door	x	x	x	
Pathfinder \ R50 \ 2003	Auto drive position	x	x	x	
Pathfinder \ R50 \ 2003	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 2003	Sonar	x	x	x	
Pathfinder \ R50 \ 2003	Lane camera	x	x	x	
Pathfinder \ R50 \ 2003	Adaptive light	x	x	x	
Pathfinder \ R50 \ 2003	AVM		x	x	
Pathfinder \ R50 \ 2003	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 2003	Difference lock	x	x	x	
Pathfinder \ R50 \ 2003	Nats immu	x	x		
Pathfinder \ R50 \ 2003	Smart entrance	x	x		
Pathfinder \ R50 \ 2003	Air levelizer	x	x	x	
Pathfinder \ R50 \ 2003	Rearview camera			x	
Pathfinder \ R50 \ 2003	S/blind camera			x	
Pathfinder \ R50 \ 2003	Motor assist	x	x	x	
Pathfinder \ R50 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ 2004	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ 2004	BCM	x	x		
Pathfinder \ R50 \ 2004	Air bag	x	x	x	
Pathfinder \ R50 \ 2004	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ 2004	HVAC	x	x	x	
Pathfinder \ R50 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ 2004	Multi AV	x	x	x	0280
Pathfinder \ R50 \ 2004	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ 2004	IPDM E/R	x	x	x	
Pathfinder \ R50 \ 2004	Air pressure monitor	x	x	x	

Pathfinder \ R50 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ 2004	DIU	x	x	x	
Pathfinder \ R50 \ 2004	Auto slide door	x	x	x	
Pathfinder \ R50 \ 2004	Auto drive position	x	x	x	
Pathfinder \ R50 \ 2004	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R50 \ 2004	Sonar	x	x	x	
Pathfinder \ R50 \ 2004	Lane camera	x	x	x	
Pathfinder \ R50 \ 2004	Adaptive light	x	x	x	
Pathfinder \ R50 \ 2004	AVM		x	x	
Pathfinder \ R50 \ 2004	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ 2004	Difference lock	x	x	x	
Pathfinder \ R50 \ 2004	Nats immu	x	x		
Pathfinder \ R50 \ 2004	Smart entrance	x	x		
Pathfinder \ R50 \ 2004	Air levelizer	x	x	x	
Pathfinder \ R50 \ 2004	Rearview camera			x	
Pathfinder \ R50 \ 2004	S/blind camera			x	
Pathfinder \ R50 \ 2004	Motor assist	x	x	x	
Pathfinder \ R50 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R50 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R50 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R50 \ All Year	BCM	x	x		
Pathfinder \ R50 \ All Year	Air bag	x	x	x	
Pathfinder \ R50 \ All Year	ICC/ADAS	x	x	x	
Pathfinder \ R50 \ All Year	HVAC	x	x	x	
Pathfinder \ R50 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R50 \ All Year	Multi AV	x	x	x	0280
Pathfinder \ R50 \ All Year	EPS/DAST 3	x	x	x	
Pathfinder \ R50 \ All Year	IPDM E/R	x	x	x	
Pathfinder \ R50 \ All Year	Air pressure monitor	x	x	x	
Pathfinder \ R50 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R50 \ All Year	DIU	x	x	x	
Pathfinder \ R50 \ All Year	Auto slide door	x	x	x	
Pathfinder \ R50 \ All Year	Auto drive position	x	x	x	
Pathfinder \ R50 \ All Year	All mode AWD/4WD	x	x	x	
Pathfinder \ R50 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	

Pathfinder \ R50 \ All Year	Sonar	x	x	x	
Pathfinder \ R50 \ All Year	Lane camera	x	x	x	
Pathfinder \ R50 \ All Year	Adaptive light	x	x	x	
Pathfinder \ R50 \ All Year	AVM		x	x	
Pathfinder \ R50 \ All Year	Head lamp levelizer	x	x	x	
Pathfinder \ R50 \ All Year	Difference lock	x	x	x	
Pathfinder \ R50 \ All Year	Nats immu	x	x		
Pathfinder \ R50 \ All Year	Smart entrance	x	x		
Pathfinder \ R50 \ All Year	Air levelizer	x	x	x	
Pathfinder \ R50 \ All Year	Rearview camera			x	
Pathfinder \ R50 \ All Year	S/blind camera			x	
Pathfinder \ R50 \ All Year	Motor assist	x	x	x	
Pathfinder \ R51 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2005	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2005	BCM	x	x		
Pathfinder \ R51 \ 2005	Air bag	x	x	x	
Pathfinder \ R51 \ 2005	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2005	HVAC	x	x	x	
Pathfinder \ R51 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2005	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2005	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2005	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2005	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2005	DIU	x	x	x	
Pathfinder \ R51 \ 2005	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2005	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2005	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2005	Sonar	x	x	x	
Pathfinder \ R51 \ 2005	Lane camera	x	x	x	
Pathfinder \ R51 \ 2005	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2005	AVM		x	x	
Pathfinder \ R51 \ 2005	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2005	Difference lock	x	x	x	
Pathfinder \ R51 \ 2005	Nats immu	x	x		
Pathfinder \ R51 \ 2005	Smart entrance	x	x		

Pathfinder \ R51 \ 2005	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2005	Rearview camera			x	
Pathfinder \ R51 \ 2005	S/blind camera			x	
Pathfinder \ R51 \ 2005	Motor assist	x	x	x	
Pathfinder \ R51 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2005-12~	BCM	x	x		
Pathfinder \ R51 \ 2005-12~	Air bag	x	x	x	
Pathfinder \ R51 \ 2005-12~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2005-12~	HVAC	x	x	x	
Pathfinder \ R51 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2005-12~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2005-12~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2005-12~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2005-12~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2005-12~	DIU	x	x	x	
Pathfinder \ R51 \ 2005-12~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2005-12~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2005-12~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2005-12~	Sonar	x	x	x	
Pathfinder \ R51 \ 2005-12~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2005-12~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2005-12~	AVM		x	x	
Pathfinder \ R51 \ 2005-12~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2005-12~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2005-12~	Nats immu	x	x		
Pathfinder \ R51 \ 2005-12~	Smart entrance	x	x		
Pathfinder \ R51 \ 2005-12~	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2005-12~	Rearview camera			x	
Pathfinder \ R51 \ 2005-12~	S/blind camera			x	
Pathfinder \ R51 \ 2005-12~	Motor assist	x	x	x	
Pathfinder \ R51 \ 2005-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2005-1~	BCM	x	x		

Pathfinder \ R51 \ 2005-1~	Air bag	x	x	x	
Pathfinder \ R51 \ 2005-1~	HVAC	x	x	x	
Pathfinder \ R51 \ 2005-1~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2005-1~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2005-1~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2005-1~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2005-1~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2005-1~	ABS	x	x	x	
Pathfinder \ R51 \ 2005-1~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2005-1~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2005-1~	SVT	x	x	x	
Pathfinder \ R51 \ 2005-1~	Rearview camera			x	
Pathfinder \ R51 \ 2005-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2005-3~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2005-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2005-3~	BCM	x	x		
Pathfinder \ R51 \ 2005-3~	Air bag	x	x	x	
Pathfinder \ R51 \ 2005-3~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2005-3~	HVAC	x	x	x	
Pathfinder \ R51 \ 2005-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2005-3~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2005-3~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2005-3~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2005-3~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2005-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2005-3~	DIU	x	x	x	
Pathfinder \ R51 \ 2005-3~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2005-3~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2005-3~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2005-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2005-3~	Sonar	x	x	x	
Pathfinder \ R51 \ 2005-3~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2005-3~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2005-3~	AVM		x	x	
Pathfinder \ R51 \ 2005-3~	Head lamp levelizer	x	x	x	

Pathfinder \ R51 \ 2005-3~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2005-3~	Nats immu	x	x		
Pathfinder \ R51 \ 2005-3~	Smart entrance	x	x		
Pathfinder \ R51 \ 2005-3~	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2005-3~	Rearview camera			x	
Pathfinder \ R51 \ 2005-3~	S/blind camera			x	
Pathfinder \ R51 \ 2005-3~	Motor assist	x	x	x	
Pathfinder \ R51 \ 2005-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2005-6~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2005-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2005-6~	BCM	x	x		
Pathfinder \ R51 \ 2005-6~	Air bag	x	x	x	
Pathfinder \ R51 \ 2005-6~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2005-6~	HVAC	x	x	x	
Pathfinder \ R51 \ 2005-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2005-6~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2005-6~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2005-6~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2005-6~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2005-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2005-6~	DIU	x	x	x	
Pathfinder \ R51 \ 2005-6~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2005-6~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2005-6~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2005-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2005-6~	Sonar	x	x	x	
Pathfinder \ R51 \ 2005-6~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2005-6~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2005-6~	AVM		x	x	
Pathfinder \ R51 \ 2005-6~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2005-6~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2005-6~	Nats immu	x	x		
Pathfinder \ R51 \ 2005-6~	Smart entrance	x	x		
Pathfinder \ R51 \ 2005-6~	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2005-6~	Rearview camera			x	
Pathfinder \ R51 \ 2005-6~	S/blind camera			x	
Pathfinder \ R51 \ 2005-6~	Motor assist	x	x	x	

Pathfinder \ R51 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2006	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2006	BCM	x	x		
Pathfinder \ R51 \ 2006	Air bag	x	x	x	
Pathfinder \ R51 \ 2006	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2006	HVAC	x	x	x	
Pathfinder \ R51 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2006	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2006	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2006	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2006	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2006	DIU	x	x	x	
Pathfinder \ R51 \ 2006	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2006	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2006	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2006	Sonar	x	x	x	
Pathfinder \ R51 \ 2006	Lane camera	x	x	x	
Pathfinder \ R51 \ 2006	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2006	AVM		x	x	
Pathfinder \ R51 \ 2006	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2006	Difference lock	x	x	x	
Pathfinder \ R51 \ 2006	Nats immu	x	x		
Pathfinder \ R51 \ 2006	Smart entrance	x	x		
Pathfinder \ R51 \ 2006	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2006	Rearview camera			x	
Pathfinder \ R51 \ 2006	S/blind camera			x	
Pathfinder \ R51 \ 2006	Motor assist	x	x	x	
Pathfinder \ R51 \ 2006-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2006-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2006-7~	BCM	x	x		
Pathfinder \ R51 \ 2006-7~	Air bag	x	x	x	
Pathfinder \ R51 \ 2006-7~	HVAC	x	x	x	
Pathfinder \ R51 \ 2006-7~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2006-7~	Multi AV	x	x	x	0280

Pathfinder \ R51 \ 2006-7~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2006-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2006-7~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2006-7~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2006-7~	ABS	x	x	x	
Pathfinder \ R51 \ 2006-7~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2006-7~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2006-7~	SVT	x	x	x	
Pathfinder \ R51 \ 2006-7~	Rearview camera			x	
Pathfinder \ R51 \ 2006-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2006-9~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2006-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2006-9~	BCM	x	x		
Pathfinder \ R51 \ 2006-9~	Air bag	x	x	x	
Pathfinder \ R51 \ 2006-9~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2006-9~	HVAC	x	x	x	
Pathfinder \ R51 \ 2006-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2006-9~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2006-9~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2006-9~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2006-9~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2006-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2006-9~	DIU	x	x	x	
Pathfinder \ R51 \ 2006-9~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2006-9~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2006-9~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2006-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2006-9~	Sonar	x	x	x	
Pathfinder \ R51 \ 2006-9~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2006-9~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2006-9~	AVM		x	x	
Pathfinder \ R51 \ 2006-9~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2006-9~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2006-9~	Nats immu	x	x		
Pathfinder \ R51 \ 2006-9~	Smart entrance	x	x		
Pathfinder \ R51 \ 2006-9~	Air levelizer	x	x	x	

Pathfinder \ R51 \ 2006-9~	Rearview camera			x	
Pathfinder \ R51 \ 2006-9~	S/blind camera			x	
Pathfinder \ R51 \ 2006-9~	Motor assist	x	x	x	
Pathfinder \ R51 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2007	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2007	BCM	x	x		
Pathfinder \ R51 \ 2007	Air bag	x	x	x	
Pathfinder \ R51 \ 2007	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2007	HVAC	x	x	x	
Pathfinder \ R51 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2007	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2007	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2007	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2007	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2007	DIU	x	x	x	
Pathfinder \ R51 \ 2007	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2007	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2007	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2007	Sonar	x	x	x	
Pathfinder \ R51 \ 2007	Lane camera	x	x	x	
Pathfinder \ R51 \ 2007	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2007	AVM		x	x	
Pathfinder \ R51 \ 2007	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2007	Difference lock	x	x	x	
Pathfinder \ R51 \ 2007	Nats immu	x	x		
Pathfinder \ R51 \ 2007	Smart entrance	x	x		
Pathfinder \ R51 \ 2007	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2007	Rearview camera			x	
Pathfinder \ R51 \ 2007	S/blind camera			x	
Pathfinder \ R51 \ 2007	Motor assist	x	x	x	
Pathfinder \ R51 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2007-5~	BCM	x	x		
Pathfinder \ R51 \ 2007-5~	Air bag	x	x	x	

Pathfinder \ R51 \ 2007-5~	HVAC	x	x	x	
Pathfinder \ R51 \ 2007-5~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2007-5~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2007-5~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2007-5~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2007-5~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2007-5~	ABS	x	x	x	
Pathfinder \ R51 \ 2007-5~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2007-5~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2007-5~	SVT	x	x	x	
Pathfinder \ R51 \ 2007-5~	Rearview camera			x	
Pathfinder \ R51 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2007-5~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2007-5~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2007-5~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2007-5~	DIU	x	x	x	
Pathfinder \ R51 \ 2007-5~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2007-5~	Sonar	x	x	x	
Pathfinder \ R51 \ 2007-5~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2007-5~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2007-5~	AVM		x	x	
Pathfinder \ R51 \ 2007-5~	Nats immu	x	x		
Pathfinder \ R51 \ 2007-5~	Smart entrance	x	x		
Pathfinder \ R51 \ 2007-5~	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2007-5~	S/blind camera			x	
Pathfinder \ R51 \ 2007-5~	Motor assist	x	x	x	
Pathfinder \ R51 \ 2007-5~	Transmission	x	x	x	
Pathfinder \ R51 \ 2007-5~	Multi AV	x	x	x	
Pathfinder \ R51 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2007-7~	BCM	x	x		
Pathfinder \ R51 \ 2007-7~	Air bag	x	x	x	
Pathfinder \ R51 \ 2007-7~	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2007-7~	HVAC	x	x	x	

Pathfinder \ R51 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2007-7~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2007-7~	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2007-7~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2007-7~	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2007-7~	DIU	x	x	x	
Pathfinder \ R51 \ 2007-7~	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2007-7~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2007-7~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2007-7~	Sonar	x	x	x	
Pathfinder \ R51 \ 2007-7~	Lane camera	x	x	x	
Pathfinder \ R51 \ 2007-7~	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2007-7~	AVM		x	x	
Pathfinder \ R51 \ 2007-7~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2007-7~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2007-7~	Nats immu	x	x		
Pathfinder \ R51 \ 2007-7~	Smart entrance	x	x		
Pathfinder \ R51 \ 2007-7~	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2007-7~	Rearview camera			x	
Pathfinder \ R51 \ 2007-7~	S/blind camera			x	
Pathfinder \ R51 \ 2007-7~	Motor assist	x	x	x	
Pathfinder \ R51 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2008	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ R51 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2008	BCM	x	x		
Pathfinder \ R51 \ 2008	Air bag	x	x	x	
Pathfinder \ R51 \ 2008	ICC/ADAS	x	x	x	
Pathfinder \ R51 \ 2008	HVAC	x	x	x	
Pathfinder \ R51 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ R51 \ 2008	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2008	EPS/DAST 3	x	x	x	
Pathfinder \ R51 \ 2008	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2008	Air pressure monitor	x	x	x	
Pathfinder \ R51 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Pathfinder \ R51 \ 2008	DIU	x	x	x	
Pathfinder \ R51 \ 2008	Auto slide door	x	x	x	
Pathfinder \ R51 \ 2008	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2008	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2008	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ R51 \ 2008	Sonar	x	x	x	
Pathfinder \ R51 \ 2008	Lane camera	x	x	x	
Pathfinder \ R51 \ 2008	Adaptive light	x	x	x	
Pathfinder \ R51 \ 2008	AVM		x	x	
Pathfinder \ R51 \ 2008	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2008	Difference lock	x	x	x	
Pathfinder \ R51 \ 2008	Nats immu	x	x		
Pathfinder \ R51 \ 2008	Smart entrance	x	x		
Pathfinder \ R51 \ 2008	Air levelizer	x	x	x	
Pathfinder \ R51 \ 2008	Rearview camera			x	
Pathfinder \ R51 \ 2008	S/blind camera			x	
Pathfinder \ R51 \ 2008	Motor assist	x	x	x	
Pathfinder \ R51 \ 2008-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2008-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2008-7~	BCM	x	x		
Pathfinder \ R51 \ 2008-7~	Air bag	x	x	x	
Pathfinder \ R51 \ 2008-7~	HVAC	x	x	x	
Pathfinder \ R51 \ 2008-7~	Transmission	x	x	x	
Pathfinder \ R51 \ 2008-7~	Multi AV	x	x	x	
Pathfinder \ R51 \ 2008-7~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2008-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2008-7~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2008-7~	ABS	x	x	x	
Pathfinder \ R51 \ 2008-7~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2008-7~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2008-7~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2008-7~	SVT	x	x	x	
Pathfinder \ R51 \ 2008-7~	Rearview camera			x	
Pathfinder \ R51 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2009	BCM	x	x		
Pathfinder \ R51 \ 2009	Air bag	x	x	x	

Pathfinder \ R51 \ 2009	HVAC	x	x	x	
Pathfinder \ R51 \ 2009	Transmission	x	x	x	
Pathfinder \ R51 \ 2009	Multi AV	x	x	x	
Pathfinder \ R51 \ 2009	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2009	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2009	ABS	x	x	x	
Pathfinder \ R51 \ 2009	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2009	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2009	Difference lock	x	x	x	
Pathfinder \ R51 \ 2009	SVT	x	x	x	
Pathfinder \ R51 \ 2009	Rearview camera			x	
Pathfinder \ R51 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2009-8~	BCM	x	x		
Pathfinder \ R51 \ 2009-8~	Air bag	x	x	x	
Pathfinder \ R51 \ 2009-8~	HVAC	x	x	x	
Pathfinder \ R51 \ 2009-8~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2009-8~	Multi AV	x	x	x	
Pathfinder \ R51 \ 2009-8~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2009-8~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2009-8~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2009-8~	ABS	x	x	x	
Pathfinder \ R51 \ 2009-8~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2009-8~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2009-8~	SVT	x	x	x	
Pathfinder \ R51 \ 2009-8~	Rearview camera			x	
Pathfinder \ R51 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2010	BCM	x	x		
Pathfinder \ R51 \ 2010	Air bag	x	x	x	
Pathfinder \ R51 \ 2010	HVAC	x	x	x	
Pathfinder \ R51 \ 2010	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2010	Multi AV	x	x	x	

Pathfinder \ R51 \ 2010	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2010	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2010	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2010	ABS	x	x	x	
Pathfinder \ R51 \ 2010	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2010	Difference lock	x	x	x	
Pathfinder \ R51 \ 2010	SVT	x	x	x	
Pathfinder \ R51 \ 2010	Rearview camera			x	
Pathfinder \ R51 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2010-2~	ABS	x	x	x	
Pathfinder \ R51 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2010-2~	BCM	x	x		
Pathfinder \ R51 \ 2010-2~	Air bag	x	x	x	
Pathfinder \ R51 \ 2010-2~	HVAC	x	x	x	
Pathfinder \ R51 \ 2010-2~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2010-2~	Multi AV	x	x	x	0280
Pathfinder \ R51 \ 2010-2~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2010-2~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2010-2~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2010-2~	Auto back door		x	x	
Pathfinder \ R51 \ 2010-2~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2010-2~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2010-2~	SVT	x	x	x	
Pathfinder \ R51 \ 2010-2~	Rearview camera			x	
Pathfinder \ R51 \ 2010-2~	S/blind camera			x	
Pathfinder \ R51 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2010-8~	BCM	x	x		
Pathfinder \ R51 \ 2010-8~	Air bag	x	x	x	
Pathfinder \ R51 \ 2010-8~	HVAC	x	x	x	
Pathfinder \ R51 \ 2010-8~	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2010-8~	Multi AV	x	x	x	
Pathfinder \ R51 \ 2010-8~	IPDM E/R	x	x	x	

Pathfinder \ R51 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2010-8~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2010-8~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2010-8~	ABS	x	x	x	
Pathfinder \ R51 \ 2010-8~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2010-8~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2010-8~	SVT	x	x	x	
Pathfinder \ R51 \ 2010-8~	Rearview camera			x	
Pathfinder \ R51 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2011	BCM	x	x		
Pathfinder \ R51 \ 2011	Air bag	x	x	x	
Pathfinder \ R51 \ 2011	HVAC	x	x	x	
Pathfinder \ R51 \ 2011	Transmission	x	x	x	0059
Pathfinder \ R51 \ 2011	Multi AV	x	x	x	
Pathfinder \ R51 \ 2011	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2011	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2011	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2011	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2011	ABS	x	x	x	
Pathfinder \ R51 \ 2011	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2011	Difference lock	x	x	x	
Pathfinder \ R51 \ 2011	SVT	x	x	x	
Pathfinder \ R51 \ 2011	Rearview camera			x	
Pathfinder \ R51 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2011-8~	BCM	x	x		
Pathfinder \ R51 \ 2011-8~	Air bag	x	x	x	
Pathfinder \ R51 \ 2011-8~	HVAC	x	x	x	
Pathfinder \ R51 \ 2011-8~	Multi AV	x	x	x	
Pathfinder \ R51 \ 2011-8~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2011-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2011-8~	Auto drive position	x	x	x	

Pathfinder \ R51 \ 2011-8~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2011-8~	ABS	x	x	x	
Pathfinder \ R51 \ 2011-8~	Transmission	x	x	x	
Pathfinder \ R51 \ 2011-8~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2011-8~	Difference lock	x	x	x	
Pathfinder \ R51 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2012	BCM	x	x		
Pathfinder \ R51 \ 2012	Air bag	x	x	x	
Pathfinder \ R51 \ 2012	HVAC	x	x	x	
Pathfinder \ R51 \ 2012	Multi AV	x	x	x	
Pathfinder \ R51 \ 2012	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2012	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ R51 \ 2012	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2012	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2012	ABS	x	x	x	
Pathfinder \ R51 \ 2012	Transmission	x	x	x	
Pathfinder \ R51 \ 2012	Difference lock	x	x	x	
Pathfinder \ R51 \ 2012	Rearview camera			x	
Pathfinder \ R51 \ 2012	S/blind camera			x	
Pathfinder \ R51 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R51 \ 2012-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pathfinder \ R51 \ 2012-9~	BCM		x		
Pathfinder \ R51 \ 2012-9~	Air bag	x	x	x	
Pathfinder \ R51 \ 2012-9~	HVAC	x	x	x	
Pathfinder \ R51 \ 2012-9~	Multi AV		x	x	
Pathfinder \ R51 \ 2012-9~	IPDM E/R	x	x	x	
Pathfinder \ R51 \ 2012-9~	Auto drive position	x	x	x	
Pathfinder \ R51 \ 2012-9~	All mode AWD/4WD	x	x	x	
Pathfinder \ R51 \ 2012-9~	ABS	x	x	x	
Pathfinder \ R51 \ 2012-9~	Transmission	x	x	x	
Pathfinder \ R51 \ 2012-9~	Head lamp levelizer	x	x	x	
Pathfinder \ R51 \ 2012-9~	Difference lock	x	x	x	
Pathfinder \ R52 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2012-10~	ABS	x	x	x	
Pathfinder \ R52 \ 2012-10~	Meter/M&A		x	x	

Pathfinder \ R52 \ 2012-10~	BCM		x		
Pathfinder \ R52 \ 2012-10~	Air bag		x	x	
Pathfinder \ R52 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pathfinder \ R52 \ 2012-10~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2012-10~	Multi AV		x	x	
Pathfinder \ R52 \ 2012-10~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2012-10~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2012-10~	Auto drive position		x	x	
Pathfinder \ R52 \ 2012-10~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2012-10~	Sonar		x	x	
Pathfinder \ R52 \ 2012-10~	CAN gateway		x		
Pathfinder \ R52 \ 2012-10~	Auto back door		x	x	
Pathfinder \ R52 \ 2012-10~	AVM		x	x	
Pathfinder \ R52 \ 2012-10~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2012-10~	Occupant detection			x	
Pathfinder \ R52 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013	ABS	x	x	x	
Pathfinder \ R52 \ 2013	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013	BCM		x		
Pathfinder \ R52 \ 2013	Air bag		x	x	
Pathfinder \ R52 \ 2013	HVAC		x	x	
Pathfinder \ R52 \ 2013	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013	Multi AV		x	x	
Pathfinder \ R52 \ 2013	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013	Auto drive position		x	x	
Pathfinder \ R52 \ 2013	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013	Sonar		x	x	
Pathfinder \ R52 \ 2013	CAN gateway		x		
Pathfinder \ R52 \ 2013	Auto back door		x	x	
Pathfinder \ R52 \ 2013	AVM		x	x	
Pathfinder \ R52 \ 2013	Occupant detection			x	
Pathfinder \ R52 \ 2013-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013-2~	ABS	x	x	x	
Pathfinder \ R52 \ 2013-2~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013-2~	BCM		x		

Pathfinder \ R52 \ 2013-2~	Air bag	x	x	x	
Pathfinder \ R52 \ 2013-2~	HVAC		x	x	
Pathfinder \ R52 \ 2013-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013-2~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2013-2~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013-2~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013-2~	Auto drive position		x	x	
Pathfinder \ R52 \ 2013-2~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013-2~	Sonar		x	x	
Pathfinder \ R52 \ 2013-2~	CAN gateway		x		
Pathfinder \ R52 \ 2013-2~	Auto back door		x	x	
Pathfinder \ R52 \ 2013-2~	AVM		x	x	
Pathfinder \ R52 \ 2013-2~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2013-2~	Occupant detection			x	
Pathfinder \ R52 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013-5~	ABS	x	x	x	
Pathfinder \ R52 \ 2013-5~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013-5~	BCM		x		
Pathfinder \ R52 \ 2013-5~	Air bag	x	x	x	
Pathfinder \ R52 \ 2013-5~	HVAC		x	x	
Pathfinder \ R52 \ 2013-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013-5~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2013-5~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013-5~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013-5~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2013-5~	Auto drive position		x	x	
Pathfinder \ R52 \ 2013-5~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013-5~	Sonar		x	x	
Pathfinder \ R52 \ 2013-5~	CAN gateway		x		
Pathfinder \ R52 \ 2013-5~	Auto back door		x	x	
Pathfinder \ R52 \ 2013-5~	AVM		x	x	
Pathfinder \ R52 \ 2013-5~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2013-5~	Occupant detection			x	
Pathfinder \ R52 \ 2013-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013-6~	ABS	x	x	x	
Pathfinder \ R52 \ 2013-6~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013-6~	BCM		x		

Pathfinder \ R52 \ 2013-6~	Air bag		x	x	
Pathfinder \ R52 \ 2013-6~	HVAC		x	x	
Pathfinder \ R52 \ 2013-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013-6~	Multi AV		x	x	
Pathfinder \ R52 \ 2013-6~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013-6~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013-6~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2013-6~	Auto drive position		x	x	
Pathfinder \ R52 \ 2013-6~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013-6~	Sonar		x	x	
Pathfinder \ R52 \ 2013-6~	CAN gateway		x		
Pathfinder \ R52 \ 2013-6~	Auto back door		x	x	
Pathfinder \ R52 \ 2013-6~	AVM		x	x	
Pathfinder \ R52 \ 2013-6~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013-7~	ABS	x	x	x	
Pathfinder \ R52 \ 2013-7~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013-7~	BCM		x		
Pathfinder \ R52 \ 2013-7~	Air bag	x	x	x	
Pathfinder \ R52 \ 2013-7~	HVAC		x	x	
Pathfinder \ R52 \ 2013-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013-7~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2013-7~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013-7~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013-7~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2013-7~	Auto drive position		x	x	
Pathfinder \ R52 \ 2013-7~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013-7~	Sonar		x	x	
Pathfinder \ R52 \ 2013-7~	CAN gateway		x		
Pathfinder \ R52 \ 2013-7~	Auto back door		x	x	
Pathfinder \ R52 \ 2013-7~	AVM		x	x	
Pathfinder \ R52 \ 2013-7~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2013-7~	Occupant detection			x	
Pathfinder \ R52 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2013-9~	ABS	x	x	x	
Pathfinder \ R52 \ 2013-9~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2013-9~	BCM		x		

Pathfinder \ R52 \ 2013-9~	Air bag	x	x	x	
Pathfinder \ R52 \ 2013-9~	HVAC		x	x	
Pathfinder \ R52 \ 2013-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2013-9~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2013-9~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2013-9~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2013-9~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2013-9~	Auto drive position		x	x	
Pathfinder \ R52 \ 2013-9~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2013-9~	Sonar		x	x	
Pathfinder \ R52 \ 2013-9~	CAN gateway		x		
Pathfinder \ R52 \ 2013-9~	Auto back door		x	x	
Pathfinder \ R52 \ 2013-9~	AVM		x	x	
Pathfinder \ R52 \ 2013-9~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2013-9~	Occupant detection			x	
Pathfinder \ R52 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2014	ABS	x	x	x	
Pathfinder \ R52 \ 2014	Meter/M&A		x	x	
Pathfinder \ R52 \ 2014	BCM		x		
Pathfinder \ R52 \ 2014	Air bag	x	x	x	
Pathfinder \ R52 \ 2014	HVAC		x	x	
Pathfinder \ R52 \ 2014	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2014	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2014	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2014	IPDM E/R		x	x	
Pathfinder \ R52 \ 2014	Auto drive position		x	x	
Pathfinder \ R52 \ 2014	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2014	Sonar		x	x	
Pathfinder \ R52 \ 2014	CAN gateway		x		
Pathfinder \ R52 \ 2014	Auto back door		x	x	
Pathfinder \ R52 \ 2014	AVM		x	x	
Pathfinder \ R52 \ 2014	Occupant detection			x	
Pathfinder \ R52 \ 2014-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2014-12~	ABS	x	x	x	
Pathfinder \ R52 \ 2014-12~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2014-12~	BCM		x		
Pathfinder \ R52 \ 2014-12~	Air bag	x	x	x	

Pathfinder \ R52 \ 2014-12~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2014-12~	HVAC		x	x	
Pathfinder \ R52 \ 2014-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2014-12~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2014-12~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2014-12~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2014-12~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2014-12~	Auto drive position		x	x	
Pathfinder \ R52 \ 2014-12~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2014-12~	Sonar	x	x	x	
Pathfinder \ R52 \ 2014-12~	Lane camera	x	x	x	
Pathfinder \ R52 \ 2014-12~	CAN gateway		x	x	
Pathfinder \ R52 \ 2014-12~	Auto back door		x	x	
Pathfinder \ R52 \ 2014-12~	Accele pedal ACT		x	x	
Pathfinder \ R52 \ 2014-12~	Side radar left		x	x	
Pathfinder \ R52 \ 2014-12~	Side radar right		x	x	
Pathfinder \ R52 \ 2014-12~	Telematics		x	x	0253
Pathfinder \ R52 \ 2014-12~	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2014-12~	AVM		x	x	
Pathfinder \ R52 \ 2014-12~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2014-12~	Occupant detection			x	
Pathfinder \ R52 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2014-4~	ABS	x	x	x	
Pathfinder \ R52 \ 2014-4~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2014-4~	BCM		x		
Pathfinder \ R52 \ 2014-4~	Air bag	x	x	x	
Pathfinder \ R52 \ 2014-4~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2014-4~	HVAC		x	x	
Pathfinder \ R52 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2014-4~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2014-4~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2014-4~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2014-4~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2014-4~	Auto drive position		x	x	
Pathfinder \ R52 \ 2014-4~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2014-4~	Sonar	x	x	x	
Pathfinder \ R52 \ 2014-4~	Lane camera	x	x	x	
Pathfinder \ R52 \ 2014-4~	CAN gateway		x		

Pathfinder \ R52 \ 2014-4~	Auto back door		x	x	
Pathfinder \ R52 \ 2014-4~	Side radar left		x	x	
Pathfinder \ R52 \ 2014-4~	Side radar right		x	x	
Pathfinder \ R52 \ 2014-4~	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2014-4~	AVM		x	x	
Pathfinder \ R52 \ 2014-4~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2014-4~	Occupant detection			x	
Pathfinder \ R52 \ 2014-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2014-9~	ABS	x	x	x	
Pathfinder \ R52 \ 2014-9~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2014-9~	BCM		x		
Pathfinder \ R52 \ 2014-9~	Air bag	x	x	x	
Pathfinder \ R52 \ 2014-9~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2014-9~	HVAC		x	x	
Pathfinder \ R52 \ 2014-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2014-9~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2014-9~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2014-9~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2014-9~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2014-9~	Auto drive position		x	x	
Pathfinder \ R52 \ 2014-9~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2014-9~	Sonar	x	x	x	
Pathfinder \ R52 \ 2014-9~	Lane camera	x	x	x	
Pathfinder \ R52 \ 2014-9~	CAN gateway		x	x	
Pathfinder \ R52 \ 2014-9~	Auto back door		x	x	
Pathfinder \ R52 \ 2014-9~	Accele pedal ACT		x	x	
Pathfinder \ R52 \ 2014-9~	Side radar left		x	x	
Pathfinder \ R52 \ 2014-9~	Side radar right		x	x	
Pathfinder \ R52 \ 2014-9~	Telematics		x	x	0253
Pathfinder \ R52 \ 2014-9~	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2014-9~	AVM		x	x	
Pathfinder \ R52 \ 2014-9~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2014-9~	Occupant detection			x	
Pathfinder \ R52 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2015	ABS	x	x	x	
Pathfinder \ R52 \ 2015	Meter/M&A		x	x	
Pathfinder \ R52 \ 2015	BCM		x		
Pathfinder \ R52 \ 2015	Air bag	x	x	x	

Pathfinder \ R52 \ 2015	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2015	HVAC		x	x	
Pathfinder \ R52 \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2015	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2015	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2015	IPDM E/R		x	x	
Pathfinder \ R52 \ 2015	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2015	Auto drive position		x	x	
Pathfinder \ R52 \ 2015	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2015	Sonar	x	x	x	
Pathfinder \ R52 \ 2015	Lane camera	x	x	x	
Pathfinder \ R52 \ 2015	CAN gateway		x	x	
Pathfinder \ R52 \ 2015	Auto back door		x	x	
Pathfinder \ R52 \ 2015	Side radar left		x	x	
Pathfinder \ R52 \ 2015	Side radar right		x	x	
Pathfinder \ R52 \ 2015	AVM		x	x	
Pathfinder \ R52 \ 2015	Occupant detection			x	
Pathfinder \ R52 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2015-11~	ABS	x	x	x	
Pathfinder \ R52 \ 2015-11~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2015-11~	BCM		x		
Pathfinder \ R52 \ 2015-11~	Air bag	x	x	x	
Pathfinder \ R52 \ 2015-11~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2015-11~	HVAC		x	x	
Pathfinder \ R52 \ 2015-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2015-11~	Multi AV		x	x	
Pathfinder \ R52 \ 2015-11~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2015-11~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2015-11~	Air pressure monitor		x	x	
Pathfinder \ R52 \ 2015-11~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2015-11~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2015-11~	Auto drive position		x	x	
Pathfinder \ R52 \ 2015-11~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2015-11~	Sonar		x	x	
Pathfinder \ R52 \ 2015-11~	CAN gateway		x		
Pathfinder \ R52 \ 2015-11~	Auto back door		x	x	
Pathfinder \ R52 \ 2015-11~	Side radar left		x	x	
Pathfinder \ R52 \ 2015-11~	ANC		x	x	

Pathfinder \ R52 \ 2015-11~	Side radar right		x	x	
Pathfinder \ R52 \ 2015-11~	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2015-11~	AVM		x	x	
Pathfinder \ R52 \ 2015-11~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2015-11~	Occupant detection			x	
Pathfinder \ R52 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2016	ABS	x	x	x	
Pathfinder \ R52 \ 2016	Meter/M&A		x	x	
Pathfinder \ R52 \ 2016	BCM		x		
Pathfinder \ R52 \ 2016	Air bag	x	x	x	
Pathfinder \ R52 \ 2016	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2016	HVAC		x	x	
Pathfinder \ R52 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2016	Multi AV		x	x	
Pathfinder \ R52 \ 2016	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2016	IPDM E/R		x	x	
Pathfinder \ R52 \ 2016	Air pressure monitor		x	x	
Pathfinder \ R52 \ 2016	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2016	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2016	Auto drive position		x	x	
Pathfinder \ R52 \ 2016	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2016	Sonar		x	x	
Pathfinder \ R52 \ 2016	CAN gateway		x		
Pathfinder \ R52 \ 2016	Auto back door		x	x	
Pathfinder \ R52 \ 2016	Side radar left		x	x	
Pathfinder \ R52 \ 2016	ANC		x	x	
Pathfinder \ R52 \ 2016	Side radar right		x	x	
Pathfinder \ R52 \ 2016	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2016	AVM		x	x	
Pathfinder \ R52 \ 2016	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2016	Occupant detection			x	
Pathfinder \ R52 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2016-2~	ABS	x	x	x	
Pathfinder \ R52 \ 2016-2~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2016-2~	BCM		x		
Pathfinder \ R52 \ 2016-2~	Air bag	x	x	x	
Pathfinder \ R52 \ 2016-2~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2016-2~	HVAC		x	x	

Pathfinder \ R52 \ 2016-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2016-2~	Multi AV		x	x	
Pathfinder \ R52 \ 2016-2~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2016-2~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2016-2~	Air pressure monitor		x	x	
Pathfinder \ R52 \ 2016-2~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2016-2~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2016-2~	Auto drive position		x	x	
Pathfinder \ R52 \ 2016-2~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2016-2~	Sonar		x	x	
Pathfinder \ R52 \ 2016-2~	CAN gateway		x		
Pathfinder \ R52 \ 2016-2~	Auto back door		x	x	
Pathfinder \ R52 \ 2016-2~	Side radar left		x	x	
Pathfinder \ R52 \ 2016-2~	ANC		x	x	
Pathfinder \ R52 \ 2016-2~	Side radar right		x	x	
Pathfinder \ R52 \ 2016-2~	BSW/buzzer		x	x	
Pathfinder \ R52 \ 2016-2~	AVM		x	x	
Pathfinder \ R52 \ 2016-2~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2016-2~	Occupant detection			x	
Pathfinder \ R52 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2016-6~	ABS	x	x	x	
Pathfinder \ R52 \ 2016-6~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2016-6~	BCM		x		
Pathfinder \ R52 \ 2016-6~	Air bag	x	x	x	
Pathfinder \ R52 \ 2016-6~	ICC/ADAS	x	x	x	
Pathfinder \ R52 \ 2016-6~	HVAC		x	x	
Pathfinder \ R52 \ 2016-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2016-6~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2016-6~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2016-6~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2016-6~	Air pressure monitor		x	x	
Pathfinder \ R52 \ 2016-6~	Laser/radar	x	x	x	
Pathfinder \ R52 \ 2016-6~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2016-6~	Auto drive position		x	x	
Pathfinder \ R52 \ 2016-6~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2016-6~	Sonar		x	x	
Pathfinder \ R52 \ 2016-6~	CAN gateway		x		
Pathfinder \ R52 \ 2016-6~	Auto back door		x	x	

Pathfinder \ R52 \ 2016-6~	Side radar left		x	x	
Pathfinder \ R52 \ 2016-6~	ANC		x	x	
Pathfinder \ R52 \ 2016-6~	Side radar right		x	x	
Pathfinder \ R52 \ 2016-6~	AVM		x	x	
Pathfinder \ R52 \ 2016-6~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2016-6~	Occupant detection			x	
Pathfinder \ R52 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ R52 \ 2016-7~	ABS	x	x	x	
Pathfinder \ R52 \ 2016-7~	Meter/M&A		x	x	
Pathfinder \ R52 \ 2016-7~	BCM		x		
Pathfinder \ R52 \ 2016-7~	Air bag	x	x	x	
Pathfinder \ R52 \ 2016-7~	ICC/ADAS		x	x	
Pathfinder \ R52 \ 2016-7~	HVAC		x	x	
Pathfinder \ R52 \ 2016-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Pathfinder \ R52 \ 2016-7~	Multi AV	x	x	x	0280
Pathfinder \ R52 \ 2016-7~	Motor control		x	x	0238
Pathfinder \ R52 \ 2016-7~	EPS/DAST 3		x	x	
Pathfinder \ R52 \ 2016-7~	IPDM E/R		x	x	
Pathfinder \ R52 \ 2016-7~	Air pressure monitor		x	x	
Pathfinder \ R52 \ 2016-7~	Laser/radar		x	x	
Pathfinder \ R52 \ 2016-7~	Precrash seatbelt		x	x	
Pathfinder \ R52 \ 2016-7~	Auto drive position		x	x	
Pathfinder \ R52 \ 2016-7~	All mode AWD/4WD		x	x	
Pathfinder \ R52 \ 2016-7~	Sonar		x	x	
Pathfinder \ R52 \ 2016-7~	CAN gateway		x		
Pathfinder \ R52 \ 2016-7~	EV/HEV		x	x	
Pathfinder \ R52 \ 2016-7~	Auto back door		x	x	
Pathfinder \ R52 \ 2016-7~	HV battery		x	x	
Pathfinder \ R52 \ 2016-7~	Side radar left		x	x	
Pathfinder \ R52 \ 2016-7~	VSP		x	x	
Pathfinder \ R52 \ 2016-7~	ANC		x	x	
Pathfinder \ R52 \ 2016-7~	Side radar right		x	x	
Pathfinder \ R52 \ 2016-7~	AVM		x	x	
Pathfinder \ R52 \ 2016-7~	Head lamp levelizer	x	x	x	
Pathfinder \ R52 \ 2016-7~	Occupant detection			x	
Pathfinder \ WD21 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pathfinder \ WD21 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pathfinder \ WD21 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Pathfinder \ WD21 \ All Year	BCM	x	x		
Pathfinder \ WD21 \ All Year	Air bag	x	x	x	
Pathfinder \ WD21 \ All Year	ICC/ADAS	x	x	x	
Pathfinder \ WD21 \ All Year	HVAC	x	x	x	
Pathfinder \ WD21 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pathfinder \ WD21 \ All Year	Multi AV	x	x	x	0280
Pathfinder \ WD21 \ All Year	EPS/DAST 3	x	x	x	
Pathfinder \ WD21 \ All Year	IPDM E/R	x	x	x	
Pathfinder \ WD21 \ All Year	Air pressure monitor	x	x	x	
Pathfinder \ WD21 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pathfinder \ WD21 \ All Year	DIU	x	x	x	
Pathfinder \ WD21 \ All Year	Auto slide door	x	x	x	
Pathfinder \ WD21 \ All Year	Auto drive position	x	x	x	
Pathfinder \ WD21 \ All Year	All mode AWD/4WD	x	x	x	
Pathfinder \ WD21 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pathfinder \ WD21 \ All Year	Sonar	x	x	x	
Pathfinder \ WD21 \ All Year	Lane camera	x	x	x	
Pathfinder \ WD21 \ All Year	Adaptive light	x	x	x	
Pathfinder \ WD21 \ All Year	AVM		x	x	
Pathfinder \ WD21 \ All Year	Head lamp levelizer	x	x	x	
Pathfinder \ WD21 \ All Year	Difference lock	x	x	x	
Pathfinder \ WD21 \ All Year	Nats immu	x	x		
Pathfinder \ WD21 \ All Year	Smart entrance	x	x		
Pathfinder \ WD21 \ All Year	Air levelizer	x	x	x	
Pathfinder \ WD21 \ All Year	Rearview camera			x	
Pathfinder \ WD21 \ All Year	S/blind camera			x	
Pathfinder \ WD21 \ All Year	Motor assist	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2011-5~	ABS		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2011-5~	BCM		x		
Patrol (AT) \ Y62 \ 2011-5~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2011-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2011-5~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2011-5~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2011-5~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Air pressure monitor	x	x	x	

Patrol (AT) \ Y62 \ 2011-5~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2011-5~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2011-5~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2011-5~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2011-5~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2011-5~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2011-6~	ABS		x	x	
Patrol (AT) \ Y62 \ 2011-6~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2011-6~	BCM		x		
Patrol (AT) \ Y62 \ 2011-6~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2011-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2011-6~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2011-6~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2011-6~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2011-6~	Air pressure monitor	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2011-6~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2011-6~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2011-6~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2011-6~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2011-6~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2011-6~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2012-10~	ABS		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Meter/M&A		x	x	

Patrol (AT) \ Y62 \ 2012-10~	BCM		x		
Patrol (AT) \ Y62 \ 2012-10~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2012-10~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2012-10~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2012-10~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Air pressure monitor	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2012-10~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2012-10~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Telematics		x	x	0253
Patrol (AT) \ Y62 \ 2012-10~	AVM		x	x	
Patrol (AT) \ Y62 \ 2012-10~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2012-10~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2012-11~	ABS		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2012-11~	BCM		x		
Patrol (AT) \ Y62 \ 2012-11~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2012-11~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2012-11~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2012-11~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Air pressure monitor	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Precrash seatbelt		x	x	

Patrol (AT) \ Y62 \ 2012-11~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2012-11~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2012-11~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Telematics		x	x	0253
Patrol (AT) \ Y62 \ 2012-11~	AVM		x	x	
Patrol (AT) \ Y62 \ 2012-11~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2012-11~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2012-9~	ABS		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2012-9~	BCM		x		
Patrol (AT) \ Y62 \ 2012-9~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2012-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2012-9~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2012-9~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2012-9~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Air pressure monitor	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2012-9~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2012-9~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2012-9~	Telematics		x	x	0253
Patrol (AT) \ Y62 \ 2012-9~	AVM		x	x	

Patrol (AT) \ Y62 \ 2012-9~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2012-9~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2013-10~	ABS		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2013-10~	BCM		x		
Patrol (AT) \ Y62 \ 2013-10~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	ICC/ADAS	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2013-10~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2013-10~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2013-10~	EPS/DAST 3	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Air pressure monitor	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2013-10~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	CAN gateway		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2013-10~	E-SUS		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Telematics		x	x	0253
Patrol (AT) \ Y62 \ 2013-10~	BSW/buzzer		x	x	
Patrol (AT) \ Y62 \ 2013-10~	AVM		x	x	
Patrol (AT) \ Y62 \ 2013-10~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2013-10~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2013-10~	Air levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2013-7~	ABS		x	x	

Patrol (AT) \ Y62 \ 2013-7~	Meter/M&A		×	×	
Patrol (AT) \ Y62 \ 2013-7~	BCM		×		
Patrol (AT) \ Y62 \ 2013-7~	Air bag	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	ICC/ADAS	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2013-7~	Transmission	×	×	×	0059
Patrol (AT) \ Y62 \ 2013-7~	Multi AV		×	×	
Patrol (AT) \ Y62 \ 2013-7~	EPS/DAST 3	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	IPDM E/R		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Air pressure monitor	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Laser/radar	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Precrash seatbelt		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Auto drive position		×	×	
Patrol (AT) \ Y62 \ 2013-7~	All mode AWD/4WD	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Sonar	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Lane camera		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Adaptive light	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	CAN gateway		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Auto back door		×	×	
Patrol (AT) \ Y62 \ 2013-7~	E-SUS		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Accele pedal ACT		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Side radar left		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Side radar right		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Telematics		×	×	0253
Patrol (AT) \ Y62 \ 2013-7~	BSW/buzzer		×	×	
Patrol (AT) \ Y62 \ 2013-7~	AVM		×	×	
Patrol (AT) \ Y62 \ 2013-7~	Head lamp levelizer	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Difference lock	×	×	×	
Patrol (AT) \ Y62 \ 2013-7~	Occupant detection			×	
Patrol (AT) \ Y62 \ 2013-7~	Air levelizer	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2014-11~	ABS		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Meter/M&A		×	×	
Patrol (AT) \ Y62 \ 2014-11~	BCM		×		
Patrol (AT) \ Y62 \ 2014-11~	Air bag	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	ICC/ADAS		×	×	
Patrol (AT) \ Y62 \ 2014-11~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2014-11~	Transmission	×	×	×	0059

Patrol (AT) \ Y62 \ 2014-11~	Multi AV		×	×	
Patrol (AT) \ Y62 \ 2014-11~	EPS/DAST 3	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	IPDM E/R		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Laser/radar	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Precrash seatbelt		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Auto drive position		×	×	
Patrol (AT) \ Y62 \ 2014-11~	All mode AWD/4WD	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Sonar	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Lane camera		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Adaptive light	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	CAN gateway		×		
Patrol (AT) \ Y62 \ 2014-11~	Auto back door		×	×	
Patrol (AT) \ Y62 \ 2014-11~	E-SUS		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Accele pedal ACT		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Side radar left		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Side radar right		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Telematics		×	×	0253
Patrol (AT) \ Y62 \ 2014-11~	BSW/buzzer		×	×	
Patrol (AT) \ Y62 \ 2014-11~	AVM		×	×	
Patrol (AT) \ Y62 \ 2014-11~	Head lamp levelizer	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Difference lock	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Occupant detection			×	
Patrol (AT) \ Y62 \ 2014-11~	Air levelizer	×	×	×	
Patrol (AT) \ Y62 \ 2014-11~	Air pressure monitor	×	×	×	
Patrol (AT) \ Y62 \ 2016-1~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2016-1~	ABS		×	×	
Patrol (AT) \ Y62 \ 2016-1~	Meter/M&A		×	×	
Patrol (AT) \ Y62 \ 2016-1~	BCM		×		
Patrol (AT) \ Y62 \ 2016-1~	Air bag	×	×	×	
Patrol (AT) \ Y62 \ 2016-1~	ICC/ADAS		×	×	
Patrol (AT) \ Y62 \ 2016-1~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2016-1~	Transmission	×	×	×	0059
Patrol (AT) \ Y62 \ 2016-1~	Multi AV		×	×	
Patrol (AT) \ Y62 \ 2016-1~	EPS/DAST 3	×	×	×	
Patrol (AT) \ Y62 \ 2016-1~	IPDM E/R		×	×	
Patrol (AT) \ Y62 \ 2016-1~	Air pressure monitor	×	×	×	
Patrol (AT) \ Y62 \ 2016-1~	Laser/radar	×	×	×	
Patrol (AT) \ Y62 \ 2016-1~	Precrash seatbelt		×	×	
Patrol (AT) \ Y62 \ 2016-1~	Auto drive position		×	×	

Patrol (AT) \ Y62 \ 2016-1~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2016-1~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2016-1~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2016-1~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2016-1~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2016-1~	E-SUS		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Accele pedal ACT		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Telematics		x	x	0253
Patrol (AT) \ Y62 \ 2016-1~	AVM		x	x	
Patrol (AT) \ Y62 \ 2016-1~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2016-1~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2016-1~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2016-1~	Air levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (AT) \ Y62 \ 2016-6~	ABS		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Meter/M&A		x	x	
Patrol (AT) \ Y62 \ 2016-6~	BCM		x		
Patrol (AT) \ Y62 \ 2016-6~	Air bag	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	ICC/ADAS		x	x	
Patrol (AT) \ Y62 \ 2016-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (AT) \ Y62 \ 2016-6~	Transmission	x	x	x	0059
Patrol (AT) \ Y62 \ 2016-6~	Multi AV		x	x	
Patrol (AT) \ Y62 \ 2016-6~	EPS/DAST 3	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	IPDM E/R		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Air pressure monitor		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Laser/radar	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Precrash seatbelt		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Auto drive position		x	x	
Patrol (AT) \ Y62 \ 2016-6~	All mode AWD/4WD	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Sonar	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Lane camera		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Adaptive light	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	CAN gateway		x		
Patrol (AT) \ Y62 \ 2016-6~	Auto back door		x	x	
Patrol (AT) \ Y62 \ 2016-6~	E-SUS		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Accele pedal ACT		x	x	

Patrol (AT) \ Y62 \ 2016-6~	Side radar left		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Side radar right		x	x	
Patrol (AT) \ Y62 \ 2016-6~	AVM		x	x	
Patrol (AT) \ Y62 \ 2016-6~	Head lamp levelizer	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Difference lock	x	x	x	
Patrol (AT) \ Y62 \ 2016-6~	Occupant detection			x	
Patrol (AT) \ Y62 \ 2016-6~	Air levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2011-5~	ABS		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2011-5~	BCM		x		
Patrol (MT) \ Y62 \ 2011-5~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2011-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2011-5~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2011-5~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2011-5~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2011-5~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2011-5~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2011-5~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2011-5~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2011-5~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2011-6~	ABS		x	x	
Patrol (MT) \ Y62 \ 2011-6~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2011-6~	BCM		x		
Patrol (MT) \ Y62 \ 2011-6~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2011-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

Patrol (MT) \ Y62 \ 2011-6~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2011-6~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2011-6~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2011-6~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2011-6~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2011-6~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2011-6~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2011-6~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2011-6~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2011-6~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2012-10~	ABS		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2012-10~	BCM		x		
Patrol (MT) \ Y62 \ 2012-10~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2012-10~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2012-10~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2012-10~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2012-10~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2012-10~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2012-10~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2012-10~	AVM		x	x	

Patrol (MT) \ Y62 \ 2012-10~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2012-10~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2012-11~	ABS		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2012-11~	BCM		x		
Patrol (MT) \ Y62 \ 2012-11~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2012-11~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2012-11~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2012-11~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2012-11~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2012-11~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2012-11~	AVM		x	x	
Patrol (MT) \ Y62 \ 2012-11~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2012-11~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2012-9~	ABS		x	x	
Patrol (MT) \ Y62 \ 2012-9~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2012-9~	BCM		x		
Patrol (MT) \ Y62 \ 2012-9~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2012-9~	ICC/ADAS		x	x	

Patrol (MT) \ Y62 \ 2012-9~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2012-9~	Transmission	×	×	×	0059
Patrol (MT) \ Y62 \ 2012-9~	Multi AV		×	×	
Patrol (MT) \ Y62 \ 2012-9~	IPDM E/R		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Air pressure monitor	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Laser/radar	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Precrash seatbelt		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Auto drive position		×	×	
Patrol (MT) \ Y62 \ 2012-9~	All mode AWD/4WD	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Lane camera		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Adaptive light	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	CAN gateway		×		
Patrol (MT) \ Y62 \ 2012-9~	Auto back door		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Accele pedal ACT		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Side radar left		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Side radar right		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Telematics		×	×	0253
Patrol (MT) \ Y62 \ 2012-9~	AVM		×	×	
Patrol (MT) \ Y62 \ 2012-9~	Head lamp levelizer	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Difference lock	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Sonar	×	×	×	
Patrol (MT) \ Y62 \ 2012-9~	Occupant detection			×	
Patrol (MT) \ Y62 \ 2013-10~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2013-10~	ABS		×	×	
Patrol (MT) \ Y62 \ 2013-10~	Meter/M&A		×	×	
Patrol (MT) \ Y62 \ 2013-10~	BCM		×		
Patrol (MT) \ Y62 \ 2013-10~	Air bag	×	×	×	
Patrol (MT) \ Y62 \ 2013-10~	ICC/ADAS	×	×	×	
Patrol (MT) \ Y62 \ 2013-10~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2013-10~	Transmission	×	×	×	0059
Patrol (MT) \ Y62 \ 2013-10~	Multi AV		×	×	
Patrol (MT) \ Y62 \ 2013-10~	EPS/DAST 3	×	×	×	
Patrol (MT) \ Y62 \ 2013-10~	IPDM E/R		×	×	
Patrol (MT) \ Y62 \ 2013-10~	Air pressure monitor	×	×	×	
Patrol (MT) \ Y62 \ 2013-10~	Laser/radar	×	×	×	
Patrol (MT) \ Y62 \ 2013-10~	Precrash seatbelt		×	×	
Patrol (MT) \ Y62 \ 2013-10~	Auto drive position		×	×	
Patrol (MT) \ Y62 \ 2013-10~	All mode AWD/4WD	×	×	×	

Patrol (MT) \ Y62 \ 2013-10~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2013-10~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2013-10~	CAN gateway		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2013-10~	E-SUS		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2013-10~	BSW/buzzer		x	x	
Patrol (MT) \ Y62 \ 2013-10~	AVM		x	x	
Patrol (MT) \ Y62 \ 2013-10~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2013-10~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2013-10~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2013-10~	Air levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2013-7~	ABS		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2013-7~	BCM		x		
Patrol (MT) \ Y62 \ 2013-7~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	ICC/ADAS	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2013-7~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2013-7~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2013-7~	EPS/DAST 3	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2013-7~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	CAN gateway		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2013-7~	E-SUS		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Accele pedal ACT		x	x	

Patrol (MT) \ Y62 \ 2013-7~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2013-7~	BSW/buzzer		x	x	
Patrol (MT) \ Y62 \ 2013-7~	AVM		x	x	
Patrol (MT) \ Y62 \ 2013-7~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2013-7~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2013-7~	Air levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2014-11~	ABS		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2014-11~	BCM		x		
Patrol (MT) \ Y62 \ 2014-11~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2014-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2014-11~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2014-11~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2014-11~	EPS/DAST 3	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2014-11~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2014-11~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2014-11~	E-SUS		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2014-11~	BSW/buzzer		x	x	
Patrol (MT) \ Y62 \ 2014-11~	AVM		x	x	
Patrol (MT) \ Y62 \ 2014-11~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Occupant detection			x	

Patrol (MT) \ Y62 \ 2014-11~	Air levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2014-11~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2016-1~	ABS		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2016-1~	BCM		x		
Patrol (MT) \ Y62 \ 2016-1~	Air bag	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2016-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2016-1~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2016-1~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2016-1~	EPS/DAST 3	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Air pressure monitor	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2016-1~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2016-1~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2016-1~	E-SUS		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Telematics		x	x	0253
Patrol (MT) \ Y62 \ 2016-1~	AVM		x	x	
Patrol (MT) \ Y62 \ 2016-1~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2016-1~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2016-1~	Air levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol (MT) \ Y62 \ 2016-6~	ABS		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Meter/M&A		x	x	
Patrol (MT) \ Y62 \ 2016-6~	BCM		x		
Patrol (MT) \ Y62 \ 2016-6~	Air bag	x	x	x	

Patrol (MT) \ Y62 \ 2016-6~	ICC/ADAS		x	x	
Patrol (MT) \ Y62 \ 2016-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol (MT) \ Y62 \ 2016-6~	Transmission	x	x	x	0059
Patrol (MT) \ Y62 \ 2016-6~	Multi AV		x	x	
Patrol (MT) \ Y62 \ 2016-6~	EPS/DAST 3	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	IPDM E/R		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Air pressure monitor		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Laser/radar	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Precrash seatbelt		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Auto drive position		x	x	
Patrol (MT) \ Y62 \ 2016-6~	All mode AWD/4WD	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Sonar	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Lane camera		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Adaptive light	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	CAN gateway		x		
Patrol (MT) \ Y62 \ 2016-6~	Auto back door		x	x	
Patrol (MT) \ Y62 \ 2016-6~	E-SUS		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Accele pedal ACT		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Side radar left		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Side radar right		x	x	
Patrol (MT) \ Y62 \ 2016-6~	AVM		x	x	
Patrol (MT) \ Y62 \ 2016-6~	Head lamp levelizer	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Difference lock	x	x	x	
Patrol (MT) \ Y62 \ 2016-6~	Occupant detection			x	
Patrol (MT) \ Y62 \ 2016-6~	Air levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 1997-10~	ABS	x	x	x	0003, 0092, 0264
PATROL (Y61) \ Y61 \ 1997-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 1997-10~	BCM	x	x		
PATROL (Y61) \ Y61 \ 1997-10~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	ICC/ADAS	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	HVAC	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
PATROL (Y61) \ Y61 \ 1997-10~	Multi AV	x	x	x	0280
PATROL (Y61) \ Y61 \ 1997-10~	EPS/DAST 3	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	IPDM E/R	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Air pressure monitor	x	x	x	

PATROL (Y61) \ Y61 \ 1997-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
PATROL (Y61) \ Y61 \ 1997-10~	DIU	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Auto slide door	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Auto drive position	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	All mode AWD/4WD	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Sonar	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Lane camera	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Adaptive light	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	AVM		x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Head lamp levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Difference lock	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Nats immu	x	x		
PATROL (Y61) \ Y61 \ 1997-10~	Smart entrance	x	x		
PATROL (Y61) \ Y61 \ 1997-10~	Air levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 1997-10~	Rearview camera			x	
PATROL (Y61) \ Y61 \ 1997-10~	S/blind camera			x	
PATROL (Y61) \ Y61 \ 1997-10~	Motor assist	x	x	x	
PATROL (Y61) \ Y61 \ 2007-3~	Engine	x	x	x	
PATROL (Y61) \ Y61 \ 2007-3~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2007-3~	HVAC	x	x	x	
PATROL (Y61) \ Y61 \ 2007-3~	Transmission	x	x	x	
PATROL (Y61) \ Y61 \ 2007-3~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2007-3~	Rearview camera			x	
PATROL (Y61) \ Y61 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 2009-11~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2009-11~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	HVAC	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	Transmission	x	x	x	0059
PATROL (Y61) \ Y61 \ 2009-11~	Multi AV	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	IPDM E/R	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
PATROL (Y61) \ Y61 \ 2009-11~	Auto drive position	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	All mode AWD/4WD	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	ABS	x	x	x	

PATROL (Y61) \ Y61 \ 2009-11~	Head lamp levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	Difference lock	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	SVT	x	x	x	
PATROL (Y61) \ Y61 \ 2009-11~	Rearview camera			x	
PATROL (Y61) \ Y61 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 2011-12~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2011-12~	HVAC	x	x	x	
PATROL (Y61) \ Y61 \ 2011-12~	ABS	x	x	x	
PATROL (Y61) \ Y61 \ 2011-12~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2011-12~	Difference lock	x	x	x	
PATROL (Y61) \ Y61 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2012-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 2012-12~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2012-12~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2012-12~	ICC/ADAS		x	x	
PATROL (Y61) \ Y61 \ 2012-12~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
PATROL (Y61) \ Y61 \ 2012-12~	IPDM E/R		x	x	
PATROL (Y61) \ Y61 \ 2012-12~	Accele pedal ACT		x	x	
PATROL (Y61) \ Y61 \ 2012-12~	ABS	x	x	x	
PATROL (Y61) \ Y61 \ 2012-12~	Transmission	x	x	x	
PATROL (Y61) \ Y61 \ 2012-12~	Head lamp levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 2013-8~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2013-8~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2013-8~	ICC/ADAS		x	x	
PATROL (Y61) \ Y61 \ 2013-8~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
PATROL (Y61) \ Y61 \ 2013-8~	IPDM E/R		x	x	
PATROL (Y61) \ Y61 \ 2013-8~	AVM		x	x	
PATROL (Y61) \ Y61 \ 2013-8~	ABS	x	x	x	
PATROL (Y61) \ Y61 \ 2013-8~	Transmission	x	x	x	
PATROL (Y61) \ Y61 \ 2013-8~	Head lamp levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2014-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

PATROL (Y61) \ Y61 \ 2014-7~	BCM	x	x		
PATROL (Y61) \ Y61 \ 2014-7~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	ICC/ADAS		x	x	
PATROL (Y61) \ Y61 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
PATROL (Y61) \ Y61 \ 2014-7~	EPS/DAST 3	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	IPDM E/R		x	x	
PATROL (Y61) \ Y61 \ 2014-7~	AVM		x	x	
PATROL (Y61) \ Y61 \ 2014-7~	ABS	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	Transmission	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	Head lamp levelizer	x	x	x	
PATROL (Y61) \ Y61 \ 2014-7~	Difference lock	x	x	x	
PATROL (Y61) \ Y61 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
PATROL (Y61) \ Y61 \ 2015-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
PATROL (Y61) \ Y61 \ 2015-9~	Air bag	x	x	x	
PATROL (Y61) \ Y61 \ 2015-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
PATROL (Y61) \ Y61 \ 2015-9~	EPS/DAST 3	x	x	x	
PATROL (Y61) \ Y61 \ 2015-9~	IPDM E/R		x	x	
PATROL (Y61) \ Y61 \ 2015-9~	AVM		x	x	
PATROL (Y61) \ Y61 \ 2015-9~	ABS	x	x	x	
PATROL (Y61) \ Y61 \ 2015-9~	Transmission	x	x	x	
PATROL (Y61) \ Y61 \ 2015-9~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2002-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2002-6~	Transmission	x	x	x	
Patrol pickup \ UY61 \ 2002-6~	Difference lock	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264
Patrol pickup \ UY61 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2006-12~	BCM	x	x		
Patrol pickup \ UY61 \ 2006-12~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	ICC/ADAS	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	HVAC	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol pickup \ UY61 \ 2006-12~	Multi AV	x	x	x	0280
Patrol pickup \ UY61 \ 2006-12~	EPS/DAST 3	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	IPDM E/R	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Air pressure monitor	x	x	x	

Patrol pickup \ UY61 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol pickup \ UY61 \ 2006-12~	DIU	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Auto slide door	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Auto drive position	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	All mode AWD/4WD	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Sonar	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Lane camera	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Adaptive light	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	AVM		x	x	
Patrol pickup \ UY61 \ 2006-12~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Difference lock	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Nats immu	x	x		
Patrol pickup \ UY61 \ 2006-12~	Smart entrance	x	x		
Patrol pickup \ UY61 \ 2006-12~	Air levelizer	x	x	x	
Patrol pickup \ UY61 \ 2006-12~	Rearview camera			x	
Patrol pickup \ UY61 \ 2006-12~	S/blind camera			x	
Patrol pickup \ UY61 \ 2006-12~	Motor assist	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2009-11~	ABS	x	x	x	0003, 0092, 0264
Patrol pickup \ UY61 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2009-11~	BCM	x	x		
Patrol pickup \ UY61 \ 2009-11~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	ICC/ADAS	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	HVAC	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol pickup \ UY61 \ 2009-11~	Multi AV	x	x	x	0280
Patrol pickup \ UY61 \ 2009-11~	EPS/DAST 3	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	IPDM E/R	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Air pressure monitor	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol pickup \ UY61 \ 2009-11~	DIU	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Auto slide door	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Auto drive position	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	All mode AWD/4WD	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Patrol pickup \ UY61 \ 2009-11~	Sonar	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Lane camera	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Adaptive light	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	AVM		x	x	
Patrol pickup \ UY61 \ 2009-11~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Difference lock	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Nats immu	x	x		
Patrol pickup \ UY61 \ 2009-11~	Smart entrance	x	x		
Patrol pickup \ UY61 \ 2009-11~	Air levelizer	x	x	x	
Patrol pickup \ UY61 \ 2009-11~	Rearview camera			x	
Patrol pickup \ UY61 \ 2009-11~	S/blind camera			x	
Patrol pickup \ UY61 \ 2009-11~	Motor assist	x	x	x	
Patrol pickup \ UY61 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2012-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2012-12~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2012-12~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol pickup \ UY61 \ 2012-12~	IPDM E/R		x	x	
Patrol pickup \ UY61 \ 2012-12~	ABS	x	x	x	
Patrol pickup \ UY61 \ 2012-12~	Transmission	x	x	x	
Patrol pickup \ UY61 \ 2012-12~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2013-8~	BCM	x	x		
Patrol pickup \ UY61 \ 2013-8~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2013-8~	ICC/ADAS		x	x	
Patrol pickup \ UY61 \ 2013-8~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol pickup \ UY61 \ 2013-8~	IPDM E/R		x	x	
Patrol pickup \ UY61 \ 2013-8~	ABS	x	x	x	
Patrol pickup \ UY61 \ 2013-8~	Transmission	x	x	x	
Patrol pickup \ UY61 \ 2013-8~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2014-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2014-7~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2014-7~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol pickup \ UY61 \ 2014-7~	EPS/DAST 3	x	x	x	

Patrol pickup \ UY61 \ 2014-7~	IPDM E/R		x	x	
Patrol pickup \ UY61 \ 2014-7~	ABS	x	x	x	
Patrol pickup \ UY61 \ 2014-7~	Transmission	x	x	x	
Patrol pickup \ UY61 \ 2014-7~	Head lamp levelizer	x	x	x	
Patrol pickup \ UY61 \ 2014-7~	Difference lock	x	x	x	
Patrol pickup \ UY61 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol pickup \ UY61 \ 2015-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol pickup \ UY61 \ 2015-9~	Air bag	x	x	x	
Patrol pickup \ UY61 \ 2015-9~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol pickup \ UY61 \ 2015-9~	EPS/DAST 3	x	x	x	
Patrol pickup \ UY61 \ 2015-9~	IPDM E/R		x	x	
Patrol pickup \ UY61 \ 2015-9~	AVM		x	x	
Patrol pickup \ UY61 \ 2015-9~	ABS	x	x	x	
Patrol pickup \ UY61 \ 2015-9~	Transmission	x	x	x	
Patrol pickup \ UY61 \ 2015-9~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 1997-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 1997-10~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 1997-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 1997-10~	BCM	x	x		
Patrol \ Y61 \ 1997-10~	Air bag	x	x	x	
Patrol \ Y61 \ 1997-10~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 1997-10~	HVAC	x	x	x	
Patrol \ Y61 \ 1997-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 1997-10~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 1997-10~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 1997-10~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 1997-10~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 1997-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 1997-10~	DIU	x	x	x	
Patrol \ Y61 \ 1997-10~	Auto slide door	x	x	x	
Patrol \ Y61 \ 1997-10~	Auto drive position	x	x	x	
Patrol \ Y61 \ 1997-10~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 1997-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 1997-10~	Sonar	x	x	x	
Patrol \ Y61 \ 1997-10~	Lane camera	x	x	x	
Patrol \ Y61 \ 1997-10~	Adaptive light	x	x	x	

Patrol \ Y61 \ 1997-10~	AVM		x	x	
Patrol \ Y61 \ 1997-10~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 1997-10~	Difference lock	x	x	x	
Patrol \ Y61 \ 1997-10~	Nats immu	x	x		
Patrol \ Y61 \ 1997-10~	Smart entrance	x	x		
Patrol \ Y61 \ 1997-10~	Air levelizer	x	x	x	
Patrol \ Y61 \ 1997-10~	Rearview camera			x	
Patrol \ Y61 \ 1997-10~	S/blind camera			x	
Patrol \ Y61 \ 1997-10~	Motor assist	x	x	x	
Patrol \ Y61 \ 1997-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 1997-12~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 1997-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 1997-12~	BCM	x	x		
Patrol \ Y61 \ 1997-12~	Air bag	x	x	x	
Patrol \ Y61 \ 1997-12~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 1997-12~	HVAC	x	x	x	
Patrol \ Y61 \ 1997-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 1997-12~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 1997-12~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 1997-12~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 1997-12~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 1997-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 1997-12~	DIU	x	x	x	
Patrol \ Y61 \ 1997-12~	Auto slide door	x	x	x	
Patrol \ Y61 \ 1997-12~	Auto drive position	x	x	x	
Patrol \ Y61 \ 1997-12~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 1997-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 1997-12~	Sonar	x	x	x	
Patrol \ Y61 \ 1997-12~	Lane camera	x	x	x	
Patrol \ Y61 \ 1997-12~	Adaptive light	x	x	x	
Patrol \ Y61 \ 1997-12~	AVM		x	x	
Patrol \ Y61 \ 1997-12~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 1997-12~	Difference lock	x	x	x	
Patrol \ Y61 \ 1997-12~	Nats immu	x	x		
Patrol \ Y61 \ 1997-12~	Smart entrance	x	x		
Patrol \ Y61 \ 1997-12~	Air levelizer	x	x	x	
Patrol \ Y61 \ 1997-12~	Rearview camera			x	
Patrol \ Y61 \ 1997-12~	S/blind camera			x	

Patrol \ Y61 \ 1997-12~	Motor assist	x	x	x	
Patrol \ Y61 \ 1998-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 1998-8~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 1998-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 1998-8~	BCM	x	x		
Patrol \ Y61 \ 1998-8~	Air bag	x	x	x	
Patrol \ Y61 \ 1998-8~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 1998-8~	HVAC	x	x	x	
Patrol \ Y61 \ 1998-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 1998-8~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 1998-8~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 1998-8~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 1998-8~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 1998-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 1998-8~	DIU	x	x	x	
Patrol \ Y61 \ 1998-8~	Auto slide door	x	x	x	
Patrol \ Y61 \ 1998-8~	Auto drive position	x	x	x	
Patrol \ Y61 \ 1998-8~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 1998-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 1998-8~	Sonar	x	x	x	
Patrol \ Y61 \ 1998-8~	Lane camera	x	x	x	
Patrol \ Y61 \ 1998-8~	Adaptive light	x	x	x	
Patrol \ Y61 \ 1998-8~	AVM		x	x	
Patrol \ Y61 \ 1998-8~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 1998-8~	Difference lock	x	x	x	
Patrol \ Y61 \ 1998-8~	Nats immu	x	x		
Patrol \ Y61 \ 1998-8~	Smart entrance	x	x		
Patrol \ Y61 \ 1998-8~	Air levelizer	x	x	x	
Patrol \ Y61 \ 1998-8~	Rearview camera			x	
Patrol \ Y61 \ 1998-8~	S/blind camera			x	
Patrol \ Y61 \ 1998-8~	Motor assist	x	x	x	
Patrol \ Y61 \ 2000-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2000-2~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2000-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2000-2~	BCM	x	x		
Patrol \ Y61 \ 2000-2~	Air bag	x	x	x	
Patrol \ Y61 \ 2000-2~	ICC/ADAS	x	x	x	

Patrol \ Y61 \ 2000-2~	HVAC	x	x	x	
Patrol \ Y61 \ 2000-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2000-2~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2000-2~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2000-2~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2000-2~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2000-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2000-2~	DIU	x	x	x	
Patrol \ Y61 \ 2000-2~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2000-2~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2000-2~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2000-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2000-2~	Sonar	x	x	x	
Patrol \ Y61 \ 2000-2~	Lane camera	x	x	x	
Patrol \ Y61 \ 2000-2~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2000-2~	AVM		x	x	
Patrol \ Y61 \ 2000-2~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2000-2~	Difference lock	x	x	x	
Patrol \ Y61 \ 2000-2~	Nats immu	x	x		
Patrol \ Y61 \ 2000-2~	Smart entrance	x	x		
Patrol \ Y61 \ 2000-2~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2000-2~	Rearview camera			x	
Patrol \ Y61 \ 2000-2~	S/blind camera			x	
Patrol \ Y61 \ 2000-2~	Motor assist	x	x	x	
Patrol \ Y61 \ 2000-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2000-3~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2000-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2000-3~	BCM	x	x		
Patrol \ Y61 \ 2000-3~	Air bag	x	x	x	
Patrol \ Y61 \ 2000-3~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2000-3~	HVAC	x	x	x	
Patrol \ Y61 \ 2000-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2000-3~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2000-3~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2000-3~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2000-3~	Air pressure monitor	x	x	x	

Patrol \ Y61 \ 2000-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2000-3~	DIU	x	x	x	
Patrol \ Y61 \ 2000-3~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2000-3~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2000-3~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2000-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2000-3~	Sonar	x	x	x	
Patrol \ Y61 \ 2000-3~	Lane camera	x	x	x	
Patrol \ Y61 \ 2000-3~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2000-3~	AVM		x	x	
Patrol \ Y61 \ 2000-3~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2000-3~	Difference lock	x	x	x	
Patrol \ Y61 \ 2000-3~	Nats immu	x	x		
Patrol \ Y61 \ 2000-3~	Smart entrance	x	x		
Patrol \ Y61 \ 2000-3~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2000-3~	Rearview camera			x	
Patrol \ Y61 \ 2000-3~	S/blind camera			x	
Patrol \ Y61 \ 2000-3~	Motor assist	x	x	x	
Patrol \ Y61 \ 2001-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2001-6~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2001-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2001-6~	BCM	x	x		
Patrol \ Y61 \ 2001-6~	Air bag	x	x	x	
Patrol \ Y61 \ 2001-6~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2001-6~	HVAC	x	x	x	
Patrol \ Y61 \ 2001-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2001-6~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2001-6~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2001-6~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2001-6~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2001-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2001-6~	DIU	x	x	x	
Patrol \ Y61 \ 2001-6~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2001-6~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2001-6~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2001-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Patrol \ Y61 \ 2001-6~	Sonar	x	x	x	
Patrol \ Y61 \ 2001-6~	Lane camera	x	x	x	
Patrol \ Y61 \ 2001-6~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2001-6~	AVM		x	x	
Patrol \ Y61 \ 2001-6~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2001-6~	Difference lock	x	x	x	
Patrol \ Y61 \ 2001-6~	Nats immu	x	x		
Patrol \ Y61 \ 2001-6~	Smart entrance	x	x		
Patrol \ Y61 \ 2001-6~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2001-6~	Rearview camera			x	
Patrol \ Y61 \ 2001-6~	S/blind camera			x	
Patrol \ Y61 \ 2001-6~	Motor assist	x	x	x	
Patrol \ Y61 \ 2001-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2001-9~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2001-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2001-9~	BCM	x	x		
Patrol \ Y61 \ 2001-9~	Air bag	x	x	x	
Patrol \ Y61 \ 2001-9~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2001-9~	HVAC	x	x	x	
Patrol \ Y61 \ 2001-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2001-9~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2001-9~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2001-9~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2001-9~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2001-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2001-9~	DIU	x	x	x	
Patrol \ Y61 \ 2001-9~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2001-9~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2001-9~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2001-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2001-9~	Sonar	x	x	x	
Patrol \ Y61 \ 2001-9~	Lane camera	x	x	x	
Patrol \ Y61 \ 2001-9~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2001-9~	AVM		x	x	
Patrol \ Y61 \ 2001-9~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2001-9~	Difference lock	x	x	x	
Patrol \ Y61 \ 2001-9~	Nats immu	x	x		
Patrol \ Y61 \ 2001-9~	Smart entrance	x	x		

Patrol \ Y61 \ 2001-9~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2001-9~	Rearview camera			x	
Patrol \ Y61 \ 2001-9~	S/blind camera			x	
Patrol \ Y61 \ 2001-9~	Motor assist	x	x	x	
Patrol \ Y61 \ 2002-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2002-10~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2002-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2002-10~	BCM	x	x		
Patrol \ Y61 \ 2002-10~	Air bag	x	x	x	
Patrol \ Y61 \ 2002-10~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2002-10~	HVAC	x	x	x	
Patrol \ Y61 \ 2002-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2002-10~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2002-10~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2002-10~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2002-10~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2002-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2002-10~	DIU	x	x	x	
Patrol \ Y61 \ 2002-10~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2002-10~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2002-10~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2002-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2002-10~	Sonar	x	x	x	
Patrol \ Y61 \ 2002-10~	Lane camera	x	x	x	
Patrol \ Y61 \ 2002-10~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2002-10~	AVM		x	x	
Patrol \ Y61 \ 2002-10~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2002-10~	Difference lock	x	x	x	
Patrol \ Y61 \ 2002-10~	Nats immu	x	x		
Patrol \ Y61 \ 2002-10~	Smart entrance	x	x		
Patrol \ Y61 \ 2002-10~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2002-10~	Rearview camera			x	
Patrol \ Y61 \ 2002-10~	S/blind camera			x	
Patrol \ Y61 \ 2002-10~	Motor assist	x	x	x	
Patrol \ Y61 \ 2002-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2002-12~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2002-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Patrol \ Y61 \ 2002-12~	BCM	x	x		
Patrol \ Y61 \ 2002-12~	Air bag	x	x	x	
Patrol \ Y61 \ 2002-12~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2002-12~	HVAC	x	x	x	
Patrol \ Y61 \ 2002-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2002-12~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2002-12~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2002-12~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2002-12~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2002-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2002-12~	DIU	x	x	x	
Patrol \ Y61 \ 2002-12~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2002-12~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2002-12~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2002-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2002-12~	Sonar	x	x	x	
Patrol \ Y61 \ 2002-12~	Lane camera	x	x	x	
Patrol \ Y61 \ 2002-12~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2002-12~	AVM		x	x	
Patrol \ Y61 \ 2002-12~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2002-12~	Difference lock	x	x	x	
Patrol \ Y61 \ 2002-12~	Nats immu	x	x		
Patrol \ Y61 \ 2002-12~	Smart entrance	x	x		
Patrol \ Y61 \ 2002-12~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2002-12~	Rearview camera			x	
Patrol \ Y61 \ 2002-12~	S/blind camera			x	
Patrol \ Y61 \ 2002-12~	Motor assist	x	x	x	
Patrol \ Y61 \ 2003-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2003-8~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2003-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2003-8~	BCM	x	x		
Patrol \ Y61 \ 2003-8~	Air bag	x	x	x	
Patrol \ Y61 \ 2003-8~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2003-8~	HVAC	x	x	x	
Patrol \ Y61 \ 2003-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2003-8~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2003-8~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2003-8~	IPDM E/R	x	x	x	

Patrol \ Y61 \ 2003-8~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2003-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2003-8~	DIU	x	x	x	
Patrol \ Y61 \ 2003-8~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2003-8~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2003-8~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2003-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2003-8~	Sonar	x	x	x	
Patrol \ Y61 \ 2003-8~	Lane camera	x	x	x	
Patrol \ Y61 \ 2003-8~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2003-8~	AVM		x	x	
Patrol \ Y61 \ 2003-8~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2003-8~	Difference lock	x	x	x	
Patrol \ Y61 \ 2003-8~	Nats immu	x	x		
Patrol \ Y61 \ 2003-8~	Smart entrance	x	x		
Patrol \ Y61 \ 2003-8~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2003-8~	Rearview camera			x	
Patrol \ Y61 \ 2003-8~	S/blind camera			x	
Patrol \ Y61 \ 2003-8~	Motor assist	x	x	x	
Patrol \ Y61 \ 2004-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2004-4~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2004-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2004-4~	BCM	x	x		
Patrol \ Y61 \ 2004-4~	Air bag	x	x	x	
Patrol \ Y61 \ 2004-4~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2004-4~	HVAC	x	x	x	
Patrol \ Y61 \ 2004-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2004-4~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2004-4~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2004-4~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2004-4~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2004-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2004-4~	DIU	x	x	x	
Patrol \ Y61 \ 2004-4~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2004-4~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2004-4~	All mode AWD/4WD	x	x	x	

Patrol \ Y61 \ 2004-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2004-4~	Sonar	x	x	x	
Patrol \ Y61 \ 2004-4~	Lane camera	x	x	x	
Patrol \ Y61 \ 2004-4~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2004-4~	AVM		x	x	
Patrol \ Y61 \ 2004-4~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2004-4~	Difference lock	x	x	x	
Patrol \ Y61 \ 2004-4~	Nats immu	x	x		
Patrol \ Y61 \ 2004-4~	Smart entrance	x	x		
Patrol \ Y61 \ 2004-4~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2004-4~	Rearview camera			x	
Patrol \ Y61 \ 2004-4~	S/blind camera			x	
Patrol \ Y61 \ 2004-4~	Motor assist	x	x	x	
Patrol \ Y61 \ 2004-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2004-7~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2004-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2004-7~	BCM	x	x		
Patrol \ Y61 \ 2004-7~	Air bag	x	x	x	
Patrol \ Y61 \ 2004-7~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2004-7~	HVAC	x	x	x	
Patrol \ Y61 \ 2004-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2004-7~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2004-7~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2004-7~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2004-7~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2004-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2004-7~	DIU	x	x	x	
Patrol \ Y61 \ 2004-7~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2004-7~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2004-7~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2004-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2004-7~	Sonar	x	x	x	
Patrol \ Y61 \ 2004-7~	Lane camera	x	x	x	
Patrol \ Y61 \ 2004-7~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2004-7~	AVM		x	x	
Patrol \ Y61 \ 2004-7~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2004-7~	Difference lock	x	x	x	
Patrol \ Y61 \ 2004-7~	Nats immu	x	x		

Patrol \ Y61 \ 2004-7~	Smart entrance	x	x		
Patrol \ Y61 \ 2004-7~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2004-7~	Rearview camera			x	
Patrol \ Y61 \ 2004-7~	S/blind camera			x	
Patrol \ Y61 \ 2004-7~	Motor assist	x	x	x	
Patrol \ Y61 \ 2005-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2005-10~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2005-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2005-10~	BCM	x	x		
Patrol \ Y61 \ 2005-10~	Air bag	x	x	x	
Patrol \ Y61 \ 2005-10~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2005-10~	HVAC	x	x	x	
Patrol \ Y61 \ 2005-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2005-10~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2005-10~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2005-10~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2005-10~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2005-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2005-10~	DIU	x	x	x	
Patrol \ Y61 \ 2005-10~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2005-10~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2005-10~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2005-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2005-10~	Sonar	x	x	x	
Patrol \ Y61 \ 2005-10~	Lane camera	x	x	x	
Patrol \ Y61 \ 2005-10~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2005-10~	AVM		x	x	
Patrol \ Y61 \ 2005-10~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2005-10~	Difference lock	x	x	x	
Patrol \ Y61 \ 2005-10~	Nats immu	x	x		
Patrol \ Y61 \ 2005-10~	Smart entrance	x	x		
Patrol \ Y61 \ 2005-10~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2005-10~	Rearview camera			x	
Patrol \ Y61 \ 2005-10~	S/blind camera			x	
Patrol \ Y61 \ 2005-10~	Motor assist	x	x	x	
Patrol \ Y61 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2006-12~	ABS	x	x	x	0003, 0092, 0264

Patrol \ Y61 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2006-12~	BCM	x	x		
Patrol \ Y61 \ 2006-12~	Air bag	x	x	x	
Patrol \ Y61 \ 2006-12~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2006-12~	HVAC	x	x	x	
Patrol \ Y61 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2006-12~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2006-12~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2006-12~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2006-12~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2006-12~	DIU	x	x	x	
Patrol \ Y61 \ 2006-12~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2006-12~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2006-12~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2006-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2006-12~	Sonar	x	x	x	
Patrol \ Y61 \ 2006-12~	Lane camera	x	x	x	
Patrol \ Y61 \ 2006-12~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2006-12~	AVM		x	x	
Patrol \ Y61 \ 2006-12~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2006-12~	Difference lock	x	x	x	
Patrol \ Y61 \ 2006-12~	Nats immu	x	x		
Patrol \ Y61 \ 2006-12~	Smart entrance	x	x		
Patrol \ Y61 \ 2006-12~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2006-12~	Rearview camera			x	
Patrol \ Y61 \ 2006-12~	S/blind camera			x	
Patrol \ Y61 \ 2006-12~	Motor assist	x	x	x	
Patrol \ Y61 \ 2006-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2006-7~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2006-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2006-7~	BCM	x	x		
Patrol \ Y61 \ 2006-7~	Air bag	x	x	x	
Patrol \ Y61 \ 2006-7~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2006-7~	HVAC	x	x	x	
Patrol \ Y61 \ 2006-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2006-7~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2006-7~	EPS/DAST 3	x	x	x	

Patrol \ Y61 \ 2006-7~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2006-7~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2006-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2006-7~	DIU	x	x	x	
Patrol \ Y61 \ 2006-7~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2006-7~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2006-7~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2006-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2006-7~	Sonar	x	x	x	
Patrol \ Y61 \ 2006-7~	Lane camera	x	x	x	
Patrol \ Y61 \ 2006-7~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2006-7~	AVM		x	x	
Patrol \ Y61 \ 2006-7~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2006-7~	Difference lock	x	x	x	
Patrol \ Y61 \ 2006-7~	Nats immu	x	x		
Patrol \ Y61 \ 2006-7~	Smart entrance	x	x		
Patrol \ Y61 \ 2006-7~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2006-7~	Rearview camera			x	
Patrol \ Y61 \ 2006-7~	S/blind camera			x	
Patrol \ Y61 \ 2006-7~	Motor assist	x	x	x	
Patrol \ Y61 \ 2007-7~	Engine	x	x	x	
Patrol \ Y61 \ 2007-7~	BCM	x	x		
Patrol \ Y61 \ 2007-7~	HVAC	x	x	x	
Patrol \ Y61 \ 2007-7~	Transmission	x	x	x	
Patrol \ Y61 \ 2007-7~	Air bag	x	x	x	
Patrol \ Y61 \ 2007-7~	Rearview camera			x	
Patrol \ Y61 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Patrol \ Y61 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2007-7~	ICC/ADAS	x	x	x	
Patrol \ Y61 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Patrol \ Y61 \ 2007-7~	Multi AV	x	x	x	0280
Patrol \ Y61 \ 2007-7~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2007-7~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2007-7~	Air pressure monitor	x	x	x	
Patrol \ Y61 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Patrol \ Y61 \ 2007-7~	DIU	x	x	x	
Patrol \ Y61 \ 2007-7~	Auto slide door	x	x	x	
Patrol \ Y61 \ 2007-7~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2007-7~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Patrol \ Y61 \ 2007-7~	Sonar	x	x	x	
Patrol \ Y61 \ 2007-7~	Lane camera	x	x	x	
Patrol \ Y61 \ 2007-7~	Adaptive light	x	x	x	
Patrol \ Y61 \ 2007-7~	AVM		x	x	
Patrol \ Y61 \ 2007-7~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2007-7~	Difference lock	x	x	x	
Patrol \ Y61 \ 2007-7~	Nats immu	x	x		
Patrol \ Y61 \ 2007-7~	Smart entrance	x	x		
Patrol \ Y61 \ 2007-7~	Air levelizer	x	x	x	
Patrol \ Y61 \ 2007-7~	S/blind camera			x	
Patrol \ Y61 \ 2007-7~	Motor assist	x	x	x	
Patrol \ Y61 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2009-11~	BCM	x	x		
Patrol \ Y61 \ 2009-11~	Air bag	x	x	x	
Patrol \ Y61 \ 2009-11~	HVAC	x	x	x	
Patrol \ Y61 \ 2009-11~	Transmission	x	x	x	0059
Patrol \ Y61 \ 2009-11~	Multi AV	x	x	x	
Patrol \ Y61 \ 2009-11~	IPDM E/R	x	x	x	
Patrol \ Y61 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Patrol \ Y61 \ 2009-11~	Auto drive position	x	x	x	
Patrol \ Y61 \ 2009-11~	All mode AWD/4WD	x	x	x	
Patrol \ Y61 \ 2009-11~	ABS	x	x	x	
Patrol \ Y61 \ 2009-11~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2009-11~	Difference lock	x	x	x	
Patrol \ Y61 \ 2009-11~	SVT	x	x	x	
Patrol \ Y61 \ 2009-11~	Rearview camera			x	
Patrol \ Y61 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2011-6~	BCM	x	x		
Patrol \ Y61 \ 2011-6~	HVAC	x	x	x	
Patrol \ Y61 \ 2011-6~	ABS	x	x	x	
Patrol \ Y61 \ 2011-6~	Air bag	x	x	x	

Patrol \ Y61 \ 2011-6~	Transmission	x	x	x	
Patrol \ Y61 \ 2011-6~	Difference lock	x	x	x	
Patrol \ Y61 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2012-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2012-12~	BCM	x	x		
Patrol \ Y61 \ 2012-12~	Air bag	x	x	x	
Patrol \ Y61 \ 2012-12~	ICC/ADAS		x	x	
Patrol \ Y61 \ 2012-12~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y61 \ 2012-12~	IPDM E/R		x	x	
Patrol \ Y61 \ 2012-12~	Accele pedal ACT		x	x	
Patrol \ Y61 \ 2012-12~	ABS	x	x	x	
Patrol \ Y61 \ 2012-12~	Transmission	x	x	x	
Patrol \ Y61 \ 2012-12~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2013-8~	BCM	x	x		
Patrol \ Y61 \ 2013-8~	Air bag	x	x	x	
Patrol \ Y61 \ 2013-8~	ICC/ADAS		x	x	
Patrol \ Y61 \ 2013-8~	HVAC	x	x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y61 \ 2013-8~	IPDM E/R		x	x	
Patrol \ Y61 \ 2013-8~	AVM		x	x	
Patrol \ Y61 \ 2013-8~	ABS	x	x	x	
Patrol \ Y61 \ 2013-8~	Transmission	x	x	x	
Patrol \ Y61 \ 2013-8~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2014-5~	BCM	x	x		
Patrol \ Y61 \ 2014-5~	Air bag	x	x	x	
Patrol \ Y61 \ 2014-5~	ICC/ADAS		x	x	
Patrol \ Y61 \ 2014-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y61 \ 2014-5~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2014-5~	IPDM E/R		x	x	
Patrol \ Y61 \ 2014-5~	AVM		x	x	
Patrol \ Y61 \ 2014-5~	ABS	x	x	x	
Patrol \ Y61 \ 2014-5~	Transmission	x	x	x	

Patrol \ Y61 \ 2014-5~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2014-5~	Difference lock	x	x	x	
Patrol \ Y61 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2014-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2014-7~	BCM	x	x		
Patrol \ Y61 \ 2014-7~	Air bag	x	x	x	
Patrol \ Y61 \ 2014-7~	ICC/ADAS		x	x	
Patrol \ Y61 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y61 \ 2014-7~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2014-7~	IPDM E/R		x	x	
Patrol \ Y61 \ 2014-7~	AVM		x	x	
Patrol \ Y61 \ 2014-7~	ABS	x	x	x	
Patrol \ Y61 \ 2014-7~	Transmission	x	x	x	
Patrol \ Y61 \ 2014-7~	Head lamp levelizer	x	x	x	
Patrol \ Y61 \ 2014-7~	Difference lock	x	x	x	
Patrol \ Y61 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y61 \ 2015-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Patrol \ Y61 \ 2015-9~	Air bag	x	x	x	
Patrol \ Y61 \ 2015-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y61 \ 2015-9~	EPS/DAST 3	x	x	x	
Patrol \ Y61 \ 2015-9~	IPDM E/R		x	x	
Patrol \ Y61 \ 2015-9~	AVM		x	x	
Patrol \ Y61 \ 2015-9~	ABS	x	x	x	
Patrol \ Y61 \ 2015-9~	Transmission	x	x	x	
Patrol \ Y61 \ 2015-9~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2010-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2010-1~	ABS		x	x	
Patrol \ Y62 \ 2010-1~	Meter/M&A		x	x	
Patrol \ Y62 \ 2010-1~	BCM		x		
Patrol \ Y62 \ 2010-1~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2010-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2010-1~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2010-1~	Multi AV		x	x	
Patrol \ Y62 \ 2010-1~	IPDM E/R		x	x	
Patrol \ Y62 \ 2010-1~	Air pressure monitor	x	x	x	

Patrol \ Y62 \ 2010-1~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2010-1~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2010-1~	Auto drive position		x	x	
Patrol \ Y62 \ 2010-1~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2010-1~	Lane camera		x	x	
Patrol \ Y62 \ 2010-1~	CAN gateway		x		
Patrol \ Y62 \ 2010-1~	Auto back door		x	x	
Patrol \ Y62 \ 2010-1~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2010-1~	Side radar left		x	x	
Patrol \ Y62 \ 2010-1~	Side radar right		x	x	
Patrol \ Y62 \ 2010-1~	Air bag	x	x	x	
Patrol \ Y62 \ 2010-1~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2010-1~	Difference lock	x	x	x	
Patrol \ Y62 \ 2010-1~	Sonar	x	x	x	
Patrol \ Y62 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2010-3~	ABS	x	x	x	
Patrol \ Y62 \ 2010-3~	Meter/M&A		x	x	
Patrol \ Y62 \ 2010-3~	BCM		x		
Patrol \ Y62 \ 2010-3~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2010-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2010-3~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2010-3~	Multi AV		x	x	
Patrol \ Y62 \ 2010-3~	IPDM E/R		x	x	
Patrol \ Y62 \ 2010-3~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2010-3~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2010-3~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2010-3~	Auto drive position		x	x	
Patrol \ Y62 \ 2010-3~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2010-3~	Lane camera		x	x	
Patrol \ Y62 \ 2010-3~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2010-3~	CAN gateway		x		
Patrol \ Y62 \ 2010-3~	Auto back door		x	x	
Patrol \ Y62 \ 2010-3~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2010-3~	Air bag	x	x	x	
Patrol \ Y62 \ 2010-3~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2010-3~	Difference lock	x	x	x	
Patrol \ Y62 \ 2010-3~	Sonar	x	x	x	
Patrol \ Y62 \ 2010-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Patrol \ Y62 \ 2010-6~	ABS		x	x	
Patrol \ Y62 \ 2010-6~	Meter/M&A		x	x	
Patrol \ Y62 \ 2010-6~	BCM		x		
Patrol \ Y62 \ 2010-6~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2010-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2010-6~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2010-6~	Multi AV		x	x	
Patrol \ Y62 \ 2010-6~	IPDM E/R		x	x	
Patrol \ Y62 \ 2010-6~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2010-6~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2010-6~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2010-6~	Auto drive position		x	x	
Patrol \ Y62 \ 2010-6~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2010-6~	Lane camera		x	x	
Patrol \ Y62 \ 2010-6~	CAN gateway		x		
Patrol \ Y62 \ 2010-6~	Auto back door		x	x	
Patrol \ Y62 \ 2010-6~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2010-6~	Side radar left		x	x	
Patrol \ Y62 \ 2010-6~	Side radar right		x	x	
Patrol \ Y62 \ 2010-6~	Air bag	x	x	x	
Patrol \ Y62 \ 2010-6~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2010-6~	Difference lock	x	x	x	
Patrol \ Y62 \ 2010-6~	Sonar	x	x	x	
Patrol \ Y62 \ 2011-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2011-7~	ABS		x	x	
Patrol \ Y62 \ 2011-7~	Meter/M&A		x	x	
Patrol \ Y62 \ 2011-7~	BCM		x		
Patrol \ Y62 \ 2011-7~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2011-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2011-7~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2011-7~	Multi AV		x	x	
Patrol \ Y62 \ 2011-7~	IPDM E/R		x	x	
Patrol \ Y62 \ 2011-7~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2011-7~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2011-7~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2011-7~	Auto drive position		x	x	
Patrol \ Y62 \ 2011-7~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2011-7~	Lane camera		x	x	

Patrol \ Y62 \ 2011-7~	CAN gateway		x		
Patrol \ Y62 \ 2011-7~	Auto back door		x	x	
Patrol \ Y62 \ 2011-7~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2011-7~	Side radar left		x	x	
Patrol \ Y62 \ 2011-7~	Side radar right		x	x	
Patrol \ Y62 \ 2011-7~	AVM		x	x	
Patrol \ Y62 \ 2011-7~	Air bag	x	x	x	
Patrol \ Y62 \ 2011-7~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2011-7~	Difference lock	x	x	x	
Patrol \ Y62 \ 2011-7~	Sonar	x	x	x	
Patrol \ Y62 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2011-9~	ABS		x	x	
Patrol \ Y62 \ 2011-9~	Meter/M&A		x	x	
Patrol \ Y62 \ 2011-9~	BCM		x		
Patrol \ Y62 \ 2011-9~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2011-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2011-9~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2011-9~	Multi AV		x	x	
Patrol \ Y62 \ 2011-9~	IPDM E/R		x	x	
Patrol \ Y62 \ 2011-9~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2011-9~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2011-9~	Auto drive position		x	x	
Patrol \ Y62 \ 2011-9~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2011-9~	Lane camera		x	x	
Patrol \ Y62 \ 2011-9~	CAN gateway		x		
Patrol \ Y62 \ 2011-9~	Auto back door		x	x	
Patrol \ Y62 \ 2011-9~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2011-9~	Side radar left		x	x	
Patrol \ Y62 \ 2011-9~	Side radar right		x	x	
Patrol \ Y62 \ 2011-9~	Air bag	x	x	x	
Patrol \ Y62 \ 2011-9~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2011-9~	Difference lock	x	x	x	
Patrol \ Y62 \ 2011-9~	Sonar	x	x	x	
Patrol \ Y62 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2012-10~	ABS		x	x	
Patrol \ Y62 \ 2012-10~	Meter/M&A		x	x	
Patrol \ Y62 \ 2012-10~	BCM		x		
Patrol \ Y62 \ 2012-10~	Air bag	x	x	x	

Patrol \ Y62 \ 2012-10~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2012-10~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2012-10~	Multi AV		x	x	
Patrol \ Y62 \ 2012-10~	IPDM E/R		x	x	
Patrol \ Y62 \ 2012-10~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2012-10~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2012-10~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2012-10~	Auto drive position		x	x	
Patrol \ Y62 \ 2012-10~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2012-10~	Lane camera		x	x	
Patrol \ Y62 \ 2012-10~	CAN gateway		x		
Patrol \ Y62 \ 2012-10~	Auto back door		x	x	
Patrol \ Y62 \ 2012-10~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2012-10~	Side radar left		x	x	
Patrol \ Y62 \ 2012-10~	Side radar right		x	x	
Patrol \ Y62 \ 2012-10~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2012-10~	Difference lock	x	x	x	
Patrol \ Y62 \ 2012-10~	Sonar	x	x	x	
Patrol \ Y62 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2013-10~	ABS		x	x	
Patrol \ Y62 \ 2013-10~	Meter/M&A		x	x	
Patrol \ Y62 \ 2013-10~	BCM		x		
Patrol \ Y62 \ 2013-10~	Air bag	x	x	x	
Patrol \ Y62 \ 2013-10~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2013-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2013-10~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2013-10~	Multi AV		x	x	
Patrol \ Y62 \ 2013-10~	IPDM E/R		x	x	
Patrol \ Y62 \ 2013-10~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2013-10~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2013-10~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2013-10~	Auto drive position		x	x	
Patrol \ Y62 \ 2013-10~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2013-10~	Sonar		x	x	
Patrol \ Y62 \ 2013-10~	Lane camera		x	x	
Patrol \ Y62 \ 2013-10~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2013-10~	CAN gateway		x		

Patrol \ Y62 \ 2013-10~	Auto back door		x	x	
Patrol \ Y62 \ 2013-10~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2013-10~	Side radar left		x	x	
Patrol \ Y62 \ 2013-10~	Side radar right		x	x	
Patrol \ Y62 \ 2013-10~	AVM		x	x	
Patrol \ Y62 \ 2013-10~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2013-10~	Difference lock	x	x	x	
Patrol \ Y62 \ 2013-10~	Occupant detection			x	
Patrol \ Y62 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2014-11~	ABS		x	x	
Patrol \ Y62 \ 2014-11~	Meter/M&A		x	x	
Patrol \ Y62 \ 2014-11~	BCM		x		
Patrol \ Y62 \ 2014-11~	Air bag	x	x	x	
Patrol \ Y62 \ 2014-11~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2014-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2014-11~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2014-11~	Multi AV		x	x	
Patrol \ Y62 \ 2014-11~	EPS/DAST 3	x	x	x	
Patrol \ Y62 \ 2014-11~	IPDM E/R		x	x	
Patrol \ Y62 \ 2014-11~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2014-11~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2014-11~	Auto drive position		x	x	
Patrol \ Y62 \ 2014-11~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2014-11~	Sonar	x	x	x	
Patrol \ Y62 \ 2014-11~	Lane camera		x	x	
Patrol \ Y62 \ 2014-11~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2014-11~	CAN gateway		x		
Patrol \ Y62 \ 2014-11~	Auto back door		x	x	
Patrol \ Y62 \ 2014-11~	E-SUS		x	x	
Patrol \ Y62 \ 2014-11~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2014-11~	Side radar left		x	x	
Patrol \ Y62 \ 2014-11~	Side radar right		x	x	
Patrol \ Y62 \ 2014-11~	BSW/buzzer		x	x	
Patrol \ Y62 \ 2014-11~	AVM		x	x	
Patrol \ Y62 \ 2014-11~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2014-11~	Difference lock	x	x	x	
Patrol \ Y62 \ 2014-11~	Occupant detection			x	
Patrol \ Y62 \ 2014-11~	Air levelizer	x	x	x	

Patrol \ Y62 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2015-11~	ABS		x	x	
Patrol \ Y62 \ 2015-11~	Meter/M&A		x	x	
Patrol \ Y62 \ 2015-11~	BCM		x		
Patrol \ Y62 \ 2015-11~	Air bag	x	x	x	
Patrol \ Y62 \ 2015-11~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2015-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2015-11~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2015-11~	Multi AV		x	x	
Patrol \ Y62 \ 2015-11~	EPS/DAST 3	x	x	x	
Patrol \ Y62 \ 2015-11~	IPDM E/R		x	x	
Patrol \ Y62 \ 2015-11~	Air pressure monitor		x	x	
Patrol \ Y62 \ 2015-11~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2015-11~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2015-11~	Auto drive position		x	x	
Patrol \ Y62 \ 2015-11~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2015-11~	Sonar	x	x	x	
Patrol \ Y62 \ 2015-11~	Lane camera		x	x	
Patrol \ Y62 \ 2015-11~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2015-11~	CAN gateway		x		
Patrol \ Y62 \ 2015-11~	Auto back door		x	x	
Patrol \ Y62 \ 2015-11~	E-SUS		x	x	
Patrol \ Y62 \ 2015-11~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2015-11~	Side radar left		x	x	
Patrol \ Y62 \ 2015-11~	Side radar right		x	x	
Patrol \ Y62 \ 2015-11~	AVM		x	x	
Patrol \ Y62 \ 2015-11~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2015-11~	Difference lock	x	x	x	
Patrol \ Y62 \ 2015-11~	Occupant detection			x	
Patrol \ Y62 \ 2015-11~	Air levelizer	x	x	x	
Patrol \ Y62 \ 2016-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2016-8~	ABS		x	x	
Patrol \ Y62 \ 2016-8~	Meter/M&A		x	x	
Patrol \ Y62 \ 2016-8~	BCM		x		
Patrol \ Y62 \ 2016-8~	Air bag	x	x	x	
Patrol \ Y62 \ 2016-8~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2016-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

Patrol \ Y62 \ 2016-8~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2016-8~	Multi AV		x	x	
Patrol \ Y62 \ 2016-8~	EPS/DAST 3	x	x	x	
Patrol \ Y62 \ 2016-8~	IPDM E/R		x	x	
Patrol \ Y62 \ 2016-8~	Air pressure monitor	x	x	x	
Patrol \ Y62 \ 2016-8~	Laser/radar	x	x	x	
Patrol \ Y62 \ 2016-8~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2016-8~	Auto drive position		x	x	
Patrol \ Y62 \ 2016-8~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2016-8~	Sonar	x	x	x	
Patrol \ Y62 \ 2016-8~	Lane camera		x	x	
Patrol \ Y62 \ 2016-8~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2016-8~	CAN gateway		x		
Patrol \ Y62 \ 2016-8~	Auto back door		x	x	
Patrol \ Y62 \ 2016-8~	E-SUS		x	x	
Patrol \ Y62 \ 2016-8~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2016-8~	Side radar left		x	x	
Patrol \ Y62 \ 2016-8~	Side radar right		x	x	
Patrol \ Y62 \ 2016-8~	Telematics		x	x	0253
Patrol \ Y62 \ 2016-8~	AVM		x	x	
Patrol \ Y62 \ 2016-8~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2016-8~	Difference lock	x	x	x	
Patrol \ Y62 \ 2016-8~	Occupant detection			x	
Patrol \ Y62 \ 2016-8~	Air levelizer	x	x	x	
Patrol \ Y62 \ 2016-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Patrol \ Y62 \ 2016-9~	ABS		x	x	
Patrol \ Y62 \ 2016-9~	Meter/M&A		x	x	
Patrol \ Y62 \ 2016-9~	BCM		x		
Patrol \ Y62 \ 2016-9~	Air bag	x	x	x	
Patrol \ Y62 \ 2016-9~	ICC/ADAS		x	x	
Patrol \ Y62 \ 2016-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Patrol \ Y62 \ 2016-9~	Transmission	x	x	x	0059
Patrol \ Y62 \ 2016-9~	Multi AV		x	x	
Patrol \ Y62 \ 2016-9~	IPDM E/R		x	x	
Patrol \ Y62 \ 2016-9~	Air pressure monitor		x	x	
Patrol \ Y62 \ 2016-9~	Precrash seatbelt		x	x	
Patrol \ Y62 \ 2016-9~	Auto drive position		x	x	
Patrol \ Y62 \ 2016-9~	All mode AWD/4WD	x	x	x	
Patrol \ Y62 \ 2016-9~	Sonar		x	x	

Patrol \ Y62 \ 2016-9~	Lane camera		x	x	
Patrol \ Y62 \ 2016-9~	Adaptive light	x	x	x	
Patrol \ Y62 \ 2016-9~	CAN gateway		x		
Patrol \ Y62 \ 2016-9~	Auto back door		x	x	
Patrol \ Y62 \ 2016-9~	E-SUS		x	x	
Patrol \ Y62 \ 2016-9~	Accele pedal ACT		x	x	
Patrol \ Y62 \ 2016-9~	Side radar left		x	x	
Patrol \ Y62 \ 2016-9~	Side radar right		x	x	
Patrol \ Y62 \ 2016-9~	AVM		x	x	
Patrol \ Y62 \ 2016-9~	Head lamp levelizer	x	x	x	
Patrol \ Y62 \ 2016-9~	Difference lock	x	x	x	
Patrol \ Y62 \ 2016-9~	Occupant detection			x	
Patrol \ Y62 \ 2016-9~	Air levelizer	x	x	x	
Pickup \ D21 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D21 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pickup \ D21 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D21 \ All Year	BCM	x	x		
Pickup \ D21 \ All Year	Air bag	x	x	x	
Pickup \ D21 \ All Year	ICC/ADAS	x	x	x	
Pickup \ D21 \ All Year	HVAC	x	x	x	
Pickup \ D21 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D21 \ All Year	Multi AV	x	x	x	0280
Pickup \ D21 \ All Year	EPS/DAST 3	x	x	x	
Pickup \ D21 \ All Year	IPDM E/R	x	x	x	
Pickup \ D21 \ All Year	Air pressure monitor	x	x	x	
Pickup \ D21 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D21 \ All Year	DIU	x	x	x	
Pickup \ D21 \ All Year	Auto slide door	x	x	x	
Pickup \ D21 \ All Year	Auto drive position	x	x	x	
Pickup \ D21 \ All Year	All mode AWD/4WD	x	x	x	
Pickup \ D21 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D21 \ All Year	Sonar	x	x	x	
Pickup \ D21 \ All Year	Lane camera	x	x	x	
Pickup \ D21 \ All Year	Adaptive light	x	x	x	
Pickup \ D21 \ All Year	AVM		x	x	
Pickup \ D21 \ All Year	Head lamp levelizer	x	x	x	
Pickup \ D21 \ All Year	Difference lock	x	x	x	
Pickup \ D21 \ All Year	Nats immu	x	x		

Pickup \ D21 \ All Year	Smart entrance	x	x		
Pickup \ D21 \ All Year	Air levelizer	x	x	x	
Pickup \ D21 \ All Year	Rearview camera			x	
Pickup \ D21 \ All Year	S/blind camera			x	
Pickup \ D21 \ All Year	Motor assist	x	x	x	
Pickup \ D22 \ 1998-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 1998-2~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 1998-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 1998-2~	BCM	x	x		
Pickup \ D22 \ 1998-2~	Air bag	x	x	x	
Pickup \ D22 \ 1998-2~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 1998-2~	HVAC	x	x	x	
Pickup \ D22 \ 1998-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 1998-2~	Multi AV	x	x	x	0280
Pickup \ D22 \ 1998-2~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 1998-2~	IPDM E/R	x	x	x	
Pickup \ D22 \ 1998-2~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 1998-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 1998-2~	DIU	x	x	x	
Pickup \ D22 \ 1998-2~	Auto slide door	x	x	x	
Pickup \ D22 \ 1998-2~	Auto drive position	x	x	x	
Pickup \ D22 \ 1998-2~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 1998-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 1998-2~	Sonar	x	x	x	
Pickup \ D22 \ 1998-2~	Lane camera	x	x	x	
Pickup \ D22 \ 1998-2~	Adaptive light	x	x	x	
Pickup \ D22 \ 1998-2~	AVM		x	x	
Pickup \ D22 \ 1998-2~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 1998-2~	Difference lock	x	x	x	
Pickup \ D22 \ 1998-2~	Nats immu	x	x		
Pickup \ D22 \ 1998-2~	Smart entrance	x	x		
Pickup \ D22 \ 1998-2~	Air levelizer	x	x	x	
Pickup \ D22 \ 1998-2~	Rearview camera			x	
Pickup \ D22 \ 1998-2~	S/blind camera			x	
Pickup \ D22 \ 1998-2~	Motor assist	x	x	x	
Pickup \ D22 \ 1999-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 1999-5~	ABS	x	x	x	0003, 0092, 0264

Pickup \ D22 \ 1999-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 1999-5~	BCM	x	x		
Pickup \ D22 \ 1999-5~	Air bag	x	x	x	
Pickup \ D22 \ 1999-5~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 1999-5~	HVAC	x	x	x	
Pickup \ D22 \ 1999-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 1999-5~	Multi AV	x	x	x	0280
Pickup \ D22 \ 1999-5~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 1999-5~	IPDM E/R	x	x	x	
Pickup \ D22 \ 1999-5~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 1999-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 1999-5~	DIU	x	x	x	
Pickup \ D22 \ 1999-5~	Auto slide door	x	x	x	
Pickup \ D22 \ 1999-5~	Auto drive position	x	x	x	
Pickup \ D22 \ 1999-5~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 1999-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 1999-5~	Sonar	x	x	x	
Pickup \ D22 \ 1999-5~	Lane camera	x	x	x	
Pickup \ D22 \ 1999-5~	Adaptive light	x	x	x	
Pickup \ D22 \ 1999-5~	AVM		x	x	
Pickup \ D22 \ 1999-5~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 1999-5~	Difference lock	x	x	x	
Pickup \ D22 \ 1999-5~	Nats immu	x	x		
Pickup \ D22 \ 1999-5~	Smart entrance	x	x		
Pickup \ D22 \ 1999-5~	Air levelizer	x	x	x	
Pickup \ D22 \ 1999-5~	Rearview camera			x	
Pickup \ D22 \ 1999-5~	S/blind camera			x	
Pickup \ D22 \ 1999-5~	Motor assist	x	x	x	
Pickup \ D22 \ 2001-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2001-11~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2001-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2001-11~	BCM	x	x		
Pickup \ D22 \ 2001-11~	Air bag	x	x	x	
Pickup \ D22 \ 2001-11~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 2001-11~	HVAC	x	x	x	
Pickup \ D22 \ 2001-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 2001-11~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2001-11~	EPS/DAST 3	x	x	x	

Pickup \ D22 \ 2001-11~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2001-11~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 2001-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2001-11~	DIU	x	x	x	
Pickup \ D22 \ 2001-11~	Auto slide door	x	x	x	
Pickup \ D22 \ 2001-11~	Auto drive position	x	x	x	
Pickup \ D22 \ 2001-11~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2001-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 2001-11~	Sonar	x	x	x	
Pickup \ D22 \ 2001-11~	Lane camera	x	x	x	
Pickup \ D22 \ 2001-11~	Adaptive light	x	x	x	
Pickup \ D22 \ 2001-11~	AVM		x	x	
Pickup \ D22 \ 2001-11~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2001-11~	Difference lock	x	x	x	
Pickup \ D22 \ 2001-11~	Nats immu	x	x		
Pickup \ D22 \ 2001-11~	Smart entrance	x	x		
Pickup \ D22 \ 2001-11~	Air levelizer	x	x	x	
Pickup \ D22 \ 2001-11~	Rearview camera			x	
Pickup \ D22 \ 2001-11~	S/blind camera			x	
Pickup \ D22 \ 2001-11~	Motor assist	x	x	x	
Pickup \ D22 \ 2003-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2003-10~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2003-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2003-10~	BCM	x	x		
Pickup \ D22 \ 2003-10~	Air bag	x	x	x	
Pickup \ D22 \ 2003-10~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 2003-10~	HVAC	x	x	x	
Pickup \ D22 \ 2003-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 2003-10~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2003-10~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2003-10~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2003-10~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 2003-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2003-10~	DIU	x	x	x	
Pickup \ D22 \ 2003-10~	Auto slide door	x	x	x	
Pickup \ D22 \ 2003-10~	Auto drive position	x	x	x	

Pickup \ D22 \ 2003-10~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2003-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 2003-10~	Sonar	x	x	x	
Pickup \ D22 \ 2003-10~	Lane camera	x	x	x	
Pickup \ D22 \ 2003-10~	Adaptive light	x	x	x	
Pickup \ D22 \ 2003-10~	AVM		x	x	
Pickup \ D22 \ 2003-10~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2003-10~	Difference lock	x	x	x	
Pickup \ D22 \ 2003-10~	Nats immu	x	x		
Pickup \ D22 \ 2003-10~	Smart entrance	x	x		
Pickup \ D22 \ 2003-10~	Air levelizer	x	x	x	
Pickup \ D22 \ 2003-10~	Rearview camera			x	
Pickup \ D22 \ 2003-10~	S/blind camera			x	
Pickup \ D22 \ 2003-10~	Motor assist	x	x	x	
Pickup \ D22 \ 2003-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2003-3~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2003-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2003-3~	BCM	x	x		
Pickup \ D22 \ 2003-3~	Air bag	x	x	x	
Pickup \ D22 \ 2003-3~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 2003-3~	HVAC	x	x	x	
Pickup \ D22 \ 2003-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 2003-3~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2003-3~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2003-3~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2003-3~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 2003-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2003-3~	DIU	x	x	x	
Pickup \ D22 \ 2003-3~	Auto slide door	x	x	x	
Pickup \ D22 \ 2003-3~	Auto drive position	x	x	x	
Pickup \ D22 \ 2003-3~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2003-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 2003-3~	Sonar	x	x	x	
Pickup \ D22 \ 2003-3~	Lane camera	x	x	x	
Pickup \ D22 \ 2003-3~	Adaptive light	x	x	x	
Pickup \ D22 \ 2003-3~	AVM		x	x	
Pickup \ D22 \ 2003-3~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2003-3~	Difference lock	x	x	x	

Pickup \ D22 \ 2003-3~	Nats immu	x	x		
Pickup \ D22 \ 2003-3~	Smart entrance	x	x		
Pickup \ D22 \ 2003-3~	Air levelizer	x	x	x	
Pickup \ D22 \ 2003-3~	Rearview camera			x	
Pickup \ D22 \ 2003-3~	S/blind camera			x	
Pickup \ D22 \ 2003-3~	Motor assist	x	x	x	
Pickup \ D22 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2004-9~	BCM	x	x		
Pickup \ D22 \ 2004-9~	Air bag	x	x	x	
Pickup \ D22 \ 2004-9~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 2004-9~	HVAC	x	x	x	
Pickup \ D22 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 2004-9~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2004-9~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2004-9~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2004-9~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2004-9~	DIU	x	x	x	
Pickup \ D22 \ 2004-9~	Auto slide door	x	x	x	
Pickup \ D22 \ 2004-9~	Auto drive position	x	x	x	
Pickup \ D22 \ 2004-9~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 2004-9~	Sonar	x	x	x	
Pickup \ D22 \ 2004-9~	Lane camera	x	x	x	
Pickup \ D22 \ 2004-9~	Adaptive light	x	x	x	
Pickup \ D22 \ 2004-9~	AVM		x	x	
Pickup \ D22 \ 2004-9~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2004-9~	Difference lock	x	x	x	
Pickup \ D22 \ 2004-9~	Nats immu	x	x		
Pickup \ D22 \ 2004-9~	Smart entrance	x	x		
Pickup \ D22 \ 2004-9~	Air levelizer	x	x	x	
Pickup \ D22 \ 2004-9~	Rearview camera			x	
Pickup \ D22 \ 2004-9~	S/blind camera			x	
Pickup \ D22 \ 2004-9~	Motor assist	x	x	x	
Pickup \ D22 \ 2008-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Pickup \ D22 \ 2008-1~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2008-1~	BCM	x	x		
Pickup \ D22 \ 2008-1~	Transmission	x	x	x	
Pickup \ D22 \ 2008-1~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2008-1~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2008-1~	Air bag	x	x	x	
Pickup \ D22 \ 2008-1~	Rearview camera			x	
Pickup \ D22 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2009-11~	BCM	x	x		
Pickup \ D22 \ 2009-11~	Air bag	x	x	x	
Pickup \ D22 \ 2009-11~	HVAC	x	x	x	
Pickup \ D22 \ 2009-11~	Transmission	x	x	x	0059
Pickup \ D22 \ 2009-11~	Multi AV	x	x	x	
Pickup \ D22 \ 2009-11~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2009-11~	Auto drive position	x	x	x	
Pickup \ D22 \ 2009-11~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2009-11~	ABS	x	x	x	
Pickup \ D22 \ 2009-11~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2009-11~	Difference lock	x	x	x	
Pickup \ D22 \ 2009-11~	SVT	x	x	x	
Pickup \ D22 \ 2009-11~	Rearview camera			x	
Pickup \ D22 \ 2009-11~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2009-11~	ICC/ADAS	x	x	x	
Pickup \ D22 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ 2009-11~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2009-11~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2009-11~	Air pressure monitor	x	x	x	
Pickup \ D22 \ 2009-11~	DIU	x	x	x	
Pickup \ D22 \ 2009-11~	Auto slide door	x	x	x	
Pickup \ D22 \ 2009-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ 2009-11~	Sonar	x	x	x	
Pickup \ D22 \ 2009-11~	Lane camera	x	x	x	
Pickup \ D22 \ 2009-11~	Adaptive light	x	x	x	
Pickup \ D22 \ 2009-11~	AVM		x	x	
Pickup \ D22 \ 2009-11~	Nats immu	x	x		

Pickup \ D22 \ 2009-11~	Smart entrance	x	x		
Pickup \ D22 \ 2009-11~	Air levelizer	x	x	x	
Pickup \ D22 \ 2009-11~	S/blind camera			x	
Pickup \ D22 \ 2009-11~	Motor assist	x	x	x	
Pickup \ D22 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2009-9~	BCM	x	x		
Pickup \ D22 \ 2009-9~	Air bag	x	x	x	
Pickup \ D22 \ 2009-9~	HVAC	x	x	x	
Pickup \ D22 \ 2009-9~	Transmission	x	x	x	0059
Pickup \ D22 \ 2009-9~	Multi AV	x	x	x	
Pickup \ D22 \ 2009-9~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2009-9~	Auto drive position	x	x	x	
Pickup \ D22 \ 2009-9~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2009-9~	ABS	x	x	x	
Pickup \ D22 \ 2009-9~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2009-9~	Difference lock	x	x	x	
Pickup \ D22 \ 2009-9~	SVT	x	x	x	
Pickup \ D22 \ 2009-9~	Rearview camera			x	
Pickup \ D22 \ 2011-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2011-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2011-2~	BCM	x	x		
Pickup \ D22 \ 2011-2~	Air bag	x	x	x	
Pickup \ D22 \ 2011-2~	HVAC	x	x	x	
Pickup \ D22 \ 2011-2~	Transmission	x	x	x	0059
Pickup \ D22 \ 2011-2~	Multi AV	x	x	x	
Pickup \ D22 \ 2011-2~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2011-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ 2011-2~	Auto drive position	x	x	x	
Pickup \ D22 \ 2011-2~	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ 2011-2~	ABS	x	x	x	
Pickup \ D22 \ 2011-2~	Head lamp levelizer	x	x	x	
Pickup \ D22 \ 2011-2~	Difference lock	x	x	x	
Pickup \ D22 \ 2011-2~	SVT	x	x	x	

Pickup \ D22 \ 2011-2~	Rearview camera			x	
Pickup \ D22 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2012-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2012-10~	BCM	x	x		
Pickup \ D22 \ 2012-10~	Transmission	x	x	x	
Pickup \ D22 \ 2012-10~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2012-10~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2012-10~	ABS	x	x	x	
Pickup \ D22 \ 2012-10~	Air bag	x	x	x	
Pickup \ D22 \ 2012-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2012-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2012-1~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2012-1~	ABS	x	x	x	
Pickup \ D22 \ 2012-1~	Air bag	x	x	x	
Pickup \ D22 \ 2012-1~	SVT	x	x	x	
Pickup \ D22 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2012-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2012-7~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2012-7~	ABS	x	x	x	
Pickup \ D22 \ 2012-7~	Air bag	x	x	x	
Pickup \ D22 \ 2012-7~	SVT	x	x	x	
Pickup \ D22 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2013-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2013-5~	BCM	x	x		
Pickup \ D22 \ 2013-5~	Multi AV	x	x	x	0280
Pickup \ D22 \ 2013-5~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2013-5~	ABS	x	x	x	
Pickup \ D22 \ 2013-5~	Air bag	x	x	x	
Pickup \ D22 \ 2013-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2013-6~	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ 2013-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2013-6~	BCM	x	x		
Pickup \ D22 \ 2013-6~	Air bag	x	x	x	
Pickup \ D22 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ 2015-6~	ABS	x	x	x	0003, 0092, 0264

Pickup \ D22 \ 2015-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ 2015-6~	BCM	x	x		
Pickup \ D22 \ 2015-6~	Transmission	x	x	x	
Pickup \ D22 \ 2015-6~	EPS/DAST 3	x	x	x	
Pickup \ D22 \ 2015-6~	IPDM E/R	x	x	x	
Pickup \ D22 \ 2015-6~	Air bag	x	x	x	
Pickup \ D22 \ 2015-6~	Rearview camera			x	
Pickup \ D22 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup \ D22 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pickup \ D22 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup \ D22 \ All Year	BCM	x	x		
Pickup \ D22 \ All Year	Air bag	x	x	x	
Pickup \ D22 \ All Year	ICC/ADAS	x	x	x	
Pickup \ D22 \ All Year	HVAC	x	x	x	
Pickup \ D22 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup \ D22 \ All Year	Multi AV	x	x	x	0280
Pickup \ D22 \ All Year	EPS/DAST 3	x	x	x	
Pickup \ D22 \ All Year	IPDM E/R	x	x	x	
Pickup \ D22 \ All Year	Air pressure monitor	x	x	x	
Pickup \ D22 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup \ D22 \ All Year	DIU	x	x	x	
Pickup \ D22 \ All Year	Auto slide door	x	x	x	
Pickup \ D22 \ All Year	Auto drive position	x	x	x	
Pickup \ D22 \ All Year	All mode AWD/4WD	x	x	x	
Pickup \ D22 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup \ D22 \ All Year	Sonar	x	x	x	
Pickup \ D22 \ All Year	Lane camera	x	x	x	
Pickup \ D22 \ All Year	Adaptive light	x	x	x	
Pickup \ D22 \ All Year	AVM		x	x	
Pickup \ D22 \ All Year	Head lamp levelizer	x	x	x	
Pickup \ D22 \ All Year	Difference lock	x	x	x	
Pickup \ D22 \ All Year	Nats immu	x	x		
Pickup \ D22 \ All Year	Smart entrance	x	x		
Pickup \ D22 \ All Year	Air levelizer	x	x	x	
Pickup \ D22 \ All Year	Rearview camera			x	
Pickup \ D22 \ All Year	S/blind camera			x	
Pickup \ D22 \ All Year	Motor assist	x	x	x	
Pickup \ D22 \ All Year	ABS	x	x	x	

Pickup-navara \ D22 \ 1997-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup-navara \ D22 \ 1997-1~	ABS	x	x	x	0003, 0092, 0264
Pickup-navara \ D22 \ 1997-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 1997-1~	BCM	x	x		
Pickup-navara \ D22 \ 1997-1~	Air bag	x	x	x	
Pickup-navara \ D22 \ 1997-1~	ICC/ADAS	x	x	x	
Pickup-navara \ D22 \ 1997-1~	HVAC	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup-navara \ D22 \ 1997-1~	Multi AV	x	x	x	0280
Pickup-navara \ D22 \ 1997-1~	EPS/DAST 3	x	x	x	
Pickup-navara \ D22 \ 1997-1~	IPDM E/R	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Air pressure monitor	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup-navara \ D22 \ 1997-1~	DIU	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Auto slide door	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Auto drive position	x	x	x	
Pickup-navara \ D22 \ 1997-1~	All mode AWD/4WD	x	x	x	
Pickup-navara \ D22 \ 1997-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Sonar	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Lane camera	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Adaptive light	x	x	x	
Pickup-navara \ D22 \ 1997-1~	AVM		x	x	
Pickup-navara \ D22 \ 1997-1~	Head lamp levelizer	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Difference lock	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Nats immu	x	x		
Pickup-navara \ D22 \ 1997-1~	Smart entrance	x	x		
Pickup-navara \ D22 \ 1997-1~	Air levelizer	x	x	x	
Pickup-navara \ D22 \ 1997-1~	Rearview camera			x	
Pickup-navara \ D22 \ 1997-1~	S/blind camera			x	
Pickup-navara \ D22 \ 1997-1~	Motor assist	x	x	x	
Pickup-navara \ D22 \ 2008-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 2008-12~	BCM	x	x		
Pickup-navara \ D22 \ 2008-12~	Transmission	x	x	x	
Pickup-navara \ D22 \ 2008-12~	IPDM E/R	x	x	x	
Pickup-navara \ D22 \ 2008-12~	Engine	x	x	x	
Pickup-navara \ D22 \ 2008-12~	Air bag	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Pickup-navara \ D22 \ 2008-1~	ABS	x	x	x	0003, 0092, 0264
Pickup-navara \ D22 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 2008-1~	BCM	x	x		
Pickup-navara \ D22 \ 2008-1~	Air bag	x	x	x	
Pickup-navara \ D22 \ 2008-1~	ICC/ADAS	x	x	x	
Pickup-navara \ D22 \ 2008-1~	HVAC	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup-navara \ D22 \ 2008-1~	Multi AV	x	x	x	0280
Pickup-navara \ D22 \ 2008-1~	EPS/DAST 3	x	x	x	
Pickup-navara \ D22 \ 2008-1~	IPDM E/R	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Air pressure monitor	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup-navara \ D22 \ 2008-1~	DIU	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Auto slide door	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Auto drive position	x	x	x	
Pickup-navara \ D22 \ 2008-1~	All mode AWD/4WD	x	x	x	
Pickup-navara \ D22 \ 2008-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Sonar	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Lane camera	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Adaptive light	x	x	x	
Pickup-navara \ D22 \ 2008-1~	AVM		x	x	
Pickup-navara \ D22 \ 2008-1~	Head lamp levelizer	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Difference lock	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Nats immu	x	x		
Pickup-navara \ D22 \ 2008-1~	Smart entrance	x	x		
Pickup-navara \ D22 \ 2008-1~	Air levelizer	x	x	x	
Pickup-navara \ D22 \ 2008-1~	Rearview camera			x	
Pickup-navara \ D22 \ 2008-1~	S/blind camera			x	
Pickup-navara \ D22 \ 2008-1~	Motor assist	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup-navara \ D22 \ 2009-11~	ABS	x	x	x	0003, 0092, 0264
Pickup-navara \ D22 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 2009-11~	BCM	x	x		
Pickup-navara \ D22 \ 2009-11~	Air bag	x	x	x	
Pickup-navara \ D22 \ 2009-11~	ICC/ADAS	x	x	x	
Pickup-navara \ D22 \ 2009-11~	HVAC	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup-navara \ D22 \ 2009-11~	Multi AV	x	x	x	0280

Pickup-navara \ D22 \ 2009-11~	EPS/DAST 3	x	x	x	
Pickup-navara \ D22 \ 2009-11~	IPDM E/R	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Air pressure monitor	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup-navara \ D22 \ 2009-11~	DIU	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Auto slide door	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Auto drive position	x	x	x	
Pickup-navara \ D22 \ 2009-11~	All mode AWD/4WD	x	x	x	
Pickup-navara \ D22 \ 2009-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Sonar	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Lane camera	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Adaptive light	x	x	x	
Pickup-navara \ D22 \ 2009-11~	AVM		x	x	
Pickup-navara \ D22 \ 2009-11~	Head lamp levelizer	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Difference lock	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Nats immu	x	x		
Pickup-navara \ D22 \ 2009-11~	Smart entrance	x	x		
Pickup-navara \ D22 \ 2009-11~	Air levelizer	x	x	x	
Pickup-navara \ D22 \ 2009-11~	Rearview camera			x	
Pickup-navara \ D22 \ 2009-11~	S/blind camera			x	
Pickup-navara \ D22 \ 2009-11~	Motor assist	x	x	x	
Pickup-navara \ D22 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup-navara \ D22 \ 2011-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 2011-11~	IPDM E/R	x	x	x	
Pickup-navara \ D22 \ 2011-11~	ABS	x	x	x	
Pickup-navara \ D22 \ 2011-11~	Air bag	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pickup-navara \ D22 \ 2011-1~	ABS	x	x	x	0003, 0092, 0264
Pickup-navara \ D22 \ 2011-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pickup-navara \ D22 \ 2011-1~	BCM	x	x		
Pickup-navara \ D22 \ 2011-1~	Air bag	x	x	x	
Pickup-navara \ D22 \ 2011-1~	ICC/ADAS	x	x	x	
Pickup-navara \ D22 \ 2011-1~	HVAC	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pickup-navara \ D22 \ 2011-1~	Multi AV	x	x	x	0280
Pickup-navara \ D22 \ 2011-1~	EPS/DAST 3	x	x	x	
Pickup-navara \ D22 \ 2011-1~	IPDM E/R	x	x	x	

Pickup-navara \ D22 \ 2011-1~	Air pressure monitor	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pickup-navara \ D22 \ 2011-1~	DIU	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Auto slide door	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Auto drive position	x	x	x	
Pickup-navara \ D22 \ 2011-1~	All mode AWD/4WD	x	x	x	
Pickup-navara \ D22 \ 2011-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Sonar	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Lane camera	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Adaptive light	x	x	x	
Pickup-navara \ D22 \ 2011-1~	AVM		x	x	
Pickup-navara \ D22 \ 2011-1~	Head lamp levelizer	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Difference lock	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Nats immu	x	x		
Pickup-navara \ D22 \ 2011-1~	Smart entrance	x	x		
Pickup-navara \ D22 \ 2011-1~	Air levelizer	x	x	x	
Pickup-navara \ D22 \ 2011-1~	Rearview camera			x	
Pickup-navara \ D22 \ 2011-1~	S/blind camera			x	
Pickup-navara \ D22 \ 2011-1~	Motor assist	x	x	x	
Prairie \ M12 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Prairie \ M12 \ All Year	ABS	x	x	x	0003, 0092, 0264
Prairie \ M12 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Prairie \ M12 \ All Year	BCM	x	x		
Prairie \ M12 \ All Year	Air bag	x	x	x	
Prairie \ M12 \ All Year	ICC/ADAS	x	x	x	
Prairie \ M12 \ All Year	HVAC	x	x	x	
Prairie \ M12 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Prairie \ M12 \ All Year	Multi AV	x	x	x	0280
Prairie \ M12 \ All Year	EPS/DAST 3	x	x	x	
Prairie \ M12 \ All Year	IPDM E/R	x	x	x	
Prairie \ M12 \ All Year	Air pressure monitor	x	x	x	
Prairie \ M12 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Prairie \ M12 \ All Year	DIU	x	x	x	
Prairie \ M12 \ All Year	Auto slide door	x	x	x	
Prairie \ M12 \ All Year	Auto drive position	x	x	x	
Prairie \ M12 \ All Year	All mode AWD/4WD	x	x	x	

Prairie \ M12 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Prairie \ M12 \ All Year	Sonar	x	x	x	
Prairie \ M12 \ All Year	Lane camera	x	x	x	
Prairie \ M12 \ All Year	Adaptive light	x	x	x	
Prairie \ M12 \ All Year	AVM		x	x	
Prairie \ M12 \ All Year	Head lamp levelizer	x	x	x	
Prairie \ M12 \ All Year	Difference lock	x	x	x	
Prairie \ M12 \ All Year	Nats immu	x	x		
Prairie \ M12 \ All Year	Smart entrance	x	x		
Prairie \ M12 \ All Year	Air levelizer	x	x	x	
Prairie \ M12 \ All Year	Rearview camera			x	
Prairie \ M12 \ All Year	S/blind camera			x	
Prairie \ M12 \ All Year	Motor assist	x	x	x	
Presage \ U30 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U30 \ All Year	ABS	x	x	x	0003, 0092, 0264
Presage \ U30 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U30 \ All Year	BCM	x	x		
Presage \ U30 \ All Year	Air bag	x	x	x	
Presage \ U30 \ All Year	ICC/ADAS	x	x	x	
Presage \ U30 \ All Year	HVAC	x	x	x	
Presage \ U30 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U30 \ All Year	Multi AV	x	x	x	0280
Presage \ U30 \ All Year	EPS/DAST 3	x	x	x	
Presage \ U30 \ All Year	IPDM E/R	x	x	x	
Presage \ U30 \ All Year	Air pressure monitor	x	x	x	
Presage \ U30 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U30 \ All Year	DIU	x	x	x	
Presage \ U30 \ All Year	Auto slide door	x	x	x	
Presage \ U30 \ All Year	Auto drive position	x	x	x	
Presage \ U30 \ All Year	All mode AWD/4WD	x	x	x	
Presage \ U30 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U30 \ All Year	Sonar	x	x	x	
Presage \ U30 \ All Year	Lane camera	x	x	x	
Presage \ U30 \ All Year	Adaptive light	x	x	x	
Presage \ U30 \ All Year	AVM		x	x	
Presage \ U30 \ All Year	Head lamp levelizer	x	x	x	
Presage \ U30 \ All Year	Difference lock	x	x	x	
Presage \ U30 \ All Year	Nats immu	x	x		

Presage \ U30 \ All Year	Smart entrance	x	x		
Presage \ U30 \ All Year	Air levelizer	x	x	x	
Presage \ U30 \ All Year	Rearview camera			x	
Presage \ U30 \ All Year	S/blind camera			x	
Presage \ U30 \ All Year	Motor assist	x	x	x	
Presage \ U31 \ 2003-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2003-6~	ABS	x	x	x	0003, 0092, 0264
Presage \ U31 \ 2003-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2003-6~	BCM	x	x		
Presage \ U31 \ 2003-6~	Air bag	x	x	x	
Presage \ U31 \ 2003-6~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2003-6~	HVAC	x	x	x	
Presage \ U31 \ 2003-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2003-6~	Multi AV	x	x	x	0280
Presage \ U31 \ 2003-6~	EPS/DAST 3	x	x	x	
Presage \ U31 \ 2003-6~	IPDM E/R	x	x	x	
Presage \ U31 \ 2003-6~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2003-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2003-6~	DIU	x	x	x	
Presage \ U31 \ 2003-6~	Auto slide door	x	x	x	
Presage \ U31 \ 2003-6~	Auto drive position	x	x	x	
Presage \ U31 \ 2003-6~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2003-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2003-6~	Sonar	x	x	x	
Presage \ U31 \ 2003-6~	Lane camera	x	x	x	
Presage \ U31 \ 2003-6~	Adaptive light	x	x	x	
Presage \ U31 \ 2003-6~	AVM		x	x	
Presage \ U31 \ 2003-6~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2003-6~	Difference lock	x	x	x	
Presage \ U31 \ 2003-6~	Nats immu	x	x		
Presage \ U31 \ 2003-6~	Smart entrance	x	x		
Presage \ U31 \ 2003-6~	Air levelizer	x	x	x	
Presage \ U31 \ 2003-6~	Rearview camera			x	
Presage \ U31 \ 2003-6~	S/blind camera			x	
Presage \ U31 \ 2003-6~	Motor assist	x	x	x	
Presage \ U31 \ 2004-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2004-10~	ABS	x	x	x	0003, 0092, 0264

Presage \ U31 \ 2004-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2004-10~	BCM	x	x		
Presage \ U31 \ 2004-10~	Air bag	x	x	x	
Presage \ U31 \ 2004-10~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2004-10~	HVAC	x	x	x	
Presage \ U31 \ 2004-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2004-10~	Multi AV	x	x	x	0280
Presage \ U31 \ 2004-10~	EPS/DAST 3	x	x	x	
Presage \ U31 \ 2004-10~	IPDM E/R	x	x	x	
Presage \ U31 \ 2004-10~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2004-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2004-10~	DIU	x	x	x	
Presage \ U31 \ 2004-10~	Auto slide door	x	x	x	
Presage \ U31 \ 2004-10~	Auto drive position	x	x	x	
Presage \ U31 \ 2004-10~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2004-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2004-10~	Sonar	x	x	x	
Presage \ U31 \ 2004-10~	Lane camera	x	x	x	
Presage \ U31 \ 2004-10~	Adaptive light	x	x	x	
Presage \ U31 \ 2004-10~	AVM		x	x	
Presage \ U31 \ 2004-10~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2004-10~	Difference lock	x	x	x	
Presage \ U31 \ 2004-10~	Nats immu	x	x		
Presage \ U31 \ 2004-10~	Smart entrance	x	x		
Presage \ U31 \ 2004-10~	Air levelizer	x	x	x	
Presage \ U31 \ 2004-10~	Rearview camera			x	
Presage \ U31 \ 2004-10~	S/blind camera			x	
Presage \ U31 \ 2004-10~	Motor assist	x	x	x	
Presage \ U31 \ 2005-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2005-1~	ABS	x	x	x	0003, 0092, 0264
Presage \ U31 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2005-1~	BCM	x	x		
Presage \ U31 \ 2005-1~	Air bag	x	x	x	
Presage \ U31 \ 2005-1~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2005-1~	HVAC	x	x	x	
Presage \ U31 \ 2005-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2005-1~	Multi AV	x	x	x	0280
Presage \ U31 \ 2005-1~	EPS/DAST 3	x	x	x	

Presage \ U31 \ 2005-1~	IPDM E/R	x	x	x	
Presage \ U31 \ 2005-1~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2005-1~	DIU	x	x	x	
Presage \ U31 \ 2005-1~	Auto slide door	x	x	x	
Presage \ U31 \ 2005-1~	Auto drive position	x	x	x	
Presage \ U31 \ 2005-1~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2005-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2005-1~	Sonar	x	x	x	
Presage \ U31 \ 2005-1~	Lane camera	x	x	x	
Presage \ U31 \ 2005-1~	Adaptive light	x	x	x	
Presage \ U31 \ 2005-1~	AVM		x	x	
Presage \ U31 \ 2005-1~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2005-1~	Difference lock	x	x	x	
Presage \ U31 \ 2005-1~	Nats immu	x	x		
Presage \ U31 \ 2005-1~	Smart entrance	x	x		
Presage \ U31 \ 2005-1~	Air levelizer	x	x	x	
Presage \ U31 \ 2005-1~	Rearview camera			x	
Presage \ U31 \ 2005-1~	S/blind camera			x	
Presage \ U31 \ 2005-1~	Motor assist	x	x	x	
Presage \ U31 \ 2005-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2005-2~	ABS	x	x	x	0003, 0092, 0264
Presage \ U31 \ 2005-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2005-2~	BCM	x	x		
Presage \ U31 \ 2005-2~	Air bag	x	x	x	
Presage \ U31 \ 2005-2~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2005-2~	HVAC	x	x	x	
Presage \ U31 \ 2005-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2005-2~	Multi AV	x	x	x	0280
Presage \ U31 \ 2005-2~	EPS/DAST 3	x	x	x	
Presage \ U31 \ 2005-2~	IPDM E/R	x	x	x	
Presage \ U31 \ 2005-2~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2005-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2005-2~	DIU	x	x	x	
Presage \ U31 \ 2005-2~	Auto slide door	x	x	x	
Presage \ U31 \ 2005-2~	Auto drive position	x	x	x	

Presage \ U31 \ 2005-2~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2005-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2005-2~	Sonar	x	x	x	
Presage \ U31 \ 2005-2~	Lane camera	x	x	x	
Presage \ U31 \ 2005-2~	Adaptive light	x	x	x	
Presage \ U31 \ 2005-2~	AVM		x	x	
Presage \ U31 \ 2005-2~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2005-2~	Difference lock	x	x	x	
Presage \ U31 \ 2005-2~	Nats immu	x	x		
Presage \ U31 \ 2005-2~	Smart entrance	x	x		
Presage \ U31 \ 2005-2~	Air levelizer	x	x	x	
Presage \ U31 \ 2005-2~	Rearview camera			x	
Presage \ U31 \ 2005-2~	S/blind camera			x	
Presage \ U31 \ 2005-2~	Motor assist	x	x	x	
Presage \ U31 \ 2006-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2006-5~	ABS	x	x	x	0003, 0092, 0264
Presage \ U31 \ 2006-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2006-5~	BCM	x	x		
Presage \ U31 \ 2006-5~	Air bag	x	x	x	
Presage \ U31 \ 2006-5~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2006-5~	HVAC	x	x	x	
Presage \ U31 \ 2006-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2006-5~	Multi AV	x	x	x	0280
Presage \ U31 \ 2006-5~	EPS/DAST 3	x	x	x	
Presage \ U31 \ 2006-5~	IPDM E/R	x	x	x	
Presage \ U31 \ 2006-5~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2006-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2006-5~	DIU	x	x	x	
Presage \ U31 \ 2006-5~	Auto slide door	x	x	x	
Presage \ U31 \ 2006-5~	Auto drive position	x	x	x	
Presage \ U31 \ 2006-5~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2006-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2006-5~	Sonar	x	x	x	
Presage \ U31 \ 2006-5~	Lane camera	x	x	x	
Presage \ U31 \ 2006-5~	Adaptive light	x	x	x	
Presage \ U31 \ 2006-5~	AVM		x	x	
Presage \ U31 \ 2006-5~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2006-5~	Difference lock	x	x	x	

Presage \ U31 \ 2006-5~	Nats immu	x	x		
Presage \ U31 \ 2006-5~	Smart entrance	x	x		
Presage \ U31 \ 2006-5~	Air levelizer	x	x	x	
Presage \ U31 \ 2006-5~	Rearview camera			x	
Presage \ U31 \ 2006-5~	S/blind camera			x	
Presage \ U31 \ 2006-5~	Motor assist	x	x	x	
Presage \ U31 \ 2007-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Presage \ U31 \ 2007-5~	ABS	x	x	x	0003, 0092, 0264
Presage \ U31 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presage \ U31 \ 2007-5~	BCM	x	x		
Presage \ U31 \ 2007-5~	Air bag	x	x	x	
Presage \ U31 \ 2007-5~	ICC/ADAS	x	x	x	
Presage \ U31 \ 2007-5~	HVAC	x	x	x	
Presage \ U31 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presage \ U31 \ 2007-5~	Multi AV	x	x	x	0280
Presage \ U31 \ 2007-5~	EPS/DAST 3	x	x	x	
Presage \ U31 \ 2007-5~	IPDM E/R	x	x	x	
Presage \ U31 \ 2007-5~	Air pressure monitor	x	x	x	
Presage \ U31 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presage \ U31 \ 2007-5~	DIU	x	x	x	
Presage \ U31 \ 2007-5~	Auto slide door	x	x	x	
Presage \ U31 \ 2007-5~	Auto drive position	x	x	x	
Presage \ U31 \ 2007-5~	All mode AWD/4WD	x	x	x	
Presage \ U31 \ 2007-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presage \ U31 \ 2007-5~	Sonar	x	x	x	
Presage \ U31 \ 2007-5~	Lane camera	x	x	x	
Presage \ U31 \ 2007-5~	Adaptive light	x	x	x	
Presage \ U31 \ 2007-5~	AVM		x	x	
Presage \ U31 \ 2007-5~	Head lamp levelizer	x	x	x	
Presage \ U31 \ 2007-5~	Difference lock	x	x	x	
Presage \ U31 \ 2007-5~	Nats immu	x	x		
Presage \ U31 \ 2007-5~	Smart entrance	x	x		
Presage \ U31 \ 2007-5~	Air levelizer	x	x	x	
Presage \ U31 \ 2007-5~	Rearview camera			x	
Presage \ U31 \ 2007-5~	S/blind camera			x	
Presage \ U31 \ 2007-5~	Motor assist	x	x	x	
Presea \ R11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Presea \ R11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Presea \ R11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Presea \ R11 \ All Year	BCM	x	x		
Presea \ R11 \ All Year	Air bag	x	x	x	
Presea \ R11 \ All Year	ICC/ADAS	x	x	x	
Presea \ R11 \ All Year	HVAC	x	x	x	
Presea \ R11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Presea \ R11 \ All Year	Multi AV	x	x	x	0280
Presea \ R11 \ All Year	EPS/DAST 3	x	x	x	
Presea \ R11 \ All Year	IPDM E/R	x	x	x	
Presea \ R11 \ All Year	Air pressure monitor	x	x	x	
Presea \ R11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Presea \ R11 \ All Year	DIU	x	x	x	
Presea \ R11 \ All Year	Auto slide door	x	x	x	
Presea \ R11 \ All Year	Auto drive position	x	x	x	
Presea \ R11 \ All Year	All mode AWD/4WD	x	x	x	
Presea \ R11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Presea \ R11 \ All Year	Sonar	x	x	x	
Presea \ R11 \ All Year	Lane camera	x	x	x	
Presea \ R11 \ All Year	Adaptive light	x	x	x	
Presea \ R11 \ All Year	AVM		x	x	
Presea \ R11 \ All Year	Head lamp levelizer	x	x	x	
Presea \ R11 \ All Year	Difference lock	x	x	x	
Presea \ R11 \ All Year	Nats immu	x	x		
Presea \ R11 \ All Year	Smart entrance	x	x		
Presea \ R11 \ All Year	Air levelizer	x	x	x	
Presea \ R11 \ All Year	Rearview camera			x	
Presea \ R11 \ All Year	S/blind camera			x	
Presea \ R11 \ All Year	Motor assist	x	x	x	
President \ PF50 \ 2003-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
President \ PF50 \ 2003-10~	ABS	x	x	x	0003, 0092, 0264
President \ PF50 \ 2003-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
President \ PF50 \ 2003-10~	BCM	x	x		
President \ PF50 \ 2003-10~	Air bag	x	x	x	
President \ PF50 \ 2003-10~	ICC/ADAS	x	x	x	
President \ PF50 \ 2003-10~	HVAC	x	x	x	
President \ PF50 \ 2003-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
President \ PF50 \ 2003-10~	Multi AV	x	x	x	0280

President \ PF50 \ 2003-10~	EPS/DAST 3	x	x	x	
President \ PF50 \ 2003-10~	IPDM E/R	x	x	x	
President \ PF50 \ 2003-10~	Air pressure monitor	x	x	x	
President \ PF50 \ 2003-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
President \ PF50 \ 2003-10~	DIU	x	x	x	
President \ PF50 \ 2003-10~	Auto slide door	x	x	x	
President \ PF50 \ 2003-10~	Auto drive position	x	x	x	
President \ PF50 \ 2003-10~	All mode AWD/4WD	x	x	x	
President \ PF50 \ 2003-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
President \ PF50 \ 2003-10~	Sonar	x	x	x	
President \ PF50 \ 2003-10~	Lane camera	x	x	x	
President \ PF50 \ 2003-10~	Adaptive light	x	x	x	
President \ PF50 \ 2003-10~	AVM		x	x	
President \ PF50 \ 2003-10~	Head lamp levelizer	x	x	x	
President \ PF50 \ 2003-10~	Difference lock	x	x	x	
President \ PF50 \ 2003-10~	Nats immu	x	x		
President \ PF50 \ 2003-10~	Smart entrance	x	x		
President \ PF50 \ 2003-10~	Air levelizer	x	x	x	
President \ PF50 \ 2003-10~	Rearview camera			x	
President \ PF50 \ 2003-10~	S/blind camera			x	
President \ PF50 \ 2003-10~	Motor assist	x	x	x	
President \ PF50 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
President \ PF50 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
President \ PF50 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
President \ PF50 \ 2005-12~	BCM	x	x		
President \ PF50 \ 2005-12~	Air bag	x	x	x	
President \ PF50 \ 2005-12~	ICC/ADAS	x	x	x	
President \ PF50 \ 2005-12~	HVAC	x	x	x	
President \ PF50 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
President \ PF50 \ 2005-12~	Multi AV	x	x	x	0280
President \ PF50 \ 2005-12~	EPS/DAST 3	x	x	x	
President \ PF50 \ 2005-12~	IPDM E/R	x	x	x	
President \ PF50 \ 2005-12~	Air pressure monitor	x	x	x	
President \ PF50 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
President \ PF50 \ 2005-12~	DIU	x	x	x	
President \ PF50 \ 2005-12~	Auto slide door	x	x	x	

President \ PF50 \ 2005-12~	Auto drive position	x	x	x	
President \ PF50 \ 2005-12~	All mode AWD/4WD	x	x	x	
President \ PF50 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
President \ PF50 \ 2005-12~	Sonar	x	x	x	
President \ PF50 \ 2005-12~	Lane camera	x	x	x	
President \ PF50 \ 2005-12~	Adaptive light	x	x	x	
President \ PF50 \ 2005-12~	AVM		x	x	
President \ PF50 \ 2005-12~	Head lamp levelizer	x	x	x	
President \ PF50 \ 2005-12~	Difference lock	x	x	x	
President \ PF50 \ 2005-12~	Nats immu	x	x		
President \ PF50 \ 2005-12~	Smart entrance	x	x		
President \ PF50 \ 2005-12~	Air levelizer	x	x	x	
President \ PF50 \ 2005-12~	Rearview camera			x	
President \ PF50 \ 2005-12~	S/blind camera			x	
President \ PF50 \ 2005-12~	Motor assist	x	x	x	
Primastar \ X83 \ 2006-9~	Engine	x	x	x	0107, 0128, 0148, 0040, 0169, 0101, 0020, 0106, 0064, 0252, 0272, 0214, 0034, 0103, 0216, 0035, 0318, 0038, 0298, 0112, 0139, 0163, 0208, 0326, 0262, 0005, 0342, 0227, 0225, 0093, 0221, 0220
Primastar \ X83 \ 2006-9~	ABS		x	x	0173, 0336, 0121, 0263, 0325, 0122, 0323, 0263, 0268, 0055, 0336
Primastar \ X83 \ 2006-9~	Transmission	x	x	x	0334, 0336, 0213, 0216, 0068, 0215, 0339, 0223
Primastar \ X83 \ 2006-9~	Multi AV		x	x	0101, 0336
Primastar \ X83 \ 2006-9~	CIU		x	x	
Primastar \ X83 \ 2006-9~	MM conn		x	x	0336
Primastar \ X83 \ 2006-9~	Cluster		x	x	0052, 0142, 0203, 0338
Primastar \ X83 \ 2006-9~	CHA		x	x	0119, 0120
Primastar \ X83 \ 2006-9~	Radio		x	x	
Primastar \ X83 \ 2006-9~	BCM	x	x	x	0179, 0326
Primastar \ X83 \ 2006-9~	Air bag		x	x	0336, 0326, 0341, 0317
Primastar \ X83 \ 2006-9~	BAC		x	x	
Primastar \ X83 \ 2006-9~	Sonar		x	x	
Primastar \ X83 \ 2009-12~	Engine	x	x	x	0107, 0128, 0148, 0040, 0169, 0101, 0020, 0106, 0064, 0252, 0272, 0214, 0034, 0103, 0216, 0035, 0318, 0038, 0298, 0112, 0139, 0163, 0208, 0326, 0262, 0005, 0342, 0227, 0225, 0093, 0221, 0220

Primastar \ X83 \ 2009-12~	ABS		x	x	0173, 0336, 0121, 0263, 0325, 0122, 0323, 0263, 0268, 0055, 0336
Primastar \ X83 \ 2009-12~	Transmission	x	x	x	0334, 0336, 0213, 0216, 0068, 0215, 0339, 0223
Primastar \ X83 \ 2009-12~	Multi AV		x	x	0101, 0336
Primastar \ X83 \ 2009-12~	CIU		x	x	
Primastar \ X83 \ 2009-12~	MM conn		x	x	0336
Primastar \ X83 \ 2009-12~	Cluster		x	x	0052, 0142, 0203, 0338
Primastar \ X83 \ 2009-12~	CHA		x	x	0119, 0120
Primastar \ X83 \ 2009-12~	Radio		x	x	
Primastar \ X83 \ 2009-12~	BCM	x	x	x	0179, 0326
Primastar \ X83 \ 2009-12~	Air bag		x	x	0336, 0326, 0341, 0317
Primastar \ X83 \ 2009-12~	BAC		x	x	
Primastar \ X83 \ 2009-12~	Sonar		x	x	
Primera \ P11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Primera \ P11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Primera \ P11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Primera \ P11 \ All Year	BCM	x	x		
Primera \ P11 \ All Year	Air bag	x	x	x	
Primera \ P11 \ All Year	ICC/ADAS	x	x	x	
Primera \ P11 \ All Year	HVAC	x	x	x	
Primera \ P11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Primera \ P11 \ All Year	Multi AV	x	x	x	0280
Primera \ P11 \ All Year	EPS/DAST 3	x	x	x	
Primera \ P11 \ All Year	IPDM E/R	x	x	x	
Primera \ P11 \ All Year	Air pressure monitor	x	x	x	
Primera \ P11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Primera \ P11 \ All Year	DIU	x	x	x	
Primera \ P11 \ All Year	Auto slide door	x	x	x	
Primera \ P11 \ All Year	Auto drive position	x	x	x	
Primera \ P11 \ All Year	All mode AWD/4WD	x	x	x	
Primera \ P11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Primera \ P11 \ All Year	Sonar	x	x	x	
Primera \ P11 \ All Year	Lane camera	x	x	x	
Primera \ P11 \ All Year	Adaptive light	x	x	x	
Primera \ P11 \ All Year	AVM		x	x	
Primera \ P11 \ All Year	Head lamp levelizer	x	x	x	
Primera \ P11 \ All Year	Difference lock	x	x	x	

Primera \ P11 \ All Year	Nats immu	x	x		
Primera \ P11 \ All Year	Smart entrance	x	x		
Primera \ P11 \ All Year	Air levelizer	x	x	x	
Primera \ P11 \ All Year	Rearview camera			x	
Primera \ P11 \ All Year	S/blind camera			x	
Primera \ P11 \ All Year	Motor assist	x	x	x	
Primera \ P12 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Primera \ P12 \ All Year	ABS	x	x	x	0003, 0092, 0264
Primera \ P12 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Primera \ P12 \ All Year	BCM	x	x		
Primera \ P12 \ All Year	Air bag	x	x	x	
Primera \ P12 \ All Year	ICC/ADAS	x	x	x	
Primera \ P12 \ All Year	HVAC	x	x	x	
Primera \ P12 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Primera \ P12 \ All Year	Multi AV	x	x	x	0280
Primera \ P12 \ All Year	EPS/DAST 3	x	x	x	
Primera \ P12 \ All Year	IPDM E/R	x	x	x	
Primera \ P12 \ All Year	Air pressure monitor	x	x	x	
Primera \ P12 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Primera \ P12 \ All Year	DIU	x	x	x	
Primera \ P12 \ All Year	Auto slide door	x	x	x	
Primera \ P12 \ All Year	Auto drive position	x	x	x	
Primera \ P12 \ All Year	All mode AWD/4WD	x	x	x	
Primera \ P12 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Primera \ P12 \ All Year	Sonar	x	x	x	
Primera \ P12 \ All Year	Lane camera	x	x	x	
Primera \ P12 \ All Year	Adaptive light	x	x	x	
Primera \ P12 \ All Year	AVM		x	x	
Primera \ P12 \ All Year	Head lamp levelizer	x	x	x	
Primera \ P12 \ All Year	Difference lock	x	x	x	
Primera \ P12 \ All Year	Nats immu	x	x		
Primera \ P12 \ All Year	Smart entrance	x	x		
Primera \ P12 \ All Year	Air levelizer	x	x	x	
Primera \ P12 \ All Year	Rearview camera			x	
Primera \ P12 \ All Year	S/blind camera			x	
Primera \ P12 \ All Year	Motor assist	x	x	x	
Pulsar hatchback \ C12 \ 2013-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Pulsar hatchback \ C12 \ 2013-3~	ABS	x	x	x	0003, 0092, 0264
Pulsar hatchback \ C12 \ 2013-3~	Meter/M&A		x	x	
Pulsar hatchback \ C12 \ 2013-3~	BCM		x		
Pulsar hatchback \ C12 \ 2013-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar hatchback \ C12 \ 2013-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar hatchback \ C12 \ 2013-3~	Multi AV		x	x	
Pulsar hatchback \ C12 \ 2013-3~	EPS/DAST 3	x	x	x	
Pulsar hatchback \ C12 \ 2013-3~	IPDM E/R		x	x	
Pulsar hatchback \ C12 \ 2013-3~	Sonar	x	x	x	
Pulsar hatchback \ C12 \ 2013-3~	Air bag	x	x	x	
Pulsar hatchback \ C12 \ 2013-3~	Head lamp levelizer	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar sedan \ B17 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
Pulsar sedan \ B17 \ 2012-11~	Meter/M&A		x	x	
Pulsar sedan \ B17 \ 2012-11~	BCM		x		
Pulsar sedan \ B17 \ 2012-11~	Air bag		x	x	
Pulsar sedan \ B17 \ 2012-11~	ICC/ADAS	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar sedan \ B17 \ 2012-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Pulsar sedan \ B17 \ 2012-11~	Multi AV	x	x	x	0280
Pulsar sedan \ B17 \ 2012-11~	EPS/DAST 3	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	IPDM E/R		x	x	
Pulsar sedan \ B17 \ 2012-11~	Air pressure monitor		x	x	
Pulsar sedan \ B17 \ 2012-11~	Laser/radar	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	Sonar	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	Side radar left		x	x	
Pulsar sedan \ B17 \ 2012-11~	Side radar right		x	x	
Pulsar sedan \ B17 \ 2012-11~	PTC heater		x	x	
Pulsar sedan \ B17 \ 2012-11~	Telematics		x	x	0253
Pulsar sedan \ B17 \ 2012-11~	AVM		x	x	
Pulsar sedan \ B17 \ 2012-11~	Head lamp levelizer	x	x	x	
Pulsar sedan \ B17 \ 2012-11~	Occupant detection			x	
Pulsar sedan \ B17 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar sedan \ B17 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
Pulsar sedan \ B17 \ 2012-12~	Meter/M&A		x	x	
Pulsar sedan \ B17 \ 2012-12~	BCM		x		

Pulsar sedan \ B17 \ 2012-12~	Air bag		x	x	
Pulsar sedan \ B17 \ 2012-12~	ICC/ADAS	x	x	x	
Pulsar sedan \ B17 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar sedan \ B17 \ 2012-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Pulsar sedan \ B17 \ 2012-12~	Multi AV	x	x	x	0280
Pulsar sedan \ B17 \ 2012-12~	EPS/DAST 3	x	x	x	
Pulsar sedan \ B17 \ 2012-12~	IPDM E/R		x	x	
Pulsar sedan \ B17 \ 2012-12~	Air pressure monitor		x	x	
Pulsar sedan \ B17 \ 2012-12~	Laser/radar	x	x	x	
Pulsar sedan \ B17 \ 2012-12~	Sonar	x	x	x	
Pulsar sedan \ B17 \ 2012-12~	Side radar left		x	x	
Pulsar sedan \ B17 \ 2012-12~	Side radar right		x	x	
Pulsar sedan \ B17 \ 2012-12~	PTC heater		x	x	
Pulsar sedan \ B17 \ 2012-12~	Telematics		x	x	0253
Pulsar sedan \ B17 \ 2012-12~	AVM		x	x	
Pulsar sedan \ B17 \ 2012-12~	Head lamp levelizer	x	x	x	
Pulsar sedan \ B17 \ 2012-12~	Occupant detection			x	
Pulsar sedan \ B17 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar sedan \ B17 \ 2014-2~	ABS	x	x	x	
Pulsar sedan \ B17 \ 2014-2~	Meter/M&A		x	x	
Pulsar sedan \ B17 \ 2014-2~	BCM		x		
Pulsar sedan \ B17 \ 2014-2~	Air bag		x	x	
Pulsar sedan \ B17 \ 2014-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar sedan \ B17 \ 2014-2~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Pulsar sedan \ B17 \ 2014-2~	Multi AV	x	x	x	0280
Pulsar sedan \ B17 \ 2014-2~	EPS/DAST 3	x	x	x	
Pulsar sedan \ B17 \ 2014-2~	IPDM E/R		x	x	
Pulsar sedan \ B17 \ 2014-2~	Sonar	x	x	x	
Pulsar sedan \ B17 \ 2014-2~	AVM		x	x	
Pulsar sedan \ B17 \ 2014-2~	Head lamp levelizer	x	x	x	
Pulsar sedan \ B17 \ 2014-2~	Occupant detection			x	
Pulsar sedan \ B17 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar sedan \ B17 \ 2015-6~	ABS	x	x	x	0003, 0092, 0264
Pulsar sedan \ B17 \ 2015-6~	Meter/M&A		x	x	
Pulsar sedan \ B17 \ 2015-6~	BCM		x		

Pulsar sedan \ B17 \ 2015-6~	Air bag		x	x	
Pulsar sedan \ B17 \ 2015-6~	ICC/ADAS	x	x	x	
Pulsar sedan \ B17 \ 2015-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar sedan \ B17 \ 2015-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Pulsar sedan \ B17 \ 2015-6~	Multi AV	x	x	x	0280
Pulsar sedan \ B17 \ 2015-6~	EPS/DAST 3	x	x	x	
Pulsar sedan \ B17 \ 2015-6~	IPDM E/R		x	x	
Pulsar sedan \ B17 \ 2015-6~	Sonar	x	x	x	
Pulsar sedan \ B17 \ 2015-6~	Side radar left		x	x	
Pulsar sedan \ B17 \ 2015-6~	Side radar right		x	x	
Pulsar sedan \ B17 \ 2015-6~	Telematics		x	x	0253
Pulsar sedan \ B17 \ 2015-6~	AVM		x	x	
Pulsar sedan \ B17 \ 2015-6~	Head lamp levelizer	x	x	x	
Pulsar sedan \ B17 \ 2015-6~	Occupant detection			x	
Pulsar wagon \ Y11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar wagon \ Y11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pulsar wagon \ Y11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pulsar wagon \ Y11 \ All Year	BCM	x	x		
Pulsar wagon \ Y11 \ All Year	Air bag	x	x	x	
Pulsar wagon \ Y11 \ All Year	ICC/ADAS	x	x	x	
Pulsar wagon \ Y11 \ All Year	HVAC	x	x	x	
Pulsar wagon \ Y11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar wagon \ Y11 \ All Year	Multi AV	x	x	x	0280
Pulsar wagon \ Y11 \ All Year	EPS/DAST 3	x	x	x	
Pulsar wagon \ Y11 \ All Year	IPDM E/R	x	x	x	
Pulsar wagon \ Y11 \ All Year	Air pressure monitor	x	x	x	
Pulsar wagon \ Y11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pulsar wagon \ Y11 \ All Year	DIU	x	x	x	
Pulsar wagon \ Y11 \ All Year	Auto slide door	x	x	x	
Pulsar wagon \ Y11 \ All Year	Auto drive position	x	x	x	
Pulsar wagon \ Y11 \ All Year	All mode AWD/4WD	x	x	x	
Pulsar wagon \ Y11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pulsar wagon \ Y11 \ All Year	Sonar	x	x	x	
Pulsar wagon \ Y11 \ All Year	Lane camera	x	x	x	
Pulsar wagon \ Y11 \ All Year	Adaptive light	x	x	x	
Pulsar wagon \ Y11 \ All Year	AVM		x	x	

Pulsar wagon \ Y11 \ All Year	Head lamp levelizer	x	x	x	
Pulsar wagon \ Y11 \ All Year	Difference lock	x	x	x	
Pulsar wagon \ Y11 \ All Year	Nats immu	x	x		
Pulsar wagon \ Y11 \ All Year	Smart entrance	x	x		
Pulsar wagon \ Y11 \ All Year	Air levelizer	x	x	x	
Pulsar wagon \ Y11 \ All Year	Rearview camera			x	
Pulsar wagon \ Y11 \ All Year	S/blind camera			x	
Pulsar wagon \ Y11 \ All Year	Motor assist	x	x	x	
Pulsar \ C12 \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ C12 \ 2014-3~	ABS	x	x	x	
Pulsar \ C12 \ 2014-3~	Meter/M&A		x	x	
Pulsar \ C12 \ 2014-3~	BCM		x		
Pulsar \ C12 \ 2014-3~	Air bag	x	x	x	
Pulsar \ C12 \ 2014-3~	ICC/ADAS	x	x	x	
Pulsar \ C12 \ 2014-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar \ C12 \ 2014-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ C12 \ 2014-3~	Multi AV	x	x	x	0280
Pulsar \ C12 \ 2014-3~	EPS/DAST 3	x	x	x	
Pulsar \ C12 \ 2014-3~	IPDM E/R		x	x	
Pulsar \ C12 \ 2014-3~	Air pressure monitor		x	x	
Pulsar \ C12 \ 2014-3~	Laser/radar	x	x	x	
Pulsar \ C12 \ 2014-3~	Sonar	x	x	x	
Pulsar \ C12 \ 2014-3~	Side radar left		x	x	
Pulsar \ C12 \ 2014-3~	Side radar right		x	x	
Pulsar \ C12 \ 2014-3~	BSW/buzzer		x	x	
Pulsar \ C12 \ 2014-3~	AVM		x	x	
Pulsar \ C12 \ 2014-3~	Head lamp levelizer	x	x	x	
Pulsar \ C12 \ 2014-3~	Occupant detection			x	
Pulsar \ C12 \ 2016-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ C12 \ 2016-5~	ABS	x	x	x	
Pulsar \ C12 \ 2016-5~	Meter/M&A		x	x	
Pulsar \ C12 \ 2016-5~	BCM		x		
Pulsar \ C12 \ 2016-5~	Air bag	x	x	x	
Pulsar \ C12 \ 2016-5~	ICC/ADAS	x	x	x	
Pulsar \ C12 \ 2016-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Pulsar \ C12 \ 2016-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ C12 \ 2016-5~	Multi AV	x	x	x	0280

Pulsar \ C12 \ 2016-5~	EPS/DAST 3	x	x	x	
Pulsar \ C12 \ 2016-5~	IPDM E/R		x	x	
Pulsar \ C12 \ 2016-5~	Air pressure monitor		x	x	
Pulsar \ C12 \ 2016-5~	Laser/radar	x	x	x	
Pulsar \ C12 \ 2016-5~	Sonar	x	x	x	
Pulsar \ C12 \ 2016-5~	Side radar left		x	x	
Pulsar \ C12 \ 2016-5~	Side radar right		x	x	
Pulsar \ C12 \ 2016-5~	BSW/buzzer		x	x	
Pulsar \ C12 \ 2016-5~	AVM		x	x	
Pulsar \ C12 \ 2016-5~	Head lamp levelizer	x	x	x	
Pulsar \ C12 \ 2016-5~	Occupant detection			x	
Pulsar \ C13 \ 2014-7~	Engine	x	x	x	0107, 0145, 0147, 0148, 0021, 0103, 0104, 0016, 0018, 0017, 0012, 0014, 0013, 0216, 0319, 0148, 0212, 0152, 0005, 0278, 0176, 0233, 0234, 0026, 0185, 0023, 0022, 0225, 0282, 0283, 0281, 0069, 0220, 0124, 0266, 0166, 0333, 0332, 0112, 0209, 0164, 0162, 0007, 0262, 0006, 0306, 0004, 0009, 0008, 0205, 0097
Pulsar \ C13 \ 2014-7~	ABS	x	x	x	
Pulsar \ C13 \ 2014-7~	Meter/M&A		x	x	
Pulsar \ C13 \ 2014-7~	BCM		x		
Pulsar \ C13 \ 2014-7~	Air bag	x	x	x	
Pulsar \ C13 \ 2014-7~	HVAC		x	x	
Pulsar \ C13 \ 2014-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ C13 \ 2014-7~	Multi AV		x	x	
Pulsar \ C13 \ 2014-7~	EPS/DAST 3		x	x	
Pulsar \ C13 \ 2014-7~	IPDM E/R		x	x	
Pulsar \ C13 \ 2014-7~	Air pressure monitor		x	x	
Pulsar \ C13 \ 2014-7~	Laser/radar	x	x	x	
Pulsar \ C13 \ 2014-7~	Sonar	x	x	x	
Pulsar \ C13 \ 2014-7~	CAN gateway		x	x	
Pulsar \ C13 \ 2014-7~	AVM		x	x	
Pulsar \ C13 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ C13 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ C13 \ 2016-1~	ABS	x	x	x	
Pulsar \ C13 \ 2016-1~	Meter/M&A		x	x	
Pulsar \ C13 \ 2016-1~	BCM		x		

Pulsar \ C13 \ 2016-1~	Air bag	x	x	x	
Pulsar \ C13 \ 2016-1~	ICC/ADAS	x	x	x	
Pulsar \ C13 \ 2016-1~	HVAC		x	x	
Pulsar \ C13 \ 2016-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ C13 \ 2016-1~	Multi AV	x	x	x	0280
Pulsar \ C13 \ 2016-1~	EPS/DAST 3	x	x	x	
Pulsar \ C13 \ 2016-1~	IPDM E/R		x	x	
Pulsar \ C13 \ 2016-1~	Air pressure monitor		x	x	
Pulsar \ C13 \ 2016-1~	Lane camera		x	x	
Pulsar \ C13 \ 2016-1~	Side radar left		x	x	
Pulsar \ C13 \ 2016-1~	Side radar right		x	x	
Pulsar \ C13 \ 2016-1~	AVM		x	x	
Pulsar \ N15 \ 1995-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ N15 \ 1995-1~	ABS	x	x	x	0003, 0092, 0264
Pulsar \ N15 \ 1995-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pulsar \ N15 \ 1995-1~	BCM	x	x		
Pulsar \ N15 \ 1995-1~	Air bag	x	x	x	
Pulsar \ N15 \ 1995-1~	ICC/ADAS	x	x	x	
Pulsar \ N15 \ 1995-1~	HVAC	x	x	x	
Pulsar \ N15 \ 1995-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ N15 \ 1995-1~	Multi AV	x	x	x	0280
Pulsar \ N15 \ 1995-1~	EPS/DAST 3	x	x	x	
Pulsar \ N15 \ 1995-1~	IPDM E/R	x	x	x	
Pulsar \ N15 \ 1995-1~	Air pressure monitor	x	x	x	
Pulsar \ N15 \ 1995-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pulsar \ N15 \ 1995-1~	DIU	x	x	x	
Pulsar \ N15 \ 1995-1~	Auto slide door	x	x	x	
Pulsar \ N15 \ 1995-1~	Auto drive position	x	x	x	
Pulsar \ N15 \ 1995-1~	All mode AWD/4WD	x	x	x	
Pulsar \ N15 \ 1995-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pulsar \ N15 \ 1995-1~	Sonar	x	x	x	
Pulsar \ N15 \ 1995-1~	Lane camera	x	x	x	
Pulsar \ N15 \ 1995-1~	Adaptive light	x	x	x	
Pulsar \ N15 \ 1995-1~	AVM		x	x	
Pulsar \ N15 \ 1995-1~	Head lamp levelizer	x	x	x	
Pulsar \ N15 \ 1995-1~	Difference lock	x	x	x	
Pulsar \ N15 \ 1995-1~	Nats immu	x	x		
Pulsar \ N15 \ 1995-1~	Smart entrance	x	x		

Pulsar \ N15 \ 1995-1~	Air levelizer	x	x	x	
Pulsar \ N15 \ 1995-1~	Rearview camera			x	
Pulsar \ N15 \ 1995-1~	S/blind camera			x	
Pulsar \ N15 \ 1995-1~	Motor assist	x	x	x	
Pulsar \ N15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ N15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Pulsar \ N15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Pulsar \ N15 \ All Year	BCM	x	x		
Pulsar \ N15 \ All Year	Air bag	x	x	x	
Pulsar \ N15 \ All Year	ICC/ADAS	x	x	x	
Pulsar \ N15 \ All Year	HVAC	x	x	x	
Pulsar \ N15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ N15 \ All Year	Multi AV	x	x	x	0280
Pulsar \ N15 \ All Year	EPS/DAST 3	x	x	x	
Pulsar \ N15 \ All Year	IPDM E/R	x	x	x	
Pulsar \ N15 \ All Year	Air pressure monitor	x	x	x	
Pulsar \ N15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pulsar \ N15 \ All Year	DIU	x	x	x	
Pulsar \ N15 \ All Year	Auto slide door	x	x	x	
Pulsar \ N15 \ All Year	Auto drive position	x	x	x	
Pulsar \ N15 \ All Year	All mode AWD/4WD	x	x	x	
Pulsar \ N15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pulsar \ N15 \ All Year	Sonar	x	x	x	
Pulsar \ N15 \ All Year	Lane camera	x	x	x	
Pulsar \ N15 \ All Year	Adaptive light	x	x	x	
Pulsar \ N15 \ All Year	AVM		x	x	
Pulsar \ N15 \ All Year	Head lamp levelizer	x	x	x	
Pulsar \ N15 \ All Year	Difference lock	x	x	x	
Pulsar \ N15 \ All Year	Nats immu	x	x		
Pulsar \ N15 \ All Year	Smart entrance	x	x		
Pulsar \ N15 \ All Year	Air levelizer	x	x	x	
Pulsar \ N15 \ All Year	Rearview camera			x	
Pulsar \ N15 \ All Year	S/blind camera			x	
Pulsar \ N15 \ All Year	Motor assist	x	x	x	
Pulsar \ N16 \ 2000-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Pulsar \ N16 \ 2000-1~	ABS	x	x	x	0003, 0092, 0264
Pulsar \ N16 \ 2000-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Pulsar \ N16 \ 2000-1~	BCM	x	x		
Pulsar \ N16 \ 2000-1~	Air bag	x	x	x	
Pulsar \ N16 \ 2000-1~	ICC/ADAS	x	x	x	
Pulsar \ N16 \ 2000-1~	HVAC	x	x	x	
Pulsar \ N16 \ 2000-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Pulsar \ N16 \ 2000-1~	Multi AV	x	x	x	0280
Pulsar \ N16 \ 2000-1~	EPS/DAST 3	x	x	x	
Pulsar \ N16 \ 2000-1~	IPDM E/R	x	x	x	
Pulsar \ N16 \ 2000-1~	Air pressure monitor	x	x	x	
Pulsar \ N16 \ 2000-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Pulsar \ N16 \ 2000-1~	DIU	x	x	x	
Pulsar \ N16 \ 2000-1~	Auto slide door	x	x	x	
Pulsar \ N16 \ 2000-1~	Auto drive position	x	x	x	
Pulsar \ N16 \ 2000-1~	All mode AWD/4WD	x	x	x	
Pulsar \ N16 \ 2000-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Pulsar \ N16 \ 2000-1~	Sonar	x	x	x	
Pulsar \ N16 \ 2000-1~	Lane camera	x	x	x	
Pulsar \ N16 \ 2000-1~	Adaptive light	x	x	x	
Pulsar \ N16 \ 2000-1~	AVM		x	x	
Pulsar \ N16 \ 2000-1~	Head lamp levelizer	x	x	x	
Pulsar \ N16 \ 2000-1~	Difference lock	x	x	x	
Pulsar \ N16 \ 2000-1~	Nats immu	x	x		
Pulsar \ N16 \ 2000-1~	Smart entrance	x	x		
Pulsar \ N16 \ 2000-1~	Air levelizer	x	x	x	
Pulsar \ N16 \ 2000-1~	Rearview camera			x	
Pulsar \ N16 \ 2000-1~	S/blind camera			x	
Pulsar \ N16 \ 2000-1~	Motor assist	x	x	x	
Qashqai \ J10 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2006-12~	BCM	x	x		
Qashqai \ J10 \ 2006-12~	Transmission	x	x	x	
Qashqai \ J10 \ 2006-12~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2006-12~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2006-12~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2006-12~	All mode AWD/4WD	x	x	x	0245, 0311

Qashqai \ J10 \ 2006-12~	ABS	x	x	x	
Qashqai \ J10 \ 2006-12~	Air bag	x	x	x	
Qashqai \ J10 \ 2006-12~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2006-12~	Rearview camera			x	
Qashqai \ J10 \ 2006-12~	S/blind camera			x	
Qashqai \ J10 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2007-6~	BCM	x	x		
Qashqai \ J10 \ 2007-6~	Transmission	x	x	x	
Qashqai \ J10 \ 2007-6~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2007-6~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2007-6~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2007-6~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2007-6~	ABS	x	x	x	
Qashqai \ J10 \ 2007-6~	Air bag	x	x	x	
Qashqai \ J10 \ 2007-6~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2007-6~	Rearview camera			x	
Qashqai \ J10 \ 2007-6~	S/blind camera			x	
Qashqai \ J10 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2008-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2008-12~	BCM	x	x		
Qashqai \ J10 \ 2008-12~	Transmission	x	x	x	
Qashqai \ J10 \ 2008-12~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2008-12~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2008-12~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2008-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2008-12~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2008-12~	ABS	x	x	x	
Qashqai \ J10 \ 2008-12~	Air bag	x	x	x	
Qashqai \ J10 \ 2008-12~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2008-12~	Rearview camera			x	
Qashqai \ J10 \ 2008-12~	S/blind camera			x	
Qashqai \ J10 \ 2008-2~	Engine	x	x	x	
Qashqai \ J10 \ 2008-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Qashqai \ J10 \ 2008-2~	BCM	x	x		
Qashqai \ J10 \ 2008-2~	Transmission	x	x	x	
Qashqai \ J10 \ 2008-2~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2008-2~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2008-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2008-2~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2008-2~	ABS	x	x	x	
Qashqai \ J10 \ 2008-2~	Air bag	x	x	x	
Qashqai \ J10 \ 2008-2~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2008-2~	Sonar	x	x	x	
Qashqai \ J10 \ 2008-2~	Rearview camera			x	
Qashqai \ J10 \ 2008-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2008-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2008-5~	BCM	x	x		
Qashqai \ J10 \ 2008-5~	Transmission	x	x	x	
Qashqai \ J10 \ 2008-5~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2008-5~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2008-5~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2008-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2008-5~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2008-5~	ABS	x	x	x	
Qashqai \ J10 \ 2008-5~	Air bag	x	x	x	
Qashqai \ J10 \ 2008-5~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2008-5~	Rearview camera			x	
Qashqai \ J10 \ 2008-5~	S/blind camera			x	
Qashqai \ J10 \ 2008-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2008-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2008-7~	BCM	x	x		
Qashqai \ J10 \ 2008-7~	Transmission	x	x	x	
Qashqai \ J10 \ 2008-7~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2008-7~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2008-7~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2008-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Qashqai \ J10 \ 2008-7~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2008-7~	ABS	x	x	x	
Qashqai \ J10 \ 2008-7~	Air bag	x	x	x	
Qashqai \ J10 \ 2008-7~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2008-7~	Rearview camera			x	
Qashqai \ J10 \ 2008-7~	S/blind camera			x	
Qashqai \ J10 \ 2009-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2009-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2009-4~	BCM	x	x		
Qashqai \ J10 \ 2009-4~	Transmission	x	x	x	
Qashqai \ J10 \ 2009-4~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2009-4~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2009-4~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2009-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2009-4~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2009-4~	ABS	x	x	x	
Qashqai \ J10 \ 2009-4~	Air bag	x	x	x	
Qashqai \ J10 \ 2009-4~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2009-4~	Rearview camera			x	
Qashqai \ J10 \ 2009-4~	S/blind camera			x	
Qashqai \ J10 \ 2009-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2009-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2009-5~	BCM	x	x		
Qashqai \ J10 \ 2009-5~	Transmission	x	x	x	
Qashqai \ J10 \ 2009-5~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2009-5~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2009-5~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2009-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2009-5~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2009-5~	ABS	x	x	x	
Qashqai \ J10 \ 2009-5~	Air bag	x	x	x	
Qashqai \ J10 \ 2009-5~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2009-5~	Rearview camera			x	
Qashqai \ J10 \ 2009-5~	S/blind camera			x	

Qashqai \ J10 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2009-8~	BCM	x	x		
Qashqai \ J10 \ 2009-8~	Transmission	x	x	x	
Qashqai \ J10 \ 2009-8~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2009-8~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2009-8~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2009-8~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2009-8~	ABS	x	x	x	
Qashqai \ J10 \ 2009-8~	Air bag	x	x	x	
Qashqai \ J10 \ 2009-8~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2009-8~	Rearview camera			x	
Qashqai \ J10 \ 2009-8~	S/blind camera			x	
Qashqai \ J10 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2009-9~	BCM	x	x		
Qashqai \ J10 \ 2009-9~	Transmission	x	x	x	
Qashqai \ J10 \ 2009-9~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2009-9~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2009-9~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2009-9~	ABS	x	x	x	
Qashqai \ J10 \ 2009-9~	Air bag	x	x	x	
Qashqai \ J10 \ 2009-9~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2009-9~	Sonar	x	x	x	
Qashqai \ J10 \ 2009-9~	Rearview camera			x	
Qashqai \ J10 \ 2010-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2010-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2010-10~	BCM	x	x		
Qashqai \ J10 \ 2010-10~	Transmission	x	x	x	
Qashqai \ J10 \ 2010-10~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2010-10~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2010-10~	IPDM E/R	x	x	x	

Qashqai \ J10 \ 2010-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2010-10~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2010-10~	ABS	x	x	x	
Qashqai \ J10 \ 2010-10~	Air bag	x	x	x	
Qashqai \ J10 \ 2010-10~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2010-10~	Rearview camera			x	
Qashqai \ J10 \ 2010-10~	S/blind camera			x	
Qashqai \ J10 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2010-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2010-11~	BCM	x	x		
Qashqai \ J10 \ 2010-11~	Transmission	x	x	x	
Qashqai \ J10 \ 2010-11~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2010-11~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2010-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2010-11~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2010-11~	Telematics		x	x	0253
Qashqai \ J10 \ 2010-11~	AVM		x	x	
Qashqai \ J10 \ 2010-11~	ABS	x	x	x	
Qashqai \ J10 \ 2010-11~	Air bag	x	x	x	
Qashqai \ J10 \ 2010-11~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2010-11~	Sonar	x	x	x	
Qashqai \ J10 \ 2010-11~	Rearview camera			x	
Qashqai \ J10 \ 2010-11~	S/blind camera			x	
Qashqai \ J10 \ 2010-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2010-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2010-1~	BCM	x	x		
Qashqai \ J10 \ 2010-1~	Transmission	x	x	x	
Qashqai \ J10 \ 2010-1~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2010-1~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2010-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2010-1~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2010-1~	ABS	x	x	x	
Qashqai \ J10 \ 2010-1~	Air bag	x	x	x	

Qashqai \ J10 \ 2010-1~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2010-1~	Sonar	x	x	x	
Qashqai \ J10 \ 2010-1~	Rearview camera			x	
Qashqai \ J10 \ 2010-1~	S/blind camera			x	
Qashqai \ J10 \ 2010-1~	Multi AV		x	x	
Qashqai \ J10 \ 2010-1~	EMCM	x	x	x	
Qashqai \ J10 \ 2010-1~	AVM		x	x	
Qashqai \ J10 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2010-2~	BCM	x	x		
Qashqai \ J10 \ 2010-2~	Transmission	x	x	x	
Qashqai \ J10 \ 2010-2~	Multi AV	x	x	x	0280
Qashqai \ J10 \ 2010-2~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2010-2~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2010-2~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2010-2~	EMCM	x	x	x	
Qashqai \ J10 \ 2010-2~	ABS	x	x	x	
Qashqai \ J10 \ 2010-2~	Air bag	x	x	x	
Qashqai \ J10 \ 2010-2~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2010-2~	Rearview camera			x	
Qashqai \ J10 \ 2010-2~	S/blind camera			x	
Qashqai \ J10 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2011-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2011-10~	BCM	x	x		
Qashqai \ J10 \ 2011-10~	Transmission	x	x	x	
Qashqai \ J10 \ 2011-10~	Multi AV		x	x	
Qashqai \ J10 \ 2011-10~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2011-10~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2011-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2011-10~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2011-10~	EMCM	x	x	x	
Qashqai \ J10 \ 2011-10~	AVM		x	x	
Qashqai \ J10 \ 2011-10~	ABS	x	x	x	
Qashqai \ J10 \ 2011-10~	Air bag	x	x	x	

Qashqai \ J10 \ 2011-10~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2011-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2011-9~	BCM	x	x		
Qashqai \ J10 \ 2011-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Qashqai \ J10 \ 2011-9~	Multi AV		x	x	
Qashqai \ J10 \ 2011-9~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2011-9~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2011-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2011-9~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2011-9~	EMCM	x	x	x	
Qashqai \ J10 \ 2011-9~	AVM		x	x	
Qashqai \ J10 \ 2011-9~	ABS	x	x	x	
Qashqai \ J10 \ 2011-9~	Air bag	x	x	x	
Qashqai \ J10 \ 2011-9~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2011-9~	Rearview camera			x	
Qashqai \ J10 \ 2011-9~	S/blind camera			x	
Qashqai \ J10 \ 2012-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J10 \ 2012-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai \ J10 \ 2012-2~	BCM	x	x		
Qashqai \ J10 \ 2012-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Qashqai \ J10 \ 2012-2~	Multi AV		x	x	
Qashqai \ J10 \ 2012-2~	EPS/DAST 3	x	x	x	
Qashqai \ J10 \ 2012-2~	IPDM E/R	x	x	x	
Qashqai \ J10 \ 2012-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai \ J10 \ 2012-2~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai \ J10 \ 2012-2~	EMCM	x	x	x	
Qashqai \ J10 \ 2012-2~	AVM		x	x	
Qashqai \ J10 \ 2012-2~	ABS	x	x	x	
Qashqai \ J10 \ 2012-2~	Air bag	x	x	x	
Qashqai \ J10 \ 2012-2~	Head lamp levelizer	x	x	x	
Qashqai \ J10 \ 2012-2~	Rearview camera			x	
Qashqai \ J10 \ 2012-2~	S/blind camera			x	
Qashqai \ J11 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Qashqai \ J11 \ 2013-12~	ABS		x	x	
Qashqai \ J11 \ 2013-12~	Meter/M&A		x	x	
Qashqai \ J11 \ 2013-12~	BCM		x		
Qashqai \ J11 \ 2013-12~	Air bag		x	x	
Qashqai \ J11 \ 2013-12~	ICC/ADAS	x	x	x	
Qashqai \ J11 \ 2013-12~	HVAC		x	x	
Qashqai \ J11 \ 2013-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Qashqai \ J11 \ 2013-12~	Multi AV	x	x	x	0280
Qashqai \ J11 \ 2013-12~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Qashqai \ J11 \ 2013-12~	EPS/DAST 3		x	x	
Qashqai \ J11 \ 2013-12~	IPDM E/R		x	x	
Qashqai \ J11 \ 2013-12~	Air pressure monitor		x	x	
Qashqai \ J11 \ 2013-12~	Laser/radar	x	x	x	
Qashqai \ J11 \ 2013-12~	All mode AWD/4WD		x	x	
Qashqai \ J11 \ 2013-12~	Sonar	x	x	x	
Qashqai \ J11 \ 2013-12~	Lane camera	x	x	x	
Qashqai \ J11 \ 2013-12~	CAN gateway		x	x	
Qashqai \ J11 \ 2013-12~	Auto back door		x	x	
Qashqai \ J11 \ 2013-12~	Side radar left		x	x	
Qashqai \ J11 \ 2013-12~	Side radar right		x	x	
Qashqai \ J11 \ 2013-12~	PTC heater		x	x	
Qashqai \ J11 \ 2013-12~	Telematics		x	x	0253
Qashqai \ J11 \ 2013-12~	AVM		x	x	
Qashqai \ J11 \ 2013-12~	Chassis control		x	x	
Qashqai \ J11 \ 2013-12~	Occupant detection			x	
Qashqai \ J11 \ 2013-12~	Laser/radar		x	x	
Qashqai \ J11 \ 2013-12~	Sonar		x	x	
Qashqai \ J11 \ 2013-12~	Lane camera		x	x	
Qashqai \ J11 \ 2013-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Qashqai \ J11 \ 2013-12~	Multi AV		x	x	
Qashqai \ J11 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J11 \ 2014-1~	ABS		x	x	
Qashqai \ J11 \ 2014-1~	Meter/M&A		x	x	
Qashqai \ J11 \ 2014-1~	BCM		x		
Qashqai \ J11 \ 2014-1~	Air bag		x	x	
Qashqai \ J11 \ 2014-1~	HVAC		x	x	

Qashqai \ J11 \ 2014-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Qashqai \ J11 \ 2014-1~	Multi AV		x	x	
Qashqai \ J11 \ 2014-1~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Qashqai \ J11 \ 2014-1~	EPS/DAST 3		x	x	
Qashqai \ J11 \ 2014-1~	IPDM E/R		x	x	
Qashqai \ J11 \ 2014-1~	Air pressure monitor		x	x	
Qashqai \ J11 \ 2014-1~	Laser/radar	x	x	x	
Qashqai \ J11 \ 2014-1~	All mode AWD/4WD		x	x	
Qashqai \ J11 \ 2014-1~	Sonar	x	x	x	
Qashqai \ J11 \ 2014-1~	Lane camera	x	x	x	
Qashqai \ J11 \ 2014-1~	CAN gateway		x	x	
Qashqai \ J11 \ 2014-1~	Telematics		x	x	0253
Qashqai \ J11 \ 2014-1~	AVM		x	x	
Qashqai \ J11 \ 2014-1~	Chassis control		x	x	
Qashqai \ J11 \ 2014-1~	Occupant detection			x	
Qashqai \ J11 \ 2014-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J11 \ 2014-3~	ABS		x	x	
Qashqai \ J11 \ 2014-3~	Meter/M&A		x	x	
Qashqai \ J11 \ 2014-3~	BCM		x		
Qashqai \ J11 \ 2014-3~	Air bag		x	x	
Qashqai \ J11 \ 2014-3~	ICC/ADAS	x	x	x	
Qashqai \ J11 \ 2014-3~	HVAC		x	x	
Qashqai \ J11 \ 2014-3~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Qashqai \ J11 \ 2014-3~	Multi AV	x	x	x	0280
Qashqai \ J11 \ 2014-3~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Qashqai \ J11 \ 2014-3~	EPS/DAST 3		x	x	
Qashqai \ J11 \ 2014-3~	IPDM E/R		x	x	
Qashqai \ J11 \ 2014-3~	Air pressure monitor		x	x	
Qashqai \ J11 \ 2014-3~	Laser/radar	x	x	x	
Qashqai \ J11 \ 2014-3~	All mode AWD/4WD		x	x	
Qashqai \ J11 \ 2014-3~	Sonar	x	x	x	
Qashqai \ J11 \ 2014-3~	Lane camera	x	x	x	
Qashqai \ J11 \ 2014-3~	CAN gateway		x	x	
Qashqai \ J11 \ 2014-3~	Auto back door		x	x	
Qashqai \ J11 \ 2014-3~	Side radar left		x	x	
Qashqai \ J11 \ 2014-3~	Side radar right		x	x	

Qashqai \ J11 \ 2014-3~	PTC heater		x	x	
Qashqai \ J11 \ 2014-3~	Telematics		x	x	0253
Qashqai \ J11 \ 2014-3~	AVM		x	x	
Qashqai \ J11 \ 2014-3~	Chassis control		x	x	
Qashqai \ J11 \ 2014-3~	Occupant detection			x	
Qashqai \ J11 \ 2014-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Qashqai \ J11 \ 2014-3~	Multi AV		x	x	
Qashqai \ J11 \ 2015-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J11 \ 2015-9~	ABS		x	x	
Qashqai \ J11 \ 2015-9~	Meter/M&A		x	x	
Qashqai \ J11 \ 2015-9~	BCM		x		
Qashqai \ J11 \ 2015-9~	Air bag		x	x	
Qashqai \ J11 \ 2015-9~	ICC/ADAS	x	x	x	
Qashqai \ J11 \ 2015-9~	HVAC		x	x	
Qashqai \ J11 \ 2015-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Qashqai \ J11 \ 2015-9~	Multi AV	x	x	x	0280
Qashqai \ J11 \ 2015-9~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Qashqai \ J11 \ 2015-9~	EPS/DAST 3		x	x	
Qashqai \ J11 \ 2015-9~	IPDM E/R		x	x	
Qashqai \ J11 \ 2015-9~	Air pressure monitor	x	x	x	
Qashqai \ J11 \ 2015-9~	Laser/radar	x	x	x	
Qashqai \ J11 \ 2015-9~	All mode AWD/4WD		x	x	
Qashqai \ J11 \ 2015-9~	Sonar		x	x	
Qashqai \ J11 \ 2015-9~	Lane camera		x	x	
Qashqai \ J11 \ 2015-9~	CAN gateway		x	x	
Qashqai \ J11 \ 2015-9~	Auto back door		x	x	
Qashqai \ J11 \ 2015-9~	Side radar left		x	x	
Qashqai \ J11 \ 2015-9~	Side radar right		x	x	
Qashqai \ J11 \ 2015-9~	PTC heater		x	x	
Qashqai \ J11 \ 2015-9~	Telematics		x	x	0253
Qashqai \ J11 \ 2015-9~	AVM		x	x	
Qashqai \ J11 \ 2015-9~	Chassis control		x	x	
Qashqai \ J11 \ 2015-9~	Occupant detection			x	
Qashqai \ J11 \ 2016-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai \ J11 \ 2016-9~	ABS		x	x	
Qashqai \ J11 \ 2016-9~	Meter/M&A		x	x	

Qashqai \ J11 \ 2016-9~	BCM		x		
Qashqai \ J11 \ 2016-9~	Air bag		x	x	
Qashqai \ J11 \ 2016-9~	ICC/ADAS	x	x	x	
Qashqai \ J11 \ 2016-9~	HVAC		x	x	
Qashqai \ J11 \ 2016-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Qashqai \ J11 \ 2016-9~	Multi AV	x	x	x	0280
Qashqai \ J11 \ 2016-9~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Qashqai \ J11 \ 2016-9~	EPS/DAST 3		x	x	
Qashqai \ J11 \ 2016-9~	IPDM E/R		x	x	
Qashqai \ J11 \ 2016-9~	Air pressure monitor		x	x	
Qashqai \ J11 \ 2016-9~	Auto drive position		x	x	
Qashqai \ J11 \ 2016-9~	All mode AWD/4WD		x	x	
Qashqai \ J11 \ 2016-9~	Sonar		x	x	
Qashqai \ J11 \ 2016-9~	CAN gateway		x	x	
Qashqai \ J11 \ 2016-9~	Side radar left		x	x	
Qashqai \ J11 \ 2016-9~	Side radar right		x	x	
Qashqai \ J11 \ 2016-9~	PTC heater		x	x	
Qashqai \ J11 \ 2016-9~	Chassis control		x	x	
Qashqai \ J11 \ 2016-9~	FSCM		x	x	
Qashqai \ J11 \ 2016-9~	Occupant detection			x	
Qashqai+2 \ J10 \ 2008-8~	Engine	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai+2 \ J10 \ 2008-8~	BCM	x	x		
Qashqai+2 \ J10 \ 2008-8~	Transmission	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Multi AV	x	x	x	0280
Qashqai+2 \ J10 \ 2008-8~	EPS/DAST 3	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	IPDM E/R	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai+2 \ J10 \ 2008-8~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai+2 \ J10 \ 2008-8~	ABS	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Air bag	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Head lamp levelizer	x	x	x	
Qashqai+2 \ J10 \ 2008-8~	Rearview camera			x	
Qashqai+2 \ J10 \ 2008-8~	S/blind camera			x	
Qashqai+2 \ J10 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai+2 \ J10 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Qashqai+2 \ J10 \ 2010-2~	BCM	x	x		
Qashqai+2 \ J10 \ 2010-2~	Transmission	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	Multi AV	x	x	x	0280
Qashqai+2 \ J10 \ 2010-2~	EPS/DAST 3	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	IPDM E/R	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai+2 \ J10 \ 2010-2~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai+2 \ J10 \ 2010-2~	EMCM	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	ABS	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	Air bag	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	Head lamp levelizer	x	x	x	
Qashqai+2 \ J10 \ 2010-2~	Rearview camera			x	
Qashqai+2 \ J10 \ 2010-2~	S/blind camera			x	
Qashqai+2 \ J10 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai+2 \ J10 \ 2011-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai+2 \ J10 \ 2011-9~	BCM	x	x		
Qashqai+2 \ J10 \ 2011-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Qashqai+2 \ J10 \ 2011-9~	Multi AV		x	x	
Qashqai+2 \ J10 \ 2011-9~	EPS/DAST 3	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	IPDM E/R	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai+2 \ J10 \ 2011-9~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai+2 \ J10 \ 2011-9~	EMCM	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	AVM		x	x	
Qashqai+2 \ J10 \ 2011-9~	ABS	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	Air bag	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	Head lamp levelizer	x	x	x	
Qashqai+2 \ J10 \ 2011-9~	Rearview camera			x	
Qashqai+2 \ J10 \ 2011-9~	S/blind camera			x	
Qashqai+2 \ J10 \ 2012-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Qashqai+2 \ J10 \ 2012-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Qashqai+2 \ J10 \ 2012-2~	BCM	x	x		
Qashqai+2 \ J10 \ 2012-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Qashqai+2 \ J10 \ 2012-2~	Multi AV		x	x	
Qashqai+2 \ J10 \ 2012-2~	EPS/DAST 3	x	x	x	

Qashqai+2 \ J10 \ 2012-2~	IPDM E/R	x	x	x	
Qashqai+2 \ J10 \ 2012-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Qashqai+2 \ J10 \ 2012-2~	All mode AWD/4WD	x	x	x	0245, 0311
Qashqai+2 \ J10 \ 2012-2~	EMCM	x	x	x	
Qashqai+2 \ J10 \ 2012-2~	AVM		x	x	
Qashqai+2 \ J10 \ 2012-2~	ABS	x	x	x	
Qashqai+2 \ J10 \ 2012-2~	Air bag	x	x	x	
Qashqai+2 \ J10 \ 2012-2~	Head lamp levelizer	x	x	x	
Qashqai+2 \ J10 \ 2012-2~	Rearview camera			x	
Qashqai+2 \ J10 \ 2012-2~	S/blind camera			x	
Quest \ E52 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2011	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2011	Meter/M&A		x	x	
Quest \ E52 \ 2011	BCM		x		
Quest \ E52 \ 2011	Air bag	x	x	x	
Quest \ E52 \ 2011	HVAC		x	x	
Quest \ E52 \ 2011	Transmission	x	x	x	
Quest \ E52 \ 2011	Multi AV		x	x	
Quest \ E52 \ 2011	EPS/DAST 3		x	x	
Quest \ E52 \ 2011	IPDM E/R		x	x	
Quest \ E52 \ 2011	Auto slide door		x	x	
Quest \ E52 \ 2011	Auto drive position		x	x	
Quest \ E52 \ 2011	All mode AWD/4WD		x	x	
Quest \ E52 \ 2011	Auto slide door right		x	x	
Quest \ E52 \ 2011	CAN gateway		x		
Quest \ E52 \ 2011	Auto back door		x	x	
Quest \ E52 \ 2011	Side radar left		x	x	
Quest \ E52 \ 2011	Side radar right		x	x	
Quest \ E52 \ 2011	BSW/buzzer		x	x	
Quest \ E52 \ 2011	Occupant detection			x	
Quest \ E52 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2011-9~	Meter/M&A		x	x	
Quest \ E52 \ 2011-9~	BCM		x		
Quest \ E52 \ 2011-9~	Air bag	x	x	x	
Quest \ E52 \ 2011-9~	HVAC		x	x	
Quest \ E52 \ 2011-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

Quest \ E52 \ 2011-9~	Multi AV		x	x	
Quest \ E52 \ 2011-9~	EPS/DAST 3		x	x	
Quest \ E52 \ 2011-9~	CAN gateway		x		
Quest \ E52 \ 2011-9~	Side radar left		x	x	
Quest \ E52 \ 2011-9~	Side radar right		x	x	
Quest \ E52 \ 2011-9~	Occupant detection			x	
Quest \ E52 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2012	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2012	Meter/M&A		x	x	
Quest \ E52 \ 2012	BCM		x		
Quest \ E52 \ 2012	Air bag	x	x	x	
Quest \ E52 \ 2012	HVAC		x	x	
Quest \ E52 \ 2012	Transmission	x	x	x	
Quest \ E52 \ 2012	Multi AV		x	x	
Quest \ E52 \ 2012	EPS/DAST 3		x	x	
Quest \ E52 \ 2012	IPDM E/R		x	x	
Quest \ E52 \ 2012	Auto slide door		x	x	
Quest \ E52 \ 2012	Auto drive position		x	x	
Quest \ E52 \ 2012	Adaptive light	x	x	x	
Quest \ E52 \ 2012	Auto slide door right		x	x	
Quest \ E52 \ 2012	CAN gateway		x		
Quest \ E52 \ 2012	Auto back door		x	x	
Quest \ E52 \ 2012	Side radar left		x	x	
Quest \ E52 \ 2012	Side radar right		x	x	
Quest \ E52 \ 2012	BSW/buzzer		x	x	
Quest \ E52 \ 2012	AVM		x	x	
Quest \ E52 \ 2012	Sonar	x	x	x	
Quest \ E52 \ 2012	Occupant detection			x	
Quest \ E52 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2012-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ E52 \ 2012-8~	BCM		x		
Quest \ E52 \ 2012-8~	Air bag	x	x	x	
Quest \ E52 \ 2012-8~	HVAC		x	x	
Quest \ E52 \ 2012-8~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Quest \ E52 \ 2012-8~	Multi AV		x	x	
Quest \ E52 \ 2012-8~	EPS/DAST 3		x	x	
Quest \ E52 \ 2012-8~	IPDM E/R		x	x	

Quest \ E52 \ 2012-8~	Auto slide door		x	x	
Quest \ E52 \ 2012-8~	Auto drive position		x	x	
Quest \ E52 \ 2012-8~	Adaptive light	x	x	x	
Quest \ E52 \ 2012-8~	Auto slide door right		x	x	
Quest \ E52 \ 2012-8~	Auto back door		x	x	
Quest \ E52 \ 2012-8~	Telematics		x	x	0253
Quest \ E52 \ 2012-8~	Head lamp levelizer	x	x	x	
Quest \ E52 \ 2012-8~	Occupant detection			x	
Quest \ E52 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2013	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2013	Meter/M&A		x	x	
Quest \ E52 \ 2013	BCM		x		
Quest \ E52 \ 2013	Air bag	x	x	x	
Quest \ E52 \ 2013	HVAC		x	x	
Quest \ E52 \ 2013	Transmission	x	x	x	
Quest \ E52 \ 2013	Multi AV		x	x	
Quest \ E52 \ 2013	EPS/DAST 3		x	x	
Quest \ E52 \ 2013	IPDM E/R		x	x	
Quest \ E52 \ 2013	Auto slide door		x	x	
Quest \ E52 \ 2013	Auto drive position		x	x	
Quest \ E52 \ 2013	Adaptive light	x	x	x	
Quest \ E52 \ 2013	Auto slide door right		x	x	
Quest \ E52 \ 2013	CAN gateway		x		
Quest \ E52 \ 2013	Auto back door		x	x	
Quest \ E52 \ 2013	Side radar left		x	x	
Quest \ E52 \ 2013	Side radar right		x	x	
Quest \ E52 \ 2013	BSW/buzzer		x	x	
Quest \ E52 \ 2013	AVM		x	x	
Quest \ E52 \ 2013	Sonar	x	x	x	
Quest \ E52 \ 2013	Occupant detection			x	
Quest \ E52 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2014	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ E52 \ 2014	BCM		x		
Quest \ E52 \ 2014	Air bag	x	x	x	
Quest \ E52 \ 2014	HVAC		x	x	
Quest \ E52 \ 2014	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Quest \ E52 \ 2014	Multi AV		x	x	

Quest \ E52 \ 2014	EPS/DAST 3		x	x	
Quest \ E52 \ 2014	IPDM E/R		x	x	
Quest \ E52 \ 2014	Auto slide door		x	x	
Quest \ E52 \ 2014	Auto drive position		x	x	
Quest \ E52 \ 2014	Adaptive light	x	x	x	
Quest \ E52 \ 2014	Auto slide door right		x	x	
Quest \ E52 \ 2014	Auto back door		x	x	
Quest \ E52 \ 2014	Side radar left		x	x	
Quest \ E52 \ 2014	Side radar right		x	x	
Quest \ E52 \ 2014	BSW/buzzer		x	x	
Quest \ E52 \ 2014	AVM		x	x	
Quest \ E52 \ 2014	Head lamp levelizer	x	x	x	
Quest \ E52 \ 2014	Occupant detection			x	
Quest \ E52 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2014-7~	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2014-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ E52 \ 2014-7~	BCM		x		
Quest \ E52 \ 2014-7~	Air bag	x	x	x	
Quest \ E52 \ 2014-7~	ICC/ADAS		x	x	
Quest \ E52 \ 2014-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Quest \ E52 \ 2014-7~	Multi AV		x	x	
Quest \ E52 \ 2014-7~	EPS/DAST 3		x	x	
Quest \ E52 \ 2014-7~	IPDM E/R		x	x	
Quest \ E52 \ 2014-7~	Laser/radar	x	x	x	
Quest \ E52 \ 2014-7~	Auto slide door		x	x	
Quest \ E52 \ 2014-7~	Auto drive position		x	x	
Quest \ E52 \ 2014-7~	All mode AWD/4WD	x	x	x	0245, 0311
Quest \ E52 \ 2014-7~	Sonar	x	x	x	
Quest \ E52 \ 2014-7~	Adaptive light	x	x	x	
Quest \ E52 \ 2014-7~	Auto slide door right		x	x	
Quest \ E52 \ 2014-7~	CAN gateway		x	x	
Quest \ E52 \ 2014-7~	Auto back door		x	x	
Quest \ E52 \ 2014-7~	Side radar left		x	x	
Quest \ E52 \ 2014-7~	Side radar right		x	x	
Quest \ E52 \ 2014-7~	Telematics		x	x	0253
Quest \ E52 \ 2014-7~	BSW/buzzer		x	x	
Quest \ E52 \ 2014-7~	AVM		x	x	
Quest \ E52 \ 2014-7~	PMAS		x	x	
Quest \ E52 \ 2014-7~	Head lamp levelizer	x	x	x	

Quest \ E52 \ 2014-7~	Occupant detection			x	
Quest \ E52 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2015	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ E52 \ 2015	BCM		x		
Quest \ E52 \ 2015	Air bag	x	x	x	
Quest \ E52 \ 2015	ICC/ADAS		x	x	
Quest \ E52 \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Quest \ E52 \ 2015	Multi AV		x	x	
Quest \ E52 \ 2015	EPS/DAST 3		x	x	
Quest \ E52 \ 2015	IPDM E/R		x	x	
Quest \ E52 \ 2015	Laser/radar	x	x	x	
Quest \ E52 \ 2015	Auto slide door		x	x	
Quest \ E52 \ 2015	Auto drive position		x	x	
Quest \ E52 \ 2015	All mode AWD/4WD	x	x	x	0245, 0311
Quest \ E52 \ 2015	Sonar	x	x	x	
Quest \ E52 \ 2015	Adaptive light	x	x	x	
Quest \ E52 \ 2015	Auto slide door right		x	x	
Quest \ E52 \ 2015	CAN gateway		x	x	
Quest \ E52 \ 2015	Auto back door		x	x	
Quest \ E52 \ 2015	Side radar left		x	x	
Quest \ E52 \ 2015	Side radar right		x	x	
Quest \ E52 \ 2015	BSW/buzzer		x	x	
Quest \ E52 \ 2015	AVM		x	x	
Quest \ E52 \ 2015	PMAS		x	x	
Quest \ E52 \ 2015	Occupant detection			x	
Quest \ E52 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ E52 \ 2016	ABS	x	x	x	0003, 0092, 0264
Quest \ E52 \ 2016	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ E52 \ 2016	BCM		x		
Quest \ E52 \ 2016	Air bag	x	x	x	
Quest \ E52 \ 2016	HVAC		x	x	
Quest \ E52 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Quest \ E52 \ 2016	Multi AV		x	x	
Quest \ E52 \ 2016	EPS/DAST 3		x	x	
Quest \ E52 \ 2016	IPDM E/R		x	x	
Quest \ E52 \ 2016	Auto slide door		x	x	

Quest \ E52 \ 2016	Preocrash seatbelt		x	x	
Quest \ E52 \ 2016	All mode AWD/4WD		x	x	
Quest \ E52 \ 2016	Adaptive light	x	x	x	
Quest \ E52 \ 2016	Auto slide door right		x	x	
Quest \ E52 \ 2016	Auto back door		x	x	
Quest \ E52 \ 2016	Side radar left		x	x	
Quest \ E52 \ 2016	Side radar right		x	x	
Quest \ E52 \ 2016	BSW/buzzer		x	x	
Quest \ E52 \ 2016	AVM		x	x	
Quest \ E52 \ 2016	Pop up hood	x	x	x	
Quest \ E52 \ 2016	Occupant detection			x	
Quest \ V41 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V41 \ 1999	ABS	x	x	x	0003, 0092, 0264
Quest \ V41 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V41 \ 1999	BCM	x	x		
Quest \ V41 \ 1999	Air bag	x	x	x	
Quest \ V41 \ 1999	ICC/ADAS	x	x	x	
Quest \ V41 \ 1999	HVAC	x	x	x	
Quest \ V41 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V41 \ 1999	Multi AV	x	x	x	0280
Quest \ V41 \ 1999	EPS/DAST 3	x	x	x	
Quest \ V41 \ 1999	IPDM E/R	x	x	x	
Quest \ V41 \ 1999	Air pressure monitor	x	x	x	
Quest \ V41 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V41 \ 1999	DIU	x	x	x	
Quest \ V41 \ 1999	Auto slide door	x	x	x	
Quest \ V41 \ 1999	Auto drive position	x	x	x	
Quest \ V41 \ 1999	All mode AWD/4WD	x	x	x	
Quest \ V41 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V41 \ 1999	Sonar	x	x	x	
Quest \ V41 \ 1999	Lane camera	x	x	x	
Quest \ V41 \ 1999	Adaptive light	x	x	x	
Quest \ V41 \ 1999	AVM		x	x	
Quest \ V41 \ 1999	Head lamp levelizer	x	x	x	
Quest \ V41 \ 1999	Difference lock	x	x	x	
Quest \ V41 \ 1999	Nats immu	x	x		
Quest \ V41 \ 1999	Smart entrance	x	x		
Quest \ V41 \ 1999	Air levelizer	x	x	x	

Quest \ V41 \ 1999	Rearview camera			x	
Quest \ V41 \ 1999	S/blind camera			x	
Quest \ V41 \ 1999	Motor assist	x	x	x	
Quest \ V41 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V41 \ 2000	ABS	x	x	x	0003, 0092, 0264
Quest \ V41 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V41 \ 2000	BCM	x	x		
Quest \ V41 \ 2000	Air bag	x	x	x	
Quest \ V41 \ 2000	ICC/ADAS	x	x	x	
Quest \ V41 \ 2000	HVAC	x	x	x	
Quest \ V41 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V41 \ 2000	Multi AV	x	x	x	0280
Quest \ V41 \ 2000	EPS/DAST 3	x	x	x	
Quest \ V41 \ 2000	IPDM E/R	x	x	x	
Quest \ V41 \ 2000	Air pressure monitor	x	x	x	
Quest \ V41 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V41 \ 2000	DIU	x	x	x	
Quest \ V41 \ 2000	Auto slide door	x	x	x	
Quest \ V41 \ 2000	Auto drive position	x	x	x	
Quest \ V41 \ 2000	All mode AWD/4WD	x	x	x	
Quest \ V41 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V41 \ 2000	Sonar	x	x	x	
Quest \ V41 \ 2000	Lane camera	x	x	x	
Quest \ V41 \ 2000	Adaptive light	x	x	x	
Quest \ V41 \ 2000	AVM		x	x	
Quest \ V41 \ 2000	Head lamp levelizer	x	x	x	
Quest \ V41 \ 2000	Difference lock	x	x	x	
Quest \ V41 \ 2000	Nats immu	x	x		
Quest \ V41 \ 2000	Smart entrance	x	x		
Quest \ V41 \ 2000	Air levelizer	x	x	x	
Quest \ V41 \ 2000	Rearview camera			x	
Quest \ V41 \ 2000	S/blind camera			x	
Quest \ V41 \ 2000	Motor assist	x	x	x	
Quest \ V41 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V41 \ 2001	ABS	x	x	x	0003, 0092, 0264
Quest \ V41 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V41 \ 2001	BCM	x	x		

Quest \ V41 \ 2001	Air bag	x	x	x	
Quest \ V41 \ 2001	ICC/ADAS	x	x	x	
Quest \ V41 \ 2001	HVAC	x	x	x	
Quest \ V41 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V41 \ 2001	Multi AV	x	x	x	0280
Quest \ V41 \ 2001	EPS/DAST 3	x	x	x	
Quest \ V41 \ 2001	IPDM E/R	x	x	x	
Quest \ V41 \ 2001	Air pressure monitor	x	x	x	
Quest \ V41 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V41 \ 2001	DIU	x	x	x	
Quest \ V41 \ 2001	Auto slide door	x	x	x	
Quest \ V41 \ 2001	Auto drive position	x	x	x	
Quest \ V41 \ 2001	All mode AWD/4WD	x	x	x	
Quest \ V41 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V41 \ 2001	Sonar	x	x	x	
Quest \ V41 \ 2001	Lane camera	x	x	x	
Quest \ V41 \ 2001	Adaptive light	x	x	x	
Quest \ V41 \ 2001	AVM		x	x	
Quest \ V41 \ 2001	Head lamp levelizer	x	x	x	
Quest \ V41 \ 2001	Difference lock	x	x	x	
Quest \ V41 \ 2001	Nats immu	x	x		
Quest \ V41 \ 2001	Smart entrance	x	x		
Quest \ V41 \ 2001	Air levelizer	x	x	x	
Quest \ V41 \ 2001	Rearview camera			x	
Quest \ V41 \ 2001	S/blind camera			x	
Quest \ V41 \ 2001	Motor assist	x	x	x	
Quest \ V41 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V41 \ 2002	ABS	x	x	x	0003, 0092, 0264
Quest \ V41 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V41 \ 2002	BCM	x	x		
Quest \ V41 \ 2002	Air bag	x	x	x	
Quest \ V41 \ 2002	ICC/ADAS	x	x	x	
Quest \ V41 \ 2002	HVAC	x	x	x	
Quest \ V41 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V41 \ 2002	Multi AV	x	x	x	0280
Quest \ V41 \ 2002	EPS/DAST 3	x	x	x	
Quest \ V41 \ 2002	IPDM E/R	x	x	x	
Quest \ V41 \ 2002	Air pressure monitor	x	x	x	

Quest \ V41 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V41 \ 2002	DIU	x	x	x	
Quest \ V41 \ 2002	Auto slide door	x	x	x	
Quest \ V41 \ 2002	Auto drive position	x	x	x	
Quest \ V41 \ 2002	All mode AWD/4WD	x	x	x	
Quest \ V41 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V41 \ 2002	Sonar	x	x	x	
Quest \ V41 \ 2002	Lane camera	x	x	x	
Quest \ V41 \ 2002	Adaptive light	x	x	x	
Quest \ V41 \ 2002	AVM		x	x	
Quest \ V41 \ 2002	Head lamp levelizer	x	x	x	
Quest \ V41 \ 2002	Difference lock	x	x	x	
Quest \ V41 \ 2002	Nats immu	x	x		
Quest \ V41 \ 2002	Smart entrance	x	x		
Quest \ V41 \ 2002	Air levelizer	x	x	x	
Quest \ V41 \ 2002	Rearview camera			x	
Quest \ V41 \ 2002	S/blind camera			x	
Quest \ V41 \ 2002	Motor assist	x	x	x	
Quest \ V41 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V41 \ All Year	ABS	x	x	x	0003, 0092, 0264
Quest \ V41 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V41 \ All Year	BCM	x	x		
Quest \ V41 \ All Year	Air bag	x	x	x	
Quest \ V41 \ All Year	ICC/ADAS	x	x	x	
Quest \ V41 \ All Year	HVAC	x	x	x	
Quest \ V41 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V41 \ All Year	Multi AV	x	x	x	0280
Quest \ V41 \ All Year	EPS/DAST 3	x	x	x	
Quest \ V41 \ All Year	IPDM E/R	x	x	x	
Quest \ V41 \ All Year	Air pressure monitor	x	x	x	
Quest \ V41 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V41 \ All Year	DIU	x	x	x	
Quest \ V41 \ All Year	Auto slide door	x	x	x	
Quest \ V41 \ All Year	Auto drive position	x	x	x	
Quest \ V41 \ All Year	All mode AWD/4WD	x	x	x	
Quest \ V41 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	

Quest \ V41 \ All Year	Sonar	x	x	x	
Quest \ V41 \ All Year	Lane camera	x	x	x	
Quest \ V41 \ All Year	Adaptive light	x	x	x	
Quest \ V41 \ All Year	AVM		x	x	
Quest \ V41 \ All Year	Head lamp levelizer	x	x	x	
Quest \ V41 \ All Year	Difference lock	x	x	x	
Quest \ V41 \ All Year	Nats immu	x	x		
Quest \ V41 \ All Year	Smart entrance	x	x		
Quest \ V41 \ All Year	Air levelizer	x	x	x	
Quest \ V41 \ All Year	Rearview camera			x	
Quest \ V41 \ All Year	S/blind camera			x	
Quest \ V41 \ All Year	Motor assist	x	x	x	
Quest \ V42 \ 2003-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2003-5~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2003-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2003-5~	BCM	x	x		
Quest \ V42 \ 2003-5~	Air bag	x	x	x	
Quest \ V42 \ 2003-5~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2003-5~	HVAC	x	x	x	
Quest \ V42 \ 2003-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2003-5~	Multi AV	x	x	x	0280
Quest \ V42 \ 2003-5~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2003-5~	IPDM E/R	x	x	x	
Quest \ V42 \ 2003-5~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2003-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2003-5~	DIU	x	x	x	
Quest \ V42 \ 2003-5~	Auto slide door	x	x	x	
Quest \ V42 \ 2003-5~	Auto drive position	x	x	x	
Quest \ V42 \ 2003-5~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2003-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2003-5~	Sonar	x	x	x	
Quest \ V42 \ 2003-5~	Lane camera	x	x	x	
Quest \ V42 \ 2003-5~	Adaptive light	x	x	x	
Quest \ V42 \ 2003-5~	AVM		x	x	
Quest \ V42 \ 2003-5~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2003-5~	Difference lock	x	x	x	
Quest \ V42 \ 2003-5~	Nats immu	x	x		
Quest \ V42 \ 2003-5~	Smart entrance	x	x		

Quest \ V42 \ 2003-5~	Air levelizer	x	x	x	
Quest \ V42 \ 2003-5~	Rearview camera			x	
Quest \ V42 \ 2003-5~	S/blind camera			x	
Quest \ V42 \ 2003-5~	Motor assist	x	x	x	
Quest \ V42 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2004	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2004	BCM	x	x		
Quest \ V42 \ 2004	Air bag	x	x	x	
Quest \ V42 \ 2004	ICC/ADAS	x	x	x	
Quest \ V42 \ 2004	HVAC	x	x	x	
Quest \ V42 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2004	Multi AV	x	x	x	0280
Quest \ V42 \ 2004	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2004	IPDM E/R	x	x	x	
Quest \ V42 \ 2004	Air pressure monitor	x	x	x	
Quest \ V42 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2004	DIU	x	x	x	
Quest \ V42 \ 2004	Auto slide door	x	x	x	
Quest \ V42 \ 2004	Auto drive position	x	x	x	
Quest \ V42 \ 2004	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2004	Sonar	x	x	x	
Quest \ V42 \ 2004	Lane camera	x	x	x	
Quest \ V42 \ 2004	Adaptive light	x	x	x	
Quest \ V42 \ 2004	AVM		x	x	
Quest \ V42 \ 2004	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2004	Difference lock	x	x	x	
Quest \ V42 \ 2004	Nats immu	x	x		
Quest \ V42 \ 2004	Smart entrance	x	x		
Quest \ V42 \ 2004	Air levelizer	x	x	x	
Quest \ V42 \ 2004	Rearview camera			x	
Quest \ V42 \ 2004	S/blind camera			x	
Quest \ V42 \ 2004	Motor assist	x	x	x	
Quest \ V42 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Quest \ V42 \ 2004-9~	BCM	x	x		
Quest \ V42 \ 2004-9~	Air bag	x	x	x	
Quest \ V42 \ 2004-9~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2004-9~	HVAC	x	x	x	
Quest \ V42 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2004-9~	Multi AV	x	x	x	0280
Quest \ V42 \ 2004-9~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2004-9~	IPDM E/R	x	x	x	
Quest \ V42 \ 2004-9~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2004-9~	DIU	x	x	x	
Quest \ V42 \ 2004-9~	Auto slide door	x	x	x	
Quest \ V42 \ 2004-9~	Auto drive position	x	x	x	
Quest \ V42 \ 2004-9~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2004-9~	Sonar	x	x	x	
Quest \ V42 \ 2004-9~	Lane camera	x	x	x	
Quest \ V42 \ 2004-9~	Adaptive light	x	x	x	
Quest \ V42 \ 2004-9~	AVM		x	x	
Quest \ V42 \ 2004-9~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2004-9~	Difference lock	x	x	x	
Quest \ V42 \ 2004-9~	Nats immu	x	x		
Quest \ V42 \ 2004-9~	Smart entrance	x	x		
Quest \ V42 \ 2004-9~	Air levelizer	x	x	x	
Quest \ V42 \ 2004-9~	Rearview camera			x	
Quest \ V42 \ 2004-9~	S/blind camera			x	
Quest \ V42 \ 2004-9~	Motor assist	x	x	x	
Quest \ V42 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2005	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2005	BCM	x	x		
Quest \ V42 \ 2005	Air bag	x	x	x	
Quest \ V42 \ 2005	ICC/ADAS	x	x	x	
Quest \ V42 \ 2005	HVAC	x	x	x	
Quest \ V42 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2005	Multi AV	x	x	x	0280
Quest \ V42 \ 2005	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2005	IPDM E/R	x	x	x	

Quest \ V42 \ 2005	Air pressure monitor	x	x	x	
Quest \ V42 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2005	DIU	x	x	x	
Quest \ V42 \ 2005	Auto slide door	x	x	x	
Quest \ V42 \ 2005	Auto drive position	x	x	x	
Quest \ V42 \ 2005	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2005	Sonar	x	x	x	
Quest \ V42 \ 2005	Lane camera	x	x	x	
Quest \ V42 \ 2005	Adaptive light	x	x	x	
Quest \ V42 \ 2005	AVM		x	x	
Quest \ V42 \ 2005	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2005	Difference lock	x	x	x	
Quest \ V42 \ 2005	Nats immu	x	x		
Quest \ V42 \ 2005	Smart entrance	x	x		
Quest \ V42 \ 2005	Air levelizer	x	x	x	
Quest \ V42 \ 2005	Rearview camera			x	
Quest \ V42 \ 2005	S/blind camera			x	
Quest \ V42 \ 2005	Motor assist	x	x	x	
Quest \ V42 \ 2005-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2005-5~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2005-5~	BCM	x	x		
Quest \ V42 \ 2005-5~	Air bag	x	x	x	
Quest \ V42 \ 2005-5~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2005-5~	HVAC	x	x	x	
Quest \ V42 \ 2005-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2005-5~	Multi AV	x	x	x	0280
Quest \ V42 \ 2005-5~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2005-5~	IPDM E/R	x	x	x	
Quest \ V42 \ 2005-5~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2005-5~	DIU	x	x	x	
Quest \ V42 \ 2005-5~	Auto slide door	x	x	x	
Quest \ V42 \ 2005-5~	Auto drive position	x	x	x	
Quest \ V42 \ 2005-5~	All mode AWD/4WD	x	x	x	

Quest \ V42 \ 2005-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2005-5~	Sonar	x	x	x	
Quest \ V42 \ 2005-5~	Lane camera	x	x	x	
Quest \ V42 \ 2005-5~	Adaptive light	x	x	x	
Quest \ V42 \ 2005-5~	AVM		x	x	
Quest \ V42 \ 2005-5~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2005-5~	Difference lock	x	x	x	
Quest \ V42 \ 2005-5~	Nats immu	x	x		
Quest \ V42 \ 2005-5~	Smart entrance	x	x		
Quest \ V42 \ 2005-5~	Air levelizer	x	x	x	
Quest \ V42 \ 2005-5~	Rearview camera			x	
Quest \ V42 \ 2005-5~	S/blind camera			x	
Quest \ V42 \ 2005-5~	Motor assist	x	x	x	
Quest \ V42 \ 2005-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2005-7~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2005-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2005-7~	BCM	x	x		
Quest \ V42 \ 2005-7~	Air bag	x	x	x	
Quest \ V42 \ 2005-7~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2005-7~	HVAC	x	x	x	
Quest \ V42 \ 2005-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2005-7~	Multi AV	x	x	x	0280
Quest \ V42 \ 2005-7~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2005-7~	IPDM E/R	x	x	x	
Quest \ V42 \ 2005-7~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2005-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2005-7~	DIU	x	x	x	
Quest \ V42 \ 2005-7~	Auto slide door	x	x	x	
Quest \ V42 \ 2005-7~	Auto drive position	x	x	x	
Quest \ V42 \ 2005-7~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2005-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2005-7~	Sonar	x	x	x	
Quest \ V42 \ 2005-7~	Lane camera	x	x	x	
Quest \ V42 \ 2005-7~	Adaptive light	x	x	x	
Quest \ V42 \ 2005-7~	AVM		x	x	
Quest \ V42 \ 2005-7~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2005-7~	Difference lock	x	x	x	
Quest \ V42 \ 2005-7~	Nats immu	x	x		

Quest \ V42 \ 2005-7~	Smart entrance	x	x		
Quest \ V42 \ 2005-7~	Air levelizer	x	x	x	
Quest \ V42 \ 2005-7~	Rearview camera			x	
Quest \ V42 \ 2005-7~	S/blind camera			x	
Quest \ V42 \ 2005-7~	Motor assist	x	x	x	
Quest \ V42 \ 2005-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2005-8~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2005-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2005-8~	BCM	x	x		
Quest \ V42 \ 2005-8~	Air bag	x	x	x	
Quest \ V42 \ 2005-8~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2005-8~	HVAC	x	x	x	
Quest \ V42 \ 2005-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2005-8~	Multi AV	x	x	x	0280
Quest \ V42 \ 2005-8~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2005-8~	IPDM E/R	x	x	x	
Quest \ V42 \ 2005-8~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2005-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2005-8~	DIU	x	x	x	
Quest \ V42 \ 2005-8~	Auto slide door	x	x	x	
Quest \ V42 \ 2005-8~	Auto drive position	x	x	x	
Quest \ V42 \ 2005-8~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2005-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2005-8~	Sonar	x	x	x	
Quest \ V42 \ 2005-8~	Lane camera	x	x	x	
Quest \ V42 \ 2005-8~	Adaptive light	x	x	x	
Quest \ V42 \ 2005-8~	AVM		x	x	
Quest \ V42 \ 2005-8~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2005-8~	Difference lock	x	x	x	
Quest \ V42 \ 2005-8~	Nats immu	x	x		
Quest \ V42 \ 2005-8~	Smart entrance	x	x		
Quest \ V42 \ 2005-8~	Air levelizer	x	x	x	
Quest \ V42 \ 2005-8~	Rearview camera			x	
Quest \ V42 \ 2005-8~	S/blind camera			x	
Quest \ V42 \ 2005-8~	Motor assist	x	x	x	
Quest \ V42 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2006	ABS	x	x	x	0003, 0092, 0264

Quest \ V42 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2006	BCM	x	x		
Quest \ V42 \ 2006	Air bag	x	x	x	
Quest \ V42 \ 2006	ICC/ADAS	x	x	x	
Quest \ V42 \ 2006	HVAC	x	x	x	
Quest \ V42 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2006	Multi AV	x	x	x	0280
Quest \ V42 \ 2006	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2006	IPDM E/R	x	x	x	
Quest \ V42 \ 2006	Air pressure monitor	x	x	x	
Quest \ V42 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2006	DIU	x	x	x	
Quest \ V42 \ 2006	Auto slide door	x	x	x	
Quest \ V42 \ 2006	Auto drive position	x	x	x	
Quest \ V42 \ 2006	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2006	Sonar	x	x	x	
Quest \ V42 \ 2006	Lane camera	x	x	x	
Quest \ V42 \ 2006	Adaptive light	x	x	x	
Quest \ V42 \ 2006	AVM		x	x	
Quest \ V42 \ 2006	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2006	Difference lock	x	x	x	
Quest \ V42 \ 2006	Nats immu	x	x		
Quest \ V42 \ 2006	Smart entrance	x	x		
Quest \ V42 \ 2006	Air levelizer	x	x	x	
Quest \ V42 \ 2006	Rearview camera			x	
Quest \ V42 \ 2006	S/blind camera			x	
Quest \ V42 \ 2006	Motor assist	x	x	x	
Quest \ V42 \ 2006-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2006-5~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2006-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2006-5~	BCM	x	x		
Quest \ V42 \ 2006-5~	Air bag	x	x	x	
Quest \ V42 \ 2006-5~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2006-5~	HVAC	x	x	x	
Quest \ V42 \ 2006-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2006-5~	Multi AV	x	x	x	0280
Quest \ V42 \ 2006-5~	EPS/DAST 3	x	x	x	

Quest \ V42 \ 2006-5~	IPDM E/R	x	x	x	
Quest \ V42 \ 2006-5~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2006-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2006-5~	DIU	x	x	x	
Quest \ V42 \ 2006-5~	Auto slide door	x	x	x	
Quest \ V42 \ 2006-5~	Auto drive position	x	x	x	
Quest \ V42 \ 2006-5~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2006-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2006-5~	Sonar	x	x	x	
Quest \ V42 \ 2006-5~	Lane camera	x	x	x	
Quest \ V42 \ 2006-5~	Adaptive light	x	x	x	
Quest \ V42 \ 2006-5~	AVM		x	x	
Quest \ V42 \ 2006-5~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2006-5~	Difference lock	x	x	x	
Quest \ V42 \ 2006-5~	Nats immu	x	x		
Quest \ V42 \ 2006-5~	Smart entrance	x	x		
Quest \ V42 \ 2006-5~	Air levelizer	x	x	x	
Quest \ V42 \ 2006-5~	Rearview camera			x	
Quest \ V42 \ 2006-5~	S/blind camera			x	
Quest \ V42 \ 2006-5~	Motor assist	x	x	x	
Quest \ V42 \ 2006-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2006-6~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2006-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2006-6~	BCM	x	x		
Quest \ V42 \ 2006-6~	Air bag	x	x	x	
Quest \ V42 \ 2006-6~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2006-6~	HVAC	x	x	x	
Quest \ V42 \ 2006-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2006-6~	Multi AV	x	x	x	0280
Quest \ V42 \ 2006-6~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2006-6~	IPDM E/R	x	x	x	
Quest \ V42 \ 2006-6~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2006-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2006-6~	DIU	x	x	x	
Quest \ V42 \ 2006-6~	Auto slide door	x	x	x	
Quest \ V42 \ 2006-6~	Auto drive position	x	x	x	

Quest \ V42 \ 2006-6~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2006-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2006-6~	Sonar	x	x	x	
Quest \ V42 \ 2006-6~	Lane camera	x	x	x	
Quest \ V42 \ 2006-6~	Adaptive light	x	x	x	
Quest \ V42 \ 2006-6~	AVM		x	x	
Quest \ V42 \ 2006-6~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2006-6~	Difference lock	x	x	x	
Quest \ V42 \ 2006-6~	Nats immu	x	x		
Quest \ V42 \ 2006-6~	Smart entrance	x	x		
Quest \ V42 \ 2006-6~	Air levelizer	x	x	x	
Quest \ V42 \ 2006-6~	Rearview camera			x	
Quest \ V42 \ 2006-6~	S/blind camera			x	
Quest \ V42 \ 2006-6~	Motor assist	x	x	x	
Quest \ V42 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2007	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2007	BCM	x	x		
Quest \ V42 \ 2007	Air bag	x	x	x	
Quest \ V42 \ 2007	ICC/ADAS	x	x	x	
Quest \ V42 \ 2007	HVAC	x	x	x	
Quest \ V42 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2007	Multi AV	x	x	x	0280
Quest \ V42 \ 2007	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2007	IPDM E/R	x	x	x	
Quest \ V42 \ 2007	Air pressure monitor	x	x	x	
Quest \ V42 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2007	DIU	x	x	x	
Quest \ V42 \ 2007	Auto slide door	x	x	x	
Quest \ V42 \ 2007	Auto drive position	x	x	x	
Quest \ V42 \ 2007	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2007	Sonar	x	x	x	
Quest \ V42 \ 2007	Lane camera	x	x	x	
Quest \ V42 \ 2007	Adaptive light	x	x	x	
Quest \ V42 \ 2007	AVM		x	x	
Quest \ V42 \ 2007	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2007	Difference lock	x	x	x	

Quest \ V42 \ 2007	Nats immu	x	x		
Quest \ V42 \ 2007	Smart entrance	x	x		
Quest \ V42 \ 2007	Air levelizer	x	x	x	
Quest \ V42 \ 2007	Rearview camera			x	
Quest \ V42 \ 2007	S/blind camera			x	
Quest \ V42 \ 2007	Motor assist	x	x	x	
Quest \ V42 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2007-8~	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2007-8~	BCM	x	x		
Quest \ V42 \ 2007-8~	Air bag	x	x	x	
Quest \ V42 \ 2007-8~	ICC/ADAS	x	x	x	
Quest \ V42 \ 2007-8~	HVAC	x	x	x	
Quest \ V42 \ 2007-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2007-8~	Multi AV	x	x	x	0280
Quest \ V42 \ 2007-8~	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2007-8~	IPDM E/R	x	x	x	
Quest \ V42 \ 2007-8~	Air pressure monitor	x	x	x	
Quest \ V42 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2007-8~	DIU	x	x	x	
Quest \ V42 \ 2007-8~	Auto slide door	x	x	x	
Quest \ V42 \ 2007-8~	Auto drive position	x	x	x	
Quest \ V42 \ 2007-8~	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2007-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2007-8~	Sonar	x	x	x	
Quest \ V42 \ 2007-8~	Lane camera	x	x	x	
Quest \ V42 \ 2007-8~	Adaptive light	x	x	x	
Quest \ V42 \ 2007-8~	AVM		x	x	
Quest \ V42 \ 2007-8~	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2007-8~	Difference lock	x	x	x	
Quest \ V42 \ 2007-8~	Nats immu	x	x		
Quest \ V42 \ 2007-8~	Smart entrance	x	x		
Quest \ V42 \ 2007-8~	Air levelizer	x	x	x	
Quest \ V42 \ 2007-8~	Rearview camera			x	
Quest \ V42 \ 2007-8~	S/blind camera			x	
Quest \ V42 \ 2007-8~	Motor assist	x	x	x	
Quest \ V42 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Quest \ V42 \ 2008	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2008	BCM	x	x		
Quest \ V42 \ 2008	Air bag	x	x	x	
Quest \ V42 \ 2008	ICC/ADAS	x	x	x	
Quest \ V42 \ 2008	HVAC	x	x	x	
Quest \ V42 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2008	Multi AV	x	x	x	0280
Quest \ V42 \ 2008	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2008	IPDM E/R	x	x	x	
Quest \ V42 \ 2008	Air pressure monitor	x	x	x	
Quest \ V42 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2008	DIU	x	x	x	
Quest \ V42 \ 2008	Auto slide door	x	x	x	
Quest \ V42 \ 2008	Auto drive position	x	x	x	
Quest \ V42 \ 2008	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2008	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2008	Sonar	x	x	x	
Quest \ V42 \ 2008	Lane camera	x	x	x	
Quest \ V42 \ 2008	Adaptive light	x	x	x	
Quest \ V42 \ 2008	AVM		x	x	
Quest \ V42 \ 2008	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2008	Difference lock	x	x	x	
Quest \ V42 \ 2008	Nats immu	x	x		
Quest \ V42 \ 2008	Smart entrance	x	x		
Quest \ V42 \ 2008	Air levelizer	x	x	x	
Quest \ V42 \ 2008	Rearview camera			x	
Quest \ V42 \ 2008	S/blind camera			x	
Quest \ V42 \ 2008	Motor assist	x	x	x	
Quest \ V42 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Quest \ V42 \ 2009	ABS	x	x	x	0003, 0092, 0264
Quest \ V42 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Quest \ V42 \ 2009	BCM	x	x		
Quest \ V42 \ 2009	Air bag	x	x	x	
Quest \ V42 \ 2009	ICC/ADAS	x	x	x	
Quest \ V42 \ 2009	HVAC	x	x	x	
Quest \ V42 \ 2009	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Quest \ V42 \ 2009	Multi AV	x	x	x	0280

Quest \ V42 \ 2009	EPS/DAST 3	x	x	x	
Quest \ V42 \ 2009	IPDM E/R	x	x	x	
Quest \ V42 \ 2009	Air pressure monitor	x	x	x	
Quest \ V42 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Quest \ V42 \ 2009	DIU	x	x	x	
Quest \ V42 \ 2009	Auto slide door	x	x	x	
Quest \ V42 \ 2009	Auto drive position	x	x	x	
Quest \ V42 \ 2009	All mode AWD/4WD	x	x	x	
Quest \ V42 \ 2009	4WAS(MAIN)/RAS/HICAS	x	x	x	
Quest \ V42 \ 2009	Sonar	x	x	x	
Quest \ V42 \ 2009	Lane camera	x	x	x	
Quest \ V42 \ 2009	Adaptive light	x	x	x	
Quest \ V42 \ 2009	AVM		x	x	
Quest \ V42 \ 2009	Head lamp levelizer	x	x	x	
Quest \ V42 \ 2009	Difference lock	x	x	x	
Quest \ V42 \ 2009	Nats immu	x	x		
Quest \ V42 \ 2009	Smart entrance	x	x		
Quest \ V42 \ 2009	Air levelizer	x	x	x	
Quest \ V42 \ 2009	Rearview camera			x	
Quest \ V42 \ 2009	S/blind camera			x	
Quest \ V42 \ 2009	Motor assist	x	x	x	
Rasheen \ RB14 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rasheen \ RB14 \ All Year	ABS	x	x	x	0003, 0092, 0264
Rasheen \ RB14 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Rasheen \ RB14 \ All Year	BCM	x	x		
Rasheen \ RB14 \ All Year	Air bag	x	x	x	
Rasheen \ RB14 \ All Year	ICC/ADAS	x	x	x	
Rasheen \ RB14 \ All Year	HVAC	x	x	x	
Rasheen \ RB14 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Rasheen \ RB14 \ All Year	Multi AV	x	x	x	0280
Rasheen \ RB14 \ All Year	EPS/DAST 3	x	x	x	
Rasheen \ RB14 \ All Year	IPDM E/R	x	x	x	
Rasheen \ RB14 \ All Year	Air pressure monitor	x	x	x	
Rasheen \ RB14 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Rasheen \ RB14 \ All Year	DIU	x	x	x	
Rasheen \ RB14 \ All Year	Auto slide door	x	x	x	

Rasheen \ RB14 \ All Year	Auto drive position	x	x	x	
Rasheen \ RB14 \ All Year	All mode AWD/4WD	x	x	x	
Rasheen \ RB14 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Rasheen \ RB14 \ All Year	Sonar	x	x	x	
Rasheen \ RB14 \ All Year	Lane camera	x	x	x	
Rasheen \ RB14 \ All Year	Adaptive light	x	x	x	
Rasheen \ RB14 \ All Year	AVM		x	x	
Rasheen \ RB14 \ All Year	Head lamp levelizer	x	x	x	
Rasheen \ RB14 \ All Year	Difference lock	x	x	x	
Rasheen \ RB14 \ All Year	Nats immu	x	x		
Rasheen \ RB14 \ All Year	Smart entrance	x	x		
Rasheen \ RB14 \ All Year	Air levelizer	x	x	x	
Rasheen \ RB14 \ All Year	Rearview camera			x	
Rasheen \ RB14 \ All Year	S/blind camera			x	
Rasheen \ RB14 \ All Year	Motor assist	x	x	x	
Rnessa \ N30 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rnessa \ N30 \ All Year	ABS	x	x	x	0003, 0092, 0264
Rnessa \ N30 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Rnessa \ N30 \ All Year	BCM	x	x		
Rnessa \ N30 \ All Year	Air bag	x	x	x	
Rnessa \ N30 \ All Year	ICC/ADAS	x	x	x	
Rnessa \ N30 \ All Year	HVAC	x	x	x	
Rnessa \ N30 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Rnessa \ N30 \ All Year	Multi AV	x	x	x	0280
Rnessa \ N30 \ All Year	EPS/DAST 3	x	x	x	
Rnessa \ N30 \ All Year	IPDM E/R	x	x	x	
Rnessa \ N30 \ All Year	Air pressure monitor	x	x	x	
Rnessa \ N30 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Rnessa \ N30 \ All Year	DIU	x	x	x	
Rnessa \ N30 \ All Year	Auto slide door	x	x	x	
Rnessa \ N30 \ All Year	Auto drive position	x	x	x	
Rnessa \ N30 \ All Year	All mode AWD/4WD	x	x	x	
Rnessa \ N30 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Rnessa \ N30 \ All Year	Sonar	x	x	x	
Rnessa \ N30 \ All Year	Lane camera	x	x	x	
Rnessa \ N30 \ All Year	Adaptive light	x	x	x	
Rnessa \ N30 \ All Year	AVM		x	x	
Rnessa \ N30 \ All Year	Head lamp levelizer	x	x	x	

Rnessa \ N30 \ All Year	Difference lock	x	x	x	
Rnessa \ N30 \ All Year	Nats immu	x	x		
Rnessa \ N30 \ All Year	Smart entrance	x	x		
Rnessa \ N30 \ All Year	Air levelizer	x	x	x	
Rnessa \ N30 \ All Year	Rearview camera			x	
Rnessa \ N30 \ All Year	S/blind camera			x	
Rnessa \ N30 \ All Year	Motor assist	x	x	x	
ROGUE Select \ S35 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ROGUE Select \ S35 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
ROGUE Select \ S35 \ 2014	BCM	x	x		
ROGUE Select \ S35 \ 2014	Air bag	x	x	x	
ROGUE Select \ S35 \ 2014	Transmission	x	x	x	
ROGUE Select \ S35 \ 2014	EPS/DAST 3	x	x	x	
ROGUE Select \ S35 \ 2014	IPDM E/R	x	x	x	
ROGUE Select \ S35 \ 2014	All mode AWD/4WD	x	x	x	0245, 0311
ROGUE Select \ S35 \ 2014	AVM		x	x	
ROGUE Select \ S35 \ 2014	ABS	x	x	x	
ROGUE Select \ S35 \ 2014	Head lamp levelizer	x	x	x	
ROGUE Select \ S35 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
ROGUE Select \ S35 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
ROGUE Select \ S35 \ 2015	BCM	x	x		
ROGUE Select \ S35 \ 2015	Air bag	x	x	x	
ROGUE Select \ S35 \ 2015	ICC/ADAS	x	x	x	
ROGUE Select \ S35 \ 2015	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
ROGUE Select \ S35 \ 2015	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
ROGUE Select \ S35 \ 2015	EPS/DAST 3	x	x	x	
ROGUE Select \ S35 \ 2015	IPDM E/R	x	x	x	
ROGUE Select \ S35 \ 2015	Laser/radar	x	x	x	
ROGUE Select \ S35 \ 2015	4WAS(MAIN)/RAS/HICAS	x	x	x	
ROGUE Select \ S35 \ 2015	CAN gateway		x	x	
ROGUE Select \ S35 \ 2015	4WAS(front)	x	x	x	
ROGUE Select \ S35 \ 2015	E-SUS		x	x	
ROGUE Select \ S35 \ 2015	Side radar left		x	x	
ROGUE Select \ S35 \ 2015	Side radar right		x	x	
ROGUE Select \ S35 \ 2015	BSW/buzzer		x	x	
ROGUE Select \ S35 \ 2015	AVM		x	x	
ROGUE Select \ S35 \ 2015	ABS	x	x	x	
ROGUE Select \ S35 \ 2015	All mode AWD/4WD	x	x	x	

ROGUE Select \ S35 \ 2015	Air levelizer	x	x	x	
Rogue \ S35 \ 2007-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2007-9~	Meter/M&A		x	x	
Rogue \ S35 \ 2007-9~	BCM	x	x		
Rogue \ S35 \ 2007-9~	Transmission	x	x	x	
Rogue \ S35 \ 2007-9~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2007-9~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2007-9~	Intelligent key	x	x	x	
Rogue \ S35 \ 2007-9~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2007-9~	ABS	x	x	x	
Rogue \ S35 \ 2007-9~	Air bag	x	x	x	
Rogue \ S35 \ 2007-9~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2007-9~	Sonar	x	x	x	
Rogue \ S35 \ 2007-9~	Rearview camera			x	
Rogue \ S35 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2008	Meter/M&A		x	x	
Rogue \ S35 \ 2008	BCM	x	x		
Rogue \ S35 \ 2008	Transmission	x	x	x	
Rogue \ S35 \ 2008	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2008	IPDM E/R	x	x	x	
Rogue \ S35 \ 2008	Intelligent key	x	x	x	
Rogue \ S35 \ 2008	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2008	ABS	x	x	x	
Rogue \ S35 \ 2008	Air bag	x	x	x	
Rogue \ S35 \ 2008	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2008	Sonar	x	x	x	
Rogue \ S35 \ 2008	Rearview camera			x	
Rogue \ S35 \ 2008-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2008-10~	Meter/M&A		x	x	
Rogue \ S35 \ 2008-10~	BCM	x	x		
Rogue \ S35 \ 2008-10~	Air bag	x	x	x	
Rogue \ S35 \ 2008-10~	Transmission	x	x	x	
Rogue \ S35 \ 2008-10~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2008-10~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2008-10~	Intelligent key	x	x	x	
Rogue \ S35 \ 2008-10~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2008-10~	ABS	x	x	x	
Rogue \ S35 \ 2008-10~	Head lamp levelizer	x	x	x	

Rogue \ S35 \ 2008-10~	Sonar	x	x	x	
Rogue \ S35 \ 2008-10~	Rearview camera			x	
Rogue \ S35 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2008-12~	Meter/M&A		x	x	
Rogue \ S35 \ 2008-12~	BCM	x	x		
Rogue \ S35 \ 2008-12~	Air bag	x	x	x	
Rogue \ S35 \ 2008-12~	Transmission	x	x	x	
Rogue \ S35 \ 2008-12~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2008-12~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2008-12~	Intelligent key	x	x	x	
Rogue \ S35 \ 2008-12~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2008-12~	ABS	x	x	x	
Rogue \ S35 \ 2008-12~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2008-12~	Sonar	x	x	x	
Rogue \ S35 \ 2008-12~	Rearview camera			x	
Rogue \ S35 \ 2008-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2008-7~	Meter/M&A		x	x	
Rogue \ S35 \ 2008-7~	BCM	x	x		
Rogue \ S35 \ 2008-7~	Transmission	x	x	x	
Rogue \ S35 \ 2008-7~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2008-7~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2008-7~	Intelligent key	x	x	x	
Rogue \ S35 \ 2008-7~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2008-7~	ABS	x	x	x	
Rogue \ S35 \ 2008-7~	Air bag	x	x	x	
Rogue \ S35 \ 2008-7~	Sonar	x	x	x	
Rogue \ S35 \ 2008-7~	Rearview camera			x	
Rogue \ S35 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2009	Meter/M&A		x	x	
Rogue \ S35 \ 2009	BCM	x	x		
Rogue \ S35 \ 2009	Transmission	x	x	x	
Rogue \ S35 \ 2009	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2009	IPDM E/R	x	x	x	
Rogue \ S35 \ 2009	Intelligent key	x	x	x	
Rogue \ S35 \ 2009	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2009	ABS	x	x	x	
Rogue \ S35 \ 2009	Air bag	x	x	x	
Rogue \ S35 \ 2009	Sonar	x	x	x	

Rogue \ S35 \ 2009	Rearview camera			x	
Rogue \ S35 \ 2009-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2009-7~	Meter/M&A		x	x	
Rogue \ S35 \ 2009-7~	BCM	x	x		
Rogue \ S35 \ 2009-7~	Air bag	x	x	x	
Rogue \ S35 \ 2009-7~	Transmission	x	x	x	
Rogue \ S35 \ 2009-7~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2009-7~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2009-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Rogue \ S35 \ 2009-7~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2009-7~	ABS	x	x	x	
Rogue \ S35 \ 2009-7~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2009-7~	Sonar	x	x	x	
Rogue \ S35 \ 2009-7~	Rearview camera			x	
Rogue \ S35 \ 2009-7~	Intelligent key	x	x	x	
Rogue \ S35 \ 2009-7~	S/blind camera			x	
Rogue \ S35 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2010	Meter/M&A		x	x	
Rogue \ S35 \ 2010	BCM	x	x		
Rogue \ S35 \ 2010	Air bag	x	x	x	
Rogue \ S35 \ 2010	Transmission	x	x	x	
Rogue \ S35 \ 2010	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2010	IPDM E/R	x	x	x	
Rogue \ S35 \ 2010	Intelligent key	x	x	x	
Rogue \ S35 \ 2010	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2010	ABS	x	x	x	
Rogue \ S35 \ 2010	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2010	Sonar	x	x	x	
Rogue \ S35 \ 2010	Rearview camera			x	
Rogue \ S35 \ 2010	S/blind camera			x	
Rogue \ S35 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2010-7~	Meter/M&A		x	x	
Rogue \ S35 \ 2010-7~	BCM	x	x		
Rogue \ S35 \ 2010-7~	Air bag	x	x	x	
Rogue \ S35 \ 2010-7~	Transmission	x	x	x	
Rogue \ S35 \ 2010-7~	EPS/DAST 3	x	x	x	

Rogue \ S35 \ 2010-7~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2010-7~	Intelligent key	x	x	x	
Rogue \ S35 \ 2010-7~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2010-7~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2010-7~	Sonar	x	x	x	
Rogue \ S35 \ 2010-7~	Rearview camera			x	
Rogue \ S35 \ 2010-7~	S/blind camera			x	
Rogue \ S35 \ 2010-7~	ABS	x	x	x	
Rogue \ S35 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2011	Meter/M&A		x	x	
Rogue \ S35 \ 2011	BCM	x	x		
Rogue \ S35 \ 2011	Air bag	x	x	x	
Rogue \ S35 \ 2011	Transmission	x	x	x	
Rogue \ S35 \ 2011	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2011	IPDM E/R	x	x	x	
Rogue \ S35 \ 2011	Intelligent key	x	x	x	
Rogue \ S35 \ 2011	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2011	ABS	x	x	x	
Rogue \ S35 \ 2011	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2011	Sonar	x	x	x	
Rogue \ S35 \ 2011	Rearview camera			x	
Rogue \ S35 \ 2011	S/blind camera			x	
Rogue \ S35 \ 2011-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2011-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Rogue \ S35 \ 2011-7~	BCM	x	x		
Rogue \ S35 \ 2011-7~	Air bag	x	x	x	
Rogue \ S35 \ 2011-7~	Transmission	x	x	x	
Rogue \ S35 \ 2011-7~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2011-7~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2011-7~	Intelligent key	x	x	x	
Rogue \ S35 \ 2011-7~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2011-7~	AVM		x	x	
Rogue \ S35 \ 2011-7~	ABS	x	x	x	
Rogue \ S35 \ 2011-7~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2011-7~	Sonar	x	x	x	
Rogue \ S35 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Rogue \ S35 \ 2012	BCM	x	x		

Rogue \ S35 \ 2012	Air bag	x	x	x	
Rogue \ S35 \ 2012	Transmission	x	x	x	
Rogue \ S35 \ 2012	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2012	IPDM E/R	x	x	x	
Rogue \ S35 \ 2012	Intelligent key	x	x	x	
Rogue \ S35 \ 2012	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2012	AVM		x	x	
Rogue \ S35 \ 2012	ABS	x	x	x	
Rogue \ S35 \ 2012	Sonar	x	x	x	
Rogue \ S35 \ 2012	Rearview camera			x	
Rogue \ S35 \ 2012	S/blind camera			x	
Rogue \ S35 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2012-6~	Meter/M&A		x	x	
Rogue \ S35 \ 2012-6~	BCM	x	x		
Rogue \ S35 \ 2012-6~	Air bag	x	x	x	
Rogue \ S35 \ 2012-6~	Transmission	x	x	x	
Rogue \ S35 \ 2012-6~	Multi AV	x	x	x	0280
Rogue \ S35 \ 2012-6~	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2012-6~	IPDM E/R	x	x	x	
Rogue \ S35 \ 2012-6~	Intelligent key	x	x	x	
Rogue \ S35 \ 2012-6~	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2012-6~	AVM		x	x	
Rogue \ S35 \ 2012-6~	ABS	x	x	x	
Rogue \ S35 \ 2012-6~	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2012-6~	Sonar	x	x	x	
Rogue \ S35 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ S35 \ 2013	Meter/M&A		x	x	
Rogue \ S35 \ 2013	BCM	x	x		
Rogue \ S35 \ 2013	Air bag	x	x	x	
Rogue \ S35 \ 2013	Transmission	x	x	x	
Rogue \ S35 \ 2013	Multi AV	x	x	x	0280
Rogue \ S35 \ 2013	EPS/DAST 3	x	x	x	
Rogue \ S35 \ 2013	IPDM E/R	x	x	x	
Rogue \ S35 \ 2013	Intelligent key	x	x	x	
Rogue \ S35 \ 2013	All mode AWD/4WD	x	x	x	0245, 0311
Rogue \ S35 \ 2013	AVM		x	x	
Rogue \ S35 \ 2013	ABS	x	x	x	
Rogue \ S35 \ 2013	Head lamp levelizer	x	x	x	
Rogue \ S35 \ 2013	Sonar	x	x	x	

Rogue \ T32 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ T32 \ 2014	ABS		x	x	
Rogue \ T32 \ 2014	Meter/M&A		x	x	
Rogue \ T32 \ 2014	BCM		x		
Rogue \ T32 \ 2014	Air bag		x	x	
Rogue \ T32 \ 2014	HVAC		x	x	
Rogue \ T32 \ 2014	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Rogue \ T32 \ 2014	Multi AV	x	x	x	0280
Rogue \ T32 \ 2014	EPS/DAST 3		x	x	
Rogue \ T32 \ 2014	IPDM E/R		x	x	
Rogue \ T32 \ 2014	Air pressure monitor		x	x	
Rogue \ T32 \ 2014	Laser/radar		x	x	
Rogue \ T32 \ 2014	All mode AWD/4WD		x	x	
Rogue \ T32 \ 2014	Sonar		x	x	
Rogue \ T32 \ 2014	CAN gateway		x	x	
Rogue \ T32 \ 2014	Auto back door		x	x	
Rogue \ T32 \ 2014	AVM		x	x	
Rogue \ T32 \ 2014	Chassis control		x	x	
Rogue \ T32 \ 2014	Occupant detection			x	
Rogue \ T32 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ T32 \ 2015	ABS		x	x	
Rogue \ T32 \ 2015	Meter/M&A		x	x	
Rogue \ T32 \ 2015	BCM		x		
Rogue \ T32 \ 2015	Air bag		x	x	
Rogue \ T32 \ 2015	ICC/ADAS		x	x	
Rogue \ T32 \ 2015	HVAC		x	x	
Rogue \ T32 \ 2015	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Rogue \ T32 \ 2015	Multi AV	x	x	x	0280
Rogue \ T32 \ 2015	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Rogue \ T32 \ 2015	EPS/DAST 3		x	x	
Rogue \ T32 \ 2015	IPDM E/R		x	x	
Rogue \ T32 \ 2015	Air pressure monitor		x	x	
Rogue \ T32 \ 2015	Laser/radar		x	x	
Rogue \ T32 \ 2015	All mode AWD/4WD		x	x	
Rogue \ T32 \ 2015	Sonar	x	x	x	
Rogue \ T32 \ 2015	Lane camera	x	x	x	

Rogue \ T32 \ 2015	CAN gateway		x	x	
Rogue \ T32 \ 2015	Auto back door		x	x	
Rogue \ T32 \ 2015	Telematics		x	x	0253
Rogue \ T32 \ 2015	BSW/buzzer		x	x	
Rogue \ T32 \ 2015	AVM		x	x	
Rogue \ T32 \ 2015	Chassis control		x	x	
Rogue \ T32 \ 2015	PMAS		x	x	
Rogue \ T32 \ 2015	Occupant detection			x	
Rogue \ T32 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Rogue \ T32 \ 2016	ABS		x	x	
Rogue \ T32 \ 2016	Meter/M&A		x	x	
Rogue \ T32 \ 2016	BCM		x		
Rogue \ T32 \ 2016	Air bag		x	x	
Rogue \ T32 \ 2016	ICC/ADAS	x	x	x	
Rogue \ T32 \ 2016	HVAC		x	x	
Rogue \ T32 \ 2016	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Rogue \ T32 \ 2016	Multi AV	x	x	x	0280
Rogue \ T32 \ 2016	EPS/DAST 3	x	x	x	
Rogue \ T32 \ 2016	IPDM E/R		x	x	
Rogue \ T32 \ 2016	Air pressure monitor		x	x	
Rogue \ T32 \ 2016	Laser/radar	x	x	x	
Rogue \ T32 \ 2016	Auto drive position		x	x	
Rogue \ T32 \ 2016	All mode AWD/4WD		x	x	
Rogue \ T32 \ 2016	Sonar		x	x	
Rogue \ T32 \ 2016	CAN gateway		x	x	
Rogue \ T32 \ 2016	Auto back door		x	x	
Rogue \ T32 \ 2016	Accele pedal ACT		x	x	
Rogue \ T32 \ 2016	Side radar left		x	x	
Rogue \ T32 \ 2016	Side radar right		x	x	
Rogue \ T32 \ 2016	Telematics		x	x	0253
Rogue \ T32 \ 2016	AVM		x	x	
Rogue \ T32 \ 2016	Chassis control		x	x	
Rogue \ T32 \ 2016	FSCM		x	x	
Rogue \ T32 \ 2016	Occupant detection			x	
Safari \ Y61 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Safari \ Y61 \ All Year	ABS	x	x	x	0003, 0092, 0264
Safari \ Y61 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Safari \ Y61 \ All Year	BCM	x	x		

Safari \ Y61 \ All Year	Air bag	x	x	x	
Safari \ Y61 \ All Year	ICC/ADAS	x	x	x	
Safari \ Y61 \ All Year	HVAC	x	x	x	
Safari \ Y61 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Safari \ Y61 \ All Year	Multi AV	x	x	x	0280
Safari \ Y61 \ All Year	EPS/DAST 3	x	x	x	
Safari \ Y61 \ All Year	IPDM E/R	x	x	x	
Safari \ Y61 \ All Year	Air pressure monitor	x	x	x	
Safari \ Y61 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Safari \ Y61 \ All Year	DIU	x	x	x	
Safari \ Y61 \ All Year	Auto slide door	x	x	x	
Safari \ Y61 \ All Year	Auto drive position	x	x	x	
Safari \ Y61 \ All Year	All mode AWD/4WD	x	x	x	
Safari \ Y61 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Safari \ Y61 \ All Year	Sonar	x	x	x	
Safari \ Y61 \ All Year	Lane camera	x	x	x	
Safari \ Y61 \ All Year	Adaptive light	x	x	x	
Safari \ Y61 \ All Year	AVM		x	x	
Safari \ Y61 \ All Year	Head lamp levelizer	x	x	x	
Safari \ Y61 \ All Year	Difference lock	x	x	x	
Safari \ Y61 \ All Year	Nats immu	x	x		
Safari \ Y61 \ All Year	Smart entrance	x	x		
Safari \ Y61 \ All Year	Air levelizer	x	x	x	
Safari \ Y61 \ All Year	Rearview camera			x	
Safari \ Y61 \ All Year	S/blind camera			x	
Safari \ Y61 \ All Year	Motor assist	x	x	x	
Sentra \ B14 \ 1995	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ 1995	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ 1995	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B14 \ 1995	BCM	x	x		
Sentra \ B14 \ 1995	Air bag	x	x	x	
Sentra \ B14 \ 1995	ICC/ADAS	x	x	x	
Sentra \ B14 \ 1995	HVAC	x	x	x	
Sentra \ B14 \ 1995	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ 1995	Multi AV	x	x	x	0280
Sentra \ B14 \ 1995	EPS/DAST 3	x	x	x	
Sentra \ B14 \ 1995	IPDM E/R	x	x	x	
Sentra \ B14 \ 1995	Air pressure monitor	x	x	x	

Sentra \ B14 \ 1995	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ 1995	DIU	x	x	x	
Sentra \ B14 \ 1995	Auto slide door	x	x	x	
Sentra \ B14 \ 1995	Auto drive position	x	x	x	
Sentra \ B14 \ 1995	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ 1995	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B14 \ 1995	Sonar	x	x	x	
Sentra \ B14 \ 1995	Lane camera	x	x	x	
Sentra \ B14 \ 1995	Adaptive light	x	x	x	
Sentra \ B14 \ 1995	AVM		x	x	
Sentra \ B14 \ 1995	Head lamp levelizer	x	x	x	
Sentra \ B14 \ 1995	Difference lock	x	x	x	
Sentra \ B14 \ 1995	Nats immu	x	x		
Sentra \ B14 \ 1995	Smart entrance	x	x		
Sentra \ B14 \ 1995	Air levelizer	x	x	x	
Sentra \ B14 \ 1995	Rearview camera			x	
Sentra \ B14 \ 1995	S/blind camera			x	
Sentra \ B14 \ 1995	Motor assist	x	x	x	
Sentra \ B14 \ 1996	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ 1996	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ 1996	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B14 \ 1996	BCM	x	x		
Sentra \ B14 \ 1996	Air bag	x	x	x	
Sentra \ B14 \ 1996	ICC/ADAS	x	x	x	
Sentra \ B14 \ 1996	HVAC	x	x	x	
Sentra \ B14 \ 1996	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ 1996	Multi AV	x	x	x	0280
Sentra \ B14 \ 1996	EPS/DAST 3	x	x	x	
Sentra \ B14 \ 1996	IPDM E/R	x	x	x	
Sentra \ B14 \ 1996	Air pressure monitor	x	x	x	
Sentra \ B14 \ 1996	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ 1996	DIU	x	x	x	
Sentra \ B14 \ 1996	Auto slide door	x	x	x	
Sentra \ B14 \ 1996	Auto drive position	x	x	x	
Sentra \ B14 \ 1996	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ 1996	4WAS(MAIN)/RAS/HICAS	x	x	x	

Sentra \ B14 \ 1996	Sonar	x	x	x	
Sentra \ B14 \ 1996	Lane camera	x	x	x	
Sentra \ B14 \ 1996	Adaptive light	x	x	x	
Sentra \ B14 \ 1996	AVM		x	x	
Sentra \ B14 \ 1996	Head lamp levelizer	x	x	x	
Sentra \ B14 \ 1996	Difference lock	x	x	x	
Sentra \ B14 \ 1996	Nats immu	x	x		
Sentra \ B14 \ 1996	Smart entrance	x	x		
Sentra \ B14 \ 1996	Air levelizer	x	x	x	
Sentra \ B14 \ 1996	Rearview camera			x	
Sentra \ B14 \ 1996	S/blind camera			x	
Sentra \ B14 \ 1996	Motor assist	x	x	x	
Sentra \ B14 \ 1997	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ 1997	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ 1997	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B14 \ 1997	BCM	x	x		
Sentra \ B14 \ 1997	Air bag	x	x	x	
Sentra \ B14 \ 1997	ICC/ADAS	x	x	x	
Sentra \ B14 \ 1997	HVAC	x	x	x	
Sentra \ B14 \ 1997	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ 1997	Multi AV	x	x	x	0280
Sentra \ B14 \ 1997	EPS/DAST 3	x	x	x	
Sentra \ B14 \ 1997	IPDM E/R	x	x	x	
Sentra \ B14 \ 1997	Air pressure monitor	x	x	x	
Sentra \ B14 \ 1997	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ 1997	DIU	x	x	x	
Sentra \ B14 \ 1997	Auto slide door	x	x	x	
Sentra \ B14 \ 1997	Auto drive position	x	x	x	
Sentra \ B14 \ 1997	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ 1997	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B14 \ 1997	Sonar	x	x	x	
Sentra \ B14 \ 1997	Lane camera	x	x	x	
Sentra \ B14 \ 1997	Adaptive light	x	x	x	
Sentra \ B14 \ 1997	AVM		x	x	
Sentra \ B14 \ 1997	Head lamp levelizer	x	x	x	
Sentra \ B14 \ 1997	Difference lock	x	x	x	
Sentra \ B14 \ 1997	Nats immu	x	x		
Sentra \ B14 \ 1997	Smart entrance	x	x		

Sentra \ B14 \ 1997	Air levelizer	x	x	x	
Sentra \ B14 \ 1997	Rearview camera			x	
Sentra \ B14 \ 1997	S/blind camera			x	
Sentra \ B14 \ 1997	Motor assist	x	x	x	
Sentra \ B14 \ 1998	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ 1998	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ 1998	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B14 \ 1998	BCM	x	x		
Sentra \ B14 \ 1998	Air bag	x	x	x	
Sentra \ B14 \ 1998	ICC/ADAS	x	x	x	
Sentra \ B14 \ 1998	HVAC	x	x	x	
Sentra \ B14 \ 1998	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ 1998	Multi AV	x	x	x	0280
Sentra \ B14 \ 1998	EPS/DAST 3	x	x	x	
Sentra \ B14 \ 1998	IPDM E/R	x	x	x	
Sentra \ B14 \ 1998	Air pressure monitor	x	x	x	
Sentra \ B14 \ 1998	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ 1998	DIU	x	x	x	
Sentra \ B14 \ 1998	Auto slide door	x	x	x	
Sentra \ B14 \ 1998	Auto drive position	x	x	x	
Sentra \ B14 \ 1998	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ 1998	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B14 \ 1998	Sonar	x	x	x	
Sentra \ B14 \ 1998	Lane camera	x	x	x	
Sentra \ B14 \ 1998	Adaptive light	x	x	x	
Sentra \ B14 \ 1998	AVM		x	x	
Sentra \ B14 \ 1998	Head lamp levelizer	x	x	x	
Sentra \ B14 \ 1998	Difference lock	x	x	x	
Sentra \ B14 \ 1998	Nats immu	x	x		
Sentra \ B14 \ 1998	Smart entrance	x	x		
Sentra \ B14 \ 1998	Air levelizer	x	x	x	
Sentra \ B14 \ 1998	Rearview camera			x	
Sentra \ B14 \ 1998	S/blind camera			x	
Sentra \ B14 \ 1998	Motor assist	x	x	x	
Sentra \ B14 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ 1999	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Sentra \ B14 \ 1999	BCM	x	x		
Sentra \ B14 \ 1999	Air bag	x	x	x	
Sentra \ B14 \ 1999	ICC/ADAS	x	x	x	
Sentra \ B14 \ 1999	HVAC	x	x	x	
Sentra \ B14 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ 1999	Multi AV	x	x	x	0280
Sentra \ B14 \ 1999	EPS/DAST 3	x	x	x	
Sentra \ B14 \ 1999	IPDM E/R	x	x	x	
Sentra \ B14 \ 1999	Air pressure monitor	x	x	x	
Sentra \ B14 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ 1999	DIU	x	x	x	
Sentra \ B14 \ 1999	Auto slide door	x	x	x	
Sentra \ B14 \ 1999	Auto drive position	x	x	x	
Sentra \ B14 \ 1999	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B14 \ 1999	Sonar	x	x	x	
Sentra \ B14 \ 1999	Lane camera	x	x	x	
Sentra \ B14 \ 1999	Adaptive light	x	x	x	
Sentra \ B14 \ 1999	AVM		x	x	
Sentra \ B14 \ 1999	Head lamp levelizer	x	x	x	
Sentra \ B14 \ 1999	Difference lock	x	x	x	
Sentra \ B14 \ 1999	Nats immu	x	x		
Sentra \ B14 \ 1999	Smart entrance	x	x		
Sentra \ B14 \ 1999	Air levelizer	x	x	x	
Sentra \ B14 \ 1999	Rearview camera			x	
Sentra \ B14 \ 1999	S/blind camera			x	
Sentra \ B14 \ 1999	Motor assist	x	x	x	
Sentra \ B14 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B14 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sentra \ B14 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B14 \ All Year	BCM	x	x		
Sentra \ B14 \ All Year	Air bag	x	x	x	
Sentra \ B14 \ All Year	ICC/ADAS	x	x	x	
Sentra \ B14 \ All Year	HVAC	x	x	x	
Sentra \ B14 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B14 \ All Year	Multi AV	x	x	x	0280
Sentra \ B14 \ All Year	EPS/DAST 3	x	x	x	
Sentra \ B14 \ All Year	IPDM E/R	x	x	x	

Sentra \ B14 \ All Year	Air pressure monitor	x	x	x	
Sentra \ B14 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B14 \ All Year	DIU	x	x	x	
Sentra \ B14 \ All Year	Auto slide door	x	x	x	
Sentra \ B14 \ All Year	Auto drive position	x	x	x	
Sentra \ B14 \ All Year	All mode AWD/4WD	x	x	x	
Sentra \ B14 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B14 \ All Year	Sonar	x	x	x	
Sentra \ B14 \ All Year	Lane camera	x	x	x	
Sentra \ B14 \ All Year	Adaptive light	x	x	x	
Sentra \ B14 \ All Year	AVM		x	x	
Sentra \ B14 \ All Year	Head lamp levelizer	x	x	x	
Sentra \ B14 \ All Year	Difference lock	x	x	x	
Sentra \ B14 \ All Year	Nats immu	x	x		
Sentra \ B14 \ All Year	Smart entrance	x	x		
Sentra \ B14 \ All Year	Air levelizer	x	x	x	
Sentra \ B14 \ All Year	Rearview camera			x	
Sentra \ B14 \ All Year	S/blind camera			x	
Sentra \ B14 \ All Year	Motor assist	x	x	x	
Sentra \ B15 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2000	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2000	BCM	x	x		
Sentra \ B15 \ 2000	Air bag	x	x	x	
Sentra \ B15 \ 2000	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2000	HVAC	x	x	x	
Sentra \ B15 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2000	Multi AV	x	x	x	0280
Sentra \ B15 \ 2000	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2000	IPDM E/R	x	x	x	
Sentra \ B15 \ 2000	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2000	DIU	x	x	x	
Sentra \ B15 \ 2000	Auto slide door	x	x	x	
Sentra \ B15 \ 2000	Auto drive position	x	x	x	
Sentra \ B15 \ 2000	All mode AWD/4WD	x	x	x	

Sentra \ B15 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2000	Sonar	x	x	x	
Sentra \ B15 \ 2000	Lane camera	x	x	x	
Sentra \ B15 \ 2000	Adaptive light	x	x	x	
Sentra \ B15 \ 2000	AVM		x	x	
Sentra \ B15 \ 2000	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2000	Difference lock	x	x	x	
Sentra \ B15 \ 2000	Nats immu	x	x		
Sentra \ B15 \ 2000	Smart entrance	x	x		
Sentra \ B15 \ 2000	Air levelizer	x	x	x	
Sentra \ B15 \ 2000	Rearview camera			x	
Sentra \ B15 \ 2000	S/blind camera			x	
Sentra \ B15 \ 2000	Motor assist	x	x	x	
Sentra \ B15 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2001	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2001	BCM	x	x		
Sentra \ B15 \ 2001	Air bag	x	x	x	
Sentra \ B15 \ 2001	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2001	HVAC	x	x	x	
Sentra \ B15 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2001	Multi AV	x	x	x	0280
Sentra \ B15 \ 2001	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2001	IPDM E/R	x	x	x	
Sentra \ B15 \ 2001	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2001	DIU	x	x	x	
Sentra \ B15 \ 2001	Auto slide door	x	x	x	
Sentra \ B15 \ 2001	Auto drive position	x	x	x	
Sentra \ B15 \ 2001	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2001	Sonar	x	x	x	
Sentra \ B15 \ 2001	Lane camera	x	x	x	
Sentra \ B15 \ 2001	Adaptive light	x	x	x	
Sentra \ B15 \ 2001	AVM		x	x	
Sentra \ B15 \ 2001	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2001	Difference lock	x	x	x	
Sentra \ B15 \ 2001	Nats immu	x	x		

Sentra \ B15 \ 2001	Smart entrance	x	x		
Sentra \ B15 \ 2001	Air levelizer	x	x	x	
Sentra \ B15 \ 2001	Rearview camera			x	
Sentra \ B15 \ 2001	S/blind camera			x	
Sentra \ B15 \ 2001	Motor assist	x	x	x	
Sentra \ B15 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2002	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2002	BCM	x	x		
Sentra \ B15 \ 2002	Air bag	x	x	x	
Sentra \ B15 \ 2002	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2002	HVAC	x	x	x	
Sentra \ B15 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2002	Multi AV	x	x	x	0280
Sentra \ B15 \ 2002	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2002	IPDM E/R	x	x	x	
Sentra \ B15 \ 2002	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2002	DIU	x	x	x	
Sentra \ B15 \ 2002	Auto slide door	x	x	x	
Sentra \ B15 \ 2002	Auto drive position	x	x	x	
Sentra \ B15 \ 2002	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2002	Sonar	x	x	x	
Sentra \ B15 \ 2002	Lane camera	x	x	x	
Sentra \ B15 \ 2002	Adaptive light	x	x	x	
Sentra \ B15 \ 2002	AVM		x	x	
Sentra \ B15 \ 2002	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2002	Difference lock	x	x	x	
Sentra \ B15 \ 2002	Nats immu	x	x		
Sentra \ B15 \ 2002	Smart entrance	x	x		
Sentra \ B15 \ 2002	Air levelizer	x	x	x	
Sentra \ B15 \ 2002	Rearview camera			x	
Sentra \ B15 \ 2002	S/blind camera			x	
Sentra \ B15 \ 2002	Motor assist	x	x	x	
Sentra \ B15 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2003	ABS	x	x	x	0003, 0092, 0264

Sentra \ B15 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2003	BCM	x	x		
Sentra \ B15 \ 2003	Air bag	x	x	x	
Sentra \ B15 \ 2003	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2003	HVAC	x	x	x	
Sentra \ B15 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2003	Multi AV	x	x	x	0280
Sentra \ B15 \ 2003	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2003	IPDM E/R	x	x	x	
Sentra \ B15 \ 2003	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2003	DIU	x	x	x	
Sentra \ B15 \ 2003	Auto slide door	x	x	x	
Sentra \ B15 \ 2003	Auto drive position	x	x	x	
Sentra \ B15 \ 2003	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2003	Sonar	x	x	x	
Sentra \ B15 \ 2003	Lane camera	x	x	x	
Sentra \ B15 \ 2003	Adaptive light	x	x	x	
Sentra \ B15 \ 2003	AVM		x	x	
Sentra \ B15 \ 2003	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2003	Difference lock	x	x	x	
Sentra \ B15 \ 2003	Nats immu	x	x		
Sentra \ B15 \ 2003	Smart entrance	x	x		
Sentra \ B15 \ 2003	Air levelizer	x	x	x	
Sentra \ B15 \ 2003	Rearview camera			x	
Sentra \ B15 \ 2003	S/blind camera			x	
Sentra \ B15 \ 2003	Motor assist	x	x	x	
Sentra \ B15 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2004	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2004	BCM	x	x		
Sentra \ B15 \ 2004	Air bag	x	x	x	
Sentra \ B15 \ 2004	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2004	HVAC	x	x	x	
Sentra \ B15 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2004	Multi AV	x	x	x	0280
Sentra \ B15 \ 2004	EPS/DAST 3	x	x	x	

Sentra \ B15 \ 2004	IPDM E/R	x	x	x	
Sentra \ B15 \ 2004	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2004	DIU	x	x	x	
Sentra \ B15 \ 2004	Auto slide door	x	x	x	
Sentra \ B15 \ 2004	Auto drive position	x	x	x	
Sentra \ B15 \ 2004	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2004	Sonar	x	x	x	
Sentra \ B15 \ 2004	Lane camera	x	x	x	
Sentra \ B15 \ 2004	Adaptive light	x	x	x	
Sentra \ B15 \ 2004	AVM		x	x	
Sentra \ B15 \ 2004	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2004	Difference lock	x	x	x	
Sentra \ B15 \ 2004	Nats immu	x	x		
Sentra \ B15 \ 2004	Smart entrance	x	x		
Sentra \ B15 \ 2004	Air levelizer	x	x	x	
Sentra \ B15 \ 2004	Rearview camera			x	
Sentra \ B15 \ 2004	S/blind camera			x	
Sentra \ B15 \ 2004	Motor assist	x	x	x	
Sentra \ B15 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2005	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2005	BCM	x	x		
Sentra \ B15 \ 2005	Air bag	x	x	x	
Sentra \ B15 \ 2005	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2005	HVAC	x	x	x	
Sentra \ B15 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2005	Multi AV	x	x	x	0280
Sentra \ B15 \ 2005	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2005	IPDM E/R	x	x	x	
Sentra \ B15 \ 2005	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2005	DIU	x	x	x	
Sentra \ B15 \ 2005	Auto slide door	x	x	x	
Sentra \ B15 \ 2005	Auto drive position	x	x	x	

Sentra \ B15 \ 2005	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2005	Sonar	x	x	x	
Sentra \ B15 \ 2005	Lane camera	x	x	x	
Sentra \ B15 \ 2005	Adaptive light	x	x	x	
Sentra \ B15 \ 2005	AVM		x	x	
Sentra \ B15 \ 2005	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2005	Difference lock	x	x	x	
Sentra \ B15 \ 2005	Nats immu	x	x		
Sentra \ B15 \ 2005	Smart entrance	x	x		
Sentra \ B15 \ 2005	Air levelizer	x	x	x	
Sentra \ B15 \ 2005	Rearview camera			x	
Sentra \ B15 \ 2005	S/blind camera			x	
Sentra \ B15 \ 2005	Motor assist	x	x	x	
Sentra \ B15 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ 2006	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ 2006	BCM	x	x		
Sentra \ B15 \ 2006	Air bag	x	x	x	
Sentra \ B15 \ 2006	ICC/ADAS	x	x	x	
Sentra \ B15 \ 2006	HVAC	x	x	x	
Sentra \ B15 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ 2006	Multi AV	x	x	x	0280
Sentra \ B15 \ 2006	EPS/DAST 3	x	x	x	
Sentra \ B15 \ 2006	IPDM E/R	x	x	x	
Sentra \ B15 \ 2006	Air pressure monitor	x	x	x	
Sentra \ B15 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ 2006	DIU	x	x	x	
Sentra \ B15 \ 2006	Auto slide door	x	x	x	
Sentra \ B15 \ 2006	Auto drive position	x	x	x	
Sentra \ B15 \ 2006	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ 2006	Sonar	x	x	x	
Sentra \ B15 \ 2006	Lane camera	x	x	x	
Sentra \ B15 \ 2006	Adaptive light	x	x	x	
Sentra \ B15 \ 2006	AVM		x	x	
Sentra \ B15 \ 2006	Head lamp levelizer	x	x	x	
Sentra \ B15 \ 2006	Difference lock	x	x	x	

Sentra \ B15 \ 2006	Nats immu	x	x		
Sentra \ B15 \ 2006	Smart entrance	x	x		
Sentra \ B15 \ 2006	Air levelizer	x	x	x	
Sentra \ B15 \ 2006	Rearview camera			x	
Sentra \ B15 \ 2006	S/blind camera			x	
Sentra \ B15 \ 2006	Motor assist	x	x	x	
Sentra \ B15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sentra \ B15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B15 \ All Year	BCM	x	x		
Sentra \ B15 \ All Year	Air bag	x	x	x	
Sentra \ B15 \ All Year	ICC/ADAS	x	x	x	
Sentra \ B15 \ All Year	HVAC	x	x	x	
Sentra \ B15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B15 \ All Year	Multi AV	x	x	x	0280
Sentra \ B15 \ All Year	EPS/DAST 3	x	x	x	
Sentra \ B15 \ All Year	IPDM E/R	x	x	x	
Sentra \ B15 \ All Year	Air pressure monitor	x	x	x	
Sentra \ B15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sentra \ B15 \ All Year	DIU	x	x	x	
Sentra \ B15 \ All Year	Auto slide door	x	x	x	
Sentra \ B15 \ All Year	Auto drive position	x	x	x	
Sentra \ B15 \ All Year	All mode AWD/4WD	x	x	x	
Sentra \ B15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B15 \ All Year	Sonar	x	x	x	
Sentra \ B15 \ All Year	Lane camera	x	x	x	
Sentra \ B15 \ All Year	Adaptive light	x	x	x	
Sentra \ B15 \ All Year	AVM		x	x	
Sentra \ B15 \ All Year	Head lamp levelizer	x	x	x	
Sentra \ B15 \ All Year	Difference lock	x	x	x	
Sentra \ B15 \ All Year	Nats immu	x	x		
Sentra \ B15 \ All Year	Smart entrance	x	x		
Sentra \ B15 \ All Year	Air levelizer	x	x	x	
Sentra \ B15 \ All Year	Rearview camera			x	
Sentra \ B15 \ All Year	S/blind camera			x	
Sentra \ B15 \ All Year	Motor assist	x	x	x	
Sentra \ B16 \ 2006-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Sentra \ B16 \ 2006-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2006-10~	BCM	x	x		
Sentra \ B16 \ 2006-10~	Transmission	x	x	x	
Sentra \ B16 \ 2006-10~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2006-10~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2006-10~	SUB meter	x	x		
Sentra \ B16 \ 2006-10~	ABS	x	x	x	
Sentra \ B16 \ 2006-10~	Air bag	x	x	x	
Sentra \ B16 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2007	BCM	x	x		
Sentra \ B16 \ 2007	Air bag	x	x	x	
Sentra \ B16 \ 2007	Transmission	x	x	x	
Sentra \ B16 \ 2007	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2007	IPDM E/R	x	x	x	
Sentra \ B16 \ 2007	SUB meter	x	x		
Sentra \ B16 \ 2007	Intelligent key	x	x	x	
Sentra \ B16 \ 2007	ABS	x	x	x	
Sentra \ B16 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2007-7~	BCM	x	x		
Sentra \ B16 \ 2007-7~	Air bag	x	x	x	
Sentra \ B16 \ 2007-7~	Transmission	x	x	x	
Sentra \ B16 \ 2007-7~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2007-7~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2007-7~	SUB meter	x	x		
Sentra \ B16 \ 2007-7~	Intelligent key	x	x	x	
Sentra \ B16 \ 2007-7~	ABS	x	x	x	
Sentra \ B16 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2008	BCM	x	x		
Sentra \ B16 \ 2008	Air bag	x	x	x	
Sentra \ B16 \ 2008	Transmission	x	x	x	
Sentra \ B16 \ 2008	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2008	IPDM E/R	x	x	x	
Sentra \ B16 \ 2008	SUB meter	x	x		
Sentra \ B16 \ 2008	Intelligent key	x	x	x	
Sentra \ B16 \ 2008	ABS	x	x	x	

Sentra \ B16 \ 2008-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2008-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2008-9~	BCM	x	x		
Sentra \ B16 \ 2008-9~	Air bag	x	x	x	
Sentra \ B16 \ 2008-9~	Transmission	x	x	x	
Sentra \ B16 \ 2008-9~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2008-9~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2008-9~	SUB meter	x	x		
Sentra \ B16 \ 2008-9~	Intelligent key	x	x	x	
Sentra \ B16 \ 2008-9~	ABS	x	x	x	
Sentra \ B16 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2009	BCM	x	x		
Sentra \ B16 \ 2009	Air bag	x	x	x	
Sentra \ B16 \ 2009	Transmission	x	x	x	
Sentra \ B16 \ 2009	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2009	IPDM E/R	x	x	x	
Sentra \ B16 \ 2009	SUB meter	x	x		
Sentra \ B16 \ 2009	Intelligent key	x	x	x	
Sentra \ B16 \ 2009	ABS	x	x	x	
Sentra \ B16 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2009-8~	BCM	x	x		
Sentra \ B16 \ 2009-8~	Air bag	x	x	x	
Sentra \ B16 \ 2009-8~	Transmission	x	x	x	
Sentra \ B16 \ 2009-8~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2009-8~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2009-8~	SUB meter	x	x		
Sentra \ B16 \ 2009-8~	Intelligent key	x	x	x	
Sentra \ B16 \ 2009-8~	ABS	x	x	x	
Sentra \ B16 \ 2009-8~	SVT	x	x	x	
Sentra \ B16 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2010	BCM	x	x		
Sentra \ B16 \ 2010	Air bag	x	x	x	
Sentra \ B16 \ 2010	Transmission	x	x	x	
Sentra \ B16 \ 2010	EPS/DAST 3	x	x	x	

Sentra \ B16 \ 2010	IPDM E/R	x	x	x	
Sentra \ B16 \ 2010	SUB meter	x	x		
Sentra \ B16 \ 2010	Intelligent key	x	x	x	
Sentra \ B16 \ 2010	ABS	x	x	x	
Sentra \ B16 \ 2010	SVT	x	x	x	
Sentra \ B16 \ 2010-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2010-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2010-4~	BCM	x	x		
Sentra \ B16 \ 2010-4~	Air bag	x	x	x	
Sentra \ B16 \ 2010-4~	Transmission	x	x	x	
Sentra \ B16 \ 2010-4~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2010-4~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2010-4~	SUB meter	x	x		
Sentra \ B16 \ 2010-4~	Intelligent key	x	x	x	
Sentra \ B16 \ 2010-4~	ABS	x	x	x	
Sentra \ B16 \ 2010-4~	SVT	x	x	x	
Sentra \ B16 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2010-8~	BCM	x	x		
Sentra \ B16 \ 2010-8~	Air bag	x	x	x	
Sentra \ B16 \ 2010-8~	Transmission	x	x	x	
Sentra \ B16 \ 2010-8~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2010-8~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2010-8~	SUB meter	x	x		
Sentra \ B16 \ 2010-8~	Intelligent key	x	x	x	
Sentra \ B16 \ 2010-8~	ABS	x	x	x	
Sentra \ B16 \ 2010-8~	SVT	x	x	x	
Sentra \ B16 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2011	BCM	x	x		
Sentra \ B16 \ 2011	Air bag	x	x	x	
Sentra \ B16 \ 2011	Transmission	x	x	x	
Sentra \ B16 \ 2011	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2011	IPDM E/R	x	x	x	
Sentra \ B16 \ 2011	SUB meter	x	x		
Sentra \ B16 \ 2011	Intelligent key	x	x	x	
Sentra \ B16 \ 2011	ABS	x	x	x	
Sentra \ B16 \ 2011	SVT	x	x	x	

Sentra \ B16 \ 2011	Rearview camera			x	
Sentra \ B16 \ 2011	S/blind camera			x	
Sentra \ B16 \ 2011-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2011-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2011-4~	BCM	x	x		
Sentra \ B16 \ 2011-4~	Air bag	x	x	x	
Sentra \ B16 \ 2011-4~	Transmission	x	x	x	
Sentra \ B16 \ 2011-4~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2011-4~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2011-4~	SUB meter	x	x		
Sentra \ B16 \ 2011-4~	Intelligent key	x	x	x	
Sentra \ B16 \ 2011-4~	ABS	x	x	x	
Sentra \ B16 \ 2011-4~	SVT	x	x	x	
Sentra \ B16 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2011-8~	BCM	x	x		
Sentra \ B16 \ 2011-8~	Air bag	x	x	x	
Sentra \ B16 \ 2011-8~	Transmission	x	x	x	
Sentra \ B16 \ 2011-8~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2011-8~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2011-8~	SUB meter	x	x		
Sentra \ B16 \ 2011-8~	Intelligent key	x	x	x	
Sentra \ B16 \ 2011-8~	ABS	x	x	x	
Sentra \ B16 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2012	BCM	x	x		
Sentra \ B16 \ 2012	Air bag	x	x	x	
Sentra \ B16 \ 2012	Transmission	x	x	x	
Sentra \ B16 \ 2012	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2012	IPDM E/R	x	x	x	
Sentra \ B16 \ 2012	SUB meter	x	x		
Sentra \ B16 \ 2012	Intelligent key	x	x	x	
Sentra \ B16 \ 2012	ABS	x	x	x	
Sentra \ B16 \ 2012-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B16 \ 2012-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sentra \ B16 \ 2012-2~	BCM	x	x		
Sentra \ B16 \ 2012-2~	Air bag	x	x	x	

Sentra \ B16 \ 2012-2~	Transmission	x	x	x	
Sentra \ B16 \ 2012-2~	EPS/DAST 3	x	x	x	
Sentra \ B16 \ 2012-2~	IPDM E/R	x	x	x	
Sentra \ B16 \ 2012-2~	SUB meter	x	x		
Sentra \ B16 \ 2012-2~	Intelligent key	x	x	x	
Sentra \ B16 \ 2012-2~	ABS	x	x	x	
Sentra \ B16 \ 2012-2~	SVT	x	x	x	
Sentra \ B17 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2012-10~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2012-10~	Meter/M&A		x	x	
Sentra \ B17 \ 2012-10~	BCM		x		
Sentra \ B17 \ 2012-10~	Air bag		x	x	
Sentra \ B17 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2012-10~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2012-10~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2012-10~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2012-10~	IPDM E/R		x	x	
Sentra \ B17 \ 2012-10~	Sonar		x	x	
Sentra \ B17 \ 2012-10~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2012-10~	Occupant detection			x	
Sentra \ B17 \ 2012-10~	SVT	x	x	x	
Sentra \ B17 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2012-11~	Meter/M&A		x	x	
Sentra \ B17 \ 2012-11~	BCM		x		
Sentra \ B17 \ 2012-11~	Air bag		x	x	
Sentra \ B17 \ 2012-11~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2012-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2012-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2012-11~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2012-11~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2012-11~	IPDM E/R		x	x	
Sentra \ B17 \ 2012-11~	Air pressure monitor		x	x	
Sentra \ B17 \ 2012-11~	Laser/radar	x	x	x	
Sentra \ B17 \ 2012-11~	Sonar	x	x	x	

Sentra \ B17 \ 2012-11~	Side radar left		x	x	
Sentra \ B17 \ 2012-11~	Side radar right		x	x	
Sentra \ B17 \ 2012-11~	PTC heater		x	x	
Sentra \ B17 \ 2012-11~	Telematics		x	x	0253
Sentra \ B17 \ 2012-11~	AVM		x	x	
Sentra \ B17 \ 2012-11~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2012-11~	Occupant detection			x	
Sentra \ B17 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2012-12~	Meter/M&A		x	x	
Sentra \ B17 \ 2012-12~	BCM		x		
Sentra \ B17 \ 2012-12~	Air bag		x	x	
Sentra \ B17 \ 2012-12~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2012-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2012-12~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2012-12~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2012-12~	IPDM E/R		x	x	
Sentra \ B17 \ 2012-12~	Air pressure monitor		x	x	
Sentra \ B17 \ 2012-12~	Laser/radar	x	x	x	
Sentra \ B17 \ 2012-12~	Sonar	x	x	x	
Sentra \ B17 \ 2012-12~	Side radar left		x	x	
Sentra \ B17 \ 2012-12~	Side radar right		x	x	
Sentra \ B17 \ 2012-12~	PTC heater		x	x	
Sentra \ B17 \ 2012-12~	Telematics		x	x	0253
Sentra \ B17 \ 2012-12~	AVM		x	x	
Sentra \ B17 \ 2012-12~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2012-12~	Occupant detection			x	
Sentra \ B17 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2013	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2013	Meter/M&A		x	x	
Sentra \ B17 \ 2013	BCM		x		
Sentra \ B17 \ 2013	Air bag		x	x	
Sentra \ B17 \ 2013	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2013	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sentra \ B17 \ 2013	Multi AV		x	x	

Sentra \ B17 \ 2013	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2013	IPDM E/R		x	x	
Sentra \ B17 \ 2013	Occupant detection			x	
Sentra \ B17 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2013-9~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2013-9~	Meter/M&A		x	x	
Sentra \ B17 \ 2013-9~	BCM		x		
Sentra \ B17 \ 2013-9~	Air bag		x	x	
Sentra \ B17 \ 2013-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2013-9~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2013-9~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2013-9~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2013-9~	IPDM E/R		x	x	
Sentra \ B17 \ 2013-9~	Laser/radar		x	x	
Sentra \ B17 \ 2013-9~	Sonar	x	x	x	
Sentra \ B17 \ 2013-9~	Telematics		x	x	0253
Sentra \ B17 \ 2013-9~	AVM		x	x	
Sentra \ B17 \ 2013-9~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2013-9~	Occupant detection			x	
Sentra \ B17 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2014	ABS	x	x	x	
Sentra \ B17 \ 2014	Meter/M&A		x	x	
Sentra \ B17 \ 2014	BCM		x		
Sentra \ B17 \ 2014	Air bag		x	x	
Sentra \ B17 \ 2014	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2014	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2014	Multi AV		x	x	
Sentra \ B17 \ 2014	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2014	IPDM E/R		x	x	
Sentra \ B17 \ 2014	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2014	Occupant detection			x	
Sentra \ B17 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2014-4~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2014-4~	Meter/M&A		x	x	

Sentra \ B17 \ 2014-4~	BCM		x		
Sentra \ B17 \ 2014-4~	Air bag		x	x	
Sentra \ B17 \ 2014-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2014-4~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2014-4~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2014-4~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2014-4~	IPDM E/R		x	x	
Sentra \ B17 \ 2014-4~	Sonar	x	x	x	
Sentra \ B17 \ 2014-4~	AVM		x	x	
Sentra \ B17 \ 2014-4~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2014-4~	Occupant detection			x	
Sentra \ B17 \ 2014-4~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2014-4~	Side radar left		x	x	
Sentra \ B17 \ 2014-4~	Side radar right		x	x	
Sentra \ B17 \ 2014-4~	Telematics		x	x	0253
Sentra \ B17 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2014-8~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2014-8~	Meter/M&A		x	x	
Sentra \ B17 \ 2014-8~	BCM		x		
Sentra \ B17 \ 2014-8~	Air bag		x	x	
Sentra \ B17 \ 2014-8~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2014-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2014-8~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2014-8~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2014-8~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2014-8~	IPDM E/R		x	x	
Sentra \ B17 \ 2014-8~	AVM		x	x	
Sentra \ B17 \ 2014-8~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2014-8~	Occupant detection			x	
Sentra \ B17 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2015	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2015	Meter/M&A		x	x	
Sentra \ B17 \ 2015	BCM		x		
Sentra \ B17 \ 2015	Air bag		x	x	

Sentra \ B17 \ 2015	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2015	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2015	Multi AV		x	x	
Sentra \ B17 \ 2015	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2015	IPDM E/R		x	x	
Sentra \ B17 \ 2015	Telematics		x	x	
Sentra \ B17 \ 2015	Occupant detection			x	
Sentra \ B17 \ 2015-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2015-1~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2015-1~	Meter/M&A		x	x	
Sentra \ B17 \ 2015-1~	BCM		x		
Sentra \ B17 \ 2015-1~	Air bag		x	x	
Sentra \ B17 \ 2015-1~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2015-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2015-1~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2015-1~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2015-1~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2015-1~	IPDM E/R		x	x	
Sentra \ B17 \ 2015-1~	Air pressure monitor		x	x	
Sentra \ B17 \ 2015-1~	Laser/radar	x	x	x	
Sentra \ B17 \ 2015-1~	Sonar	x	x	x	
Sentra \ B17 \ 2015-1~	Side radar left		x	x	
Sentra \ B17 \ 2015-1~	Side radar right		x	x	
Sentra \ B17 \ 2015-1~	PTC heater		x	x	
Sentra \ B17 \ 2015-1~	Telematics		x	x	0253
Sentra \ B17 \ 2015-1~	AVM		x	x	
Sentra \ B17 \ 2015-1~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2015-1~	Occupant detection			x	
Sentra \ B17 \ 2015-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2015-2~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2015-2~	Meter/M&A		x	x	
Sentra \ B17 \ 2015-2~	BCM		x		
Sentra \ B17 \ 2015-2~	Air bag		x	x	
Sentra \ B17 \ 2015-2~	ICC/ADAS	x	x	x	

Sentra \ B17 \ 2015-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2015-2~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2015-2~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2015-2~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2015-2~	IPDM E/R		x	x	
Sentra \ B17 \ 2015-2~	Air pressure monitor		x	x	
Sentra \ B17 \ 2015-2~	Laser/radar	x	x	x	
Sentra \ B17 \ 2015-2~	Sonar	x	x	x	
Sentra \ B17 \ 2015-2~	Side radar left		x	x	
Sentra \ B17 \ 2015-2~	Side radar right		x	x	
Sentra \ B17 \ 2015-2~	PTC heater		x	x	
Sentra \ B17 \ 2015-2~	Telematics		x	x	0253
Sentra \ B17 \ 2015-2~	AVM		x	x	
Sentra \ B17 \ 2015-2~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2015-2~	Occupant detection			x	
Sentra \ B17 \ 2015-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2015-4~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2015-4~	Meter/M&A		x	x	
Sentra \ B17 \ 2015-4~	BCM		x		
Sentra \ B17 \ 2015-4~	Air bag		x	x	
Sentra \ B17 \ 2015-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2015-4~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2015-4~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2015-4~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2015-4~	IPDM E/R		x	x	
Sentra \ B17 \ 2015-4~	Laser/radar		x	x	
Sentra \ B17 \ 2015-4~	Sonar	x	x	x	
Sentra \ B17 \ 2015-4~	Telematics		x	x	0253
Sentra \ B17 \ 2015-4~	AVM		x	x	
Sentra \ B17 \ 2015-4~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2015-4~	Occupant detection			x	
Sentra \ B17 \ 2015-4~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2015-4~	Side radar left		x	x	
Sentra \ B17 \ 2015-4~	Side radar right		x	x	
Sentra \ B17 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Sentra \ B17 \ 2015-6~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2015-6~	Meter/M&A		x	x	
Sentra \ B17 \ 2015-6~	BCM		x		
Sentra \ B17 \ 2015-6~	Air bag		x	x	
Sentra \ B17 \ 2015-6~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2015-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2015-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2015-6~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2015-6~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2015-6~	IPDM E/R		x	x	
Sentra \ B17 \ 2015-6~	Sonar	x	x	x	
Sentra \ B17 \ 2015-6~	Side radar left		x	x	
Sentra \ B17 \ 2015-6~	Side radar right		x	x	
Sentra \ B17 \ 2015-6~	Telematics		x	x	0253
Sentra \ B17 \ 2015-6~	AVM		x	x	
Sentra \ B17 \ 2015-6~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2015-6~	Occupant detection			x	
Sentra \ B17 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2016	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2016	Meter/M&A		x	x	
Sentra \ B17 \ 2016	BCM		x		
Sentra \ B17 \ 2016	Air bag		x	x	
Sentra \ B17 \ 2016	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2016	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2016	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2016	Multi AV		x	x	
Sentra \ B17 \ 2016	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2016	IPDM E/R		x	x	
Sentra \ B17 \ 2016	Laser/radar		x	x	
Sentra \ B17 \ 2016	Side radar left		x	x	
Sentra \ B17 \ 2016	Side radar right		x	x	
Sentra \ B17 \ 2016	Telematics		x	x	0253
Sentra \ B17 \ 2016	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2016	Occupant detection			x	
Sentra \ B17 \ 2016-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Sentra \ B17 \ 2016-1~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2016-1~	Meter/M&A		x	x	
Sentra \ B17 \ 2016-1~	BCM		x		
Sentra \ B17 \ 2016-1~	Air bag		x	x	
Sentra \ B17 \ 2016-1~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2016-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2016-1~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2016-1~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2016-1~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2016-1~	IPDM E/R		x	x	
Sentra \ B17 \ 2016-1~	Laser/radar	x	x	x	
Sentra \ B17 \ 2016-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B17 \ 2016-1~	4WAS(front)	x	x	x	
Sentra \ B17 \ 2016-1~	Accele pedal ACT		x	x	
Sentra \ B17 \ 2016-1~	Side radar left		x	x	
Sentra \ B17 \ 2016-1~	Side radar right		x	x	
Sentra \ B17 \ 2016-1~	AVM		x	x	
Sentra \ B17 \ 2016-1~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2016-1~	Occupant detection			x	
Sentra \ B17 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2016-2~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2016-2~	Meter/M&A		x	x	
Sentra \ B17 \ 2016-2~	BCM		x		
Sentra \ B17 \ 2016-2~	Air bag		x	x	
Sentra \ B17 \ 2016-2~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2016-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2016-2~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2016-2~	Multi AV		x	x	
Sentra \ B17 \ 2016-2~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2016-2~	IPDM E/R		x	x	
Sentra \ B17 \ 2016-2~	Laser/radar		x	x	
Sentra \ B17 \ 2016-2~	Side radar left		x	x	
Sentra \ B17 \ 2016-2~	Side radar right		x	x	
Sentra \ B17 \ 2016-2~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2016-2~	Occupant detection			x	

Sentra \ B17 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2016-4~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2016-4~	Meter/M&A		x	x	
Sentra \ B17 \ 2016-4~	BCM		x		
Sentra \ B17 \ 2016-4~	Air bag		x	x	
Sentra \ B17 \ 2016-4~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2016-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2016-4~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2016-4~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2016-4~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2016-4~	IPDM E/R		x	x	
Sentra \ B17 \ 2016-4~	Laser/radar	x	x	x	
Sentra \ B17 \ 2016-4~	Side radar left		x	x	
Sentra \ B17 \ 2016-4~	Side radar right		x	x	
Sentra \ B17 \ 2016-4~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2016-4~	Occupant detection			x	
Sentra \ B17 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2016-6~	Meter/M&A		x	x	
Sentra \ B17 \ 2016-6~	BCM		x		
Sentra \ B17 \ 2016-6~	Air bag		x	x	
Sentra \ B17 \ 2016-6~	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2016-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2016-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sentra \ B17 \ 2016-6~	Multi AV		x	x	
Sentra \ B17 \ 2016-6~	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2016-6~	IPDM E/R		x	x	
Sentra \ B17 \ 2016-6~	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2016-6~	Occupant detection			x	
Sentra \ B17 \ 2016-6~	Multi AV	x	x	x	0280
Sentra \ B17 \ 2016-6~	Laser/radar	x	x	x	
Sentra \ B17 \ 2016-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B17 \ 2016-6~	4WAS(front)	x	x	x	
Sentra \ B17 \ 2016-6~	Accele pedal ACT		x	x	
Sentra \ B17 \ 2016-6~	Side radar left		x	x	

Sentra \ B17 \ 2016-6~	Side radar right		x	x	
Sentra \ B17 \ 2016-6~	AVM		x	x	
Sentra \ B17 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sentra \ B17 \ 2017	ABS	x	x	x	0003, 0092, 0264
Sentra \ B17 \ 2017	Meter/M&A		x	x	0143
Sentra \ B17 \ 2017	BCM		x		
Sentra \ B17 \ 2017	Air bag	x	x	x	
Sentra \ B17 \ 2017	ICC/ADAS	x	x	x	
Sentra \ B17 \ 2017	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sentra \ B17 \ 2017	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0083, 0100, 0059, 0150, 0085
Sentra \ B17 \ 2017	Multi AV	x	x	x	0280
Sentra \ B17 \ 2017	EPS/DAST 3	x	x	x	
Sentra \ B17 \ 2017	IPDM E/R		x	x	
Sentra \ B17 \ 2017	Air pressure monitor	x	x	x	
Sentra \ B17 \ 2017	Laser/radar	x	x	x	
Sentra \ B17 \ 2017	Precrash seatbelt		x	x	
Sentra \ B17 \ 2017	Auto drive position	x	x	x	
Sentra \ B17 \ 2017	All mode AWD/4WD		x	x	
Sentra \ B17 \ 2017	Difference lock	x	x	x	
Sentra \ B17 \ 2017	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sentra \ B17 \ 2017	Sonar	x	x	x	
Sentra \ B17 \ 2017	Adaptive light	x	x	x	
Sentra \ B17 \ 2017	4WAS(front)	x	x	x	
Sentra \ B17 \ 2017	Accele pedal ACT		x	x	
Sentra \ B17 \ 2017	Side radar left		x	x	
Sentra \ B17 \ 2017	Side radar right		x	x	
Sentra \ B17 \ 2017	PTC heater		x	x	
Sentra \ B17 \ 2017	Telematics		x	x	0253
Sentra \ B17 \ 2017	AVM		x	x	
Sentra \ B17 \ 2017	Head lamp levelizer	x	x	x	
Sentra \ B17 \ 2017	Occupant detection			x	
Serena \ C24 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C24 \ All Year	ABS	x	x	x	0003, 0092, 0264
Serena \ C24 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C24 \ All Year	BCM	x	x		
Serena \ C24 \ All Year	Air bag	x	x	x	
Serena \ C24 \ All Year	ICC/ADAS	x	x	x	

Serena \ C24 \ All Year	HVAC	x	x	x	
Serena \ C24 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Serena \ C24 \ All Year	Multi AV	x	x	x	0280
Serena \ C24 \ All Year	EPS/DAST 3	x	x	x	
Serena \ C24 \ All Year	IPDM E/R	x	x	x	
Serena \ C24 \ All Year	Air pressure monitor	x	x	x	
Serena \ C24 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C24 \ All Year	DIU	x	x	x	
Serena \ C24 \ All Year	Auto slide door	x	x	x	
Serena \ C24 \ All Year	Auto drive position	x	x	x	
Serena \ C24 \ All Year	All mode AWD/4WD	x	x	x	
Serena \ C24 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Serena \ C24 \ All Year	Sonar	x	x	x	
Serena \ C24 \ All Year	Lane camera	x	x	x	
Serena \ C24 \ All Year	Adaptive light	x	x	x	
Serena \ C24 \ All Year	AVM		x	x	
Serena \ C24 \ All Year	Head lamp levelizer	x	x	x	
Serena \ C24 \ All Year	Difference lock	x	x	x	
Serena \ C24 \ All Year	Nats immu	x	x		
Serena \ C24 \ All Year	Smart entrance	x	x		
Serena \ C24 \ All Year	Air levelizer	x	x	x	
Serena \ C24 \ All Year	Rearview camera			x	
Serena \ C24 \ All Year	S/blind camera			x	
Serena \ C24 \ All Year	Motor assist	x	x	x	
Serena \ C25 \ 2005-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2005-5~	BCM	x	x		
Serena \ C25 \ 2005-5~	Transmission	x	x	x	
Serena \ C25 \ 2005-5~	Multi AV	x	x	x	0280
Serena \ C25 \ 2005-5~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2005-5~	IPDM E/R	x	x	x	
Serena \ C25 \ 2005-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2005-5~	Auto slide door	x	x	x	
Serena \ C25 \ 2005-5~	Auto slide door right	x	x	x	
Serena \ C25 \ 2005-5~	Engine	x	x	x	
Serena \ C25 \ 2005-5~	ABS	x	x	x	
Serena \ C25 \ 2005-5~	Air bag	x	x	x	
Serena \ C25 \ 2005-5~	Head lamp levelizer	x	x	x	

Serena \ C25 \ 2005-5~	Rearview camera			x	
Serena \ C25 \ 2005-5~	S/blind camera			x	
Serena \ C25 \ 2005-5~	Motor assist	x	x	x	
Serena \ C25 \ 2006-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2006-6~	BCM	x	x		
Serena \ C25 \ 2006-6~	Transmission	x	x	x	
Serena \ C25 \ 2006-6~	Multi AV	x	x	x	0280
Serena \ C25 \ 2006-6~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2006-6~	IPDM E/R	x	x	x	
Serena \ C25 \ 2006-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2006-6~	Auto slide door	x	x	x	
Serena \ C25 \ 2006-6~	Auto slide door right	x	x	x	
Serena \ C25 \ 2006-6~	Engine	x	x	x	
Serena \ C25 \ 2006-6~	ABS	x	x	x	
Serena \ C25 \ 2006-6~	Air bag	x	x	x	
Serena \ C25 \ 2006-6~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2006-6~	Rearview camera			x	
Serena \ C25 \ 2006-6~	S/blind camera			x	
Serena \ C25 \ 2006-6~	Motor assist	x	x	x	
Serena \ C25 \ 2007-10~	Meter/M&A		x	x	
Serena \ C25 \ 2007-10~	BCM	x	x		
Serena \ C25 \ 2007-10~	Transmission	x	x	x	
Serena \ C25 \ 2007-10~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2007-10~	IPDM E/R	x	x	x	
Serena \ C25 \ 2007-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2007-10~	Auto slide door	x	x	x	
Serena \ C25 \ 2007-10~	Adaptive light	x	x	x	
Serena \ C25 \ 2007-10~	Auto slide door right	x	x	x	
Serena \ C25 \ 2007-10~	Engine	x	x	x	
Serena \ C25 \ 2007-10~	ABS	x	x	x	
Serena \ C25 \ 2007-10~	Air bag	x	x	x	
Serena \ C25 \ 2007-10~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2007-10~	Sonar	x	x	x	
Serena \ C25 \ 2007-10~	Rearview camera			x	
Serena \ C25 \ 2007-10~	S/blind camera			x	
Serena \ C25 \ 2007-10~	Motor assist	x	x	x	
Serena \ C25 \ 2007-11~	Meter/M&A		x	x	

Serena \ C25 \ 2007-11~	BCM	x	x		
Serena \ C25 \ 2007-11~	Transmission	x	x	x	
Serena \ C25 \ 2007-11~	Multi AV	x	x	x	
Serena \ C25 \ 2007-11~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2007-11~	IPDM E/R	x	x	x	
Serena \ C25 \ 2007-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2007-11~	Auto slide door	x	x	x	
Serena \ C25 \ 2007-11~	Adaptive light	x	x	x	
Serena \ C25 \ 2007-11~	Auto slide door right	x	x	x	
Serena \ C25 \ 2007-11~	Engine	x	x	x	
Serena \ C25 \ 2007-11~	ABS	x	x	x	
Serena \ C25 \ 2007-11~	Air bag	x	x	x	
Serena \ C25 \ 2007-11~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2007-11~	Sonar	x	x	x	
Serena \ C25 \ 2007-11~	Rearview camera			x	
Serena \ C25 \ 2007-11~	S/blind camera			x	
Serena \ C25 \ 2007-11~	Motor assist	x	x	x	
Serena \ C25 \ 2007-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2007-1~	BCM	x	x		
Serena \ C25 \ 2007-1~	Transmission	x	x	x	
Serena \ C25 \ 2007-1~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2007-1~	IPDM E/R	x	x	x	
Serena \ C25 \ 2007-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2007-1~	Auto slide door	x	x	x	
Serena \ C25 \ 2007-1~	Auto slide door right	x	x	x	
Serena \ C25 \ 2007-1~	Engine	x	x	x	
Serena \ C25 \ 2007-1~	ABS	x	x	x	
Serena \ C25 \ 2007-1~	Air bag	x	x	x	
Serena \ C25 \ 2007-1~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2007-1~	Rearview camera			x	
Serena \ C25 \ 2007-1~	S/blind camera			x	
Serena \ C25 \ 2007-1~	Motor assist	x	x	x	
Serena \ C25 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2007-6~	BCM	x	x		
Serena \ C25 \ 2007-6~	Transmission	x	x	x	
Serena \ C25 \ 2007-6~	Multi AV	x	x	x	0280
Serena \ C25 \ 2007-6~	EPS/DAST 3	x	x	x	

Serena \ C25 \ 2007-6~	IPDM E/R	x	x	x	
Serena \ C25 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2007-6~	Auto slide door	x	x	x	
Serena \ C25 \ 2007-6~	Auto slide door right	x	x	x	
Serena \ C25 \ 2007-6~	Engine	x	x	x	
Serena \ C25 \ 2007-6~	ABS	x	x	x	
Serena \ C25 \ 2007-6~	Air bag	x	x	x	
Serena \ C25 \ 2007-6~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2007-6~	Rearview camera			x	
Serena \ C25 \ 2007-6~	S/blind camera			x	
Serena \ C25 \ 2007-6~	Motor assist	x	x	x	
Serena \ C25 \ 2008-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C25 \ 2008-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2008-11~	BCM	x	x		
Serena \ C25 \ 2008-11~	Transmission	x	x	x	
Serena \ C25 \ 2008-11~	Multi AV	x	x	x	
Serena \ C25 \ 2008-11~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2008-11~	IPDM E/R	x	x	x	
Serena \ C25 \ 2008-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2008-11~	Auto slide door	x	x	x	
Serena \ C25 \ 2008-11~	Adaptive light	x	x	x	
Serena \ C25 \ 2008-11~	Auto slide door right	x	x	x	
Serena \ C25 \ 2008-11~	ABS	x	x	x	
Serena \ C25 \ 2008-11~	Air bag	x	x	x	
Serena \ C25 \ 2008-11~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2008-11~	Sonar	x	x	x	
Serena \ C25 \ 2008-11~	Rearview camera			x	
Serena \ C25 \ 2008-11~	S/blind camera			x	
Serena \ C25 \ 2008-11~	Motor assist	x	x	x	
Serena \ C25 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C25 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Serena \ C25 \ 2009-11~	BCM	x	x		
Serena \ C25 \ 2009-11~	Transmission	x	x	x	
Serena \ C25 \ 2009-11~	Multi AV	x	x	x	
Serena \ C25 \ 2009-11~	EPS/DAST 3	x	x	x	

Serena \ C25 \ 2009-11~	IPDM E/R	x	x	x	
Serena \ C25 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2009-11~	Auto slide door	x	x	x	
Serena \ C25 \ 2009-11~	Adaptive light	x	x	x	
Serena \ C25 \ 2009-11~	Auto slide door right	x	x	x	
Serena \ C25 \ 2009-11~	ABS	x	x	x	
Serena \ C25 \ 2009-11~	Air bag	x	x	x	
Serena \ C25 \ 2009-11~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2009-11~	Sonar	x	x	x	
Serena \ C25 \ 2009-11~	Rearview camera			x	
Serena \ C25 \ 2009-11~	S/blind camera			x	
Serena \ C25 \ 2009-11~	Motor assist	x	x	x	
Serena \ C25 \ 2009-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C25 \ 2009-12~	Meter/M&A		x	x	
Serena \ C25 \ 2009-12~	BCM	x	x		
Serena \ C25 \ 2009-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Serena \ C25 \ 2009-12~	Multi AV	x	x	x	
Serena \ C25 \ 2009-12~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2009-12~	IPDM E/R	x	x	x	
Serena \ C25 \ 2009-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2009-12~	Auto slide door	x	x	x	
Serena \ C25 \ 2009-12~	Adaptive light	x	x	x	
Serena \ C25 \ 2009-12~	Auto slide door right	x	x	x	
Serena \ C25 \ 2009-12~	ABS	x	x	x	
Serena \ C25 \ 2009-12~	Air bag	x	x	x	
Serena \ C25 \ 2009-12~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2009-12~	Sonar	x	x	x	
Serena \ C25 \ 2009-12~	Rearview camera			x	
Serena \ C25 \ 2009-12~	S/blind camera			x	
Serena \ C25 \ 2009-12~	Motor assist	x	x	x	
Serena \ C25 \ 2009-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C25 \ 2009-7~	Meter/M&A		x	x	
Serena \ C25 \ 2009-7~	BCM	x	x		
Serena \ C25 \ 2009-7~	Transmission	x	x	x	
Serena \ C25 \ 2009-7~	Multi AV	x	x	x	

Serena \ C25 \ 2009-7~	EPS/DAST 3	x	x	x	
Serena \ C25 \ 2009-7~	IPDM E/R	x	x	x	
Serena \ C25 \ 2009-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Serena \ C25 \ 2009-7~	Auto slide door	x	x	x	
Serena \ C25 \ 2009-7~	Adaptive light	x	x	x	
Serena \ C25 \ 2009-7~	Auto slide door right	x	x	x	
Serena \ C25 \ 2009-7~	ABS	x	x	x	
Serena \ C25 \ 2009-7~	Air bag	x	x	x	
Serena \ C25 \ 2009-7~	Head lamp levelizer	x	x	x	
Serena \ C25 \ 2009-7~	Sonar	x	x	x	
Serena \ C25 \ 2009-7~	Rearview camera			x	
Serena \ C25 \ 2009-7~	S/blind camera			x	
Serena \ C25 \ 2009-7~	Motor assist	x	x	x	
Serena \ C26 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2010-11~	ABS	x	x	x	
Serena \ C26 \ 2010-11~	Meter/M&A		x	x	
Serena \ C26 \ 2010-11~	BCM		x		
Serena \ C26 \ 2010-11~	Air bag	x	x	x	
Serena \ C26 \ 2010-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2010-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Serena \ C26 \ 2010-11~	Multi AV		x	x	
Serena \ C26 \ 2010-11~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2010-11~	IPDM E/R		x	x	
Serena \ C26 \ 2010-11~	Auto slide door	x	x	x	
Serena \ C26 \ 2010-11~	Auto drive position		x	x	
Serena \ C26 \ 2010-11~	All mode AWD/4WD		x	x	
Serena \ C26 \ 2010-11~	Adaptive light	x	x	x	
Serena \ C26 \ 2010-11~	Auto slide door right	x	x	x	
Serena \ C26 \ 2010-11~	Auto back door		x	x	
Serena \ C26 \ 2010-11~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2010-11~	Sonar	x	x	x	
Serena \ C26 \ 2010-11~	Rearview camera			x	
Serena \ C26 \ 2010-11~	S/blind camera			x	
Serena \ C26 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2010-12~	ABS	x	x	x	
Serena \ C26 \ 2010-12~	Meter/M&A		x	x	

Serena \ C26 \ 2010-12~	BCM		x		
Serena \ C26 \ 2010-12~	Air bag	x	x	x	
Serena \ C26 \ 2010-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2010-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Serena \ C26 \ 2010-12~	Multi AV		x	x	
Serena \ C26 \ 2010-12~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2010-12~	IPDM E/R		x	x	
Serena \ C26 \ 2010-12~	Auto slide door	x	x	x	
Serena \ C26 \ 2010-12~	All mode AWD/4WD		x	x	
Serena \ C26 \ 2010-12~	Adaptive light	x	x	x	
Serena \ C26 \ 2010-12~	Auto slide door right	x	x	x	
Serena \ C26 \ 2010-12~	Auto back door		x	x	
Serena \ C26 \ 2010-12~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2010-12~	Sonar	x	x	x	
Serena \ C26 \ 2010-12~	Rearview camera			x	
Serena \ C26 \ 2010-12~	S/blind camera			x	
Serena \ C26 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2012-12~	ABS	x	x	x	
Serena \ C26 \ 2012-12~	Meter/M&A		x	x	
Serena \ C26 \ 2012-12~	BCM		x		
Serena \ C26 \ 2012-12~	Air bag	x	x	x	
Serena \ C26 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2012-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Serena \ C26 \ 2012-12~	Multi AV	x	x	x	0280
Serena \ C26 \ 2012-12~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2012-12~	IPDM E/R		x	x	
Serena \ C26 \ 2012-12~	Auto slide door	x	x	x	
Serena \ C26 \ 2012-12~	Auto slide door right	x	x	x	
Serena \ C26 \ 2012-12~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2012-12~	Sonar	x	x	x	
Serena \ C26 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2012-6~	ABS	x	x	x	
Serena \ C26 \ 2012-6~	Meter/M&A		x	x	
Serena \ C26 \ 2012-6~	BCM		x		
Serena \ C26 \ 2012-6~	Air bag	x	x	x	

Serena \ C26 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2012-6~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Serena \ C26 \ 2012-6~	Multi AV	x	x	x	0280
Serena \ C26 \ 2012-6~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2012-6~	IPDM E/R		x	x	
Serena \ C26 \ 2012-6~	Auto slide door	x	x	x	
Serena \ C26 \ 2012-6~	Auto slide door right	x	x	x	
Serena \ C26 \ 2012-6~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2012-6~	Sonar	x	x	x	
Serena \ C26 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2012-7~	ABS	x	x	x	
Serena \ C26 \ 2012-7~	Meter/M&A		x	x	
Serena \ C26 \ 2012-7~	BCM		x		
Serena \ C26 \ 2012-7~	Air bag	x	x	x	
Serena \ C26 \ 2012-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2012-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Serena \ C26 \ 2012-7~	Multi AV		x	x	
Serena \ C26 \ 2012-7~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2012-7~	IPDM E/R		x	x	
Serena \ C26 \ 2012-7~	Auto slide door	x	x	x	
Serena \ C26 \ 2012-7~	Auto slide door right	x	x	x	
Serena \ C26 \ 2012-7~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2012-7~	Sonar	x	x	x	
Serena \ C26 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2013-11~	ABS	x	x	x	
Serena \ C26 \ 2013-11~	Meter/M&A		x	x	
Serena \ C26 \ 2013-11~	BCM		x		
Serena \ C26 \ 2013-11~	Air bag	x	x	x	
Serena \ C26 \ 2013-11~	ICC/ADAS	x	x	x	
Serena \ C26 \ 2013-11~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2013-11~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Serena \ C26 \ 2013-11~	Multi AV		x	x	
Serena \ C26 \ 2013-11~	EPS/DAST 3	x	x	x	

Serena \ C26 \ 2013-11~	IPDM E/R		x	x	
Serena \ C26 \ 2013-11~	Auto slide door	x	x	x	
Serena \ C26 \ 2013-11~	Sonar		x	x	
Serena \ C26 \ 2013-11~	Lane camera		x	x	
Serena \ C26 \ 2013-11~	Adaptive light	x	x	x	
Serena \ C26 \ 2013-11~	Auto slide door right	x	x	x	
Serena \ C26 \ 2013-11~	AVM		x	x	
Serena \ C26 \ 2013-11~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2013-11~	BSW/buzzer		x	x	
Serena \ C26 \ 2014-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2014-7~	ABS	x	x	x	
Serena \ C26 \ 2014-7~	Meter/M&A		x	x	
Serena \ C26 \ 2014-7~	BCM		x		
Serena \ C26 \ 2014-7~	Air bag	x	x	x	
Serena \ C26 \ 2014-7~	ICC/ADAS	x	x	x	
Serena \ C26 \ 2014-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2014-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Serena \ C26 \ 2014-7~	Multi AV	x	x	x	0280
Serena \ C26 \ 2014-7~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2014-7~	IPDM E/R		x	x	
Serena \ C26 \ 2014-7~	Auto slide door	x	x	x	
Serena \ C26 \ 2014-7~	Sonar	x	x	x	
Serena \ C26 \ 2014-7~	Lane camera	x	x	x	
Serena \ C26 \ 2014-7~	Auto slide door right	x	x	x	
Serena \ C26 \ 2014-7~	BSW/buzzer		x	x	
Serena \ C26 \ 2014-7~	AVM		x	x	
Serena \ C26 \ 2014-7~	PMAS		x	x	
Serena \ C26 \ 2014-7~	Head lamp levelizer	x	x	x	
Serena \ C26 \ 2015-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Serena \ C26 \ 2015-1~	ABS	x	x	x	
Serena \ C26 \ 2015-1~	Meter/M&A		x	x	
Serena \ C26 \ 2015-1~	BCM		x		
Serena \ C26 \ 2015-1~	Air bag	x	x	x	
Serena \ C26 \ 2015-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Serena \ C26 \ 2015-1~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085

Serena \ C26 \ 2015-1~	EPS/DAST 3	x	x	x	
Serena \ C26 \ 2015-1~	IPDM E/R		x	x	
Serena \ C26 \ 2015-1~	Auto slide door	x	x	x	
Serena \ C26 \ 2015-1~	Lane camera		x	x	
Serena \ C26 \ 2015-1~	Auto slide door right	x	x	x	
Serena \ C26 \ 2015-1~	BSW/buzzer		x	x	
Serena \ C26 \ 2015-1~	Head lamp levelizer	x	x	x	
Silvia \ S15 \ 2000-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Silvia \ S15 \ 2000-1~	ABS	x	x	x	0003, 0092, 0264
Silvia \ S15 \ 2000-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Silvia \ S15 \ 2000-1~	BCM	x	x		
Silvia \ S15 \ 2000-1~	Air bag	x	x	x	
Silvia \ S15 \ 2000-1~	ICC/ADAS	x	x	x	
Silvia \ S15 \ 2000-1~	HVAC	x	x	x	
Silvia \ S15 \ 2000-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Silvia \ S15 \ 2000-1~	Multi AV	x	x	x	0280
Silvia \ S15 \ 2000-1~	EPS/DAST 3	x	x	x	
Silvia \ S15 \ 2000-1~	IPDM E/R	x	x	x	
Silvia \ S15 \ 2000-1~	Air pressure monitor	x	x	x	
Silvia \ S15 \ 2000-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Silvia \ S15 \ 2000-1~	DIU	x	x	x	
Silvia \ S15 \ 2000-1~	Auto slide door	x	x	x	
Silvia \ S15 \ 2000-1~	Auto drive position	x	x	x	
Silvia \ S15 \ 2000-1~	All mode AWD/4WD	x	x	x	
Silvia \ S15 \ 2000-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Silvia \ S15 \ 2000-1~	Sonar	x	x	x	
Silvia \ S15 \ 2000-1~	Lane camera	x	x	x	
Silvia \ S15 \ 2000-1~	Adaptive light	x	x	x	
Silvia \ S15 \ 2000-1~	AVM		x	x	
Silvia \ S15 \ 2000-1~	Head lamp levelizer	x	x	x	
Silvia \ S15 \ 2000-1~	Difference lock	x	x	x	
Silvia \ S15 \ 2000-1~	Nats immu	x	x		
Silvia \ S15 \ 2000-1~	Smart entrance	x	x		
Silvia \ S15 \ 2000-1~	Air levelizer	x	x	x	
Silvia \ S15 \ 2000-1~	Rearview camera			x	
Silvia \ S15 \ 2000-1~	S/blind camera			x	
Silvia \ S15 \ 2000-1~	Motor assist	x	x	x	

Silvia \ S15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Silvia \ S15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Silvia \ S15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Silvia \ S15 \ All Year	BCM	x	x		
Silvia \ S15 \ All Year	Air bag	x	x	x	
Silvia \ S15 \ All Year	ICC/ADAS	x	x	x	
Silvia \ S15 \ All Year	HVAC	x	x	x	
Silvia \ S15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Silvia \ S15 \ All Year	Multi AV	x	x	x	0280
Silvia \ S15 \ All Year	EPS/DAST 3	x	x	x	
Silvia \ S15 \ All Year	IPDM E/R	x	x	x	
Silvia \ S15 \ All Year	Air pressure monitor	x	x	x	
Silvia \ S15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Silvia \ S15 \ All Year	DIU	x	x	x	
Silvia \ S15 \ All Year	Auto slide door	x	x	x	
Silvia \ S15 \ All Year	Auto drive position	x	x	x	
Silvia \ S15 \ All Year	All mode AWD/4WD	x	x	x	
Silvia \ S15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Silvia \ S15 \ All Year	Sonar	x	x	x	
Silvia \ S15 \ All Year	Lane camera	x	x	x	
Silvia \ S15 \ All Year	Adaptive light	x	x	x	
Silvia \ S15 \ All Year	AVM		x	x	
Silvia \ S15 \ All Year	Head lamp levelizer	x	x	x	
Silvia \ S15 \ All Year	Difference lock	x	x	x	
Silvia \ S15 \ All Year	Nats immu	x	x		
Silvia \ S15 \ All Year	Smart entrance	x	x		
Silvia \ S15 \ All Year	Air levelizer	x	x	x	
Silvia \ S15 \ All Year	Rearview camera			x	
Silvia \ S15 \ All Year	S/blind camera			x	
Silvia \ S15 \ All Year	Motor assist	x	x	x	
Skyline coupe \ CV35 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV35 \ All Year	ABS	x	x	x	0003, 0092, 0264
Skyline coupe \ CV35 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Skyline coupe \ CV35 \ All Year	BCM	x	x		
Skyline coupe \ CV35 \ All Year	Air bag	x	x	x	
Skyline coupe \ CV35 \ All Year	ICC/ADAS	x	x	x	
Skyline coupe \ CV35 \ All Year	HVAC	x	x	x	

Skyline coupe \ CV35 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Skyline coupe \ CV35 \ All Year	Multi AV	x	x	x	0280
Skyline coupe \ CV35 \ All Year	EPS/DAST 3	x	x	x	
Skyline coupe \ CV35 \ All Year	IPDM E/R	x	x	x	
Skyline coupe \ CV35 \ All Year	Air pressure monitor	x	x	x	
Skyline coupe \ CV35 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Skyline coupe \ CV35 \ All Year	DIU	x	x	x	
Skyline coupe \ CV35 \ All Year	Auto slide door	x	x	x	
Skyline coupe \ CV35 \ All Year	Auto drive position	x	x	x	
Skyline coupe \ CV35 \ All Year	All mode AWD/4WD	x	x	x	
Skyline coupe \ CV35 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV35 \ All Year	Sonar	x	x	x	
Skyline coupe \ CV35 \ All Year	Lane camera	x	x	x	
Skyline coupe \ CV35 \ All Year	Adaptive light	x	x	x	
Skyline coupe \ CV35 \ All Year	AVM		x	x	
Skyline coupe \ CV35 \ All Year	Head lamp levelizer	x	x	x	
Skyline coupe \ CV35 \ All Year	Difference lock	x	x	x	
Skyline coupe \ CV35 \ All Year	Nats immu	x	x		
Skyline coupe \ CV35 \ All Year	Smart entrance	x	x		
Skyline coupe \ CV35 \ All Year	Air levelizer	x	x	x	
Skyline coupe \ CV35 \ All Year	Rearview camera			x	
Skyline coupe \ CV35 \ All Year	S/blind camera			x	
Skyline coupe \ CV35 \ All Year	Motor assist	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2007-8~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2007-8~	BCM		x		
Skyline coupe \ CV36 \ 2007-8~	ICC/ADAS	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Transmission	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2007-8~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2007-8~	Pop up hood	x	x	x	

Skyline coupe \ CV36 \ 2008-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2008-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2008-11~	BCM		x		
Skyline coupe \ CV36 \ 2008-11~	ICC/ADAS	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2008-11~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2008-11~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	All mode AWD/4WD	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2008-11~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2009-12~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2009-12~	BCM		x		
Skyline coupe \ CV36 \ 2009-12~	ICC/ADAS	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2009-12~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2009-12~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	All mode AWD/4WD	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2009-12~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2010-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2010-11~	BCM		x		
Skyline coupe \ CV36 \ 2010-11~	ICC/ADAS	x	x	x	

Skyline coupe \ CV36 \ 2010-11~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2010-11~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2010-11~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	All mode AWD/4WD	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2010-11~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2011-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2011-11~	BCM		x		
Skyline coupe \ CV36 \ 2011-11~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2011-11~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2011-11~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2011-11~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2013-2~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2013-2~	BCM		x		
Skyline coupe \ CV36 \ 2013-2~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2013-2~	Multi AV		x	x	
Skyline coupe \ CV36 \ 2013-2~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2013-2~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Adaptive light	x	x	x	

Skyline coupe \ CV36 \ 2013-2~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Sonar	x	x	x	
Skyline coupe \ CV36 \ 2013-2~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2013-9~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2013-9~	BCM		x		
Skyline coupe \ CV36 \ 2013-9~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	ICC/ADAS	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2013-9~	Multi AV	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2013-9~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	ABS	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Sonar	x	x	x	
Skyline coupe \ CV36 \ 2013-9~	Pop up hood	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline coupe \ CV36 \ 2014-6~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline coupe \ CV36 \ 2014-6~	BCM		x		
Skyline coupe \ CV36 \ 2014-6~	Air bag	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Transmission	x	x	x	0059
Skyline coupe \ CV36 \ 2014-6~	Multi AV		x	x	
Skyline coupe \ CV36 \ 2014-6~	EPS/DAST 3	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	IPDM E/R		x	x	
Skyline coupe \ CV36 \ 2014-6~	Laser/radar	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Precrash seatbelt	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Auto drive position	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Sonar	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Adaptive light	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	4WAS(front)	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	E-SUS		x	x	
Skyline coupe \ CV36 \ 2014-6~	AVM		x	x	
Skyline coupe \ CV36 \ 2014-6~	ABS	x	x	x	

Skyline coupe \ CV36 \ 2014-6~	Head lamp levelizer	x	x	x	
Skyline coupe \ CV36 \ 2014-6~	Pop up hood	x	x	x	
Skyline GT-R \ R34 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline GT-R \ R34 \ All Year	ABS	x	x	x	0003, 0092, 0264
Skyline GT-R \ R34 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Skyline GT-R \ R34 \ All Year	BCM	x	x		
Skyline GT-R \ R34 \ All Year	Air bag	x	x	x	
Skyline GT-R \ R34 \ All Year	ICC/ADAS	x	x	x	
Skyline GT-R \ R34 \ All Year	HVAC	x	x	x	
Skyline GT-R \ R34 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Skyline GT-R \ R34 \ All Year	Multi AV	x	x	x	0280
Skyline GT-R \ R34 \ All Year	EPS/DAST 3	x	x	x	
Skyline GT-R \ R34 \ All Year	IPDM E/R	x	x	x	
Skyline GT-R \ R34 \ All Year	Air pressure monitor	x	x	x	
Skyline GT-R \ R34 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Skyline GT-R \ R34 \ All Year	DIU	x	x	x	
Skyline GT-R \ R34 \ All Year	Auto slide door	x	x	x	
Skyline GT-R \ R34 \ All Year	Auto drive position	x	x	x	
Skyline GT-R \ R34 \ All Year	All mode AWD/4WD	x	x	x	
Skyline GT-R \ R34 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline GT-R \ R34 \ All Year	Sonar	x	x	x	
Skyline GT-R \ R34 \ All Year	Lane camera	x	x	x	
Skyline GT-R \ R34 \ All Year	Adaptive light	x	x	x	
Skyline GT-R \ R34 \ All Year	AVM		x	x	
Skyline GT-R \ R34 \ All Year	Head lamp levelizer	x	x	x	
Skyline GT-R \ R34 \ All Year	Difference lock	x	x	x	
Skyline GT-R \ R34 \ All Year	Nats immu	x	x		
Skyline GT-R \ R34 \ All Year	Smart entrance	x	x		
Skyline GT-R \ R34 \ All Year	Air levelizer	x	x	x	
Skyline GT-R \ R34 \ All Year	Rearview camera			x	
Skyline GT-R \ R34 \ All Year	S/blind camera			x	
Skyline GT-R \ R34 \ All Year	Motor assist	x	x	x	
Skyline \ R34 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ R34 \ All Year	ABS	x	x	x	0003, 0092, 0264
Skyline \ R34 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Skyline \ R34 \ All Year	BCM	x	x		
Skyline \ R34 \ All Year	Air bag	x	x	x	

Skyline \ R34 \ All Year	ICC/ADAS	x	x	x	
Skyline \ R34 \ All Year	HVAC	x	x	x	
Skyline \ R34 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Skyline \ R34 \ All Year	Multi AV	x	x	x	0280
Skyline \ R34 \ All Year	EPS/DAST 3	x	x	x	
Skyline \ R34 \ All Year	IPDM E/R	x	x	x	
Skyline \ R34 \ All Year	Air pressure monitor	x	x	x	
Skyline \ R34 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Skyline \ R34 \ All Year	DIU	x	x	x	
Skyline \ R34 \ All Year	Auto slide door	x	x	x	
Skyline \ R34 \ All Year	Auto drive position	x	x	x	
Skyline \ R34 \ All Year	All mode AWD/4WD	x	x	x	
Skyline \ R34 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ R34 \ All Year	Sonar	x	x	x	
Skyline \ R34 \ All Year	Lane camera	x	x	x	
Skyline \ R34 \ All Year	Adaptive light	x	x	x	
Skyline \ R34 \ All Year	AVM		x	x	
Skyline \ R34 \ All Year	Head lamp levelizer	x	x	x	
Skyline \ R34 \ All Year	Difference lock	x	x	x	
Skyline \ R34 \ All Year	Nats immu	x	x		
Skyline \ R34 \ All Year	Smart entrance	x	x		
Skyline \ R34 \ All Year	Air levelizer	x	x	x	
Skyline \ R34 \ All Year	Rearview camera			x	
Skyline \ R34 \ All Year	S/blind camera			x	
Skyline \ R34 \ All Year	Motor assist	x	x	x	
Skyline \ V35 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V35 \ All Year	ABS	x	x	x	0003, 0092, 0264
Skyline \ V35 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Skyline \ V35 \ All Year	BCM	x	x		
Skyline \ V35 \ All Year	Air bag	x	x	x	
Skyline \ V35 \ All Year	ICC/ADAS	x	x	x	
Skyline \ V35 \ All Year	HVAC	x	x	x	
Skyline \ V35 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Skyline \ V35 \ All Year	Multi AV	x	x	x	0280
Skyline \ V35 \ All Year	EPS/DAST 3	x	x	x	
Skyline \ V35 \ All Year	IPDM E/R	x	x	x	
Skyline \ V35 \ All Year	Air pressure monitor	x	x	x	

Skyline \ V35 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Skyline \ V35 \ All Year	DIU	x	x	x	
Skyline \ V35 \ All Year	Auto slide door	x	x	x	
Skyline \ V35 \ All Year	Auto drive position	x	x	x	
Skyline \ V35 \ All Year	All mode AWD/4WD	x	x	x	
Skyline \ V35 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V35 \ All Year	Sonar	x	x	x	
Skyline \ V35 \ All Year	Lane camera	x	x	x	
Skyline \ V35 \ All Year	Adaptive light	x	x	x	
Skyline \ V35 \ All Year	AVM		x	x	
Skyline \ V35 \ All Year	Head lamp levelizer	x	x	x	
Skyline \ V35 \ All Year	Difference lock	x	x	x	
Skyline \ V35 \ All Year	Nats immu	x	x		
Skyline \ V35 \ All Year	Smart entrance	x	x		
Skyline \ V35 \ All Year	Air levelizer	x	x	x	
Skyline \ V35 \ All Year	Rearview camera			x	
Skyline \ V35 \ All Year	S/blind camera			x	
Skyline \ V35 \ All Year	Motor assist	x	x	x	
Skyline \ V36 \ 2006-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2006-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2006-11~	BCM		x		
Skyline \ V36 \ 2006-11~	ICC/ADAS	x	x	x	
Skyline \ V36 \ 2006-11~	Transmission	x	x	x	
Skyline \ V36 \ 2006-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2006-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2006-11~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2006-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2006-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2006-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2006-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2006-11~	ABS	x	x	x	
Skyline \ V36 \ 2006-11~	Air bag	x	x	x	
Skyline \ V36 \ 2006-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2006-11~	All mode AWD/4WD	x	x	x	
Skyline \ V36 \ 2007-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2007-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2007-11~	BCM		x		

Skyline \ V36 \ 2007-11~	ICC/ADAS	x	x	x	
Skyline \ V36 \ 2007-11~	Transmission	x	x	x	0059
Skyline \ V36 \ 2007-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2007-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2007-11~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2007-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2007-11~	All mode AWD/4WD	x	x	x	
Skyline \ V36 \ 2007-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2007-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2007-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2007-11~	ABS	x	x	x	
Skyline \ V36 \ 2007-11~	Air bag	x	x	x	
Skyline \ V36 \ 2007-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2008-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2008-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2008-11~	BCM		x		
Skyline \ V36 \ 2008-11~	ICC/ADAS	x	x	x	
Skyline \ V36 \ 2008-11~	Transmission	x	x	x	0059
Skyline \ V36 \ 2008-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2008-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2008-11~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2008-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2008-11~	All mode AWD/4WD	x	x	x	0245, 0311
Skyline \ V36 \ 2008-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2008-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2008-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2008-11~	ABS	x	x	x	
Skyline \ V36 \ 2008-11~	Air bag	x	x	x	
Skyline \ V36 \ 2008-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2009-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2009-12~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2009-12~	BCM		x		
Skyline \ V36 \ 2009-12~	ICC/ADAS	x	x	x	
Skyline \ V36 \ 2009-12~	Transmission	x	x	x	0059
Skyline \ V36 \ 2009-12~	Multi AV	x	x	x	
Skyline \ V36 \ 2009-12~	IPDM E/R		x	x	
Skyline \ V36 \ 2009-12~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2009-12~	Auto drive position	x	x	x	
Skyline \ V36 \ 2009-12~	All mode AWD/4WD	x	x	x	0245, 0311

Skyline \ V36 \ 2009-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2009-12~	Adaptive light	x	x	x	
Skyline \ V36 \ 2009-12~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2009-12~	ABS	x	x	x	
Skyline \ V36 \ 2009-12~	Air bag	x	x	x	
Skyline \ V36 \ 2009-12~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2009-12~	Pop up hood	x	x	x	
Skyline \ V36 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2010-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2010-11~	BCM		x		
Skyline \ V36 \ 2010-11~	ICC/ADAS	x	x	x	
Skyline \ V36 \ 2010-11~	Transmission	x	x	x	0059
Skyline \ V36 \ 2010-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2010-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2010-11~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2010-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2010-11~	All mode AWD/4WD	x	x	x	0245, 0311
Skyline \ V36 \ 2010-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2010-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2010-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2010-11~	ABS	x	x	x	
Skyline \ V36 \ 2010-11~	Air bag	x	x	x	
Skyline \ V36 \ 2010-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2010-11~	Pop up hood	x	x	x	
Skyline \ V36 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2011-12~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2011-12~	BCM		x		
Skyline \ V36 \ 2011-12~	ICC/ADAS		x	x	
Skyline \ V36 \ 2011-12~	Transmission	x	x	x	0059
Skyline \ V36 \ 2011-12~	Multi AV	x	x	x	
Skyline \ V36 \ 2011-12~	IPDM E/R		x	x	
Skyline \ V36 \ 2011-12~	Precrash seatbelt	x	x	x	
Skyline \ V36 \ 2011-12~	Auto drive position	x	x	x	
Skyline \ V36 \ 2011-12~	All mode AWD/4WD		x	x	
Skyline \ V36 \ 2011-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2011-12~	Adaptive light	x	x	x	
Skyline \ V36 \ 2011-12~	CAN gateway		x		
Skyline \ V36 \ 2011-12~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2011-12~	ABS	x	x	x	

Skyline \ V36 \ 2011-12~	Air bag	x	x	x	
Skyline \ V36 \ 2011-12~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2012-11~	Meter/M&A		x	x	
Skyline \ V36 \ 2012-11~	BCM		x		
Skyline \ V36 \ 2012-11~	Air bag	x	x	x	
Skyline \ V36 \ 2012-11~	Transmission	x	x	x	0059
Skyline \ V36 \ 2012-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2012-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2012-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2012-11~	All mode AWD/4WD		x	x	
Skyline \ V36 \ 2012-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2012-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2012-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2012-11~	ABS	x	x	x	
Skyline \ V36 \ 2012-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V36 \ 2013-11~	Meter/M&A	x	x	x	0143, 0197, 0331
Skyline \ V36 \ 2013-11~	BCM		x		
Skyline \ V36 \ 2013-11~	Air bag	x	x	x	
Skyline \ V36 \ 2013-11~	Transmission	x	x	x	0059
Skyline \ V36 \ 2013-11~	Multi AV	x	x	x	
Skyline \ V36 \ 2013-11~	IPDM E/R		x	x	
Skyline \ V36 \ 2013-11~	Preocrash seatbelt	x	x	x	
Skyline \ V36 \ 2013-11~	Auto drive position	x	x	x	
Skyline \ V36 \ 2013-11~	All mode AWD/4WD		x	x	
Skyline \ V36 \ 2013-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V36 \ 2013-11~	Adaptive light	x	x	x	
Skyline \ V36 \ 2013-11~	4WAS(front)	x	x	x	
Skyline \ V36 \ 2013-11~	ABS	x	x	x	
Skyline \ V36 \ 2013-11~	Head lamp levelizer	x	x	x	
Skyline \ V36 \ 2013-11~	Pop up hood	x	x	x	
Skyline \ V37 \ 2014-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V37 \ 2014-10~	ABS		x	x	
Skyline \ V37 \ 2014-10~	Meter/M&A		x	x	
Skyline \ V37 \ 2014-10~	BCM		x		
Skyline \ V37 \ 2014-10~	Air bag		x	x	
Skyline \ V37 \ 2014-10~	ICC/ADAS		x	x	

Skyline \ V37 \ 2014-10~	HVAC		x	x	
Skyline \ V37 \ 2014-10~	Transmission		x	x	0059
Skyline \ V37 \ 2014-10~	Multi AV		x	x	
Skyline \ V37 \ 2014-10~	EPS/DAST 3		x	x	
Skyline \ V37 \ 2014-10~	IPDM E/R		x	x	
Skyline \ V37 \ 2014-10~	Air pressure monitor		x	x	
Skyline \ V37 \ 2014-10~	Laser/radar	x	x	x	
Skyline \ V37 \ 2014-10~	Preocrash seatbelt		x	x	
Skyline \ V37 \ 2014-10~	Auto drive position		x	x	
Skyline \ V37 \ 2014-10~	All mode AWD/4WD	x	x	x	0245, 0311
Skyline \ V37 \ 2014-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V37 \ 2014-10~	Sonar		x	x	
Skyline \ V37 \ 2014-10~	Lane camera		x	x	
Skyline \ V37 \ 2014-10~	Adaptive light		x	x	
Skyline \ V37 \ 2014-10~	CAN gateway		x		
Skyline \ V37 \ 2014-10~	Pop up hood	x	x	x	
Skyline \ V37 \ 2014-10~	4WAS(front)	x	x	x	
Skyline \ V37 \ 2014-10~	Accele pedal ACT		x	x	
Skyline \ V37 \ 2014-10~	Side radar left		x	x	
Skyline \ V37 \ 2014-10~	ANC		x	x	
Skyline \ V37 \ 2014-10~	Side radar right		x	x	
Skyline \ V37 \ 2014-10~	EMCM	x	x	x	
Skyline \ V37 \ 2014-10~	BSW/buzzer		x	x	
Skyline \ V37 \ 2014-10~	AVM		x	x	
Skyline \ V37 \ 2014-10~	Chassis control		x	x	
Skyline \ V37 \ 2014-10~	DAST 1		x	x	
Skyline \ V37 \ 2014-10~	DAST 2		x	x	
Skyline \ V37 \ 2014-10~	HIGH BEAM ASSIST	x	x	x	
Skyline \ V37 \ 2014-10~	FSCM		x	x	
Skyline \ V37 \ 2014-10~	Head lamp levelizer	x	x	x	
Skyline \ V37 \ 2014-10~	Occupant detection			x	
Skyline \ V37 \ 2014-4~	Engine	x	x	x	0278, 0060, 0262, 0274, 0237, 0209, 0294, 0216, 0267, 0233, 0103, 0234, 0212, 0152
Skyline \ V37 \ 2014-4~	ABS		x	x	
Skyline \ V37 \ 2014-4~	Meter/M&A		x	x	
Skyline \ V37 \ 2014-4~	BCM		x		
Skyline \ V37 \ 2014-4~	Air bag		x	x	
Skyline \ V37 \ 2014-4~	ICC/ADAS		x	x	
Skyline \ V37 \ 2014-4~	HVAC		x	x	
Skyline \ V37 \ 2014-4~	Transmission		x	x	0250, 0309, 0237, 0059

Skyline \ V37 \ 2014-4~	Multi AV		x	x	
Skyline \ V37 \ 2014-4~	EPS/DAST 3		x	x	
Skyline \ V37 \ 2014-4~	IPDM E/R		x	x	
Skyline \ V37 \ 2014-4~	Air pressure monitor		x	x	
Skyline \ V37 \ 2014-4~	Laser/radar		x	x	
Skyline \ V37 \ 2014-4~	Precrash seatbelt		x	x	
Skyline \ V37 \ 2014-4~	Auto drive position		x	x	
Skyline \ V37 \ 2014-4~	All mode AWD/4WD		x	x	
Skyline \ V37 \ 2014-4~	Sonar		x	x	
Skyline \ V37 \ 2014-4~	Lane camera		x	x	
Skyline \ V37 \ 2014-4~	Adaptive light		x	x	
Skyline \ V37 \ 2014-4~	CAN gateway		x		
Skyline \ V37 \ 2014-4~	Pop up hood	x	x	x	
Skyline \ V37 \ 2014-4~	Accele pedal ACT		x	x	
Skyline \ V37 \ 2014-4~	Side radar left		x	x	
Skyline \ V37 \ 2014-4~	VSP		x	x	
Skyline \ V37 \ 2014-4~	ANC		x	x	
Skyline \ V37 \ 2014-4~	Side radar right		x	x	
Skyline \ V37 \ 2014-4~	EMCM	x	x	x	
Skyline \ V37 \ 2014-4~	BSW/buzzer		x	x	
Skyline \ V37 \ 2014-4~	AVM		x	x	
Skyline \ V37 \ 2014-4~	Chassis control		x	x	
Skyline \ V37 \ 2014-4~	DAST 1		x	x	
Skyline \ V37 \ 2014-4~	DAST 2		x	x	
Skyline \ V37 \ 2014-4~	HIGH BEAM ASSIST	x	x	x	
Skyline \ V37 \ 2014-4~	FSCM		x	x	
Skyline \ V37 \ 2014-4~	Head lamp levelizer	x	x	x	
Skyline \ V37 \ 2014-4~	Occupant detection			x	
Skyline \ V37 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Skyline \ V37 \ 2016-3~	ABS		x	x	
Skyline \ V37 \ 2016-3~	Meter/M&A		x	x	
Skyline \ V37 \ 2016-3~	BCM		x		
Skyline \ V37 \ 2016-3~	Air bag		x	x	
Skyline \ V37 \ 2016-3~	ICC/ADAS		x	x	
Skyline \ V37 \ 2016-3~	HVAC		x	x	
Skyline \ V37 \ 2016-3~	Transmission		x	x	0059
Skyline \ V37 \ 2016-3~	Multi AV		x	x	
Skyline \ V37 \ 2016-3~	Motor control		x	x	
Skyline \ V37 \ 2016-3~	EPS/DAST 3	x	x	x	
Skyline \ V37 \ 2016-3~	IPDM E/R		x	x	

Skyline \ V37 \ 2016-3~	Air pressure monitor		x	x	
Skyline \ V37 \ 2016-3~	Laser/radar		x	x	
Skyline \ V37 \ 2016-3~	Precrash seatbelt		x	x	
Skyline \ V37 \ 2016-3~	Auto drive position		x	x	
Skyline \ V37 \ 2016-3~	All mode AWD/4WD		x	x	
Skyline \ V37 \ 2016-3~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Skyline \ V37 \ 2016-3~	Sonar		x	x	
Skyline \ V37 \ 2016-3~	Lane camera		x	x	
Skyline \ V37 \ 2016-3~	Adaptive light		x	x	
Skyline \ V37 \ 2016-3~	CAN gateway		x		
Skyline \ V37 \ 2016-3~	EV/HEV		x	x	
Skyline \ V37 \ 2016-3~	Pop up hood	x	x	x	
Skyline \ V37 \ 2016-3~	Accele pedal ACT		x	x	
Skyline \ V37 \ 2016-3~	HV battery		x	x	
Skyline \ V37 \ 2016-3~	Brake		x	x	
Skyline \ V37 \ 2016-3~	Side radar left		x	x	
Skyline \ V37 \ 2016-3~	VSP		x	x	
Skyline \ V37 \ 2016-3~	ANC		x	x	
Skyline \ V37 \ 2016-3~	Side radar right		x	x	
Skyline \ V37 \ 2016-3~	EMCM	x	x	x	
Skyline \ V37 \ 2016-3~	BSW/buzzer		x	x	
Skyline \ V37 \ 2016-3~	AVM		x	x	
Skyline \ V37 \ 2016-3~	Chassis control		x	x	
Skyline \ V37 \ 2016-3~	DAST 1		x	x	
Skyline \ V37 \ 2016-3~	DAST 2		x	x	
Skyline \ V37 \ 2016-3~	HIGH BEAM ASSIST	x	x	x	
Skyline \ V37 \ 2016-3~	FSCM		x	x	
Skyline \ V37 \ 2016-3~	Head lamp levelizer	x	x	x	
Skyline \ V37 \ 2016-3~	Occupant detection			x	
Stagea \ M35 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Stagea \ M35 \ All Year	ABS	x	x	x	0003, 0092, 0264
Stagea \ M35 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Stagea \ M35 \ All Year	BCM	x	x		
Stagea \ M35 \ All Year	Air bag	x	x	x	
Stagea \ M35 \ All Year	ICC/ADAS	x	x	x	
Stagea \ M35 \ All Year	HVAC	x	x	x	
Stagea \ M35 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Stagea \ M35 \ All Year	Multi AV	x	x	x	0280
Stagea \ M35 \ All Year	EPS/DAST 3	x	x	x	
Stagea \ M35 \ All Year	IPDM E/R	x	x	x	

Stagea \ M35 \ All Year	Air pressure monitor	x	x	x	
Stagea \ M35 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Stagea \ M35 \ All Year	DIU	x	x	x	
Stagea \ M35 \ All Year	Auto slide door	x	x	x	
Stagea \ M35 \ All Year	Auto drive position	x	x	x	
Stagea \ M35 \ All Year	All mode AWD/4WD	x	x	x	
Stagea \ M35 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Stagea \ M35 \ All Year	Sonar	x	x	x	
Stagea \ M35 \ All Year	Lane camera	x	x	x	
Stagea \ M35 \ All Year	Adaptive light	x	x	x	
Stagea \ M35 \ All Year	AVM		x	x	
Stagea \ M35 \ All Year	Head lamp levelizer	x	x	x	
Stagea \ M35 \ All Year	Difference lock	x	x	x	
Stagea \ M35 \ All Year	Nats immu	x	x		
Stagea \ M35 \ All Year	Smart entrance	x	x		
Stagea \ M35 \ All Year	Air levelizer	x	x	x	
Stagea \ M35 \ All Year	Rearview camera			x	
Stagea \ M35 \ All Year	S/blind camera			x	
Stagea \ M35 \ All Year	Motor assist	x	x	x	
Stagea \ WC34 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Stagea \ WC34 \ All Year	ABS	x	x	x	0003, 0092, 0264
Stagea \ WC34 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Stagea \ WC34 \ All Year	BCM	x	x		
Stagea \ WC34 \ All Year	Air bag	x	x	x	
Stagea \ WC34 \ All Year	ICC/ADAS	x	x	x	
Stagea \ WC34 \ All Year	HVAC	x	x	x	
Stagea \ WC34 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Stagea \ WC34 \ All Year	Multi AV	x	x	x	0280
Stagea \ WC34 \ All Year	EPS/DAST 3	x	x	x	
Stagea \ WC34 \ All Year	IPDM E/R	x	x	x	
Stagea \ WC34 \ All Year	Air pressure monitor	x	x	x	
Stagea \ WC34 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Stagea \ WC34 \ All Year	DIU	x	x	x	
Stagea \ WC34 \ All Year	Auto slide door	x	x	x	
Stagea \ WC34 \ All Year	Auto drive position	x	x	x	
Stagea \ WC34 \ All Year	All mode AWD/4WD	x	x	x	

Stagea \ WC34 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Stagea \ WC34 \ All Year	Sonar	x	x	x	
Stagea \ WC34 \ All Year	Lane camera	x	x	x	
Stagea \ WC34 \ All Year	Adaptive light	x	x	x	
Stagea \ WC34 \ All Year	AVM		x	x	
Stagea \ WC34 \ All Year	Head lamp levelizer	x	x	x	
Stagea \ WC34 \ All Year	Difference lock	x	x	x	
Stagea \ WC34 \ All Year	Nats immu	x	x		
Stagea \ WC34 \ All Year	Smart entrance	x	x		
Stagea \ WC34 \ All Year	Air levelizer	x	x	x	
Stagea \ WC34 \ All Year	Rearview camera			x	
Stagea \ WC34 \ All Year	S/blind camera			x	
Stagea \ WC34 \ All Year	Motor assist	x	x	x	
Sunny \ B10 \ 2006-4~	Meter/M&A		x	x	
Sunny \ B10 \ 2006-4~	Transmission		x	x	
Sunny \ B10 \ 2006-4~	Engine	x	x	x	
Sunny \ B10 \ 2006-4~	ABS	x	x	x	
Sunny \ B10 \ 2006-4~	Air bag		x	x	0317, 0341
Sunny \ B14 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ B14 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny \ B14 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ B14 \ All Year	BCM	x	x		
Sunny \ B14 \ All Year	Air bag	x	x	x	
Sunny \ B14 \ All Year	ICC/ADAS	x	x	x	
Sunny \ B14 \ All Year	HVAC	x	x	x	
Sunny \ B14 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ B14 \ All Year	Multi AV	x	x	x	0280
Sunny \ B14 \ All Year	EPS/DAST 3	x	x	x	
Sunny \ B14 \ All Year	IPDM E/R	x	x	x	
Sunny \ B14 \ All Year	Air pressure monitor	x	x	x	
Sunny \ B14 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny \ B14 \ All Year	DIU	x	x	x	
Sunny \ B14 \ All Year	Auto slide door	x	x	x	
Sunny \ B14 \ All Year	Auto drive position	x	x	x	
Sunny \ B14 \ All Year	All mode AWD/4WD	x	x	x	
Sunny \ B14 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny \ B14 \ All Year	Sonar	x	x	x	
Sunny \ B14 \ All Year	Lane camera	x	x	x	

Sunny \ B14 \ All Year	Adaptive light	x	x	x	
Sunny \ B14 \ All Year	AVM		x	x	
Sunny \ B14 \ All Year	Head lamp levelizer	x	x	x	
Sunny \ B14 \ All Year	Difference lock	x	x	x	
Sunny \ B14 \ All Year	Nats immu	x	x		
Sunny \ B14 \ All Year	Smart entrance	x	x		
Sunny \ B14 \ All Year	Air levelizer	x	x	x	
Sunny \ B14 \ All Year	Rearview camera			x	
Sunny \ B14 \ All Year	S/blind camera			x	
Sunny \ B14 \ All Year	Motor assist	x	x	x	
Sunny \ B15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ B15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny \ B15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ B15 \ All Year	BCM	x	x		
Sunny \ B15 \ All Year	Air bag	x	x	x	
Sunny \ B15 \ All Year	ICC/ADAS	x	x	x	
Sunny \ B15 \ All Year	HVAC	x	x	x	
Sunny \ B15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ B15 \ All Year	Multi AV	x	x	x	0280
Sunny \ B15 \ All Year	EPS/DAST 3	x	x	x	
Sunny \ B15 \ All Year	IPDM E/R	x	x	x	
Sunny \ B15 \ All Year	Air pressure monitor	x	x	x	
Sunny \ B15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny \ B15 \ All Year	DIU	x	x	x	
Sunny \ B15 \ All Year	Auto slide door	x	x	x	
Sunny \ B15 \ All Year	Auto drive position	x	x	x	
Sunny \ B15 \ All Year	All mode AWD/4WD	x	x	x	
Sunny \ B15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny \ B15 \ All Year	Sonar	x	x	x	
Sunny \ B15 \ All Year	Lane camera	x	x	x	
Sunny \ B15 \ All Year	Adaptive light	x	x	x	
Sunny \ B15 \ All Year	AVM		x	x	
Sunny \ B15 \ All Year	Head lamp levelizer	x	x	x	
Sunny \ B15 \ All Year	Difference lock	x	x	x	
Sunny \ B15 \ All Year	Nats immu	x	x		
Sunny \ B15 \ All Year	Smart entrance	x	x		
Sunny \ B15 \ All Year	Air levelizer	x	x	x	
Sunny \ B15 \ All Year	Rearview camera			x	

Sunny \ B15 \ All Year	S/blind camera			x	
Sunny \ B15 \ All Year	Motor assist	x	x	x	
Sunny \ N15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny \ N15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N15 \ All Year	BCM	x	x		
Sunny \ N15 \ All Year	Air bag	x	x	x	
Sunny \ N15 \ All Year	ICC/ADAS	x	x	x	
Sunny \ N15 \ All Year	HVAC	x	x	x	
Sunny \ N15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ N15 \ All Year	Multi AV	x	x	x	0280
Sunny \ N15 \ All Year	EPS/DAST 3	x	x	x	
Sunny \ N15 \ All Year	IPDM E/R	x	x	x	
Sunny \ N15 \ All Year	Air pressure monitor	x	x	x	
Sunny \ N15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny \ N15 \ All Year	DIU	x	x	x	
Sunny \ N15 \ All Year	Auto slide door	x	x	x	
Sunny \ N15 \ All Year	Auto drive position	x	x	x	
Sunny \ N15 \ All Year	All mode AWD/4WD	x	x	x	
Sunny \ N15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny \ N15 \ All Year	Sonar	x	x	x	
Sunny \ N15 \ All Year	Lane camera	x	x	x	
Sunny \ N15 \ All Year	Adaptive light	x	x	x	
Sunny \ N15 \ All Year	AVM		x	x	
Sunny \ N15 \ All Year	Head lamp levelizer	x	x	x	
Sunny \ N15 \ All Year	Difference lock	x	x	x	
Sunny \ N15 \ All Year	Nats immu	x	x		
Sunny \ N15 \ All Year	Smart entrance	x	x		
Sunny \ N15 \ All Year	Air levelizer	x	x	x	
Sunny \ N15 \ All Year	Rearview camera			x	
Sunny \ N15 \ All Year	S/blind camera			x	
Sunny \ N15 \ All Year	Motor assist	x	x	x	
Sunny \ N16 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N16 \ 2012-9~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N16 \ 2012-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N16 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Sunny \ N16 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny \ N16 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N16 \ All Year	BCM	x	x		
Sunny \ N16 \ All Year	Air bag	x	x	x	
Sunny \ N16 \ All Year	ICC/ADAS	x	x	x	
Sunny \ N16 \ All Year	HVAC	x	x	x	
Sunny \ N16 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ N16 \ All Year	Multi AV	x	x	x	0280
Sunny \ N16 \ All Year	EPS/DAST 3	x	x	x	
Sunny \ N16 \ All Year	IPDM E/R	x	x	x	
Sunny \ N16 \ All Year	Air pressure monitor	x	x	x	
Sunny \ N16 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny \ N16 \ All Year	DIU	x	x	x	
Sunny \ N16 \ All Year	Auto slide door	x	x	x	
Sunny \ N16 \ All Year	Auto drive position	x	x	x	
Sunny \ N16 \ All Year	All mode AWD/4WD	x	x	x	
Sunny \ N16 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny \ N16 \ All Year	Sonar	x	x	x	
Sunny \ N16 \ All Year	Lane camera	x	x	x	
Sunny \ N16 \ All Year	Adaptive light	x	x	x	
Sunny \ N16 \ All Year	AVM		x	x	
Sunny \ N16 \ All Year	Head lamp levelizer	x	x	x	
Sunny \ N16 \ All Year	Difference lock	x	x	x	
Sunny \ N16 \ All Year	Nats immu	x	x		
Sunny \ N16 \ All Year	Smart entrance	x	x		
Sunny \ N16 \ All Year	Air levelizer	x	x	x	
Sunny \ N16 \ All Year	Rearview camera			x	
Sunny \ N16 \ All Year	S/blind camera			x	
Sunny \ N16 \ All Year	Motor assist	x	x	x	
Sunny \ N17 \ 2010-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2010-12~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2010-12~	Meter/M&A		x	x	
Sunny \ N17 \ 2010-12~	BCM	x	x		
Sunny \ N17 \ 2010-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ N17 \ 2010-12~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2010-12~	IPDM E/R		x	x	
Sunny \ N17 \ 2010-12~	Air bag	x	x	x	

Sunny \ N17 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2011-12~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2011-12~	Meter/M&A		x	x	
Sunny \ N17 \ 2011-12~	BCM		x		
Sunny \ N17 \ 2011-12~	Transmission		x	x	
Sunny \ N17 \ 2011-12~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2011-12~	IPDM E/R		x	x	
Sunny \ N17 \ 2011-12~	Air bag	x	x	x	
Sunny \ N17 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2011-8~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2011-8~	BCM	x	x		
Sunny \ N17 \ 2011-8~	Air bag	x	x	x	
Sunny \ N17 \ 2011-8~	Transmission	x	x	x	
Sunny \ N17 \ 2011-8~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2011-8~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2011-8~	IPDM E/R		x	x	
Sunny \ N17 \ 2011-8~	Occupant detection			x	
Sunny \ N17 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2011-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2011-9~	BCM	x	x		
Sunny \ N17 \ 2011-9~	Air bag	x	x	x	
Sunny \ N17 \ 2011-9~	Transmission	x	x	x	
Sunny \ N17 \ 2011-9~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2011-9~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2011-9~	IPDM E/R		x	x	
Sunny \ N17 \ 2011-9~	Occupant detection			x	
Sunny \ N17 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2012-7~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2012-7~	Meter/M&A		x	x	
Sunny \ N17 \ 2012-7~	BCM		x		
Sunny \ N17 \ 2012-7~	Transmission		x	x	
Sunny \ N17 \ 2012-7~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2012-7~	IPDM E/R		x	x	
Sunny \ N17 \ 2012-7~	Air bag	x	x	x	

Sunny \ N17 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2013-11~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2013-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2013-11~	BCM		x		
Sunny \ N17 \ 2013-11~	Air bag	x	x	x	
Sunny \ N17 \ 2013-11~	Transmission		x	x	
Sunny \ N17 \ 2013-11~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2013-11~	IPDM E/R		x	x	
Sunny \ N17 \ 2013-11~	Occupant detection			x	
Sunny \ N17 \ 2013-11~	SVT	x	x	x	
Sunny \ N17 \ 2013-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2013-2~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2013-2~	Meter/M&A		x	x	
Sunny \ N17 \ 2013-2~	BCM		x		
Sunny \ N17 \ 2013-2~	Air bag	x	x	x	
Sunny \ N17 \ 2013-2~	Transmission		x	x	
Sunny \ N17 \ 2013-2~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2013-2~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2013-2~	IPDM E/R		x	x	
Sunny \ N17 \ 2013-2~	Occupant detection			x	
Sunny \ N17 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2013-8~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2013-8~	BCM		x		
Sunny \ N17 \ 2013-8~	Air bag	x	x	x	
Sunny \ N17 \ 2013-8~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2013-8~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2013-8~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2013-8~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2013-8~	IPDM E/R		x	x	
Sunny \ N17 \ 2013-8~	Laser/radar	x	x	x	
Sunny \ N17 \ 2013-8~	Sonar	x	x	x	
Sunny \ N17 \ 2013-8~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2013-8~	Side radar left		x	x	
Sunny \ N17 \ 2013-8~	ANC		x	x	
Sunny \ N17 \ 2013-8~	Side radar right		x	x	
Sunny \ N17 \ 2013-8~	PTC heater		x	x	

Sunny \ N17 \ 2013-8~	Telematics		x	x	0253
Sunny \ N17 \ 2013-8~	AVM		x	x	
Sunny \ N17 \ 2013-8~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2013-8~	Occupant detection			x	
Sunny \ N17 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2014-4~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2014-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2014-4~	BCM		x		
Sunny \ N17 \ 2014-4~	Air bag	x	x	x	
Sunny \ N17 \ 2014-4~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2014-4~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2014-4~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2014-4~	IPDM E/R		x	x	
Sunny \ N17 \ 2014-4~	Laser/radar	x	x	x	
Sunny \ N17 \ 2014-4~	Sonar	x	x	x	
Sunny \ N17 \ 2014-4~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2014-4~	Side radar left		x	x	
Sunny \ N17 \ 2014-4~	ANC		x	x	
Sunny \ N17 \ 2014-4~	Side radar right		x	x	
Sunny \ N17 \ 2014-4~	PTC heater		x	x	
Sunny \ N17 \ 2014-4~	Telematics		x	x	0253
Sunny \ N17 \ 2014-4~	AVM		x	x	
Sunny \ N17 \ 2014-4~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2014-4~	Occupant detection			x	
Sunny \ N17 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2014-5~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2014-5~	BCM		x		
Sunny \ N17 \ 2014-5~	Air bag	x	x	x	
Sunny \ N17 \ 2014-5~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2014-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2014-5~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2014-5~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2014-5~	IPDM E/R		x	x	
Sunny \ N17 \ 2014-5~	Laser/radar	x	x	x	
Sunny \ N17 \ 2014-5~	Sonar	x	x	x	

Sunny \ N17 \ 2014-5~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2014-5~	Side radar left		x	x	
Sunny \ N17 \ 2014-5~	ANC		x	x	
Sunny \ N17 \ 2014-5~	Side radar right		x	x	
Sunny \ N17 \ 2014-5~	PTC heater		x	x	
Sunny \ N17 \ 2014-5~	Telematics		x	x	0253
Sunny \ N17 \ 2014-5~	AVM		x	x	
Sunny \ N17 \ 2014-5~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2014-5~	Occupant detection			x	
Sunny \ N17 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2015-3~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2015-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2015-3~	BCM		x		
Sunny \ N17 \ 2015-3~	Air bag	x	x	x	
Sunny \ N17 \ 2015-3~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2015-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2015-3~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2015-3~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2015-3~	IPDM E/R		x	x	
Sunny \ N17 \ 2015-3~	Laser/radar	x	x	x	
Sunny \ N17 \ 2015-3~	Sonar	x	x	x	
Sunny \ N17 \ 2015-3~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2015-3~	Side radar left		x	x	
Sunny \ N17 \ 2015-3~	ANC		x	x	
Sunny \ N17 \ 2015-3~	Side radar right		x	x	
Sunny \ N17 \ 2015-3~	PTC heater		x	x	
Sunny \ N17 \ 2015-3~	Telematics		x	x	0253
Sunny \ N17 \ 2015-3~	AVM		x	x	
Sunny \ N17 \ 2015-3~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2015-3~	Occupant detection			x	
Sunny \ N17 \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2015-7~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2015-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2015-7~	BCM		x		
Sunny \ N17 \ 2015-7~	Air bag	x	x	x	
Sunny \ N17 \ 2015-7~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150

Sunny \ N17 \ 2015-7~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2015-7~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2015-7~	IPDM E/R		x	x	
Sunny \ N17 \ 2015-7~	Laser/radar	x	x	x	
Sunny \ N17 \ 2015-7~	Sonar	x	x	x	
Sunny \ N17 \ 2015-7~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2015-7~	Side radar left		x	x	
Sunny \ N17 \ 2015-7~	ANC		x	x	
Sunny \ N17 \ 2015-7~	Side radar right		x	x	
Sunny \ N17 \ 2015-7~	PTC heater		x	x	
Sunny \ N17 \ 2015-7~	Telematics		x	x	0253
Sunny \ N17 \ 2015-7~	AVM		x	x	
Sunny \ N17 \ 2015-7~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2015-7~	Occupant detection			x	
Sunny \ N17 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2016-3~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2016-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ N17 \ 2016-3~	BCM		x		
Sunny \ N17 \ 2016-3~	Air bag	x	x	x	
Sunny \ N17 \ 2016-3~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2016-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2016-3~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2016-3~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2016-3~	IPDM E/R		x	x	
Sunny \ N17 \ 2016-3~	Laser/radar	x	x	x	
Sunny \ N17 \ 2016-3~	Sonar	x	x	x	
Sunny \ N17 \ 2016-3~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2016-3~	Side radar left		x	x	
Sunny \ N17 \ 2016-3~	ANC		x	x	
Sunny \ N17 \ 2016-3~	Side radar right		x	x	
Sunny \ N17 \ 2016-3~	PTC heater		x	x	
Sunny \ N17 \ 2016-3~	Telematics		x	x	0253
Sunny \ N17 \ 2016-3~	AVM		x	x	
Sunny \ N17 \ 2016-3~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2016-3~	Occupant detection			x	
Sunny \ N17 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ N17 \ 2016-6~	ABS	x	x	x	0003, 0092, 0264
Sunny \ N17 \ 2016-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Sunny \ N17 \ 2016-6~	BCM		x		
Sunny \ N17 \ 2016-6~	Air bag	x	x	x	
Sunny \ N17 \ 2016-6~	ICC/ADAS	x	x	x	
Sunny \ N17 \ 2016-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny \ N17 \ 2016-6~	Multi AV	x	x	x	0280
Sunny \ N17 \ 2016-6~	EPS/DAST 3	x	x	x	
Sunny \ N17 \ 2016-6~	IPDM E/R		x	x	
Sunny \ N17 \ 2016-6~	Laser/radar	x	x	x	
Sunny \ N17 \ 2016-6~	Sonar	x	x	x	
Sunny \ N17 \ 2016-6~	Accele pedal ACT		x	x	
Sunny \ N17 \ 2016-6~	Side radar left		x	x	
Sunny \ N17 \ 2016-6~	ANC		x	x	
Sunny \ N17 \ 2016-6~	Side radar right		x	x	
Sunny \ N17 \ 2016-6~	PTC heater		x	x	
Sunny \ N17 \ 2016-6~	Telematics		x	x	0253
Sunny \ N17 \ 2016-6~	AVM		x	x	
Sunny \ N17 \ 2016-6~	Head lamp levelizer	x	x	x	
Sunny \ N17 \ 2016-6~	Occupant detection			x	
Sunny \ Y10 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny \ Y10 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny \ Y10 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny \ Y10 \ All Year	BCM	x	x		
Sunny \ Y10 \ All Year	Air bag	x	x	x	
Sunny \ Y10 \ All Year	ICC/ADAS	x	x	x	
Sunny \ Y10 \ All Year	HVAC	x	x	x	
Sunny \ Y10 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny \ Y10 \ All Year	Multi AV	x	x	x	0280
Sunny \ Y10 \ All Year	EPS/DAST 3	x	x	x	
Sunny \ Y10 \ All Year	IPDM E/R	x	x	x	
Sunny \ Y10 \ All Year	Air pressure monitor	x	x	x	
Sunny \ Y10 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny \ Y10 \ All Year	DIU	x	x	x	
Sunny \ Y10 \ All Year	Auto slide door	x	x	x	
Sunny \ Y10 \ All Year	Auto drive position	x	x	x	
Sunny \ Y10 \ All Year	All mode AWD/4WD	x	x	x	
Sunny \ Y10 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny \ Y10 \ All Year	Sonar	x	x	x	

Sunny \ Y10 \ All Year	Lane camera	x	x	x	
Sunny \ Y10 \ All Year	Adaptive light	x	x	x	
Sunny \ Y10 \ All Year	AVM		x	x	
Sunny \ Y10 \ All Year	Head lamp levelizer	x	x	x	
Sunny \ Y10 \ All Year	Difference lock	x	x	x	
Sunny \ Y10 \ All Year	Nats immu	x	x		
Sunny \ Y10 \ All Year	Smart entrance	x	x		
Sunny \ Y10 \ All Year	Air levelizer	x	x	x	
Sunny \ Y10 \ All Year	Rearview camera			x	
Sunny \ Y10 \ All Year	S/blind camera			x	
Sunny \ Y10 \ All Year	Motor assist	x	x	x	
Sunny-almera \ N15 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-almera \ N15 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny-almera \ N15 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-almera \ N15 \ All Year	BCM	x	x		
Sunny-almera \ N15 \ All Year	Air bag	x	x	x	
Sunny-almera \ N15 \ All Year	ICC/ADAS	x	x	x	
Sunny-almera \ N15 \ All Year	HVAC	x	x	x	
Sunny-almera \ N15 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny-almera \ N15 \ All Year	Multi AV	x	x	x	0280
Sunny-almera \ N15 \ All Year	EPS/DAST 3	x	x	x	
Sunny-almera \ N15 \ All Year	IPDM E/R	x	x	x	
Sunny-almera \ N15 \ All Year	Air pressure monitor	x	x	x	
Sunny-almera \ N15 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny-almera \ N15 \ All Year	DIU	x	x	x	
Sunny-almera \ N15 \ All Year	Auto slide door	x	x	x	
Sunny-almera \ N15 \ All Year	Auto drive position	x	x	x	
Sunny-almera \ N15 \ All Year	All mode AWD/4WD	x	x	x	
Sunny-almera \ N15 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny-almera \ N15 \ All Year	Sonar	x	x	x	
Sunny-almera \ N15 \ All Year	Lane camera	x	x	x	
Sunny-almera \ N15 \ All Year	Adaptive light	x	x	x	
Sunny-almera \ N15 \ All Year	AVM		x	x	
Sunny-almera \ N15 \ All Year	Head lamp levelizer	x	x	x	
Sunny-almera \ N15 \ All Year	Difference lock	x	x	x	
Sunny-almera \ N15 \ All Year	Nats immu	x	x		
Sunny-almera \ N15 \ All Year	Smart entrance	x	x		
Sunny-almera \ N15 \ All Year	Air levelizer	x	x	x	

Sunny-almera \ N15 \ All Year	Rearview camera			x	
Sunny-almera \ N15 \ All Year	S/blind camera			x	
Sunny-almera \ N15 \ All Year	Motor assist	x	x	x	
Sunny-almera \ N16 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-almera \ N16 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny-almera \ N16 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-almera \ N16 \ All Year	BCM	x	x		
Sunny-almera \ N16 \ All Year	Air bag	x	x	x	
Sunny-almera \ N16 \ All Year	ICC/ADAS	x	x	x	
Sunny-almera \ N16 \ All Year	HVAC	x	x	x	
Sunny-almera \ N16 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny-almera \ N16 \ All Year	Multi AV	x	x	x	0280
Sunny-almera \ N16 \ All Year	EPS/DAST 3	x	x	x	
Sunny-almera \ N16 \ All Year	IPDM E/R	x	x	x	
Sunny-almera \ N16 \ All Year	Air pressure monitor	x	x	x	
Sunny-almera \ N16 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny-almera \ N16 \ All Year	DIU	x	x	x	
Sunny-almera \ N16 \ All Year	Auto slide door	x	x	x	
Sunny-almera \ N16 \ All Year	Auto drive position	x	x	x	
Sunny-almera \ N16 \ All Year	All mode AWD/4WD	x	x	x	
Sunny-almera \ N16 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny-almera \ N16 \ All Year	Sonar	x	x	x	
Sunny-almera \ N16 \ All Year	Lane camera	x	x	x	
Sunny-almera \ N16 \ All Year	Adaptive light	x	x	x	
Sunny-almera \ N16 \ All Year	AVM		x	x	
Sunny-almera \ N16 \ All Year	Head lamp levelizer	x	x	x	
Sunny-almera \ N16 \ All Year	Difference lock	x	x	x	
Sunny-almera \ N16 \ All Year	Nats immu	x	x		
Sunny-almera \ N16 \ All Year	Smart entrance	x	x		
Sunny-almera \ N16 \ All Year	Air levelizer	x	x	x	
Sunny-almera \ N16 \ All Year	Rearview camera			x	
Sunny-almera \ N16 \ All Year	S/blind camera			x	
Sunny-almera \ N16 \ All Year	Motor assist	x	x	x	
Sunny-almera \ N17 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-almera \ N17 \ 2011-12~	ABS	x	x	x	0003, 0092, 0264
Sunny-almera \ N17 \ 2011-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-almera \ N17 \ 2011-12~	BCM	x	x		

Sunny-almera \ N17 \ 2011-12~	Air bag	x	x	x	
Sunny-almera \ N17 \ 2011-12~	Transmission	x	x	x	
Sunny-almera \ N17 \ 2011-12~	Multi AV	x	x	x	0280
Sunny-almera \ N17 \ 2011-12~	EPS/DAST 3	x	x	x	
Sunny-almera \ N17 \ 2011-12~	IPDM E/R		x	x	
Sunny-almera \ N17 \ 2011-12~	Occupant detection			x	
Sunny-almera \ N17 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-almera \ N17 \ 2014-5~	ABS	x	x	x	0003, 0092, 0264
Sunny-almera \ N17 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-almera \ N17 \ 2014-5~	BCM		x		
Sunny-almera \ N17 \ 2014-5~	Air bag	x	x	x	
Sunny-almera \ N17 \ 2014-5~	ICC/ADAS	x	x	x	
Sunny-almera \ N17 \ 2014-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny-almera \ N17 \ 2014-5~	Multi AV	x	x	x	0280
Sunny-almera \ N17 \ 2014-5~	EPS/DAST 3	x	x	x	
Sunny-almera \ N17 \ 2014-5~	IPDM E/R		x	x	
Sunny-almera \ N17 \ 2014-5~	Laser/radar	x	x	x	
Sunny-almera \ N17 \ 2014-5~	Sonar	x	x	x	
Sunny-almera \ N17 \ 2014-5~	Accele pedal ACT		x	x	
Sunny-almera \ N17 \ 2014-5~	Side radar left		x	x	
Sunny-almera \ N17 \ 2014-5~	ANC		x	x	
Sunny-almera \ N17 \ 2014-5~	Side radar right		x	x	
Sunny-almera \ N17 \ 2014-5~	PTC heater		x	x	
Sunny-almera \ N17 \ 2014-5~	Telematics		x	x	0253
Sunny-almera \ N17 \ 2014-5~	AVM		x	x	
Sunny-almera \ N17 \ 2014-5~	Head lamp levelizer	x	x	x	
Sunny-almera \ N17 \ 2014-5~	Occupant detection			x	
Sunny-almera \ N17 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-almera \ N17 \ 2016-3~	ABS	x	x	x	0003, 0092, 0264
Sunny-almera \ N17 \ 2016-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-almera \ N17 \ 2016-3~	BCM		x		
Sunny-almera \ N17 \ 2016-3~	Air bag	x	x	x	
Sunny-almera \ N17 \ 2016-3~	ICC/ADAS	x	x	x	
Sunny-almera \ N17 \ 2016-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Sunny-almera \ N17 \ 2016-3~	Multi AV	x	x	x	0280
Sunny-almera \ N17 \ 2016-3~	EPS/DAST 3	x	x	x	
Sunny-almera \ N17 \ 2016-3~	IPDM E/R		x	x	

Sunny-almera \ N17 \ 2016-3~	Laser/radar	x	x	x	
Sunny-almera \ N17 \ 2016-3~	Sonar	x	x	x	
Sunny-almera \ N17 \ 2016-3~	Accele pedal ACT		x	x	
Sunny-almera \ N17 \ 2016-3~	Side radar left		x	x	
Sunny-almera \ N17 \ 2016-3~	ANC		x	x	
Sunny-almera \ N17 \ 2016-3~	Side radar right		x	x	
Sunny-almera \ N17 \ 2016-3~	PTC heater		x	x	
Sunny-almera \ N17 \ 2016-3~	Telematics		x	x	0253
Sunny-almera \ N17 \ 2016-3~	AVM		x	x	
Sunny-almera \ N17 \ 2016-3~	Head lamp levelizer	x	x	x	
Sunny-almera \ N17 \ 2016-3~	Occupant detection			x	
Sunny-sentra \ N16 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sunny-sentra \ N16 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sunny-sentra \ N16 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sunny-sentra \ N16 \ All Year	BCM	x	x		
Sunny-sentra \ N16 \ All Year	Air bag	x	x	x	
Sunny-sentra \ N16 \ All Year	ICC/ADAS	x	x	x	
Sunny-sentra \ N16 \ All Year	HVAC	x	x	x	
Sunny-sentra \ N16 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sunny-sentra \ N16 \ All Year	Multi AV	x	x	x	0280
Sunny-sentra \ N16 \ All Year	EPS/DAST 3	x	x	x	
Sunny-sentra \ N16 \ All Year	IPDM E/R	x	x	x	
Sunny-sentra \ N16 \ All Year	Air pressure monitor	x	x	x	
Sunny-sentra \ N16 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sunny-sentra \ N16 \ All Year	DIU	x	x	x	
Sunny-sentra \ N16 \ All Year	Auto slide door	x	x	x	
Sunny-sentra \ N16 \ All Year	Auto drive position	x	x	x	
Sunny-sentra \ N16 \ All Year	All mode AWD/4WD	x	x	x	
Sunny-sentra \ N16 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sunny-sentra \ N16 \ All Year	Sonar	x	x	x	
Sunny-sentra \ N16 \ All Year	Lane camera	x	x	x	
Sunny-sentra \ N16 \ All Year	Adaptive light	x	x	x	
Sunny-sentra \ N16 \ All Year	AVM		x	x	
Sunny-sentra \ N16 \ All Year	Head lamp levelizer	x	x	x	
Sunny-sentra \ N16 \ All Year	Difference lock	x	x	x	
Sunny-sentra \ N16 \ All Year	Nats immu	x	x		
Sunny-sentra \ N16 \ All Year	Smart entrance	x	x		
Sunny-sentra \ N16 \ All Year	Air levelizer	x	x	x	

Sunny-sentra \ N16 \ All Year	Rearview camera			x	
Sunny-sentra \ N16 \ All Year	S/blind camera			x	
Sunny-sentra \ N16 \ All Year	Motor assist	x	x	x	
Sylphy \ B17 \ 2012-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2012-10~	ABS	x	x	x	
Sylphy \ B17 \ 2012-10~	Meter/M&A		x	x	
Sylphy \ B17 \ 2012-10~	BCM		x		
Sylphy \ B17 \ 2012-10~	Air bag		x	x	
Sylphy \ B17 \ 2012-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2012-10~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2012-10~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2012-10~	IPDM E/R		x	x	
Sylphy \ B17 \ 2012-10~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2012-10~	Occupant detection			x	
Sylphy \ B17 \ 2012-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2012-12~	ABS	x	x	x	0003, 0092, 0264
Sylphy \ B17 \ 2012-12~	Meter/M&A		x	x	
Sylphy \ B17 \ 2012-12~	BCM		x		
Sylphy \ B17 \ 2012-12~	Air bag		x	x	
Sylphy \ B17 \ 2012-12~	ICC/ADAS	x	x	x	
Sylphy \ B17 \ 2012-12~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2012-12~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2012-12~	Multi AV	x	x	x	0280
Sylphy \ B17 \ 2012-12~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2012-12~	IPDM E/R		x	x	
Sylphy \ B17 \ 2012-12~	Air pressure monitor		x	x	
Sylphy \ B17 \ 2012-12~	Laser/radar	x	x	x	
Sylphy \ B17 \ 2012-12~	Sonar	x	x	x	
Sylphy \ B17 \ 2012-12~	Side radar left		x	x	
Sylphy \ B17 \ 2012-12~	Side radar right		x	x	
Sylphy \ B17 \ 2012-12~	PTC heater		x	x	
Sylphy \ B17 \ 2012-12~	Telematics		x	x	0253
Sylphy \ B17 \ 2012-12~	AVM		x	x	
Sylphy \ B17 \ 2012-12~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2012-12~	Occupant detection			x	

Sylphy \ B17 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2012-6~	ABS	x	x	x	
Sylphy \ B17 \ 2012-6~	Meter/M&A		x	x	
Sylphy \ B17 \ 2012-6~	BCM		x		
Sylphy \ B17 \ 2012-6~	Air bag		x	x	
Sylphy \ B17 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2012-6~	Transmission		x	x	
Sylphy \ B17 \ 2012-6~	Multi AV		x	x	
Sylphy \ B17 \ 2012-6~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2012-6~	IPDM E/R		x	x	
Sylphy \ B17 \ 2012-6~	Sonar		x	x	
Sylphy \ B17 \ 2012-6~	Telematics		x	x	0253
Sylphy \ B17 \ 2012-6~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2012-7~	ABS	x	x	x	
Sylphy \ B17 \ 2012-7~	Meter/M&A		x	x	
Sylphy \ B17 \ 2012-7~	BCM		x		
Sylphy \ B17 \ 2012-7~	Air bag		x	x	
Sylphy \ B17 \ 2012-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2012-7~	Transmission		x	x	
Sylphy \ B17 \ 2012-7~	Multi AV		x	x	
Sylphy \ B17 \ 2012-7~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2012-7~	IPDM E/R		x	x	
Sylphy \ B17 \ 2012-7~	Sonar		x	x	
Sylphy \ B17 \ 2012-7~	Telematics		x	x	0253
Sylphy \ B17 \ 2012-7~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2014-2~	ABS	x	x	x	
Sylphy \ B17 \ 2014-2~	Meter/M&A		x	x	
Sylphy \ B17 \ 2014-2~	BCM		x		
Sylphy \ B17 \ 2014-2~	Air bag		x	x	
Sylphy \ B17 \ 2014-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2014-2~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2014-2~	Multi AV	x	x	x	0280

Sylphy \ B17 \ 2014-2~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2014-2~	IPDM E/R		x	x	
Sylphy \ B17 \ 2014-2~	Sonar	x	x	x	
Sylphy \ B17 \ 2014-2~	AVM		x	x	
Sylphy \ B17 \ 2014-2~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2014-2~	Occupant detection			x	
Sylphy \ B17 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2015-3~	ABS	x	x	x	0003, 0092, 0264
Sylphy \ B17 \ 2015-3~	Meter/M&A		x	x	
Sylphy \ B17 \ 2015-3~	BCM		x		
Sylphy \ B17 \ 2015-3~	Air bag		x	x	
Sylphy \ B17 \ 2015-3~	ICC/ADAS	x	x	x	
Sylphy \ B17 \ 2015-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2015-3~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2015-3~	Multi AV	x	x	x	0280
Sylphy \ B17 \ 2015-3~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2015-3~	IPDM E/R		x	x	
Sylphy \ B17 \ 2015-3~	Sonar	x	x	x	
Sylphy \ B17 \ 2015-3~	Side radar left		x	x	
Sylphy \ B17 \ 2015-3~	Side radar right		x	x	
Sylphy \ B17 \ 2015-3~	Telematics		x	x	0253
Sylphy \ B17 \ 2015-3~	AVM		x	x	
Sylphy \ B17 \ 2015-3~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2015-3~	Occupant detection			x	
Sylphy \ B17 \ 2015-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2015-8~	ABS	x	x	x	0003, 0092, 0264
Sylphy \ B17 \ 2015-8~	Meter/M&A		x	x	
Sylphy \ B17 \ 2015-8~	BCM		x		
Sylphy \ B17 \ 2015-8~	Air bag		x	x	
Sylphy \ B17 \ 2015-8~	ICC/ADAS	x	x	x	
Sylphy \ B17 \ 2015-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2015-8~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2015-8~	Multi AV	x	x	x	0280
Sylphy \ B17 \ 2015-8~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2015-8~	IPDM E/R		x	x	

Sylphy \ B17 \ 2015-8~	Air pressure monitor		×	×	
Sylphy \ B17 \ 2015-8~	Laser/radar	×	×	×	
Sylphy \ B17 \ 2015-8~	Sonar	×	×	×	
Sylphy \ B17 \ 2015-8~	Side radar left		×	×	
Sylphy \ B17 \ 2015-8~	Side radar right		×	×	
Sylphy \ B17 \ 2015-8~	PTC heater		×	×	
Sylphy \ B17 \ 2015-8~	Telematics		×	×	0253
Sylphy \ B17 \ 2015-8~	AVM		×	×	
Sylphy \ B17 \ 2015-8~	Head lamp levelizer	×	×	×	
Sylphy \ B17 \ 2015-8~	Occupant detection			×	
Sylphy \ B17 \ 2016-1~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2016-1~	ABS	×	×	×	0003, 0092, 0264
Sylphy \ B17 \ 2016-1~	Meter/M&A		×	×	
Sylphy \ B17 \ 2016-1~	BCM		×		
Sylphy \ B17 \ 2016-1~	Air bag		×	×	
Sylphy \ B17 \ 2016-1~	ICC/ADAS	×	×	×	
Sylphy \ B17 \ 2016-1~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2016-1~	Transmission	×	×	×	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2016-1~	Multi AV		×	×	
Sylphy \ B17 \ 2016-1~	EPS/DAST 3	×	×	×	
Sylphy \ B17 \ 2016-1~	IPDM E/R		×	×	
Sylphy \ B17 \ 2016-1~	Air pressure monitor		×	×	
Sylphy \ B17 \ 2016-1~	Laser/radar	×	×	×	
Sylphy \ B17 \ 2016-1~	Sonar		×	×	
Sylphy \ B17 \ 2016-1~	Lane camera		×	×	
Sylphy \ B17 \ 2016-1~	Side radar left		×	×	
Sylphy \ B17 \ 2016-1~	Side radar right		×	×	
Sylphy \ B17 \ 2016-1~	Head lamp levelizer	×	×	×	
Sylphy \ B17 \ 2016-1~	Occupant detection			×	
Sylphy \ B17 \ 2016-5~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2016-5~	ABS	×	×	×	0003, 0092, 0264
Sylphy \ B17 \ 2016-5~	Meter/M&A		×	×	
Sylphy \ B17 \ 2016-5~	BCM		×		
Sylphy \ B17 \ 2016-5~	Air bag		×	×	
Sylphy \ B17 \ 2016-5~	ICC/ADAS	×	×	×	
Sylphy \ B17 \ 2016-5~	HVAC		×	×	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308

Sylphy \ B17 \ 2016-5~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2016-5~	Multi AV	x	x	x	0280
Sylphy \ B17 \ 2016-5~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2016-5~	IPDM E/R		x	x	
Sylphy \ B17 \ 2016-5~	Air pressure monitor		x	x	
Sylphy \ B17 \ 2016-5~	Laser/radar	x	x	x	
Sylphy \ B17 \ 2016-5~	Sonar	x	x	x	
Sylphy \ B17 \ 2016-5~	Side radar left		x	x	
Sylphy \ B17 \ 2016-5~	Side radar right		x	x	
Sylphy \ B17 \ 2016-5~	PTC heater		x	x	
Sylphy \ B17 \ 2016-5~	Telematics		x	x	0253
Sylphy \ B17 \ 2016-5~	AVM		x	x	
Sylphy \ B17 \ 2016-5~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2016-5~	Occupant detection			x	
Sylphy \ B17 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ B17 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
Sylphy \ B17 \ 2016-7~	Meter/M&A		x	x	
Sylphy \ B17 \ 2016-7~	BCM		x		
Sylphy \ B17 \ 2016-7~	Air bag		x	x	
Sylphy \ B17 \ 2016-7~	ICC/ADAS		x	x	
Sylphy \ B17 \ 2016-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Sylphy \ B17 \ 2016-7~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Sylphy \ B17 \ 2016-7~	Multi AV	x	x	x	0280
Sylphy \ B17 \ 2016-7~	EPS/DAST 3	x	x	x	
Sylphy \ B17 \ 2016-7~	IPDM E/R		x	x	
Sylphy \ B17 \ 2016-7~	Head lamp levelizer	x	x	x	
Sylphy \ B17 \ 2016-7~	Occupant detection			x	
Sylphy \ G10 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ G10 \ All Year	ABS	x	x	x	0003, 0092, 0264
Sylphy \ G10 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G10 \ All Year	BCM	x	x		
Sylphy \ G10 \ All Year	Air bag	x	x	x	
Sylphy \ G10 \ All Year	ICC/ADAS	x	x	x	
Sylphy \ G10 \ All Year	HVAC	x	x	x	
Sylphy \ G10 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sylphy \ G10 \ All Year	Multi AV	x	x	x	0280

Sylphy \ G10 \ All Year	EPS/DAST 3	x	x	x	
Sylphy \ G10 \ All Year	IPDM E/R	x	x	x	
Sylphy \ G10 \ All Year	Air pressure monitor	x	x	x	
Sylphy \ G10 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G10 \ All Year	DIU	x	x	x	
Sylphy \ G10 \ All Year	Auto slide door	x	x	x	
Sylphy \ G10 \ All Year	Auto drive position	x	x	x	
Sylphy \ G10 \ All Year	All mode AWD/4WD	x	x	x	
Sylphy \ G10 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Sylphy \ G10 \ All Year	Sonar	x	x	x	
Sylphy \ G10 \ All Year	Lane camera	x	x	x	
Sylphy \ G10 \ All Year	Adaptive light	x	x	x	
Sylphy \ G10 \ All Year	AVM		x	x	
Sylphy \ G10 \ All Year	Head lamp levelizer	x	x	x	
Sylphy \ G10 \ All Year	Difference lock	x	x	x	
Sylphy \ G10 \ All Year	Nats immu	x	x		
Sylphy \ G10 \ All Year	Smart entrance	x	x		
Sylphy \ G10 \ All Year	Air levelizer	x	x	x	
Sylphy \ G10 \ All Year	Rearview camera			x	
Sylphy \ G10 \ All Year	S/blind camera			x	
Sylphy \ G10 \ All Year	Motor assist	x	x	x	
Sylphy \ G11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2005-12~	BCM	x	x		
Sylphy \ G11 \ 2005-12~	Transmission	x	x	x	
Sylphy \ G11 \ 2005-12~	Multi AV	x	x	x	0280
Sylphy \ G11 \ 2005-12~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2005-12~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2005-12~	E-4wd	x	x	x	
Sylphy \ G11 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2005-12~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2005-12~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2005-12~	Engine	x	x	x	
Sylphy \ G11 \ 2005-12~	ABS	x	x	x	
Sylphy \ G11 \ 2005-12~	Air bag	x	x	x	
Sylphy \ G11 \ 2005-12~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Sylphy \ G11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2006-12~	BCM	x	x		
Sylphy \ G11 \ 2006-12~	Transmission	x	x	x	
Sylphy \ G11 \ 2006-12~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2006-12~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2006-12~	DIU	x	x	x	
Sylphy \ G11 \ 2006-12~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2006-12~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2006-12~	ABS	x	x	x	
Sylphy \ G11 \ 2006-12~	Air bag	x	x	x	
Sylphy \ G11 \ 2006-12~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2006-12~	S/blind camera			x	
Sylphy \ G11 \ 2006-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2006-1~	BCM	x	x		
Sylphy \ G11 \ 2006-1~	Transmission	x	x	x	
Sylphy \ G11 \ 2006-1~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2006-1~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2006-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2006-1~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2006-1~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2006-1~	Engine	x	x	x	
Sylphy \ G11 \ 2006-1~	ABS	x	x	x	
Sylphy \ G11 \ 2006-1~	Air bag	x	x	x	
Sylphy \ G11 \ 2006-1~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2006-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2006-7~	BCM	x	x		
Sylphy \ G11 \ 2006-7~	Transmission	x	x	x	
Sylphy \ G11 \ 2006-7~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2006-7~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2006-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2006-7~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2006-7~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2006-7~	Engine	x	x	x	
Sylphy \ G11 \ 2006-7~	ABS	x	x	x	

Sylphy \ G11 \ 2006-7~	Air bag	x	x	x	
Sylphy \ G11 \ 2006-7~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2006-7~	Rearview camera			x	
Sylphy \ G11 \ 2006-7~	S/blind camera			x	
Sylphy \ G11 \ 2007-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ G11 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2007-4~	BCM	x	x		
Sylphy \ G11 \ 2007-4~	Transmission	x	x	x	
Sylphy \ G11 \ 2007-4~	Multi AV	x	x	x	
Sylphy \ G11 \ 2007-4~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2007-4~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2007-4~	E-4wd	x	x	x	
Sylphy \ G11 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2007-4~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2007-4~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2007-4~	ABS	x	x	x	
Sylphy \ G11 \ 2007-4~	Air bag	x	x	x	
Sylphy \ G11 \ 2007-4~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2007-4~	Engine	x	x	x	
Sylphy \ G11 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2008-1~	BCM	x	x		
Sylphy \ G11 \ 2008-1~	Transmission	x	x	x	
Sylphy \ G11 \ 2008-1~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2008-1~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2008-1~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2008-1~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2008-1~	Engine	x	x	x	
Sylphy \ G11 \ 2008-1~	ABS	x	x	x	
Sylphy \ G11 \ 2008-1~	Air bag	x	x	x	
Sylphy \ G11 \ 2008-1~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2008-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2008-7~	BCM	x	x		
Sylphy \ G11 \ 2008-7~	Transmission	x	x	x	
Sylphy \ G11 \ 2008-7~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2008-7~	IPDM E/R	x	x	x	

Sylphy \ G11 \ 2008-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2008-7~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2008-7~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2008-7~	Engine	x	x	x	
Sylphy \ G11 \ 2008-7~	ABS	x	x	x	
Sylphy \ G11 \ 2008-7~	Air bag	x	x	x	
Sylphy \ G11 \ 2008-7~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2008-7~	Rearview camera			x	
Sylphy \ G11 \ 2008-7~	S/blind camera			x	
Sylphy \ G11 \ 2009-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ G11 \ 2009-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2009-3~	BCM	x	x		
Sylphy \ G11 \ 2009-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sylphy \ G11 \ 2009-3~	Multi AV	x	x	x	0280
Sylphy \ G11 \ 2009-3~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2009-3~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2009-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2009-3~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2009-3~	All mode AWD/4WD	x	x	x	0245, 0311
Sylphy \ G11 \ 2009-3~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2009-3~	AVM		x	x	
Sylphy \ G11 \ 2009-3~	ABS	x	x	x	
Sylphy \ G11 \ 2009-3~	Air bag	x	x	x	
Sylphy \ G11 \ 2009-3~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2009-3~	Rearview camera			x	
Sylphy \ G11 \ 2009-3~	S/blind camera			x	
Sylphy \ G11 \ 2009-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2009-4~	BCM	x	x		
Sylphy \ G11 \ 2009-4~	Transmission	x	x	x	
Sylphy \ G11 \ 2009-4~	Multi AV		x	x	
Sylphy \ G11 \ 2009-4~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2009-4~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2009-4~	E-4wd	x	x	x	
Sylphy \ G11 \ 2009-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Sylphy \ G11 \ 2009-4~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2009-4~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2009-4~	Engine	x	x	x	
Sylphy \ G11 \ 2009-4~	ABS	x	x	x	
Sylphy \ G11 \ 2009-4~	Air bag	x	x	x	
Sylphy \ G11 \ 2009-4~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2009-4~	Rearview camera			x	
Sylphy \ G11 \ 2009-4~	S/blind camera			x	
Sylphy \ G11 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ G11 \ 2010-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2010-9~	BCM	x	x		
Sylphy \ G11 \ 2010-9~	Transmission	x	x	x	
Sylphy \ G11 \ 2010-9~	Multi AV		x	x	
Sylphy \ G11 \ 2010-9~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2010-9~	IPDM E/R	x	x	x	
Sylphy \ G11 \ 2010-9~	E-4wd	x	x	x	
Sylphy \ G11 \ 2010-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2010-9~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2010-9~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2010-9~	ABS	x	x	x	
Sylphy \ G11 \ 2010-9~	Air bag	x	x	x	
Sylphy \ G11 \ 2010-9~	Head lamp levelizer	x	x	x	
Sylphy \ G11 \ 2010-9~	Rearview camera			x	
Sylphy \ G11 \ 2010-9~	S/blind camera			x	
Sylphy \ G11 \ 2010-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Sylphy \ G11 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Sylphy \ G11 \ 2011-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Sylphy \ G11 \ 2011-9~	BCM	x	x		
Sylphy \ G11 \ 2011-9~	Transmission	x	x	x	
Sylphy \ G11 \ 2011-9~	EPS/DAST 3	x	x	x	
Sylphy \ G11 \ 2011-9~	IPDM E/R		x	x	
Sylphy \ G11 \ 2011-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Sylphy \ G11 \ 2011-9~	Auto drive position	x	x	x	
Sylphy \ G11 \ 2011-9~	Adaptive light	x	x	x	
Sylphy \ G11 \ 2011-9~	ABS	x	x	x	

Sylphy \ G11 \ 2011-9~	Air bag	x	x	x	
Sylphy \ G11 \ 2011-9~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2003-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2003-2~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2003-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2003-2~	BCM	x	x		
Teana \ J31 \ 2003-2~	Air bag	x	x	x	
Teana \ J31 \ 2003-2~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2003-2~	HVAC	x	x	x	
Teana \ J31 \ 2003-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2003-2~	Multi AV	x	x	x	0280
Teana \ J31 \ 2003-2~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2003-2~	IPDM E/R	x	x	x	
Teana \ J31 \ 2003-2~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2003-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2003-2~	DIU	x	x	x	
Teana \ J31 \ 2003-2~	Auto slide door	x	x	x	
Teana \ J31 \ 2003-2~	Auto drive position	x	x	x	
Teana \ J31 \ 2003-2~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2003-2~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2003-2~	Sonar	x	x	x	
Teana \ J31 \ 2003-2~	Lane camera	x	x	x	
Teana \ J31 \ 2003-2~	Adaptive light	x	x	x	
Teana \ J31 \ 2003-2~	AVM		x	x	
Teana \ J31 \ 2003-2~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2003-2~	Difference lock	x	x	x	
Teana \ J31 \ 2003-2~	Nats immu	x	x		
Teana \ J31 \ 2003-2~	Smart entrance	x	x		
Teana \ J31 \ 2003-2~	Air levelizer	x	x	x	
Teana \ J31 \ 2003-2~	Rearview camera			x	
Teana \ J31 \ 2003-2~	S/blind camera			x	
Teana \ J31 \ 2003-2~	Motor assist	x	x	x	
Teana \ J31 \ 2003-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2003-9~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2003-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2003-9~	BCM	x	x		
Teana \ J31 \ 2003-9~	Air bag	x	x	x	

Teana \ J31 \ 2003-9~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2003-9~	HVAC	x	x	x	
Teana \ J31 \ 2003-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2003-9~	Multi AV	x	x	x	0280
Teana \ J31 \ 2003-9~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2003-9~	IPDM E/R	x	x	x	
Teana \ J31 \ 2003-9~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2003-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2003-9~	DIU	x	x	x	
Teana \ J31 \ 2003-9~	Auto slide door	x	x	x	
Teana \ J31 \ 2003-9~	Auto drive position	x	x	x	
Teana \ J31 \ 2003-9~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2003-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2003-9~	Sonar	x	x	x	
Teana \ J31 \ 2003-9~	Lane camera	x	x	x	
Teana \ J31 \ 2003-9~	Adaptive light	x	x	x	
Teana \ J31 \ 2003-9~	AVM		x	x	
Teana \ J31 \ 2003-9~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2003-9~	Difference lock	x	x	x	
Teana \ J31 \ 2003-9~	Nats immu	x	x		
Teana \ J31 \ 2003-9~	Smart entrance	x	x		
Teana \ J31 \ 2003-9~	Air levelizer	x	x	x	
Teana \ J31 \ 2003-9~	Rearview camera			x	
Teana \ J31 \ 2003-9~	S/blind camera			x	
Teana \ J31 \ 2003-9~	Motor assist	x	x	x	
Teana \ J31 \ 2004-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2004-6~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2004-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2004-6~	BCM	x	x		
Teana \ J31 \ 2004-6~	Air bag	x	x	x	
Teana \ J31 \ 2004-6~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2004-6~	HVAC	x	x	x	
Teana \ J31 \ 2004-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2004-6~	Multi AV	x	x	x	0280
Teana \ J31 \ 2004-6~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2004-6~	IPDM E/R	x	x	x	
Teana \ J31 \ 2004-6~	Air pressure monitor	x	x	x	

Teana \ J31 \ 2004-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2004-6~	DIU	x	x	x	
Teana \ J31 \ 2004-6~	Auto slide door	x	x	x	
Teana \ J31 \ 2004-6~	Auto drive position	x	x	x	
Teana \ J31 \ 2004-6~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2004-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2004-6~	Sonar	x	x	x	
Teana \ J31 \ 2004-6~	Lane camera	x	x	x	
Teana \ J31 \ 2004-6~	Adaptive light	x	x	x	
Teana \ J31 \ 2004-6~	AVM		x	x	
Teana \ J31 \ 2004-6~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2004-6~	Difference lock	x	x	x	
Teana \ J31 \ 2004-6~	Nats immu	x	x		
Teana \ J31 \ 2004-6~	Smart entrance	x	x		
Teana \ J31 \ 2004-6~	Air levelizer	x	x	x	
Teana \ J31 \ 2004-6~	Rearview camera			x	
Teana \ J31 \ 2004-6~	S/blind camera			x	
Teana \ J31 \ 2004-6~	Motor assist	x	x	x	
Teana \ J31 \ 2004-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2004-7~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2004-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2004-7~	BCM	x	x		
Teana \ J31 \ 2004-7~	Air bag	x	x	x	
Teana \ J31 \ 2004-7~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2004-7~	HVAC	x	x	x	
Teana \ J31 \ 2004-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2004-7~	Multi AV	x	x	x	0280
Teana \ J31 \ 2004-7~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2004-7~	IPDM E/R	x	x	x	
Teana \ J31 \ 2004-7~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2004-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2004-7~	DIU	x	x	x	
Teana \ J31 \ 2004-7~	Auto slide door	x	x	x	
Teana \ J31 \ 2004-7~	Auto drive position	x	x	x	
Teana \ J31 \ 2004-7~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2004-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Teana \ J31 \ 2004-7~	Sonar	x	x	x	
Teana \ J31 \ 2004-7~	Lane camera	x	x	x	
Teana \ J31 \ 2004-7~	Adaptive light	x	x	x	
Teana \ J31 \ 2004-7~	AVM		x	x	
Teana \ J31 \ 2004-7~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2004-7~	Difference lock	x	x	x	
Teana \ J31 \ 2004-7~	Nats immu	x	x		
Teana \ J31 \ 2004-7~	Smart entrance	x	x		
Teana \ J31 \ 2004-7~	Air levelizer	x	x	x	
Teana \ J31 \ 2004-7~	Rearview camera			x	
Teana \ J31 \ 2004-7~	S/blind camera			x	
Teana \ J31 \ 2004-7~	Motor assist	x	x	x	
Teana \ J31 \ 2004-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2004-9~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2004-9~	BCM	x	x		
Teana \ J31 \ 2004-9~	Air bag	x	x	x	
Teana \ J31 \ 2004-9~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2004-9~	HVAC	x	x	x	
Teana \ J31 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2004-9~	Multi AV	x	x	x	0280
Teana \ J31 \ 2004-9~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2004-9~	IPDM E/R	x	x	x	
Teana \ J31 \ 2004-9~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2004-9~	DIU	x	x	x	
Teana \ J31 \ 2004-9~	Auto slide door	x	x	x	
Teana \ J31 \ 2004-9~	Auto drive position	x	x	x	
Teana \ J31 \ 2004-9~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2004-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2004-9~	Sonar	x	x	x	
Teana \ J31 \ 2004-9~	Lane camera	x	x	x	
Teana \ J31 \ 2004-9~	Adaptive light	x	x	x	
Teana \ J31 \ 2004-9~	AVM		x	x	
Teana \ J31 \ 2004-9~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2004-9~	Difference lock	x	x	x	
Teana \ J31 \ 2004-9~	Nats immu	x	x		
Teana \ J31 \ 2004-9~	Smart entrance	x	x		

Teana \ J31 \ 2004-9~	Air levelizer	x	x	x	
Teana \ J31 \ 2004-9~	Rearview camera			x	
Teana \ J31 \ 2004-9~	S/blind camera			x	
Teana \ J31 \ 2004-9~	Motor assist	x	x	x	
Teana \ J31 \ 2005-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2005-12~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Teana \ J31 \ 2005-12~	BCM	x	x		
Teana \ J31 \ 2005-12~	Air bag	x	x	x	
Teana \ J31 \ 2005-12~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2005-12~	HVAC	x	x	x	
Teana \ J31 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2005-12~	Multi AV	x	x	x	0280
Teana \ J31 \ 2005-12~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2005-12~	IPDM E/R	x	x	x	
Teana \ J31 \ 2005-12~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2005-12~	DIU	x	x	x	
Teana \ J31 \ 2005-12~	Auto slide door	x	x	x	
Teana \ J31 \ 2005-12~	Auto drive position	x	x	x	
Teana \ J31 \ 2005-12~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2005-12~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2005-12~	Sonar	x	x	x	
Teana \ J31 \ 2005-12~	Lane camera	x	x	x	
Teana \ J31 \ 2005-12~	Adaptive light	x	x	x	
Teana \ J31 \ 2005-12~	AVM		x	x	
Teana \ J31 \ 2005-12~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2005-12~	Difference lock	x	x	x	
Teana \ J31 \ 2005-12~	Nats immu	x	x		
Teana \ J31 \ 2005-12~	Smart entrance	x	x		
Teana \ J31 \ 2005-12~	Air levelizer	x	x	x	
Teana \ J31 \ 2005-12~	Rearview camera			x	
Teana \ J31 \ 2005-12~	S/blind camera			x	
Teana \ J31 \ 2005-12~	Motor assist	x	x	x	
Teana \ J31 \ 2006-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J31 \ 2006-4~	ABS	x	x	x	0003, 0092, 0264
Teana \ J31 \ 2006-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Teana \ J31 \ 2006-4~	BCM	x	x		
Teana \ J31 \ 2006-4~	Air bag	x	x	x	
Teana \ J31 \ 2006-4~	ICC/ADAS	x	x	x	
Teana \ J31 \ 2006-4~	HVAC	x	x	x	
Teana \ J31 \ 2006-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J31 \ 2006-4~	Multi AV	x	x	x	0280
Teana \ J31 \ 2006-4~	EPS/DAST 3	x	x	x	
Teana \ J31 \ 2006-4~	IPDM E/R	x	x	x	
Teana \ J31 \ 2006-4~	Air pressure monitor	x	x	x	
Teana \ J31 \ 2006-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2006-4~	DIU	x	x	x	
Teana \ J31 \ 2006-4~	Auto slide door	x	x	x	
Teana \ J31 \ 2006-4~	Auto drive position	x	x	x	
Teana \ J31 \ 2006-4~	All mode AWD/4WD	x	x	x	
Teana \ J31 \ 2006-4~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ J31 \ 2006-4~	Sonar	x	x	x	
Teana \ J31 \ 2006-4~	Lane camera	x	x	x	
Teana \ J31 \ 2006-4~	Adaptive light	x	x	x	
Teana \ J31 \ 2006-4~	AVM		x	x	
Teana \ J31 \ 2006-4~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2006-4~	Difference lock	x	x	x	
Teana \ J31 \ 2006-4~	Nats immu	x	x		
Teana \ J31 \ 2006-4~	Smart entrance	x	x		
Teana \ J31 \ 2006-4~	Air levelizer	x	x	x	
Teana \ J31 \ 2006-4~	Rearview camera			x	
Teana \ J31 \ 2006-4~	S/blind camera			x	
Teana \ J31 \ 2006-4~	Motor assist	x	x	x	
Teana \ J31 \ 2007-12~	Meter/M&A	x	x	x	0143, 0331
Teana \ J31 \ 2007-12~	BCM	x	x		
Teana \ J31 \ 2007-12~	Transmission	x	x	x	
Teana \ J31 \ 2007-12~	Multi AV	x	x	x	0280
Teana \ J31 \ 2007-12~	IPDM E/R	x	x	x	
Teana \ J31 \ 2007-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2007-12~	Auto drive position	x	x	x	
Teana \ J31 \ 2007-12~	Adaptive light	x	x	x	
Teana \ J31 \ 2007-12~	Engine	x	x	x	
Teana \ J31 \ 2007-12~	ABS	x	x	x	

Teana \ J31 \ 2007-12~	Air bag	x	x	x	
Teana \ J31 \ 2007-12~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2007-12~	Rearview camera			x	
Teana \ J31 \ 2007-6~	Meter/M&A	x	x	x	0143, 0331
Teana \ J31 \ 2007-6~	BCM	x	x		
Teana \ J31 \ 2007-6~	Transmission	x	x	x	
Teana \ J31 \ 2007-6~	Multi AV	x	x	x	0280
Teana \ J31 \ 2007-6~	IPDM E/R	x	x	x	
Teana \ J31 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Teana \ J31 \ 2007-6~	Auto drive position	x	x	x	
Teana \ J31 \ 2007-6~	Adaptive light	x	x	x	
Teana \ J31 \ 2007-6~	Engine	x	x	x	
Teana \ J31 \ 2007-6~	ABS	x	x	x	
Teana \ J31 \ 2007-6~	Air bag	x	x	x	
Teana \ J31 \ 2007-6~	Head lamp levelizer	x	x	x	
Teana \ J31 \ 2007-6~	Rearview camera			x	
Teana \ J32 \ 2008-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2008-2~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2008-2~	Meter/M&A		x	x	
Teana \ J32 \ 2008-2~	BCM		x		
Teana \ J32 \ 2008-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2008-2~	Transmission	x	x	x	
Teana \ J32 \ 2008-2~	Multi AV	x	x	x	
Teana \ J32 \ 2008-2~	IPDM E/R		x	x	
Teana \ J32 \ 2008-2~	Auto drive position		x	x	
Teana \ J32 \ 2008-2~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2008-2~	Adaptive light	x	x	x	
Teana \ J32 \ 2008-2~	Air bag	x	x	x	
Teana \ J32 \ 2008-2~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2008-2~	Rearview camera			x	
Teana \ J32 \ 2008-2~	Sonar	x	x	x	
Teana \ J32 \ 2008-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2008-4~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2008-4~	Meter/M&A		x	x	
Teana \ J32 \ 2008-4~	BCM		x		

Teana \ J32 \ 2008-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2008-4~	Transmission	x	x	x	
Teana \ J32 \ 2008-4~	Multi AV	x	x	x	
Teana \ J32 \ 2008-4~	IPDM E/R		x	x	
Teana \ J32 \ 2008-4~	Auto drive position		x	x	
Teana \ J32 \ 2008-4~	Adaptive light	x	x	x	
Teana \ J32 \ 2008-4~	Air bag	x	x	x	
Teana \ J32 \ 2008-4~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2008-6~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2008-6~	Meter/M&A		x	x	
Teana \ J32 \ 2008-6~	BCM		x		
Teana \ J32 \ 2008-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2008-6~	Transmission	x	x	x	
Teana \ J32 \ 2008-6~	Multi AV	x	x	x	
Teana \ J32 \ 2008-6~	IPDM E/R		x	x	
Teana \ J32 \ 2008-6~	Auto drive position		x	x	
Teana \ J32 \ 2008-6~	Adaptive light	x	x	x	
Teana \ J32 \ 2008-6~	Air bag	x	x	x	
Teana \ J32 \ 2008-6~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2008-6~	Sonar	x	x	x	
Teana \ J32 \ 2008-6~	Rearview camera			x	
Teana \ J32 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-10~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-10~	Meter/M&A		x	x	
Teana \ J32 \ 2009-10~	BCM		x		
Teana \ J32 \ 2009-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-10~	Transmission	x	x	x	
Teana \ J32 \ 2009-10~	Multi AV	x	x	x	
Teana \ J32 \ 2009-10~	IPDM E/R		x	x	
Teana \ J32 \ 2009-10~	Auto drive position		x	x	
Teana \ J32 \ 2009-10~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2009-10~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-10~	Air bag	x	x	x	
Teana \ J32 \ 2009-10~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-10~	Rearview camera			x	

Teana \ J32 \ 2009-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-1~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-1~	Meter/M&A		x	x	
Teana \ J32 \ 2009-1~	BCM		x		
Teana \ J32 \ 2009-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-1~	Transmission	x	x	x	
Teana \ J32 \ 2009-1~	Multi AV	x	x	x	
Teana \ J32 \ 2009-1~	IPDM E/R		x	x	
Teana \ J32 \ 2009-1~	Auto drive position		x	x	
Teana \ J32 \ 2009-1~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-1~	Air bag	x	x	x	
Teana \ J32 \ 2009-1~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-1~	Sonar	x	x	x	
Teana \ J32 \ 2009-1~	Rearview camera			x	
Teana \ J32 \ 2009-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-2~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-2~	Meter/M&A		x	x	
Teana \ J32 \ 2009-2~	BCM		x		
Teana \ J32 \ 2009-2~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-2~	Transmission	x	x	x	
Teana \ J32 \ 2009-2~	IPDM E/R		x	x	
Teana \ J32 \ 2009-2~	Auto drive position		x	x	
Teana \ J32 \ 2009-2~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2009-2~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-2~	Air bag	x	x	x	
Teana \ J32 \ 2009-2~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-2~	Sonar	x	x	x	
Teana \ J32 \ 2009-2~	Rearview camera			x	
Teana \ J32 \ 2009-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-4~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-4~	Meter/M&A		x	x	
Teana \ J32 \ 2009-4~	BCM		x		
Teana \ J32 \ 2009-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-4~	Transmission	x	x	x	
Teana \ J32 \ 2009-4~	Multi AV	x	x	x	

Teana \ J32 \ 2009-4~	IPDM E/R		x	x	
Teana \ J32 \ 2009-4~	Auto drive position		x	x	
Teana \ J32 \ 2009-4~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2009-4~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-4~	Air bag	x	x	x	
Teana \ J32 \ 2009-4~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-4~	Rearview camera			x	
Teana \ J32 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-8~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-8~	Meter/M&A		x	x	
Teana \ J32 \ 2009-8~	BCM		x		
Teana \ J32 \ 2009-8~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-8~	Transmission	x	x	x	
Teana \ J32 \ 2009-8~	Multi AV	x	x	x	
Teana \ J32 \ 2009-8~	IPDM E/R		x	x	
Teana \ J32 \ 2009-8~	Auto drive position		x	x	
Teana \ J32 \ 2009-8~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-8~	Air bag	x	x	x	
Teana \ J32 \ 2009-8~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2009-9~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2009-9~	Meter/M&A		x	x	
Teana \ J32 \ 2009-9~	BCM		x		
Teana \ J32 \ 2009-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2009-9~	Transmission	x	x	x	
Teana \ J32 \ 2009-9~	Multi AV	x	x	x	
Teana \ J32 \ 2009-9~	IPDM E/R		x	x	
Teana \ J32 \ 2009-9~	Auto drive position		x	x	
Teana \ J32 \ 2009-9~	Adaptive light	x	x	x	
Teana \ J32 \ 2009-9~	Air bag	x	x	x	
Teana \ J32 \ 2009-9~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2009-9~	Sonar	x	x	x	
Teana \ J32 \ 2009-9~	Rearview camera			x	
Teana \ J32 \ 2010-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2010-11~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2010-11~	Meter/M&A		x	x	

Teana \ J32 \ 2010-11~	BCM		x		
Teana \ J32 \ 2010-11~	HVAC		x	x	
Teana \ J32 \ 2010-11~	Transmission	x	x	x	
Teana \ J32 \ 2010-11~	Multi AV	x	x	x	
Teana \ J32 \ 2010-11~	IPDM E/R		x	x	
Teana \ J32 \ 2010-11~	Auto drive position		x	x	
Teana \ J32 \ 2010-11~	Adaptive light	x	x	x	
Teana \ J32 \ 2010-11~	Telematics		x	x	0253
Teana \ J32 \ 2010-11~	Air bag	x	x	x	
Teana \ J32 \ 2010-11~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2010-11~	Sonar	x	x	x	
Teana \ J32 \ 2010-11~	Rearview camera			x	
Teana \ J32 \ 2010-11~	S/blind camera			x	
Teana \ J32 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2010-7~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2010-7~	Meter/M&A		x	x	
Teana \ J32 \ 2010-7~	BCM		x		
Teana \ J32 \ 2010-7~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2010-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J32 \ 2010-7~	Multi AV	x	x	x	
Teana \ J32 \ 2010-7~	IPDM E/R		x	x	
Teana \ J32 \ 2010-7~	Auto drive position		x	x	
Teana \ J32 \ 2010-7~	Adaptive light	x	x	x	
Teana \ J32 \ 2010-7~	Air bag	x	x	x	
Teana \ J32 \ 2010-7~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2010-7~	Rearview camera			x	
Teana \ J32 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2010-9~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2010-9~	Meter/M&A		x	x	
Teana \ J32 \ 2010-9~	BCM		x		
Teana \ J32 \ 2010-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2010-9~	Transmission	x	x	x	
Teana \ J32 \ 2010-9~	Multi AV	x	x	x	
Teana \ J32 \ 2010-9~	IPDM E/R		x	x	
Teana \ J32 \ 2010-9~	Auto drive position		x	x	
Teana \ J32 \ 2010-9~	Adaptive light	x	x	x	
Teana \ J32 \ 2010-9~	Air bag	x	x	x	

Teana \ J32 \ 2010-9~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2010-9~	Sonar	x	x	x	
Teana \ J32 \ 2010-9~	Rearview camera			x	
Teana \ J32 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2011-10~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2011-10~	Meter/M&A		x	x	
Teana \ J32 \ 2011-10~	BCM		x		
Teana \ J32 \ 2011-10~	Air bag	x	x	x	
Teana \ J32 \ 2011-10~	ICC/ADAS	x	x	x	
Teana \ J32 \ 2011-10~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2011-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J32 \ 2011-10~	Multi AV	x	x	x	0280
Teana \ J32 \ 2011-10~	EPS/DAST 3	x	x	x	
Teana \ J32 \ 2011-10~	IPDM E/R		x	x	
Teana \ J32 \ 2011-10~	Auto drive position		x	x	
Teana \ J32 \ 2011-10~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2011-10~	Sonar	x	x	x	
Teana \ J32 \ 2011-10~	Adaptive light	x	x	x	
Teana \ J32 \ 2011-10~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2011-10~	Occupant detection			x	
Teana \ J32 \ 2011-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2011-2~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2011-2~	Meter/M&A		x	x	
Teana \ J32 \ 2011-2~	BCM		x		
Teana \ J32 \ 2011-2~	HVAC		x	x	
Teana \ J32 \ 2011-2~	Transmission	x	x	x	
Teana \ J32 \ 2011-2~	Multi AV	x	x	x	
Teana \ J32 \ 2011-2~	IPDM E/R		x	x	
Teana \ J32 \ 2011-2~	Auto drive position		x	x	
Teana \ J32 \ 2011-2~	Adaptive light	x	x	x	
Teana \ J32 \ 2011-2~	Telematics		x	x	0253
Teana \ J32 \ 2011-2~	Air bag	x	x	x	
Teana \ J32 \ 2011-2~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2011-2~	Sonar	x	x	x	
Teana \ J32 \ 2011-2~	Rearview camera			x	
Teana \ J32 \ 2011-2~	S/blind camera			x	
Teana \ J32 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Teana \ J32 \ 2011-6~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2011-6~	Meter/M&A		x	x	
Teana \ J32 \ 2011-6~	BCM		x		
Teana \ J32 \ 2011-6~	Air bag	x	x	x	
Teana \ J32 \ 2011-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2011-6~	Transmission	x	x	x	
Teana \ J32 \ 2011-6~	Multi AV		x	x	
Teana \ J32 \ 2011-6~	IPDM E/R		x	x	
Teana \ J32 \ 2011-6~	Auto drive position		x	x	
Teana \ J32 \ 2011-6~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2011-6~	Adaptive light	x	x	x	
Teana \ J32 \ 2011-6~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2011-9~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2011-9~	Meter/M&A		x	x	
Teana \ J32 \ 2011-9~	BCM		x		
Teana \ J32 \ 2011-9~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2011-9~	Transmission	x	x	x	
Teana \ J32 \ 2011-9~	Multi AV		x	x	
Teana \ J32 \ 2011-9~	IPDM E/R		x	x	
Teana \ J32 \ 2011-9~	Auto drive position		x	x	
Teana \ J32 \ 2011-9~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2011-9~	Sonar	x	x	x	
Teana \ J32 \ 2011-9~	Adaptive light	x	x	x	
Teana \ J32 \ 2011-9~	Air bag	x	x	x	
Teana \ J32 \ 2011-9~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2011-9~	SVT	x	x	x	
Teana \ J32 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2012-3~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2012-3~	Meter/M&A		x	x	
Teana \ J32 \ 2012-3~	BCM		x		
Teana \ J32 \ 2012-3~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2012-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J32 \ 2012-3~	Multi AV		x	x	
Teana \ J32 \ 2012-3~	IPDM E/R		x	x	
Teana \ J32 \ 2012-3~	Auto drive position		x	x	

Teana \ J32 \ 2012-3~	Adaptive light	x	x	x	
Teana \ J32 \ 2012-3~	Accele pedal ACT		x	x	
Teana \ J32 \ 2012-3~	Telematics		x	x	0253
Teana \ J32 \ 2012-3~	Air bag	x	x	x	
Teana \ J32 \ 2012-3~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2012-3~	Sonar	x	x	x	
Teana \ J32 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2012-6~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2012-6~	Meter/M&A		x	x	
Teana \ J32 \ 2012-6~	BCM		x		
Teana \ J32 \ 2012-6~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2012-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J32 \ 2012-6~	Multi AV		x	x	
Teana \ J32 \ 2012-6~	IPDM E/R		x	x	
Teana \ J32 \ 2012-6~	Auto drive position		x	x	
Teana \ J32 \ 2012-6~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2012-6~	Adaptive light	x	x	x	
Teana \ J32 \ 2012-6~	Air bag	x	x	x	
Teana \ J32 \ 2012-6~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2012-6~	Transmission	x	x	x	
Teana \ J32 \ 2012-6~	ICC/ADAS	x	x	x	
Teana \ J32 \ 2012-6~	Multi AV	x	x	x	0280
Teana \ J32 \ 2012-6~	EPS/DAST 3	x	x	x	
Teana \ J32 \ 2012-6~	Sonar	x	x	x	
Teana \ J32 \ 2012-6~	Occupant detection			x	
Teana \ J32 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ J32 \ 2016-4~	ABS	x	x	x	0003, 0092, 0264
Teana \ J32 \ 2016-4~	Meter/M&A		x	x	
Teana \ J32 \ 2016-4~	BCM		x		
Teana \ J32 \ 2016-4~	Air bag	x	x	x	
Teana \ J32 \ 2016-4~	ICC/ADAS	x	x	x	
Teana \ J32 \ 2016-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Teana \ J32 \ 2016-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Teana \ J32 \ 2016-4~	Multi AV	x	x	x	0280
Teana \ J32 \ 2016-4~	EPS/DAST 3	x	x	x	
Teana \ J32 \ 2016-4~	IPDM E/R		x	x	
Teana \ J32 \ 2016-4~	Auto drive position		x	x	

Teana \ J32 \ 2016-4~	All mode AWD/4WD		x	x	
Teana \ J32 \ 2016-4~	Sonar	x	x	x	
Teana \ J32 \ 2016-4~	Adaptive light	x	x	x	
Teana \ J32 \ 2016-4~	Head lamp levelizer	x	x	x	
Teana \ J32 \ 2016-4~	Occupant detection			x	
Teana \ L33 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2013-11~	ABS		x	x	
Teana \ L33 \ 2013-11~	Meter/M&A		x	x	
Teana \ L33 \ 2013-11~	BCM		x		
Teana \ L33 \ 2013-11~	Air bag		x	x	
Teana \ L33 \ 2013-11~	HVAC		x	x	
Teana \ L33 \ 2013-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2013-11~	Multi AV	x	x	x	0280
Teana \ L33 \ 2013-11~	EPS/DAST 3		x	x	
Teana \ L33 \ 2013-11~	IPDM E/R		x	x	
Teana \ L33 \ 2013-11~	Auto drive position		x	x	
Teana \ L33 \ 2013-11~	Sonar		x	x	
Teana \ L33 \ 2013-11~	AVM		x	x	
Teana \ L33 \ 2013-11~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2013-11~	Occupant detection			x	
Teana \ L33 \ 2013-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2013-12~	ABS		x	x	
Teana \ L33 \ 2013-12~	Meter/M&A		x	x	
Teana \ L33 \ 2013-12~	BCM		x		
Teana \ L33 \ 2013-12~	Air bag		x	x	
Teana \ L33 \ 2013-12~	HVAC		x	x	
Teana \ L33 \ 2013-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2013-12~	Multi AV	x	x	x	0280
Teana \ L33 \ 2013-12~	EPS/DAST 3		x	x	
Teana \ L33 \ 2013-12~	IPDM E/R		x	x	
Teana \ L33 \ 2013-12~	Auto drive position		x	x	
Teana \ L33 \ 2013-12~	AVM		x	x	
Teana \ L33 \ 2013-12~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2013-12~	Occupant detection			x	
Teana \ L33 \ 2013-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2013-2~	ABS		x	x	

Teana \ L33 \ 2013-2~	Meter/M&A		x	x	
Teana \ L33 \ 2013-2~	BCM		x		
Teana \ L33 \ 2013-2~	Air bag		x	x	
Teana \ L33 \ 2013-2~	HVAC		x	x	
Teana \ L33 \ 2013-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2013-2~	Multi AV	x	x	x	0280
Teana \ L33 \ 2013-2~	EPS/DAST 3		x	x	
Teana \ L33 \ 2013-2~	IPDM E/R		x	x	
Teana \ L33 \ 2013-2~	Auto drive position		x	x	
Teana \ L33 \ 2013-2~	Sonar		x	x	
Teana \ L33 \ 2013-2~	Telematics		x	x	0253
Teana \ L33 \ 2013-2~	AVM		x	x	
Teana \ L33 \ 2013-2~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2013-2~	Occupant detection			x	
Teana \ L33 \ 2013-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2013-7~	ABS		x	x	
Teana \ L33 \ 2013-7~	Meter/M&A		x	x	
Teana \ L33 \ 2013-7~	BCM		x		
Teana \ L33 \ 2013-7~	Air bag		x	x	
Teana \ L33 \ 2013-7~	HVAC		x	x	
Teana \ L33 \ 2013-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2013-7~	Multi AV	x	x	x	0280
Teana \ L33 \ 2013-7~	EPS/DAST 3		x	x	
Teana \ L33 \ 2013-7~	IPDM E/R		x	x	
Teana \ L33 \ 2013-7~	Auto drive position		x	x	
Teana \ L33 \ 2013-7~	Sonar		x	x	
Teana \ L33 \ 2013-7~	AVM		x	x	
Teana \ L33 \ 2013-7~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2013-7~	Occupant detection			x	
Teana \ L33 \ 2013-7~	SVT	x	x	x	
Teana \ L33 \ 2013-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2013-9~	ABS		x	x	
Teana \ L33 \ 2013-9~	Meter/M&A		x	x	
Teana \ L33 \ 2013-9~	BCM		x		
Teana \ L33 \ 2013-9~	Air bag		x	x	
Teana \ L33 \ 2013-9~	HVAC		x	x	

Teana \ L33 \ 2013-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2013-9~	Multi AV	x	x	x	0280
Teana \ L33 \ 2013-9~	EPS/DAST 3		x	x	
Teana \ L33 \ 2013-9~	IPDM E/R		x	x	
Teana \ L33 \ 2013-9~	Auto drive position		x	x	
Teana \ L33 \ 2013-9~	Sonar		x	x	
Teana \ L33 \ 2013-9~	AVM		x	x	
Teana \ L33 \ 2013-9~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2013-9~	Occupant detection			x	
Teana \ L33 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2014-1~	ABS		x	x	
Teana \ L33 \ 2014-1~	Meter/M&A		x	x	
Teana \ L33 \ 2014-1~	BCM		x		
Teana \ L33 \ 2014-1~	Air bag		x	x	
Teana \ L33 \ 2014-1~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2014-1~	HVAC		x	x	
Teana \ L33 \ 2014-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2014-1~	Multi AV		x	x	
Teana \ L33 \ 2014-1~	EPS/DAST 3		x	x	
Teana \ L33 \ 2014-1~	IPDM E/R		x	x	
Teana \ L33 \ 2014-1~	Air pressure monitor		x	x	
Teana \ L33 \ 2014-1~	Laser/radar	x	x	x	
Teana \ L33 \ 2014-1~	Auto drive position		x	x	
Teana \ L33 \ 2014-1~	Sonar	x	x	x	
Teana \ L33 \ 2014-1~	Side radar left		x	x	
Teana \ L33 \ 2014-1~	Side radar right		x	x	
Teana \ L33 \ 2014-1~	PTC heater		x	x	
Teana \ L33 \ 2014-1~	AVM		x	x	
Teana \ L33 \ 2014-1~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2014-1~	Occupant detection			x	
Teana \ L33 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2014-4~	ABS		x	x	
Teana \ L33 \ 2014-4~	Meter/M&A		x	x	
Teana \ L33 \ 2014-4~	BCM		x		
Teana \ L33 \ 2014-4~	Air bag		x	x	
Teana \ L33 \ 2014-4~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2014-4~	HVAC		x	x	

Teana \ L33 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2014-4~	Multi AV	x	x	x	0280
Teana \ L33 \ 2014-4~	EPS/DAST 3		x	x	
Teana \ L33 \ 2014-4~	IPDM E/R		x	x	
Teana \ L33 \ 2014-4~	Laser/radar	x	x	x	
Teana \ L33 \ 2014-4~	Auto drive position		x	x	
Teana \ L33 \ 2014-4~	Sonar		x	x	
Teana \ L33 \ 2014-4~	CAN gateway		x	x	
Teana \ L33 \ 2014-4~	Side radar left		x	x	
Teana \ L33 \ 2014-4~	Side radar right		x	x	
Teana \ L33 \ 2014-4~	Telematics		x	x	0253
Teana \ L33 \ 2014-4~	AVM		x	x	
Teana \ L33 \ 2014-4~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2014-4~	Occupant detection			x	
Teana \ L33 \ 2014-4~	CAN gateway		x		
Teana \ L33 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2014-6~	ABS	x	x	x	
Teana \ L33 \ 2014-6~	Meter/M&A		x	x	
Teana \ L33 \ 2014-6~	BCM		x		
Teana \ L33 \ 2014-6~	Air bag		x	x	
Teana \ L33 \ 2014-6~	ICC/ADAS		x	x	
Teana \ L33 \ 2014-6~	HVAC		x	x	
Teana \ L33 \ 2014-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2014-6~	Multi AV	x	x	x	0280
Teana \ L33 \ 2014-6~	EPS/DAST 3		x	x	
Teana \ L33 \ 2014-6~	IPDM E/R		x	x	
Teana \ L33 \ 2014-6~	Air pressure monitor		x	x	
Teana \ L33 \ 2014-6~	Auto drive position		x	x	
Teana \ L33 \ 2014-6~	Sonar		x	x	
Teana \ L33 \ 2014-6~	Lane camera		x	x	
Teana \ L33 \ 2014-6~	Side radar left		x	x	
Teana \ L33 \ 2014-6~	Side radar right		x	x	
Teana \ L33 \ 2014-6~	Telematics		x	x	0253
Teana \ L33 \ 2014-6~	AVM		x	x	
Teana \ L33 \ 2014-6~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2014-6~	Occupant detection			x	
Teana \ L33 \ 2014-6~	SVT	x	x	x	

Teana \ L33 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2014-8~	ABS		x	x	
Teana \ L33 \ 2014-8~	Meter/M&A		x	x	
Teana \ L33 \ 2014-8~	BCM		x		
Teana \ L33 \ 2014-8~	Air bag		x	x	
Teana \ L33 \ 2014-8~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2014-8~	HVAC		x	x	
Teana \ L33 \ 2014-8~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2014-8~	Multi AV	x	x	x	0280
Teana \ L33 \ 2014-8~	EPS/DAST 3		x	x	
Teana \ L33 \ 2014-8~	IPDM E/R		x	x	
Teana \ L33 \ 2014-8~	Laser/radar	x	x	x	
Teana \ L33 \ 2014-8~	Auto drive position		x	x	
Teana \ L33 \ 2014-8~	Sonar		x	x	
Teana \ L33 \ 2014-8~	CAN gateway		x	x	
Teana \ L33 \ 2014-8~	Side radar left		x	x	
Teana \ L33 \ 2014-8~	Side radar right		x	x	
Teana \ L33 \ 2014-8~	Telematics		x	x	0253
Teana \ L33 \ 2014-8~	AVM		x	x	
Teana \ L33 \ 2014-8~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2014-8~	Occupant detection			x	
Teana \ L33 \ 2015-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2015-1~	ABS		x	x	
Teana \ L33 \ 2015-1~	Meter/M&A		x	x	
Teana \ L33 \ 2015-1~	BCM		x		
Teana \ L33 \ 2015-1~	Air bag		x	x	
Teana \ L33 \ 2015-1~	ICC/ADAS		x	x	
Teana \ L33 \ 2015-1~	HVAC		x	x	
Teana \ L33 \ 2015-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2015-1~	EPS/DAST 3		x	x	
Teana \ L33 \ 2015-1~	IPDM E/R		x	x	
Teana \ L33 \ 2015-1~	Auto drive position		x	x	
Teana \ L33 \ 2015-1~	Sonar		x	x	
Teana \ L33 \ 2015-1~	Lane camera		x	x	
Teana \ L33 \ 2015-1~	Side radar left		x	x	
Teana \ L33 \ 2015-1~	Side radar right		x	x	
Teana \ L33 \ 2015-1~	AVM		x	x	

Teana \ L33 \ 2015-1~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2015-1~	Occupant detection			x	
Teana \ L33 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2015-3~	ABS	x	x	x	
Teana \ L33 \ 2015-3~	Meter/M&A		x	x	
Teana \ L33 \ 2015-3~	BCM		x		
Teana \ L33 \ 2015-3~	Air bag		x	x	
Teana \ L33 \ 2015-3~	ICC/ADAS		x	x	
Teana \ L33 \ 2015-3~	HVAC		x	x	
Teana \ L33 \ 2015-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2015-3~	Multi AV	x	x	x	0280
Teana \ L33 \ 2015-3~	EPS/DAST 3		x	x	
Teana \ L33 \ 2015-3~	IPDM E/R		x	x	
Teana \ L33 \ 2015-3~	Air pressure monitor		x	x	
Teana \ L33 \ 2015-3~	Auto drive position		x	x	
Teana \ L33 \ 2015-3~	Sonar		x	x	
Teana \ L33 \ 2015-3~	Lane camera		x	x	
Teana \ L33 \ 2015-3~	Side radar left		x	x	
Teana \ L33 \ 2015-3~	Side radar right		x	x	
Teana \ L33 \ 2015-3~	Telematics		x	x	0253
Teana \ L33 \ 2015-3~	AVM		x	x	
Teana \ L33 \ 2015-3~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2015-3~	Occupant detection			x	
Teana \ L33 \ 2015-3~	SVT	x	x	x	
Teana \ L33 \ 2016-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2016-2~	ABS		x	x	
Teana \ L33 \ 2016-2~	Meter/M&A		x	x	
Teana \ L33 \ 2016-2~	BCM		x		
Teana \ L33 \ 2016-2~	Air bag		x	x	
Teana \ L33 \ 2016-2~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2016-2~	HVAC		x	x	
Teana \ L33 \ 2016-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2016-2~	Multi AV	x	x	x	0280
Teana \ L33 \ 2016-2~	EPS/DAST 3		x	x	
Teana \ L33 \ 2016-2~	IPDM E/R		x	x	
Teana \ L33 \ 2016-2~	Air pressure monitor		x	x	
Teana \ L33 \ 2016-2~	Laser/radar		x	x	

Teana \ L33 \ 2016-2~	Auto drive position		x	x	
Teana \ L33 \ 2016-2~	Sonar		x	x	
Teana \ L33 \ 2016-2~	Side radar left		x	x	
Teana \ L33 \ 2016-2~	Side radar right		x	x	
Teana \ L33 \ 2016-2~	AVM		x	x	
Teana \ L33 \ 2016-2~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2016-2~	Occupant detection			x	
Teana \ L33 \ 2016-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2016-6~	ABS		x	x	
Teana \ L33 \ 2016-6~	Meter/M&A		x	x	
Teana \ L33 \ 2016-6~	BCM		x		
Teana \ L33 \ 2016-6~	Air bag		x	x	
Teana \ L33 \ 2016-6~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2016-6~	HVAC		x	x	
Teana \ L33 \ 2016-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2016-6~	Multi AV	x	x	x	0280
Teana \ L33 \ 2016-6~	EPS/DAST 3		x	x	
Teana \ L33 \ 2016-6~	IPDM E/R		x	x	
Teana \ L33 \ 2016-6~	Air pressure monitor		x	x	
Teana \ L33 \ 2016-6~	Auto drive position		x	x	
Teana \ L33 \ 2016-6~	Sonar		x	x	
Teana \ L33 \ 2016-6~	Lane camera		x	x	
Teana \ L33 \ 2016-6~	Side radar left		x	x	
Teana \ L33 \ 2016-6~	Side radar right		x	x	
Teana \ L33 \ 2016-6~	Telematics		x	x	0253
Teana \ L33 \ 2016-6~	AVM		x	x	
Teana \ L33 \ 2016-6~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2016-6~	Occupant detection			x	
Teana \ L33 \ 2016-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Teana \ L33 \ 2016-9~	ABS		x	x	
Teana \ L33 \ 2016-9~	Meter/M&A		x	x	
Teana \ L33 \ 2016-9~	BCM		x		
Teana \ L33 \ 2016-9~	Air bag		x	x	
Teana \ L33 \ 2016-9~	ICC/ADAS	x	x	x	
Teana \ L33 \ 2016-9~	HVAC		x	x	
Teana \ L33 \ 2016-9~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Teana \ L33 \ 2016-9~	Multi AV	x	x	x	0280

Teana \ L33 \ 2016-9~	EPS/DAST 3		x	x	
Teana \ L33 \ 2016-9~	IPDM E/R		x	x	
Teana \ L33 \ 2016-9~	Air pressure monitor		x	x	
Teana \ L33 \ 2016-9~	Laser/radar		x	x	
Teana \ L33 \ 2016-9~	Auto drive position		x	x	
Teana \ L33 \ 2016-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Teana \ L33 \ 2016-9~	Sonar	x	x	x	
Teana \ L33 \ 2016-9~	4WAS(front)	x	x	x	
Teana \ L33 \ 2016-9~	Accele pedal ACT		x	x	
Teana \ L33 \ 2016-9~	Side radar left		x	x	
Teana \ L33 \ 2016-9~	Side radar right		x	x	
Teana \ L33 \ 2016-9~	Head lamp levelizer	x	x	x	
Teana \ L33 \ 2016-9~	Occupant detection			x	
Terrano \ D10 \ 2015-10~	Engine		x	x	0064, 0041, 0148, 0061, 0168, 0191, 0270, 0192, 0219, 0041, 0134, 0230, 0135, 0132, 0133, 0138, 0112, 0139, 0136, 0029, 0137, 0157, 0241, 0262, 0282, 0281, 0220
Terrano \ D10 \ 2015-10~	ABS	x	x	x	0174, 0001, 0336, 0263, 0160, 0284, 0247, 0174, 0302, 0268, 0056, 0056
Terrano \ D10 \ 2015-10~	BCM		x	x	
Terrano \ D10 \ 2015-10~	Air bag		x	x	0259, 0317, 0341
Terrano \ D10 \ 2015-10~	Transmission		x	x	0033, 0182, 0336, 0337
Terrano \ D10 \ 2015-10~	Cluster		x	x	
Terrano \ D10 \ 2015-10~	HANDS FREE MODULE		x	x	
Terrano \ D10 \ 2015-10~	HVAC		x	x	
Terrano \ D10 \ 2015-10~	Cluster	x	x	x	0312
Terrano \ D10 \ 2016-4~	Engine		x	x	0064, 0041, 0148, 0061, 0168, 0191, 0270, 0192, 0219, 0041, 0134, 0230, 0135, 0132, 0133, 0138, 0112, 0139, 0136, 0029, 0137, 0157, 0241, 0262, 0282, 0281, 0220
Terrano \ D10 \ 2016-4~	ABS	x	x	x	0174, 0001, 0336, 0263, 0160, 0284, 0247, 0174, 0302, 0268, 0056, 0056
Terrano \ D10 \ 2016-4~	BCM		x	x	
Terrano \ D10 \ 2016-4~	Air bag		x	x	0259, 0317, 0341
Terrano \ D10 \ 2016-4~	HVAC		x	x	
Terrano \ D10 \ 2016-4~	Cluster	x	x	x	0312
Terrano \ R20 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Terrano \ R20 \ All Year	ABS	x	x	x	0003, 0092, 0264

Terrano \ R20 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Terrano \ R20 \ All Year	BCM	x	x		
Terrano \ R20 \ All Year	Air bag	x	x	x	
Terrano \ R20 \ All Year	ICC/ADAS	x	x	x	
Terrano \ R20 \ All Year	HVAC	x	x	x	
Terrano \ R20 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Terrano \ R20 \ All Year	Multi AV	x	x	x	0280
Terrano \ R20 \ All Year	EPS/DAST 3	x	x	x	
Terrano \ R20 \ All Year	IPDM E/R	x	x	x	
Terrano \ R20 \ All Year	Air pressure monitor	x	x	x	
Terrano \ R20 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Terrano \ R20 \ All Year	DIU	x	x	x	
Terrano \ R20 \ All Year	Auto slide door	x	x	x	
Terrano \ R20 \ All Year	Auto drive position	x	x	x	
Terrano \ R20 \ All Year	All mode AWD/4WD	x	x	x	
Terrano \ R20 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Terrano \ R20 \ All Year	Sonar	x	x	x	
Terrano \ R20 \ All Year	Lane camera	x	x	x	
Terrano \ R20 \ All Year	Adaptive light	x	x	x	
Terrano \ R20 \ All Year	AVM		x	x	
Terrano \ R20 \ All Year	Head lamp levelizer	x	x	x	
Terrano \ R20 \ All Year	Difference lock	x	x	x	
Terrano \ R20 \ All Year	Nats immu	x	x		
Terrano \ R20 \ All Year	Smart entrance	x	x		
Terrano \ R20 \ All Year	Air levelizer	x	x	x	
Terrano \ R20 \ All Year	Rearview camera			x	
Terrano \ R20 \ All Year	S/blind camera			x	
Terrano \ R20 \ All Year	Motor assist	x	x	x	
Terrano \ R50 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Terrano \ R50 \ All Year	ABS	x	x	x	0003, 0092, 0264
Terrano \ R50 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Terrano \ R50 \ All Year	BCM	x	x		
Terrano \ R50 \ All Year	Air bag	x	x	x	
Terrano \ R50 \ All Year	ICC/ADAS	x	x	x	
Terrano \ R50 \ All Year	HVAC	x	x	x	
Terrano \ R50 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Terrano \ R50 \ All Year	Multi AV	x	x	x	0280
Terrano \ R50 \ All Year	EPS/DAST 3	x	x	x	

Terrano \ R50 \ All Year	IPDM E/R	x	x	x	
Terrano \ R50 \ All Year	Air pressure monitor	x	x	x	
Terrano \ R50 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Terrano \ R50 \ All Year	DIU	x	x	x	
Terrano \ R50 \ All Year	Auto slide door	x	x	x	
Terrano \ R50 \ All Year	Auto drive position	x	x	x	
Terrano \ R50 \ All Year	All mode AWD/4WD	x	x	x	
Terrano \ R50 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Terrano \ R50 \ All Year	Sonar	x	x	x	
Terrano \ R50 \ All Year	Lane camera	x	x	x	
Terrano \ R50 \ All Year	Adaptive light	x	x	x	
Terrano \ R50 \ All Year	AVM		x	x	
Terrano \ R50 \ All Year	Head lamp levelizer	x	x	x	
Terrano \ R50 \ All Year	Difference lock	x	x	x	
Terrano \ R50 \ All Year	Nats immu	x	x		
Terrano \ R50 \ All Year	Smart entrance	x	x		
Terrano \ R50 \ All Year	Air levelizer	x	x	x	
Terrano \ R50 \ All Year	Rearview camera			x	
Terrano \ R50 \ All Year	S/blind camera			x	
Terrano \ R50 \ All Year	Motor assist	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Terrano-Regulus \ JR50 \ All Year	ABS	x	x	x	0003, 0092, 0264
Terrano-Regulus \ JR50 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Terrano-Regulus \ JR50 \ All Year	BCM	x	x		
Terrano-Regulus \ JR50 \ All Year	Air bag	x	x	x	
Terrano-Regulus \ JR50 \ All Year	ICC/ADAS	x	x	x	
Terrano-Regulus \ JR50 \ All Year	HVAC	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Terrano-Regulus \ JR50 \ All Year	Multi AV	x	x	x	0280
Terrano-Regulus \ JR50 \ All Year	EPS/DAST 3	x	x	x	
Terrano-Regulus \ JR50 \ All Year	IPDM E/R	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Air pressure monitor	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Terrano-Regulus \ JR50 \ All Year	DIU	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Auto slide door	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Auto drive position	x	x	x	

Terrano-Regulus \ JR50 \ All Year	All mode AWD/4WD	x	x	x	
Terrano-Regulus \ JR50 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Sonar	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Lane camera	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Adaptive light	x	x	x	
Terrano-Regulus \ JR50 \ All Year	AVM		x	x	
Terrano-Regulus \ JR50 \ All Year	Head lamp levelizer	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Difference lock	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Nats immu	x	x		
Terrano-Regulus \ JR50 \ All Year	Smart entrance	x	x		
Terrano-Regulus \ JR50 \ All Year	Air levelizer	x	x	x	
Terrano-Regulus \ JR50 \ All Year	Rearview camera			x	
Terrano-Regulus \ JR50 \ All Year	S/blind camera			x	
Terrano-Regulus \ JR50 \ All Year	Motor assist	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2005-12~	BCM	x	x		
Tiida hatchback \ C11 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2005-12~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2005-12~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2005-8~	BCM	x	x		
Tiida hatchback \ C11 \ 2005-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2005-8~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2005-8~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2005-9~	BCM	x	x		
Tiida hatchback \ C11 \ 2005-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2005-9~	Multi AV	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	IPDM E/R	x	x	x	

Tiida hatchback \ C11 \ 2005-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2005-9~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2005-9~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2006-6~	BCM	x	x		
Tiida hatchback \ C11 \ 2006-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2006-6~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2006-6~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2006-6~	DIU	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2007-10~	BCM	x	x		
Tiida hatchback \ C11 \ 2007-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2007-10~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Intelligent key	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2007-10~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2007-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2007-11~	BCM	x	x		
Tiida hatchback \ C11 \ 2007-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2007-11~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2007-11~	Auto drive position	x	x	x	

Tiida hatchback \ C11 \ 2007-11~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2007-11~	Rearview camera			x	
Tiida hatchback \ C11 \ 2007-11~	S/blind camera			x	
Tiida hatchback \ C11 \ 2007-3~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2007-3~	BCM	x	x		
Tiida hatchback \ C11 \ 2007-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2007-3~	Multi AV	x	x	x	0280
Tiida hatchback \ C11 \ 2007-3~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2007-3~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2007-3~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2007-5~	BCM	x	x		
Tiida hatchback \ C11 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2007-5~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2007-5~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2007-5~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2007-6~	BCM	x	x		
Tiida hatchback \ C11 \ 2007-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2007-6~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2007-6~	Air bag	x	x	x	

Tiida hatchback \ C11 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2008-1~	BCM	x	x		
Tiida hatchback \ C11 \ 2008-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2008-1~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2008-1~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2008-1~	Rearview camera			x	
Tiida hatchback \ C11 \ 2008-1~	S/blind camera			x	
Tiida hatchback \ C11 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2008-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2008-6~	BCM	x	x		
Tiida hatchback \ C11 \ 2008-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2008-6~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2008-6~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2008-6~	Rearview camera			x	
Tiida hatchback \ C11 \ 2008-6~	S/blind camera			x	
Tiida hatchback \ C11 \ 2008-7~	Engine	x	x	x	
Tiida hatchback \ C11 \ 2008-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2008-7~	BCM	x	x		
Tiida hatchback \ C11 \ 2008-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2008-7~	Multi AV	x	x	x	0280
Tiida hatchback \ C11 \ 2008-7~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2008-7~	IPDM E/R	x	x	x	

Tiida hatchback \ C11 \ 2008-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2008-7~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2008-7~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2008-7~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2008-7~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2008-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2008-9~	BCM	x	x		
Tiida hatchback \ C11 \ 2008-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2008-9~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2008-9~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2008-9~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2009-11~	BCM	x	x		
Tiida hatchback \ C11 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2009-11~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2009-11~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2009-11~	Rearview camera			x	
Tiida hatchback \ C11 \ 2009-11~	S/blind camera			x	
Tiida hatchback \ C11 \ 2009-11~	DIU	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Tiida hatchback \ C11 \ 2009-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2009-3~	BCM	x	x		
Tiida hatchback \ C11 \ 2009-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2009-3~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2009-3~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2009-3~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2009-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2009-6~	BCM	x	x		
Tiida hatchback \ C11 \ 2009-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2009-6~	Multi AV	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	E-4wd	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2009-6~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2009-6~	Rearview camera			x	
Tiida hatchback \ C11 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2009-9~	BCM	x	x		
Tiida hatchback \ C11 \ 2009-9~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2009-9~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Tiida hatchback \ C11 \ 2009-9~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	SVT	x	x	x	
Tiida hatchback \ C11 \ 2009-9~	S/blind camera			x	
Tiida hatchback \ C11 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2010-2~	BCM	x	x		
Tiida hatchback \ C11 \ 2010-2~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2010-2~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2010-2~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	SVT	x	x	x	
Tiida hatchback \ C11 \ 2010-2~	Rearview camera			x	
Tiida hatchback \ C11 \ 2010-2~	S/blind camera			x	
Tiida hatchback \ C11 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2010-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2010-3~	BCM	x	x		
Tiida hatchback \ C11 \ 2010-3~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2010-3~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2010-3~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	SVT	x	x	x	
Tiida hatchback \ C11 \ 2010-3~	Rearview camera			x	

Tiida hatchback \ C11 \ 2010-3~	S/blind camera			×	
Tiida hatchback \ C11 \ 2010-5~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2010-5~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2010-5~	BCM	×	×		
Tiida hatchback \ C11 \ 2010-5~	Air bag	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2010-5~	EPS/DAST 3	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	IPDM E/R	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2010-5~	Auto drive position	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	Adaptive light	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	ABS	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	Head lamp levelizer	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	SVT	×	×	×	
Tiida hatchback \ C11 \ 2010-5~	Rearview camera			×	
Tiida hatchback \ C11 \ 2010-5~	S/blind camera			×	
Tiida hatchback \ C11 \ 2010-6~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2010-6~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2010-6~	BCM	×	×		
Tiida hatchback \ C11 \ 2010-6~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2010-6~	EPS/DAST 3	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	IPDM E/R	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2010-6~	Auto drive position	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	Adaptive light	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	ABS	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	Air bag	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	Head lamp levelizer	×	×	×	
Tiida hatchback \ C11 \ 2010-6~	Rearview camera			×	
Tiida hatchback \ C11 \ 2010-6~	S/blind camera			×	
Tiida hatchback \ C11 \ 2010-8~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2010-8~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2010-8~	BCM	×	×		
Tiida hatchback \ C11 \ 2010-8~	Transmission	×	×	×	0076, 0113, 0076, 0083, 0100, 0059

Tiida hatchback \ C11 \ 2010-8~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2010-8~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	Rearview camera			x	
Tiida hatchback \ C11 \ 2010-8~	S/blind camera			x	
Tiida hatchback \ C11 \ 2010-8~	Multi AV	x	x	x	
Tiida hatchback \ C11 \ 2010-8~	E-4wd	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2011-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2011-6~	BCM	x	x		
Tiida hatchback \ C11 \ 2011-6~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2011-6~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2011-6~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2011-6~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2012-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2012-4~	BCM	x	x		
Tiida hatchback \ C11 \ 2012-4~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2012-4~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2012-4~	Auto drive position	x	x	x	

Tiida hatchback \ C11 \ 2012-4~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2012-4~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2012-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2012-9~	BCM	x	x		
Tiida hatchback \ C11 \ 2012-9~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2012-9~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2012-9~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida hatchback \ C11 \ 2013-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida hatchback \ C11 \ 2013-1~	BCM	x	x		
Tiida hatchback \ C11 \ 2013-1~	Air bag	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida hatchback \ C11 \ 2013-1~	Multi AV	x	x	x	0280
Tiida hatchback \ C11 \ 2013-1~	EPS/DAST 3	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	IPDM E/R	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Air pressure monitor		x	x	
Tiida hatchback \ C11 \ 2013-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida hatchback \ C11 \ 2013-1~	Auto drive position	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Adaptive light	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	ABS	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Head lamp levelizer	x	x	x	
Tiida hatchback \ C11 \ 2013-1~	Rearview camera			x	
Tiida hatchback \ C11 \ 2013-1~	S/blind camera			x	
Tiida latio \ SC11 \ 2004-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2004-10~	BCM	x	x		
Tiida latio \ SC11 \ 2004-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2004-10~	Multi AV	x	x	x	0280
Tiida latio \ SC11 \ 2004-10~	EPS/DAST 3	x	x	x	

Tiida latio \ SC11 \ 2004-10~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2004-10~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2004-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2004-10~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2004-10~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2004-10~	Engine	x	x	x	
Tiida latio \ SC11 \ 2004-10~	ABS	x	x	x	
Tiida latio \ SC11 \ 2004-10~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2004-10~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2005-12~	BCM	x	x		
Tiida latio \ SC11 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2005-12~	Multi AV	x	x	x	0280
Tiida latio \ SC11 \ 2005-12~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2005-12~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2005-12~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2005-12~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Engine	x	x	x	
Tiida latio \ SC11 \ 2005-12~	ABS	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2005-12~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida latio \ SC11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2006-12~	BCM	x	x		
Tiida latio \ SC11 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2006-12~	Multi AV	x	x	x	
Tiida latio \ SC11 \ 2006-12~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2006-12~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2006-12~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2006-12~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2006-12~	Adaptive light	x	x	x	

Tiida latio \ SC11 \ 2006-12~	ABS	x	x	x	
Tiida latio \ SC11 \ 2006-12~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2006-12~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2007-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida latio \ SC11 \ 2007-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2007-12~	BCM	x	x		
Tiida latio \ SC11 \ 2007-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2007-12~	Multi AV	x	x	x	
Tiida latio \ SC11 \ 2007-12~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2007-12~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2007-12~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2007-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2007-12~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2007-12~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2007-12~	ABS	x	x	x	
Tiida latio \ SC11 \ 2007-12~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2007-12~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida latio \ SC11 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2009-11~	BCM	x	x		
Tiida latio \ SC11 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2009-11~	Multi AV	x	x	x	
Tiida latio \ SC11 \ 2009-11~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2009-11~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2009-11~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2009-11~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2009-11~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2009-11~	ABS	x	x	x	
Tiida latio \ SC11 \ 2009-11~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2009-11~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2009-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida latio \ SC11 \ 2009-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2009-5~	BCM	x	x		

Tiida latio \ SC11 \ 2009-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2009-5~	Multi AV	x	x	x	
Tiida latio \ SC11 \ 2009-5~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2009-5~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2009-5~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2009-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2009-5~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2009-5~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2009-5~	ABS	x	x	x	
Tiida latio \ SC11 \ 2009-5~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2009-5~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida latio \ SC11 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida latio \ SC11 \ 2010-8~	BCM	x	x		
Tiida latio \ SC11 \ 2010-8~	Air bag	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida latio \ SC11 \ 2010-8~	Multi AV	x	x	x	
Tiida latio \ SC11 \ 2010-8~	EPS/DAST 3	x	x	x	
Tiida latio \ SC11 \ 2010-8~	IPDM E/R	x	x	x	
Tiida latio \ SC11 \ 2010-8~	E-4wd	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida latio \ SC11 \ 2010-8~	Auto drive position	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Adaptive light	x	x	x	
Tiida latio \ SC11 \ 2010-8~	ABS	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Head lamp levelizer	x	x	x	
Tiida latio \ SC11 \ 2010-8~	Rearview camera			x	
Tiida latio \ SC11 \ 2010-8~	S/blind camera			x	
Tiida sedan \ SC11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2005-12~	BCM	x	x		
Tiida sedan \ SC11 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2005-12~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2005-12~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2005-12~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2005-12~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2005-12~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2005-12~	Air bag	x	x	x	

Tiida sedan \ SC11 \ 2005-4~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2005-4~	BCM	x	x		
Tiida sedan \ SC11 \ 2005-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2005-4~	Multi AV	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2005-4~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2005-4~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2005-8~	BCM	x	x		
Tiida sedan \ SC11 \ 2005-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2005-8~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2005-8~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2006-4~	BCM	x	x		
Tiida sedan \ SC11 \ 2006-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2006-4~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2006-4~	DIU	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2006-4~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2006-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2006-5~	BCM	x	x		
Tiida sedan \ SC11 \ 2006-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2006-5~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2006-5~	IPDM E/R	x	x	x	

Tiida sedan \ SC11 \ 2006-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2006-5~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2006-5~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2006-5~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2006-5~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2006-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2006-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2006-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2006-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2006-7~	BCM	x	x		
Tiida sedan \ SC11 \ 2006-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2006-7~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2006-7~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2006-7~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-10~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-10~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Intelligent key	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-10~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Tiida sedan \ SC11 \ 2007-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-11~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-11~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2007-11~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2007-11~	Rearview camera			x	
Tiida sedan \ SC11 \ 2007-11~	S/blind camera			x	
Tiida sedan \ SC11 \ 2007-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-1~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-1~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-1~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2007-1~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-1~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-1~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-1~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-2~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-2~	Multi AV	x	x	x	0280
Tiida sedan \ SC11 \ 2007-2~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2007-2~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-2~	Head lamp levelizer	x	x	x	

Tiida sedan \ SC11 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-4~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-4~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-4~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2007-4~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-4~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-4~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-4~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-5~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-5~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-5~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2007-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2007-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2007-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2007-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2008-1~	BCM	x	x		
Tiida sedan \ SC11 \ 2008-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2008-1~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2008-1~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Engine	x	x	x	

Tiida sedan \ SC11 \ 2008-1~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2008-1~	Rearview camera			x	
Tiida sedan \ SC11 \ 2008-1~	S/blind camera			x	
Tiida sedan \ SC11 \ 2008-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2008-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2008-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2008-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2008-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2008-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2008-6~	Rearview camera			x	
Tiida sedan \ SC11 \ 2008-6~	S/blind camera			x	
Tiida sedan \ SC11 \ 2008-7~	Engine	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2008-7~	BCM	x	x		
Tiida sedan \ SC11 \ 2008-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2008-7~	Multi AV	x	x	x	0280
Tiida sedan \ SC11 \ 2008-7~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2008-7~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2008-7~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2008-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2008-9~	BCM	x	x		
Tiida sedan \ SC11 \ 2008-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

Tiida sedan \ SC11 \ 2008-9~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2008-9~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2008-9~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2009-11~	BCM	x	x		
Tiida sedan \ SC11 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2009-11~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2009-11~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2009-11~	Rearview camera			x	
Tiida sedan \ SC11 \ 2009-11~	S/blind camera			x	
Tiida sedan \ SC11 \ 2009-11~	DIU	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2009-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2009-3~	BCM	x	x		
Tiida sedan \ SC11 \ 2009-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2009-3~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2009-3~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2009-3~	Air bag	x	x	x	

Tiida sedan \ SC11 \ 2009-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2009-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2009-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2009-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2009-6~	Multi AV	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	E-4wd	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2009-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2009-6~	Rearview camera			x	
Tiida sedan \ SC11 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2009-9~	BCM	x	x		
Tiida sedan \ SC11 \ 2009-9~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2009-9~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2009-9~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	SVT	x	x	x	
Tiida sedan \ SC11 \ 2009-9~	S/blind camera			x	
Tiida sedan \ SC11 \ 2010-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2010-2~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2010-2~	BCM	x	x		
Tiida sedan \ SC11 \ 2010-2~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

Tiida sedan \ SC11 \ 2010-2~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2010-2~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	SVT	x	x	x	
Tiida sedan \ SC11 \ 2010-2~	Rearview camera			x	
Tiida sedan \ SC11 \ 2010-2~	S/blind camera			x	
Tiida sedan \ SC11 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2010-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2010-3~	BCM	x	x		
Tiida sedan \ SC11 \ 2010-3~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2010-3~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2010-3~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	SVT	x	x	x	
Tiida sedan \ SC11 \ 2010-3~	Rearview camera			x	
Tiida sedan \ SC11 \ 2010-3~	S/blind camera			x	
Tiida sedan \ SC11 \ 2010-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2010-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2010-5~	BCM	x	x		
Tiida sedan \ SC11 \ 2010-5~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2010-5~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Tiida sedan \ SC11 \ 2010-5~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	SVT	x	x	x	
Tiida sedan \ SC11 \ 2010-5~	Rearview camera			x	
Tiida sedan \ SC11 \ 2010-5~	S/blind camera			x	
Tiida sedan \ SC11 \ 2010-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2010-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2010-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2010-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2010-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2010-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2010-6~	Rearview camera			x	
Tiida sedan \ SC11 \ 2010-6~	S/blind camera			x	
Tiida sedan \ SC11 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2010-8~	BCM	x	x		
Tiida sedan \ SC11 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2010-8~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2010-8~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	Rearview camera			x	
Tiida sedan \ SC11 \ 2010-8~	S/blind camera			x	

Tiida sedan \ SC11 \ 2010-8~	Multi AV	x	x	x	
Tiida sedan \ SC11 \ 2010-8~	E-4wd	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2011-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2011-6~	BCM	x	x		
Tiida sedan \ SC11 \ 2011-6~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2011-6~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2011-6~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2011-6~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2012-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2012-3~	BCM	x	x		
Tiida sedan \ SC11 \ 2012-3~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2012-3~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2012-3~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2012-3~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2012-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2012-4~	BCM	x	x		
Tiida sedan \ SC11 \ 2012-4~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	IPDM E/R	x	x	x	

Tiida sedan \ SC11 \ 2012-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2012-4~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2012-4~	SVT	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2013-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2013-1~	BCM	x	x		
Tiida sedan \ SC11 \ 2013-1~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2013-1~	Multi AV	x	x	x	0280
Tiida sedan \ SC11 \ 2013-1~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Air pressure monitor		x	x	
Tiida sedan \ SC11 \ 2013-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2013-1~	Auto drive position	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2013-1~	Rearview camera			x	
Tiida sedan \ SC11 \ 2013-1~	S/blind camera			x	
Tiida sedan \ SC11 \ 2016-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida sedan \ SC11 \ 2016-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida sedan \ SC11 \ 2016-5~	BCM	x	x		
Tiida sedan \ SC11 \ 2016-5~	Air bag	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida sedan \ SC11 \ 2016-5~	Multi AV	x	x	x	0280
Tiida sedan \ SC11 \ 2016-5~	EPS/DAST 3	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	IPDM E/R	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	Air pressure monitor		x	x	
Tiida sedan \ SC11 \ 2016-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida sedan \ SC11 \ 2016-5~	Auto drive position	x	x	x	

Tiida sedan \ SC11 \ 2016-5~	Adaptive light	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	ABS	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	Head lamp levelizer	x	x	x	
Tiida sedan \ SC11 \ 2016-5~	Rearview camera			x	
Tiida sedan \ SC11 \ 2016-5~	S/blind camera			x	
Tiida \ C11 \ 2004-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2004-9~	BCM	x	x		
Tiida \ C11 \ 2004-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2004-9~	Multi AV	x	x	x	0280
Tiida \ C11 \ 2004-9~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2004-9~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2004-9~	E-4wd	x	x	x	
Tiida \ C11 \ 2004-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2004-9~	Auto drive position	x	x	x	
Tiida \ C11 \ 2004-9~	Adaptive light	x	x	x	
Tiida \ C11 \ 2004-9~	Engine	x	x	x	
Tiida \ C11 \ 2004-9~	ABS	x	x	x	
Tiida \ C11 \ 2004-9~	Air bag	x	x	x	
Tiida \ C11 \ 2004-9~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2005-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2005-12~	BCM	x	x		
Tiida \ C11 \ 2005-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2005-12~	Multi AV	x	x	x	0280
Tiida \ C11 \ 2005-12~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2005-12~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2005-12~	E-4wd	x	x	x	
Tiida \ C11 \ 2005-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2005-12~	Auto drive position	x	x	x	
Tiida \ C11 \ 2005-12~	Adaptive light	x	x	x	
Tiida \ C11 \ 2005-12~	Engine	x	x	x	
Tiida \ C11 \ 2005-12~	ABS	x	x	x	
Tiida \ C11 \ 2005-12~	Air bag	x	x	x	
Tiida \ C11 \ 2005-12~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C11 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2006-12~	BCM	x	x		

Tiida \ C11 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2006-12~	Multi AV	x	x	x	
Tiida \ C11 \ 2006-12~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2006-12~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2006-12~	E-4wd	x	x	x	
Tiida \ C11 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2006-12~	Auto drive position	x	x	x	
Tiida \ C11 \ 2006-12~	Adaptive light	x	x	x	
Tiida \ C11 \ 2006-12~	ABS	x	x	x	
Tiida \ C11 \ 2006-12~	Air bag	x	x	x	
Tiida \ C11 \ 2006-12~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2007-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C11 \ 2007-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2007-12~	BCM	x	x		
Tiida \ C11 \ 2007-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2007-12~	Multi AV	x	x	x	
Tiida \ C11 \ 2007-12~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2007-12~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2007-12~	E-4wd	x	x	x	
Tiida \ C11 \ 2007-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2007-12~	Auto drive position	x	x	x	
Tiida \ C11 \ 2007-12~	Adaptive light	x	x	x	
Tiida \ C11 \ 2007-12~	ABS	x	x	x	
Tiida \ C11 \ 2007-12~	Air bag	x	x	x	
Tiida \ C11 \ 2007-12~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C11 \ 2009-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2009-11~	BCM	x	x		
Tiida \ C11 \ 2009-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2009-11~	Multi AV	x	x	x	
Tiida \ C11 \ 2009-11~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2009-11~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2009-11~	E-4wd	x	x	x	

Tiida \ C11 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2009-11~	Auto drive position	x	x	x	
Tiida \ C11 \ 2009-11~	Adaptive light	x	x	x	
Tiida \ C11 \ 2009-11~	ABS	x	x	x	
Tiida \ C11 \ 2009-11~	Air bag	x	x	x	
Tiida \ C11 \ 2009-11~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2009-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C11 \ 2009-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2009-5~	BCM	x	x		
Tiida \ C11 \ 2009-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2009-5~	Multi AV	x	x	x	
Tiida \ C11 \ 2009-5~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2009-5~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2009-5~	E-4wd	x	x	x	
Tiida \ C11 \ 2009-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2009-5~	Auto drive position	x	x	x	
Tiida \ C11 \ 2009-5~	Adaptive light	x	x	x	
Tiida \ C11 \ 2009-5~	ABS	x	x	x	
Tiida \ C11 \ 2009-5~	Air bag	x	x	x	
Tiida \ C11 \ 2009-5~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C11 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tiida \ C11 \ 2010-8~	BCM	x	x		
Tiida \ C11 \ 2010-8~	Air bag	x	x	x	
Tiida \ C11 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C11 \ 2010-8~	Multi AV	x	x	x	
Tiida \ C11 \ 2010-8~	EPS/DAST 3	x	x	x	
Tiida \ C11 \ 2010-8~	IPDM E/R	x	x	x	
Tiida \ C11 \ 2010-8~	E-4wd	x	x	x	
Tiida \ C11 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tiida \ C11 \ 2010-8~	Auto drive position	x	x	x	
Tiida \ C11 \ 2010-8~	Adaptive light	x	x	x	
Tiida \ C11 \ 2010-8~	ABS	x	x	x	

Tiida \ C11 \ 2010-8~	Head lamp levelizer	x	x	x	
Tiida \ C11 \ 2010-8~	Rearview camera			x	
Tiida \ C11 \ 2010-8~	S/blind camera			x	
Tiida \ C12 \ 2011-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C12 \ 2011-4~	ABS	x	x	x	0003, 0092, 0264
Tiida \ C12 \ 2011-4~	Meter/M&A		x	x	
Tiida \ C12 \ 2011-4~	BCM		x		
Tiida \ C12 \ 2011-4~	Air bag	x	x	x	
Tiida \ C12 \ 2011-4~	ICC/ADAS	x	x	x	
Tiida \ C12 \ 2011-4~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Tiida \ C12 \ 2011-4~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C12 \ 2011-4~	Multi AV	x	x	x	0280
Tiida \ C12 \ 2011-4~	EPS/DAST 3	x	x	x	
Tiida \ C12 \ 2011-4~	IPDM E/R		x	x	
Tiida \ C12 \ 2011-4~	Laser/radar	x	x	x	
Tiida \ C12 \ 2011-4~	Sonar	x	x	x	
Tiida \ C12 \ 2011-4~	AVM		x	x	
Tiida \ C12 \ 2011-4~	Head lamp levelizer	x	x	x	
Tiida \ C12 \ 2012-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C12 \ 2012-5~	ABS	x	x	x	
Tiida \ C12 \ 2012-5~	Meter/M&A		x	x	
Tiida \ C12 \ 2012-5~	BCM		x		
Tiida \ C12 \ 2012-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Tiida \ C12 \ 2012-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tiida \ C12 \ 2012-5~	EPS/DAST 3	x	x	x	
Tiida \ C12 \ 2012-5~	IPDM E/R		x	x	
Tiida \ C12 \ 2012-5~	Air bag	x	x	x	
Tiida \ C12 \ 2012-5~	Head lamp levelizer	x	x	x	
Tiida \ C12 \ 2012-5~	Sonar	x	x	x	
Tiida \ C12 \ 2013-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C12 \ 2013-5~	ABS	x	x	x	0003, 0092, 0264
Tiida \ C12 \ 2013-5~	Meter/M&A		x	x	
Tiida \ C12 \ 2013-5~	BCM		x		
Tiida \ C12 \ 2013-5~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
Tiida \ C12 \ 2013-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059

Tiida \ C12 \ 2013-5~	Multi AV		x	x	
Tiida \ C12 \ 2013-5~	EPS/DAST 3	x	x	x	
Tiida \ C12 \ 2013-5~	IPDM E/R		x	x	
Tiida \ C12 \ 2013-5~	Sonar	x	x	x	
Tiida \ C12 \ 2013-5~	Air bag	x	x	x	
Tiida \ C12 \ 2013-5~	Head lamp levelizer	x	x	x	
Tiida \ C13 \ 2015-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tiida \ C13 \ 2015-1~	ABS	x	x	x	
Tiida \ C13 \ 2015-1~	Meter/M&A		x	x	
Tiida \ C13 \ 2015-1~	BCM		x		
Tiida \ C13 \ 2015-1~	Air bag	x	x	x	
Tiida \ C13 \ 2015-1~	ICC/ADAS	x	x	x	
Tiida \ C13 \ 2015-1~	HVAC		x	x	
Tiida \ C13 \ 2015-1~	Transmission	x	x	x	0076, 0117, 0113, 0149, 0110, 0076, 0059, 0100, 0083, 0059, 0150, 0085
Tiida \ C13 \ 2015-1~	Multi AV	x	x	x	0280
Tiida \ C13 \ 2015-1~	EPS/DAST 3	x	x	x	
Tiida \ C13 \ 2015-1~	IPDM E/R		x	x	
Tiida \ C13 \ 2015-1~	AVM		x	x	
Tiida \ C13 \ 2015-1~	Chassis control		x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
TIIDA-PULSAR \ C12 \ 2013-1~	ABS	x	x	x	0003, 0092, 0264
TIIDA-PULSAR \ C12 \ 2013-1~	Meter/M&A		x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	BCM		x		
TIIDA-PULSAR \ C12 \ 2013-1~	HVAC		x	x	0024, 0027, 0048, 0067, 0098, 0140, 0151, 0228, 0229, 0285, 0297, 0308
TIIDA-PULSAR \ C12 \ 2013-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
TIIDA-PULSAR \ C12 \ 2013-1~	Multi AV		x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	EPS/DAST 3	x	x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	IPDM E/R		x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	Sonar	x	x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	Air bag	x	x	x	
TIIDA-PULSAR \ C12 \ 2013-1~	Head lamp levelizer	x	x	x	
Tino \ V10 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tino \ V10 \ All Year	ABS	x	x	x	0003, 0092, 0264
Tino \ V10 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tino \ V10 \ All Year	BCM	x	x		
Tino \ V10 \ All Year	Air bag	x	x	x	

Tino \ V10 \ All Year	ICC/ADAS	x	x	x	
Tino \ V10 \ All Year	HVAC	x	x	x	
Tino \ V10 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tino \ V10 \ All Year	Multi AV	x	x	x	0280
Tino \ V10 \ All Year	EPS/DAST 3	x	x	x	
Tino \ V10 \ All Year	IPDM E/R	x	x	x	
Tino \ V10 \ All Year	Air pressure monitor	x	x	x	
Tino \ V10 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tino \ V10 \ All Year	DIU	x	x	x	
Tino \ V10 \ All Year	Auto slide door	x	x	x	
Tino \ V10 \ All Year	Auto drive position	x	x	x	
Tino \ V10 \ All Year	All mode AWD/4WD	x	x	x	
Tino \ V10 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Tino \ V10 \ All Year	Sonar	x	x	x	
Tino \ V10 \ All Year	Lane camera	x	x	x	
Tino \ V10 \ All Year	Adaptive light	x	x	x	
Tino \ V10 \ All Year	AVM		x	x	
Tino \ V10 \ All Year	Head lamp levelizer	x	x	x	
Tino \ V10 \ All Year	Difference lock	x	x	x	
Tino \ V10 \ All Year	Nats immu	x	x		
Tino \ V10 \ All Year	Smart entrance	x	x		
Tino \ V10 \ All Year	Air levelizer	x	x	x	
Tino \ V10 \ All Year	Rearview camera			x	
Tino \ V10 \ All Year	S/blind camera			x	
Tino \ V10 \ All Year	Motor assist	x	x	x	
Titan \ A60 \ 2003-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2003-10~	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2003-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2003-10~	BCM	x	x		
Titan \ A60 \ 2003-10~	Air bag	x	x	x	
Titan \ A60 \ 2003-10~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2003-10~	HVAC	x	x	x	
Titan \ A60 \ 2003-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2003-10~	Multi AV	x	x	x	0280
Titan \ A60 \ 2003-10~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2003-10~	IPDM E/R	x	x	x	
Titan \ A60 \ 2003-10~	Air pressure monitor	x	x	x	

Titan \ A60 \ 2003-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2003-10~	DIU	x	x	x	
Titan \ A60 \ 2003-10~	Auto slide door	x	x	x	
Titan \ A60 \ 2003-10~	Auto drive position	x	x	x	
Titan \ A60 \ 2003-10~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2003-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2003-10~	Sonar	x	x	x	
Titan \ A60 \ 2003-10~	Lane camera	x	x	x	
Titan \ A60 \ 2003-10~	Adaptive light	x	x	x	
Titan \ A60 \ 2003-10~	AVM		x	x	
Titan \ A60 \ 2003-10~	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2003-10~	Difference lock	x	x	x	
Titan \ A60 \ 2003-10~	Nats immu	x	x		
Titan \ A60 \ 2003-10~	Smart entrance	x	x		
Titan \ A60 \ 2003-10~	Air levelizer	x	x	x	
Titan \ A60 \ 2003-10~	Rearview camera			x	
Titan \ A60 \ 2003-10~	S/blind camera			x	
Titan \ A60 \ 2003-10~	Motor assist	x	x	x	
Titan \ A60 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2004	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2004	BCM	x	x		
Titan \ A60 \ 2004	Air bag	x	x	x	
Titan \ A60 \ 2004	ICC/ADAS	x	x	x	
Titan \ A60 \ 2004	HVAC	x	x	x	
Titan \ A60 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2004	Multi AV	x	x	x	0280
Titan \ A60 \ 2004	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2004	IPDM E/R	x	x	x	
Titan \ A60 \ 2004	Air pressure monitor	x	x	x	
Titan \ A60 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2004	DIU	x	x	x	
Titan \ A60 \ 2004	Auto slide door	x	x	x	
Titan \ A60 \ 2004	Auto drive position	x	x	x	
Titan \ A60 \ 2004	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	

Titan \ A60 \ 2004	Sonar	x	x	x	
Titan \ A60 \ 2004	Lane camera	x	x	x	
Titan \ A60 \ 2004	Adaptive light	x	x	x	
Titan \ A60 \ 2004	AVM		x	x	
Titan \ A60 \ 2004	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2004	Difference lock	x	x	x	
Titan \ A60 \ 2004	Nats immu	x	x		
Titan \ A60 \ 2004	Smart entrance	x	x		
Titan \ A60 \ 2004	Air levelizer	x	x	x	
Titan \ A60 \ 2004	Rearview camera			x	
Titan \ A60 \ 2004	S/blind camera			x	
Titan \ A60 \ 2004	Motor assist	x	x	x	
Titan \ A60 \ 2004-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2004-10~	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2004-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2004-10~	BCM	x	x		
Titan \ A60 \ 2004-10~	Air bag	x	x	x	
Titan \ A60 \ 2004-10~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2004-10~	HVAC	x	x	x	
Titan \ A60 \ 2004-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2004-10~	Multi AV	x	x	x	0280
Titan \ A60 \ 2004-10~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2004-10~	IPDM E/R	x	x	x	
Titan \ A60 \ 2004-10~	Air pressure monitor	x	x	x	
Titan \ A60 \ 2004-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2004-10~	DIU	x	x	x	
Titan \ A60 \ 2004-10~	Auto slide door	x	x	x	
Titan \ A60 \ 2004-10~	Auto drive position	x	x	x	
Titan \ A60 \ 2004-10~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2004-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2004-10~	Sonar	x	x	x	
Titan \ A60 \ 2004-10~	Lane camera	x	x	x	
Titan \ A60 \ 2004-10~	Adaptive light	x	x	x	
Titan \ A60 \ 2004-10~	AVM		x	x	
Titan \ A60 \ 2004-10~	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2004-10~	Difference lock	x	x	x	
Titan \ A60 \ 2004-10~	Nats immu	x	x		
Titan \ A60 \ 2004-10~	Smart entrance	x	x		

Titan \ A60 \ 2004-10~	Air levelizer	x	x	x	
Titan \ A60 \ 2004-10~	Rearview camera			x	
Titan \ A60 \ 2004-10~	S/blind camera			x	
Titan \ A60 \ 2004-10~	Motor assist	x	x	x	
Titan \ A60 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2005	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2005	BCM	x	x		
Titan \ A60 \ 2005	Air bag	x	x	x	
Titan \ A60 \ 2005	ICC/ADAS	x	x	x	
Titan \ A60 \ 2005	HVAC	x	x	x	
Titan \ A60 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2005	Multi AV	x	x	x	0280
Titan \ A60 \ 2005	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2005	IPDM E/R	x	x	x	
Titan \ A60 \ 2005	Air pressure monitor	x	x	x	
Titan \ A60 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2005	DIU	x	x	x	
Titan \ A60 \ 2005	Auto slide door	x	x	x	
Titan \ A60 \ 2005	Auto drive position	x	x	x	
Titan \ A60 \ 2005	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2005	Sonar	x	x	x	
Titan \ A60 \ 2005	Lane camera	x	x	x	
Titan \ A60 \ 2005	Adaptive light	x	x	x	
Titan \ A60 \ 2005	AVM		x	x	
Titan \ A60 \ 2005	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2005	Difference lock	x	x	x	
Titan \ A60 \ 2005	Nats immu	x	x		
Titan \ A60 \ 2005	Smart entrance	x	x		
Titan \ A60 \ 2005	Air levelizer	x	x	x	
Titan \ A60 \ 2005	Rearview camera			x	
Titan \ A60 \ 2005	S/blind camera			x	
Titan \ A60 \ 2005	Motor assist	x	x	x	
Titan \ A60 \ 2005-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2005-8~	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2005-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Titan \ A60 \ 2005-8~	BCM	x	x		
Titan \ A60 \ 2005-8~	Air bag	x	x	x	
Titan \ A60 \ 2005-8~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2005-8~	HVAC	x	x	x	
Titan \ A60 \ 2005-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2005-8~	Multi AV	x	x	x	0280
Titan \ A60 \ 2005-8~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2005-8~	IPDM E/R	x	x	x	
Titan \ A60 \ 2005-8~	Air pressure monitor	x	x	x	
Titan \ A60 \ 2005-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2005-8~	DIU	x	x	x	
Titan \ A60 \ 2005-8~	Auto slide door	x	x	x	
Titan \ A60 \ 2005-8~	Auto drive position	x	x	x	
Titan \ A60 \ 2005-8~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2005-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2005-8~	Sonar	x	x	x	
Titan \ A60 \ 2005-8~	Lane camera	x	x	x	
Titan \ A60 \ 2005-8~	Adaptive light	x	x	x	
Titan \ A60 \ 2005-8~	AVM		x	x	
Titan \ A60 \ 2005-8~	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2005-8~	Difference lock	x	x	x	
Titan \ A60 \ 2005-8~	Nats immu	x	x		
Titan \ A60 \ 2005-8~	Smart entrance	x	x		
Titan \ A60 \ 2005-8~	Air levelizer	x	x	x	
Titan \ A60 \ 2005-8~	Rearview camera			x	
Titan \ A60 \ 2005-8~	S/blind camera			x	
Titan \ A60 \ 2005-8~	Motor assist	x	x	x	
Titan \ A60 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2006	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2006	BCM	x	x		
Titan \ A60 \ 2006	Air bag	x	x	x	
Titan \ A60 \ 2006	ICC/ADAS	x	x	x	
Titan \ A60 \ 2006	HVAC	x	x	x	
Titan \ A60 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2006	Multi AV	x	x	x	0280
Titan \ A60 \ 2006	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2006	IPDM E/R	x	x	x	

Titan \ A60 \ 2006	Air pressure monitor	x	x	x	
Titan \ A60 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2006	DIU	x	x	x	
Titan \ A60 \ 2006	Auto slide door	x	x	x	
Titan \ A60 \ 2006	Auto drive position	x	x	x	
Titan \ A60 \ 2006	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2006	Sonar	x	x	x	
Titan \ A60 \ 2006	Lane camera	x	x	x	
Titan \ A60 \ 2006	Adaptive light	x	x	x	
Titan \ A60 \ 2006	AVM		x	x	
Titan \ A60 \ 2006	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2006	Difference lock	x	x	x	
Titan \ A60 \ 2006	Nats immu	x	x		
Titan \ A60 \ 2006	Smart entrance	x	x		
Titan \ A60 \ 2006	Air levelizer	x	x	x	
Titan \ A60 \ 2006	Rearview camera			x	
Titan \ A60 \ 2006	S/blind camera			x	
Titan \ A60 \ 2006	Motor assist	x	x	x	
Titan \ A60 \ 2006-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2006-8~	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2006-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2006-8~	BCM	x	x		
Titan \ A60 \ 2006-8~	Air bag	x	x	x	
Titan \ A60 \ 2006-8~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2006-8~	HVAC	x	x	x	
Titan \ A60 \ 2006-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2006-8~	Multi AV	x	x	x	0280
Titan \ A60 \ 2006-8~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2006-8~	IPDM E/R	x	x	x	
Titan \ A60 \ 2006-8~	Air pressure monitor	x	x	x	
Titan \ A60 \ 2006-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2006-8~	DIU	x	x	x	
Titan \ A60 \ 2006-8~	Auto slide door	x	x	x	
Titan \ A60 \ 2006-8~	Auto drive position	x	x	x	
Titan \ A60 \ 2006-8~	All mode AWD/4WD	x	x	x	

Titan \ A60 \ 2006-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2006-8~	Sonar	x	x	x	
Titan \ A60 \ 2006-8~	Lane camera	x	x	x	
Titan \ A60 \ 2006-8~	Adaptive light	x	x	x	
Titan \ A60 \ 2006-8~	AVM		x	x	
Titan \ A60 \ 2006-8~	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2006-8~	Difference lock	x	x	x	
Titan \ A60 \ 2006-8~	Nats immu	x	x		
Titan \ A60 \ 2006-8~	Smart entrance	x	x		
Titan \ A60 \ 2006-8~	Air levelizer	x	x	x	
Titan \ A60 \ 2006-8~	Rearview camera			x	
Titan \ A60 \ 2006-8~	S/blind camera			x	
Titan \ A60 \ 2006-8~	Motor assist	x	x	x	
Titan \ A60 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2007	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2007	BCM	x	x		
Titan \ A60 \ 2007	Air bag	x	x	x	
Titan \ A60 \ 2007	ICC/ADAS	x	x	x	
Titan \ A60 \ 2007	HVAC	x	x	x	
Titan \ A60 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Titan \ A60 \ 2007	Multi AV	x	x	x	0280
Titan \ A60 \ 2007	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2007	IPDM E/R	x	x	x	
Titan \ A60 \ 2007	Air pressure monitor	x	x	x	
Titan \ A60 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2007	DIU	x	x	x	
Titan \ A60 \ 2007	Auto slide door	x	x	x	
Titan \ A60 \ 2007	Auto drive position	x	x	x	
Titan \ A60 \ 2007	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2007	Sonar	x	x	x	
Titan \ A60 \ 2007	Lane camera	x	x	x	
Titan \ A60 \ 2007	Adaptive light	x	x	x	
Titan \ A60 \ 2007	AVM		x	x	
Titan \ A60 \ 2007	Head lamp levelizer	x	x	x	
Titan \ A60 \ 2007	Difference lock	x	x	x	
Titan \ A60 \ 2007	Nats immu	x	x		

Titan \ A60 \ 2007	Smart entrance	x	x		
Titan \ A60 \ 2007	Air levelizer	x	x	x	
Titan \ A60 \ 2007	Rearview camera			x	
Titan \ A60 \ 2007	S/blind camera			x	
Titan \ A60 \ 2007	Motor assist	x	x	x	
Titan \ A60 \ 2007-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2007-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2007-4~	BCM	x	x		
Titan \ A60 \ 2007-4~	HVAC	x	x	x	
Titan \ A60 \ 2007-4~	Transmission	x	x	x	
Titan \ A60 \ 2007-4~	Multi AV	x	x	x	0280
Titan \ A60 \ 2007-4~	IPDM E/R	x	x	x	
Titan \ A60 \ 2007-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2007-4~	Auto drive position	x	x	x	
Titan \ A60 \ 2007-4~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2007-4~	ABS	x	x	x	
Titan \ A60 \ 2007-4~	Air bag	x	x	x	
Titan \ A60 \ 2007-4~	Difference lock	x	x	x	
Titan \ A60 \ 2007-4~	Sonar	x	x	x	
Titan \ A60 \ 2007-4~	Air levelizer	x	x	x	
Titan \ A60 \ 2007-4~	Rearview camera			x	
Titan \ A60 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2008	BCM	x	x		
Titan \ A60 \ 2008	HVAC	x	x	x	
Titan \ A60 \ 2008	Transmission	x	x	x	
Titan \ A60 \ 2008	Multi AV	x	x	x	0280
Titan \ A60 \ 2008	IPDM E/R	x	x	x	
Titan \ A60 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2008	Auto drive position	x	x	x	
Titan \ A60 \ 2008	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2008	ABS	x	x	x	
Titan \ A60 \ 2008	Air bag	x	x	x	
Titan \ A60 \ 2008	Difference lock	x	x	x	
Titan \ A60 \ 2008	Sonar	x	x	x	

Titan \ A60 \ 2008	Air levelizer	x	x	x	
Titan \ A60 \ 2008	Rearview camera			x	
Titan \ A60 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2009	BCM	x	x		
Titan \ A60 \ 2009	HVAC	x	x	x	
Titan \ A60 \ 2009	Transmission	x	x	x	
Titan \ A60 \ 2009	Multi AV	x	x	x	0280
Titan \ A60 \ 2009	IPDM E/R	x	x	x	
Titan \ A60 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2009	Auto drive position	x	x	x	
Titan \ A60 \ 2009	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2009	ABS	x	x	x	
Titan \ A60 \ 2009	Air bag	x	x	x	
Titan \ A60 \ 2009	Difference lock	x	x	x	
Titan \ A60 \ 2009	Sonar	x	x	x	
Titan \ A60 \ 2009	Air levelizer	x	x	x	
Titan \ A60 \ 2009	Rearview camera			x	
Titan \ A60 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2010	BCM	x	x		
Titan \ A60 \ 2010	HVAC	x	x	x	
Titan \ A60 \ 2010	Transmission	x	x	x	
Titan \ A60 \ 2010	Multi AV	x	x	x	
Titan \ A60 \ 2010	IPDM E/R	x	x	x	
Titan \ A60 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2010	Auto drive position	x	x	x	
Titan \ A60 \ 2010	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2010	ABS	x	x	x	
Titan \ A60 \ 2010	Air bag	x	x	x	
Titan \ A60 \ 2010	Difference lock	x	x	x	
Titan \ A60 \ 2010	Sonar	x	x	x	
Titan \ A60 \ 2010	Air levelizer	x	x	x	
Titan \ A60 \ 2010	Rearview camera			x	
Titan \ A60 \ 2010	S/blind camera			x	

Titan \ A60 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2011	BCM	x	x		
Titan \ A60 \ 2011	Air bag	x	x	x	
Titan \ A60 \ 2011	HVAC	x	x	x	
Titan \ A60 \ 2011	Transmission	x	x	x	
Titan \ A60 \ 2011	Multi AV	x	x	x	
Titan \ A60 \ 2011	IPDM E/R	x	x	x	
Titan \ A60 \ 2011	Intelligent key	x	x	x	
Titan \ A60 \ 2011	Auto drive position	x	x	x	
Titan \ A60 \ 2011	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2011	ABS	x	x	x	
Titan \ A60 \ 2011	Difference lock	x	x	x	
Titan \ A60 \ 2011	Sonar	x	x	x	
Titan \ A60 \ 2011	Air levelizer	x	x	x	
Titan \ A60 \ 2011	Rearview camera			x	
Titan \ A60 \ 2011	S/blind camera			x	
Titan \ A60 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2012	BCM	x	x		
Titan \ A60 \ 2012	Air bag	x	x	x	
Titan \ A60 \ 2012	HVAC	x	x	x	
Titan \ A60 \ 2012	Multi AV	x	x	x	0280
Titan \ A60 \ 2012	IPDM E/R	x	x	x	
Titan \ A60 \ 2012	Intelligent key	x	x	x	
Titan \ A60 \ 2012	Auto drive position	x	x	x	
Titan \ A60 \ 2012	ABS	x	x	x	
Titan \ A60 \ 2012	Transmission	x	x	x	
Titan \ A60 \ 2012	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2012	Difference lock	x	x	x	
Titan \ A60 \ 2012	Sonar	x	x	x	
Titan \ A60 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2013	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2013	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2013	BCM	x	x		
Titan \ A60 \ 2013	Air bag	x	x	x	
Titan \ A60 \ 2013	HVAC	x	x	x	
Titan \ A60 \ 2013	Multi AV		x	x	

Titan \ A60 \ 2013	IPDM E/R	x	x	x	
Titan \ A60 \ 2013	Intelligent key	x	x	x	
Titan \ A60 \ 2013	Auto drive position	x	x	x	
Titan \ A60 \ 2013	Transmission	x	x	x	
Titan \ A60 \ 2013	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2013-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2013-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2013-8~	BCM	x	x		
Titan \ A60 \ 2013-8~	Air bag	x	x	x	
Titan \ A60 \ 2013-8~	HVAC	x	x	x	
Titan \ A60 \ 2013-8~	Multi AV		x	x	
Titan \ A60 \ 2013-8~	IPDM E/R	x	x	x	
Titan \ A60 \ 2013-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2013-8~	Auto drive position	x	x	x	
Titan \ A60 \ 2013-8~	ABS	x	x	x	
Titan \ A60 \ 2013-8~	Transmission	x	x	x	
Titan \ A60 \ 2013-8~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2014	BCM	x	x		
Titan \ A60 \ 2014	Air bag	x	x	x	
Titan \ A60 \ 2014	HVAC	x	x	x	
Titan \ A60 \ 2014	Multi AV		x	x	
Titan \ A60 \ 2014	IPDM E/R	x	x	x	
Titan \ A60 \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2014	Auto drive position	x	x	x	
Titan \ A60 \ 2014	ABS	x	x	x	
Titan \ A60 \ 2014	Transmission	x	x	x	
Titan \ A60 \ 2014	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2014	Difference lock	x	x	x	
Titan \ A60 \ 2014-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2014-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2014-10~	BCM	x	x		
Titan \ A60 \ 2014-10~	Air bag	x	x	x	

Titan \ A60 \ 2014-10~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2014-10~	HVAC	x	x	x	
Titan \ A60 \ 2014-10~	Multi AV	x	x	x	0280
Titan \ A60 \ 2014-10~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2014-10~	IPDM E/R	x	x	x	
Titan \ A60 \ 2014-10~	Laser/radar	x	x	x	
Titan \ A60 \ 2014-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2014-10~	Auto drive position	x	x	x	
Titan \ A60 \ 2014-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2014-10~	Lane camera	x	x	x	
Titan \ A60 \ 2014-10~	CAN gateway		x	x	
Titan \ A60 \ 2014-10~	4WAS(front)	x	x	x	
Titan \ A60 \ 2014-10~	E-SUS		x	x	
Titan \ A60 \ 2014-10~	Accele pedal ACT		x	x	
Titan \ A60 \ 2014-10~	Side radar left		x	x	
Titan \ A60 \ 2014-10~	Side radar right		x	x	
Titan \ A60 \ 2014-10~	Telematics		x	x	0253
Titan \ A60 \ 2014-10~	BSW/buzzer		x	x	
Titan \ A60 \ 2014-10~	AVM		x	x	
Titan \ A60 \ 2014-10~	ABS	x	x	x	
Titan \ A60 \ 2014-10~	Transmission	x	x	x	
Titan \ A60 \ 2014-10~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2014-10~	Difference lock	x	x	x	
Titan \ A60 \ 2014-10~	Air levelizer	x	x	x	
Titan \ A60 \ 2014-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2014-11~	ABS	x	x	x	0003, 0092, 0264
Titan \ A60 \ 2014-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2014-11~	Air bag	x	x	x	
Titan \ A60 \ 2014-11~	ICC/ADAS	x	x	x	
Titan \ A60 \ 2014-11~	HVAC	x	x	x	
Titan \ A60 \ 2014-11~	Multi AV		x	x	
Titan \ A60 \ 2014-11~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Titan \ A60 \ 2014-11~	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2014-11~	IPDM E/R	x	x	x	
Titan \ A60 \ 2014-11~	Laser/radar	x	x	x	

Titan \ A60 \ 2014-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2014-11~	Auto drive position	x	x	x	
Titan \ A60 \ 2014-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2014-11~	CAN gateway		x	x	
Titan \ A60 \ 2014-11~	4WAS(front)	x	x	x	
Titan \ A60 \ 2014-11~	E-SUS		x	x	
Titan \ A60 \ 2014-11~	Side radar left		x	x	
Titan \ A60 \ 2014-11~	Side radar right		x	x	
Titan \ A60 \ 2014-11~	BSW/buzzer		x	x	
Titan \ A60 \ 2014-11~	Transmission	x	x	x	
Titan \ A60 \ 2014-11~	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2014-11~	Difference lock	x	x	x	
Titan \ A60 \ 2014-11~	Air levelizer	x	x	x	
Titan \ A60 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A60 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Titan \ A60 \ 2015	BCM	x	x		
Titan \ A60 \ 2015	Air bag	x	x	x	
Titan \ A60 \ 2015	ICC/ADAS	x	x	x	
Titan \ A60 \ 2015	HVAC	x	x	x	
Titan \ A60 \ 2015	Multi AV	x	x	x	0280
Titan \ A60 \ 2015	EPS/DAST 3	x	x	x	
Titan \ A60 \ 2015	IPDM E/R	x	x	x	
Titan \ A60 \ 2015	Laser/radar	x	x	x	
Titan \ A60 \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Titan \ A60 \ 2015	Auto drive position	x	x	x	
Titan \ A60 \ 2015	4WAS(MAIN)/RAS/HICAS	x	x	x	
Titan \ A60 \ 2015	Lane camera	x	x	x	
Titan \ A60 \ 2015	CAN gateway		x	x	
Titan \ A60 \ 2015	4WAS(front)	x	x	x	
Titan \ A60 \ 2015	E-SUS		x	x	
Titan \ A60 \ 2015	Accele pedal ACT		x	x	
Titan \ A60 \ 2015	Side radar left		x	x	
Titan \ A60 \ 2015	Side radar right		x	x	
Titan \ A60 \ 2015	Telematics		x	x	0253
Titan \ A60 \ 2015	BSW/buzzer		x	x	
Titan \ A60 \ 2015	AVM		x	x	

Titan \ A60 \ 2015	ABS	x	x	x	
Titan \ A60 \ 2015	Transmission	x	x	x	
Titan \ A60 \ 2015	All mode AWD/4WD	x	x	x	
Titan \ A60 \ 2015	Difference lock	x	x	x	
Titan \ A60 \ 2015	Air levelizer	x	x	x	
Titan \ A61 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A61 \ 2016	ABS		x	x	
Titan \ A61 \ 2016	Meter/M&A		x	x	0143
Titan \ A61 \ 2016	BCM		x		
Titan \ A61 \ 2016	Air bag	x	x	x	
Titan \ A61 \ 2016	ICC/ADAS	x	x	x	
Titan \ A61 \ 2016	HVAC		x	x	
Titan \ A61 \ 2016	Transmission		x	x	0059
Titan \ A61 \ 2016	Multi AV	x	x	x	0280
Titan \ A61 \ 2016	EPS/DAST 3	x	x	x	
Titan \ A61 \ 2016	IPDM E/R		x	x	
Titan \ A61 \ 2016	Air pressure monitor	x	x	x	
Titan \ A61 \ 2016	Precrash seatbelt		x	x	
Titan \ A61 \ 2016	Auto drive position	x	x	x	
Titan \ A61 \ 2016	All mode AWD/4WD		x	x	
Titan \ A61 \ 2016	Difference lock	x	x	x	
Titan \ A61 \ 2016	Sonar		x	x	
Titan \ A61 \ 2016	Adaptive light	x	x	x	
Titan \ A61 \ 2016	CAN gateway		x		
Titan \ A61 \ 2016	Accele pedal ACT		x	x	
Titan \ A61 \ 2016	Side radar left		x	x	
Titan \ A61 \ 2016	Side radar right		x	x	
Titan \ A61 \ 2016	PTC heater		x	x	
Titan \ A61 \ 2016	Telematics		x	x	0253
Titan \ A61 \ 2016	AVM		x	x	
Titan \ A61 \ 2016	Occupant detection			x	
Titan \ A61 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Titan \ A61 \ 2017	ABS		x	x	
Titan \ A61 \ 2017	Meter/M&A		x	x	0143
Titan \ A61 \ 2017	BCM		x		
Titan \ A61 \ 2017	Air bag	x	x	x	
Titan \ A61 \ 2017	ICC/ADAS	x	x	x	
Titan \ A61 \ 2017	HVAC		x	x	
Titan \ A61 \ 2017	Transmission		x	x	0059

Titan \ A61 \ 2017	Multi AV	x	x	x	0280
Titan \ A61 \ 2017	EPS/DAST 3	x	x	x	
Titan \ A61 \ 2017	IPDM E/R		x	x	
Titan \ A61 \ 2017	Air pressure monitor	x	x	x	
Titan \ A61 \ 2017	Precrash seatbelt		x	x	
Titan \ A61 \ 2017	Auto drive position	x	x	x	
Titan \ A61 \ 2017	All mode AWD/4WD		x	x	
Titan \ A61 \ 2017	Difference lock	x	x	x	
Titan \ A61 \ 2017	Sonar		x	x	
Titan \ A61 \ 2017	Adaptive light	x	x	x	
Titan \ A61 \ 2017	CAN gateway		x		
Titan \ A61 \ 2017	Accele pedal ACT		x	x	
Titan \ A61 \ 2017	Side radar left		x	x	
Titan \ A61 \ 2017	Side radar right		x	x	
Titan \ A61 \ 2017	PTC heater		x	x	
Titan \ A61 \ 2017	Telematics		x	x	0253
Titan \ A61 \ 2017	AVM		x	x	
Titan \ A61 \ 2017	Occupant detection			x	
Tsuru-sentra \ B13 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Tsuru-sentra \ B13 \ All Year	ABS	x	x	x	0003, 0092, 0264
Tsuru-sentra \ B13 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Tsuru-sentra \ B13 \ All Year	BCM	x	x		
Tsuru-sentra \ B13 \ All Year	Air bag	x	x	x	
Tsuru-sentra \ B13 \ All Year	ICC/ADAS	x	x	x	
Tsuru-sentra \ B13 \ All Year	HVAC	x	x	x	
Tsuru-sentra \ B13 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Tsuru-sentra \ B13 \ All Year	Multi AV	x	x	x	0280
Tsuru-sentra \ B13 \ All Year	EPS/DAST 3	x	x	x	
Tsuru-sentra \ B13 \ All Year	IPDM E/R	x	x	x	
Tsuru-sentra \ B13 \ All Year	Air pressure monitor	x	x	x	
Tsuru-sentra \ B13 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Tsuru-sentra \ B13 \ All Year	DIU	x	x	x	
Tsuru-sentra \ B13 \ All Year	Auto slide door	x	x	x	
Tsuru-sentra \ B13 \ All Year	Auto drive position	x	x	x	
Tsuru-sentra \ B13 \ All Year	All mode AWD/4WD	x	x	x	
Tsuru-sentra \ B13 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Tsuru-sentra \ B13 \ All Year	Sonar	x	x	x	
Tsuru-sentra \ B13 \ All Year	Lane camera	x	x	x	

Tsuru-sentra \ B13 \ All Year	Adaptive light	x	x	x	
Tsuru-sentra \ B13 \ All Year	AVM		x	x	
Tsuru-sentra \ B13 \ All Year	Head lamp levelizer	x	x	x	
Tsuru-sentra \ B13 \ All Year	Difference lock	x	x	x	
Tsuru-sentra \ B13 \ All Year	Nats immu	x	x		
Tsuru-sentra \ B13 \ All Year	Smart entrance	x	x		
Tsuru-sentra \ B13 \ All Year	Air levelizer	x	x	x	
Tsuru-sentra \ B13 \ All Year	Rearview camera			x	
Tsuru-sentra \ B13 \ All Year	S/blind camera			x	
Tsuru-sentra \ B13 \ All Year	Motor assist	x	x	x	
Urvan \ E25 \ 2001-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2001-7~	ABS	x	x	x	0003, 0092, 0264
Urvan \ E25 \ 2001-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Urvan \ E25 \ 2001-7~	BCM	x	x		
Urvan \ E25 \ 2001-7~	Air bag	x	x	x	
Urvan \ E25 \ 2001-7~	ICC/ADAS	x	x	x	
Urvan \ E25 \ 2001-7~	HVAC	x	x	x	
Urvan \ E25 \ 2001-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Urvan \ E25 \ 2001-7~	Multi AV	x	x	x	0280
Urvan \ E25 \ 2001-7~	EPS/DAST 3	x	x	x	
Urvan \ E25 \ 2001-7~	IPDM E/R	x	x	x	
Urvan \ E25 \ 2001-7~	Air pressure monitor	x	x	x	
Urvan \ E25 \ 2001-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Urvan \ E25 \ 2001-7~	DIU	x	x	x	
Urvan \ E25 \ 2001-7~	Auto slide door	x	x	x	
Urvan \ E25 \ 2001-7~	Auto drive position	x	x	x	
Urvan \ E25 \ 2001-7~	All mode AWD/4WD	x	x	x	
Urvan \ E25 \ 2001-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Urvan \ E25 \ 2001-7~	Sonar	x	x	x	
Urvan \ E25 \ 2001-7~	Lane camera	x	x	x	
Urvan \ E25 \ 2001-7~	Adaptive light	x	x	x	
Urvan \ E25 \ 2001-7~	AVM		x	x	
Urvan \ E25 \ 2001-7~	Head lamp levelizer	x	x	x	
Urvan \ E25 \ 2001-7~	Difference lock	x	x	x	
Urvan \ E25 \ 2001-7~	Nats immu	x	x		
Urvan \ E25 \ 2001-7~	Smart entrance	x	x		
Urvan \ E25 \ 2001-7~	Air levelizer	x	x	x	
Urvan \ E25 \ 2001-7~	Rearview camera			x	

Urvan \ E25 \ 2001-7~	S/blind camera			x	
Urvan \ E25 \ 2001-7~	Motor assist	x	x	x	
Urvan \ E25 \ 2003-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2003-5~	ABS	x	x	x	0003, 0092, 0264
Urvan \ E25 \ 2003-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Urvan \ E25 \ 2003-5~	BCM	x	x		
Urvan \ E25 \ 2003-5~	Air bag	x	x	x	
Urvan \ E25 \ 2003-5~	ICC/ADAS	x	x	x	
Urvan \ E25 \ 2003-5~	HVAC	x	x	x	
Urvan \ E25 \ 2003-5~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Urvan \ E25 \ 2003-5~	Multi AV	x	x	x	0280
Urvan \ E25 \ 2003-5~	EPS/DAST 3	x	x	x	
Urvan \ E25 \ 2003-5~	IPDM E/R	x	x	x	
Urvan \ E25 \ 2003-5~	Air pressure monitor	x	x	x	
Urvan \ E25 \ 2003-5~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Urvan \ E25 \ 2003-5~	DIU	x	x	x	
Urvan \ E25 \ 2003-5~	Auto slide door	x	x	x	
Urvan \ E25 \ 2003-5~	Auto drive position	x	x	x	
Urvan \ E25 \ 2003-5~	All mode AWD/4WD	x	x	x	
Urvan \ E25 \ 2003-5~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Urvan \ E25 \ 2003-5~	Sonar	x	x	x	
Urvan \ E25 \ 2003-5~	Lane camera	x	x	x	
Urvan \ E25 \ 2003-5~	Adaptive light	x	x	x	
Urvan \ E25 \ 2003-5~	AVM		x	x	
Urvan \ E25 \ 2003-5~	Head lamp levelizer	x	x	x	
Urvan \ E25 \ 2003-5~	Difference lock	x	x	x	
Urvan \ E25 \ 2003-5~	Nats immu	x	x		
Urvan \ E25 \ 2003-5~	Smart entrance	x	x		
Urvan \ E25 \ 2003-5~	Air levelizer	x	x	x	
Urvan \ E25 \ 2003-5~	Rearview camera			x	
Urvan \ E25 \ 2003-5~	S/blind camera			x	
Urvan \ E25 \ 2003-5~	Motor assist	x	x	x	
Urvan \ E25 \ 2006-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2006-1~	ABS	x	x	x	0003, 0092, 0264
Urvan \ E25 \ 2006-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Urvan \ E25 \ 2006-1~	BCM	x	x		
Urvan \ E25 \ 2006-1~	Air bag	x	x	x	

Urvan \ E25 \ 2006-1~	ICC/ADAS	x	x	x	
Urvan \ E25 \ 2006-1~	HVAC	x	x	x	
Urvan \ E25 \ 2006-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Urvan \ E25 \ 2006-1~	Multi AV	x	x	x	0280
Urvan \ E25 \ 2006-1~	EPS/DAST 3	x	x	x	
Urvan \ E25 \ 2006-1~	IPDM E/R	x	x	x	
Urvan \ E25 \ 2006-1~	Air pressure monitor	x	x	x	
Urvan \ E25 \ 2006-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Urvan \ E25 \ 2006-1~	DIU	x	x	x	
Urvan \ E25 \ 2006-1~	Auto slide door	x	x	x	
Urvan \ E25 \ 2006-1~	Auto drive position	x	x	x	
Urvan \ E25 \ 2006-1~	All mode AWD/4WD	x	x	x	
Urvan \ E25 \ 2006-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Urvan \ E25 \ 2006-1~	Sonar	x	x	x	
Urvan \ E25 \ 2006-1~	Lane camera	x	x	x	
Urvan \ E25 \ 2006-1~	Adaptive light	x	x	x	
Urvan \ E25 \ 2006-1~	AVM		x	x	
Urvan \ E25 \ 2006-1~	Head lamp levelizer	x	x	x	
Urvan \ E25 \ 2006-1~	Difference lock	x	x	x	
Urvan \ E25 \ 2006-1~	Nats immu	x	x		
Urvan \ E25 \ 2006-1~	Smart entrance	x	x		
Urvan \ E25 \ 2006-1~	Air levelizer	x	x	x	
Urvan \ E25 \ 2006-1~	Rearview camera			x	
Urvan \ E25 \ 2006-1~	S/blind camera			x	
Urvan \ E25 \ 2006-1~	Motor assist	x	x	x	
Urvan \ E25 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2007-8~	ABS	x	x	x	0003, 0092, 0264
Urvan \ E25 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Urvan \ E25 \ 2007-8~	BCM	x	x		
Urvan \ E25 \ 2007-8~	Air bag	x	x	x	
Urvan \ E25 \ 2007-8~	ICC/ADAS	x	x	x	
Urvan \ E25 \ 2007-8~	HVAC	x	x	x	
Urvan \ E25 \ 2007-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Urvan \ E25 \ 2007-8~	Multi AV	x	x	x	0280
Urvan \ E25 \ 2007-8~	EPS/DAST 3	x	x	x	
Urvan \ E25 \ 2007-8~	IPDM E/R	x	x	x	
Urvan \ E25 \ 2007-8~	Air pressure monitor	x	x	x	

Urvan \ E25 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Urvan \ E25 \ 2007-8~	DIU	x	x	x	
Urvan \ E25 \ 2007-8~	Auto slide door	x	x	x	
Urvan \ E25 \ 2007-8~	Auto drive position	x	x	x	
Urvan \ E25 \ 2007-8~	All mode AWD/4WD	x	x	x	
Urvan \ E25 \ 2007-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Urvan \ E25 \ 2007-8~	Sonar	x	x	x	
Urvan \ E25 \ 2007-8~	Lane camera	x	x	x	
Urvan \ E25 \ 2007-8~	Adaptive light	x	x	x	
Urvan \ E25 \ 2007-8~	AVM		x	x	
Urvan \ E25 \ 2007-8~	Head lamp levelizer	x	x	x	
Urvan \ E25 \ 2007-8~	Difference lock	x	x	x	
Urvan \ E25 \ 2007-8~	Nats immu	x	x		
Urvan \ E25 \ 2007-8~	Smart entrance	x	x		
Urvan \ E25 \ 2007-8~	Air levelizer	x	x	x	
Urvan \ E25 \ 2007-8~	Rearview camera			x	
Urvan \ E25 \ 2007-8~	S/blind camera			x	
Urvan \ E25 \ 2007-8~	Motor assist	x	x	x	
Urvan \ E25 \ 2009-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2009-5~	Transmission	x	x	x	
Urvan \ E25 \ 2009-5~	ABS	x	x	x	
Urvan \ E25 \ 2009-5~	Air bag	x	x	x	
Urvan \ E25 \ 2009-5~	Smart entrance	x	x		
Urvan \ E25 \ 2009-5~	Rearview camera			x	
Urvan \ E25 \ 2009-5~	S/blind camera			x	
Urvan \ E25 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2010-7~	Transmission	x	x	x	
Urvan \ E25 \ 2010-7~	ABS	x	x	x	
Urvan \ E25 \ 2010-7~	Air bag	x	x	x	
Urvan \ E25 \ 2010-7~	Smart entrance	x	x		
Urvan \ E25 \ 2010-7~	Rearview camera			x	
Urvan \ E25 \ 2010-7~	S/blind camera			x	
Urvan \ E25 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2011-11~	ABS	x	x	x	
Urvan \ E25 \ 2011-11~	Air bag	x	x	x	
Urvan \ E25 \ 2011-11~	Transmission	x	x	x	

Urvan \ E25 \ 2011-11~	Smart entrance	x	x		
Urvan \ E25 \ 2011-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Urvan \ E25 \ 2011-5~	ABS	x	x	x	
Urvan \ E25 \ 2011-5~	Air bag	x	x	x	
Urvan \ E25 \ 2011-5~	Transmission	x	x	x	
Urvan \ E25 \ 2011-5~	Smart entrance	x	x		
Venucia D50 \ S10C \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Venucia D50 \ S10C \ 2012-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Venucia D50 \ S10C \ 2012-4~	BCM	x	x		
Venucia D50 \ S10C \ 2012-4~	Air bag	x	x	x	
Venucia D50 \ S10C \ 2012-4~	EPS/DAST 3	x	x	x	
Venucia D50 \ S10C \ 2012-4~	IPDM E/R	x	x	x	
Venucia D50 \ S10C \ 2012-4~	ABS		x	x	
Venucia e30 \ ZE0 \ 2013-10~	ABS	x	x	x	
Venucia e30 \ ZE0 \ 2013-10~	Meter/M&A		x	x	0143
Venucia e30 \ ZE0 \ 2013-10~	BCM		x		
Venucia e30 \ ZE0 \ 2013-10~	Air bag	x	x	x	
Venucia e30 \ ZE0 \ 2013-10~	HVAC		x	x	
Venucia e30 \ ZE0 \ 2013-10~	Multi AV	x	x	x	0280
Venucia e30 \ ZE0 \ 2013-10~	Motor control		x	x	
Venucia e30 \ ZE0 \ 2013-10~	EPS/DAST 3	x	x	x	
Venucia e30 \ ZE0 \ 2013-10~	IPDM E/R		x	x	
Venucia e30 \ ZE0 \ 2013-10~	Shift		x	x	0204
Venucia e30 \ ZE0 \ 2013-10~	EV/HEV	x	x	x	0053
Venucia e30 \ ZE0 \ 2013-10~	HV battery		x	x	0251
Venucia e30 \ ZE0 \ 2013-10~	Brake		x	x	
Venucia e30 \ ZE0 \ 2013-10~	VSP	x	x	x	
Venucia e30 \ ZE0 \ 2013-10~	Charger/PD module		x	x	0065
Venucia e30 \ ZE0 \ 2013-10~	AVM		x	x	
Venucia e30 \ ZE0 \ 2013-10~	Head lamp levelizer	x	x	x	
Venucia e30 \ ZE0 \ 2013-10~	Occupant detection			x	
Venucia e30 \ ZE0 \ 2014-7~	ABS	x	x	x	
Venucia e30 \ ZE0 \ 2014-7~	Meter/M&A		x	x	0143
Venucia e30 \ ZE0 \ 2014-7~	BCM		x		
Venucia e30 \ ZE0 \ 2014-7~	Air bag	x	x	x	
Venucia e30 \ ZE0 \ 2014-7~	HVAC		x	x	
Venucia e30 \ ZE0 \ 2014-7~	Multi AV	x	x	x	0280
Venucia e30 \ ZE0 \ 2014-7~	Motor control		x	x	
Venucia e30 \ ZE0 \ 2014-7~	EPS/DAST 3	x	x	x	

Venucia e30 \ ZE0 \ 2014-7~	IPDM E/R		x	x	
Venucia e30 \ ZE0 \ 2014-7~	Shift		x	x	0204
Venucia e30 \ ZE0 \ 2014-7~	EV/HEV		x	x	
Venucia e30 \ ZE0 \ 2014-7~	HV battery		x	x	
Venucia e30 \ ZE0 \ 2014-7~	Brake		x	x	
Venucia e30 \ ZE0 \ 2014-7~	VSP	x	x	x	
Venucia e30 \ ZE0 \ 2014-7~	Charger/PD module		x	x	
Venucia e30 \ ZE0 \ 2014-7~	AVM		x	x	
Venucia e30 \ ZE0 \ 2014-7~	Head lamp levelizer	x	x	x	
Venucia e30 \ ZE0 \ 2014-7~	Occupant detection			x	
Venucia R30 \ 10K \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Venucia R30 \ 10K \ 2014-6~	ABS	x	x	x	
Venucia R30 \ 10K \ 2014-6~	Meter/M&A		x	x	
Venucia R30 \ 10K \ 2014-6~	BCM		x		
Venucia R30 \ 10K \ 2014-6~	Air bag		x	x	
Venucia R30 \ 10K \ 2014-6~	EPS/DAST 3	x	x	x	
Venucia R30 \ 10K \ 2014-6~	Transmission	x	x	x	
Venucia R50 \ 10C \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Venucia R50 \ 10C \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Venucia R50 \ 10C \ 2012-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Venucia R50 \ 10C \ 2012-8~	BCM	x	x		
Venucia R50 \ 10C \ 2012-8~	EPS/DAST 3	x	x	x	
Venucia R50 \ 10C \ 2012-8~	IPDM E/R	x	x	x	
Venucia R50 \ 10C \ 2012-8~	Air bag	x	x	x	
Venucia T70 \ 10J \ 2014-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Venucia T70 \ 10J \ 2014-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Venucia T70 \ 10J \ 2014-12~	BCM	x	x		
Venucia T70 \ 10J \ 2014-12~	Air bag	x	x	x	
Venucia T70 \ 10J \ 2014-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Venucia T70 \ 10J \ 2014-12~	EPS/DAST 3		x	x	
Venucia T70 \ 10J \ 2014-12~	IPDM E/R	x	x	x	
Venucia T70 \ 10J \ 2014-12~	AVM		x	x	
Venucia T70 \ 10J \ 2014-12~	Chassis control		x	x	
Venucia T70 \ 10J \ 2014-12~	ABS		x	x	
Versa hatchback \ C11 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa hatchback \ C11 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2007	BCM	x	x		

Versa hatchback \ C11 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2007	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2007	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2007	Auto drive position	x	x	x	
Versa hatchback \ C11 \ 2007	ABS	x	x	x	
Versa hatchback \ C11 \ 2007	Air bag	x	x	x	
Versa hatchback \ C11 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa hatchback \ C11 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2008	BCM	x	x		
Versa hatchback \ C11 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2008	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2008	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2008	Auto drive position	x	x	x	
Versa hatchback \ C11 \ 2008	All mode AWD/4WD		x	x	
Versa hatchback \ C11 \ 2008	ABS	x	x	x	
Versa hatchback \ C11 \ 2008	Air bag	x	x	x	
Versa hatchback \ C11 \ 2008	Rearview camera			x	
Versa hatchback \ C11 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa hatchback \ C11 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2009	BCM	x	x		
Versa hatchback \ C11 \ 2009	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2009	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2009	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2009	Auto drive position	x	x	x	
Versa hatchback \ C11 \ 2009	All mode AWD/4WD		x	x	
Versa hatchback \ C11 \ 2009	ABS	x	x	x	
Versa hatchback \ C11 \ 2009	Air bag	x	x	x	
Versa hatchback \ C11 \ 2009	Rearview camera			x	
Versa hatchback \ C11 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

Versa hatchback \ C11 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2010	BCM	x	x		
Versa hatchback \ C11 \ 2010	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2010	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2010	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2010	Auto drive position	x	x	x	
Versa hatchback \ C11 \ 2010	Adaptive light	x	x	x	
Versa hatchback \ C11 \ 2010	ABS	x	x	x	
Versa hatchback \ C11 \ 2010	Air bag	x	x	x	
Versa hatchback \ C11 \ 2010	Rearview camera			x	
Versa hatchback \ C11 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa hatchback \ C11 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2011	BCM	x	x		
Versa hatchback \ C11 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2011	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2011	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2011	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2011	Auto drive position	x	x	x	
Versa hatchback \ C11 \ 2011	Adaptive light	x	x	x	
Versa hatchback \ C11 \ 2011	ABS	x	x	x	
Versa hatchback \ C11 \ 2011	Air bag	x	x	x	
Versa hatchback \ C11 \ 2011	Rearview camera			x	
Versa hatchback \ C11 \ 2011	S/blind camera			x	
Versa hatchback \ C11 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa hatchback \ C11 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa hatchback \ C11 \ 2012	BCM	x	x		
Versa hatchback \ C11 \ 2012	Air bag	x	x	x	
Versa hatchback \ C11 \ 2012	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa hatchback \ C11 \ 2012	EPS/DAST 3	x	x	x	
Versa hatchback \ C11 \ 2012	IPDM E/R	x	x	x	
Versa hatchback \ C11 \ 2012	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa hatchback \ C11 \ 2012	Auto drive position	x	x	x	

Versa hatchback \ C11 \ 2012	Adaptive light	x	x	x	
Versa hatchback \ C11 \ 2012	ABS	x	x	x	
Versa note \ E12 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa note \ E12 \ 2014	ABS	x	x	x	
Versa note \ E12 \ 2014	Meter/M&A		x	x	
Versa note \ E12 \ 2014	BCM		x		
Versa note \ E12 \ 2014	Air bag	x	x	x	
Versa note \ E12 \ 2014	Transmission		x	x	
Versa note \ E12 \ 2014	Multi AV		x	x	
Versa note \ E12 \ 2014	EPS/DAST 3	x	x	x	
Versa note \ E12 \ 2014	IPDM E/R		x	x	
Versa note \ E12 \ 2014	AVM		x	x	
Versa note \ E12 \ 2014	Occupant detection			x	
Versa note \ E12 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa note \ E12 \ 2015	ABS	x	x	x	
Versa note \ E12 \ 2015	Meter/M&A		x	x	
Versa note \ E12 \ 2015	BCM		x		
Versa note \ E12 \ 2015	Air bag	x	x	x	
Versa note \ E12 \ 2015	Transmission		x	x	
Versa note \ E12 \ 2015	Multi AV	x	x	x	0280
Versa note \ E12 \ 2015	EPS/DAST 3	x	x	x	
Versa note \ E12 \ 2015	IPDM E/R		x	x	
Versa note \ E12 \ 2015	Telematics		x	x	
Versa note \ E12 \ 2015	AVM		x	x	
Versa note \ E12 \ 2015	Occupant detection			x	
Versa note \ E12 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa note \ E12 \ 2016	ABS	x	x	x	
Versa note \ E12 \ 2016	Meter/M&A		x	x	
Versa note \ E12 \ 2016	BCM		x		
Versa note \ E12 \ 2016	Air bag	x	x	x	
Versa note \ E12 \ 2016	Transmission		x	x	
Versa note \ E12 \ 2016	Multi AV	x	x	x	0280
Versa note \ E12 \ 2016	EPS/DAST 3	x	x	x	
Versa note \ E12 \ 2016	IPDM E/R		x	x	
Versa note \ E12 \ 2016	Side radar left		x	x	
Versa note \ E12 \ 2016	Side radar right		x	x	
Versa note \ E12 \ 2016	PTC heater		x	x	
Versa note \ E12 \ 2016	AVM		x	x	

Versa note \ E12 \ 2016	Occupant detection			x	
Versa sedan \ N17 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2012	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2012	Meter/M&A		x	x	
Versa sedan \ N17 \ 2012	BCM		x		
Versa sedan \ N17 \ 2012	Air bag	x	x	x	
Versa sedan \ N17 \ 2012	Transmission		x	x	
Versa sedan \ N17 \ 2012	EPS/DAST 3	x	x	x	
Versa sedan \ N17 \ 2012	IPDM E/R		x	x	
Versa sedan \ N17 \ 2012	Occupant detection			x	
Versa sedan \ N17 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2013	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2013	Meter/M&A		x	x	
Versa sedan \ N17 \ 2013	BCM		x		
Versa sedan \ N17 \ 2013	Air bag		x	x	
Versa sedan \ N17 \ 2013	Transmission		x	x	
Versa sedan \ N17 \ 2013	EPS/DAST 3	x	x	x	
Versa sedan \ N17 \ 2013	IPDM E/R		x	x	
Versa sedan \ N17 \ 2013	Occupant detection			x	
Versa sedan \ N17 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2014	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2014	Meter/M&A		x	x	
Versa sedan \ N17 \ 2014	BCM		x		
Versa sedan \ N17 \ 2014	Air bag	x	x	x	
Versa sedan \ N17 \ 2014	Transmission		x	x	
Versa sedan \ N17 \ 2014	Multi AV		x	x	
Versa sedan \ N17 \ 2014	EPS/DAST 3	x	x	x	
Versa sedan \ N17 \ 2014	IPDM E/R		x	x	
Versa sedan \ N17 \ 2014	Occupant detection			x	
Versa sedan \ N17 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2015	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ N17 \ 2015	BCM		x		
Versa sedan \ N17 \ 2015	Air bag	x	x	x	
Versa sedan \ N17 \ 2015	Transmission		x	x	
Versa sedan \ N17 \ 2015	Multi AV	x	x	x	0280
Versa sedan \ N17 \ 2015	EPS/DAST 3	x	x	x	

Versa sedan \ N17 \ 2015	IPDM E/R		x	x	
Versa sedan \ N17 \ 2015	Air pressure monitor	x	x	x	
Versa sedan \ N17 \ 2015	AVM		x	x	
Versa sedan \ N17 \ 2015	Occupant detection			x	
Versa sedan \ N17 \ 2016	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2016	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2016	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ N17 \ 2016	BCM		x		
Versa sedan \ N17 \ 2016	Air bag	x	x	x	
Versa sedan \ N17 \ 2016	Transmission		x	x	
Versa sedan \ N17 \ 2016	Multi AV	x	x	x	0280
Versa sedan \ N17 \ 2016	EPS/DAST 3	x	x	x	
Versa sedan \ N17 \ 2016	IPDM E/R		x	x	
Versa sedan \ N17 \ 2016	PTC heater		x	x	
Versa sedan \ N17 \ 2016	AVM		x	x	
Versa sedan \ N17 \ 2016	Occupant detection			x	
Versa sedan \ N17 \ 2017	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ N17 \ 2017	ABS	x	x	x	0003, 0092, 0264
Versa sedan \ N17 \ 2017	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ N17 \ 2017	BCM		x		
Versa sedan \ N17 \ 2017	Air bag	x	x	x	
Versa sedan \ N17 \ 2017	ICC/ADAS	x	x	x	
Versa sedan \ N17 \ 2017	Transmission		x	x	
Versa sedan \ N17 \ 2017	Multi AV	x	x	x	0280
Versa sedan \ N17 \ 2017	EPS/DAST 3	x	x	x	
Versa sedan \ N17 \ 2017	IPDM E/R		x	x	
Versa sedan \ N17 \ 2017	Occupant detection			x	
Versa sedan \ SC11 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ SC11 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ SC11 \ 2007	BCM	x	x		
Versa sedan \ SC11 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa sedan \ SC11 \ 2007	EPS/DAST 3	x	x	x	
Versa sedan \ SC11 \ 2007	IPDM E/R	x	x	x	
Versa sedan \ SC11 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa sedan \ SC11 \ 2007	Auto drive position	x	x	x	
Versa sedan \ SC11 \ 2007	ABS	x	x	x	

Versa sedan \ SC11 \ 2007	Air bag	x	x	x	
Versa sedan \ SC11 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ SC11 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ SC11 \ 2008	BCM	x	x		
Versa sedan \ SC11 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa sedan \ SC11 \ 2008	EPS/DAST 3	x	x	x	
Versa sedan \ SC11 \ 2008	IPDM E/R	x	x	x	
Versa sedan \ SC11 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa sedan \ SC11 \ 2008	Auto drive position	x	x	x	
Versa sedan \ SC11 \ 2008	All mode AWD/4WD		x	x	
Versa sedan \ SC11 \ 2008	ABS	x	x	x	
Versa sedan \ SC11 \ 2008	Air bag	x	x	x	
Versa sedan \ SC11 \ 2008	Rearview camera			x	
Versa sedan \ SC11 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ SC11 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ SC11 \ 2009	BCM	x	x		
Versa sedan \ SC11 \ 2009	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa sedan \ SC11 \ 2009	EPS/DAST 3	x	x	x	
Versa sedan \ SC11 \ 2009	IPDM E/R	x	x	x	
Versa sedan \ SC11 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa sedan \ SC11 \ 2009	Auto drive position	x	x	x	
Versa sedan \ SC11 \ 2009	All mode AWD/4WD		x	x	
Versa sedan \ SC11 \ 2009	ABS	x	x	x	
Versa sedan \ SC11 \ 2009	Air bag	x	x	x	
Versa sedan \ SC11 \ 2009	Rearview camera			x	
Versa sedan \ SC11 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ SC11 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ SC11 \ 2010	BCM	x	x		
Versa sedan \ SC11 \ 2010	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa sedan \ SC11 \ 2010	EPS/DAST 3	x	x	x	
Versa sedan \ SC11 \ 2010	IPDM E/R	x	x	x	
Versa sedan \ SC11 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Versa sedan \ SC11 \ 2010	Auto drive position	x	x	x	
Versa sedan \ SC11 \ 2010	Adaptive light	x	x	x	
Versa sedan \ SC11 \ 2010	ABS	x	x	x	
Versa sedan \ SC11 \ 2010	Air bag	x	x	x	
Versa sedan \ SC11 \ 2010	Rearview camera			x	
Versa sedan \ SC11 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa sedan \ SC11 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa sedan \ SC11 \ 2011	BCM	x	x		
Versa sedan \ SC11 \ 2011	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Versa sedan \ SC11 \ 2011	EPS/DAST 3	x	x	x	
Versa sedan \ SC11 \ 2011	IPDM E/R	x	x	x	
Versa sedan \ SC11 \ 2011	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Versa sedan \ SC11 \ 2011	Auto drive position	x	x	x	
Versa sedan \ SC11 \ 2011	Adaptive light	x	x	x	
Versa sedan \ SC11 \ 2011	ABS	x	x	x	
Versa sedan \ SC11 \ 2011	Air bag	x	x	x	
Versa sedan \ SC11 \ 2011	Rearview camera			x	
Versa sedan \ SC11 \ 2011	S/blind camera			x	
Versa \ N17 \ 2014-5~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa \ N17 \ 2014-5~	ABS	x	x	x	0003, 0092, 0264
Versa \ N17 \ 2014-5~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa \ N17 \ 2014-5~	BCM		x		
Versa \ N17 \ 2014-5~	Air bag	x	x	x	
Versa \ N17 \ 2014-5~	ICC/ADAS	x	x	x	
Versa \ N17 \ 2014-5~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Versa \ N17 \ 2014-5~	Multi AV	x	x	x	0280
Versa \ N17 \ 2014-5~	EPS/DAST 3	x	x	x	
Versa \ N17 \ 2014-5~	IPDM E/R		x	x	
Versa \ N17 \ 2014-5~	Laser/radar	x	x	x	
Versa \ N17 \ 2014-5~	Sonar	x	x	x	
Versa \ N17 \ 2014-5~	Accele pedal ACT		x	x	
Versa \ N17 \ 2014-5~	Side radar left		x	x	
Versa \ N17 \ 2014-5~	ANC		x	x	
Versa \ N17 \ 2014-5~	Side radar right		x	x	
Versa \ N17 \ 2014-5~	PTC heater		x	x	
Versa \ N17 \ 2014-5~	Telematics		x	x	0253

Versa \ N17 \ 2014-5~	AVM		x	x	
Versa \ N17 \ 2014-5~	Head lamp levelizer	x	x	x	
Versa \ N17 \ 2014-5~	Occupant detection			x	
Versa \ N17 \ 2015-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa \ N17 \ 2015-7~	ABS	x	x	x	0003, 0092, 0264
Versa \ N17 \ 2015-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa \ N17 \ 2015-7~	BCM		x		
Versa \ N17 \ 2015-7~	Air bag	x	x	x	
Versa \ N17 \ 2015-7~	ICC/ADAS	x	x	x	
Versa \ N17 \ 2015-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Versa \ N17 \ 2015-7~	Multi AV	x	x	x	0280
Versa \ N17 \ 2015-7~	EPS/DAST 3	x	x	x	
Versa \ N17 \ 2015-7~	IPDM E/R		x	x	
Versa \ N17 \ 2015-7~	Side radar left		x	x	
Versa \ N17 \ 2015-7~	Side radar right		x	x	
Versa \ N17 \ 2015-7~	PTC heater		x	x	
Versa \ N17 \ 2015-7~	AVM		x	x	
Versa \ N17 \ 2015-7~	Occupant detection			x	
Versa \ N17 \ 2016-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa \ N17 \ 2016-3~	ABS	x	x	x	0003, 0092, 0264
Versa \ N17 \ 2016-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa \ N17 \ 2016-3~	BCM		x		
Versa \ N17 \ 2016-3~	Air bag	x	x	x	
Versa \ N17 \ 2016-3~	ICC/ADAS	x	x	x	
Versa \ N17 \ 2016-3~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Versa \ N17 \ 2016-3~	Multi AV	x	x	x	0280
Versa \ N17 \ 2016-3~	EPS/DAST 3	x	x	x	
Versa \ N17 \ 2016-3~	IPDM E/R		x	x	
Versa \ N17 \ 2016-3~	Laser/radar	x	x	x	
Versa \ N17 \ 2016-3~	Sonar	x	x	x	
Versa \ N17 \ 2016-3~	Accele pedal ACT		x	x	
Versa \ N17 \ 2016-3~	Side radar left		x	x	
Versa \ N17 \ 2016-3~	ANC		x	x	
Versa \ N17 \ 2016-3~	Side radar right		x	x	
Versa \ N17 \ 2016-3~	PTC heater		x	x	
Versa \ N17 \ 2016-3~	Telematics		x	x	0253
Versa \ N17 \ 2016-3~	AVM		x	x	

Versa \ N17 \ 2016-3~	Head lamp levelizer	x	x	x	
Versa \ N17 \ 2016-3~	Occupant detection			x	
Versa \ N17 \ 2016-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa \ N17 \ 2016-4~	ABS	x	x	x	0003, 0092, 0264
Versa \ N17 \ 2016-4~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa \ N17 \ 2016-4~	BCM		x		
Versa \ N17 \ 2016-4~	Air bag	x	x	x	
Versa \ N17 \ 2016-4~	Transmission		x	x	
Versa \ N17 \ 2016-4~	Multi AV	x	x	x	0280
Versa \ N17 \ 2016-4~	EPS/DAST 3	x	x	x	
Versa \ N17 \ 2016-4~	IPDM E/R		x	x	
Versa \ N17 \ 2016-4~	Side radar left		x	x	
Versa \ N17 \ 2016-4~	Side radar right		x	x	
Versa \ N17 \ 2016-4~	PTC heater		x	x	
Versa \ N17 \ 2016-4~	Occupant detection			x	
Versa \ N17 \ 2016-4~	ICC/ADAS	x	x	x	
Versa \ N17 \ 2016-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Versa \ N17 \ 2016-4~	AVM		x	x	
Versa \ N17 \ 2016-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa \ N17 \ 2016-7~	ABS	x	x	x	0003, 0092, 0264
Versa \ N17 \ 2016-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa \ N17 \ 2016-7~	BCM		x		
Versa \ N17 \ 2016-7~	Air bag	x	x	x	
Versa \ N17 \ 2016-7~	ICC/ADAS	x	x	x	
Versa \ N17 \ 2016-7~	Transmission		x	x	
Versa \ N17 \ 2016-7~	Multi AV	x	x	x	0280
Versa \ N17 \ 2016-7~	EPS/DAST 3	x	x	x	
Versa \ N17 \ 2016-7~	IPDM E/R		x	x	
Versa \ N17 \ 2016-7~	Accele pedal ACT		x	x	
Versa \ N17 \ 2016-7~	Occupant detection			x	
Versa-Tiida Sedan \ N17 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa-Tiida Sedan \ N17 \ 2011-10~	ABS	x	x	x	0003, 0092, 0264
Versa-Tiida Sedan \ N17 \ 2011-10~	Meter/M&A		x	x	
Versa-Tiida Sedan \ N17 \ 2011-10~	BCM		x		
Versa-Tiida Sedan \ N17 \ 2011-10~	Air bag	x	x	x	
Versa-Tiida Sedan \ N17 \ 2011-10~	Transmission		x	x	
Versa-Tiida Sedan \ N17 \ 2011-10~	EPS/DAST 3	x	x	x	

Versa-Tiida Sedan \ N17 \ 2011-10~	IPDM E/R		x	x	
Versa-Tiida Sedan \ N17 \ 2011-10~	Sonar	x	x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa-Tiida Sedan \ N17 \ 2011-6~	ABS	x	x	x	0003, 0092, 0264
Versa-Tiida Sedan \ N17 \ 2011-6~	Meter/M&A		x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	BCM		x		
Versa-Tiida Sedan \ N17 \ 2011-6~	Air bag	x	x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	Transmission		x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	Multi AV	x	x	x	0280
Versa-Tiida Sedan \ N17 \ 2011-6~	EPS/DAST 3	x	x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	IPDM E/R		x	x	
Versa-Tiida Sedan \ N17 \ 2011-6~	Occupant detection			x	
Versa-Tiida Sedan \ N17 \ 2012-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa-Tiida Sedan \ N17 \ 2012-11~	ABS	x	x	x	0003, 0092, 0264
Versa-Tiida Sedan \ N17 \ 2012-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa-Tiida Sedan \ N17 \ 2012-11~	BCM		x		
Versa-Tiida Sedan \ N17 \ 2012-11~	Air bag	x	x	x	
Versa-Tiida Sedan \ N17 \ 2012-11~	Transmission		x	x	
Versa-Tiida Sedan \ N17 \ 2012-11~	EPS/DAST 3	x	x	x	
Versa-Tiida Sedan \ N17 \ 2012-11~	IPDM E/R		x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa-Tiida Sedan \ N17 \ 2012-8~	ABS	x	x	x	0003, 0092, 0264
Versa-Tiida Sedan \ N17 \ 2012-8~	Meter/M&A		x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	BCM		x		
Versa-Tiida Sedan \ N17 \ 2012-8~	Air bag	x	x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	Transmission		x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	EPS/DAST 3	x	x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	IPDM E/R		x	x	
Versa-Tiida Sedan \ N17 \ 2012-8~	SVT	x	x	x	
Versa-Tiida Sedan \ N17 \ 2013-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Versa-Tiida Sedan \ N17 \ 2013-1~	ABS	x	x	x	0003, 0092, 0264
Versa-Tiida Sedan \ N17 \ 2013-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Versa-Tiida Sedan \ N17 \ 2013-1~	BCM		x		
Versa-Tiida Sedan \ N17 \ 2013-1~	Air bag	x	x	x	
Versa-Tiida Sedan \ N17 \ 2013-1~	Transmission		x	x	
Versa-Tiida Sedan \ N17 \ 2013-1~	EPS/DAST 3	x	x	x	
Versa-Tiida Sedan \ N17 \ 2013-1~	IPDM E/R		x	x	

Versa-Tiida Sedan \ N17 \ 2013-1~	Occupant detection			x	
Versa-Tiida Sedan \ N17 \ 2013-1~	SVT	x	x	x	
Wingroad \ Y10 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y10 \ All Year	ABS	x	x	x	0003, 0092, 0264
Wingroad \ Y10 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y10 \ All Year	BCM	x	x		
Wingroad \ Y10 \ All Year	Air bag	x	x	x	
Wingroad \ Y10 \ All Year	ICC/ADAS	x	x	x	
Wingroad \ Y10 \ All Year	HVAC	x	x	x	
Wingroad \ Y10 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y10 \ All Year	Multi AV	x	x	x	0280
Wingroad \ Y10 \ All Year	EPS/DAST 3	x	x	x	
Wingroad \ Y10 \ All Year	IPDM E/R	x	x	x	
Wingroad \ Y10 \ All Year	Air pressure monitor	x	x	x	
Wingroad \ Y10 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y10 \ All Year	DIU	x	x	x	
Wingroad \ Y10 \ All Year	Auto slide door	x	x	x	
Wingroad \ Y10 \ All Year	Auto drive position	x	x	x	
Wingroad \ Y10 \ All Year	All mode AWD/4WD	x	x	x	
Wingroad \ Y10 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Wingroad \ Y10 \ All Year	Sonar	x	x	x	
Wingroad \ Y10 \ All Year	Lane camera	x	x	x	
Wingroad \ Y10 \ All Year	Adaptive light	x	x	x	
Wingroad \ Y10 \ All Year	AVM		x	x	
Wingroad \ Y10 \ All Year	Head lamp levelizer	x	x	x	
Wingroad \ Y10 \ All Year	Difference lock	x	x	x	
Wingroad \ Y10 \ All Year	Nats immu	x	x		
Wingroad \ Y10 \ All Year	Smart entrance	x	x		
Wingroad \ Y10 \ All Year	Air levelizer	x	x	x	
Wingroad \ Y10 \ All Year	Rearview camera			x	
Wingroad \ Y10 \ All Year	S/blind camera			x	
Wingroad \ Y10 \ All Year	Motor assist	x	x	x	
Wingroad \ Y11 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y11 \ All Year	ABS	x	x	x	0003, 0092, 0264
Wingroad \ Y11 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y11 \ All Year	BCM	x	x		
Wingroad \ Y11 \ All Year	Air bag	x	x	x	

Wingroad \ Y11 \ All Year	ICC/ADAS	x	x	x	
Wingroad \ Y11 \ All Year	HVAC	x	x	x	
Wingroad \ Y11 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y11 \ All Year	Multi AV	x	x	x	0280
Wingroad \ Y11 \ All Year	EPS/DAST 3	x	x	x	
Wingroad \ Y11 \ All Year	IPDM E/R	x	x	x	
Wingroad \ Y11 \ All Year	Air pressure monitor	x	x	x	
Wingroad \ Y11 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y11 \ All Year	DIU	x	x	x	
Wingroad \ Y11 \ All Year	Auto slide door	x	x	x	
Wingroad \ Y11 \ All Year	Auto drive position	x	x	x	
Wingroad \ Y11 \ All Year	All mode AWD/4WD	x	x	x	
Wingroad \ Y11 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Wingroad \ Y11 \ All Year	Sonar	x	x	x	
Wingroad \ Y11 \ All Year	Lane camera	x	x	x	
Wingroad \ Y11 \ All Year	Adaptive light	x	x	x	
Wingroad \ Y11 \ All Year	AVM		x	x	
Wingroad \ Y11 \ All Year	Head lamp levelizer	x	x	x	
Wingroad \ Y11 \ All Year	Difference lock	x	x	x	
Wingroad \ Y11 \ All Year	Nats immu	x	x		
Wingroad \ Y11 \ All Year	Smart entrance	x	x		
Wingroad \ Y11 \ All Year	Air levelizer	x	x	x	
Wingroad \ Y11 \ All Year	Rearview camera			x	
Wingroad \ Y11 \ All Year	S/blind camera			x	
Wingroad \ Y11 \ All Year	Motor assist	x	x	x	
Wingroad \ Y12 \ 2005-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2005-11~	BCM	x	x		
Wingroad \ Y12 \ 2005-11~	Transmission	x	x	x	
Wingroad \ Y12 \ 2005-11~	Multi AV	x	x	x	0280
Wingroad \ Y12 \ 2005-11~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2005-11~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2005-11~	E-4wd	x	x	x	
Wingroad \ Y12 \ 2005-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2005-11~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2005-11~	Engine	x	x	x	
Wingroad \ Y12 \ 2005-11~	ABS	x	x	x	
Wingroad \ Y12 \ 2005-11~	Air bag	x	x	x	

Wingroad \ Y12 \ 2005-11~	Head lamp levelizer	x	x	x	
Wingroad \ Y12 \ 2006-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y12 \ 2006-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2006-12~	BCM	x	x		
Wingroad \ Y12 \ 2006-12~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y12 \ 2006-12~	Multi AV	x	x	x	
Wingroad \ Y12 \ 2006-12~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2006-12~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2006-12~	E-4wd	x	x	x	
Wingroad \ Y12 \ 2006-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2006-12~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2006-12~	ABS	x	x	x	
Wingroad \ Y12 \ 2006-12~	Air bag	x	x	x	
Wingroad \ Y12 \ 2006-12~	Head lamp levelizer	x	x	x	
Wingroad \ Y12 \ 2006-12~	Transmission	x	x	x	
Wingroad \ Y12 \ 2006-12~	Engine	x	x	x	
Wingroad \ Y12 \ 2008-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y12 \ 2008-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2008-1~	BCM	x	x		
Wingroad \ Y12 \ 2008-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y12 \ 2008-1~	Multi AV	x	x	x	
Wingroad \ Y12 \ 2008-1~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2008-1~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2008-1~	E-4wd	x	x	x	
Wingroad \ Y12 \ 2008-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2008-1~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2008-1~	ABS	x	x	x	
Wingroad \ Y12 \ 2008-1~	Air bag	x	x	x	
Wingroad \ Y12 \ 2008-1~	Head lamp levelizer	x	x	x	
Wingroad \ Y12 \ 2008-1~	Transmission		x	x	
Wingroad \ Y12 \ 2008-1~	Engine	x	x	x	
Wingroad \ Y12 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y12 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2010-8~	BCM	x	x		

Wingroad \ Y12 \ 2010-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y12 \ 2010-8~	Multi AV	x	x	x	
Wingroad \ Y12 \ 2010-8~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2010-8~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2010-8~	E-4wd	x	x	x	
Wingroad \ Y12 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2010-8~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2010-8~	ABS	x	x	x	
Wingroad \ Y12 \ 2010-8~	Air bag	x	x	x	
Wingroad \ Y12 \ 2010-8~	Head lamp levelizer	x	x	x	
Wingroad \ Y12 \ 2010-8~	Rearview camera			x	
Wingroad \ Y12 \ 2010-8~	S/blind camera			x	
Wingroad \ Y12 \ 2012-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y12 \ 2012-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2012-6~	BCM	x	x		
Wingroad \ Y12 \ 2012-6~	Air bag	x	x	x	
Wingroad \ Y12 \ 2012-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y12 \ 2012-6~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2012-6~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2012-6~	E-4wd	x	x	x	
Wingroad \ Y12 \ 2012-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2012-6~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2012-6~	ABS	x	x	x	
Wingroad \ Y12 \ 2012-6~	Head lamp levelizer	x	x	x	
Wingroad \ Y12 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Wingroad \ Y12 \ 2014-8~	ABS	x	x	x	
Wingroad \ Y12 \ 2014-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Wingroad \ Y12 \ 2014-8~	BCM	x	x		
Wingroad \ Y12 \ 2014-8~	Air bag	x	x	x	
Wingroad \ Y12 \ 2014-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Wingroad \ Y12 \ 2014-8~	Multi AV	x	x	x	0280
Wingroad \ Y12 \ 2014-8~	EPS/DAST 3	x	x	x	
Wingroad \ Y12 \ 2014-8~	IPDM E/R	x	x	x	
Wingroad \ Y12 \ 2014-8~	Laser/radar	x	x	x	

Wingroad \ Y12 \ 2014-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Wingroad \ Y12 \ 2014-8~	All mode AWD/4WD	x	x	x	0245, 0311
Wingroad \ Y12 \ 2014-8~	Sonar	x	x	x	
Wingroad \ Y12 \ 2014-8~	Adaptive light	x	x	x	
Wingroad \ Y12 \ 2014-8~	AVM		x	x	
Wingroad \ Y12 \ 2014-8~	Head lamp levelizer	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-TRAIL Hybrid \ HT32 \ 2015-11~	ABS		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Meter/M&A		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	BCM		x		
X-TRAIL Hybrid \ HT32 \ 2015-11~	Air bag		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	ICC/ADAS	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	HVAC		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-TRAIL Hybrid \ HT32 \ 2015-11~	Multi AV	x	x	x	0280
X-TRAIL Hybrid \ HT32 \ 2015-11~	Motor control		x	x	0238
X-TRAIL Hybrid \ HT32 \ 2015-11~	EPS/DAST 3		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	IPDM E/R		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Air pressure monitor	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Laser/radar	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Auto drive position		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	All mode AWD/4WD		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Sonar		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	CAN gateway		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	EV/HEV		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Auto back door		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	HV battery		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Brake		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Side radar left		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	VSP		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Side radar right		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	AVM		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Chassis control		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-11~	Occupant detection			x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-TRAIL Hybrid \ HT32 \ 2015-3~	ABS		x	x	

X-TRAIL Hybrid \ HT32 \ 2015-3~	Meter/M&A		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	BCM		x		
X-TRAIL Hybrid \ HT32 \ 2015-3~	Air bag		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	ICC/ADAS	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	HVAC		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Transmission		x	x	0076, 0117, 0113, 0149, 0110, 0059, 0150, 0085
X-TRAIL Hybrid \ HT32 \ 2015-3~	Multi AV	x	x	x	0280
X-TRAIL Hybrid \ HT32 \ 2015-3~	Motor control		x	x	0238
X-TRAIL Hybrid \ HT32 \ 2015-3~	EPS/DAST 3		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	IPDM E/R		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Laser/radar	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	All mode AWD/4WD		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Sonar		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Lane camera	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	CAN gateway		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	EV/HEV		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Auto back door		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	HV battery		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Brake		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Side radar left		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	VSP		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Side radar right		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Telematics		x	x	0253
X-TRAIL Hybrid \ HT32 \ 2015-3~	AVM		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Chassis control		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	FSCM		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-3~	Occupant detection			x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-TRAIL Hybrid \ HT32 \ 2015-8~	ABS		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Meter/M&A		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	BCM		x		
X-TRAIL Hybrid \ HT32 \ 2015-8~	Air bag		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	ICC/ADAS	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	HVAC		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-TRAIL Hybrid \ HT32 \ 2015-8~	Multi AV	x	x	x	0280
X-TRAIL Hybrid \ HT32 \ 2015-8~	Motor control		x	x	0238
X-TRAIL Hybrid \ HT32 \ 2015-8~	EPS/DAST 3		x	x	

X-TRAIL Hybrid \ HT32 \ 2015-8~	IPDM E/R		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Air pressure monitor	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Laser/radar	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Auto drive position		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	All mode AWD/4WD		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Sonar		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	CAN gateway		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	EV/HEV		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Auto back door		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	HV battery		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Brake		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Side radar left		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	VSP		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Side radar right		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	AVM		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Chassis control		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Occupant detection			x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	ICC/ADAS		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Air pressure monitor		x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Sonar	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Lane camera	x	x	x	
X-TRAIL Hybrid \ HT32 \ 2015-8~	Telematics		x	x	0253
X-trail \ T30 \ 2001-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T30 \ 2001-6~	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ 2001-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ 2001-6~	BCM	x	x		
X-trail \ T30 \ 2001-6~	Air bag	x	x	x	
X-trail \ T30 \ 2001-6~	ICC/ADAS	x	x	x	
X-trail \ T30 \ 2001-6~	HVAC	x	x	x	
X-trail \ T30 \ 2001-6~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ 2001-6~	Multi AV	x	x	x	0280
X-trail \ T30 \ 2001-6~	EPS/DAST 3	x	x	x	
X-trail \ T30 \ 2001-6~	IPDM E/R	x	x	x	
X-trail \ T30 \ 2001-6~	Air pressure monitor	x	x	x	
X-trail \ T30 \ 2001-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ 2001-6~	DIU	x	x	x	
X-trail \ T30 \ 2001-6~	Auto slide door	x	x	x	
X-trail \ T30 \ 2001-6~	Auto drive position	x	x	x	

X-trail \ T30 \ 2001-6~	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ 2001-6~	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ 2001-6~	Sonar	x	x	x	
X-trail \ T30 \ 2001-6~	Lane camera	x	x	x	
X-trail \ T30 \ 2001-6~	Adaptive light	x	x	x	
X-trail \ T30 \ 2001-6~	AVM		x	x	
X-trail \ T30 \ 2001-6~	Head lamp levelizer	x	x	x	
X-trail \ T30 \ 2001-6~	Difference lock	x	x	x	
X-trail \ T30 \ 2001-6~	Nats immu	x	x		
X-trail \ T30 \ 2001-6~	Smart entrance	x	x		
X-trail \ T30 \ 2001-6~	Air levelizer	x	x	x	
X-trail \ T30 \ 2001-6~	Rearview camera			x	
X-trail \ T30 \ 2001-6~	S/blind camera			x	
X-trail \ T30 \ 2001-6~	Motor assist	x	x	x	
X-trail \ T30 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T30 \ 2005	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ 2005	BCM	x	x		
X-trail \ T30 \ 2005	Air bag	x	x	x	
X-trail \ T30 \ 2005	ICC/ADAS	x	x	x	
X-trail \ T30 \ 2005	HVAC	x	x	x	
X-trail \ T30 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ 2005	Multi AV	x	x	x	0280
X-trail \ T30 \ 2005	EPS/DAST 3	x	x	x	
X-trail \ T30 \ 2005	IPDM E/R	x	x	x	
X-trail \ T30 \ 2005	Air pressure monitor	x	x	x	
X-trail \ T30 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ 2005	DIU	x	x	x	
X-trail \ T30 \ 2005	Auto slide door	x	x	x	
X-trail \ T30 \ 2005	Auto drive position	x	x	x	
X-trail \ T30 \ 2005	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ 2005	Sonar	x	x	x	
X-trail \ T30 \ 2005	Lane camera	x	x	x	
X-trail \ T30 \ 2005	Adaptive light	x	x	x	
X-trail \ T30 \ 2005	AVM		x	x	
X-trail \ T30 \ 2005	Head lamp levelizer	x	x	x	
X-trail \ T30 \ 2005	Difference lock	x	x	x	

X-trail \ T30 \ 2005	Nats immu	x	x		
X-trail \ T30 \ 2005	Smart entrance	x	x		
X-trail \ T30 \ 2005	Air levelizer	x	x	x	
X-trail \ T30 \ 2005	Rearview camera			x	
X-trail \ T30 \ 2005	S/blind camera			x	
X-trail \ T30 \ 2005	Motor assist	x	x	x	
X-trail \ T30 \ 2005-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T30 \ 2005-10~	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ 2005-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ 2005-10~	BCM	x	x		
X-trail \ T30 \ 2005-10~	Air bag	x	x	x	
X-trail \ T30 \ 2005-10~	ICC/ADAS	x	x	x	
X-trail \ T30 \ 2005-10~	HVAC	x	x	x	
X-trail \ T30 \ 2005-10~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ 2005-10~	Multi AV	x	x	x	0280
X-trail \ T30 \ 2005-10~	EPS/DAST 3	x	x	x	
X-trail \ T30 \ 2005-10~	IPDM E/R	x	x	x	
X-trail \ T30 \ 2005-10~	Air pressure monitor	x	x	x	
X-trail \ T30 \ 2005-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ 2005-10~	DIU	x	x	x	
X-trail \ T30 \ 2005-10~	Auto slide door	x	x	x	
X-trail \ T30 \ 2005-10~	Auto drive position	x	x	x	
X-trail \ T30 \ 2005-10~	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ 2005-10~	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ 2005-10~	Sonar	x	x	x	
X-trail \ T30 \ 2005-10~	Lane camera	x	x	x	
X-trail \ T30 \ 2005-10~	Adaptive light	x	x	x	
X-trail \ T30 \ 2005-10~	AVM		x	x	
X-trail \ T30 \ 2005-10~	Head lamp levelizer	x	x	x	
X-trail \ T30 \ 2005-10~	Difference lock	x	x	x	
X-trail \ T30 \ 2005-10~	Nats immu	x	x		
X-trail \ T30 \ 2005-10~	Smart entrance	x	x		
X-trail \ T30 \ 2005-10~	Air levelizer	x	x	x	
X-trail \ T30 \ 2005-10~	Rearview camera			x	
X-trail \ T30 \ 2005-10~	S/blind camera			x	
X-trail \ T30 \ 2005-10~	Motor assist	x	x	x	
X-trail \ T30 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

X-trail \ T30 \ 2006	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ 2006	BCM	x	x		
X-trail \ T30 \ 2006	Air bag	x	x	x	
X-trail \ T30 \ 2006	ICC/ADAS	x	x	x	
X-trail \ T30 \ 2006	HVAC	x	x	x	
X-trail \ T30 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ 2006	Multi AV	x	x	x	0280
X-trail \ T30 \ 2006	EPS/DAST 3	x	x	x	
X-trail \ T30 \ 2006	IPDM E/R	x	x	x	
X-trail \ T30 \ 2006	Air pressure monitor	x	x	x	
X-trail \ T30 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ 2006	DIU	x	x	x	
X-trail \ T30 \ 2006	Auto slide door	x	x	x	
X-trail \ T30 \ 2006	Auto drive position	x	x	x	
X-trail \ T30 \ 2006	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ 2006	Sonar	x	x	x	
X-trail \ T30 \ 2006	Lane camera	x	x	x	
X-trail \ T30 \ 2006	Adaptive light	x	x	x	
X-trail \ T30 \ 2006	AVM		x	x	
X-trail \ T30 \ 2006	Head lamp levelizer	x	x	x	
X-trail \ T30 \ 2006	Difference lock	x	x	x	
X-trail \ T30 \ 2006	Nats immu	x	x		
X-trail \ T30 \ 2006	Smart entrance	x	x		
X-trail \ T30 \ 2006	Air levelizer	x	x	x	
X-trail \ T30 \ 2006	Rearview camera			x	
X-trail \ T30 \ 2006	S/blind camera			x	
X-trail \ T30 \ 2006	Motor assist	x	x	x	
X-trail \ T30 \ 2007-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T30 \ 2007-11~	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ 2007-11~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ 2007-11~	BCM	x	x		
X-trail \ T30 \ 2007-11~	Air bag	x	x	x	
X-trail \ T30 \ 2007-11~	ICC/ADAS	x	x	x	
X-trail \ T30 \ 2007-11~	HVAC	x	x	x	
X-trail \ T30 \ 2007-11~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ 2007-11~	Multi AV	x	x	x	0280

X-trail \ T30 \ 2007-11~	EPS/DAST 3	x	x	x	
X-trail \ T30 \ 2007-11~	IPDM E/R	x	x	x	
X-trail \ T30 \ 2007-11~	Air pressure monitor	x	x	x	
X-trail \ T30 \ 2007-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ 2007-11~	DIU	x	x	x	
X-trail \ T30 \ 2007-11~	Auto slide door	x	x	x	
X-trail \ T30 \ 2007-11~	Auto drive position	x	x	x	
X-trail \ T30 \ 2007-11~	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ 2007-11~	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ 2007-11~	Sonar	x	x	x	
X-trail \ T30 \ 2007-11~	Lane camera	x	x	x	
X-trail \ T30 \ 2007-11~	Adaptive light	x	x	x	
X-trail \ T30 \ 2007-11~	AVM		x	x	
X-trail \ T30 \ 2007-11~	Head lamp levelizer	x	x	x	
X-trail \ T30 \ 2007-11~	Difference lock	x	x	x	
X-trail \ T30 \ 2007-11~	Nats immu	x	x		
X-trail \ T30 \ 2007-11~	Smart entrance	x	x		
X-trail \ T30 \ 2007-11~	Air levelizer	x	x	x	
X-trail \ T30 \ 2007-11~	Rearview camera			x	
X-trail \ T30 \ 2007-11~	S/blind camera			x	
X-trail \ T30 \ 2007-11~	Motor assist	x	x	x	
X-trail \ T30 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T30 \ All Year	ABS	x	x	x	0003, 0092, 0264
X-trail \ T30 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T30 \ All Year	BCM	x	x		
X-trail \ T30 \ All Year	Air bag	x	x	x	
X-trail \ T30 \ All Year	ICC/ADAS	x	x	x	
X-trail \ T30 \ All Year	HVAC	x	x	x	
X-trail \ T30 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T30 \ All Year	Multi AV	x	x	x	0280
X-trail \ T30 \ All Year	EPS/DAST 3	x	x	x	
X-trail \ T30 \ All Year	IPDM E/R	x	x	x	
X-trail \ T30 \ All Year	Air pressure monitor	x	x	x	
X-trail \ T30 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T30 \ All Year	DIU	x	x	x	
X-trail \ T30 \ All Year	Auto slide door	x	x	x	

X-trail \ T30 \ All Year	Auto drive position	x	x	x	
X-trail \ T30 \ All Year	All mode AWD/4WD	x	x	x	
X-trail \ T30 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
X-trail \ T30 \ All Year	Sonar	x	x	x	
X-trail \ T30 \ All Year	Lane camera	x	x	x	
X-trail \ T30 \ All Year	Adaptive light	x	x	x	
X-trail \ T30 \ All Year	AVM		x	x	
X-trail \ T30 \ All Year	Head lamp levelizer	x	x	x	
X-trail \ T30 \ All Year	Difference lock	x	x	x	
X-trail \ T30 \ All Year	Nats immu	x	x		
X-trail \ T30 \ All Year	Smart entrance	x	x		
X-trail \ T30 \ All Year	Air levelizer	x	x	x	
X-trail \ T30 \ All Year	Rearview camera			x	
X-trail \ T30 \ All Year	S/blind camera			x	
X-trail \ T30 \ All Year	Motor assist	x	x	x	
X-trail \ T31 \ 2007-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2007-3~	Meter/M&A		x	x	
X-trail \ T31 \ 2007-3~	BCM	x	x		
X-trail \ T31 \ 2007-3~	Transmission	x	x	x	
X-trail \ T31 \ 2007-3~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2007-3~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2007-3~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2007-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2007-3~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2007-3~	Adaptive light	x	x	x	
X-trail \ T31 \ 2007-3~	ABS	x	x	x	
X-trail \ T31 \ 2007-3~	Air bag	x	x	x	
X-trail \ T31 \ 2007-3~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2007-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2007-6~	Meter/M&A		x	x	
X-trail \ T31 \ 2007-6~	BCM	x	x		
X-trail \ T31 \ 2007-6~	Transmission	x	x	x	
X-trail \ T31 \ 2007-6~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2007-6~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2007-6~	IPDM E/R	x	x	x	

X-trail \ T31 \ 2007-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2007-6~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2007-6~	ABS	x	x	x	
X-trail \ T31 \ 2007-6~	Air bag	x	x	x	
X-trail \ T31 \ 2007-6~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2007-6~	S/blind camera			x	
X-trail \ T31 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T31 \ 2007-8~	BCM	x	x		
X-trail \ T31 \ 2007-8~	Transmission	x	x	x	
X-trail \ T31 \ 2007-8~	Multi AV	x	x	x	
X-trail \ T31 \ 2007-8~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2007-8~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2007-8~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2007-8~	ABS	x	x	x	
X-trail \ T31 \ 2007-8~	Air bag	x	x	x	
X-trail \ T31 \ 2007-8~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2007-8~	Rearview camera			x	
X-trail \ T31 \ 2007-8~	S/blind camera			x	
X-trail \ T31 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2008-12~	Meter/M&A		x	x	
X-trail \ T31 \ 2008-12~	BCM	x	x		
X-trail \ T31 \ 2008-12~	Transmission	x	x	x	
X-trail \ T31 \ 2008-12~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2008-12~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2008-12~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2008-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2008-12~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2008-12~	Adaptive light	x	x	x	
X-trail \ T31 \ 2008-12~	ABS	x	x	x	
X-trail \ T31 \ 2008-12~	Air bag	x	x	x	
X-trail \ T31 \ 2008-12~	Head lamp levelizer	x	x	x	

X-trail \ T31 \ 2008-12~	BCM			×	
X-trail \ T31 \ 2008-12~	E-SUS	×	×		
X-trail \ T31 \ 2008-1~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2008-1~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
X-trail \ T31 \ 2008-1~	BCM	×	×		
X-trail \ T31 \ 2008-1~	Air bag	×	×	×	
X-trail \ T31 \ 2008-1~	Transmission	×	×	×	
X-trail \ T31 \ 2008-1~	EPS/DAST 3	×	×	×	
X-trail \ T31 \ 2008-1~	IPDM E/R	×	×	×	
X-trail \ T31 \ 2008-1~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2008-1~	All mode AWD/4WD	×	×	×	0245, 0311
X-trail \ T31 \ 2008-1~	ABS	×	×	×	
X-trail \ T31 \ 2008-1~	Head lamp levelizer	×	×	×	
X-trail \ T31 \ 2008-6~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2008-6~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
X-trail \ T31 \ 2008-6~	BCM	×	×		
X-trail \ T31 \ 2008-6~	Transmission	×	×	×	
X-trail \ T31 \ 2008-6~	Multi AV	×	×	×	
X-trail \ T31 \ 2008-6~	EPS/DAST 3	×	×	×	
X-trail \ T31 \ 2008-6~	IPDM E/R	×	×	×	
X-trail \ T31 \ 2008-6~	Intelligent key	×	×	×	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2008-6~	All mode AWD/4WD	×	×	×	0245, 0311
X-trail \ T31 \ 2008-6~	ABS	×	×	×	
X-trail \ T31 \ 2008-6~	Air bag	×	×	×	
X-trail \ T31 \ 2008-6~	Head lamp levelizer	×	×	×	
X-trail \ T31 \ 2008-6~	Rearview camera			×	
X-trail \ T31 \ 2008-6~	S/blind camera			×	
X-trail \ T31 \ 2008-9~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2008-9~	Meter/M&A	×	×	×	0331, 0330, 0197, 0143
X-trail \ T31 \ 2008-9~	BCM	×	×		
X-trail \ T31 \ 2008-9~	Transmission	×	×	×	
X-trail \ T31 \ 2008-9~	Multi AV	×	×	×	
X-trail \ T31 \ 2008-9~	EPS/DAST 3	×	×	×	
X-trail \ T31 \ 2008-9~	IPDM E/R	×	×	×	

X-trail \ T31 \ 2008-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2008-9~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2008-9~	ABS	x	x	x	
X-trail \ T31 \ 2008-9~	Air bag	x	x	x	
X-trail \ T31 \ 2008-9~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2008-9~	Rearview camera			x	
X-trail \ T31 \ 2008-9~	S/blind camera			x	
X-trail \ T31 \ 2009-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2009-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T31 \ 2009-10~	BCM	x	x		
X-trail \ T31 \ 2009-10~	Air bag	x	x	x	
X-trail \ T31 \ 2009-10~	Transmission	x	x	x	
X-trail \ T31 \ 2009-10~	Multi AV	x	x	x	
X-trail \ T31 \ 2009-10~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2009-10~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2009-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2009-10~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2009-10~	ABS	x	x	x	
X-trail \ T31 \ 2009-10~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2009-11~	Meter/M&A		x	x	
X-trail \ T31 \ 2009-11~	BCM	x	x		
X-trail \ T31 \ 2009-11~	Transmission	x	x	x	
X-trail \ T31 \ 2009-11~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2009-11~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2009-11~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2009-11~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2009-11~	ABS	x	x	x	
X-trail \ T31 \ 2009-11~	Air bag	x	x	x	
X-trail \ T31 \ 2009-11~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2009-11~	S/blind camera			x	
X-trail \ T31 \ 2009-11~	Adaptive light	x	x	x	

X-trail \ T31 \ 2009-11~	BCM			x	
X-trail \ T31 \ 2009-11~	E-SUS	x	x		
X-trail \ T31 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2009-8~	Meter/M&A		x	x	
X-trail \ T31 \ 2009-8~	BCM	x	x		
X-trail \ T31 \ 2009-8~	Transmission	x	x	x	
X-trail \ T31 \ 2009-8~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2009-8~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2009-8~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2009-8~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2009-8~	Adaptive light	x	x	x	
X-trail \ T31 \ 2009-8~	ABS	x	x	x	
X-trail \ T31 \ 2009-8~	Air bag	x	x	x	
X-trail \ T31 \ 2009-8~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2009-8~	Rearview camera			x	
X-trail \ T31 \ 2009-8~	S/blind camera			x	
X-trail \ T31 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T31 \ 2009-9~	BCM	x	x		
X-trail \ T31 \ 2009-9~	Air bag	x	x	x	
X-trail \ T31 \ 2009-9~	Transmission	x	x	x	
X-trail \ T31 \ 2009-9~	Multi AV	x	x	x	
X-trail \ T31 \ 2009-9~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2009-9~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2009-9~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2009-9~	ABS	x	x	x	
X-trail \ T31 \ 2009-9~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2010-10~	BCM			x	
X-trail \ T31 \ 2010-10~	E-SUS	x	x		
X-trail \ T31 \ 2010-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2010-3~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T31 \ 2010-3~	BCM	x	x		

X-trail \ T31 \ 2010-3~	Transmission	x	x	x	
X-trail \ T31 \ 2010-3~	Multi AV	x	x	x	
X-trail \ T31 \ 2010-3~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2010-3~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2010-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2010-3~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2010-3~	ABS	x	x	x	
X-trail \ T31 \ 2010-3~	Air bag	x	x	x	
X-trail \ T31 \ 2010-3~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2010-3~	Rearview camera			x	
X-trail \ T31 \ 2010-3~	S/blind camera			x	
X-trail \ T31 \ 2010-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2010-6~	Meter/M&A		x	x	
X-trail \ T31 \ 2010-6~	BCM	x	x		
X-trail \ T31 \ 2010-6~	Transmission	x	x	x	
X-trail \ T31 \ 2010-6~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2010-6~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2010-6~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2010-6~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2010-6~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2010-6~	ABS	x	x	x	
X-trail \ T31 \ 2010-6~	Air bag	x	x	x	
X-trail \ T31 \ 2010-6~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2010-6~	Rearview camera			x	
X-trail \ T31 \ 2010-6~	S/blind camera			x	
X-trail \ T31 \ 2010-6~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T31 \ 2010-6~	Auto drive position		x	x	
X-trail \ T31 \ 2010-6~	Adaptive light	x	x	x	
X-trail \ T31 \ 2010-6~	Multi AV	x	x	x	
X-trail \ T31 \ 2010-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2010-7~	Meter/M&A		x	x	
X-trail \ T31 \ 2010-7~	BCM	x	x		
X-trail \ T31 \ 2010-7~	Transmission	x	x	x	
X-trail \ T31 \ 2010-7~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2010-7~	EPS/DAST 3	x	x	x	

X-trail \ T31 \ 2010-7~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2010-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2010-7~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2010-7~	Adaptive light	x	x	x	
X-trail \ T31 \ 2010-7~	ABS	x	x	x	
X-trail \ T31 \ 2010-7~	Air bag	x	x	x	
X-trail \ T31 \ 2010-7~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2010-7~	Rearview camera			x	
X-trail \ T31 \ 2010-7~	S/blind camera			x	
X-trail \ T31 \ 2010-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2010-9~	Meter/M&A		x	x	
X-trail \ T31 \ 2010-9~	BCM	x	x		
X-trail \ T31 \ 2010-9~	Transmission	x	x	x	
X-trail \ T31 \ 2010-9~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2010-9~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2010-9~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2010-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2010-9~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2010-9~	Adaptive light	x	x	x	
X-trail \ T31 \ 2010-9~	ABS	x	x	x	
X-trail \ T31 \ 2010-9~	Air bag	x	x	x	
X-trail \ T31 \ 2010-9~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2010-9~	Rearview camera			x	
X-trail \ T31 \ 2010-9~	S/blind camera			x	
X-trail \ T31 \ 2011-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2011-10~	Meter/M&A		x	x	
X-trail \ T31 \ 2011-10~	BCM	x	x		
X-trail \ T31 \ 2011-10~	Transmission	x	x	x	
X-trail \ T31 \ 2011-10~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2011-10~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2011-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2011-10~	Auto drive position	x	x	x	
X-trail \ T31 \ 2011-10~	All mode AWD/4WD	x	x	x	0245, 0311

X-trail \ T31 \ 2011-10~	Telematics		x	x	0253
X-trail \ T31 \ 2011-10~	AVM		x	x	
X-trail \ T31 \ 2011-10~	ABS	x	x	x	
X-trail \ T31 \ 2011-10~	Air bag	x	x	x	
X-trail \ T31 \ 2011-10~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2011-11~	BCM			x	
X-trail \ T31 \ 2011-11~	E-SUS	x	x		
X-trail \ T31 \ 2011-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2011-11~	Meter/M&A		x	x	
X-trail \ T31 \ 2011-11~	BCM	x	x		
X-trail \ T31 \ 2011-11~	Transmission	x	x	x	
X-trail \ T31 \ 2011-11~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2011-11~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2011-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2011-11~	Auto drive position	x	x	x	
X-trail \ T31 \ 2011-11~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2011-11~	ABS	x	x	x	
X-trail \ T31 \ 2011-11~	Air bag	x	x	x	
X-trail \ T31 \ 2011-11~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2011-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2011-12~	Meter/M&A		x	x	
X-trail \ T31 \ 2011-12~	BCM	x	x		
X-trail \ T31 \ 2011-12~	Transmission	x	x	x	
X-trail \ T31 \ 2011-12~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2011-12~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2011-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2011-12~	Auto drive position	x	x	x	
X-trail \ T31 \ 2011-12~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2011-12~	ABS	x	x	x	
X-trail \ T31 \ 2011-12~	Air bag	x	x	x	
X-trail \ T31 \ 2011-12~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2011-8~	Meter/M&A		x	x	
X-trail \ T31 \ 2011-8~	BCM	x	x		

X-trail \ T31 \ 2011-8~	Transmission	x	x	x	
X-trail \ T31 \ 2011-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2011-8~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2011-8~	ABS	x	x	x	
X-trail \ T31 \ 2011-8~	Air bag	x	x	x	
X-trail \ T31 \ 2011-8~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2011-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2011-9~	Meter/M&A		x	x	
X-trail \ T31 \ 2011-9~	BCM	x	x		
X-trail \ T31 \ 2011-9~	Transmission	x	x	x	
X-trail \ T31 \ 2011-9~	Multi AV		x	x	
X-trail \ T31 \ 2011-9~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2011-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2011-9~	Auto drive position	x	x	x	
X-trail \ T31 \ 2011-9~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2011-9~	AVM		x	x	
X-trail \ T31 \ 2011-9~	ABS	x	x	x	
X-trail \ T31 \ 2011-9~	Air bag	x	x	x	
X-trail \ T31 \ 2011-9~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2012-11~	BCM			x	
X-trail \ T31 \ 2012-11~	E-SUS	x	x		
X-trail \ T31 \ 2012-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2012-3~	Meter/M&A		x	x	
X-trail \ T31 \ 2012-3~	BCM	x	x		
X-trail \ T31 \ 2012-3~	Transmission	x	x	x	
X-trail \ T31 \ 2012-3~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2012-3~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2012-3~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2012-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2012-3~	Auto drive position	x	x	x	
X-trail \ T31 \ 2012-3~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2012-3~	ABS	x	x	x	
X-trail \ T31 \ 2012-3~	Air bag	x	x	x	

X-trail \ T31 \ 2012-3~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2012-3~	SVT	x	x	x	
X-trail \ T31 \ 2012-3~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
X-trail \ T31 \ 2012-3~	AVM		x	x	
X-trail \ T31 \ 2012-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2012-4~	Meter/M&A		x	x	
X-trail \ T31 \ 2012-4~	BCM	x	x		
X-trail \ T31 \ 2012-4~	Transmission	x	x	x	
X-trail \ T31 \ 2012-4~	Multi AV	x	x	x	0280
X-trail \ T31 \ 2012-4~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2012-4~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2012-4~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2012-4~	Auto drive position	x	x	x	
X-trail \ T31 \ 2012-4~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2012-4~	AVM		x	x	
X-trail \ T31 \ 2012-4~	ABS	x	x	x	
X-trail \ T31 \ 2012-4~	Air bag	x	x	x	
X-trail \ T31 \ 2012-4~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2012-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2012-7~	Meter/M&A		x	x	
X-trail \ T31 \ 2012-7~	BCM	x	x		
X-trail \ T31 \ 2012-7~	Transmission	x	x	x	
X-trail \ T31 \ 2012-7~	Multi AV		x	x	
X-trail \ T31 \ 2012-7~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2012-7~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2012-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2012-7~	Auto drive position	x	x	x	
X-trail \ T31 \ 2012-7~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2012-7~	PTC heater		x	x	
X-trail \ T31 \ 2012-7~	ABS	x	x	x	
X-trail \ T31 \ 2012-7~	Air bag	x	x	x	
X-trail \ T31 \ 2012-7~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2012-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T31 \ 2012-8~	Meter/M&A		x	x	

X-trail \ T31 \ 2012-8~	BCM	x	x		
X-trail \ T31 \ 2012-8~	Transmission	x	x	x	
X-trail \ T31 \ 2012-8~	Multi AV		x	x	
X-trail \ T31 \ 2012-8~	EPS/DAST 3	x	x	x	
X-trail \ T31 \ 2012-8~	IPDM E/R	x	x	x	
X-trail \ T31 \ 2012-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
X-trail \ T31 \ 2012-8~	Auto drive position	x	x	x	
X-trail \ T31 \ 2012-8~	All mode AWD/4WD	x	x	x	0245, 0311
X-trail \ T31 \ 2012-8~	AVM		x	x	
X-trail \ T31 \ 2012-8~	ABS	x	x	x	
X-trail \ T31 \ 2012-8~	Air bag	x	x	x	
X-trail \ T31 \ 2012-8~	Head lamp levelizer	x	x	x	
X-trail \ T31 \ 2012-8~	Telematics		x	x	0253
X-trail \ T31 \ 2013-11~	BCM			x	
X-trail \ T31 \ 2013-11~	E-SUS	x	x		
X-trail \ T31 \ 2014-11~	BCM			x	
X-trail \ T31 \ 2014-11~	E-SUS	x	x		
X-trail \ T32 \ 2013-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2013-11~	ABS		x	x	
X-trail \ T32 \ 2013-11~	Meter/M&A		x	x	
X-trail \ T32 \ 2013-11~	BCM		x		
X-trail \ T32 \ 2013-11~	Air bag		x	x	
X-trail \ T32 \ 2013-11~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2013-11~	HVAC		x	x	
X-trail \ T32 \ 2013-11~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2013-11~	Multi AV		x	x	
X-trail \ T32 \ 2013-11~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2013-11~	IPDM E/R		x	x	
X-trail \ T32 \ 2013-11~	Laser/radar	x	x	x	
X-trail \ T32 \ 2013-11~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2013-11~	Sonar		x	x	
X-trail \ T32 \ 2013-11~	Lane camera		x	x	
X-trail \ T32 \ 2013-11~	CAN gateway		x	x	
X-trail \ T32 \ 2013-11~	Auto back door		x	x	
X-trail \ T32 \ 2013-11~	Side radar left		x	x	
X-trail \ T32 \ 2013-11~	Side radar right		x	x	
X-trail \ T32 \ 2013-11~	PTC heater		x	x	

X-trail \ T32 \ 2013-11~	AVM		x	x	
X-trail \ T32 \ 2013-11~	Chassis control		x	x	
X-trail \ T32 \ 2013-11~	Occupant detection			x	
X-trail \ T32 \ 2013-11~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2013-11~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2013-11~	Air pressure monitor		x	x	
X-trail \ T32 \ 2013-11~	Sonar	x	x	x	
X-trail \ T32 \ 2013-11~	Lane camera	x	x	x	
X-trail \ T32 \ 2013-11~	Telematics		x	x	0253
X-trail \ T32 \ 2013-11~	BSW/buzzer		x	x	
X-trail \ T32 \ 2013-11~	PMAS		x	x	
X-trail \ T32 \ 2014-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-12~	ABS	x	x	x	
X-trail \ T32 \ 2014-12~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
X-trail \ T32 \ 2014-12~	BCM		x		
X-trail \ T32 \ 2014-12~	Air bag	x	x	x	
X-trail \ T32 \ 2014-12~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2014-12~	HVAC		x	x	
X-trail \ T32 \ 2014-12~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-12~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2014-12~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-12~	EPS/DAST 3	x	x	x	
X-trail \ T32 \ 2014-12~	IPDM E/R		x	x	
X-trail \ T32 \ 2014-12~	Laser/radar	x	x	x	
X-trail \ T32 \ 2014-12~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2014-12~	Sonar		x	x	
X-trail \ T32 \ 2014-12~	Lane camera		x	x	
X-trail \ T32 \ 2014-12~	CAN gateway		x	x	
X-trail \ T32 \ 2014-12~	Auto back door		x	x	
X-trail \ T32 \ 2014-12~	Side radar left		x	x	
X-trail \ T32 \ 2014-12~	Side radar right		x	x	
X-trail \ T32 \ 2014-12~	PTC heater		x	x	
X-trail \ T32 \ 2014-12~	AVM		x	x	
X-trail \ T32 \ 2014-12~	Chassis control		x	x	
X-trail \ T32 \ 2014-12~	Occupant detection			x	
X-trail \ T32 \ 2014-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212

X-trail \ T32 \ 2014-1~	ABS		x	x	
X-trail \ T32 \ 2014-1~	Meter/M&A		x	x	
X-trail \ T32 \ 2014-1~	BCM		x		
X-trail \ T32 \ 2014-1~	Air bag		x	x	
X-trail \ T32 \ 2014-1~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2014-1~	HVAC		x	x	
X-trail \ T32 \ 2014-1~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-1~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2014-1~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-1~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2014-1~	IPDM E/R		x	x	
X-trail \ T32 \ 2014-1~	Air pressure monitor		x	x	
X-trail \ T32 \ 2014-1~	Laser/radar	x	x	x	
X-trail \ T32 \ 2014-1~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2014-1~	Sonar	x	x	x	
X-trail \ T32 \ 2014-1~	Lane camera	x	x	x	
X-trail \ T32 \ 2014-1~	CAN gateway		x	x	
X-trail \ T32 \ 2014-1~	Auto back door		x	x	
X-trail \ T32 \ 2014-1~	Side radar left		x	x	
X-trail \ T32 \ 2014-1~	Side radar right		x	x	
X-trail \ T32 \ 2014-1~	Telematics		x	x	0253
X-trail \ T32 \ 2014-1~	BSW/buzzer		x	x	
X-trail \ T32 \ 2014-1~	AVM		x	x	
X-trail \ T32 \ 2014-1~	Chassis control		x	x	
X-trail \ T32 \ 2014-1~	PMAS		x	x	
X-trail \ T32 \ 2014-1~	Occupant detection			x	
X-trail \ T32 \ 2014-1~	Auto drive position		x	x	
X-trail \ T32 \ 2014-1~	FSCM		x	x	
X-trail \ T32 \ 2014-2~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-2~	ABS		x	x	
X-trail \ T32 \ 2014-2~	Meter/M&A		x	x	
X-trail \ T32 \ 2014-2~	BCM		x		
X-trail \ T32 \ 2014-2~	Air bag		x	x	
X-trail \ T32 \ 2014-2~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2014-2~	HVAC		x	x	
X-trail \ T32 \ 2014-2~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-2~	Multi AV	x	x	x	0280

X-trail \ T32 \ 2014-2~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-2~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2014-2~	IPDM E/R		x	x	
X-trail \ T32 \ 2014-2~	Air pressure monitor		x	x	
X-trail \ T32 \ 2014-2~	Laser/radar	x	x	x	
X-trail \ T32 \ 2014-2~	Auto drive position		x	x	
X-trail \ T32 \ 2014-2~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2014-2~	Sonar	x	x	x	
X-trail \ T32 \ 2014-2~	Lane camera	x	x	x	
X-trail \ T32 \ 2014-2~	CAN gateway		x	x	
X-trail \ T32 \ 2014-2~	Auto back door		x	x	
X-trail \ T32 \ 2014-2~	Side radar left		x	x	
X-trail \ T32 \ 2014-2~	Side radar right		x	x	
X-trail \ T32 \ 2014-2~	Telematics		x	x	0253
X-trail \ T32 \ 2014-2~	BSW/buzzer		x	x	
X-trail \ T32 \ 2014-2~	AVM		x	x	
X-trail \ T32 \ 2014-2~	Chassis control		x	x	
X-trail \ T32 \ 2014-2~	FSCM		x	x	
X-trail \ T32 \ 2014-2~	PMAS		x	x	
X-trail \ T32 \ 2014-2~	Occupant detection			x	
X-trail \ T32 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-4~	ABS		x	x	
X-trail \ T32 \ 2014-4~	Meter/M&A		x	x	
X-trail \ T32 \ 2014-4~	BCM		x		
X-trail \ T32 \ 2014-4~	Air bag		x	x	
X-trail \ T32 \ 2014-4~	ICC/ADAS		x	x	
X-trail \ T32 \ 2014-4~	HVAC		x	x	
X-trail \ T32 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-4~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2014-4~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-4~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2014-4~	IPDM E/R		x	x	
X-trail \ T32 \ 2014-4~	Air pressure monitor		x	x	
X-trail \ T32 \ 2014-4~	Laser/radar		x	x	
X-trail \ T32 \ 2014-4~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2014-4~	Sonar	x	x	x	
X-trail \ T32 \ 2014-4~	Lane camera		x	x	

X-trail \ T32 \ 2014-4~	CAN gateway		x	x	
X-trail \ T32 \ 2014-4~	Auto back door		x	x	
X-trail \ T32 \ 2014-4~	Side radar left		x	x	
X-trail \ T32 \ 2014-4~	Side radar right		x	x	
X-trail \ T32 \ 2014-4~	Telematics		x	x	0253
X-trail \ T32 \ 2014-4~	BSW/buzzer		x	x	
X-trail \ T32 \ 2014-4~	AVM		x	x	
X-trail \ T32 \ 2014-4~	Chassis control		x	x	
X-trail \ T32 \ 2014-4~	PMAS		x	x	
X-trail \ T32 \ 2014-4~	Occupant detection			x	
X-trail \ T32 \ 2014-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-6~	ABS		x	x	
X-trail \ T32 \ 2014-6~	Meter/M&A		x	x	
X-trail \ T32 \ 2014-6~	BCM		x		
X-trail \ T32 \ 2014-6~	Air bag		x	x	
X-trail \ T32 \ 2014-6~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2014-6~	HVAC		x	x	
X-trail \ T32 \ 2014-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-6~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2014-6~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-6~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2014-6~	IPDM E/R		x	x	
X-trail \ T32 \ 2014-6~	Air pressure monitor		x	x	
X-trail \ T32 \ 2014-6~	Laser/radar	x	x	x	
X-trail \ T32 \ 2014-6~	Auto drive position		x	x	
X-trail \ T32 \ 2014-6~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2014-6~	Sonar	x	x	x	
X-trail \ T32 \ 2014-6~	Lane camera	x	x	x	
X-trail \ T32 \ 2014-6~	CAN gateway		x	x	
X-trail \ T32 \ 2014-6~	Auto back door		x	x	
X-trail \ T32 \ 2014-6~	Side radar left		x	x	
X-trail \ T32 \ 2014-6~	Side radar right		x	x	
X-trail \ T32 \ 2014-6~	Telematics		x	x	0253
X-trail \ T32 \ 2014-6~	BSW/buzzer		x	x	
X-trail \ T32 \ 2014-6~	AVM		x	x	
X-trail \ T32 \ 2014-6~	Chassis control		x	x	
X-trail \ T32 \ 2014-6~	FSCM		x	x	
X-trail \ T32 \ 2014-6~	PMAS		x	x	

X-trail \ T32 \ 2014-6~	Occupant detection			×	
X-trail \ T32 \ 2014-7~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-7~	ABS		×	×	
X-trail \ T32 \ 2014-7~	Meter/M&A		×	×	
X-trail \ T32 \ 2014-7~	BCM		×		
X-trail \ T32 \ 2014-7~	Air bag		×	×	
X-trail \ T32 \ 2014-7~	ICC/ADAS	×	×	×	
X-trail \ T32 \ 2014-7~	HVAC		×	×	
X-trail \ T32 \ 2014-7~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-7~	Multi AV	×	×	×	0280
X-trail \ T32 \ 2014-7~	EHS/PKB		×	×	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-7~	EPS/DAST 3		×	×	
X-trail \ T32 \ 2014-7~	IPDM E/R		×	×	
X-trail \ T32 \ 2014-7~	Air pressure monitor		×	×	
X-trail \ T32 \ 2014-7~	Laser/radar	×	×	×	
X-trail \ T32 \ 2014-7~	Auto drive position		×	×	
X-trail \ T32 \ 2014-7~	All mode AWD/4WD		×	×	
X-trail \ T32 \ 2014-7~	Sonar	×	×	×	
X-trail \ T32 \ 2014-7~	Lane camera	×	×	×	
X-trail \ T32 \ 2014-7~	CAN gateway		×	×	
X-trail \ T32 \ 2014-7~	Auto back door		×	×	
X-trail \ T32 \ 2014-7~	Side radar left		×	×	
X-trail \ T32 \ 2014-7~	Side radar right		×	×	
X-trail \ T32 \ 2014-7~	Telematics		×	×	0253
X-trail \ T32 \ 2014-7~	BSW/buzzer		×	×	
X-trail \ T32 \ 2014-7~	AVM		×	×	
X-trail \ T32 \ 2014-7~	Chassis control		×	×	
X-trail \ T32 \ 2014-7~	FSCM		×	×	
X-trail \ T32 \ 2014-7~	PMAS		×	×	
X-trail \ T32 \ 2014-7~	Occupant detection			×	
X-trail \ T32 \ 2014-9~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2014-9~	ABS		×	×	
X-trail \ T32 \ 2014-9~	Meter/M&A		×	×	
X-trail \ T32 \ 2014-9~	BCM		×		
X-trail \ T32 \ 2014-9~	Air bag		×	×	
X-trail \ T32 \ 2014-9~	ICC/ADAS	×	×	×	
X-trail \ T32 \ 2014-9~	HVAC		×	×	

X-trail \ T32 \ 2014-9~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2014-9~	Multi AV	×	×	×	0280
X-trail \ T32 \ 2014-9~	EHS/PKB		×	×	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2014-9~	EPS/DAST 3		×	×	
X-trail \ T32 \ 2014-9~	IPDM E/R		×	×	
X-trail \ T32 \ 2014-9~	Air pressure monitor		×	×	
X-trail \ T32 \ 2014-9~	Laser/radar	×	×	×	
X-trail \ T32 \ 2014-9~	Auto drive position		×	×	
X-trail \ T32 \ 2014-9~	All mode AWD/4WD		×	×	
X-trail \ T32 \ 2014-9~	Sonar	×	×	×	
X-trail \ T32 \ 2014-9~	Lane camera	×	×	×	
X-trail \ T32 \ 2014-9~	CAN gateway		×	×	
X-trail \ T32 \ 2014-9~	Auto back door		×	×	
X-trail \ T32 \ 2014-9~	Side radar left		×	×	
X-trail \ T32 \ 2014-9~	Side radar right		×	×	
X-trail \ T32 \ 2014-9~	Telematics		×	×	0253
X-trail \ T32 \ 2014-9~	BSW/buzzer		×	×	
X-trail \ T32 \ 2014-9~	AVM		×	×	
X-trail \ T32 \ 2014-9~	Chassis control		×	×	
X-trail \ T32 \ 2014-9~	FSCM		×	×	
X-trail \ T32 \ 2014-9~	PMAS		×	×	
X-trail \ T32 \ 2014-9~	Occupant detection			×	
X-trail \ T32 \ 2015-2~	Engine	×	×	×	0107, 0145, 0147, 0148, 0124, 0188, 0187, 0266, 0189, 0021, 0166, 0103, 0104, 0190, 0011, 0333, 0332, 0216, 0212, 0152, 0005, 0299, 0278, 0276, 0275, 0209, 0177, 0159, 0176, 0233, 0234, 0322, 0029, 0185, 0006, 0262, 0023, 0306, 0022, 0225, 0283, 0205, 0069, 0096, 0097, 0220
X-trail \ T32 \ 2015-2~	ABS		×	×	
X-trail \ T32 \ 2015-2~	Meter/M&A		×	×	
X-trail \ T32 \ 2015-2~	BCM		×		
X-trail \ T32 \ 2015-2~	Air bag		×	×	
X-trail \ T32 \ 2015-2~	ICC/ADAS	×	×	×	
X-trail \ T32 \ 2015-2~	HVAC		×	×	
X-trail \ T32 \ 2015-2~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2015-2~	Multi AV		×	×	

X-trail \ T32 \ 2015-2~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2015-2~	IPDM E/R		x	x	
X-trail \ T32 \ 2015-2~	Laser/radar	x	x	x	
X-trail \ T32 \ 2015-2~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2015-2~	Sonar		x	x	
X-trail \ T32 \ 2015-2~	Lane camera		x	x	
X-trail \ T32 \ 2015-2~	CAN gateway		x	x	
X-trail \ T32 \ 2015-2~	Auto back door		x	x	
X-trail \ T32 \ 2015-2~	Side radar left		x	x	
X-trail \ T32 \ 2015-2~	Side radar right		x	x	
X-trail \ T32 \ 2015-2~	PTC heater		x	x	
X-trail \ T32 \ 2015-2~	AVM		x	x	
X-trail \ T32 \ 2015-2~	Chassis control		x	x	
X-trail \ T32 \ 2015-2~	Occupant detection			x	
X-trail \ T32 \ 2015-6~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2015-6~	ABS		x	x	
X-trail \ T32 \ 2015-6~	Meter/M&A		x	x	
X-trail \ T32 \ 2015-6~	BCM		x		
X-trail \ T32 \ 2015-6~	Air bag		x	x	
X-trail \ T32 \ 2015-6~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2015-6~	HVAC		x	x	
X-trail \ T32 \ 2015-6~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2015-6~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2015-6~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2015-6~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2015-6~	IPDM E/R		x	x	
X-trail \ T32 \ 2015-6~	Air pressure monitor		x	x	
X-trail \ T32 \ 2015-6~	Laser/radar	x	x	x	
X-trail \ T32 \ 2015-6~	Auto drive position		x	x	
X-trail \ T32 \ 2015-6~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2015-6~	Sonar	x	x	x	
X-trail \ T32 \ 2015-6~	Lane camera	x	x	x	
X-trail \ T32 \ 2015-6~	CAN gateway		x	x	
X-trail \ T32 \ 2015-6~	Auto back door		x	x	
X-trail \ T32 \ 2015-6~	Side radar left		x	x	
X-trail \ T32 \ 2015-6~	Side radar right		x	x	
X-trail \ T32 \ 2015-6~	Telematics		x	x	0253
X-trail \ T32 \ 2015-6~	BSW/buzzer		x	x	

X-trail \ T32 \ 2015-6~	AVM		×	×	
X-trail \ T32 \ 2015-6~	Chassis control		×	×	
X-trail \ T32 \ 2015-6~	FSCM		×	×	
X-trail \ T32 \ 2015-6~	PMAS		×	×	
X-trail \ T32 \ 2015-6~	Occupant detection			×	
X-trail \ T32 \ 2016-3~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2016-3~	ABS		×	×	
X-trail \ T32 \ 2016-3~	Meter/M&A		×	×	
X-trail \ T32 \ 2016-3~	BCM		×		
X-trail \ T32 \ 2016-3~	Air bag		×	×	
X-trail \ T32 \ 2016-3~	ICC/ADAS	×	×	×	
X-trail \ T32 \ 2016-3~	HVAC		×	×	
X-trail \ T32 \ 2016-3~	Transmission		×	×	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2016-3~	Multi AV	×	×	×	0280
X-trail \ T32 \ 2016-3~	EHS/PKB		×	×	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2016-3~	EPS/DAST 3		×	×	
X-trail \ T32 \ 2016-3~	IPDM E/R		×	×	
X-trail \ T32 \ 2016-3~	Air pressure monitor		×	×	
X-trail \ T32 \ 2016-3~	Laser/radar	×	×	×	
X-trail \ T32 \ 2016-3~	Auto drive position		×	×	
X-trail \ T32 \ 2016-3~	All mode AWD/4WD		×	×	
X-trail \ T32 \ 2016-3~	Sonar	×	×	×	
X-trail \ T32 \ 2016-3~	Lane camera	×	×	×	
X-trail \ T32 \ 2016-3~	CAN gateway		×	×	
X-trail \ T32 \ 2016-3~	Auto back door		×	×	
X-trail \ T32 \ 2016-3~	Side radar left		×	×	
X-trail \ T32 \ 2016-3~	Side radar right		×	×	
X-trail \ T32 \ 2016-3~	Telematics		×	×	0253
X-trail \ T32 \ 2016-3~	BSW/buzzer		×	×	
X-trail \ T32 \ 2016-3~	AVM		×	×	
X-trail \ T32 \ 2016-3~	Chassis control		×	×	
X-trail \ T32 \ 2016-3~	FSCM		×	×	
X-trail \ T32 \ 2016-3~	PMAS		×	×	
X-trail \ T32 \ 2016-3~	Occupant detection			×	
X-trail \ T32 \ 2016-7~	Engine	×	×	×	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
X-trail \ T32 \ 2016-7~	ABS		×	×	
X-trail \ T32 \ 2016-7~	Meter/M&A		×	×	

X-trail \ T32 \ 2016-7~	BCM		x		
X-trail \ T32 \ 2016-7~	Air bag		x	x	
X-trail \ T32 \ 2016-7~	ICC/ADAS	x	x	x	
X-trail \ T32 \ 2016-7~	HVAC		x	x	
X-trail \ T32 \ 2016-7~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
X-trail \ T32 \ 2016-7~	Multi AV	x	x	x	0280
X-trail \ T32 \ 2016-7~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
X-trail \ T32 \ 2016-7~	EPS/DAST 3		x	x	
X-trail \ T32 \ 2016-7~	IPDM E/R		x	x	
X-trail \ T32 \ 2016-7~	Air pressure monitor		x	x	
X-trail \ T32 \ 2016-7~	Laser/radar	x	x	x	
X-trail \ T32 \ 2016-7~	Auto drive position		x	x	
X-trail \ T32 \ 2016-7~	All mode AWD/4WD		x	x	
X-trail \ T32 \ 2016-7~	Sonar	x	x	x	
X-trail \ T32 \ 2016-7~	Lane camera	x	x	x	
X-trail \ T32 \ 2016-7~	CAN gateway		x	x	
X-trail \ T32 \ 2016-7~	Auto back door		x	x	
X-trail \ T32 \ 2016-7~	Side radar left		x	x	
X-trail \ T32 \ 2016-7~	Side radar right		x	x	
X-trail \ T32 \ 2016-7~	Telematics		x	x	0253
X-trail \ T32 \ 2016-7~	BSW/buzzer		x	x	
X-trail \ T32 \ 2016-7~	AVM		x	x	
X-trail \ T32 \ 2016-7~	Chassis control		x	x	
X-trail \ T32 \ 2016-7~	FSCM		x	x	
X-trail \ T32 \ 2016-7~	PMAS		x	x	
X-trail \ T32 \ 2016-7~	Occupant detection			x	
Xterra \ N50 \ 2005	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2005	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2005	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2005	BCM	x	x		
Xterra \ N50 \ 2005	Air bag	x	x	x	
Xterra \ N50 \ 2005	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2005	HVAC	x	x	x	
Xterra \ N50 \ 2005	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2005	Multi AV	x	x	x	0280
Xterra \ N50 \ 2005	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2005	IPDM E/R	x	x	x	
Xterra \ N50 \ 2005	Air pressure monitor	x	x	x	

Xterra \ N50 \ 2005	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2005	DIU	x	x	x	
Xterra \ N50 \ 2005	Auto slide door	x	x	x	
Xterra \ N50 \ 2005	Auto drive position	x	x	x	
Xterra \ N50 \ 2005	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2005	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2005	Sonar	x	x	x	
Xterra \ N50 \ 2005	Lane camera	x	x	x	
Xterra \ N50 \ 2005	Adaptive light	x	x	x	
Xterra \ N50 \ 2005	AVM		x	x	
Xterra \ N50 \ 2005	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2005	Difference lock	x	x	x	
Xterra \ N50 \ 2005	Nats immu	x	x		
Xterra \ N50 \ 2005	Smart entrance	x	x		
Xterra \ N50 \ 2005	Air levelizer	x	x	x	
Xterra \ N50 \ 2005	Rearview camera			x	
Xterra \ N50 \ 2005	S/blind camera			x	
Xterra \ N50 \ 2005	Motor assist	x	x	x	
Xterra \ N50 \ 2005-1~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2005-1~	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2005-1~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2005-1~	BCM	x	x		
Xterra \ N50 \ 2005-1~	Air bag	x	x	x	
Xterra \ N50 \ 2005-1~	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2005-1~	HVAC	x	x	x	
Xterra \ N50 \ 2005-1~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2005-1~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2005-1~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2005-1~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2005-1~	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2005-1~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2005-1~	DIU	x	x	x	
Xterra \ N50 \ 2005-1~	Auto slide door	x	x	x	
Xterra \ N50 \ 2005-1~	Auto drive position	x	x	x	
Xterra \ N50 \ 2005-1~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2005-1~	4WAS(MAIN)/RAS/HICAS	x	x	x	

Xterra \ N50 \ 2005-1~	Sonar	x	x	x	
Xterra \ N50 \ 2005-1~	Lane camera	x	x	x	
Xterra \ N50 \ 2005-1~	Adaptive light	x	x	x	
Xterra \ N50 \ 2005-1~	AVM		x	x	
Xterra \ N50 \ 2005-1~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2005-1~	Difference lock	x	x	x	
Xterra \ N50 \ 2005-1~	Nats immu	x	x		
Xterra \ N50 \ 2005-1~	Smart entrance	x	x		
Xterra \ N50 \ 2005-1~	Air levelizer	x	x	x	
Xterra \ N50 \ 2005-1~	Rearview camera			x	
Xterra \ N50 \ 2005-1~	S/blind camera			x	
Xterra \ N50 \ 2005-1~	Motor assist	x	x	x	
Xterra \ N50 \ 2005-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2005-9~	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2005-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2005-9~	BCM	x	x		
Xterra \ N50 \ 2005-9~	Air bag	x	x	x	
Xterra \ N50 \ 2005-9~	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2005-9~	HVAC	x	x	x	
Xterra \ N50 \ 2005-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2005-9~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2005-9~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2005-9~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2005-9~	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2005-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2005-9~	DIU	x	x	x	
Xterra \ N50 \ 2005-9~	Auto slide door	x	x	x	
Xterra \ N50 \ 2005-9~	Auto drive position	x	x	x	
Xterra \ N50 \ 2005-9~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2005-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2005-9~	Sonar	x	x	x	
Xterra \ N50 \ 2005-9~	Lane camera	x	x	x	
Xterra \ N50 \ 2005-9~	Adaptive light	x	x	x	
Xterra \ N50 \ 2005-9~	AVM		x	x	
Xterra \ N50 \ 2005-9~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2005-9~	Difference lock	x	x	x	
Xterra \ N50 \ 2005-9~	Nats immu	x	x		
Xterra \ N50 \ 2005-9~	Smart entrance	x	x		

Xterra \ N50 \ 2005-9~	Air levelizer	x	x	x	
Xterra \ N50 \ 2005-9~	Rearview camera			x	
Xterra \ N50 \ 2005-9~	S/blind camera			x	
Xterra \ N50 \ 2005-9~	Motor assist	x	x	x	
Xterra \ N50 \ 2006	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2006	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2006	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2006	BCM	x	x		
Xterra \ N50 \ 2006	Air bag	x	x	x	
Xterra \ N50 \ 2006	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2006	HVAC	x	x	x	
Xterra \ N50 \ 2006	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2006	Multi AV	x	x	x	0280
Xterra \ N50 \ 2006	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2006	IPDM E/R	x	x	x	
Xterra \ N50 \ 2006	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2006	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2006	DIU	x	x	x	
Xterra \ N50 \ 2006	Auto slide door	x	x	x	
Xterra \ N50 \ 2006	Auto drive position	x	x	x	
Xterra \ N50 \ 2006	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2006	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2006	Sonar	x	x	x	
Xterra \ N50 \ 2006	Lane camera	x	x	x	
Xterra \ N50 \ 2006	Adaptive light	x	x	x	
Xterra \ N50 \ 2006	AVM		x	x	
Xterra \ N50 \ 2006	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2006	Difference lock	x	x	x	
Xterra \ N50 \ 2006	Nats immu	x	x		
Xterra \ N50 \ 2006	Smart entrance	x	x		
Xterra \ N50 \ 2006	Air levelizer	x	x	x	
Xterra \ N50 \ 2006	Rearview camera			x	
Xterra \ N50 \ 2006	S/blind camera			x	
Xterra \ N50 \ 2006	Motor assist	x	x	x	
Xterra \ N50 \ 2006-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2006-9~	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2006-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Xterra \ N50 \ 2006-9~	BCM	x	x		
Xterra \ N50 \ 2006-9~	Air bag	x	x	x	
Xterra \ N50 \ 2006-9~	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2006-9~	HVAC	x	x	x	
Xterra \ N50 \ 2006-9~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2006-9~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2006-9~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2006-9~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2006-9~	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2006-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2006-9~	DIU	x	x	x	
Xterra \ N50 \ 2006-9~	Auto slide door	x	x	x	
Xterra \ N50 \ 2006-9~	Auto drive position	x	x	x	
Xterra \ N50 \ 2006-9~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2006-9~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2006-9~	Sonar	x	x	x	
Xterra \ N50 \ 2006-9~	Lane camera	x	x	x	
Xterra \ N50 \ 2006-9~	Adaptive light	x	x	x	
Xterra \ N50 \ 2006-9~	AVM		x	x	
Xterra \ N50 \ 2006-9~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2006-9~	Difference lock	x	x	x	
Xterra \ N50 \ 2006-9~	Nats immu	x	x		
Xterra \ N50 \ 2006-9~	Smart entrance	x	x		
Xterra \ N50 \ 2006-9~	Air levelizer	x	x	x	
Xterra \ N50 \ 2006-9~	Rearview camera			x	
Xterra \ N50 \ 2006-9~	S/blind camera			x	
Xterra \ N50 \ 2006-9~	Motor assist	x	x	x	
Xterra \ N50 \ 2007	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2007	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2007	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2007	BCM	x	x		
Xterra \ N50 \ 2007	Air bag	x	x	x	
Xterra \ N50 \ 2007	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2007	HVAC	x	x	x	
Xterra \ N50 \ 2007	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2007	Multi AV	x	x	x	0280
Xterra \ N50 \ 2007	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2007	IPDM E/R	x	x	x	

Xterra \ N50 \ 2007	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2007	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2007	DIU	x	x	x	
Xterra \ N50 \ 2007	Auto slide door	x	x	x	
Xterra \ N50 \ 2007	Auto drive position	x	x	x	
Xterra \ N50 \ 2007	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2007	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2007	Sonar	x	x	x	
Xterra \ N50 \ 2007	Lane camera	x	x	x	
Xterra \ N50 \ 2007	Adaptive light	x	x	x	
Xterra \ N50 \ 2007	AVM		x	x	
Xterra \ N50 \ 2007	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2007	Difference lock	x	x	x	
Xterra \ N50 \ 2007	Nats immu	x	x		
Xterra \ N50 \ 2007	Smart entrance	x	x		
Xterra \ N50 \ 2007	Air levelizer	x	x	x	
Xterra \ N50 \ 2007	Rearview camera			x	
Xterra \ N50 \ 2007	S/blind camera			x	
Xterra \ N50 \ 2007	Motor assist	x	x	x	
Xterra \ N50 \ 2007-7~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2007-7~	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2007-7~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2007-7~	BCM	x	x		
Xterra \ N50 \ 2007-7~	Air bag	x	x	x	
Xterra \ N50 \ 2007-7~	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2007-7~	HVAC	x	x	x	
Xterra \ N50 \ 2007-7~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2007-7~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2007-7~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2007-7~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2007-7~	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2007-7~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2007-7~	DIU	x	x	x	
Xterra \ N50 \ 2007-7~	Auto slide door	x	x	x	
Xterra \ N50 \ 2007-7~	Auto drive position	x	x	x	
Xterra \ N50 \ 2007-7~	All mode AWD/4WD	x	x	x	

Xterra \ N50 \ 2007-7~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2007-7~	Sonar	x	x	x	
Xterra \ N50 \ 2007-7~	Lane camera	x	x	x	
Xterra \ N50 \ 2007-7~	Adaptive light	x	x	x	
Xterra \ N50 \ 2007-7~	AVM		x	x	
Xterra \ N50 \ 2007-7~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2007-7~	Difference lock	x	x	x	
Xterra \ N50 \ 2007-7~	Nats immu	x	x		
Xterra \ N50 \ 2007-7~	Smart entrance	x	x		
Xterra \ N50 \ 2007-7~	Air levelizer	x	x	x	
Xterra \ N50 \ 2007-7~	Rearview camera			x	
Xterra \ N50 \ 2007-7~	S/blind camera			x	
Xterra \ N50 \ 2007-7~	Motor assist	x	x	x	
Xterra \ N50 \ 2007-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2007-8~	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2007-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2007-8~	BCM	x	x		
Xterra \ N50 \ 2007-8~	Air bag	x	x	x	
Xterra \ N50 \ 2007-8~	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2007-8~	HVAC	x	x	x	
Xterra \ N50 \ 2007-8~	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2007-8~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2007-8~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2007-8~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2007-8~	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2007-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2007-8~	DIU	x	x	x	
Xterra \ N50 \ 2007-8~	Auto slide door	x	x	x	
Xterra \ N50 \ 2007-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2007-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2007-8~	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2007-8~	Sonar	x	x	x	
Xterra \ N50 \ 2007-8~	Lane camera	x	x	x	
Xterra \ N50 \ 2007-8~	Adaptive light	x	x	x	
Xterra \ N50 \ 2007-8~	AVM		x	x	
Xterra \ N50 \ 2007-8~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2007-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2007-8~	Nats immu	x	x		

Xterra \ N50 \ 2007-8~	Smart entrance	x	x		
Xterra \ N50 \ 2007-8~	Air levelizer	x	x	x	
Xterra \ N50 \ 2007-8~	Rearview camera			x	
Xterra \ N50 \ 2007-8~	S/blind camera			x	
Xterra \ N50 \ 2007-8~	Motor assist	x	x	x	
Xterra \ N50 \ 2008	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2008	ABS	x	x	x	0003, 0092, 0264
Xterra \ N50 \ 2008	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2008	BCM	x	x		
Xterra \ N50 \ 2008	Air bag	x	x	x	
Xterra \ N50 \ 2008	ICC/ADAS	x	x	x	
Xterra \ N50 \ 2008	HVAC	x	x	x	
Xterra \ N50 \ 2008	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ N50 \ 2008	Multi AV	x	x	x	0280
Xterra \ N50 \ 2008	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2008	IPDM E/R	x	x	x	
Xterra \ N50 \ 2008	Air pressure monitor	x	x	x	
Xterra \ N50 \ 2008	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2008	DIU	x	x	x	
Xterra \ N50 \ 2008	Auto slide door	x	x	x	
Xterra \ N50 \ 2008	Auto drive position	x	x	x	
Xterra \ N50 \ 2008	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2008	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ N50 \ 2008	Sonar	x	x	x	
Xterra \ N50 \ 2008	Lane camera	x	x	x	
Xterra \ N50 \ 2008	Adaptive light	x	x	x	
Xterra \ N50 \ 2008	AVM		x	x	
Xterra \ N50 \ 2008	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2008	Difference lock	x	x	x	
Xterra \ N50 \ 2008	Nats immu	x	x		
Xterra \ N50 \ 2008	Smart entrance	x	x		
Xterra \ N50 \ 2008	Air levelizer	x	x	x	
Xterra \ N50 \ 2008	Rearview camera			x	
Xterra \ N50 \ 2008	S/blind camera			x	
Xterra \ N50 \ 2008	Motor assist	x	x	x	
Xterra \ N50 \ 2008-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2008-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Xterra \ N50 \ 2008-8~	BCM	x	x		
Xterra \ N50 \ 2008-8~	HVAC	x	x	x	
Xterra \ N50 \ 2008-8~	Transmission	x	x	x	
Xterra \ N50 \ 2008-8~	Multi AV	x	x	x	
Xterra \ N50 \ 2008-8~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2008-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2008-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2008-8~	ABS	x	x	x	
Xterra \ N50 \ 2008-8~	Air bag	x	x	x	
Xterra \ N50 \ 2008-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2008-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2008-8~	Rearview camera			x	
Xterra \ N50 \ 2009	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2009	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2009	BCM	x	x		
Xterra \ N50 \ 2009	HVAC	x	x	x	
Xterra \ N50 \ 2009	Transmission	x	x	x	
Xterra \ N50 \ 2009	Multi AV	x	x	x	
Xterra \ N50 \ 2009	IPDM E/R	x	x	x	
Xterra \ N50 \ 2009	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2009	Auto drive position	x	x	x	
Xterra \ N50 \ 2009	ABS	x	x	x	
Xterra \ N50 \ 2009	Air bag	x	x	x	
Xterra \ N50 \ 2009	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2009	Difference lock	x	x	x	
Xterra \ N50 \ 2009	Rearview camera			x	
Xterra \ N50 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2009-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2009-8~	BCM	x	x		
Xterra \ N50 \ 2009-8~	Air bag	x	x	x	
Xterra \ N50 \ 2009-8~	HVAC	x	x	x	
Xterra \ N50 \ 2009-8~	Transmission	x	x	x	0059
Xterra \ N50 \ 2009-8~	Multi AV	x	x	x	
Xterra \ N50 \ 2009-8~	IPDM E/R	x	x	x	

Xterra \ N50 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2009-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2009-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2009-8~	ABS	x	x	x	
Xterra \ N50 \ 2009-8~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2009-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2009-8~	SVT	x	x	x	
Xterra \ N50 \ 2009-8~	Rearview camera			x	
Xterra \ N50 \ 2009-9~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2009-9~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2009-9~	BCM	x	x		
Xterra \ N50 \ 2009-9~	Air bag	x	x	x	
Xterra \ N50 \ 2009-9~	HVAC	x	x	x	
Xterra \ N50 \ 2009-9~	Transmission	x	x	x	0059
Xterra \ N50 \ 2009-9~	Multi AV	x	x	x	
Xterra \ N50 \ 2009-9~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2009-9~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2009-9~	Auto drive position	x	x	x	
Xterra \ N50 \ 2009-9~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2009-9~	ABS	x	x	x	
Xterra \ N50 \ 2009-9~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2009-9~	Difference lock	x	x	x	
Xterra \ N50 \ 2009-9~	SVT	x	x	x	
Xterra \ N50 \ 2009-9~	Rearview camera			x	
Xterra \ N50 \ 2010	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2010	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2010	BCM	x	x		
Xterra \ N50 \ 2010	Air bag	x	x	x	
Xterra \ N50 \ 2010	HVAC	x	x	x	
Xterra \ N50 \ 2010	Transmission	x	x	x	0059
Xterra \ N50 \ 2010	Multi AV	x	x	x	
Xterra \ N50 \ 2010	IPDM E/R	x	x	x	
Xterra \ N50 \ 2010	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344

Xterra \ N50 \ 2010	Auto drive position	x	x	x	
Xterra \ N50 \ 2010	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2010	ABS	x	x	x	
Xterra \ N50 \ 2010	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2010	Difference lock	x	x	x	
Xterra \ N50 \ 2010	SVT	x	x	x	
Xterra \ N50 \ 2010	Rearview camera			x	
Xterra \ N50 \ 2010-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2010-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2010-8~	BCM	x	x		
Xterra \ N50 \ 2010-8~	Air bag	x	x	x	
Xterra \ N50 \ 2010-8~	HVAC	x	x	x	
Xterra \ N50 \ 2010-8~	Transmission	x	x	x	0059
Xterra \ N50 \ 2010-8~	Multi AV	x	x	x	
Xterra \ N50 \ 2010-8~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2010-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2010-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2010-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2010-8~	ABS	x	x	x	
Xterra \ N50 \ 2010-8~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2010-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2010-8~	SVT	x	x	x	
Xterra \ N50 \ 2010-8~	Rearview camera			x	
Xterra \ N50 \ 2011	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2011	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2011	BCM	x	x		
Xterra \ N50 \ 2011	Air bag	x	x	x	
Xterra \ N50 \ 2011	HVAC	x	x	x	
Xterra \ N50 \ 2011	Transmission	x	x	x	0059
Xterra \ N50 \ 2011	Multi AV	x	x	x	
Xterra \ N50 \ 2011	IPDM E/R	x	x	x	
Xterra \ N50 \ 2011	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2011	Auto drive position	x	x	x	
Xterra \ N50 \ 2011	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2011	ABS	x	x	x	

Xterra \ N50 \ 2011	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2011	Difference lock	x	x	x	
Xterra \ N50 \ 2011	SVT	x	x	x	
Xterra \ N50 \ 2011	Rearview camera			x	
Xterra \ N50 \ 2011-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2011-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2011-8~	BCM	x	x		
Xterra \ N50 \ 2011-8~	Air bag	x	x	x	
Xterra \ N50 \ 2011-8~	HVAC	x	x	x	
Xterra \ N50 \ 2011-8~	Multi AV		x	x	
Xterra \ N50 \ 2011-8~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2011-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2011-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2011-8~	ABS	x	x	x	
Xterra \ N50 \ 2011-8~	Transmission	x	x	x	
Xterra \ N50 \ 2011-8~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2011-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2011-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2011-8~	Rearview camera			x	
Xterra \ N50 \ 2011-8~	S/blind camera			x	
Xterra \ N50 \ 2012	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2012	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2012	BCM	x	x		
Xterra \ N50 \ 2012	Air bag	x	x	x	
Xterra \ N50 \ 2012	HVAC	x	x	x	
Xterra \ N50 \ 2012	Multi AV		x	x	
Xterra \ N50 \ 2012	IPDM E/R	x	x	x	
Xterra \ N50 \ 2012	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2012	Auto drive position	x	x	x	
Xterra \ N50 \ 2012	ABS	x	x	x	
Xterra \ N50 \ 2012	Transmission	x	x	x	
Xterra \ N50 \ 2012	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2012	Difference lock	x	x	x	
Xterra \ N50 \ 2012	Rearview camera			x	
Xterra \ N50 \ 2012	S/blind camera			x	

Xterra \ N50 \ 2013	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2013	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2013	BCM	x	x		
Xterra \ N50 \ 2013	Air bag	x	x	x	
Xterra \ N50 \ 2013	HVAC	x	x	x	
Xterra \ N50 \ 2013	Multi AV		x	x	
Xterra \ N50 \ 2013	IPDM E/R	x	x	x	
Xterra \ N50 \ 2013	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2013	Auto drive position	x	x	x	
Xterra \ N50 \ 2013	ABS	x	x	x	
Xterra \ N50 \ 2013	Transmission	x	x	x	
Xterra \ N50 \ 2013	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2013	Difference lock	x	x	x	
Xterra \ N50 \ 2013	Rearview camera			x	
Xterra \ N50 \ 2013	S/blind camera			x	
Xterra \ N50 \ 2013-10~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2013-10~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2013-10~	BCM	x	x		
Xterra \ N50 \ 2013-10~	Air bag	x	x	x	
Xterra \ N50 \ 2013-10~	HVAC	x	x	x	
Xterra \ N50 \ 2013-10~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2013-10~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2013-10~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2013-10~	Auto drive position	x	x	x	
Xterra \ N50 \ 2013-10~	ABS	x	x	x	
Xterra \ N50 \ 2013-10~	Transmission	x	x	x	
Xterra \ N50 \ 2013-10~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2013-10~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2013-10~	Difference lock	x	x	x	
Xterra \ N50 \ 2014	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2014	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2014	BCM	x	x		
Xterra \ N50 \ 2014	Air bag	x	x	x	
Xterra \ N50 \ 2014	HVAC	x	x	x	

Xterra \ N50 \ 2014	Multi AV		x	x	
Xterra \ N50 \ 2014	IPDM E/R	x	x	x	
Xterra \ N50 \ 2014	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2014	Auto drive position	x	x	x	
Xterra \ N50 \ 2014	ABS	x	x	x	
Xterra \ N50 \ 2014	Transmission	x	x	x	
Xterra \ N50 \ 2014	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2014-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2014-8~	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2014-8~	BCM	x	x		
Xterra \ N50 \ 2014-8~	Air bag	x	x	x	
Xterra \ N50 \ 2014-8~	HVAC	x	x	x	
Xterra \ N50 \ 2014-8~	Multi AV	x	x	x	0280
Xterra \ N50 \ 2014-8~	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2014-8~	IPDM E/R	x	x	x	
Xterra \ N50 \ 2014-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2014-8~	Auto drive position	x	x	x	
Xterra \ N50 \ 2014-8~	AVM		x	x	
Xterra \ N50 \ 2014-8~	ABS	x	x	x	
Xterra \ N50 \ 2014-8~	Transmission	x	x	x	
Xterra \ N50 \ 2014-8~	Head lamp levelizer	x	x	x	
Xterra \ N50 \ 2014-8~	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2014-8~	Difference lock	x	x	x	
Xterra \ N50 \ 2015	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ N50 \ 2015	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ N50 \ 2015	BCM	x	x		
Xterra \ N50 \ 2015	Air bag	x	x	x	
Xterra \ N50 \ 2015	HVAC	x	x	x	
Xterra \ N50 \ 2015	Multi AV	x	x	x	0280
Xterra \ N50 \ 2015	EPS/DAST 3	x	x	x	
Xterra \ N50 \ 2015	IPDM E/R	x	x	x	
Xterra \ N50 \ 2015	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ N50 \ 2015	Auto drive position	x	x	x	

Xterra \ N50 \ 2015	AVM		x	x	
Xterra \ N50 \ 2015	ABS	x	x	x	
Xterra \ N50 \ 2015	Transmission	x	x	x	
Xterra \ N50 \ 2015	All mode AWD/4WD	x	x	x	
Xterra \ N50 \ 2015	Difference lock	x	x	x	
Xterra \ T32 \ 2014-4~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ T32 \ 2014-4~	ABS		x	x	
Xterra \ T32 \ 2014-4~	Meter/M&A		x	x	
Xterra \ T32 \ 2014-4~	BCM		x		
Xterra \ T32 \ 2014-4~	Air bag		x	x	
Xterra \ T32 \ 2014-4~	ICC/ADAS		x	x	
Xterra \ T32 \ 2014-4~	HVAC		x	x	
Xterra \ T32 \ 2014-4~	Transmission		x	x	0059, 0076, 0085, 0110, 0113, 0117, 0149, 0150
Xterra \ T32 \ 2014-4~	Multi AV	x	x	x	0280
Xterra \ T32 \ 2014-4~	EHS/PKB		x	x	0049, 0050, 0070, 0130, 0150, 0165, 0265, 0277
Xterra \ T32 \ 2014-4~	EPS/DAST 3		x	x	
Xterra \ T32 \ 2014-4~	IPDM E/R		x	x	
Xterra \ T32 \ 2014-4~	Air pressure monitor		x	x	
Xterra \ T32 \ 2014-4~	Laser/radar		x	x	
Xterra \ T32 \ 2014-4~	All mode AWD/4WD		x	x	
Xterra \ T32 \ 2014-4~	Sonar	x	x	x	
Xterra \ T32 \ 2014-4~	Lane camera		x	x	
Xterra \ T32 \ 2014-4~	CAN gateway		x	x	
Xterra \ T32 \ 2014-4~	Auto back door		x	x	
Xterra \ T32 \ 2014-4~	Side radar left		x	x	
Xterra \ T32 \ 2014-4~	Side radar right		x	x	
Xterra \ T32 \ 2014-4~	Telematics		x	x	0253
Xterra \ T32 \ 2014-4~	BSW/buzzer		x	x	
Xterra \ T32 \ 2014-4~	AVM		x	x	
Xterra \ T32 \ 2014-4~	Chassis control		x	x	
Xterra \ T32 \ 2014-4~	PMAS		x	x	
Xterra \ T32 \ 2014-4~	Occupant detection			x	
Xterra \ WD22 \ 1999	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 1999	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 1999	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ 1999	BCM	x	x		
Xterra \ WD22 \ 1999	Air bag	x	x	x	

Xterra \ WD22 \ 1999	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 1999	HVAC	x	x	x	
Xterra \ WD22 \ 1999	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 1999	Multi AV	x	x	x	0280
Xterra \ WD22 \ 1999	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 1999	IPDM E/R	x	x	x	
Xterra \ WD22 \ 1999	Air pressure monitor	x	x	x	
Xterra \ WD22 \ 1999	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 1999	DIU	x	x	x	
Xterra \ WD22 \ 1999	Auto slide door	x	x	x	
Xterra \ WD22 \ 1999	Auto drive position	x	x	x	
Xterra \ WD22 \ 1999	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 1999	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ 1999	Sonar	x	x	x	
Xterra \ WD22 \ 1999	Lane camera	x	x	x	
Xterra \ WD22 \ 1999	Adaptive light	x	x	x	
Xterra \ WD22 \ 1999	AVM		x	x	
Xterra \ WD22 \ 1999	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 1999	Difference lock	x	x	x	
Xterra \ WD22 \ 1999	Nats immu	x	x		
Xterra \ WD22 \ 1999	Smart entrance	x	x		
Xterra \ WD22 \ 1999	Air levelizer	x	x	x	
Xterra \ WD22 \ 1999	Rearview camera			x	
Xterra \ WD22 \ 1999	S/blind camera			x	
Xterra \ WD22 \ 1999	Motor assist	x	x	x	
Xterra \ WD22 \ 2000	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2000	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 2000	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ 2000	BCM	x	x		
Xterra \ WD22 \ 2000	Air bag	x	x	x	
Xterra \ WD22 \ 2000	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 2000	HVAC	x	x	x	
Xterra \ WD22 \ 2000	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 2000	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2000	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2000	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2000	Air pressure monitor	x	x	x	

Xterra \ WD22 \ 2000	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2000	DIU	x	x	x	
Xterra \ WD22 \ 2000	Auto slide door	x	x	x	
Xterra \ WD22 \ 2000	Auto drive position	x	x	x	
Xterra \ WD22 \ 2000	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 2000	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ 2000	Sonar	x	x	x	
Xterra \ WD22 \ 2000	Lane camera	x	x	x	
Xterra \ WD22 \ 2000	Adaptive light	x	x	x	
Xterra \ WD22 \ 2000	AVM		x	x	
Xterra \ WD22 \ 2000	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2000	Difference lock	x	x	x	
Xterra \ WD22 \ 2000	Nats immu	x	x		
Xterra \ WD22 \ 2000	Smart entrance	x	x		
Xterra \ WD22 \ 2000	Air levelizer	x	x	x	
Xterra \ WD22 \ 2000	Rearview camera			x	
Xterra \ WD22 \ 2000	S/blind camera			x	
Xterra \ WD22 \ 2000	Motor assist	x	x	x	
Xterra \ WD22 \ 2001	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2001	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 2001	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ 2001	BCM	x	x		
Xterra \ WD22 \ 2001	Air bag	x	x	x	
Xterra \ WD22 \ 2001	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 2001	HVAC	x	x	x	
Xterra \ WD22 \ 2001	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 2001	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2001	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2001	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2001	Air pressure monitor	x	x	x	
Xterra \ WD22 \ 2001	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2001	DIU	x	x	x	
Xterra \ WD22 \ 2001	Auto slide door	x	x	x	
Xterra \ WD22 \ 2001	Auto drive position	x	x	x	
Xterra \ WD22 \ 2001	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 2001	4WAS(MAIN)/RAS/HICAS	x	x	x	

Xterra \ WD22 \ 2001	Sonar	x	x	x	
Xterra \ WD22 \ 2001	Lane camera	x	x	x	
Xterra \ WD22 \ 2001	Adaptive light	x	x	x	
Xterra \ WD22 \ 2001	AVM		x	x	
Xterra \ WD22 \ 2001	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2001	Difference lock	x	x	x	
Xterra \ WD22 \ 2001	Nats immu	x	x		
Xterra \ WD22 \ 2001	Smart entrance	x	x		
Xterra \ WD22 \ 2001	Air levelizer	x	x	x	
Xterra \ WD22 \ 2001	Rearview camera			x	
Xterra \ WD22 \ 2001	S/blind camera			x	
Xterra \ WD22 \ 2001	Motor assist	x	x	x	
Xterra \ WD22 \ 2002	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2002	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 2002	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ 2002	BCM	x	x		
Xterra \ WD22 \ 2002	Air bag	x	x	x	
Xterra \ WD22 \ 2002	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 2002	HVAC	x	x	x	
Xterra \ WD22 \ 2002	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 2002	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2002	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2002	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2002	Air pressure monitor	x	x	x	
Xterra \ WD22 \ 2002	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2002	DIU	x	x	x	
Xterra \ WD22 \ 2002	Auto slide door	x	x	x	
Xterra \ WD22 \ 2002	Auto drive position	x	x	x	
Xterra \ WD22 \ 2002	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 2002	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ 2002	Sonar	x	x	x	
Xterra \ WD22 \ 2002	Lane camera	x	x	x	
Xterra \ WD22 \ 2002	Adaptive light	x	x	x	
Xterra \ WD22 \ 2002	AVM		x	x	
Xterra \ WD22 \ 2002	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2002	Difference lock	x	x	x	
Xterra \ WD22 \ 2002	Nats immu	x	x		
Xterra \ WD22 \ 2002	Smart entrance	x	x		

Xterra \ WD22 \ 2002	Air levelizer	x	x	x	
Xterra \ WD22 \ 2002	Rearview camera			x	
Xterra \ WD22 \ 2002	S/blind camera			x	
Xterra \ WD22 \ 2002	Motor assist	x	x	x	
Xterra \ WD22 \ 2003	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2003	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 2003	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ 2003	BCM	x	x		
Xterra \ WD22 \ 2003	Air bag	x	x	x	
Xterra \ WD22 \ 2003	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 2003	HVAC	x	x	x	
Xterra \ WD22 \ 2003	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 2003	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2003	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2003	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2003	Air pressure monitor	x	x	x	
Xterra \ WD22 \ 2003	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2003	DIU	x	x	x	
Xterra \ WD22 \ 2003	Auto slide door	x	x	x	
Xterra \ WD22 \ 2003	Auto drive position	x	x	x	
Xterra \ WD22 \ 2003	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 2003	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ 2003	Sonar	x	x	x	
Xterra \ WD22 \ 2003	Lane camera	x	x	x	
Xterra \ WD22 \ 2003	Adaptive light	x	x	x	
Xterra \ WD22 \ 2003	AVM		x	x	
Xterra \ WD22 \ 2003	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2003	Difference lock	x	x	x	
Xterra \ WD22 \ 2003	Nats immu	x	x		
Xterra \ WD22 \ 2003	Smart entrance	x	x		
Xterra \ WD22 \ 2003	Air levelizer	x	x	x	
Xterra \ WD22 \ 2003	Rearview camera			x	
Xterra \ WD22 \ 2003	S/blind camera			x	
Xterra \ WD22 \ 2003	Motor assist	x	x	x	
Xterra \ WD22 \ 2004	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2004	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ 2004	Meter/M&A	x	x	x	0331, 0330, 0197, 0143

Xterra \ WD22 \ 2004	BCM	x	x		
Xterra \ WD22 \ 2004	Air bag	x	x	x	
Xterra \ WD22 \ 2004	ICC/ADAS	x	x	x	
Xterra \ WD22 \ 2004	HVAC	x	x	x	
Xterra \ WD22 \ 2004	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ 2004	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2004	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2004	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2004	Air pressure monitor	x	x	x	
Xterra \ WD22 \ 2004	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2004	DIU	x	x	x	
Xterra \ WD22 \ 2004	Auto slide door	x	x	x	
Xterra \ WD22 \ 2004	Auto drive position	x	x	x	
Xterra \ WD22 \ 2004	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ 2004	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ 2004	Sonar	x	x	x	
Xterra \ WD22 \ 2004	Lane camera	x	x	x	
Xterra \ WD22 \ 2004	Adaptive light	x	x	x	
Xterra \ WD22 \ 2004	AVM		x	x	
Xterra \ WD22 \ 2004	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2004	Difference lock	x	x	x	
Xterra \ WD22 \ 2004	Nats immu	x	x		
Xterra \ WD22 \ 2004	Smart entrance	x	x		
Xterra \ WD22 \ 2004	Air levelizer	x	x	x	
Xterra \ WD22 \ 2004	Rearview camera			x	
Xterra \ WD22 \ 2004	S/blind camera			x	
Xterra \ WD22 \ 2004	Motor assist	x	x	x	
Xterra \ WD22 \ 2007-3~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2007-3~	Meter/M&A		x	x	
Xterra \ WD22 \ 2007-3~	BCM	x	x		
Xterra \ WD22 \ 2007-3~	Transmission	x	x	x	
Xterra \ WD22 \ 2007-3~	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2007-3~	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2007-3~	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2007-3~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2007-3~	All mode AWD/4WD	x	x	x	0245, 0311

Xterra \ WD22 \ 2007-3~	Adaptive light	x	x	x	
Xterra \ WD22 \ 2007-3~	ABS	x	x	x	
Xterra \ WD22 \ 2007-3~	Air bag	x	x	x	
Xterra \ WD22 \ 2007-3~	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2008-12~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2008-12~	Meter/M&A		x	x	
Xterra \ WD22 \ 2008-12~	BCM	x	x		
Xterra \ WD22 \ 2008-12~	Transmission	x	x	x	
Xterra \ WD22 \ 2008-12~	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2008-12~	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2008-12~	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2008-12~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2008-12~	All mode AWD/4WD	x	x	x	0245, 0311
Xterra \ WD22 \ 2008-12~	Adaptive light	x	x	x	
Xterra \ WD22 \ 2008-12~	ABS	x	x	x	
Xterra \ WD22 \ 2008-12~	Air bag	x	x	x	
Xterra \ WD22 \ 2008-12~	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2009-11~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2009-11~	Meter/M&A		x	x	
Xterra \ WD22 \ 2009-11~	BCM	x	x		
Xterra \ WD22 \ 2009-11~	Transmission	x	x	x	
Xterra \ WD22 \ 2009-11~	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2009-11~	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2009-11~	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2009-11~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2009-11~	All mode AWD/4WD	x	x	x	0245, 0311
Xterra \ WD22 \ 2009-11~	Adaptive light	x	x	x	
Xterra \ WD22 \ 2009-11~	ABS	x	x	x	
Xterra \ WD22 \ 2009-11~	Air bag	x	x	x	
Xterra \ WD22 \ 2009-11~	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2009-8~	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ 2009-8~	Meter/M&A		x	x	
Xterra \ WD22 \ 2009-8~	BCM	x	x		
Xterra \ WD22 \ 2009-8~	Transmission	x	x	x	

Xterra \ WD22 \ 2009-8~	Multi AV	x	x	x	0280
Xterra \ WD22 \ 2009-8~	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ 2009-8~	IPDM E/R	x	x	x	
Xterra \ WD22 \ 2009-8~	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ 2009-8~	All mode AWD/4WD	x	x	x	0245, 0311
Xterra \ WD22 \ 2009-8~	Adaptive light	x	x	x	
Xterra \ WD22 \ 2009-8~	ABS	x	x	x	
Xterra \ WD22 \ 2009-8~	Air bag	x	x	x	
Xterra \ WD22 \ 2009-8~	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ 2009-8~	Rearview camera			x	
Xterra \ WD22 \ 2009-8~	S/blind camera			x	
Xterra \ WD22 \ All Year	Engine	x	x	x	0209, 0278, 0262, 0216, 0103, 0233, 0234, 0212
Xterra \ WD22 \ All Year	ABS	x	x	x	0003, 0092, 0264
Xterra \ WD22 \ All Year	Meter/M&A	x	x	x	0331, 0330, 0197, 0143
Xterra \ WD22 \ All Year	BCM	x	x		
Xterra \ WD22 \ All Year	Air bag	x	x	x	
Xterra \ WD22 \ All Year	ICC/ADAS	x	x	x	
Xterra \ WD22 \ All Year	HVAC	x	x	x	
Xterra \ WD22 \ All Year	Transmission	x	x	x	0076, 0113, 0076, 0083, 0100, 0059
Xterra \ WD22 \ All Year	Multi AV	x	x	x	0280
Xterra \ WD22 \ All Year	EPS/DAST 3	x	x	x	
Xterra \ WD22 \ All Year	IPDM E/R	x	x	x	
Xterra \ WD22 \ All Year	Air pressure monitor	x	x	x	
Xterra \ WD22 \ All Year	Intelligent key	x	x	x	0031, 0032, 0042, 0043, 0075, 0115, 0156, 0170, 0175, 0207, 0258, 0303, 0305, 0307, 0344
Xterra \ WD22 \ All Year	DIU	x	x	x	
Xterra \ WD22 \ All Year	Auto slide door	x	x	x	
Xterra \ WD22 \ All Year	Auto drive position	x	x	x	
Xterra \ WD22 \ All Year	All mode AWD/4WD	x	x	x	
Xterra \ WD22 \ All Year	4WAS(MAIN)/RAS/HICAS	x	x	x	
Xterra \ WD22 \ All Year	Sonar	x	x	x	
Xterra \ WD22 \ All Year	Lane camera	x	x	x	
Xterra \ WD22 \ All Year	Adaptive light	x	x	x	
Xterra \ WD22 \ All Year	AVM		x	x	
Xterra \ WD22 \ All Year	Head lamp levelizer	x	x	x	
Xterra \ WD22 \ All Year	Difference lock	x	x	x	
Xterra \ WD22 \ All Year	Nats immu	x	x		

Xterra \ WD22 \ All Year	Smart entrance	x	x		
Xterra \ WD22 \ All Year	Air levelizer	x	x	x	
Xterra \ WD22 \ All Year	Rearview camera			x	
Xterra \ WD22 \ All Year	S/blind camera			x	
Xterra \ WD22 \ All Year	Motor assist	x	x	x	

Special Function Table

0001	ACCELERATION SENSOR
0002	ACCUMULATOR PRESSURE DECREASES
0003	ACT OR DEACT ROLLER BENCH TEST MODE
0004	ACTIVATE EVAP SYSTEM
0005	ADAPTIVES AFTER REGENERATING PF
0006	ADAPTIVES ON AIR INTAKE FLAP MALFUNCTION
0007	AFTER CAMSHAFT POS SENSOR REPLACEMENT
0008	AFTER CLUCH PEDAL SWITCH REPLACEMENT
0009	AFTER CRANKSHAFT POS SENSOR REPLACEMENT
0010	AFTER DPF REGENERATION
0011	AFTER DPF REPLACEMENT
0012	AFTER FUEL INJECTOR REPLACEMENT
0013	AFTER FUEL RAIL PRESSURE SENSOR REPLACEMENT
0014	AFTER HIGH PRESSURE FUEL PUMP REPLACEMENT
0015	AFTER PRESSURE LINE REPLACEMENT
0016	AFTER TC SOLENOID VALVE REPLACEMENT
0017	AFTER TURBOCHARGER REPLACEMENT
0018	AFTR ELECTRIC THRCTL CNTRL ACTUATOR RPLCMNT
0019	AIR BLEEDING
0020	AIR DAMPER VALVE PROGRAMMING
0021	AIR DAMPER VALVE PROGRAMMING(R044)
0022	AIR DAMPER VALVE PROGRAMMING(R088)
0023	AIR FLOW METER PROGRAMMING
0024	AIR FLOW REDUCTION SETTING
0025	AIR FLOWMETER PROGRAMMING
0026	AIR FUEL RATIO SENSOR
0027	AIR INLET CHANGE SETTING
0028	AIR PATH PROGRAMMING
0029	ALTERNATOR SETPOINT VOLTAGE
0030	ANALOGIC DISPLAY FUEL GAUGE CALIBRATION
0031	ANSWER BACK FUNCTION
0032	AUTO RElock TIMER

0033	AUTO-ADAPTIVES
0034	AVERAGE AIR TEMPERATURE
0035	Adaptives after replacing cabin filter
0036	Adaptives on etc actuator malfunction
0037	After p/filter regen with diag tool
0038	After particle filter regeneration with the diag tool.
0039	After replacement of the p/filter
0040	After replacement of the particle filter
0041	Alcohol level prog.
0042	Answer back with i-key Unlock
0043	Answer back with i-key lock
0044	BATTERY CORROSION COUNTER
0045	BATTERY CYCLE COUNTER
0046	BATTERY CYCLE COUNTER ESTIMATED
0047	BATTERY CYCLE COUNTER MEMORISED
0048	BLOW SET
0049	BRAKE OPERATION
0050	BRAKE RELEASE
0051	BREAKING IN OF REFRIGERANT COMPRESSOR
0052	Backup of instrument panel data for injection
0053	Battery gradual cap loss data clear
0054	Bld hyd unit brk circ
0055	Bleed hydraulic unit and braking circuits
0056	Brake PRESSURE OFFSET SENSOR
0057	CALCULATE BATTERY WEAR COUNTERS(R011)
0058	CALCULATE BATTERY WEAR COUNTERS(S006)
0059	CALIB DATA
0060	CAMSHAFT REFERENCE ADAPTATION
0061	CAMSHAFT SENSOR PROGRAMMING
0062	CARAVAN TOWING DISTANCE
0063	CATALYTIC CONVERTER
0064	CC/SL PRGRM
0065	CHARGE CURRENT LIMITATION HISTORY
0066	CHECKING A KEY
0067	CLEAN SW SET
0068	CLTH INI CLOSE POS
0069	CLUTCH PEDAL END STROKE
0070	CLUTCH SENSOR RESET
0071	CML B/DCHRG CRNT CLEAR
0072	COMPUTER CALIBRATION

0073	COMPUTER INITIALISATION
0074	COMPUTER REINITIALISATION
0075	CONFIRM KEY FOB ID
0076	CONFORM CVTF DETERIORTN
0077	CORROSION BATTERY COUNTER ESTIMATED
0078	CORROSION BATTERY COUNTER MEMORISED
0079	CYLINDER 1 INJECTOR CODE
0080	CYLINDER 2 INJECTOR CODE
0081	CYLINDER 3 INJECTOR CODE
0082	CYLINDER 4 INJECTOR CODE
0083	Calib data
0084	Calibration of EPS torque sensor
0085	Clutch Point
0086	Commercial VHCL idle SPD mod
0087	Control deviation charge air system
0088	DAST CALIBRATION (MODE1)
0089	DAST CALIBRATION (MODE2)
0090	DATA CLEAR FOR REPLACING CPU A
0091	DATA CLEAR FOR REPLACING CPU B
0092	DECEL G SEN CALIBRATION
0093	DECREMENT IDLE SPEED
0094	DIFF EXH PRES. SEN
0095	DPF DATA CLEAR
0096	DPF REGENERATION
0097	DPF RELATIVE PRESSURE SENSOR
0098	Door motor starting position reset
0099	E/O CC/SL PRGRM
0100	ECO MODE RESET FUNCTION
0101	ECU MEMORY
0102	EEPROM CLEAR CONFIRM
0103	EGR ADAPTIVES
0104	EGR BYPASS PROGRAMMING
0105	EGR PROGRAMMING
0106	EGR VALVE
0107	EGR VALVE PROGRAMMING
0108	EGR control valve closed position learning
0109	EGR/V LEARN CLR
0110	ELECTRIC O.P. AIR BLEEDING
0111	ELECTRICAL CONTACT ACTUATORS/BRAKE CLEARANCE SETTING
0112	ENGINE ADAPTIVES

0113	ENGINE Brake ADJ.
0114	ENGINE COOLANT BYPASS VALVE
0115	ENGINE START BY I-KEY
0116	ERASE COMPUTER MEMORY
0117	ERASE LEARNING VALUE
0118	ERASE MEMORY DATA
0119	ERASE OVERHEAT COUNTER
0120	ERS INCRRECT CRNKNG CNTR
0121	ESP A-RECN THRSH
0122	ESP SENSOR PROGRAMMING
0123	EXHAUST AIR FLAP PROGRAMMING
0124	EXHAUST FLAP LOW SETTING
0125	EXHAUST FUEL INJECTOR CIRCUIT
0126	EXHAUST THROTTLE VALVE PROGRAMMING
0127	Exh fuel inj data clear
0128	FAST IDLE SPEED MODIFICATION
0129	FAULT MEMORY
0130	FINISH BRAKE PAD REPLACEMENT
0131	FLIPPER DOOR
0132	FLYWHEEL TARGET PROGRAMMING (R061)
0133	FLYWHEEL TARGET PROGRAMMING (R065)
0134	FLYWHEEL TARGET PROGRAMMING (R102)
0135	FLYWHEEL TARGET PROGRAMMING (R103)
0136	FLYWHEEL TARGET PROGRAMMING (R104)
0137	FLYWHEEL TARGET PROGRAMMING (R105)
0138	FLYWHEEL TARGET PROGRAMMING (R106)
0139	FLYWHL TGT PG
0140	FRE MEMORY SET
0141	FRONT OR REAR SENSOR LOCALIZATION WAS UNSUCCESSFUL
0142	FUEL GAUGE CALIBRATION
0143	FUEL METER DIAGNOSIS(ANALOG POINTER)
0144	FUEL PRESSURE RELEASE
0145	FUEL PUMP PROGRAMMING
0146	FUEL RAIL PRESS LIMITING INJCTN COUNTR CLEAR
0147	FUEL RAIL PRESSURE TEST
0148	FUEL SPLY PREV
0149	FWD CLUTCH POINT LEARNING
0150	G SENSOR CALIBRATION
0151	GAS SENSOR ADJUSTMENT
0152	H/P FUEL PUMP TOTAL STARTS COUNTER CLEAR

0153	H/p fuel pump initial starts counter reset
0154	H/p fuel pump total starts counter reset
0155	HANDS-FREE CARD READING
0156	HAZARD ANSWER BACK
0157	HIGH PRESSURE PUMP COUNTER
0158	HIGH PRESSURE PUMP COUNTER (V344)
0159	HIGH PRESSURE TURBINE BYPASS SOLENOID VALVE
0160	HILL START
0161	HP TURBINE BYPASS SOL VLV PROGRAMMING
0162	High pressure fuel circuit fault finding
0163	INCREMENT IDLE SPEED
0164	INHIBIT EVAP SYSTEM
0165	INITIALIZATION POSITION ADJUSTMENT
0166	INJECTION PUMP ADAPTATIVES
0167	INJECTION PUMP ADAPTATIVES (R077)
0168	INJECTOR ADAPTIVES
0169	INLET FLAP
0170	KEYLESS FUNCTION
0171	LCD DISPLAY FUEL GAUGE CALIBRATION
0172	LEARNING
0173	LONGITUDINAL ACCELERATION SENSOR
0174	LONGITUDINAL ACCELERATION SENSOR OFFSET
0175	Low batt of key fob warn
0176	Low pressure egr valve programming
0177	MANIFOLD PRESSURE SENSOR PROGRAMMING
0178	MEMORISATION OF SPEEDS
0179	MULTIPLEXED NETWORK CONFIGURATION
0180	NORMALIZATION
0181	NORMALIZATION OF ACTUATOR MOTORS
0182	NOTE OIL WEAR COUNTER
0183	NOX SENSOR 1 DATA CLEAR
0184	NOX SENSOR 2 DATA CLEAR
0185	NOX TRAP
0186	NUMBER OF STARTING
0187	NUMBER OF STARTING 1
0188	NUMBER OF STARTING 2
0189	NUMBER OF STARTING 3
0190	NUMBER OF STARTING 4
0191	NUMBER OF STARTING CYCLES
0192	NUMBER OF STARTING CYCLES (V343)

0193	OC DATA CLEAR
0194	OIL CHG INT(km)
0195	OPE TIME BASIC DIAG TEMP SEN UPSTREAM SCR CAT
0196	OPR TIME BASIC DIAG SCR CATALYSTIC CONVRTR
0197	OUTSIDE AIR TEMPERATURE DIAGNOSIS
0198	OXIDATION CATALYST DATA CLEAR
0199	Oil change interval in months
0200	Oil change range: in km
0201	Oil change range:current value in months
0202	Oil grade factor
0203	Oil service and odometry miles - km
0204	P position learning value clear
0205	P/FLT DIFF PRS SEN
0206	P062F EXCLUSIVE FUNCTION
0207	POWER SLIDE DOOR DELAY
0208	PREHEATER UNIT
0209	PRES REG ADAPTIVE
0210	PRESSURE REGULATION ADAPTIVES
0211	PRESSURE SENSOR CALIBRATION
0212	PRGRM REINITIALIZE
0213	PROGRAM CLUTCH OPEN POSITION
0214	PROGRAM REINITIALIZE
0215	PROGRAM SLIP POINT
0216	PROGRAMMED VALUES
0217	PROGRAMMING REINITIALISATION
0218	PROGRAMMING THE HANDS-FREE CARD
0219	PROGRAMMING THROTTLE LIMITS
0220	PRPR RICH SEN PROG
0221	PUMP PRESSURE REGULATOR TYPE
0222	PUMP lock/Unlock
0223	Programming selection/engaging zones
0224	Qk tch in zero qunty calib val while driving
0225	RAIL PRESSURE SENSOR ADAPTIVES
0226	RAIL PRS SEN ADAPTIVES
0227	READ VIN
0228	REAR TEMP SET CORRECT
0229	REC MEMORY SET
0230	REGULATION WASTE GATE
0231	REMOVE ADAPTATIONS VALUE OF SHIFT OPERATIONS
0232	REPLACE DIESEL PARTICULATE FILTER

0233	RESET INJCTR ADAPTATIVE
0234	RESET PUMP FORCEFEEDING
0235	RESETTING CENTER POSITION OF STEERING
0236	RESETTING INTERNAL PROTECTION
0237	RESETTING OF ADAPTION VALUES
0238	RESOLVER OFFSET
0239	RESTART THE COMPUTER
0240	REVERSING CAMERA CALIBRATION
0241	RICHNESS REGULATION PROGRAMMING
0242	ROOF LATCH
0243	ROOF STATE RESET
0244	ROOF/TRUNK/PARCEL SHELF
0245	RPS OFFSET LEARNING VALUE CLEAR
0246	Re learning
0247	Reset
0248	Reset of contamination level of air filter
0249	Reset of learned values of cmsft hall SEN
0250	Reverse gear reset of adaption values
0251	SAVE BATTERY INFORMATION DATA
0252	SAVE COMPUTER DATA
0253	SAVE VIN DATA
0254	SCR CAT AMOUNT OF UREA ADSORPT DATA CLEAR
0255	SCR CATALYST DATA CLEAR
0256	SCR CATALYST TEMP SENSOR 1 DATA CLEAR
0257	SCR MALFUNCTION HISTORY RESET
0258	SELECTIVE Unlock FUNCTION
0259	SENSOR CONFIGURATION
0260	SERVIC REGENERATION
0261	SET AUTOLOCATION DISABLE
0262	SPEED LIMITER
0263	SPEEDO INDEX
0264	ST ANGLE SENSOR ADJUSTMENT
0265	START BRAKE PAD REPLACEMENT
0266	STARTER OPERATION COUNTER CLEAR
0267	STATUS OF TEACH IN PROCESSES
0268	STEERING WHEEL ANGLE SENSOR
0269	STEERING WHL ANGLE SEN
0270	STOP AND START FUNCTION
0271	STORED ENERGY MANAGEMENT DATA
0272	STP FUEL SPLY PREV

0273	STROKE SENSOR CALIBRATION
0274	STRT OPRTN CNTR CLEAR
0275	SWIRL FLAP
0276	SWIRL FLAP PROGRAMMING
0277	SYSTEM MODE CHANGE
0278	Saving data for replc cpu
0279	Sc magnetic clutch engage count clear
0280	St ang sen adjustment
0281	Start obd test: catalytic converter
0282	Start obd test: o2 sensors
0283	Static Test
0284	Steering wheel angle offset sensor
0285	Stop/start system operation cond setting
0286	TABLE INITIALIZATION ASSYST
0287	TACHOMETRIC INDEX
0288	TARGET IDLE RPM ADJ
0289	TARGET IGN TIM ADJ
0290	TEACH IN AFTER REPLAC ADBLUE METERING VALVE
0291	TEACH IN BOOST PRESSURE POSITIONER
0292	TEACH IN COMBINATION METER
0293	TEACH IN OF ACTUATOR MOTORS
0294	TEACH IN OF CAMSHAFT POSITION
0295	TEACH IN OF DPF AFTER REPLACE OF CDI C/U
0296	TEACH IN OF SENSOR ROTOR ADAPTATION
0297	TEMP SET CORRECT
0298	THERMOPLUNGER
0299	THERMOPLUNGER PROGRAMMING
0300	TP POS LEARN CLR
0301	TRANSFER OF MANUFACTURER DEFAULT SETTINGS
0302	TRANSVERSE ACCELERATION OFFSET SENSOR
0303	TRUNK OPEN DELAY
0304	TRUNK OPENER
0305	TRUNK/GLASS HATCH OPEN
0306	TURBOCHARGER PROGRAMMING
0307	Take out from window warn
0308	Target evaporator temp upper limit setting
0309	Teach in of selection range sensor
0310	Teach in of throttle valve stop
0311	UNIT CHARACTERISTICS DATA
0312	UPDATE ODOMETER

0313	UREA INJECTOR DATA CLEAR
0314	UREA INJECTOR LEARNING VALUE CLEAR
0315	UREA PUMP LEARNINNG VALUE CLEAR
0316	UREA TANK UNIT ASSEMBLY LEARNING VALUE CLEAR
0317	Unlock COMPUTER
0318	Unlock INJECTOR CONTROL
0319	VACUUM PUMP
0320	VALVE CALIBRATION
0321	VALVE CHECK
0322	VARIABLE VALVE TIMING
0323	VEH. SPEED AT INITIALISATION
0324	VEHICLE FUNC PROG
0325	VEHICLE PARAMETERS
0326	VIN REGISTRATION
0327	VOLUME CONTROL VALVE LEARNING VALUE CLEAR
0328	Valve timing offset data clear
0329	Valve timing offset data writing
0330	W/L ON HISTORY
0331	WARNING LAMP DIAGNOSIS
0332	WRITE H/P FUEL PUMP TOTAL STARTS COUNT
0333	WRITE STARTER OPERATION COUNT
0334	Write date new clutch fitted
0335	Write date of after sales operation
0336	Write date of last after sales ope
0337	Write transmission oil change date
0338	Writing of instrument panel data for injection
0339	Wrte clth ini close pos
0340	ZFC VALUE RESET
0341	lock COMPUTER
0342	lock INJECTOR CONTROL
0343	lock INJECTOR CTRL
0344	lock/Unlock BY I-KEY