

JEEP Function list

Note:

x Functions marked with x is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

Vehicle	System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
2017\4C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\4C	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\4C	PAM -- Park Assist Module	x	x	x	x		
2017\4C	ECM -- Engine Control Module	x	x	x	x	x	
2017\4C	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\4C	TCM -- Transmission Control Module	x	x	x	x		
2017\4C	BCM -- Body Controller	x	x	x	x	x	
2017\4C	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\B1-Renegade	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\B1-Renegade	PAM -- Park Assist Module	x	x	x	x		
2017\B1-Renegade	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2017\B1-Renegade	TCM -- Transmission Control Module	x	x	x	x		
2017\B1-Renegade	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\B1-Renegade	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\B1-Renegade	TTM -- Trailer tow module	x	x	x	x	x	
2017\B1-Renegade	EPS -- Electric Power Steering	x	x	x	x		
2017\B1-Renegade	AMP -- Amplifier	x	x	x	x	x	
2017\B1-Renegade	ECM -- Engine Control Module	x	x	x	x	x	
2017\B1-Renegade	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\B1-Renegade	BCM -- Body Controller	x	x	x	x	x	
2017\B1-Renegade	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\B1-Renegade	ESM -- Electronic Shifter	x	x	x	x	x	
2017\B1-Renegade	DTCM -- Drive Train Control Module	x	x	x	x		
2017\B1-Renegade	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\B1-Renegade	HALF -- Haptical Lane Feedback	x	x	x	x		
2017\B1-Renegade	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\B1-Renegade	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\B1-Renegade	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\B1-Renegade	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	

2017\B1-Renegade	ESL -- Electronic Steering Lock		x	x	x		
2017\BF-Fiat 500L	PAM -- Park Assist Module	x	x	x	x		
2017\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\BF-Fiat 500L	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2017\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x		
2017\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	
2017\BF-Fiat 500L	EPS -- Electric Power Steering	x	x	x	x		
2017\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x	x	
2017\BF-Fiat 500L	ESM -- Electronic Shifter	x	x	x	x	x	
2017\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	
2017\BF-Fiat 500L	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\B0-Renegade	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\B0-Renegade	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\B0-Renegade	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\B0-Renegade	EPS -- Electric Power Steering	x	x	x	x		
2017\B0-Renegade	TCM -- Transmission Control Module	x	x	x	x		
2017\B0-Renegade	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2017\B0-Renegade	DTCM -- Drive Train Control Module	x	x	x	x		
2017\B0-Renegade	ESL -- Electronic Steering Lock		x	x	x		
2017\B0-Renegade	AMP -- Amplifier	x	x	x	x	x	
2017\B0-Renegade	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\B0-Renegade	ECM -- Engine Control Module	x	x	x	x	x	
2017\B0-Renegade	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\B0-Renegade	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\B0-Renegade	HALF -- Haptical Lane Feedback	x	x	x	x		
2017\B0-Renegade	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\B0-Renegade	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\B0-Renegade	ESM -- Electronic Shifter	x	x	x	x	x	
2017\B0-Renegade	BCM -- Body Controller	x	x	x	x	x	
2017\B0-Renegade	TTM -- Trailer tow module	x	x	x	x	x	
2017\B0-Renegade	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\B0-Renegade	PAM -- Park Assist Module	x	x	x	x		
2017\B0-Renegade	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2017\B2-Ram Truck	AMP -- Amplifier	x	x	x	x		
2017\B2-Ram Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2017\B2-Ram Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2017\B2-Ram Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\B2-Ram Truck	PTS -- Parktronics	x	x	x	x	x	

2017DZ-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
2017DZ-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017DZ-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2017DZ-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
2017DZ-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
2017DZ-Kam	RADIO -- Radio	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017DZ-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017DZ-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2017DZ-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
2017DZ-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017DD-Kam	AMP -- Amplifier	x	x	x	x		
Truck	RADIO -- Radio	x	x	x	x	x	
2017DD-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017DD-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
2017DD-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
2017DD-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017DD-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
2017DD-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	BCM -- Body Controller	x	x	x	x	x	
2017DD-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2017DD-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017DD-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	

2017 DD-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017k DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
2017k DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
2017 Cph Chassis	TCM -- Transmission Control Module	x	x	x	x	x	
2017 Cph Chassis	DCU -- Dosing Control Unit	x	x	x			
2017 Cph Chassis	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017 Cph Chassis	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017 Cph Chassis	BCM -- Body Controller	x	x	x	x	x	
2017 Cph Chassis	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017 Cph Chassis	ECM -- Engine Control Module	x	x	x	x	x	
2017 Cph Chassis	SCCM -- Steering Column Control Module	x	x	x	x		
2017 Cph Chassis	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017 Cph Chassis	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017 Cph Chassis	ICS -- Integrated Center Stack	x	x	x	x	x	
2017 Cph Chassis	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017 Cph Chassis	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017 Cph Chassis	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017 Cph Chassis	VGT -- Variable Geometry Turbo	x	x	x			
2017 Cph Chassis	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2017 Cph Chassis	HSM -- Heated Seat Module	x	x	x	x	x	
2017 Cph Chassis	PTS -- Parktronics	x	x	x	x	x	
2017 Cph Chassis	RADIO -- Radio	x	x	x	x	x	
2017 Cph Chassis	DDM -- Driver Door Module	x	x	x	x	x	
2017 Cph Chassis	AMP -- Amplifier	x	x	x	x		
2017 Cph Chassis	PDM -- Passenger Door Module	x	x	x	x	x	
2017k DD-Ram	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017k DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
2017k DD-Ram	VGT -- Variable Geometry Turbo	x	x	x			
2017k DD-Ram	PDM -- Passenger Door Module	x	x	x	x	x	
2017k DD-Ram	BCM -- Body Controller	x	x	x	x	x	
2017k DD-Ram	DCU -- Dosing Control Unit	x	x	x			
2017k DD-Ram	DDM -- Driver Door Module	x	x	x	x	x	
2017k DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017k DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017k DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017k DD-Ram	AMP -- Amplifier	x	x	x	x		
2017k DD-Ram	ASCM -- Air Suspension Control Module	x	x	x	x		
2017k DD-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017k DD-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017k DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck							

2017DS-Ram	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017DS-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2017DS-Ram	RADIO -- Radio	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
2017DS-Ram	EDM -- External Disc Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
2017DS-Ram	PTS -- Parktronics	x	x	x	x	x	
Truck	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2017DR-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
2017DR-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2017DR-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2017DR-Ram	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	EDM -- External Disc Module	x	x	x	x	x	
2017DR-Ram	BCM -- Body Controller	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017DR-Ram	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017DR-Ram	DCU -- Dosing Control Unit	x	x	x			
Truck	VGT -- Variable Geometry Turbo	x	x	x			
2017DR-Ram	AMP -- Amplifier	x	x	x	x		
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017DR-Ram	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
2017DR-Ram	PTS -- Parktronics	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2017DR-Ram	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2017DR-Ram	RADIO -- Radio	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2017DS-Ram	AMP -- Amplifier	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2017DS-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
2017DS-Ram	DDM -- Driver Door Module	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		

2017DS-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2017DS-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2017DS-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2017DS-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2017DS-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2017DS-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2017DS-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2017DS-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2017DS-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2017DS-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2017DS-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2017DS-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2017DS-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2017DS-Kam	TCM -- Transmission Control Module	x	x	x	x		
Truck							
2017DS-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2017DS-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2017DS-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2017DS-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2017DS-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2017DS-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2017DS-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2017DS-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2017DS-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2017DS-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2017DS-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2017DS-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2017DS-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2017DS-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2017DS-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2017DS-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2017DS-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2017DS-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2017DS-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2017DS-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2017DS-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2017DS-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2017DS-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2017DS-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2017DS-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2017DS-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							

2017\BX-Kam Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017\BX-Kam Truck	DCU -- Dosing Control Unit	x	x	x			
2017\BX-Kam Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2017\FB-500X	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\FB-500X	ESL -- Electronic Steering Lock		x	x	x		
2017\FB-500X	TCM -- Transmission Control Module	x	x	x	x		
2017\FB-500X	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\FB-500X	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\FB-500X	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2017\FB-500X	BCM -- Body Controller	x	x	x	x	x	
2017\FB-500X	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\FB-500X	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\FB-500X	DTCM -- Drive Train Control Module	x	x	x	x		
2017\FB-500X	ECM -- Engine Control Module	x	x	x	x	x	
2017\FB-500X	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\FB-500X	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\FB-500X	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\FB-500X	AMP -- Amplifier	x	x	x	x	x	
2017\FB-500X	EPS -- Electric Power Steering	x	x	x	x		
2017\FB-500X	PAM -- Park Assist Module	x	x	x	x		
2017\FB-500X	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\FB-500X	ESM -- Electronic Shifter	x	x	x	x	x	
2017\FB-500X	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2017\FB-500X	HALF -- Haptical Lane Feedback	x	x	x	x		
2017\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2017\FF-500	PIM -- Power Inverter Module	x	x	x	x		
2017\FF-500	OBCM -- On Board Charging Module	x	x	x	x		
2017\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\FF-500	PTS -- Parktronics	x	x	x	x		
2017\FF-500	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2017\FF-500	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\FF-500	EVCU -- Electronic Vehicle Control Unit	x	x	x	x	x	
2017\FF-500	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2017\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2017\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2017\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\FF-500	EAC -- Electric A/C Compressor	x	x	x	x		
2017\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2017\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2017\FF-500	ESM -- Electronic Shifter	x	x	x			
2017\FF-500	RBC -- Regenerative Brake Controller	x	x	x	x		
2017\FF-500	BCM -- Body Controller	x	x	x	x	x	
2017\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2017\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2017\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2017\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2017\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2017\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2017\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\J8-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2017\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	0011, 0010
2017\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2017\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2017\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2017\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2017\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2017\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2017\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2017\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2017\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2017\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2017\JC-Journey	AMP -- Amplifier	x	x	x	x		
2017\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2017\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2017\JC-Journey	VTM -- Vehicle Tracking Module	x	x	x	x		
2017\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2017\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2017\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2017\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\JF-Freemont	AMP -- Amplifier	x	x	x	x		

2017\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2017\JF-Freemont	VTM -- Vehicle Tracking Module	x	x	x	x		
2017\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2017\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2017\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2017\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2017\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2017\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2017\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	
2017\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2017\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2017\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2017\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2017\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2017\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2017\JK-Wrangler	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2017\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2017\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2017\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2017\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2017\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2017\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2017\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	0011, 0010
2017\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\KL-Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2017\KL-Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\KL-Cherokee	SCCM -- Steering Column Control Module	x	x	x	x	x	
2017\KL-Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\KL-Cherokee	TCM -- Transmission Control Module	x	x	x	x		

2017\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2017\KL-Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\KL-Cherokee	AMP -- Amplifier	x	x	x	x		
2017\KL-Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\KL-Cherokee	OCM -- Occupant Classification	x	x	x	x		
2017\KL-Cherokee	RDM -- Rear Drive Module	x	x	x			
2017\KL-Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\KL-Cherokee	DTV -- Digital Television	x	x	x	x	x	
2017\KL-Cherokee	BCM -- Body Controller	x	x	x	x	x	
2017\KL-Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\KL-Cherokee	PAM -- Park Assist Module	x	x	x	x	x	
2017\KL-Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\KL-Cherokee	AHLM -- Headlamp Leveling	x	x	x	x		
2017\KL-Cherokee	EDM -- External Disc Module	x	x	x		x	
2017\KL-Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\KL-Cherokee	EPB -- Electrical Parking Brake	x	x	x	x		
2017\KL-Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2017\KL-Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2017\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\KL-Cherokee	PTU -- Power Transfer Unit	x	x	x			
2017\KL-Cherokee	ESL -- Electronic Steering Lock	x	x	x	x		
2017\KL-Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\KL-Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2017\KL-Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2017\KL-Cherokee	RADIO -- Radio	x	x	x	x	x	
2017\KL-Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\KL-Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\LA-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\LA-Challenger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\LA-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2017\LA-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\LA-Challenger	SCCM -- Steering Column Control Module	x	x	x	x		
2017\LA-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2017\LA-Challenger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\LA-Challenger	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\LA-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2017\LA-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\LA-Challenger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\LA-Challenger	ADCM -- Active Damping Control Module	x	x	x	x		

2017\LD-Challenger	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\LD-Challenger	AMP -- Amplifier	x	x	x	x		
2017\LD-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\LD-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2017\LD-Challenger	RADIO -- Radio	x	x	x	x	x	
2017\LD-Challenger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\LD-Challenger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\LD-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2017\LD-Challenger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\LD-Challenger	BCM -- Body Controller	x	x	x	x	x	
2017\LD-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2017\LD-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2017\LD-Challenger	PTS -- Parktronics	x	x	x	x	x	
2017\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2017\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2017\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2017\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2017\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\LD-Charger	AMP -- Amplifier	x	x	x	x		
2017\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2017\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2017\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2017\LD-Charger	DSM -- Display Screen Module	x	x	x	x		
2017\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2017\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2017\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2017\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2017\LD-Charger	RADIO -- Radio	x	x	x	x	x	
2017\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2017\LD-Charger	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2017LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2017LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2017LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2017LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2017LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2017LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017LD-Charger	RADIO -- Radio	x	x	x	x	x	
2017LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2017LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2017LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2017LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2017LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2017LD-Charger	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2017LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2017LD-Charger	AMP -- Amplifier	x	x	x	x		
2017LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2017LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2017LD-Charger	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2017LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2017LD-Charger	OCM -- Occupant Classification	x	x	x	x		
2017M1-551	DTV -- Digital Television	x	x	x	x	x	
2017M1-551	ESM -- Electronic Shifter	x	x	x	x		
2017M1-551	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017M1-551	TCM -- Transmission Control Module	x	x	x	x	x	
2017M1-551	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017M1-551	ESL -- Electronic Steering Lock		x	x	x		
2017M1-551	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017M1-551	ECM -- Engine Control Module	x	x	x	x	x	0010
2017M1-551	TTM -- Trailer tow module	x	x	x	x	x	

2017M1-551	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017M1-551	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017M1-551	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017M1-551	DTCM -- Drive Train Control Module	x	x	x	x		
2017M1-551	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017M1-551	BCM -- Body Controller	x	x	x	x	x	
2017M1-551	PAM -- Park Assist Module	x	x	x	x		
2017M1-551	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017M1-551	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017M1-551	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017M1-551	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017M1-551	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017M1-551	ICS -- Integrated Center Stack	x	x	x	x	x	
2017M1-551	EPS -- Electric Power Steering	x	x	x	x		
2017M1-551	AMP -- Amplifier	x	x	x	x	x	
2017M1-551	RRM -- Radio Receiver Module	x	x	x	x	x	
2017M1-551	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017M4-553	TTM -- Trailer tow module	x	x	x	x	x	
2017M4-553	BCM -- Body Controller	x	x	x	x	x	
2017M4-553	PAM -- Park Assist Module	x	x	x	x		
2017M4-553	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017M4-553	ICS -- Integrated Center Stack	x	x	x	x	x	
2017M4-553	ESM -- Electronic Shifter	x	x	x	x		
2017M4-553	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017M4-553	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017M4-553	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017M4-553	DTCM -- Drive Train Control Module	x	x	x	x		
2017M4-553	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017M4-553	TCM -- Transmission Control Module	x	x	x	x	x	
2017M4-553	EPS -- Electric Power Steering	x	x	x	x		
2017M4-553	ECM -- Engine Control Module	x	x	x	x	x	0010
2017M4-553	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017M4-553	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017M4-553	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017M4-553	ESL -- Electronic Steering Lock		x	x	x		
2017M4-553	DTV -- Digital Television	x	x	x	x	x	
2017M4-553	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017M4-553	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017M4-553	AMP -- Amplifier	x	x	x	x	x	
2017M4-553	RFH -- Radio Frequency Hub	x	x	x	x	x	

2017\M4-553	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\M4-553	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\M4-553	OCM -- Occupant Classification	x	x	x	x		
2017\M4-553	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\M6-556	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\M6-556	EPS -- Electric Power Steering	x	x	x	x		
2017\M6-556	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\M6-556	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\M6-556	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\M6-556	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\M6-556	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\M6-556	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\M6-556	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\M6-556	DTCM -- Drive Train Control Module	x	x	x	x		
2017\M6-556	TCM -- Transmission Control Module	x	x	x	x		
2017\M6-556	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\M6-556	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\M6-556	ECM -- Engine Control Module	x	x	x	x	x	0010
2017\M6-556	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\M6-556	OCM -- Occupant Classification	x	x	x	x		
2017\M6-556	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\M6-556	DTV -- Digital Television	x	x	x	x	x	
2017\M6-556	ESM -- Electronic Shifter	x	x	x	x		
2017\M6-556	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\M6-556	TTM -- Trailer tow module	x	x	x	x	x	
2017\M6-556	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\M6-556	PAM -- Park Assist Module	x	x	x	x		
2017\M6-556	ESL -- Electronic Steering Lock		x	x	x		
2017\M6-556	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\M6-556	AMP -- Amplifier	x	x	x	x	x	
2017\M6-556	BCM -- Body Controller	x	x	x	x	x	
2017\M6-556	SAS -- Steering Angle Sensor	x	x	x	x		
Compass Patriot	CGW -- Central Gateway	x	x	x	x	x	
Compass Patriot	AMP -- Amplifier	x	x	x	x		
2017\M6-556	ABS -- Anti Lock Brakes	x	x	x	x	x	0015, 0001, 0015, 0001,
Compass Patriot	TCM -- Transmission Control Module	x	x	x	x	x	0012
Compass Patriot	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
Compass Patriot	WCM/TPMS -- Wireless Control	x	x	x	x		
2017\M6-556	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Compass Patriot	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2017\MP-Compass Patriot	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2017\MP-Compass Patriot	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017\MP-Compass Patriot	RADIO -- Radio	x	x	x	x	x	
2017\MP-Compass Patriot	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\MP-Compass Patriot	HFM -- Hands Free Module	x	x	x	x	x	
2017\MP-552	TCM -- Transmission Control Module	x	x	x	x	x	
2017\MP-552	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\MP-552	DTCM -- Drive Train Control Module	x	x	x	x		
2017\MP-552	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\MP-552	DTV -- Digital Television	x	x	x	x	x	
2017\MP-552	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\MP-552	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\MP-552	AMP -- Amplifier	x	x	x	x	x	
2017\MP-552	ECM -- Engine Control Module	x	x	x	x	x	0010
2017\MP-552	OCM -- Occupant Classification	x	x	x	x		
2017\MP-552	TTM -- Trailer tow module	x	x	x	x	x	
2017\MP-552	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\MP-552	ESM -- Electronic Shifter	x	x	x	x		
2017\MP-552	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\MP-552	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\MP-552	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\MP-552	EPS -- Electric Power Steering	x	x	x	x		
2017\MP-552	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\MP-552	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\MP-552	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\MP-552	BCM -- Body Controller	x	x	x	x	x	
2017\MP-552	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\MP-552	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\MP-552	ESL -- Electronic Steering Lock		x	x	x		
2017\MP-552	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\MP-552	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\MP-552	PAM -- Park Assist Module	x	x	x	x		
2017\PD-Neon	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2017\PD-Neon	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\PD-Neon	ECM -- Engine Control Module	x	x	x	x	x	
2017\PD-Neon	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\PD-Neon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\PD-Neon	AHM -- Additional Heater Module	x	x	x	x		
2017\PD-Neon	RRM -- Radio Receiver Module	x	x	x	x	x	
2017\PD-Neon	ESM -- Electronic Shifter	x	x	x	x	x	

2017\PD-Neon	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\PD-Neon	TCM -- Transmission Control Module	x	x	x	x		
2017\PD-Neon	PAM -- Park Assist Module	x	x	x	x		
2017\PD-Neon	EPS -- Electric Power Steering	x	x	x	x		
2017\PD-Neon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\PD-Neon	BCM -- Body Controller	x	x	x	x	x	
2017\PD-Neon	SUNR -- Sunroof	x	x	x	x	x	
2017\VRP-Town &	PEM -- Passive Entry Module	x	x	x	x		
2017\VRP-Town &	VES2 -- Second Row Screen	x	x	x	x	x	
2017\VRP-Town &	AMP -- Amplifier	x	x	x	x		
2017\VRP-Town &	HFM -- Hands Free Module	x	x	x	x	x	
2017\VRP-Town &	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\VRP-Town &	DMFL -- Door Module Front Left	x	x	x	x	x	
2017\VRP-Town &	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\VRP-Town &	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\VRP-Town &	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\VRP-Town &	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2017\VRP-Town &	RADIO -- Radio	x	x	x	x	x	
2017\VRP-Town &	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2017\VRP-Town &	FSM -- Fold Stow Module	x	x	x	x	x	
2017\VRP-Town &	DVD -- DVD Changer	x	x	x	x		
2017\VRP-Town &	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2017\VRP-Town &	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2017\VRP-Town &	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2017\VRP-Town &	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\VRP-Town &	DMFR -- Door Module Front Right	x	x	x	x	x	
2017\VRP-Town &	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2017\VRP-Town &	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017\VRP-Town &	TCM -- Transmission Control Module	x	x	x	x	x	
2017\VRP-Town &	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2017\VRP-Town &	ECM -- Engine Control Module	x	x	x	x	x	
2017\VRP-Town &	SAS -- Steering Angle Sensor	x	x	x	x		
2017\VRP-Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2017\VRP-Town &	CGW -- Central Gateway	x	x	x	x	x	
2017\VRP-Town &	VES3 -- Last Row Screen	x	x	x	x	x	
2017\VRP-Town &	VRM -- Video Routing Module	x	x	x	x		
2017\RU	TCM -- Transmission Control Module	x	x	x	x		
2017\RU	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\RU	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2017\RU	DSM -- Display Screen Module	x	x	x	x		

2017\RU	AHCP -- Auxiliary Hybrid Control Processor	x	x	x			
2017\RU	ECM -- Engine Control Module	x	x	x	x	x	
2017\RU	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2017\RU	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2017\RU	APM -- Adjustable Pedal Module	x	x	x	x		
2017\RU	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\RU	AMP -- Amplifier	x	x	x	x	x	
2017\RU	EAC -- Electric A/C Compressor	x	x	x	x		
2017\RU	PSDML -- Power Sliding Doors (Left)	x	x	x	x	x	
2017\RU	HSM -- Heated Seat Module	x	x	x	x	x	
2017\RU	ABSO -- Anti Lock Brakes OBD	x	x	x	x	x	
2017\RU	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\RU	HVACR -- Heat, Ventilation and A/C Rear	x	x	x	x	x	
2017\RU	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\RU	ANC -- Active Noise Cancelation	x	x	x	x	x	
2017\RU	CVPM -- Central vision processing module	x	x	x	x		
2017\RU	EBBM -- Electronic Brake Booster Module	x	x	x	x		
2017\RU	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\RU	MSMP -- Memory Seat Module - Passenger	x	x	x	x		
2017\RU	PTS -- Parktronics	x	x	x	x	x	
2017\RU	RADIO -- Radio	x	x	x	x	x	
2017\RU	ESM -- Electronic Shifter	x	x	x	x	x	
2017\RU	OCM -- Occupant Classification	x	x	x	x		
2017\RU	EAM -- Emergency Assistance Module	x	x	x	x	x	
2017\RU	RBSS -- Right Blind Spot Sensor	x	x	x			
2017\RU	OBCM -- On Board Charging Module	x	x	x	x		
2017\RU	SCCM -- Steering Column Control Module	x	x	x	x		
2017\RU	LBSS -- Left Blind Spot Sensor	x	x	x			
2017\RU	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\RU	BCM -- Body Controller	x	x	x	x	x	
2017\RU	EDM -- External Disc Module	x	x	x	x	x	
2017\RU	PSDMR -- Power Sliding Doors (Right)	x	x	x	x	x	
2017\RU	EPS -- Electric Power Steering	x	x	x	x		
2017\RU	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\RU	FSM -- Fold Stow Module	x	x	x	x	x	
2017\RU	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\RU	ESL -- Electronic Steering Lock	x	x	x	x		
2017\RU	DDM -- Driver Door Module	x	x	x	x	x	
2017\RU	HCP -- Hybrid Control Processor	x	x	x	x	x	
2017\RU	DMRL -- Rear Door Module (Left)	x	x	x	x	x	

2017\RU	PDM -- Passenger Door Module	x	x	x	x	x	
2017\RU	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\RU	AHLM -- Headlamp Leveling	x	x	x	x	x	
2017\RU	EOMR -- Electronic Overhead Module Rear	x	x	x	x	x	
2017\UF-200	EPS -- Electric Power Steering	x	x	x	x		
2017\UF-200	RADIO -- Radio	x	x	x	x	x	
2017\UF-200	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\UF-200	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2017\UF-200	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2017\UF-200	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\UF-200	RRM -- Radio Receiver Module	x	x	x	x		
2017\UF-200	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\UF-200	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\UF-200	PTU -- Power Transfer Unit	x	x	x			
2017\UF-200	SCCM -- Steering Column Control Module	x	x	x	x		
2017\UF-200	PAM -- Park Assist Module	x	x	x	x	x	
2017\UF-200	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2017\UF-200	ECM -- Engine Control Module	x	x	x	x	x	
2017\UF-200	PDM -- Passenger Door Module	x	x	x	x	x	
2017\UF-200	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2017\UF-200	EPB -- Electrical Parking Brake	x	x	x	x		
2017\UF-200	DDM -- Driver Door Module	x	x	x	x	x	
2017\UF-200	AMP -- Amplifier	x	x	x	x		
2017\UF-200	TCM -- Transmission Control Module	x	x	x	x		
2017\UF-200	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017\UF-200	BCM -- Body Controller	x	x	x	x	x	
2017\UF-200	ESM -- Electronic Shifter	x	x	x	x		
2017\UF-200	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\UF-200	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\UF-200	OCM -- Occupant Classification	x	x	x	x		
2017\UF-200	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\UF-200	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\VF-ProMaster	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\VF-ProMaster	BCM -- Body Controller	x	x	x	x	x	
2017\VF-ProMaster	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\VF-ProMaster	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\VF-ProMaster	EPB -- Electrical Parking Brake	x	x	x	x	x	
2017\VF-ProMaster	TCM -- Transmission Control Module	x	x	x	x	x	
2017\VF-ProMaster	ECM -- Engine Control Module	x	x	x	x	x	0007

2017\VF-ProMaster	RADIO -- Radio	x	x	x	x	x	
2017\VF-ProMaster	PAM -- Park Assist Module	x	x	x	x		
2017\VF-ProMaster	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2017\VF-ProMaster	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\VF-ProMaster	TTM -- Trailer tow module	x	x	x	x		
2017\VF-ProMaster	ESM -- Electronic Shifter	x	x	x	x	x	
2017\VF-ProMaster	TCM -- Transmission Control Module	x	x	x	x		
2017\VF-ProMaster	PAM -- Park Assist Module	x	x	x	x		
2017\VF-ProMaster	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\VF-ProMaster	RADIO -- Radio	x	x	x	x	x	
2017\VF-ProMaster	ECM -- Engine Control Module	x	x	x	x	x	
2017\VF-ProMaster	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\VF-ProMaster	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\VF-ProMaster	BCM -- Body Controller	x	x	x	x	x	
2017\VF-ProMaster	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2017\VF-ProMaster	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2017\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2017\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2017\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2017\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2017\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\WD-Durango	RBSS -- Right Blind Spot Sensor	x	x	x			
2017\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017\WD-Durango	EDM -- External Disc Module	x	x	x	x	x	
2017\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2017\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	x	x	x	x	x	
2017\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2017\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			
2017\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2017\WD-Durango	AMP -- Amplifier	x	x	x	x		
2017\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x		
2017\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2017\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2017\WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	

2017WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2017WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2017WD-Durango	ESM -- Electronic Shifter	x	x	x	x	x	
2017WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2017WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2017WD-Durango	RADIO -- Radio	x	x	x	x	x	
2017WD-Durango	ESM -- Electronic Shifter	x	x	x	x	x	
2017WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2017WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2017WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2017WD-Durango	EDM -- External Disc Module	x	x	x	x	x	
2017WD-Durango	RADIO -- Radio	x	x	x	x	x	
2017WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2017WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2017WD-Durango	EAM -- Emergency Assistance Module	x	x	x	x	x	
2017WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2017WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2017WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2017WD-Durango	ANC -- Active Noise Cancelation	x	x	x	x		
2017WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2017WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2017WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2017WD-Durango	ASCM -- Air Suspension Control Module	x	x	x	x		
2017WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2017WD-Durango	DTV -- Digital Television	x	x	x	x	x	
2017WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2017WD-Durango	AMP -- Amplifier	x	x	x	x	x	
2017WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2017WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2017WD-Durango	RBSS -- Right Blind Spot Sensor	x	x	x			
2017WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2017WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2017WD-Durango	AFLS -- Adaptive Front Lighting System	x	x	x	x		
2017WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2017WD-Durango	ICS -- Integrated Center Stack	x	x	x	x	x	

2017\WR-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\WR-Grand Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x			
2017\WR-Grand Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2017\WR-Grand Cherokee	BCM -- Body Controller	x	x	x	x	x	
2017\WR-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2017\WR-Grand Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	ABS -- Anti Lock Brakes	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	TPM -- Tire Pressure Monitor	x	x	x	x		
2017\Z0-Viper (Post 2013)	PDM -- Passenger Door Module	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	OCM -- Occupant Classification	x	x	x	x		
2017\Z0-Viper (Post 2013)	DDM -- Driver Door Module	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	ICS -- Integrated Center Stack	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	RFH -- Radio Frequency Hub	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	RADIO -- Radio	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	ADCM -- Active Damping Control Module	x	x	x	x		
2017\Z0-Viper (Post 2013)	BCM -- Body Controller	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	ECM -- Engine Control Module	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2017\Z0-Viper (Post 2013)	SCCM -- Steering Column Control Module	x	x	x	x		
2017\Z0-Viper (Post 2013)	AMP -- Amplifier	x	x	x	x		
2016\4C	ECM -- Engine Control Module	x	x	x	x	x	
2016\4C	TCM -- Transmission Control Module	x	x	x	x		
2016\4C	BCM -- Body Controller	x	x	x	x	x	
2016\4C	PAM -- Park Assist Module	x	x	x	x		
2016\4C	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\4C	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\4C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\4C	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\B1-Renegade	ESM -- Electronic Shifter	x	x	x	x	x	
2016\B1-Renegade	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\B1-Renegade	ESL -- Electronic Steering Lock		x	x	x		
2016\B1-Renegade	PAM -- Park Assist Module	x	x	x	x		
2016\B1-Renegade	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2016\B1-Renegade	RRM -- Radio Receiver Module	x	x	x	x	x	
2016\B1-Renegade	ECM -- Engine Control Module	x	x	x	x	x	
2016\B1-Renegade	TCM -- Transmission Control Module	x	x	x	x		
2016\B1-Renegade	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\B1-Renegade	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2016\B1-Renegade	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2016\B1-Renegade	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\B1-Renegade	EPS -- Electric Power Steering	x	x	x	x		
2016\B1-Renegade	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2016\B1-Renegade	DTCM -- Drive Train Control Module	x	x	x	x		
2016\B1-Renegade	HALF -- Haptical Lane Feedback	x	x	x	x		
2016\B1-Renegade	BCM -- Body Controller	x	x	x	x	x	
2016\B1-Renegade	AMP -- Amplifier	x	x	x	x	x	
2016\B1-Renegade	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2016\B1-Renegade	TTM -- Trailer tow module	x	x	x	x	x	
2016\B1-Renegade	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2016\B1-Renegade	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x	x	
2016\BF-Fiat 500L	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2016\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	
2016\BF-Fiat 500L	PAM -- Park Assist Module	x	x	x	x		
2016\BF-Fiat 500L	EPS -- Electric Power Steering	x	x	x	x		
2016\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x		
2016\BF-Fiat 500L	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2016\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	
2016\BF-Fiat 500L	ESM -- Electronic Shifter	x	x	x	x	x	
2016\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\B0-Renegade	ECM -- Engine Control Module	x	x	x	x	x	
2016\B0-Renegade	TCM -- Transmission Control Module	x	x	x	x		
2016\B0-Renegade	HALF -- Haptical Lane Feedback	x	x	x	x		
2016\B0-Renegade	ESM -- Electronic Shifter	x	x	x	x	x	
2016\B0-Renegade	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\B0-Renegade	RRM -- Radio Receiver Module	x	x	x	x	x	
2016\B0-Renegade	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2016\B0-Renegade	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\B0-Renegade	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\B0-Renegade	ESL -- Electronic Steering Lock		x	x	x		
2016\B0-Renegade	PAM -- Park Assist Module	x	x	x	x		
2016\B0-Renegade	AMP -- Amplifier	x	x	x	x	x	
2016\B0-Renegade	DTCM -- Drive Train Control Module	x	x	x	x		
2016\B0-Renegade	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2016\B0-Renegade	EPS -- Electric Power Steering	x	x	x	x		
2016\B0-Renegade	ACC -- Adaptive Cruise Control	x	x	x	x	x	

2010DD	BCM -- Body Controller	x	x	x	x	x	
2010DD	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2010DD	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2010DD	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2010DD	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010DD	TTM -- Trailer tow module	x	x	x	x	x	
2010DZ-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	

2010 DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
2010 DD-Ram	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2010 DD-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010 DD-Ram	VGT -- Variable Geometry Turbo	x	x	x			
Truck	AMP -- Amplifier	x	x	x	x		
2010 DD-Ram	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
2010 DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2010 DD-Ram	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2500 Cph Chassis	VGT -- Variable Geometry Turbo	x	x	x			
2500 Cph Chassis	PTS -- Parktronics	x	x	x	x	x	
2500 Cph Chassis	ABS -- Anti Lock Brakes	x	x	x	x	x	
2500 Cph Chassis	DDM -- Driver Door Module	x	x	x	x	x	
2500 Cph Chassis	HSM -- Heated Seat Module	x	x	x	x	x	
2500 Cph Chassis	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2500 Cph Chassis	RFH -- Radio Frequency Hub	x	x	x	x	x	
2500 Cph Chassis	DTCM -- Drive Train Control Module	x	x	x	x	x	
2500 Cph Chassis	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2500 Cph Chassis	BCM -- Body Controller	x	x	x	x	x	
2500 Cph Chassis	SCCM -- Steering Column Control Module	x	x	x	x		
2500 Cph Chassis	AMP -- Amplifier	x	x	x	x		
2500 Cph Chassis	DCU -- Dosing Control Unit	x	x	x			
2500 Cph Chassis	TCM -- Transmission Control Module	x	x	x	x	x	
2500 Cph Chassis	RADIO -- Radio	x	x	x	x	x	
2500 Cph Chassis	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2500 Cph Chassis	ICS -- Integrated Center Stack	x	x	x	x	x	
2500 Cph Chassis	PDM -- Passenger Door Module	x	x	x	x	x	
2500 Cph Chassis	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2500 Cph Chassis	EDM -- External Disc Module	x	x	x	x	x	
2500 Cph Chassis	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2500 Cph Chassis	ECM -- Engine Control Module	x	x	x	x	x	
2500 Cph Chassis	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	

Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		

2010DT-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2010DT-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2010DT-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2010DS-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2010DS-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2010DS-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2010DS-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2010DS-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2010DS-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2010DS-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2010DS-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2010DS-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2010DS-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2010DS-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2010DS-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2010DS-Kam	TCM -- Transmission Control Module	x	x	x	x		
Truck							
2010DS-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2010DS-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2010DS-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2010DS-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2010DS-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2010DS-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2010DS-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2010DS-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2010DS-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2010DS-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2010DS-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2010DX-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2010DX-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2010DX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2010DX-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck							
2010DX-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2010DX-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2010DX-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2010DX-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2010DX-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2010DX-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2010DX-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2010DX-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2010DX-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							

2016\BX-Kam	BCM -- Body Controller	x	x	x	x	x	
2016\BX-Kam	EPS -- Electric Power Steering	x	x	x	x		
2016\BX-Kam	EDM -- External Disc Module	x	x	x	x	x	
2016\BX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2016\BX-Kam	ECM -- Engine Control Module	x	x	x	x	x	
2016\BX-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\BX-Kam	RADIO -- Radio	x	x	x	x	x	
2016\BX-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\BX-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
2016\BX-Kam	ESM -- Electronic Shifter	x	x	x	x		
2016\BX-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
2016\BX-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\BX-Kam	AMP -- Amplifier	x	x	x	x		
2016\FB-500X	ECM -- Engine Control Module	x	x	x	x	x	
2016\FB-500X	HALF -- Haptical Lane Feedback	x	x	x	x		
2016\FB-500X	BCM -- Body Controller	x	x	x	x	x	
2016\FB-500X	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2016\FB-500X	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2016\FB-500X	TCM -- Transmission Control Module	x	x	x	x		
2016\FB-500X	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\FB-500X	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2016\FB-500X	DTCM -- Drive Train Control Module	x	x	x	x		
2016\FB-500X	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2016\FB-500X	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\FB-500X	EPS -- Electric Power Steering	x	x	x	x		
2016\FB-500X	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\FB-500X	ESM -- Electronic Shifter	x	x	x	x	x	
2016\FB-500X	ESL -- Electronic Steering Lock		x	x	x		
2016\FB-500X	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\FB-500X	RRM -- Radio Receiver Module	x	x	x	x	x	
2016\FB-500X	PAM -- Park Assist Module	x	x	x	x		
2016\FB-500X	AMP -- Amplifier	x	x	x	x	x	
2016\FB-500X	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2016\FB-500X	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\FF-500	EVCU -- Electronic Vehicle Control Unit	x	x	x	x	x	
2016\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2016\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2016\FF-500	RBC -- Regenerative Brake Controller	x	x	x	x		
2016\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2016\FF-500	OBCM -- On Board Charging Module	x	x	x	x		

2016\FF-500	PTS -- Parktronics	x	x	x	x		
2016\FF-500	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\FF-500	PIM -- Power Inverter Module	x	x	x	x		
2016\FF-500	EAC -- Electric A/C Compressor	x	x	x	x		
2016\FF-500	ESM -- Electronic Shifter	x	x	x			
2016\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2016\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2016\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\FF-500	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2016\FF-500	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2016\FF-500	BCM -- Body Controller	x	x	x	x	x	
2016\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2016\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2016\J8-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2016\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2016\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2016\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2016\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2016\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2016\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	0011, 0010
2016\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2016\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\JC-Journey	VTM -- Vehicle Tracking Module	x	x	x	x		
2016\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2016\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2016\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2016\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2016\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2016\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2016\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\JC-Journey	BCM -- Body Controller	x	x	x	x	x	

2016\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2016\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2016\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2016\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2016\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\JC-Journey	AMP -- Amplifier	x	x	x	x		
2016\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2016\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2016\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2016\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2016\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2016\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	
2016\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2016\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2016\JF-Freemont	VTM -- Vehicle Tracking Module	x	x	x	x		
2016\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2016\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2016\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2016\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2016\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2016\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	0011, 0010
2016\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2016\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2016\JK-Wrangler	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2016\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2016\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2016\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		

2016\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2016\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2016\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2016\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2016\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2016\KL-Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2016\KL-Cherokee	DTV -- Digital Television	x	x	x	x	x	
2016\KL-Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\KL-Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		
2016\KL-Cherokee	PAM -- Park Assist Module	x	x	x	x	x	
2016\KL-Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2016\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\KL-Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\KL-Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2016\KL-Cherokee	EDM -- External Disc Module	x	x	x		x	
2016\KL-Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\KL-Cherokee	OCM -- Occupant Classification	x	x	x	x		
2016\KL-Cherokee	PTU -- Power Transfer Unit	x	x	x			
2016\KL-Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2016\KL-Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2016\KL-Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2016\KL-Cherokee	AHLM -- Headlamp Leveling	x	x	x	x		
2016\KL-Cherokee	BCM -- Body Controller	x	x	x	x	x	
2016\KL-Cherokee	AMP -- Amplifier	x	x	x	x		
2016\KL-Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2016\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2016\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2016\KL-Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2016\KL-Cherokee	EPB -- Electrical Parking Brake	x	x	x	x		
2016\KL-Cherokee	ESL -- Electronic Steering Lock	x	x	x	x		
2016\KL-Cherokee	SCCM -- Steering Column Control Module	x	x	x	x	x	
2016\KL-Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2016\KL-Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2016\KL-Cherokee	RADIO -- Radio	x	x	x	x	x	
2016\KL-Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\KL-Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\KL-Cherokee	RDM -- Rear Drive Module	x	x	x			
2016\KL-Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2016\KL-Challenger	ACC -- Adaptive Cruise Control	x	x	x	x		

2016\LD-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\LD-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2016\LD-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2016\LD-Challenger	SCCM -- Steering Column Control Module	x	x	x	x		
2016\LD-Challenger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2016\LD-Challenger	BCM -- Body Controller	x	x	x	x	x	
2016\LD-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\LD-Challenger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2016\LD-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2016\LD-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\LD-Challenger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2016\LD-Challenger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\LD-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2016\LD-Challenger	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\LD-Challenger	AMP -- Amplifier	x	x	x	x	x	
2016\LD-Challenger	RADIO -- Radio	x	x	x	x	x	
2016\LD-Challenger	ADCM -- Active Damping Control Module	x	x	x	x		
2016\LD-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\LD-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2016\LD-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2016\LD-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2016\LD-Challenger	PTS -- Parktronics	x	x	x	x	x	
2016\LD-Challenger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2016\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2016\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2016\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2016\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2016\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2016\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2016\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2016\LD-Charger	AMP -- Amplifier	x	x	x	x		
2016\LD-Charger	DSM -- Display Screen Module	x	x	x	x		
2016\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2016\LD-Charger	RADIO -- Radio	x	x	x	x	x	
2016\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	

2016\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2016\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2016\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2016\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2016\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2016\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2016\LD-Charger	FFCM -- Forward Facing Camera Module	x	x	x	x		
2016\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2016\LD-Charger	RADIO -- Radio	x	x	x	x	x	
2016\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2016\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2016\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2016\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2016\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2016\LD-Charger	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2016\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2016\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2016\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2016\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\LD-Charger	AMP -- Amplifier	x	x	x	x	x	
2016\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2016\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2016\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2016\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2016\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2016\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2016\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2016\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\LD-Charger	FFCM -- Forward Facing Camera Module	x	x	x	x		

2016\WR-Compass Patriot	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\WR-Compass Patriot	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2016\WR-Compass Patriot	RADIO -- Radio	x	x	x	x	x	
2016\WR-Compass Patriot	TCM -- Transmission Control Module	x	x	x	x	x	
2016\WR-Compass Patriot	SAS -- Steering Angle Sensor	x	x	x	x		
2016\WR-Compass Patriot	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2016\WR-Compass Patriot	ECM -- Engine Control Module	x	x	x	x	x	
2016\WR-Compass Patriot	HFM -- Hands Free Module	x	x	x	x	x	
2016\WR-Compass Patriot	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\WR-Compass Patriot	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\WR-Compass Patriot	CGW -- Central Gateway	x	x	x	x	x	
2016\WR-Compass Patriot	WCM/TPMS -- Wireless Control	x	x	x	x		
2016\WR-Compass Patriot	AMP -- Amplifier	x	x	x	x		
2016\WR-Compass Patriot	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2016\NY-Ypsilon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\NY-Ypsilon	ECM -- Engine Control Module	x	x	x	x	x	
2016\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2016\NY-Ypsilon	AHM -- Additional Heater Module	x	x	x	x	x	
2016\NY-Ypsilon	TCM -- Transmission Control Module	x	x	x	x	x	
2016\NY-Ypsilon	EPS -- Electric Power Steering	x	x	x	x		
2016\NY-Ypsilon	BCM -- Body Controller	x	x	x	x	x	
2016\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\NY-Ypsilon	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\PF-Dart	CTM -- Convergence Telematic Module	x	x	x	x		
2016\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2016\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2016\PF-Dart	PAM -- Park Assist Module	x	x	x	x		
2016\PF-Dart	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2016\PF-Dart	SCCM -- Steering Column Control Module	x	x	x	x		
2016\PF-Dart	OCM -- Occupant Classification	x	x	x	x		
2016\PF-Dart	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\PF-Dart	EPS -- Electric Power Steering	x	x	x	x		
2016\PF-Dart	BCM -- Body Controller	x	x	x	x	x	
2016\PF-Dart	EDM -- External Disc Module	x	x	x		x	
2016\PF-Dart	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2016\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\PF-Dart	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\PF-Dart	AMP -- Amplifier	x	x	x	x		

2016\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2016\PF-Dart	ESM -- Electronic Shifter	x	x	x	x		
2016\PF-Dart	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\PF-Dart	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2016\PF-Dart	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2016\PF-Dart	TPM -- Tire Pressure Monitor	x	x	x	x		
2016\PF-Dart	SAS -- Steering Angle Sensor	x	x	x	x		
2016\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2016\PF-Dart	DVD -- DVD Changer	x	x	x	x		
2016\PF-Dart	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2016\PF-Dart	PEM -- Passive Entry Module	x	x	x	x		
2016\PF-Dart	DMFL -- Door Module Front Left	x	x	x	x	x	
2016\PF-Dart	VES2 -- Second Row Screen	x	x	x	x	x	
2016\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2016\PF-Dart	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2016\PF-Dart	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2016\PF-Dart	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2016\PF-Dart	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2016\PF-Dart	HFM -- Hands Free Module	x	x	x	x	x	
2016\PF-Dart	VES3 -- Last Row Screen	x	x	x	x	x	
2016\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\PF-Dart	PLGM -- Power Liftgate Module	x	x	x	x	x	
2016\PF-Dart	AMP -- Amplifier	x	x	x	x		
2016\PF-Dart	DMFR -- Door Module Front Right	x	x	x	x	x	
2016\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2016\PF-Dart	CGW -- Central Gateway	x	x	x	x	x	
2016\PF-Dart	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2016\PF-Dart	FSM -- Fold Stow Module	x	x	x	x	x	
2016\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\PF-Dart	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2016\PF-Dart	SUNR -- Sunroof	x	x	x	x	x	
2016\PF-Dart	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\UF-200	OCM -- Occupant Classification	x	x	x	x		
2016\UF-200	PTU -- Power Transfer Unit	x	x	x			
2016\UF-200	EPB -- Electrical Parking Brake	x	x	x	x		
2016\UF-200	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2016\UF-200	PDM -- Passenger Door Module	x	x	x	x	x	
2016\UF-200	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\UF-200	FFCM -- Forward Facing Camera Module	x	x	x	x		

2016\UF-200	SCCM -- Steering Column Control Module	x	x	x	x		
2016\UF-200	TCM -- Transmission Control Module	x	x	x	x		
2016\UF-200	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2016\UF-200	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2016\UF-200	EPS -- Electric Power Steering	x	x	x	x		
2016\UF-200	ACC -- Adaptive Cruise Control	x	x	x	x		
2016\UF-200	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\UF-200	RRM -- Radio Receiver Module	x	x	x	x		
2016\UF-200	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2016\UF-200	ECM -- Engine Control Module	x	x	x	x	x	
2016\UF-200	DDM -- Driver Door Module	x	x	x	x	x	
2016\UF-200	AMP -- Amplifier	x	x	x	x		
2016\UF-200	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\UF-200	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\UF-200	RADIO -- Radio	x	x	x	x	x	
2016\UF-200	PAM -- Park Assist Module	x	x	x	x	x	
2016\UF-200	ESM -- Electronic Shifter	x	x	x	x		
2016\UF-200	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2016\UF-200	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\UF-200	BCM -- Body Controller	x	x	x	x	x	
2016\UF-200	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\VF-ProMaster	PAM -- Park Assist Module	x	x	x	x		
2016\VF-ProMaster	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\VF-ProMaster	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\VF-ProMaster	RADIO -- Radio	x	x	x	x	x	
2016\VF-ProMaster	ECM -- Engine Control Module	x	x	x	x	x	0007
2016\VF-ProMaster	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2016\VF-ProMaster	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2016\VF-ProMaster	BCM -- Body Controller	x	x	x	x	x	
2016\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\VF-ProMaster	TCM -- Transmission Control Module	x	x	x	x	x	
2016\VF-ProMaster	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\VF-ProMaster	ECM -- Engine Control Module	x	x	x	x	x	
2016\VF-ProMaster	TCM -- Transmission Control Module	x	x	x	x		
2016\VF-ProMaster	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\VF-ProMaster	BCM -- Body Controller	x	x	x	x	x	
2016\VF-ProMaster	RADIO -- Radio	x	x	x	x	x	
2016\VF-ProMaster	TTM -- Trailer tow module	x	x	x	x		
2016\VF-ProMaster	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2010Viper	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2010Viper	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2010Viper	ESM -- Electronic Shifter	x	x	x	x	x	
2010Viper	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2010Viper	PAM -- Park Assist Module	x	x	x	x		
2010Viper	TPM -- Tire Pressure Monitor	x	x	x	x		
2010Viper	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2010Viper	ECM -- Engine Control Module	x	x	x	x	x	
2010Viper	AMP -- Amplifier	x	x	x	x		
2010Viper	ICS -- Integrated Center Stack	x	x	x	x	x	
2010Viper	DDM -- Driver Door Module	x	x	x	x	x	
2010Viper	RFH -- Radio Frequency Hub	x	x	x	x	x	
2010Viper	PDM -- Passenger Door Module	x	x	x	x	x	
2010Viper	ABS -- Anti Lock Brakes	x	x	x	x	x	
2010Viper	OCM -- Occupant Classification	x	x	x	x		
2010Viper	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2010Viper	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010Viper	SCCM -- Steering Column Control Module	x	x	x	x		
2010Viper	BCM -- Body Controller	x	x	x	x	x	
2010Viper	RADIO -- Radio	x	x	x	x	x	
2010Viper	ADCM -- Active Damping Control Module	x	x	x	x		
2010Viper	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2010Viper	ESL -- Electronic Steering Lock		x	x	x		
2010Viper	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2010Viper	AMP -- Amplifier	x	x	x	x	x	
2010Viper	RRM -- Radio Receiver Module	x	x	x	x	x	
2010Viper	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2010Viper	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2010Viper	TCM -- Transmission Control Module	x	x	x	x		
2010Viper	EPS -- Electric Power Steering	x	x	x	x		
2010Viper	ABS -- Anti Lock Brakes	x	x	x	x	x	
2010Viper	DTCM -- Drive Train Control Module	x	x	x	x		
2010Viper	BCM -- Body Controller	x	x	x	x	x	
2010Viper	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2010Viper	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010Viper	PAM -- Park Assist Module	x	x	x	x		
2010Viper	ESM -- Electronic Shifter	x	x	x	x		
2010Viper	ECM -- Engine Control Module	x	x	x	x	x	
2010Viper	TTM -- Trailer tow module	x	x	x	x	x	
2010Viper	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2016\Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\Durango	HALF -- Haptical Lane Feedback	x	x	x	x		
2016\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2016\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2016\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x	x	
2016\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2016\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			
2016\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2016\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2016\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2016\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2016\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2016\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2016\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x		
2016\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2016\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2016\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2016\WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2016\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	x	x	x	x	x	
2016\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2016\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2016\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2016\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2016\WD-Durango	EDM -- External Disc Module	x	x	x	x	x	
2016\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2016\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2016\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2016\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2016\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2016\WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2016\WD-Durango	AMP -- Amplifier	x	x	x	x		
2016\WD-Durango	RBSS -- Right Blind Spot Sensor	x	x	x			
2016\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2016\WD-Durango	ESM -- Electronic Shifter	x	x	x	x		
2016\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2016\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2016\WD-Durango	AMP -- Amplifier	x	x	x	x	x	
2016\WD-Durango	ASCM -- Air Suspension Control Module	x	x	x	x		
2016\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			

2010\WK-Grand Cherokee	VES2 -- Second Row Screen	x	x	x	x	x	
2010\WK-Grand Cherokee	SCCM -- Steering Column Control Module	x	x	x	x		
2010\WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\WK-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2010\WK-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2010\WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010\WK-Grand Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2010\WK-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2010\WK-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\WK-Grand Cherokee	TPM -- Tire Pressure Monitor	x	x	x	x		
2010\WK-Grand Cherokee	AFLS -- Adaptive Front Lighting System	x	x	x	x		
2010\WK-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2010\WK-Grand Cherokee	RADIO -- Radio	x	x	x	x	x	
2010\WK-Grand Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2010\WK-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2010\WK-Grand Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2010\WK-Grand Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2010\WK-Grand Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x			
2010\WK-Grand Cherokee	EDM -- External Disc Module	x	x	x	x	x	
2010\WK-Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2010\WK-Grand Cherokee	DTV -- Digital Television	x	x	x	x	x	
2010\WK-Grand Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2010\WK-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2010\WK-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2010\WK-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2010\WK-Grand Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		
2010\WK-Grand Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2010\WK-Grand Cherokee	ANC -- Active Noise Cancelation	x	x	x	x		
2010\WK-Grand Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2010\WK-Grand Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\4C	ECM -- Engine Control Module	x	x	x	x	x	
2015\4C	TCM -- Transmission Control Module	x	x	x	x		
2015\4C	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\4C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\4C	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\4C	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\4C	BCM -- Body Controller	x	x	x	x	x	
2015\4C	PAM -- Park Assist Module	x	x	x	x		
2015\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	

2015\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x	x	
2015\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x		
2015\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\BF-Fiat 500L	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2015\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	
2015\BF-Fiat 500L	EPS -- Electric Power Steering	x	x	x	x		
2015\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\BF-Fiat 500L	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2015\BF-Fiat 500L	PAM -- Park Assist Module	x	x	x	x		
2015\BF-Fiat 500L	ESM -- Electronic Shifter	x	x	x	x	x	
2015\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	
2015\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x		
2015\BF-Fiat 500L	DTCM -- Drive Train Control Module	x	x	x	x		
2015\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	
2015\BF-Fiat 500L	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\BF-Fiat 500L	ESL -- Electronic Steering Lock		x	x	x		
2015\BF-Fiat 500L	EPS -- Electric Power Steering	x	x	x	x		
2015\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\BF-Fiat 500L	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2015\BF-Fiat 500L	ACC -- Adaptive Cruise Control	x	x	x	x	x	
2015\BF-Fiat 500L	PAM -- Park Assist Module	x	x	x	x		
2015\BF-Fiat 500L	ESM -- Electronic Shifter	x	x	x	x	x	
2015\BF-Fiat 500L	AMP -- Amplifier	x	x	x	x	x	
2015\BF-Fiat 500L	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2015\BF-Fiat 500L	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2015\BF-Fiat 500L	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2015\BF-Fiat 500L	HALF -- Haptical Lane Feedback	x	x	x	x		
2015\BF-Fiat 500L	RRM -- Radio Receiver Module	x	x	x	x	x	
2015\BF-Fiat 500L	TTM -- Trailer tow module	x	x	x	x	x	
2015\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	
2015\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x	x	
2015\BF-Fiat 500L	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2015\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	

Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	

2013DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
2013DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013DD-Ram	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013DD-Ram	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
2013DD-Ram	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013DD-Ram	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013DD-Ram	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
2013DD-Ram	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
2013DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2013DD-Ram	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
2013DD-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
2013DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2013DD-Ram	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2013DD-Ram	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
2013DD-Ram	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
2013DD-Ram	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
2013DD-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2013DD-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	

Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x		
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	EPS -- Electric Power Steering	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	ESM -- Electronic Shifter	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	

2015\BX-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
2015\BX-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
2015\BX-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2015\BX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
2015\BX-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	ESM -- Electronic Shifter	x	x	x	x		
2015\BX-Kam	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2015\BX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
2015\BX-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2015\BX-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
2015\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2015\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2015\FF-500	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2015\FF-500	BCM -- Body Controller	x	x	x	x	x	
2015\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2015\FF-500	PTS -- Parktronics	x	x	x	x		
2015\FF-500	RADIO -- Radio	x	x	x	x	x	
2015\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\FF-500	EVCU -- Electronic Vehicle Control Unit	x	x	x	x	x	
2015\FF-500	ESM -- Electronic Shifter	x	x	x			
2015\FF-500	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2015\FF-500	EAC -- Electric A/C Compressor	x	x	x	x		
2015\FF-500	OBCM -- On Board Charging Module	x	x	x	x		
2015\FF-500	CTM -- Convergence Telematic Module	x	x	x	x	x	
2015\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2015\FF-500	RBC -- Regenerative Brake Controller	x	x	x	x		
2015\FF-500	PIM -- Power Inverter Module	x	x	x	x		
2015\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2015\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		

2015\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2015\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2015\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2015\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2015\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2015\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2015\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\J8-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2015\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2015\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2015\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2015\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2015\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2015\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2015\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2015\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2015\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\JC-Journey	AMP -- Amplifier	x	x	x	x		
2015\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2015\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2015\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2015\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2015\JC-Journey	VTM -- Vehicle Tracking Module	x	x	x	x		
2015\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2015\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	
2015\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	

2015\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2015\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2015\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2015\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2015\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2015\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2015\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2015\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2015\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2015\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2015\JF-Freemont	VTM -- Vehicle Tracking Module	x	x	x	x		
2015\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2015\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2015\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2015\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2015\JK-Wrangler	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2015\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2015\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2015\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2015\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2015\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2015\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2015\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2015\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2015\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2015\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2015\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2015\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2015\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2015\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2015\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	

2015\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2015\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2015\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2015\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2015\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2015\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2015\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2015\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2015\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2015\KL-Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2015\KL-Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2015\KL-Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\KL-Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\KL-Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2015\KL-Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\KL-Cherokee	EPB -- Electrical Parking Brake	x	x	x	x		
2015\KL-Cherokee	BCM -- Body Controller	x	x	x	x	x	
2015\KL-Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\KL-Cherokee	ESL -- Electronic Steering Lock	x	x	x	x		
2015\KL-Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2015\KL-Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\KL-Cherokee	RADIO -- Radio	x	x	x	x	x	
2015\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\KL-Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\KL-Cherokee	PTU -- Power Transfer Unit	x	x	x			
2015\KL-Cherokee	SCCM -- Steering Column Control Module	x	x	x	x	x	
2015\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2015\KL-Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2015\KL-Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2015\KL-Cherokee	PAM -- Park Assist Module	x	x	x	x	x	
2015\KL-Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2015\KL-Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2015\KL-Cherokee	OCM -- Occupant Classification	x	x	x	x		
2015\KL-Cherokee	AHLM -- Headlamp Leveling	x	x	x	x		
2015\KL-Cherokee	AMP -- Amplifier	x	x	x	x		
2015\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2015\KL-Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		

2015\KL-Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\KL-Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\KL-Cherokee	RDM -- Rear Drive Module	x	x	x			
2015\KL-Cherokee	EDM -- External Disc Module	x	x	x		x	
2015\KL-Cherokee	DTV -- Digital Television	x	x	x	x	x	
2015\KL-Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2015\KL-Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2015\KL-Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\KL-Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\KL-Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\KL-Cherokee	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\KL-Cherokee	BCM -- Body Controller	x	x	x	x	x	
2015\KL-Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\KL-Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2015\KL-Cherokee	PTS -- Parktronics	x	x	x	x		
2015\KL-Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\KL-Cherokee	RADIO -- Radio	x	x	x	x	x	
2015\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\KL-Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\KL-Cherokee	SCCM -- Steering Column Control Module	x	x	x	x		
2015\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\KL-Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2015\KL-Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2015\KL-Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2015\KL-Cherokee	AMP -- Amplifier	x	x	x	x		
2015\KL-Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2015\KL-Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2015\KL-Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\KL-Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2015\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2015\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2015\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2015\LD-Charger	PTS -- Parktronics	x	x	x	x		

2015\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\LD-Charger	RADIO -- Radio	x	x	x	x	x	
2015\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2015\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2015\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2015\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2015\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\LD-Charger	AMP -- Amplifier	x	x	x	x		
2015\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2015\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2015\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2015\LD-Charger	FFCM -- Forward Facing Camera Module	x	x	x	x		
2015\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2015\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2015\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2015\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2015\LD-Charger	PTS -- Parktronics	x	x	x	x		
2015\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\LD-Charger	RADIO -- Radio	x	x	x	x	x	
2015\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\LD-Charger	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2015\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2015\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2015\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2015\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2015\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\LD-Charger	AMP -- Amplifier	x	x	x	x		

2015\EX-	HSM -- Heated Seat Module	x	x	x	x	x	
2015\EX-	ADCM -- Active Damping Control Module	x	x	x	x		
2015\EX-	FFCM -- Forward Facing Camera Module	x	x	x	x		
2015\EX-	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\EX-	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\EX-	ECM -- Engine Control Module	x	x	x	x	x	
2015\EX-	TCM -- Transmission Control Module	x	x	x	x	x	
2015\EX-	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2015\EX-	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\EX-	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2015\EX-	CGW -- Central Gateway	x	x	x	x	x	
2015\EX-	WCM/TPMS -- Wireless Control	x	x	x	x		
2015\EX-	SAS -- Steering Angle Sensor	x	x	x	x		
2015\EX-	RADIO -- Radio	x	x	x	x	x	
2015\EX-	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\EX-	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2015\EX-	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\EX-	AMP -- Amplifier	x	x	x	x		
2015\EX-	HFM -- Hands Free Module	x	x	x	x	x	
2015\NY-Ypsilon	ECM -- Engine Control Module	x	x	x	x	x	
2015\NY-Ypsilon	TCM -- Transmission Control Module	x	x	x	x	x	
2015\NY-Ypsilon	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2015\NY-Ypsilon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\NY-Ypsilon	BCM -- Body Controller	x	x	x	x	x	
2015\NY-Ypsilon	EPS -- Electric Power Steering	x	x	x	x		
2015\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\NY-Ypsilon	AHM -- Additional Heater Module	x	x	x	x	x	
2015\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2015\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2015\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\PF-Dart	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\PF-Dart	BCM -- Body Controller	x	x	x	x	x	
2015\PF-Dart	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\PF-Dart	EPS -- Electric Power Steering	x	x	x	x		
2015\PF-Dart	ICS -- Integrated Center Stack	x	x	x	x	x	
2015\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2015\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\PF-Dart	SCCM -- Steering Column Control Module	x	x	x	x		

2015\PF-Dart	PAM -- Park Assist Module	x	x	x	x		
2015\PF-Dart	ESM -- Electronic Shifter	x	x	x	x		
2015\PF-Dart	OCM -- Occupant Classification	x	x	x	x		
2015\PF-Dart	AMP -- Amplifier	x	x	x	x		
2015\PF-Dart	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2015\PF-Dart	CTM -- Convergence Telematic Module	x	x	x	x		
2015\PF-Dart	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2015\PF-Dart	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2015\PF-Dart	EDM -- External Disc Module	x	x	x		x	
2015\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2015\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2015\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\PF-Dart	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2015\PF-Dart	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\PF-Dart	CGW -- Central Gateway	x	x	x	x	x	
2015\PF-Dart	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2015\PF-Dart	SAS -- Steering Angle Sensor	x	x	x	x		
2015\PF-Dart	PTS -- Parktronics	x	x	x	x	x	
2015\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2015\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\PF-Dart	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\PF-Dart	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2015\PF-Dart	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2015\PF-Dart	DMFR -- Door Module Front Right	x	x	x	x	x	
2015\PF-Dart	DMFL -- Door Module Front Left	x	x	x	x	x	
2015\PF-Dart	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2015\PF-Dart	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2015\PF-Dart	PLGM -- Power Liftgate Module	x	x	x	x	x	
2015\PF-Dart	FSM -- Fold Stow Module	x	x	x	x	x	
2015\PF-Dart	SUNR -- Sunroof	x	x	x	x	x	
2015\PF-Dart	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2015\PF-Dart	AHBM -- Automatic High Beam	x	x	x	x	x	
2015\PF-Dart	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\PF-Dart	DVD -- DVD Changer	x	x	x	x		
2015\PF-Dart	AMP -- Amplifier	x	x	x	x		
2015\PF-Dart	HFM -- Hands Free Module	x	x	x	x	x	
2015\PF-Dart	VES2 -- Second Row Screen	x	x	x	x	x	
2015\PF-Dart	VES3 -- Last Row Screen	x	x	x	x	x	
2015\PF-Dart	HSM -- Heated Seat Module	x	x	x	x	x	

2015\VF-ProMaster	Caravan Town &	PEM -- Passive Entry Module	x	x	x	x		
2015\VF-ProMaster	Caravan Town &	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2015\VF-ProMaster	Caravan Town &	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\VF-ProMaster	Caravan Town &	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\UF-200		ECM -- Engine Control Module	x	x	x	x	x	
2015\UF-200		TCM -- Transmission Control Module	x	x	x	x		
2015\UF-200		DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\UF-200		ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\UF-200		ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2015\UF-200		IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\UF-200		EPB -- Electrical Parking Brake	x	x	x	x		
2015\UF-200		BCM -- Body Controller	x	x	x	x	x	
2015\UF-200		RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\UF-200		EPS -- Electric Power Steering	x	x	x	x		
2015\UF-200		ICS -- Integrated Center Stack	x	x	x	x	x	
2015\UF-200		RADIO -- Radio	x	x	x	x	x	
2015\UF-200		HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\UF-200		ACC -- Adaptive Cruise Control	x	x	x	x		
2015\UF-200		PTU -- Power Transfer Unit	x	x	x			
2015\UF-200		SCCM -- Steering Column Control Module	x	x	x	x		
2015\UF-200		MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2015\UF-200		DDM -- Driver Door Module	x	x	x	x	x	
2015\UF-200		PDM -- Passenger Door Module	x	x	x	x	x	
2015\UF-200		PAM -- Park Assist Module	x	x	x	x	x	
2015\UF-200		ESM -- Electronic Shifter	x	x	x	x		
2015\UF-200		OCM -- Occupant Classification	x	x	x	x		
2015\UF-200		AMP -- Amplifier	x	x	x	x		
2015\UF-200		CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2015\UF-200		FFCM -- Forward Facing Camera Module	x	x	x	x		
2015\UF-200		LBSS -- Left Blind Spot Sensor	x	x	x	x		
2015\UF-200		RBSS -- Right Blind Spot Sensor	x	x	x	x		
2015\UF-200		RRM -- Radio Receiver Module	x	x	x	x		
2015\VF-ProMaster		ECM -- Engine Control Module	x	x	x	x	x	0007
2015\VF-ProMaster		TCM -- Transmission Control Module	x	x	x	x	x	
2015\VF-ProMaster		ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\VF-ProMaster		ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\VF-ProMaster		IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\VF-ProMaster		TPM -- Tire Pressure Monitor	x	x	x	x	x	
2015\VF-ProMaster		BCM -- Body Controller	x	x	x	x	x	
2015\VF-ProMaster		HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2015\VF-ProMaster	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2015\VF-ProMaster	PAM -- Park Assist Module	x	x	x	x		
2015\VF-ProMaster City	ECM -- Engine Control Module	x	x	x	x	x	
2015\VF-ProMaster City	TCM -- Transmission Control Module	x	x	x	x		
2015\VF-ProMaster City	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\VF-ProMaster City	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\VF-ProMaster City	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\VF-ProMaster City	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2015\VF-ProMaster City	BCM -- Body Controller	x	x	x	x	x	
2015\VF-ProMaster City	RADIO -- Radio	x	x	x	x	x	
2015\VF-ProMaster City	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\VF-ProMaster City	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2015\VF-ProMaster City	PAM -- Park Assist Module	x	x	x	x		
2015\VF-ProMaster City	ESM -- Electronic Shifter	x	x	x	x	x	
2015\VF-ProMaster City	TTM -- Trailer tow module	x	x	x	x		
2015\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2015\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2015\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2015\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2015\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2015\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x		
2015\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2015\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	x	x	x	x	x	
2015\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2015\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2015\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2015\WD-Durango	ESM -- Electronic Shifter	x	x	x	x		
2015\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2015\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x		
2015\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\WD-Durango	AMP -- Amplifier	x	x	x	x		

2015\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2015\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2015\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2015\WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2015\WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2015\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			
2015\WD-Durango	RBSS -- Right Blind Spot Sensor	x	x	x			
2015\WD-Durango	EDM -- External Disc Module	x	x	x	x	x	
2015\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2015\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2015\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2015\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2015\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2015\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2015\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2015\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2015\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2015\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2015\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2015\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x		
2015\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2015\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2015\WD-Durango	AFLS -- Adaptive Front Lighting System	x	x	x	x		
2015\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2015\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2015\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2015\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2015\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2015\WD-Durango	ESM -- Electronic Shifter	x	x	x	x		
2015\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2015\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2015\WD-Durango	AMP -- Amplifier	x	x	x	x		
2015\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2015\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2015\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2015\WD-Durango	ADCM -- Active Damping Control Module	x	x	x	x		
2015\WD-Durango	ASCM -- Air Suspension Control Module	x	x	x	x		
2015\WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2015\WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2015\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			

2013\WR-Grand Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x			
2013\WR-Grand Cherokee	EDM -- External Disc Module	x	x	x	x	x	
2013\WR-Grand Cherokee	ANC -- Active Noise Cancelation	x	x	x	x		
2013\WR-Grand Cherokee	DTV -- Digital Television	x	x	x	x	x	
2013\2014 Viper (Post 2013)	ECM -- Engine Control Module	x	x	x	x	x	
2013\2014 Viper (Post 2013)	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\2014 Viper (Post 2013)	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2013\2014 Viper (Post 2013)	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\2014 Viper (Post 2013)	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\2014 Viper (Post 2013)	BCM -- Body Controller	x	x	x	x	x	
2013\2014 Viper (Post 2013)	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\2014 Viper (Post 2013)	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\2014 Viper (Post 2013)	RADIO -- Radio	x	x	x	x	x	
2013\2014 Viper (Post 2013)	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\2014 Viper (Post 2013)	SCCM -- Steering Column Control Module	x	x	x	x		
2013\2014 Viper (Post 2013)	DDM -- Driver Door Module	x	x	x	x	x	
2013\2014 Viper (Post 2013)	PDM -- Passenger Door Module	x	x	x	x	x	
2013\2014 Viper (Post 2013)	OCM -- Occupant Classification	x	x	x	x		
2013\2014 Viper (Post 2013)	AMP -- Amplifier	x	x	x	x		
2013\2014 Viper (Post 2013)	ADCM -- Active Damping Control Module	x	x	x	x		
2014\4C	ECM -- Engine Control Module	x	x	x	x	x	
2014\4C	TCM -- Transmission Control Module	x	x	x	x		
2014\4C	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\4C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\4C	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\4C	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\4C	BCM -- Body Controller	x	x	x	x	x	
2014\4C	PAM -- Park Assist Module	x	x	x	x		
2014\BF-Fiat 500L	ECM -- Engine Control Module	x	x	x	x	x	
2014\BF-Fiat 500L	TCM -- Transmission Control Module	x	x	x	x	x	
2014\BF-Fiat 500L	ABS -- Anti Lock Brakes	x	x	x	x		
2014\BF-Fiat 500L	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\BF-Fiat 500L	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\BF-Fiat 500L	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2014\BF-Fiat 500L	BCM -- Body Controller	x	x	x	x	x	
2014\BF-Fiat 500L	EPS -- Electric Power Steering	x	x	x	x		
2014\BF-Fiat 500L	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\BF-Fiat 500L	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2014\BF-Fiat 500L	PAM -- Park Assist Module	x	x	x	x		
2014\BF-Fiat 500L	ESM -- Electronic Shifter	x	x	x	x	x	

2014DZ-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DZ-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2014DZ-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014DZ-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014DZ-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014DZ-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014DZ-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014DZ-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2014DZ-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014DZ-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014DZ-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2014DZ-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014DZ-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014DZ-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014DZ-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014DZ-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2014DZ-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2014DZ-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014DZ-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014DZ-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2014DZ-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck							
2014DZ-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2014DZ-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2014DZ-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014DD-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DD-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2014DD-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014DD-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014DD-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014DD-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014DD-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014DD-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2014DD-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014DD-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014DD-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2014DD-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014DD-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014DD-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014DD-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014DD-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							

2014DD-Ram	AMP -- Amplifier	x	x	x	x		
Truck							
2014DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014DD-Ram	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014DD-Ram	DCU -- Dosing Control Unit	x	x	x			
Truck							
2014DD-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2014DD-Ram	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2014DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014DD-Ram	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014DD-Ram	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014DD-Ram	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2014DD-Ram	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014DD-Ram	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014DD-Ram	RADIO -- Radio	x	x	x	x	x	
Truck							
2014DD-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014DD-Ram	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014DD-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014DD-Ram	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014DD-Ram	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2014DD-Ram	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck							
2014DD-Ram	AMP -- Amplifier	x	x	x	x		
Truck							
2014DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014DD-Ram	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014DD-Ram	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2014DD-Ram	DCU -- Dosing Control Unit	x	x	x			
Truck							
2014DD-Ram	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2014DD-Ram	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2014DD-Ram	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014DD-Ram	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014DD-Ram	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014DD-Ram	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							

2014DR-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014DR-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014DR-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2014DR-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014DR-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014DR-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014DR-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014DR-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2014DR-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2014DR-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014DR-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014DR-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck							
2014DR-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2014DR-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2014DR-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014DS-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DS-Kam	TCM -- Transmission Control Module	x	x	x	x		
Truck							
2014DS-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014DS-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014DS-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014DS-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014DS-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014DS-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2014DS-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2014DS-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014DS-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014DS-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2014DS-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014DS-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014DS-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014DS-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014DS-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2014DS-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2014DS-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2014DS-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014DS-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014DS-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2014DS-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014DX-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2014DX-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							

2014\BX-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2014\BX-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2014\BX-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2014\BX-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2014\BX-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2014\BX-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2014\BX-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2014\BX-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2014\BX-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2014\BX-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2014\BX-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2014\BX-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2014\BX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2014\BX-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2014\BX-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2014\BX-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2014\BX-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2014\BX-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2014\BX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2014\BX-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2014\BX-Kam	DCU -- Dosing Control Unit	x	x	x			
Truck							
2014\BX-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck							
2014\BX-Kam	VGT -- Variable Geometry Turbo	x	x	x			
Truck							
2014\BX-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2014\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2014\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2014\FF-500	ABS -- Anti Lock Brakes	x	x	x	x		
2014\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2014\FF-500	BCM -- Body Controller	x	x	x	x	x	
2014\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2014\FF-500	PTS -- Parktronics	x	x	x	x		
2014\FF-500	RADIO -- Radio	x	x	x	x	x	
2014\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\FF-500	EVCU -- Electronic Vehicle Control Unit	x	x	x	x	x	
2014\FF-500	ESM -- Electronic Shifter	x	x	x			
2014\FF-500	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2014\FF-500	EAC -- Electric A/C Compressor	x	x	x	x		
2014\FF-500	OBCM -- On Board Charging Module	x	x	x	x		

2014\FF-500	CTM -- Convergence Telematic Module	x	x	x	x	x	
2014\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2014\FF-500	RBC -- Regenerative Brake Controller	x	x	x	x		
2014\FF-500	PIM -- Power Inverter Module	x	x	x	x		
2014\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2014\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2014\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2014\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2014\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2014\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2014\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2014\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\J8-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2014\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2014\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2014\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2014\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2014\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2014\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2014\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2014\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2014\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\JC-Journey	AMP -- Amplifier	x	x	x	x		
2014\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2014\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2014\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2014\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2014\JC-Journey	VTM -- Vehicle Tracking Module	x	x	x	x		
2014\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2014\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	

2014\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2014\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2014\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2014\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2014\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2014\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2014\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2014\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2014\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2014\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2014\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2014\JF-Freemont	VTM -- Vehicle Tracking Module	x	x	x	x		
2014\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2014\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2014\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2014\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\JK-Wrangler	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2014\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2014\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2014\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2014\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2014\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2014\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2014\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2014\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2014\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2014\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2014\SS-Avenger-Sebring C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\SS-Avenger-Sebring C	CGW -- Central Gateway	x	x	x	x	x	
2014\SS-Avenger-Sebring C	WCM/TPMS -- Wireless Control	x	x	x	x		
2014\SS-Avenger-Sebring C	SAS -- Steering Angle Sensor	x	x	x	x		
2014\SS-Avenger-Sebring C	RADIO -- Radio	x	x	x	x	x	
2014\SS-Avenger-Sebring C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\SS-Avenger-Sebring C	DDM -- Driver Door Module	x	x	x	x	x	
2014\SS-Avenger-Sebring C	PDM -- Passenger Door Module	x	x	x	x	x	
2014\SS-Avenger-Sebring C	PTCM -- Power Top Control Module	x	x	x	x		
2014\SS-Avenger-Sebring C	AMP -- Amplifier	x	x	x	x		
2014\SS-Avenger-Sebring C	HFM -- Hands Free Module	x	x	x	x	x	
2014\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2014\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2014\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2014\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2014\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2014\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2014\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2014\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2014\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2014\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2014\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2014\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2014\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2014\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2014\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2014\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2014\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2014\KL-Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2014\KL-Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2014\KL-Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\KL-Cherokee	ABS -- Anti Lock Brakes	x	x	x	x		
2014\KL-Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2014\KL-Cherokee	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\KL-Cherokee	EPB -- Electrical Parking Brake	x	x	x	x		
2014\KL-Cherokee	BCM -- Body Controller	x	x	x	x	x	

2014\KL-Cherokee	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\KL-Cherokee	ESL -- Electronic Steering Lock	x	x	x	x		
2014\KL-Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2014\KL-Cherokee	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\KL-Cherokee	RADIO -- Radio	x	x	x	x	x	
2014\KL-Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\KL-Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2014\KL-Cherokee	PTU -- Power Transfer Unit	x	x	x			
2014\KL-Cherokee	SCCM -- Steering Column Control Module	x	x	x	x	x	
2014\KL-Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2014\KL-Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2014\KL-Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2014\KL-Cherokee	PAM -- Park Assist Module	x	x	x	x	x	
2014\KL-Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2014\KL-Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2014\KL-Cherokee	OCM -- Occupant Classification	x	x	x	x		
2014\KL-Cherokee	AHLM -- Headlamp Leveling	x	x	x	x		
2014\KL-Cherokee	AMP -- Amplifier	x	x	x	x		
2014\KL-Cherokee	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2014\KL-Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		
2014\KL-Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2014\KL-Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2014\KL-Cherokee	RDM -- Rear Drive Module	x	x	x			
2014\KL-Cherokee	EDM -- External Disc Module	x	x	x		x	
2014\LC-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2014\LC-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2014\LC-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\LC-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\LC-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\LC-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2014\LC-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2014\LC-Challenger	SAS -- Steering Angle Sensor	x	x	x	x	x	
2014\LC-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2014\LC-Challenger	PTS -- Parktronics	x	x	x	x		
2014\LC-Challenger	RADIO -- Radio	x	x	x	x	x	
2014\LC-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\LC-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2014\LC-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2014\LC-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	

2014\LD-Challenger	SUNR -- Sunroof	x	x	x	x	x	
2014\LD-Challenger	EOM -- Electronic Overhead	x	x	x	x		
2014\LD-Challenger	AMP -- Amplifier	x	x	x	x		
2014\LD-Challenger	HFM -- Hands Free Module	x	x	x	x	x	
2014\LD-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2014\LD-Challenger	PEM -- Passive Entry Module	x	x	x	x		
2014\LD-Challenger	ADCM -- Active Damping Control Module	x	x	x	x		
2014\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2014\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2014\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2014\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2014\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2014\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2014\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2014\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2014\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2014\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2014\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2014\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2014\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\LD-Charger	AMP -- Amplifier	x	x	x	x		
2014\LD-Charger	HFM -- Hands Free Module	x	x	x	x		
2014\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2014\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2014\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2014\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2014\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2014\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2014\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2014\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		

2014\EX-	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\EX-	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\EX-	BCM -- Body Controller	x	x	x	x	x	
2014\EX-	TGW -- Telematic Gateway Radio	x	x	x	x		
2014\EX-	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\EX-	EPS -- Electric Power Steering	x	x	x	x		
2014\EX-	PTS -- Parktronics	x	x	x	x	x	
2014\EX-	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\EX-	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\EX-	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2014\EX-	ACC -- Adaptive Cruise Control	x	x	x	x		
2014\EX-	SCCM -- Steering Column Control Module	x	x	x	x		
2014\EX-	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2014\EX-	DDM -- Driver Door Module	x	x	x	x	x	
2014\EX-	PDM -- Passenger Door Module	x	x	x	x	x	
2014\EX-	ESM -- Electronic Shifter	x	x	x	x	x	
2014\EX-	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\EX-	AMP -- Amplifier	x	x	x	x		
2014\EX-	HFM -- Hands Free Module	x	x	x	x		
2014\EX-	HSM -- Heated Seat Module	x	x	x	x	x	
2014\EX-	ADCM -- Active Damping Control Module	x	x	x	x		
2014\EX-	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2014\EX-	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2014\EX-	ECM -- Engine Control Module	x	x	x	x	x	
2014\EX-	TCM -- Transmission Control Module	x	x	x	x	x	
2014\EX-	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2014\EX-	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\EX-	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\EX-	CGW -- Central Gateway	x	x	x	x	x	
2014\EX-	WCM/TPMS -- Wireless Control	x	x	x	x		
2014\EX-	SAS -- Steering Angle Sensor	x	x	x	x		
2014\EX-	RADIO -- Radio	x	x	x	x	x	
2014\EX-	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\EX-	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2014\EX-	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\EX-	AMP -- Amplifier	x	x	x	x		
2014\EX-	HFM -- Hands Free Module	x	x	x	x	x	
2014\EX-	ECM -- Engine Control Module	x	x	x	x	x	
2014\EX-	TCM -- Transmission Control Module	x	x	x	x	x	
2014\EX-	ABS -- Anti Lock Brakes	x	x	x	x	x	

2014\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2014\NY-Ypsilon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\NY-Ypsilon	BCM -- Body Controller	x	x	x	x	x	
2014\NY-Ypsilon	EPS -- Electric Power Steering	x	x	x	x		
2014\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\NY-Ypsilon	AHM -- Additional Heater Module	x	x	x	x	x	
2014\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2014\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2014\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\PF-Dart	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\PF-Dart	BCM -- Body Controller	x	x	x	x	x	
2014\PF-Dart	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\PF-Dart	EPS -- Electric Power Steering	x	x	x	x		
2014\PF-Dart	ICS -- Integrated Center Stack	x	x	x	x	x	
2014\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2014\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\PF-Dart	SCCM -- Steering Column Control Module	x	x	x	x		
2014\PF-Dart	PAM -- Park Assist Module	x	x	x	x		
2014\PF-Dart	ESM -- Electronic Shifter	x	x	x	x		
2014\PF-Dart	OCM -- Occupant Classification	x	x	x	x		
2014\PF-Dart	AMP -- Amplifier	x	x	x	x		
2014\PF-Dart	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2014\PF-Dart	CTM -- Convergence Telematic Module	x	x	x	x		
2014\PF-Dart	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2014\PF-Dart	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2014\PF-Dart	EDM -- External Disc Module	x	x	x		x	
2014\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2014\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2014\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2014\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2014\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2014\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2014\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2014\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2014\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	

2014\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2014\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2014\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2014\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2014\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2014\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2014\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2014\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2014\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2014\RM-Routan	AMP -- Amplifier	x	x	x	x		
2014\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2014\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2014\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	
2014\RM-Routan	HSM -- Heated Seat Module	x	x	x	x	x	
2014\RM-Routan	PEM -- Passive Entry Module	x	x	x	x		
2014\RM-Routan	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2014\RM-Routan	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2014\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
Coravan Town &	TCM -- Transmission Control Module	x	x	x	x	x	
Coravan Town &	ABS -- Anti Lock Brakes	x	x	x	x	x	
Coravan Town &	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Coravan Town &	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Coravan Town &	TPM -- Tire Pressure Monitor	x	x	x	x		
Coravan Town &	CGW -- Central Gateway	x	x	x	x	x	
Coravan Town &	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Coravan Town &	SAS -- Steering Angle Sensor	x	x	x	x		
Coravan Town &	PTS -- Parktronics	x	x	x	x	x	
Coravan Town &	RADIO -- Radio	x	x	x	x	x	
Coravan Town &	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Coravan Town &	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Coravan Town &	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
Coravan Town &	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
Coravan Town &	DMFR -- Door Module Front Right	x	x	x	x	x	
Coravan Town &	DMFL -- Door Module Front Left	x	x	x	x	x	
Coravan Town &	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
Coravan Town &	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
Coravan Town &	PLGM -- Power Liftgate Module	x	x	x	x	x	
Coravan Town &	FSM -- Fold Stow Module	x	x	x	x	x	
Coravan Town &	SUNR -- Sunroof	x	x	x	x	x	
Coravan Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	

2014\KT-Coraven Town 8	AHBM -- Automatic High Beam	x	x	x	x	x	
2014\KT-Coraven Town 8	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\KT-Coraven Town 8	DVD -- DVD Changer	x	x	x	x		
2014\KT-Coraven Town 8	AMP -- Amplifier	x	x	x	x		
2014\KT-Coraven Town 8	HFM -- Hands Free Module	x	x	x	x	x	
2014\KT-Coraven Town 8	VES2 -- Second Row Screen	x	x	x	x	x	
2014\KT-Coraven Town 8	VES3 -- Last Row Screen	x	x	x	x	x	
2014\KT-Coraven Town 8	HSM -- Heated Seat Module	x	x	x	x	x	
2014\KT-Coraven Town 8	PEM -- Passive Entry Module	x	x	x	x		
2014\KT-Coraven Town 8	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2014\KT-Coraven Town 8	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2014\KT-Coraven Town 8	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2014\VF-ProMaster	ECM -- Engine Control Module	x	x	x	x	x	0007
2014\VF-ProMaster	TCM -- Transmission Control Module	x	x	x	x	x	
2014\VF-ProMaster	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\VF-ProMaster	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\VF-ProMaster	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\VF-ProMaster	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2014\VF-ProMaster	BCM -- Body Controller	x	x	x	x	x	
2014\VF-ProMaster	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\VF-ProMaster	ETM -- Entertainment Telematic Module	x	x	x	x	x	
2014\VF-ProMaster	PAM -- Park Assist Module	x	x	x	x		
2014\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2014\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2014\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2014\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2014\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2014\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x		
2014\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2014\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\WD-Durango	HVACR -- Heat, Ventilation and A/C Rear	x	x	x	x	x	
2014\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2014\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2014\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	

2014\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2014\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2014\WD-Durango	ESM -- Electronic Shifter	x	x	x	x		
2014\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2014\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x		
2014\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\WD-Durango	AMP -- Amplifier	x	x	x	x		
2014\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	
2014\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2014\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2014\WD-Durango	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2014\WD-Durango	FFCM -- Forward Facing Camera Module	x	x	x	x		
2014\WD-Durango	LBSS -- Left Blind Spot Sensor	x	x	x			
2014\WD-Durango	RBSS -- Right Blind Spot Sensor	x	x	x			
2014\WD-Durango	EDM -- External Disc Module	x	x	x	x	x	
2014\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2014\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2014\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2014\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2014\WD-Durango	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2014\WD-Durango	BCM -- Body Controller	x	x	x	x	x	
2014\WD-Durango	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2014\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2014\WD-Durango	ICS -- Integrated Center Stack	x	x	x	x		
2014\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2014\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014\WD-Durango	AFLS -- Adaptive Front Lighting System	x	x	x	x		
2014\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2014\WD-Durango	SCCM -- Steering Column Control Module	x	x	x	x		
2014\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2014\WD-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2014\WD-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2014\WD-Durango	ESM -- Electronic Shifter	x	x	x	x		
2014\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2014\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2014\WD-Durango	AMP -- Amplifier	x	x	x	x		
2014\WD-Durango	VES2 -- Second Row Screen	x	x	x	x	x	

2014WR-Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2014WR-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2014WR-Grand Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2014WR-Grand Cherokee	ASCM -- Air Suspension Control Module	x	x	x	x		
2014WR-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2014WR-Grand Cherokee	FFCM -- Forward Facing Camera Module	x	x	x	x		
2014WR-Grand Cherokee	LBSS -- Left Blind Spot Sensor	x	x	x			
2014WR-Grand Cherokee	RBSS -- Right Blind Spot Sensor	x	x	x			
2014WR-Grand Cherokee	EDM -- External Disc Module	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	ECM -- Engine Control Module	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	ABS -- Anti Lock Brakes	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	TPM -- Tire Pressure Monitor	x	x	x	x		
2014Z-Viper (Rnst 2013)	BCM -- Body Controller	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	RFH -- Radio Frequency Hub	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	ICS -- Integrated Center Stack	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	RADIO -- Radio	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	SCCM -- Steering Column Control Module	x	x	x	x		
2014Z-Viper (Rnst 2013)	DDM -- Driver Door Module	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	PDM -- Passenger Door Module	x	x	x	x	x	
2014Z-Viper (Rnst 2013)	OCM -- Occupant Classification	x	x	x	x		
2014Z-Viper (Rnst 2013)	AMP -- Amplifier	x	x	x	x		
2014Z-Viper (Rnst 2013)	ADCM -- Active Damping Control Module	x	x	x	x		
2013DZ-Ram Truck	ECM -- Engine Control Module	x	x	x	x	x	
2013DZ-Ram Truck	TCM -- Transmission Control Module	x	x	x	x	x	
2013DZ-Ram Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013DZ-Ram Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013DZ-Ram Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2013DZ-Ram Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013DZ-Ram Truck	BCM -- Body Controller	x	x	x	x	x	
2013DZ-Ram Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013DZ-Ram Truck	PTS -- Parktronics	x	x	x	x	x	
2013DZ-Ram Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
2013DZ-Ram Truck	RADIO -- Radio	x	x	x	x	x	
2013DZ-Ram Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013DZ-Ram Truck	SCCM -- Steering Column Control Module	x	x	x	x		
2013DZ-Ram Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013DZ-Ram Truck	DDM -- Driver Door Module	x	x	x	x	x	

Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	BCM -- Body Controller	x	x	x	x	x	

Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			
Truck	EDM -- External Disc Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck	BCM -- Body Controller	x	x	x	x	x	
Truck	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	SCCM -- Steering Column Control Module	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DDM -- Driver Door Module	x	x	x	x	x	
Truck	PDM -- Passenger Door Module	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x	x	x			
Truck	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
Truck	VGT -- Variable Geometry Turbo	x	x	x			

2013DL-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2013DL-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2013DL-Kam	TCM -- Transmission Control Module	x	x	x	x		
Truck							
2013DL-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2013DL-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2013DL-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2013DL-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2013DL-Kam	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck							
2013DL-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2013DL-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2013DL-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2013DL-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2013DL-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2013DL-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2013DL-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2013DL-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							
2013DL-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2013DL-Kam	DDM -- Driver Door Module	x	x	x	x	x	
Truck							
2013DL-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
Truck							
2013DL-Kam	ESM -- Electronic Shifter	x	x	x	x		
Truck							
2013DL-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2013DL-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2013DL-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2013DL-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
Truck							
2013DL-Kam	EDM -- External Disc Module	x	x	x	x	x	
Truck							
2013DL-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2013DL-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2013DL-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2013DL-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	
Truck							
2013DL-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
Truck							
2013DL-Kam	IPC -- Instrument Panel Cluster	x	x	x	x	x	
Truck							
2013DL-Kam	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck							
2013DL-Kam	BCM -- Body Controller	x	x	x	x	x	
Truck							
2013DL-Kam	RFH -- Radio Frequency Hub	x	x	x	x	x	
Truck							
2013DL-Kam	EPS -- Electric Power Steering	x	x	x	x		
Truck							
2013DL-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2013DL-Kam	ICS -- Integrated Center Stack	x	x	x	x	x	
Truck							
2013DL-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2013DL-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2013DL-Kam	SCCM -- Steering Column Control Module	x	x	x	x		
Truck							

2013\DX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\DX-Kam	DDM -- Driver Door Module	x	x	x	x	x	
2013\DX-Kam	PDM -- Passenger Door Module	x	x	x	x	x	
2013\DX-Kam	ESM -- Electronic Shifter	x	x	x	x		
2013\DX-Kam	AMP -- Amplifier	x	x	x	x		
2013\DX-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
2013\DX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2013\DX-Kam	ASCM -- Air Suspension Control Module	x	x	x	x		
2013\DX-Kam	DCU -- Dosing Control Unit	x	x	x			
2013\DX-Kam	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2013\DX-Kam	VGT -- Variable Geometry Turbo	x	x	x			
2013\DX-Kam	EDM -- External Disc Module	x	x	x	x	x	
2013\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2013\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2013\FF-500	ABS -- Anti Lock Brakes	x	x	x	x		
2013\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2013\FF-500	BCM -- Body Controller	x	x	x	x	x	
2013\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2013\FF-500	PTS -- Parktronics	x	x	x	x		
2013\FF-500	RADIO -- Radio	x	x	x	x	x	
2013\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\FF-500	EVCU -- Electronic Vehicle Control Unit	x	x	x	x	x	
2013\FF-500	ESM -- Electronic Shifter	x	x	x			
2013\FF-500	BPCM -- Battery Pack Control Module	x	x	x	x	x	
2013\FF-500	EAC -- Electric A/C Compressor	x	x	x	x		
2013\FF-500	OBCM -- On Board Charging Module	x	x	x	x		
2013\FF-500	CTM -- Convergence Telematic Module	x	x	x	x	x	
2013\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2013\FF-500	RBC -- Regenerative Brake Controller	x	x	x	x		
2013\FF-500	PIM -- Power Inverter Module	x	x	x	x		
2013\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2013\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2013\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2013\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2013\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		

2013\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2013\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\J8-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2013\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2013\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2013\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2013\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2013\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2013\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2013\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2013\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2013\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\JC-Journey	AMP -- Amplifier	x	x	x	x		
2013\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2013\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2013\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2013\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2013\JC-Journey	VTM -- Vehicle Tracking Module	x	x	x	x		
2013\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2013\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	
2013\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2013\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2013\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2013\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		

2013\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2013\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2013\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2013\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2013\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2013\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2013\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2013\JF-Freemont	VTM -- Vehicle Tracking Module	x	x	x	x		
2013\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2013\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2013\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\JK-Wrangler	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2013\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2013\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2013\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2013\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2013\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2013\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2013\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2013\SS-Avenger	ECM -- Engine Control Module	x	x	x	x	x	
2013\SS-Avenger	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\SS-Avenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\SS-Avenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\SS-Avenger	CGW -- Central Gateway	x	x	x	x	x	
2013\SS-Avenger	WCM/TPMS -- Wireless Control	x	x	x	x		
2013\SS-Avenger	SAS -- Steering Angle Sensor	x	x	x	x		
2013\SS-Avenger	RADIO -- Radio	x	x	x	x	x	
2013\SS-Avenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\SS-Avenger	DDM -- Driver Door Module	x	x	x	x	x	
2013\SS-Avenger	PDM -- Passenger Door Module	x	x	x	x	x	
2013\SS-Avenger	PTCM -- Power Top Control Module	x	x	x	x		
2013\SS-Avenger	AMP -- Amplifier	x	x	x	x		
2013\SS-Avenger	HFM -- Hands Free Module	x	x	x	x	x	
2013\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	

2013\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2013\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2013\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2013\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2013\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2013\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2013\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2013\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2013\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2013\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2013\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2013\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2013\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2013\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2013\LEO-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2013\LEO-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2013\LEO-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\LEO-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\LEO-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\LEO-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\LEO-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2013\LEO-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2013\LEO-Challenger	SAS -- Steering Angle Sensor	x	x	x	x	x	
2013\LEO-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2013\LEO-Challenger	PTS -- Parktronics	x	x	x	x		
2013\LEO-Challenger	RADIO -- Radio	x	x	x	x	x	
2013\LEO-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\LEO-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2013\LEO-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2013\LEO-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2013\LEO-Challenger	SUNR -- Sunroof	x	x	x	x	x	
2013\LEO-Challenger	EOM -- Electronic Overhead	x	x	x	x		
2013\LEO-Challenger	AMP -- Amplifier	x	x	x	x		
2013\LEO-Challenger	HFM -- Hands Free Module	x	x	x	x	x	

2013\LD-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2013\LD-Challenger	PEM -- Passive Entry Module	x	x	x	x		
2013\LD-Challenger	ADCM -- Active Damping Control Module	x	x	x	x		
2013\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2013\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2013\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2013\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2013\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2013\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2013\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2013\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2013\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2013\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2013\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2013\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\LD-Charger	AMP -- Amplifier	x	x	x	x		
2013\LD-Charger	HFM -- Hands Free Module	x	x	x	x		
2013\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2013\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2013\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2013\LD-Charger	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2013\LD-Charger	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2013\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2013\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2013\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2013\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		

2013\ELX	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\Charger Maan	EPS -- Electric Power Steering	x	x	x	x		
2013\ELX	PTS -- Parktronics	x	x	x	x	x	
2013\Charger Maan	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\ELX	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\Charger Maan	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2013\ELX	ACC -- Adaptive Cruise Control	x	x	x	x		
2013\Charger Maan	SCCM -- Steering Column Control Module	x	x	x	x		
2013\ELX	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\Charger Maan	DDM -- Driver Door Module	x	x	x	x	x	
2013\ELX	PDM -- Passenger Door Module	x	x	x	x	x	
2013\Charger Maan	ESM -- Electronic Shifter	x	x	x	x	x	
2013\ELX	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\Charger Maan	AMP -- Amplifier	x	x	x	x		
2013\ELX	HFM -- Hands Free Module	x	x	x	x		
2013\Charger Maan	HSM -- Heated Seat Module	x	x	x	x	x	
2013\ELX	ADCM -- Active Damping Control Module	x	x	x	x		
2013\Charger Maan	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2013\ELX	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2013\Charger Maan	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2013\Charger Maan	TCM -- Transmission Control Module	x	x	x	x	x	
2013\Charger Maan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\Charger Maan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\Charger Maan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\Charger Maan	CGW -- Central Gateway	x	x	x	x	x	
2013\Charger Maan	WCM/TPMS -- Wireless Control	x	x	x	x		
2013\Charger Maan	SAS -- Steering Angle Sensor	x	x	x	x		
2013\Charger Maan	RADIO -- Radio	x	x	x	x	x	
2013\Charger Maan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\Charger Maan	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2013\Charger Maan	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\Charger Maan	AMP -- Amplifier	x	x	x	x		
2013\Charger Maan	HFM -- Hands Free Module	x	x	x	x	x	
2013\NY-Ypsilon	ECM -- Engine Control Module	x	x	x	x	x	
2013\NY-Ypsilon	TCM -- Transmission Control Module	x	x	x	x	x	
2013\NY-Ypsilon	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2013\NY-Ypsilon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\NY-Ypsilon	BCM -- Body Controller	x	x	x	x	x	
2013\NY-Ypsilon	EPS -- Electric Power Steering	x	x	x	x		

2013\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\NY-Ypsilon	AHM -- Additional Heater Module	x	x	x	x	x	
2013\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	
2013\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2013\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\PF-Dart	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013\PF-Dart	BCM -- Body Controller	x	x	x	x	x	
2013\PF-Dart	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013\PF-Dart	EPS -- Electric Power Steering	x	x	x	x		
2013\PF-Dart	ICS -- Integrated Center Stack	x	x	x	x	x	
2013\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2013\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\PF-Dart	SCCM -- Steering Column Control Module	x	x	x	x		
2013\PF-Dart	PAM -- Park Assist Module	x	x	x	x		
2013\PF-Dart	ESM -- Electronic Shifter	x	x	x	x		
2013\PF-Dart	OCM -- Occupant Classification	x	x	x	x		
2013\PF-Dart	AMP -- Amplifier	x	x	x	x		
2013\PF-Dart	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2013\PF-Dart	CTM -- Convergence Telematic Module	x	x	x	x		
2013\PF-Dart	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2013\PF-Dart	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2013\PF-Dart	EDM -- External Disc Module	x	x	x		x	
2013\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2013\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2013\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2013\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2013\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2013\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2013\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2013\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2013\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2013\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2013\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		

2013\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2013\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2013\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2013\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2013\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2013\RM-Routan	AMP -- Amplifier	x	x	x	x		
2013\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2013\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2013\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	
2013\RM-Routan	HSM -- Heated Seat Module	x	x	x	x	x	
2013\RM-Routan	PEM -- Passive Entry Module	x	x	x	x		
2013\RM-Routan	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2013\RM-Routan	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2013\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2013\RM-Routan	TCM -- Transmission Control Module	x	x	x	x	x	
2013\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2013\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2013\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2013\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2013\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2013\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2013\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2013\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2013\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2013\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2013\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2013\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2013\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2013\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2013\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2013\RM-Routan	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2013\RM-Routan	AHBM -- Automatic High Beam	x	x	x	x	x	
2013\RM-Routan	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2013\RM-Routan	AMP -- Amplifier	x	x	x	x		

2013\WT-Corvair Town &	HFM -- Hands Free Module	x	x	x	x	x	
2013\WT-Corvair Town &	VES2 -- Second Row Screen	x	x	x	x	x	
2013\WT-Corvair Town &	VES3 -- Last Row Screen	x	x	x	x	x	
2013\WT-Corvair Town &	HSM -- Heated Seat Module	x	x	x	x	x	
2013\WT-Corvair Town &	PEM -- Passive Entry Module	x	x	x	x		
2013\WT-Corvair Town &	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2013\WT-Corvair Town &	LBSS -- Left Blind Spot Sensor	x	x	x	x		
2013\WT-Corvair Town &	RBSS -- Right Blind Spot Sensor	x	x	x	x		
2013\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2013\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2013\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2013\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2013\WD-Durango	CGW -- Central Gateway	x	x	x	x	x	
2013\WD-Durango	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2013\WD-Durango	SAS -- Steering Angle Sensor	x	x	x	x	x	
2013\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2013\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2013\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2013\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2013\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013\WD-Durango	DMFR -- Door Module Front Right	x	x	x	x	x	
2013\WD-Durango	DMFL -- Door Module Front Left	x	x	x	x	x	
2013\WD-Durango	ESM -- Electronic Shifter	x	x	x	x	x	
2013\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2013\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x	x	
2013\WD-Durango	AHBM -- Automatic High Beam	x	x	x	x	x	
2013\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013\WD-Durango	AMP -- Amplifier	x	x	x	x		
2013\WD-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2013\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2013\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2013\WD-Durango	BSM -- Blind Spot Module	x	x	x	x		
2013\WD-Durango	PEM -- Passive Entry Module	x	x	x	x		
2013\WT-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2013\WT-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2013\WT-Grand Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	

2013WVGrand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013WVGrand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2013WVGrand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2013WVGrand Cherokee	TPM -- Tire Pressure Monitor	x	x	x	x		
2013WVGrand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2013WVGrand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2013WVGrand Cherokee	SAS -- Steering Angle Sensor	x	x	x	x	x	
2013WVGrand Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2013WVGrand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2013WVGrand Cherokee	RADIO -- Radio	x	x	x	x	x	
2013WVGrand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013WVGrand Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2013WVGrand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2013WVGrand Cherokee	DMFR -- Door Module Front Right	x	x	x	x	x	
2013WVGrand Cherokee	DMFL -- Door Module Front Left	x	x	x	x	x	
2013WVGrand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2013WVGrand Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2013WVGrand Cherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2013WVGrand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2013WVGrand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2013WVGrand Cherokee	AMP -- Amplifier	x	x	x	x		
2013WVGrand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2013WVGrand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2013WVGrand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2013WVGrand Cherokee	BSM -- Blind Spot Module	x	x	x	x		
2013WVGrand Cherokee	PEM -- Passive Entry Module	x	x	x	x		
2013WVGrand Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2013WVGrand Cherokee	ASCM -- Air Suspension Control Module	x	x	x	x		
2013WVGrand Cherokee	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2013ZD4Viper (Post 2013)	ECM -- Engine Control Module	x	x	x	x	x	
2013ZD4Viper (Post 2013)	ABS -- Anti Lock Brakes	x	x	x	x	x	
2013ZD4Viper (Post 2013)	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2013ZD4Viper (Post 2013)	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2013ZD4Viper (Post 2013)	TPM -- Tire Pressure Monitor	x	x	x	x		
2013ZD4Viper (Post 2013)	BCM -- Body Controller	x	x	x	x	x	
2013ZD4Viper (Post 2013)	RFH -- Radio Frequency Hub	x	x	x	x	x	
2013ZD4Viper (Post 2013)	ICS -- Integrated Center Stack	x	x	x	x	x	
2013ZD4Viper (Post 2013)	RADIO -- Radio	x	x	x	x	x	
2013ZD4Viper (Post 2013)	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2013ZD4Viper (Post 2013)	SCCM -- Steering Column Control Module	x	x	x	x		

2013ZD-Viper	DDM -- Driver Door Module	x	x	x	x	x	
2013ZD-Viper	PDM -- Passenger Door Module	x	x	x	x	x	
2013ZD-Viper	OCM -- Occupant Classification	x	x	x	x		
2013ZD-Viper	AMP -- Amplifier	x	x	x	x		
2013ZD-Viper	ADCM -- Active Damping Control Module	x	x	x	x		
2012DZ-Kam	ECM -- Engine Control Module	x	x	x	x	x	
2012DZ-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012DZ-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012DZ-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012DZ-Kam	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012DZ-Kam	CGW -- Central Gateway	x	x	x	x	x	
2012DZ-Kam	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012DZ-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
2012DZ-Kam	PTS -- Parktronics	x	x	x	x	x	
2012DZ-Kam	RADIO -- Radio	x	x	x	x	x	
2012DZ-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012DZ-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012DZ-Kam	DMFR -- Door Module Front Right	x	x	x	x	x	
2012DZ-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
2012DZ-Kam	AMP -- Amplifier	x	x	x	x		
2012DZ-Kam	HFM -- Hands Free Module	x	x	x	x	x	
2012DZ-Kam	VES3 -- Last Row Screen	x	x	x	x	x	
2012DZ-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
2012DZ-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2012DD-Kam	ECM -- Engine Control Module	x	x	x	x	x	
2012DD-Kam	TCM -- Transmission Control Module	x	x	x	x	x	
2012DD-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012DD-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012DD-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012DD-Kam	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012DD-Kam	CGW -- Central Gateway	x	x	x	x	x	
2012DD-Kam	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012DD-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
2012DD-Kam	RADIO -- Radio	x	x	x	x	x	
2012DD-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012DD-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012DD-Kam	DMFR -- Door Module Front Right	x	x	x	x	x	
2012DD-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
2012DD-Kam	AMP -- Amplifier	x	x	x	x		
2012DD-Kam	HFM -- Hands Free Module	x	x	x	x	x	
Truck							

2012DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2012DD-Ram	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2012DD-Ram	DCU -- Dosing Control Unit	x					
Truck							
2012DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2012DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2012DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck							
2012DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck							
2012DD-Ram	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck							
2012DD-Ram	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck							
2012DD-Ram	CGW -- Central Gateway	x	x	x	x	x	
Truck							
2012DD-Ram	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck							
2012DD-Ram	SAS -- Steering Angle Sensor	x	x	x	x		
Truck							
2012DD-Ram	PTS -- Parktronics	x	x	x	x	x	
Truck							
2012DD-Ram	RADIO -- Radio	x	x	x	x	x	
Truck							
2012DD-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2012DD-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2012DD-Ram	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck							
2012DD-Ram	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck							
2012DD-Ram	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck							
2012DD-Ram	AMP -- Amplifier	x	x	x	x		
Truck							
2012DD-Ram	HFM -- Hands Free Module	x	x	x	x	x	
Truck							
2012DD-Ram	VES3 -- Last Row Screen	x	x	x	x	x	
Truck							
2012DD-Ram	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2012DD-Ram	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2012DD-Ram	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2012DD-Ram	TCM -- Transmission Control Module	x	x	x	x	x	
Truck							
2012DD-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2012DD-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck							
2012DD-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck							
2012DD-Ram	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck							
2012DD-Ram	CGW -- Central Gateway	x	x	x	x	x	
Truck							
2012DD-Ram	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck							
2012DD-Ram	SAS -- Steering Angle Sensor	x	x	x	x		
Truck							
2012DD-Ram	RADIO -- Radio	x	x	x	x	x	
Truck							
2012DD-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2012DD-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2012DD-Ram	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck							
2012DD-Ram	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck							
2012DD-Ram	AMP -- Amplifier	x	x	x	x		
Truck							
2012DD-Ram	HFM -- Hands Free Module	x	x	x	x	x	
Truck							

2012DL-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2012DL-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2012DL-Kam	DCU -- Dosing Control Unit	x					
Truck							
2012DL-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2012DL-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2012DL-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck							
2012DL-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck							
2012DL-Kam	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck							
2012DL-Kam	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck							
2012DL-Kam	CGW -- Central Gateway	x	x	x	x	x	
Truck							
2012DL-Kam	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck							
2012DL-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
Truck							
2012DL-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2012DL-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2012DL-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2012DL-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2012DL-Kam	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck							
2012DL-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck							
2012DL-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2012DL-Kam	HFM -- Hands Free Module	x	x	x	x	x	
Truck							
2012DL-Kam	VES3 -- Last Row Screen	x	x	x	x	x	
Truck							
2012DL-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck							
2012DL-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck							
2012DL-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck							
2012DL-Kam	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck							
2012DL-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck							
2012DL-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck							
2012DL-Kam	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck							
2012DL-Kam	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck							
2012DL-Kam	CGW -- Central Gateway	x	x	x	x	x	
Truck							
2012DL-Kam	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck							
2012DL-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
Truck							
2012DL-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck							
2012DL-Kam	RADIO -- Radio	x	x	x	x	x	
Truck							
2012DL-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck							
2012DL-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck							
2012DL-Kam	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck							
2012DL-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck							
2012DL-Kam	AMP -- Amplifier	x	x	x	x		
Truck							
2012DL-Kam	HFM -- Hands Free Module	x	x	x	x	x	
Truck							

2012\DX-Ram Truck	VES3 -- Last Row Screen	x	x	x	x	x	
2012\DX-Ram Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2012\DX-Ram Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2012\FF-500	ECM -- Engine Control Module	x	x	x	x	x	
2012\FF-500	TCM -- Transmission Control Module	x	x	x	x	x	
2012\FF-500	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\FF-500	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\FF-500	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\FF-500	TPM -- Tire Pressure Monitor	x	x	x	x	x	
2012\FF-500	BCM -- Body Controller	x	x	x	x	x	
2012\FF-500	EPS -- Electric Power Steering	x	x	x	x		
2012\FF-500	PTS -- Parktronics	x	x	x	x		
2012\FF-500	RADIO -- Radio	x	x	x	x	x	
2012\FF-500	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\FF-500	CTM -- Convergence Telematic Module	x	x	x	x	x	
2012\FF-500	VTM -- Vehicle Tracking Module	x	x	x	x		
2012\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2012\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2012\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2012\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2012\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2012\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2012\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2012\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2012\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2012\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2012\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2012\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2012\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		

2012\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2012\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2012\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\JC-Journey	AMP -- Amplifier	x	x	x	x		
2012\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2012\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2012\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2012\JC-Journey	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2012\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2012\JF-Freemont	TCM -- Transmission Control Module	x	x	x	x	x	
2012\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2012\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2012\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2012\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2012\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2012\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2012\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2012\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2012\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2012\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2012\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2012\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2012\JF-Freemont	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2012\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2012\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2012\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2012\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2012\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2012\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2012\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2012\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2012\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2012\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2012\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2012\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2012\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2012\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2012\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\JK-Wrangler	DDM -- Driver Door Module	x	x	x	x	x	
2012\JK-Wrangler	PDM -- Passenger Door Module	x	x	x	x	x	
2012\JK-Wrangler	PTCM -- Power Top Control Module	x	x	x	x		
2012\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2012\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2012\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2012\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2012\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2012\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2012\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2012\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2012\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2012\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2012\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2012\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2012\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2012\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2012\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2012\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001

2012\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2012\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2012\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2012\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2012\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2012\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2012\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2012\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2012\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2012\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2012\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2012\LC-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2012\LC-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2012\LC-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\LC-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\LC-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\LC-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2012\LC-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012\LC-Challenger	SAS -- Steering Angle Sensor	x	x	x	x	x	
2012\LC-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2012\LC-Challenger	RADIO -- Radio	x	x	x	x	x	
2012\LC-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\LC-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2012\LC-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2012\LC-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2012\LC-Challenger	SUNR -- Sunroof	x	x	x	x	x	
2012\LC-Challenger	EOM -- Electronic Overhead	x	x	x	x		
2012\LC-Challenger	AMP -- Amplifier	x	x	x	x		
2012\LC-Challenger	HFM -- Hands Free Module	x	x	x	x	x	
2012\LC-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2012\LC-Challenger	PEM -- Passive Entry Module	x	x	x	x		
2012\LC-Challenger	ADCM -- Active Damping Control Module	x	x	x	x		

2012\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2012\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2012\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2012\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2012\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2012\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2012\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2012\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2012\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2012\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2012\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2012\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2012\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2012\LD-Charger	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\LD-Charger	AMP -- Amplifier	x	x	x	x		
2012\LD-Charger	HFM -- Hands Free Module	x	x	x	x		
2012\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2012\LD-Charger	BSM -- Blind Spot Module	x	x	x	x		
2012\LD-Charger	ADCM -- Active Damping Control Module	x	x	x	x		
2012\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2012\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2012\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2012\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2012\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2012\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2012\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2012\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2012\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	

2012\EX*	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\Charger Maan	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2012\EX*	ACC -- Adaptive Cruise Control	x	x	x	x		
2012\Charger Maan	SCCM -- Steering Column Control Module	x	x	x	x		
2012\EX*	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\Charger Maan	DDM -- Driver Door Module	x	x	x	x	x	
2012\EX*	PDM -- Passenger Door Module	x	x	x	x	x	
2012\Charger Maan	ESM -- Electronic Shifter	x	x	x	x	x	
2012\EX*	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\Charger Maan	AMP -- Amplifier	x	x	x	x		
2012\EX*	HFM -- Hands Free Module	x	x	x	x		
2012\Charger Maan	HSM -- Heated Seat Module	x	x	x	x	x	
2012\EX*	BSM -- Blind Spot Module	x	x	x	x		
2012\Charger Maan	ADCM -- Active Damping Control Module	x	x	x	x		
2012\Charger Maan	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2012\Compass Patriot	TCM -- Transmission Control Module	x	x	x	x	x	
2012\Compass Patriot	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\Compass Patriot	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\Compass Patriot	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\Compass Patriot	CGW -- Central Gateway	x	x	x	x	x	
2012\Compass Patriot	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\Compass Patriot	SAS -- Steering Angle Sensor	x	x	x	x		
2012\Compass Patriot	RADIO -- Radio	x	x	x	x	x	
2012\Compass Patriot	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\Compass Patriot	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2012\Compass Patriot	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\Compass Patriot	AMP -- Amplifier	x	x	x	x		
2012\Compass Patriot	HFM -- Hands Free Module	x	x	x	x	x	
2012\ND-Dakota	ECM -- Engine Control Module	x	x	x	x	x	
2012\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2012\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\ND-Dakota	RADIO -- Radio	x	x	x	x	x	
2012\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2012\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2012\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2012\PF-Dart	ECM -- Engine Control Module	x	x	x	x	x	

2012\PF-Dart	TCM -- Transmission Control Module	x	x	x	x	x	
2012\PF-Dart	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\PF-Dart	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\PF-Dart	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2012\PF-Dart	BCM -- Body Controller	x	x	x	x	x	
2012\PF-Dart	RFH -- Radio Frequency Hub	x	x	x	x	x	
2012\PF-Dart	EPS -- Electric Power Steering	x	x	x	x		
2012\PF-Dart	ICS -- Integrated Center Stack	x	x	x	x	x	
2012\PF-Dart	RADIO -- Radio	x	x	x	x	x	
2012\PF-Dart	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\PF-Dart	SCCM -- Steering Column Control Module	x	x	x	x		
2012\PF-Dart	PAM -- Park Assist Module	x	x	x	x		
2012\PF-Dart	ESM -- Electronic Shifter	x	x	x	x		
2012\PF-Dart	OCM -- Occupant Classification	x	x	x	x		
2012\PF-Dart	AMP -- Amplifier	x	x	x	x		
2012\PF-Dart	CSWM -- Comfort Seat Wheel Module	x	x	x	x	x	
2012\PF-Dart	CTM -- Convergence Telematic Module	x	x	x	x		
2012\PF-Dart	LBSS -- Left Blind Spot Sensor	x	x	x	x	x	
2012\PF-Dart	RBSS -- Right Blind Spot Sensor	x	x	x	x	x	
2012\PF-Dart	EDM -- External Disc Module	x	x	x		x	
2012\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2012\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2012\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2012\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2012\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2012\PM-Caliber	RADIO -- Radio	x	x	x	x	x	
2012\PM-Caliber	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2012\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2012\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2012\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2012\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	

2012\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2012\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2012\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2012\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2012\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2012\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2012\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2012\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2012\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2012\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2012\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2012\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2012\RM-Routan	AMP -- Amplifier	x	x	x	x		
2012\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2012\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2012\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	
2012\RM-Routan	HSM -- Heated Seat Module	x	x	x	x	x	
2012\RM-Routan	BSM -- Blind Spot Module	x	x	x	x		
2012\RM-Routan	PEM -- Passive Entry Module	x	x	x	x		
2012\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2012\RM-Routan	TCM -- Transmission Control Module	x	x	x	x	x	
2012\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2012\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2012\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2012\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2012\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2012\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2012\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2012\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	

2012\RTT-Cor2\RTT-Town &	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	PLGM -- Power Liftgate Module	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	FSM -- Fold Stow Module	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	SUNR -- Sunroof	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	AHBM -- Automatic High Beam	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	DVD -- DVD Changer	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	AMP -- Amplifier	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	HFM -- Hands Free Module	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	VES2 -- Second Row Screen	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	VES3 -- Last Row Screen	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	HSM -- Heated Seat Module	x	x	x	x	x	
2012\RTT-Cor2\RTT-Town &	BSM -- Blind Spot Module	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	PEM -- Passive Entry Module	x	x	x	x		
2012\RTT-Cor2\RTT-Town &	EPPM -- Electronic Pedestrian Protection Module	x	x	x	x		
2012\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2012\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2012\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\WD-Durango	CGW -- Central Gateway	x	x	x	x	x	
2012\WD-Durango	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012\WD-Durango	SAS -- Steering Angle Sensor	x	x	x	x	x	
2012\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2012\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2012\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2012\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2012\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\WD-Durango	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\WD-Durango	DMFL -- Door Module Front Left	x	x	x	x	x	
2012\WD-Durango	ESM -- Electronic Shifter	x	x	x	x	x	
2012\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2012\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x	x	
2012\WD-Durango	AHBM -- Automatic High Beam	x	x	x	x	x	
2012\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	

2012\WD-Durango	AMP -- Amplifier	x	x	x	x		
2012\WD-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2012\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2012\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2012\WD-Durango	BSM -- Blind Spot Module	x	x	x	x		
2012\WD-Durango	PEM -- Passive Entry Module	x	x	x	x		
2012\WVC-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2012\WVC-Grand Cherokee	DTCM -- Drive Train Control Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2012\WVC-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2012\WVC-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2012\WVC-Grand Cherokee	TPM -- Tire Pressure Monitor	x	x	x	x		
2012\WVC-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2012\WVC-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2012\WVC-Grand Cherokee	SAS -- Steering Angle Sensor	x	x	x	x	x	
2012\WVC-Grand Cherokee	EPS -- Electric Power Steering	x	x	x	x		
2012\WVC-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2012\WVC-Grand Cherokee	RADIO -- Radio	x	x	x	x	x	
2012\WVC-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2012\WVC-Grand Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2012\WVC-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2012\WVC-Grand Cherokee	DMFR -- Door Module Front Right	x	x	x	x	x	
2012\WVC-Grand Cherokee	DMFL -- Door Module Front Left	x	x	x	x	x	
2012\WVC-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2012\WVC-Grand Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2012\WVC-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2012\WVC-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2012\WVC-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2012\WVC-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2012\WVC-Grand Cherokee	BSM -- Blind Spot Module	x	x	x	x		
2012\WVC-Grand Cherokee	PEM -- Passive Entry Module	x	x	x	x		
2012\WVC-Grand Cherokee	ADCM -- Active Damping Control Module	x	x	x	x		
2012\WVC-Grand Cherokee	ASCM -- Air Suspension Control Module	x	x	x	x		
2012\WVC-Grand Cherokee	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2011\B24-tram	ECM -- Engine Control Module	x	x	x	x	x	
2011\B24-tram	DTCM -- Drive Train Control Module	x	x	x	x	x	

Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
Truck	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x					
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001

Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
Truck	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	DCU -- Dosing Control Unit	x					
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	TCM -- Transmission Control Module	x	x	x	x		

Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	HGM -- Hybrid Gateway Module	x	x	x	x	x	
Truck	PHGM -- Plug In Hybrid Gateway Module	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	EPS -- Electric Power Steering	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	APM -- Adjustable Pedal Module	x					
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
Truck	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	BPCM -- Battery Pack Control Module	x	x	x	x	x	
Truck	EAC -- Electric A/C Compressor	x	x	x	x		
Truck	HCP -- Hybrid Control Processor	x	x	x	x		
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	MCPA -- Motor Control Processor A	x			x		
Truck	MCPB -- Motor Control Processor B	x			x		
Truck	BTM -- Battery Thermal Module	x	x	x	x	x	
Truck	DRM -- Data Recorder Module	x	x	x	x		
Truck	OBCM -- On Board Charging Module	x	x	x	x	x	
Truck	ECM -- Engine Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	

2011\DX-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
2011\DX-Kam	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\DX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\DX-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
2011\DX-Kam	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
2011\DX-Kam	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2011\DX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2011\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2011\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2011\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2011\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2011\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2011\JC-Journey	DTCM -- Drive Train Control Module	x	x	x	x	x	
2011\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\JC-Journey	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2011\JC-Journey	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\JC-Journey	BCM -- Body Controller	x	x	x	x	x	
2011\JC-Journey	TGW -- Telematic Gateway Radio	x	x	x	x		
2011\JC-Journey	RFH -- Radio Frequency Hub	x	x	x	x	x	
2011\JC-Journey	PTS -- Parktronics	x	x	x	x	x	
2011\JC-Journey	ICS -- Integrated Center Stack	x	x	x	x	x	
2011\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\JC-Journey	SCCM -- Steering Column Control Module	x	x	x	x		
2011\JC-Journey	DDM -- Driver Door Module	x	x	x	x	x	
2011\JC-Journey	PDM -- Passenger Door Module	x	x	x	x	x	
2011\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\JC-Journey	AMP -- Amplifier	x	x	x	x		

2011\JC-Journey	HFM -- Hands Free Module	x	x	x	x		
2011\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2011\JC-Journey	HSM -- Heated Seat Module	x	x	x	x	x	
2011\JF-Freemont	ECM -- Engine Control Module	x	x	x	x	x	
2011\JF-Freemont	DTCM -- Drive Train Control Module	x	x	x	x	x	
2011\JF-Freemont	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\JF-Freemont	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\JF-Freemont	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2011\JF-Freemont	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\JF-Freemont	BCM -- Body Controller	x	x	x	x	x	
2011\JF-Freemont	TGW -- Telematic Gateway Radio	x	x	x	x		
2011\JF-Freemont	RFH -- Radio Frequency Hub	x	x	x	x	x	
2011\JF-Freemont	PTS -- Parktronics	x	x	x	x	x	
2011\JF-Freemont	ICS -- Integrated Center Stack	x	x	x	x	x	
2011\JF-Freemont	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\JF-Freemont	SCCM -- Steering Column Control Module	x	x	x	x		
2011\JF-Freemont	DDM -- Driver Door Module	x	x	x	x	x	
2011\JF-Freemont	PDM -- Passenger Door Module	x	x	x	x	x	
2011\JF-Freemont	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\JF-Freemont	AMP -- Amplifier	x	x	x	x		
2011\JF-Freemont	HFM -- Hands Free Module	x	x	x	x		
2011\JF-Freemont	VES3 -- Last Row Screen	x	x	x	x	x	
2011\JF-Freemont	HSM -- Heated Seat Module	x	x	x	x	x	
2011\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2011\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x		
2011\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2011\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2011\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2011\JK-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\JK-Wrangler	ESM -- Electronic Shifter	x	x	x	x	x	
2011\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2011\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2011\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2011\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2011\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	

2011\SS-Avenger-Sebring C	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\SS-Avenger-Sebring C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\SS-Avenger-Sebring C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\SS-Avenger-Sebring C	CGW -- Central Gateway	x	x	x	x	x	
2011\SS-Avenger-Sebring C	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\SS-Avenger-Sebring C	SAS -- Steering Angle Sensor	x	x	x	x		
2011\SS-Avenger-Sebring C	RADIO -- Radio	x	x	x	x	x	
2011\SS-Avenger-Sebring C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\SS-Avenger-Sebring C	DDM -- Driver Door Module	x	x	x	x	x	
2011\SS-Avenger-Sebring C	PDM -- Passenger Door Module	x	x	x	x	x	
2011\SS-Avenger-Sebring C	ESM -- Electronic Shifter	x	x	x	x	x	
2011\SS-Avenger-Sebring C	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2011\SS-Avenger-Sebring C	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\SS-Avenger-Sebring C	PTCM -- Power Top Control Module	x	x	x	x		
2011\SS-Avenger-Sebring C	AMP -- Amplifier	x	x	x	x		
2011\SS-Avenger-Sebring C	HFM -- Hands Free Module	x	x	x	x	x	
2011\SS-Avenger-Sebring C	VES3 -- Last Row Screen	x	x	x	x	x	
2011\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2011\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2011\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2011\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2011\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2011\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2011\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2011\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2011\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2011\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2011\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2011\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2011\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2011\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	

2011\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2011\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2011\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2011\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2011\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2011\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2011\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2011\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2011\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2011\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2011\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2011\LD-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2011\LD-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2011\LD-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\LD-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\LD-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\LD-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\LD-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2011\LD-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2011\LD-Challenger	SAS -- Steering Angle Sensor	x	x	x	x	x	
2011\LD-Challenger	EPS -- Electric Power Steering	x	x	x	x		
2011\LD-Challenger	RADIO -- Radio	x	x	x	x	x	
2011\LD-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\LD-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2011\LD-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2011\LD-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2011\LD-Challenger	SUNR -- Sunroof	x	x	x	x	x	
2011\LD-Challenger	EOM -- Electronic Overhead	x	x	x	x		
2011\LD-Challenger	AMP -- Amplifier	x	x	x	x		
2011\LD-Challenger	HFM -- Hands Free Module	x	x	x	x	x	
2011\LD-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2011\LD-Challenger	PEM -- Passive Entry Module	x	x	x	x		
2011\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2011\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2011\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	

2011\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2011\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2011\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2011\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2011\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2011\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2011\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2011\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2011\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2011\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011\LD-Charger	DDM -- Driver Door Module	x	x	x	x	x	
2011\LD-Charger	PDM -- Passenger Door Module	x	x	x	x	x	
2011\LD-Charger	ESM -- Electronic Shifter	x	x	x	x	x	
2011\LD-Charger	AMP -- Amplifier	x	x	x	x		
2011\LD-Charger	HFM -- Hands Free Module	x	x	x	x		
2011\LD-Charger	HSM -- Heated Seat Module	x	x	x	x	x	
2011\LD-Charger	BSM -- Blind Spot Module	x	x	x	x		
2011\LD-Charger	VSIM -- Vehicle System Interface Module	x	x	x	x	x	
2011\LD-Charger	ECM -- Engine Control Module	x	x	x	x	x	
2011\LD-Charger	TCM -- Transmission Control Module	x	x	x	x		
2011\LD-Charger	DTCM -- Drive Train Control Module	x	x	x	x	x	
2011\LD-Charger	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\LD-Charger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\LD-Charger	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2011\LD-Charger	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\LD-Charger	BCM -- Body Controller	x	x	x	x	x	
2011\LD-Charger	TGW -- Telematic Gateway Radio	x	x	x	x		
2011\LD-Charger	RFH -- Radio Frequency Hub	x	x	x	x	x	
2011\LD-Charger	EPS -- Electric Power Steering	x	x	x	x		
2011\LD-Charger	PTS -- Parktronics	x	x	x	x	x	
2011\LD-Charger	ICS -- Integrated Center Stack	x	x	x	x	x	
2011\LD-Charger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\LD-Charger	AFLS -- Adaptive Front Lighting System	x	x	x	x	x	
2011\LD-Charger	ACC -- Adaptive Cruise Control	x	x	x	x		
2011\LD-Charger	SCCM -- Steering Column Control Module	x	x	x	x		
2011\LD-Charger	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	

2011\LEX	DDM -- Driver Door Module	x	x	x	x	x	
2011\LEX	PDM -- Passenger Door Module	x	x	x	x	x	
2011\LEX	ESM -- Electronic Shifter	x	x	x	x	x	
2011\LEX	AMP -- Amplifier	x	x	x	x		
2011\LEX	HFM -- Hands Free Module	x	x	x	x		
2011\LEX	HSM -- Heated Seat Module	x	x	x	x	x	
2011\LEX	BSM -- Blind Spot Module	x	x	x	x		
2011\LEX	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2011\LEX	TCM -- Transmission Control Module	x	x	x	x	x	
2011\LEX	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\LEX	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\LEX	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\LEX	CGW -- Central Gateway	x	x	x	x	x	
2011\LEX	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\LEX	SAS -- Steering Angle Sensor	x	x	x	x		
2011\LEX	RADIO -- Radio	x	x	x	x	x	
2011\LEX	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\LEX	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2011\LEX	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\LEX	AMP -- Amplifier	x	x	x	x		
2011\LEX	HFM -- Hands Free Module	x	x	x	x	x	
2011\LEX	ECM -- Engine Control Module	x	x	x	x	x	
2011\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2011\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\ND-Dakota	RADIO -- Radio	x	x	x	x	x	
2011\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2011\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2011\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2011\NY-Ypsilon	ECM -- Engine Control Module	x	x	x	x	x	
2011\NY-Ypsilon	TCM -- Transmission Control Module	x	x	x	x	x	
2011\NY-Ypsilon	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\NY-Ypsilon	ORC -- AirBag/Occupant Restraint	x	x	x	x	x	
2011\NY-Ypsilon	IPC -- Instrument Panel Cluster	x	x	x	x	x	
2011\NY-Ypsilon	BCM -- Body Controller	x	x	x	x	x	
2011\NY-Ypsilon	EPS -- Electric Power Steering	x	x	x	x		
2011\NY-Ypsilon	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2011\NY-Ypsilon	AHM -- Additional Heater Module	x	x	x	x	x	
2011\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2011\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2011\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2011\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2011\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2011\PM-Caliber	RADIO -- Radio	x	x	x	x	x	
2011\PM-Caliber	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2011\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2011\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2011\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2011\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2011\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2011\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2011\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2011\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2011\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2011\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2011\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2011\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2011\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2011\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2011\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2011\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2011\RM-Routan	AMP -- Amplifier	x	x	x	x		
2011\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2011\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2011\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	

2011\RM-Routan	HSM -- Heated Seat Module	x	x	x	x	x	
2011\RM-Routan	PEM -- Passive Entry Module	x	x	x	x		
2011\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	0011, 0012, 0017
2011\RM-Routan	TCM -- Transmission Control Module	x	x	x	x	x	
2011\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2011\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\RM-Routan	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2011\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2011\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2011\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2011\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2011\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2011\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2011\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2011\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2011\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2011\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2011\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2011\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2011\RM-Routan	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2011\RM-Routan	AHBM -- Automatic High Beam	x	x	x	x		
2011\RM-Routan	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2011\RM-Routan	SDARV -- Satellite Video Receiver	x	x	x	x		
2011\RM-Routan	AMP -- Amplifier	x	x	x	x		
2011\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2011\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2011\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	
2011\RM-Routan	HSM -- Heated Seat Module	x	x	x	x	x	
2011\RM-Routan	BSM -- Blind Spot Module	x	x	x	x		
2011\RM-Routan	PEM -- Passive Entry Module	x	x	x	x		
2011\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2011\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2011\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2011\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	

2011\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\WD-Durango	CGW -- Central Gateway	x	x	x	x	x	
2011\WD-Durango	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2011\WD-Durango	SAS -- Steering Angle Sensor	x	x	x	x	x	
2011\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2011\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2011\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2011\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2011\WD-Durango	ACC -- Adaptive Cruise Control	x	x	x	x		
2011\WD-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011\WD-Durango	DMFR -- Door Module Front Right	x	x	x	x	x	
2011\WD-Durango	DMFL -- Door Module Front Left	x	x	x	x	x	
2011\WD-Durango	ESM -- Electronic Shifter	x	x	x	x	x	
2011\WD-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2011\WD-Durango	AHLM -- Headlamp Leveling	x	x	x	x	x	
2011\WD-Durango	AHBM -- Automatic High Beam	x	x	x	x	x	
2011\WD-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011\WD-Durango	SDARV -- Satellite Video Receiver	x	x	x	x		
2011\WD-Durango	AMP -- Amplifier	x	x	x	x		
2011\WD-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2011\WD-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2011\WD-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2011\WD-Durango	BSM -- Blind Spot Module	x	x	x	x		
2011\WD-Durango	PEM -- Passive Entry Module	x	x	x	x		
2011\WD-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2011\WD-Durango	TCM -- Transmission Control Module	x	x	x	x		
2011\WD-Durango	DTCM -- Drive Train Control Module	x	x	x	x	x	
2011\WD-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2011\WD-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2011\WD-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2011\WD-Durango	TPM -- Tire Pressure Monitor	x	x	x	x		
2011\WD-Durango	CGW -- Central Gateway	x	x	x	x	x	
2011\WD-Durango	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2011\WD-Durango	SAS -- Steering Angle Sensor	x	x	x	x	x	
2011\WD-Durango	EPS -- Electric Power Steering	x	x	x	x		
2011\WD-Durango	PTS -- Parktronics	x	x	x	x	x	
2011\WD-Durango	RADIO -- Radio	x	x	x	x	x	
2011\WD-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2011 WK Grand Cherokee	ACC -- Adaptive Cruise Control	x	x	x	x		
2011 WK Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2011 WK Grand Cherokee	DMFR -- Door Module Front Right	x	x	x	x	x	
2011 WK Grand Cherokee	DMFL -- Door Module Front Left	x	x	x	x	x	
2011 WK Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2011 WK Grand Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2011 WK Grand Cherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2011 WK Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2011 WK Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2011 WK Grand Cherokee	SDARV -- Satellite Video Receiver	x	x	x	x		
2011 WK Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2011 WK Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2011 WK Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2011 WK Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2011 WK Grand Cherokee	BSM -- Blind Spot Module	x	x	x	x		
2011 WK Grand Cherokee	PEM -- Passive Entry Module	x	x	x	x		
2011 WK Grand Cherokee	ASCM -- Air Suspension Control Module	x	x	x	x		
2011 WK Grand Cherokee	ELSD -- Electronic Limited Slip Differential	x	x	x	x		
2010 D2 Ram Truck	ECM -- Engine Control Module	x	x	x	x	x	
2010 D2 Ram Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2010 D2 Ram Truck	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010 D2 Ram Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010 D2 Ram Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010 D2 Ram Truck	CGW -- Central Gateway	x	x	x	x	x	
2010 D2 Ram Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010 D2 Ram Truck	SAS -- Steering Angle Sensor	x	x	x	x		
2010 D2 Ram Truck	PTS -- Parktronics	x	x	x	x	x	
2010 D2 Ram Truck	RADIO -- Radio	x	x	x	x	x	
2010 D2 Ram Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x		
2010 D2 Ram Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010 D2 Ram Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
2010 D2 Ram Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
2010 D2 Ram Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
2010 D2 Ram Truck	AMP -- Amplifier	x	x	x	x		
2010 D2 Ram Truck	HFM -- Hands Free Module	x	x	x	x	x	
2010 D2 Ram Truck	VES3 -- Last Row Screen	x	x	x	x	x	
2010 D2 Ram Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2010 D2 Ram Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2010 D5 Ram Truck	ECM -- Engine Control Module	x	x	x	x	x	
2010 D5 Ram Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	

Truck	2010\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	2010\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	2010\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	2010\DR-RAM	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	2010\DR-RAM	CGW -- Central Gateway	x	x	x	x	x	
Truck	2010\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	2010\DR-RAM	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	2010\DR-RAM	PTS -- Parktronics	x	x	x	x	x	
Truck	2010\DR-RAM	RADIO -- Radio	x	x	x	x	x	
Truck	2010\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x		
Truck	2010\DR-RAM	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	2010\DR-RAM	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	2010\DR-RAM	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	2010\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	2010\DR-RAM	SDARV -- Satellite Video Receiver	x	x	x	x		
Truck	2010\DR-RAM	AMP -- Amplifier	x	x	x	x		
Truck	2010\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
Truck	2010\DR-RAM	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	2010\DR-RAM	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	2010\DR-RAM	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	2010\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x	
Truck	2010\DR-RAM	TCM -- Transmission Control Module	x	x	x	x	x	
Truck	2010\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	2010\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	2010\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	2010\DR-RAM	CGW -- Central Gateway	x	x	x	x	x	
Truck	2010\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x		
Truck	2010\DR-RAM	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	2010\DR-RAM	RADIO -- Radio	x	x	x	x		
Truck	2010\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Truck	2010\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
Truck	2010\DR-RAM	SUNR -- Sunroof	x	x	x	x	x	
Truck	2010\DR-RAM	EOM -- Electronic Overhead	x	x	x	x	x	
Truck	2010\DR-RAM	SDAR -- Satellite Radio	x	x	x	x		
Truck	2010\DR-RAM	AMP -- Amplifier	x	x	x	x		
Truck	2010\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
Truck	2010\DR-RAM	VES -- Vehicle Entertainment System	x	x	x	x	x	
Truck	2010\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x	
Truck	2010\DR-RAM	DTCM -- Drive Train Control Module	x	x	x	x	x	
Truck	2010\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	0001

2010\DS-Kam	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Truck	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\DS-Kam	TPM -- Tire Pressure Monitor	x	x	x	x		
Truck	CGW -- Central Gateway	x	x	x	x	x	
2010\DS-Kam	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Truck	SAS -- Steering Angle Sensor	x	x	x	x		
2010\DS-Kam	PTS -- Parktronics	x	x	x	x	x	
Truck	RADIO -- Radio	x	x	x	x	x	
2010\DS-Kam	HVAC -- Heat, Ventilation and A/C	x	x	x	x		
Truck	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010\DS-Kam	DMFR -- Door Module Front Right	x	x	x	x	x	
Truck	DMFL -- Door Module Front Left	x	x	x	x	x	
2010\DS-Kam	SDARV -- Satellite Video Receiver	x	x	x	x		
Truck	AMP -- Amplifier	x	x	x	x		
2010\DS-Kam	HFM -- Hands Free Module	x	x	x	x	x	
Truck	VES3 -- Last Row Screen	x	x	x	x	x	
2010\DS-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
Truck	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
2010\DX-Kam	ECM -- Engine Control Module	x	x	x	x	x	
Truck	DTCM -- Drive Train Control Module	x	x	x	x	x	
2010\DX-Kam	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Truck	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\DX-Kam	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Truck	TPM -- Tire Pressure Monitor	x	x	x	x		
2010\DX-Kam	CGW -- Central Gateway	x	x	x	x	x	
Truck	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010\DX-Kam	SAS -- Steering Angle Sensor	x	x	x	x		
Truck	PTS -- Parktronics	x	x	x	x	x	
2010\DX-Kam	RADIO -- Radio	x	x	x	x	x	
Truck	HVAC -- Heat, Ventilation and A/C	x	x	x	x		
2010\DX-Kam	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Truck	DMFR -- Door Module Front Right	x	x	x	x	x	
2010\DX-Kam	DMFL -- Door Module Front Left	x	x	x	x	x	
Truck	SDARV -- Satellite Video Receiver	x	x	x	x		
2010\DX-Kam	AMP -- Amplifier	x	x	x	x		
Truck	HFM -- Hands Free Module	x	x	x	x	x	
2010\DX-Kam	VES3 -- Last Row Screen	x	x	x	x	x	
Truck	HSM -- Heated Seat Module	x	x	x	x	x	
2010\DX-Kam	ITBM -- Integrated Trailer Brake Module	x	x	x	x		
Truck	ECM -- Engine Control Module	x	x	x	x	x	
2010\J8-Wrangler							

2010\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2010\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2010\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2010\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2010\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	0009
2010\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2010\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\JC-Journey	CGW -- Central Gateway	x	x	x	x	x	
2010\JC-Journey	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010\JC-Journey	SAS -- Steering Angle Sensor	x	x	x	x		
2010\JC-Journey	RADIO -- Radio	x	x	x	x	x	
2010\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\JC-Journey	DMFR -- Door Module Front Right	x	x	x	x	x	
2010\JC-Journey	DMFL -- Door Module Front Left	x	x	x	x	x	
2010\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2010\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\JC-Journey	SDARV -- Satellite Video Receiver	x	x	x	x		
2010\JC-Journey	AMP -- Amplifier	x	x	x	x		
2010\JC-Journey	HFM -- Hands Free Module	x	x	x	x	x	
2010\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2010\JC-Journey	DISP -- Front Display	x	x	x	x		
2010\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2010\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2010\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2010\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2010\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2010\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2010\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\JK-Wrangler	AMP -- Amplifier	x	x	x	x		

2010\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	ECM -- Engine Control Module	x	x	x	x	x	0009
2010\JS-Avenger-Sebring-C	TCM -- Transmission Control Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\JS-Avenger-Sebring-C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\JS-Avenger-Sebring-C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	CGW -- Central Gateway	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\JS-Avenger-Sebring-C	SAS -- Steering Angle Sensor	x	x	x	x		
2010\JS-Avenger-Sebring-C	RADIO -- Radio	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	DDM -- Driver Door Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	PDM -- Passenger Door Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2010\JS-Avenger-Sebring-C	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	PTCM -- Power Top Control Module	x	x	x	x		
2010\JS-Avenger-Sebring-C	AMP -- Amplifier	x	x	x	x		
2010\JS-Avenger-Sebring-C	HFM -- Hands Free Module	x	x	x	x	x	
2010\JS-Avenger-Sebring-C	VES3 -- Last Row Screen	x	x	x	x	x	
2010\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2010\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2010\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2010\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2010\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2010\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2010\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2010\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2010\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2010\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2010\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2010\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2010\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2010\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2010\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001

2010\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2010\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2010\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2010\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2010\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2010\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2010\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2010\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2010\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2010\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2010\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2010\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2010\EC	ECM -- Engine Control Module	x	x	x	x	x	
2010\EC	TCM -- Transmission Control Module	x	x	x	x		
2010\EC	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\EC	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\EC	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\EC	TPM -- Tire Pressure Monitor	x	x	x	x		
2010\EC	CGW -- Central Gateway	x	x	x	x	x	
2010\EC	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010\EC	RADIO -- Radio	x	x	x	x	x	
2010\EC	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\EC	DDM -- Driver Door Module	x	x	x	x	x	
2010\EC	PDM -- Passenger Door Module	x	x	x	x	x	
2010\EC	SCM -- Steering Column	x	x	x	x	x	
2010\EC	ESM -- Electronic Shifter	x	x	x	x	x	
2010\EC	SUNR -- Sunroof	x	x	x	x	x	
2010\EC	EOM -- Electronic Overhead	x	x	x	x		
2010\EC	AMP -- Amplifier	x	x	x	x		
2010\EC	HFM -- Hands Free Module	x	x	x	x	x	
2010\EC	HSM -- Heated Seat Module	x	x	x	x	x	
2010\EC	PEM -- Passive Entry Module	x	x	x	x		
2010\EC	ECM -- Engine Control Module	x	x	x	x	x	
2010\EC	TCM -- Transmission Control Module	x	x	x	x		

2010 CLX	DTCM -- Drive Train Control Module	x	x	x	x	x	
2010 CLX	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010 CLX	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010 CLX	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010 CLX	TPM -- Tire Pressure Monitor	x	x	x	x		
2010 CLX	CGW -- Central Gateway	x	x	x	x	x	
2010 CLX	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010 CLX	PTS -- Parktronics	x	x	x	x	x	
2010 CLX	RADIO -- Radio	x	x	x	x	x	
2010 CLX	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010 CLX	ACC -- Adaptive Cruise Control	x	x	x	x		
2010 CLX	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2010 CLX	DDM -- Driver Door Module	x	x	x	x	x	
2010 CLX	PDM -- Passenger Door Module	x	x	x	x	x	
2010 CLX	SCM -- Steering Column	x	x	x	x	x	
2010 CLX	ESM -- Electronic Shifter	x	x	x	x	x	
2010 CLX	SUNR -- Sunroof	x	x	x	x	x	
2010 CLX	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2010 CLX	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2010 CLX	AHBM -- Automatic High Beam	x	x	x	x		
2010 CLX	EOM -- Electronic Overhead	x	x	x	x		
2010 CLX	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010 CLX	RSM -- Rain Sensor Module	x	x	x	x		
2010 CLX	SDARV -- Satellite Video Receiver	x	x	x	x		
2010 CLX	AMP -- Amplifier	x	x	x	x		
2010 CLX	HFM -- Hands Free Module	x	x	x	x	x	
2010 CLX	VES3 -- Last Row Screen	x	x	x	x	x	
2010 CLX	HSM -- Heated Seat Module	x	x	x	x	x	
2010 CLX	PEM -- Passive Entry Module	x	x	x	x		
2010 CLX	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
Coronair Patriot	TCM -- Transmission Control Module	x	x	x	x	x	
Coronair Patriot	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Coronair Patriot	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Coronair Patriot	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Coronair Patriot	CGW -- Central Gateway	x	x	x	x	x	
Coronair Patriot	WCM/TPMS -- Wireless Control	x	x	x	x		
Coronair Patriot	SAS -- Steering Angle Sensor	x	x	x	x		
Coronair Patriot	RADIO -- Radio	x	x	x	x	x	
Coronair Patriot	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Coronair Patriot	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	

2010\NM-Raider	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\NM-Raider	AMP -- Amplifier	x	x	x	x		
2010\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2010\ND-Dakota	ECM -- Engine Control Module	x	x	x	x	x	
2010\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2010\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\ND-Dakota	RADIO -- Radio	x	x	x	x	x	
2010\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2010\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2010\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2010\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2010\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2010\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\NM-Raider	RADIO -- Radio	x	x	x	x	x	
2010\NM-Raider	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\NM-Raider	EOM -- Electronic Overhead	x	x	x	x		
2010\NM-Raider	AMP -- Amplifier	x	x	x	x		
2010\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2010\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	0008, 0016
2010\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2010\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2010\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2010\PM-Caliber	RADIO -- Radio	x	x	x	x	x	
2010\PM-Caliber	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2010\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2010\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2010\PM-Caliber	EBG -- Electronic Booster Gauge	x	x	x	x		

2010\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2010\RM-Routan	TCM -- Transmission Control Module	x	x	x	x	x	
2010\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2010\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2010\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x		
2010\RM-Routan	RADIO -- Radio	x	x	x	x		
2010\RM-Routan	DDM -- Driver Door Module	x	x	x	x	x	
2010\RM-Routan	PDM -- Passenger Door Module	x	x	x	x	x	
2010\RM-Routan	OCM -- Occupant Classification	x	x	x	x		
2010\RM-Routan	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\RM-Routan	SDAR -- Satellite Radio	x	x	x	x		
2010\RM-Routan	AMP -- Amplifier	x	x	x	x		
2010\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2010\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2010\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2010\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2010\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2010\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2010\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2010\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2010\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2010\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2010\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2010\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2010\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2010\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2010\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2010\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2010\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2010\RM-Routan	AMP -- Amplifier	x	x	x	x		
2010\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2010\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2010\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	

Corolla Town &	ECM -- Engine Control Module	x	x	x	x	x	
Corolla Town &	TCM -- Transmission Control Module	x	x	x	x	x	
Corolla Town &	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Corolla Town &	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Corolla Town &	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Corolla Town &	CGW -- Central Gateway	x	x	x	x	x	
Corolla Town &	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Corolla Town &	SAS -- Steering Angle Sensor	x	x	x	x		
Corolla Town &	PTS -- Parktronics	x	x	x	x	x	
Corolla Town &	RADIO -- Radio	x	x	x	x	x	
Corolla Town &	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
Corolla Town &	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
Corolla Town &	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
Corolla Town &	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
Corolla Town &	DMFR -- Door Module Front Right	x	x	x	x	x	
Corolla Town &	DMFL -- Door Module Front Left	x	x	x	x	x	
Corolla Town &	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
Corolla Town &	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
Corolla Town &	PLGM -- Power Liftgate Module	x	x	x	x	x	
Corolla Town &	FSM -- Fold Stow Module	x	x	x	x	x	
Corolla Town &	SUNR -- Sunroof	x	x	x	x	x	
Corolla Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
Corolla Town &	AHBM -- Automatic High Beam	x	x	x	x		
Corolla Town &	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
Corolla Town &	DVD -- DVD Changer	x	x	x	x		
Corolla Town &	SDARV -- Satellite Video Receiver	x	x	x	x		
Corolla Town &	AMP -- Amplifier	x	x	x	x		
Corolla Town &	HFM -- Hands Free Module	x	x	x	x	x	
Corolla Town &	VES2 -- Second Row Screen	x	x	x	x	x	
Corolla Town &	VES3 -- Last Row Screen	x	x	x	x	x	
Corolla Town &	BSM -- Blind Spot Module	x	x	x	x		
Cherokee Grand	ECM -- Engine Control Module	x	x	x	x	x	
Cherokee Grand	TCM -- Transmission Control Module	x	x	x	x		
Cherokee Grand	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
Cherokee Grand	ORC -- AirBag/Occupant Restraint	x	x	x	x		
Cherokee Grand	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
Cherokee Grand	CGW -- Central Gateway	x	x	x	x	x	
Cherokee Grand	WCM/TPMS -- Wireless Control	x	x	x	x	x	
Cherokee Grand	SAS -- Steering Angle Sensor	x	x	x	x		
Cherokee	PTS -- Parktronics	x	x	x	x	x	

2010WK-Grand Cherokee	RADIO -- Radio	x	x	x	x	x	
2010WK-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010WK-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2010WK-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2010WK-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2010WK-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2010WK-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2010WK-Grand Cherokee	TM -- Trailer		x	x			
2010WK-Grand Cherokee	SUNR -- Sunroof	x	x	x	x	x	
2010WK-Grand Cherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2010WK-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x		
2010WK-Grand Cherokee	EOM -- Electronic Overhead	x	x	x	x		
2010WK-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010WK-Grand Cherokee	RSM -- Rain Sensor Module	x	x	x	x		
2010WK-Grand Cherokee	SDARV -- Satellite Video Receiver	x	x	x	x		
2010WK-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2010WK-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2010WK-Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2010WK-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2010WK-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2010WK-Commander	TCM -- Transmission Control Module	x	x	x	x		
2010WK-Commander	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2010WK-Commander	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2010WK-Commander	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2010WK-Commander	CGW -- Central Gateway	x	x	x	x	x	
2010WK-Commander	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2010WK-Commander	SAS -- Steering Angle Sensor	x	x	x	x		
2010WK-Commander	PTS -- Parktronics	x	x	x	x	x	
2010WK-Commander	RADIO -- Radio	x	x	x	x	x	
2010WK-Commander	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2010WK-Commander	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2010WK-Commander	DDM -- Driver Door Module	x	x	x	x	x	
2010WK-Commander	PDM -- Passenger Door Module	x	x	x	x	x	
2010WK-Commander	ESM -- Electronic Shifter	x	x	x	x	x	
2010WK-Commander	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2010WK-Commander	PLGM -- Power Liftgate Module	x	x	x	x	x	
2010WK-Commander	TM -- Trailer		x	x			
2010WK-Commander	SUNR -- Sunroof	x	x	x	x	x	
2010WK-Commander	AHLM -- Headlamp Leveling	x	x	x	x	x	
2010WK-Commander	AHBM -- Automatic High Beam	x	x	x	x		

2010\XR-Commander	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2010\XR-Commander	RSM -- Rain Sensor Module	x	x	x	x		
2010\XR-Commander	SDARV -- Satellite Video Receiver	x	x	x	x		
2010\XR-Commander	AMP -- Amplifier	x	x	x	x		
2010\XR-Commander	HFM -- Hands Free Module	x	x	x	x	x	
2010\XR-Commander	VES3 -- Last Row Screen	x	x	x	x	x	
2010\XR-Commander	HSM -- Heated Seat Module	x	x	x	x	x	
2010\ZB-Viper	ECM -- Engine Control Module	x	x	x	x	x	
2010\ZB-Viper	OCM -- Occupant Classification	x	x	x	x		
2009\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x	
2009\DR-RAM	TCM -- Transmission Control Module	x	x	x	x	x	
2009\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\DR-RAM	CGW -- Central Gateway	x	x	x	x	x	
2009\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\DR-RAM	SAS -- Steering Angle Sensor	x	x	x	x		
2009\DR-RAM	RADIO -- Radio	x	x	x	x		
2009\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2009\DR-RAM	SUNR -- Sunroof	x	x	x	x	x	
2009\DR-RAM	EOM -- Electronic Overhead	x	x	x	x	x	
2009\DR-RAM	SDAR -- Satellite Radio	x	x	x	x		
2009\DR-RAM	AMP -- Amplifier	x	x	x	x		
2009\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
2009\DR-RAM	VES -- Vehicle Entertainment System	x	x	x	x	x	
2009\DS-Ram	ECM -- Engine Control Module	x	x	x	x	x	
2009\DS-Ram	DTCM -- Drive Train Control Module	x	x	x	x	x	
2009\DS-Ram	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\DS-Ram	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\DS-Ram	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\DS-Ram	CGW -- Central Gateway	x	x	x	x	x	
2009\DS-Ram	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\DS-Ram	SAS -- Steering Angle Sensor	x	x	x	x		
2009\DS-Ram	PTS -- Parktronics	x	x	x	x	x	
2009\DS-Ram	RADIO -- Radio	x	x	x	x	x	
2009\DS-Ram	HVAC -- Heat, Ventilation and A/C	x	x	x	x		
2009\DS-Ram	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2009\DS-Ram	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\DS-Ram	DMFL -- Door Module Front Left	x	x	x	x	x	

2009\DS-Kam	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\DS-Kam	AMP -- Amplifier	x	x	x	x		
2009\DS-Kam	HFM -- Hands Free Module	x	x	x	x	x	
2009\DS-Kam	VES3 -- Last Row Screen	x	x	x	x	x	
2009\DS-Kam	HSM -- Heated Seat Module	x	x	x	x	x	
2009\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2009\HB-Durango	TCM -- Transmission Control Module	x	x	x	x		
2009\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2009\HB-Durango	HGM -- Hybrid Gateway Module	x	x	x	x	x	
2009\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\HB-Durango	SAS -- Steering Angle Sensor	x	x	x	x		
2009\HB-Durango	EPS -- Electric Power Steering	x	x	x	x		
2009\HB-Durango	PTS -- Parktronics	x	x	x	x	x	
2009\HB-Durango	RADIO -- Radio	x	x	x	x	x	
2009\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\HB-Durango	APM -- Adjustable Pedal Module	x					
2009\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2009\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2009\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2009\HB-Durango	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\HB-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2009\HB-Durango	EOM -- Electronic Overhead	x	x	x	x	x	
2009\HB-Durango	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\HB-Durango	AMP -- Amplifier	x	x	x	x		
2009\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2009\HB-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2009\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2009\HB-Durango	BPCM -- Battery Pack Control Module	x			x		
2009\HB-Durango	EAC -- Electric A/C Compressor	x	x	x	x		
2009\HB-Durango	HCP -- Hybrid Control Processor	x	x	x	x		
2009\HB-Durango	MCPA -- Motor Control Processor A	x			x		
2009\HB-Durango	MCPB -- Motor Control Processor B	x			x		
2009\HG-Aspen	ECM -- Engine Control Module	x	x	x	x	x	
2009\HG-Aspen	TCM -- Transmission Control Module	x	x	x	x		
2009\HG-Aspen	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\HG-Aspen	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	

2009\HG-Aspen	CGW -- Central Gateway	x	x	x	x	x	
2009\HG-Aspen	HGM -- Hybrid Gateway Module	x	x	x	x	x	
2009\HG-Aspen	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\HG-Aspen	SAS -- Steering Angle Sensor	x	x	x	x		
2009\HG-Aspen	EPS -- Electric Power Steering	x	x	x	x		
2009\HG-Aspen	PTS -- Parktronics	x	x	x	x	x	
2009\HG-Aspen	RADIO -- Radio	x	x	x	x	x	
2009\HG-Aspen	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\HG-Aspen	APM -- Adjustable Pedal Module	x					
2009\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2009\HG-Aspen	DDM -- Driver Door Module	x	x	x	x	x	
2009\HG-Aspen	PDM -- Passenger Door Module	x	x	x	x	x	
2009\HG-Aspen	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\HG-Aspen	PLGM -- Power Liftgate Module	x	x	x	x	x	
2009\HG-Aspen	EOM -- Electronic Overhead	x	x	x	x	x	
2009\HG-Aspen	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\HG-Aspen	AMP -- Amplifier	x	x	x	x		
2009\HG-Aspen	HFM -- Hands Free Module	x	x	x	x	x	
2009\HG-Aspen	VES3 -- Last Row Screen	x	x	x	x	x	
2009\HG-Aspen	HSM -- Heated Seat Module	x	x	x	x	x	
2009\HG-Aspen	BPCM -- Battery Pack Control Module	x			x		
2009\HG-Aspen	EAC -- Electric A/C Compressor	x	x	x	x		
2009\HG-Aspen	HCP -- Hybrid Control Processor	x	x	x	x		
2009\HG-Aspen	MCPA -- Motor Control Processor A	x			x		
2009\HG-Aspen	MCPB -- Motor Control Processor B	x			x		
2009\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2009\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2009\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2009\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2009\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2009\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2009\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2009\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	

2009\JC-Journey	CGW -- Central Gateway	x	x	x	x	x	
2009\JC-Journey	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\JC-Journey	SAS -- Steering Angle Sensor	x	x	x	x		
2009\JC-Journey	RADIO -- Radio	x	x	x	x	x	
2009\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\JC-Journey	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\JC-Journey	DMFL -- Door Module Front Left	x	x	x	x	x	
2009\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2009\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\JC-Journey	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\JC-Journey	AMP -- Amplifier	x	x	x	x		
2009\JC-Journey	HFM -- Hands Free Module	x	x	x	x	x	
2009\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2009\JC-Journey	DISP -- Front Display	x	x	x	x		
2009\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2009\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2009\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2009\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2009\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2009\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2009\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2009\JK-Wrangler	HFM -- Hands Free Module	x	x	x	x	x	
2009\JS-	ECM -- Engine Control Module	x	x	x	x	x	
2009\JS-Sebring C	TCM -- Transmission Control Module	x	x	x	x	x	
2009\JS-Sebring C	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\JS-Sebring C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\JS-Sebring C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\JS-Sebring C	CGW -- Central Gateway	x	x	x	x	x	
2009\JS-Sebring C	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\JS-Sebring C	SAS -- Steering Angle Sensor	x	x	x	x		
2009\JS-Sebring C	RADIO -- Radio	x	x	x	x	x	
2009\JS-Sebring C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\JS-Sebring C	DDM -- Driver Door Module	x	x	x	x	x	
2009\JS-Sebring C	PDM -- Passenger Door Module	x	x	x	x	x	
2009\JS-Sebring C	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		

2009\SS-Avenger-Sebring-C	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\SS-Avenger-Sebring-C	PTCM -- Power Top Control Module	x	x	x	x		
2009\SS-Avenger-Sebring-C	AMP -- Amplifier	x	x	x	x		
2009\SS-Avenger-Sebring-C	HFM -- Hands Free Module	x	x	x	x	x	
2009\SS-Avenger-Sebring-C	VES3 -- Last Row Screen	x	x	x	x	x	
2009\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2009\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2009\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2009\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2009\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2009\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2009\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2009\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2009\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2009\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2009\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2009\KA-Nitro	VES3 -- Last Row Screen	x	x	x	x	x	
2009\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2009\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2009\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2009\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2009\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2009\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2009\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2009\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2009\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2009\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	

2009\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2009\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2009\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2009\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2009\KK-Liberty	VES3 -- Last Row Screen	x	x	x	x	x	
2009\LC-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2009\LC-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2009\LC-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\LC-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\LC-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2009\LC-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2009\LC-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\LC-Challenger	RADIO -- Radio	x	x	x	x	x	
2009\LC-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\LC-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2009\LC-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2009\LC-Challenger	SCM -- Steering Column	x	x	x	x	x	
2009\LC-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2009\LC-Challenger	SUNR -- Sunroof	x	x	x	x	x	
2009\LC-Challenger	EOM -- Electronic Overhead	x	x	x	x		
2009\LC-Challenger	AMP -- Amplifier	x	x	x	x		
2009\LC-Challenger	HFM -- Hands Free Module	x	x	x	x	x	
2009\LC-Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2009\LC-Challenger	PEM -- Passive Entry Module	x	x	x	x		
2009\LC-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2009\LC-Challenger Magn	TCM -- Transmission Control Module	x	x	x	x		
2009\LC-Challenger Magn	DTCM -- Drive Train Control Module	x	x	x	x	x	
2009\LC-Challenger Magn	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\LC-Challenger Magn	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\LC-Challenger Magn	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\LC-Challenger Magn	TPM -- Tire Pressure Monitor	x	x	x	x		
2009\LC-Challenger Magn	CGW -- Central Gateway	x	x	x	x	x	
2009\LC-Challenger Magn	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\LC-Challenger Magn	PTS -- Parktronics	x	x	x	x	x	
2009\LC-Challenger Magn	RADIO -- Radio	x	x	x	x	x	
2009\LC-Challenger Magn	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\LC-Challenger Magn	ACC -- Adaptive Cruise Control	x	x	x	x		
2009\LC-Challenger Magn	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		

2009\EX-	DDM -- Driver Door Module	x	x	x	x	x	
2009\EX-	PDM -- Passenger Door Module	x	x	x	x	x	
2009\EX-	SCM -- Steering Column	x	x	x	x	x	
2009\EX-	ESM -- Electronic Shifter	x	x	x	x	x	
2009\EX-	SUNR -- Sunroof	x	x	x	x	x	
2009\EX-	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2009\EX-	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2009\EX-	AHBM -- Automatic High Beam	x	x	x	x		
2009\EX-	EOM -- Electronic Overhead	x	x	x	x		
2009\EX-	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\EX-	RSM -- Rain Sensor Module	x	x	x	x		
2009\EX-	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\EX-	AMP -- Amplifier	x	x	x	x		
2009\EX-	HFM -- Hands Free Module	x	x	x	x	x	
2009\EX-	VES3 -- Last Row Screen	x	x	x	x	x	
2009\EX-	HSM -- Heated Seat Module	x	x	x	x	x	
2009\EX-	PEM -- Passive Entry Module	x	x	x	x		
2009\EX-	ECM -- Engine Control Module	x	x	x	x	x	
2009\EX-	TCM -- Transmission Control Module	x	x	x	x	x	
2009\EX-	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\EX-	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\EX-	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\EX-	CGW -- Central Gateway	x	x	x	x	x	
2009\EX-	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\EX-	SAS -- Steering Angle Sensor	x	x	x	x		
2009\EX-	RADIO -- Radio	x	x	x	x	x	
2009\EX-	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\EX-	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\EX-	AMP -- Amplifier	x	x	x	x		
2009\EX-	HFM -- Hands Free Module	x	x	x	x	x	
2009\EX-	ECM -- Engine Control Module	x	x	x	x	x	
2009\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2009\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\ND-Dakota	RADIO -- Radio	x	x	x	x	x	
2009\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2009\ND-Dakota	AMP -- Amplifier	x	x	x	x		

2009\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2009\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2009\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2009\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\NM-Raider	RADIO -- Radio	x	x	x	x	x	
2009\NM-Raider	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\NM-Raider	EOM -- Electronic Overhead	x	x	x	x		
2009\NM-Raider	AMP -- Amplifier	x	x	x	x		
2009\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2009\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2009\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2009\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2009\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2009\PM-Caliber	RADIO -- Radio	x	x	x	x	x	
2009\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2009\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2009\PM-Caliber	EBG -- Electronic Booster Gauge	x	x	x	x		
2009\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2009\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2009\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2009\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2009\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2009\PM-Caliber	RADIO -- Radio	x	x	x	x		
2009\PM-Caliber	DDM -- Driver Door Module	x	x	x	x	x	
2009\PM-Caliber	PDM -- Passenger Door Module	x	x	x	x	x	
2009\PM-Caliber	OCM -- Occupant Classification	x	x	x	x		
2009\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\PM-Caliber	SDAR -- Satellite Radio	x	x	x	x		
2009\PM-Caliber	AMP -- Amplifier	x	x	x	x		

2009\RT-1 Cruiser	HFM -- Hands Free Module	x	x	x	x	x	
2009\RM-Mini-Van	ECM -- Engine Control Module		x		x	x	
2009\RM-Routan	ECM -- Engine Control Module	x	x	x	x	x	
2009\RM-Routan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\RM-Routan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\RM-Routan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\RM-Routan	CGW -- Central Gateway	x	x	x	x	x	
2009\RM-Routan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\RM-Routan	SAS -- Steering Angle Sensor	x	x	x	x		
2009\RM-Routan	PTS -- Parktronics	x	x	x	x	x	
2009\RM-Routan	RADIO -- Radio	x	x	x	x	x	
2009\RM-Routan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\RM-Routan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2009\RM-Routan	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2009\RM-Routan	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2009\RM-Routan	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\RM-Routan	DMFL -- Door Module Front Left	x	x	x	x	x	
2009\RM-Routan	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2009\RM-Routan	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2009\RM-Routan	PLGM -- Power Liftgate Module	x	x	x	x	x	
2009\RM-Routan	FSM -- Fold Stow Module	x	x	x	x	x	
2009\RM-Routan	SUNR -- Sunroof	x	x	x	x	x	
2009\RM-Routan	DVD -- DVD Changer	x	x	x	x		
2009\RM-Routan	AMP -- Amplifier	x	x	x	x		
2009\RM-Routan	HFM -- Hands Free Module	x	x	x	x	x	
2009\RM-Routan	VES2 -- Second Row Screen	x	x	x	x	x	
2009\RM-Routan	VES3 -- Last Row Screen	x	x	x	x	x	
2009\RT-1 Caravan Town &	ECM -- Engine Control Module	x	x	x	x	x	
2009\RT-1 Caravan Town &	TCM -- Transmission Control Module	x	x	x	x	x	
2009\RT-1 Caravan Town &	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\RT-1 Caravan Town &	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\RT-1 Caravan Town &	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\RT-1 Caravan Town &	CGW -- Central Gateway	x	x	x	x	x	
2009\RT-1 Caravan Town &	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\RT-1 Caravan Town &	SAS -- Steering Angle Sensor	x	x	x	x		
2009\RT-1 Caravan Town &	PTS -- Parktronics	x	x	x	x	x	
2009\RT-1 Caravan Town &	RADIO -- Radio	x	x	x	x	x	
2009\RT-1 Caravan Town &	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\RT-1 Caravan Town &	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2009\RT-1 Caravan Town &	DMRL -- Rear Door Module (Left)	x	x	x	x	x	

2009\RT-Caravan Town &	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2009\RT-Caravan Town &	DMFR -- Door Module Front Right	x	x	x	x	x	
2009\RT-Caravan Town &	DMFL -- Door Module Front Left	x	x	x	x	x	
2009\RT-Caravan Town &	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2009\RT-Caravan Town &	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2009\RT-Caravan Town &	PLGM -- Power Liftgate Module	x	x	x	x	x	
2009\RT-Caravan Town &	FSM -- Fold Stow Module	x	x	x	x	x	
2009\RT-Caravan Town &	SUNR -- Sunroof	x	x	x	x	x	
2009\RT-Caravan Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2009\RT-Caravan Town &	AHBM -- Automatic High Beam	x	x	x	x		
2009\RT-Caravan Town &	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\RT-Caravan Town &	DVD -- DVD Changer	x	x	x	x		
2009\RT-Caravan Town &	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\RT-Caravan Town &	AMP -- Amplifier	x	x	x	x		
2009\RT-Caravan Town &	HFM -- Hands Free Module	x	x	x	x	x	
2009\RT-Caravan Town &	VES2 -- Second Row Screen	x	x	x	x	x	
2009\RT-Caravan Town &	VES3 -- Last Row Screen	x	x	x	x	x	
2009\RT-Caravan Town &	BSM -- Blind Spot Module	x	x	x	x		
2009\VB-Sprinter	ECM -- Engine Control Module	x	x	x	x	x	
2009\VB-Sprinter	TCM -- Transmission Control Module	x	x	x	x		
2009\VB-Sprinter	ABS -- Anti Lock Brakes	x	x	x	x		0001
2009\VB-Sprinter	ORC -- AirBag/Occupant Restraint	x	x	x			
2009\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x		
2009\VB-Sprinter	TPM -- Tire Pressure Monitor	x	x	x	x		
2009\VB-Sprinter	BCM -- Body Controller	x	x	x	x	x	
2009\VB-Sprinter	CGW -- Central Gateway	x	x	x	x		
2009\VB-Sprinter	PTS -- Parktronics	x	x	x	x	x	
2009\VB-Sprinter	RADIO -- Radio	x	x	x	x		
2009\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\VB-Sprinter	PSDMR -- Power Sliding Doors (Right)	x	x	x	x	x	
2009\VB-Sprinter	PSDML -- Power Sliding Doors (Left)	x	x	x	x	x	
2009\VB-Sprinter	DDM -- Driver Door Module	x	x	x	x	x	
2009\VB-Sprinter	SCM -- Steering Column	x	x	x	x	x	
2009\VB-Sprinter	SBM -- Center Console / Switch Bank Module	x	x	x	x	x	
2009\VB-Sprinter	ESM -- Electronic Shifter	x	x	x	x	x	
2009\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	x	x	x	x	x	
2009\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	x	x	x	x	x	
2009\VB-Sprinter	TM -- Trailer	x	x	x	x		
2009\VB-Sprinter	AHLM -- Headlamp Leveling	x	x	x	x	x	
2009\VB-Sprinter	RCM -- Roof Control Module	x	x	x	x	x	

2009\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	x	x	x	x		
2009\VB-Sprinter	CDC -- CD Changer	x	x	x	x		
2009\VB-Sprinter	HFM -- Hands Free Module	x	x	x	x		
2009\VB-Sprinter	PSM -- Universal/Special ECU	x	x	x	x	x	
2009\WVC-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2009\WVC-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\WVC-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\WVC-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\WVC-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2009\WVC-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\WVC-Grand Cherokee	SAS -- Steering Angle Sensor	x	x	x	x		
2009\WVC-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2009\WVC-Grand Cherokee	RADIO -- Radio	x	x	x	x	x	
2009\WVC-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\WVC-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2009\WVC-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2009\WVC-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\WVC-Grand Cherokee	TM -- Trailer		x	x			
2009\WVC-Grand Cherokee	SUNR -- Sunroof	x	x	x	x	x	
2009\WVC-Grand Cherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2009\WVC-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x		
2009\WVC-Grand Cherokee	EOM -- Electronic Overhead	x	x	x	x		
2009\WVC-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	RSM -- Rain Sensor Module	x	x	x	x		
2009\WVC-Grand Cherokee	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\WVC-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2009\WVC-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2009\WVC-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2009\WVC-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2009\WVC-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2009\WVC-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2009\WVC-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2009\WVC-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2009\WVC-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2009\WVC-Grand Cherokee	SAS -- Steering Angle Sensor	x	x	x	x		

2009\XR-Commander	PTS -- Parktronics	x	x	x	x	x	
2009\XR-Commander	RADIO -- Radio	x	x	x	x	x	
2009\XR-Commander	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2009\XR-Commander	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2009\XR-Commander	DDM -- Driver Door Module	x	x	x	x	x	
2009\XR-Commander	PDM -- Passenger Door Module	x	x	x	x	x	
2009\XR-Commander	ESM -- Electronic Shifter	x	x	x	x	x	
2009\XR-Commander	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2009\XR-Commander	PLGM -- Power Liftgate Module	x	x	x	x	x	
2009\XR-Commander	TM -- Trailer		x	x			
2009\XR-Commander	SUNR -- Sunroof	x	x	x	x	x	
2009\XR-Commander	AHLM -- Headlamp Leveling	x	x	x	x	x	
2009\XR-Commander	AHBM -- Automatic High Beam	x	x	x	x		
2009\XR-Commander	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2009\XR-Commander	RSM -- Rain Sensor Module	x	x	x	x		
2009\XR-Commander	SDARV -- Satellite Video Receiver	x	x	x	x		
2009\XR-Commander	AMP -- Amplifier	x	x	x	x		
2009\XR-Commander	HFM -- Hands Free Module	x	x	x	x	x	
2009\XR-Commander	VES3 -- Last Row Screen	x	x	x	x	x	
2009\XR-Commander	HSM -- Heated Seat Module	x	x	x	x	x	
2009\ZB-Viper	ECM -- Engine Control Module	x	x	x	x	x	
2009\ZB-Viper	OCM -- Occupant Classification	x	x	x	x		
2008\CS-Pacifica	ECM -- Engine Control Module	x	x	x	x	x	
2008\CS-Pacifica	ABS -- Anti Lock Brakes	x	x	x	x	x	
2008\CS-Pacifica	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\CS-Pacifica	CGW -- Central Gateway	x	x	x	x	x	
2008\CS-Pacifica	SAS -- Steering Angle Sensor	x	x	x	x		
2008\CS-Pacifica	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2008\CS-Pacifica	PLGM -- Power Liftgate Module	x	x	x	x	x	
2008\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x	
2008\DR-RAM	TCM -- Transmission Control Module	x	x	x	x	x	
2008\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\DR-RAM	CGW -- Central Gateway	x	x	x	x	x	
2008\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\DR-RAM	SAS -- Steering Angle Sensor	x	x	x	x		
2008\DR-RAM	RADIO -- Radio	x	x	x	x		
2008\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		

2008\DR-RAM	SUNR -- Sunroof	x	x	x	x	x	
2008\DR-RAM	EOM -- Electronic Overhead	x	x	x	x	x	
2008\DR-RAM	SDAR -- Satellite Radio	x	x	x	x		
2008\DR-RAM	AMP -- Amplifier	x	x	x	x		
2008\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
2008\DR-RAM	VES -- Vehicle Entertainment System	x	x	x	x	x	
2008\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2008\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2008\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\HB-Durango	SAS -- Steering Angle Sensor	x	x	x	x		
2008\HB-Durango	PTS -- Parktronics	x	x	x	x	x	
2008\HB-Durango	RADIO -- Radio	x	x	x	x	x	
2008\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2008\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2008\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2008\HB-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2008\HB-Durango	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2008\HB-Durango	EOM -- Electronic Overhead	x	x	x	x	x	
2008\HB-Durango	AMP -- Amplifier	x	x	x	x		
2008\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2008\HB-Durango	VES3 -- Last Row Screen	x	x	x	x	x	
2008\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2008\HG-Aspen	ECM -- Engine Control Module	x	x	x	x	x	
2008\HG-Aspen	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\HG-Aspen	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\HG-Aspen	CGW -- Central Gateway	x	x	x	x	x	
2008\HG-Aspen	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\HG-Aspen	SAS -- Steering Angle Sensor	x	x	x	x		
2008\HG-Aspen	PTS -- Parktronics	x	x	x	x	x	
2008\HG-Aspen	RADIO -- Radio	x	x	x	x	x	
2008\HG-Aspen	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2008\HG-Aspen	DDM -- Driver Door Module	x	x	x	x	x	
2008\HG-Aspen	PDM -- Passenger Door Module	x	x	x	x	x	
2008\HG-Aspen	PLGM -- Power Liftgate Module	x	x	x	x	x	

2008\HG-Aspen	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2008\HG-Aspen	EOM -- Electronic Overhead	x	x	x	x	x	
2008\HG-Aspen	AMP -- Amplifier	x	x	x	x		
2008\HG-Aspen	HFM -- Hands Free Module	x	x	x	x	x	
2008\HG-Aspen	VES3 -- Last Row Screen	x	x	x	x	x	
2008\HG-Aspen	HSM -- Heated Seat Module	x	x	x	x	x	
2008\J8-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2008\J8-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2008\J8-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\J8-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\J8-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\J8-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2008\J8-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\J8-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2008\J8-Wrangler	RADIO -- Radio	x	x	x	x	x	
2008\J8-Wrangler	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\JC-Journey	ECM -- Engine Control Module	x	x	x	x	x	
2008\JC-Journey	TCM -- Transmission Control Module	x	x	x	x	x	
2008\JC-Journey	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\JC-Journey	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\JC-Journey	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\JC-Journey	CGW -- Central Gateway	x	x	x	x	x	
2008\JC-Journey	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2008\JC-Journey	SAS -- Steering Angle Sensor	x	x	x	x		
2008\JC-Journey	RADIO -- Radio	x	x	x	x	x	
2008\JC-Journey	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\JC-Journey	DMFR -- Door Module Front Right	x	x	x	x	x	
2008\JC-Journey	DMFL -- Door Module Front Left	x	x	x	x	x	
2008\JC-Journey	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2008\JC-Journey	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\JC-Journey	AMP -- Amplifier	x	x	x	x		
2008\JC-Journey	HFM -- Hands Free Module	x	x	x	x	x	
2008\JC-Journey	VES3 -- Last Row Screen	x	x	x	x	x	
2008\JC-Journey	DISP -- Front Display	x	x	x	x		
2008\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2008\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2008\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	

2008\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2008\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2008\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2008\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2008\JS-Avenger-Sebring C	ECM -- Engine Control Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	TCM -- Transmission Control Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\JS-Avenger-Sebring C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\JS-Avenger-Sebring C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\JS-Avenger-Sebring C	CGW -- Central Gateway	x	x	x	x	x	
2008\JS-Avenger-Sebring C	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\JS-Avenger-Sebring C	SAS -- Steering Angle Sensor	x	x	x	x		
2008\JS-Avenger-Sebring C	RADIO -- Radio	x	x	x	x	x	
2008\JS-Avenger-Sebring C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\JS-Avenger-Sebring C	DDM -- Driver Door Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	PDM -- Passenger Door Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2008\JS-Avenger-Sebring C	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	PTCM -- Power Top Control Module	x	x	x	x		
2008\JS-Avenger-Sebring C	AMP -- Amplifier	x	x	x	x		
2008\JS-Avenger-Sebring C	HFM -- Hands Free Module	x	x	x	x	x	
2008\JS-Avenger-Sebring C	VES3 -- Last Row Screen	x	x	x	x	x	
2008\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2008\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2008\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2008\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2008\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2008\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2008\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2008\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2008\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2008\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2008\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	

2008\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2008\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2008\KA-Nitro	VES3 -- Last Row Screen	x	x	x	x	x	
2008\KK-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2008\KK-Liberty	TCM -- Transmission Control Module	x	x	x	x		
2008\KK-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\KK-Liberty	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\KK-Liberty	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\KK-Liberty	CGW -- Central Gateway	x	x	x	x	x	
2008\KK-Liberty	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\KK-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2008\KK-Liberty	PTS -- Parktronics	x	x	x	x	x	
2008\KK-Liberty	RADIO -- Radio	x	x	x	x	x	
2008\KK-Liberty	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\KK-Liberty	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2008\KK-Liberty	DMFR -- Door Module Front Right	x	x	x	x	x	
2008\KK-Liberty	DMFL -- Door Module Front Left	x	x	x	x	x	
2008\KK-Liberty	ESM -- Electronic Shifter	x	x	x	x	x	
2008\KK-Liberty	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2008\KK-Liberty	OCM -- Occupant Classification	x	x	x	x		
2008\KK-Liberty	SUNR -- Sunroof	x	x	x	x		
2008\KK-Liberty	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\KK-Liberty	AMP -- Amplifier	x	x	x	x		
2008\KK-Liberty	HFM -- Hands Free Module	x	x	x	x	x	
2008\KK-Liberty	VES3 -- Last Row Screen	x	x	x	x	x	
2008\LC-Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2008\LC-Challenger	TCM -- Transmission Control Module	x	x	x	x		
2008\LC-Challenger	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\LC-Challenger	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\LC-Challenger	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\LC-Challenger	TPM -- Tire Pressure Monitor	x	x	x	x		
2008\LC-Challenger	CGW -- Central Gateway	x	x	x	x	x	
2008\LC-Challenger	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2008\LC-Challenger	RADIO -- Radio	x	x	x	x	x	
2008\LC-Challenger	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\LC-Challenger	DDM -- Driver Door Module	x	x	x	x	x	
2008\LC-Challenger	PDM -- Passenger Door Module	x	x	x	x	x	
2008\LC-Challenger	SCM -- Steering Column	x	x	x	x	x	
2008\LC-Challenger	ESM -- Electronic Shifter	x	x	x	x	x	
2008\LC-Challenger	SUNR -- Sunroof	x	x	x	x	x	

2000LC Challenger	EOM -- Electronic Overhead	x	x	x	x		
2000LC Challenger	AMP -- Amplifier	x	x	x	x		
2000LC Challenger	HFM -- Hands Free Module	x	x	x	x	x	
2000LC Challenger	HSM -- Heated Seat Module	x	x	x	x	x	
2000LC Challenger	PEM -- Passive Entry Module	x	x	x	x		
2000LC Challenger	ECM -- Engine Control Module	x	x	x	x	x	
2000LC Challenger Maan	TCM -- Transmission Control Module	x	x	x	x		
2000LC Challenger Maan	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2000LC Challenger Maan	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2000LC Challenger Maan	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2000LC Challenger Maan	CGW -- Central Gateway	x	x	x	x	x	
2000LC Challenger Maan	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2000LC Challenger Maan	PTS -- Parktronics	x	x	x	x	x	
2000LC Challenger Maan	RADIO -- Radio	x	x	x	x	x	
2000LC Challenger Maan	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2000LC Challenger Maan	ACC -- Adaptive Cruise Control	x	x	x	x		
2000LC Challenger Maan	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2000LC Challenger Maan	DDM -- Driver Door Module	x	x	x	x	x	
2000LC Challenger Maan	PDM -- Passenger Door Module	x	x	x	x	x	
2000LC Challenger Maan	SCM -- Steering Column	x	x	x	x	x	
2000LC Challenger Maan	ESM -- Electronic Shifter	x	x	x	x	x	
2000LC Challenger Maan	SUNR -- Sunroof	x	x	x	x	x	
2000LC Challenger Maan	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2000LC Challenger Maan	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2000LC Challenger Maan	AHBM -- Automatic High Beam	x	x	x	x		
2000LC Challenger Maan	EOM -- Electronic Overhead	x	x	x	x		
2000LC Challenger Maan	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2000LC Challenger Maan	RSM -- Rain Sensor Module	x	x	x	x		
2000LC Challenger Maan	SDARV -- Satellite Video Receiver	x	x	x	x		
2000LC Challenger Maan	AMP -- Amplifier	x	x	x	x		
2000LC Challenger Maan	HFM -- Hands Free Module	x	x	x	x	x	
2000LC Challenger Maan	VES3 -- Last Row Screen	x	x	x	x	x	
2000LC Challenger Maan	HSM -- Heated Seat Module	x	x	x	x	x	
2000LC Challenger Maan	ECM -- Engine Control Module	x	x	x	x	x	
2000LC Challenger Patriot	TCM -- Transmission Control Module	x	x	x	x	x	
2000LC Challenger Patriot	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2000LC Challenger Patriot	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2000LC Challenger Patriot	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2000LC Challenger Patriot	CGW -- Central Gateway	x	x	x	x	x	
2000LC Challenger Patriot	WCM/TPMS -- Wireless Control	x	x	x	x		

2008\NM-Raider	SAS -- Steering Angle Sensor	x	x	x	x		
2008\NM-Raider	RADIO -- Radio	x	x	x	x		
2008\NM-Raider	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2008\NM-Raider	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\NM-Raider	SDAR -- Satellite Radio	x	x	x	x		
2008\NM-Raider	AMP -- Amplifier	x	x	x	x		
2008\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2008\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2008\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2008\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\ND-Dakota	RADIO -- Radio	x	x	x	x	x	
2008\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2008\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2008\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2008\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2008\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2008\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\NM-Raider	RADIO -- Radio	x	x	x	x	x	
2008\NM-Raider	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\NM-Raider	EOM -- Electronic Overhead	x	x	x	x		
2008\NM-Raider	AMP -- Amplifier	x	x	x	x		
2008\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2008\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2008\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2008\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2008\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2008\PM-Caliber	RADIO -- Radio	x	x	x	x	x	
2008\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2008\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	

2008\PM-Caliber	SDAR -- Satellite Radio	x	x	x	x		
2008\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2008\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2008\PM-Caliber	EBG -- Electronic Booster Gauge	x	x	x	x		
2008\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2008\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2008\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2008\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2008\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2008\PM-Caliber	RADIO -- Radio	x	x	x	x		
2008\PM-Caliber	DDM -- Driver Door Module	x	x	x	x	x	
2008\PM-Caliber	PDM -- Passenger Door Module	x	x	x	x	x	
2008\PM-Caliber	OCM -- Occupant Classification	x	x	x	x		
2008\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\PM-Caliber	SDAR -- Satellite Radio	x	x	x	x		
2008\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2008\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2008\R2-Mini-Van	ECM -- Engine Control Module		x		x	x	
2008\R2-Mini-Van	ECM -- Engine Control Module	x	x	x	x	x	
2008\R2-Mini-Van	TCM -- Transmission Control Module	x	x	x	x	x	
2008\R2-Mini-Van	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\R2-Mini-Van	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\R2-Mini-Van	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008\R2-Mini-Van	CGW -- Central Gateway	x	x	x	x	x	
2008\R2-Mini-Van	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2008\R2-Mini-Van	SAS -- Steering Angle Sensor	x	x	x	x		
2008\R2-Mini-Van	PTS -- Parktronics	x	x	x	x	x	
2008\R2-Mini-Van	RADIO -- Radio	x	x	x	x	x	
2008\R2-Mini-Van	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\R2-Mini-Van	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x	x	
2008\R2-Mini-Van	DMRL -- Rear Door Module (Left)	x	x	x	x	x	
2008\R2-Mini-Van	DMRR -- Rear Door Module (Right)	x	x	x	x	x	
2008\R2-Mini-Van	DMFR -- Door Module Front Right	x	x	x	x	x	
2008\R2-Mini-Van	DMFL -- Door Module Front Left	x	x	x	x	x	
2008\R2-Mini-Van	PSDMR -- Power Sliding Doors (Right)	x	x	x	x		
2008\R2-Mini-Van	PSDML -- Power Sliding Doors (Left)	x	x	x	x		
2008\R2-Mini-Van	PLGM -- Power Liftgate Module	x	x	x	x	x	
2008\R2-Mini-Van	FSM -- Fold Stow Module	x	x	x	x	x	

2008\Caravan Town &	SUNR -- Sunroof	x	x	x	x	x	
2008\Caravan Town &	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2008\Caravan Town &	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008\Caravan Town &	DVD -- DVD Changer	x	x	x	x		
2008\Caravan Town &	SDARV -- Satellite Video Receiver	x	x	x	x		
2008\Caravan Town &	AMP -- Amplifier	x	x	x	x		
2008\Caravan Town &	HFM -- Hands Free Module	x	x	x	x	x	
2008\Caravan Town &	VES2 -- Second Row Screen	x	x	x	x	x	
2008\Caravan Town &	VES3 -- Last Row Screen	x	x	x	x	x	
2008\VB-Sprinter	ECM -- Engine Control Module	x	x	x	x	x	
2008\VB-Sprinter	TCM -- Transmission Control Module	x	x	x	x		
2008\VB-Sprinter	ABS -- Anti Lock Brakes	x	x	x	x		0001
2008\VB-Sprinter	ORC -- AirBag/Occupant Restraint	x	x	x			
2008\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x		
2008\VB-Sprinter	TPM -- Tire Pressure Monitor	x	x	x	x		
2008\VB-Sprinter	BCM -- Body Controller	x	x	x	x	x	
2008\VB-Sprinter	CGW -- Central Gateway	x	x	x	x		
2008\VB-Sprinter	PTS -- Parktronics	x	x	x	x	x	
2008\VB-Sprinter	RADIO -- Radio	x	x	x	x		
2008\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008\VB-Sprinter	PSDMR -- Power Sliding Doors (Right)	x	x	x	x	x	
2008\VB-Sprinter	PSDML -- Power Sliding Doors (Left)	x	x	x	x	x	
2008\VB-Sprinter	DDM -- Driver Door Module	x	x	x	x	x	
2008\VB-Sprinter	SCM -- Steering Column	x	x	x	x	x	
2008\VB-Sprinter	SBM -- Center Console / Switch Bank Module	x	x	x	x	x	
2008\VB-Sprinter	ESM -- Electronic Shifter	x	x	x	x	x	
2008\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	x	x	x	x	x	
2008\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	x	x	x	x	x	
2008\VB-Sprinter	TM -- Trailer	x	x	x	x		
2008\VB-Sprinter	AHLM -- Headlamp Leveling	x	x	x	x	x	
2008\VB-Sprinter	RCM -- Roof Control Module	x	x	x	x	x	
2008\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	x	x	x	x		
2008\VB-Sprinter	CDC -- CD Changer	x	x	x	x		
2008\VB-Sprinter	HFM -- Hands Free Module	x	x	x	x		
2008\VB-Sprinter	PSM -- Universal/Special ECU	x	x	x	x	x	
2008\Cherokee Grand	ECM -- Engine Control Module	x	x	x	x	x	
2008\Cherokee Grand	TCM -- Transmission Control Module	x	x	x	x		
2008\Cherokee Grand	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008\Cherokee Grand	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008\Cherokee Grand	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	

2008VWGrandCherokee	CGW -- Central Gateway	x	x	x	x	x	
2008VWGrandCherokee	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2008VWGrandCherokee	SAS -- Steering Angle Sensor	x	x	x	x		
2008VWGrandCherokee	PTS -- Parktronics	x	x	x	x	x	
2008VWGrandCherokee	RADIO -- Radio	x	x	x	x	x	
2008VWGrandCherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008VWGrandCherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2008VWGrandCherokee	DDM -- Driver Door Module	x	x	x	x	x	
2008VWGrandCherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2008VWGrandCherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2008VWGrandCherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2008VWGrandCherokee	TM -- Trailer		x	x			
2008VWGrandCherokee	SUNR -- Sunroof	x	x	x	x	x	
2008VWGrandCherokee	AHLM -- Headlamp Leveling	x	x	x	x	x	
2008VWGrandCherokee	AHBM -- Automatic High Beam	x	x	x	x		
2008VWGrandCherokee	EOM -- Electronic Overhead	x	x	x	x		
2008VWGrandCherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2008VWGrandCherokee	RSM -- Rain Sensor Module	x	x	x	x		
2008VWGrandCherokee	SDARV -- Satellite Video Receiver	x	x	x	x		
2008VWGrandCherokee	AMP -- Amplifier	x	x	x	x		
2008VWGrandCherokee	HFM -- Hands Free Module	x	x	x	x	x	
2008VWGrandCherokee	VES3 -- Last Row Screen	x	x	x	x	x	
2008VWGrandCherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2008VWGrandCherokee	ECM -- Engine Control Module	x	x	x	x	x	
2008VWCommander	TCM -- Transmission Control Module	x	x	x	x		
2008VWCommander	ABS -- Anti Lock Brakes	x	x	x	x	x	0001
2008VWCommander	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2008VWCommander	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2008VWCommander	CGW -- Central Gateway	x	x	x	x	x	
2008VWCommander	WCM/TPMS -- Wireless Control	x	x	x	x	x	
2008VWCommander	SAS -- Steering Angle Sensor	x	x	x	x		
2008VWCommander	PTS -- Parktronics	x	x	x	x	x	
2008VWCommander	RADIO -- Radio	x	x	x	x	x	
2008VWCommander	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2008VWCommander	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2008VWCommander	DDM -- Driver Door Module	x	x	x	x	x	
2008VWCommander	PDM -- Passenger Door Module	x	x	x	x	x	
2008VWCommander	ESM -- Electronic Shifter	x	x	x	x	x	
2008VWCommander	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2008VWCommander	PLGM -- Power Liftgate Module	x	x	x	x	x	

2008\XR-Commander	TM -- Trailer		x	x		
2008\XR-Commander	SUNR -- Sunroof	x	x	x	x	x
2008\XR-Commander	AHBM -- Automatic High Beam	x	x	x	x	
2008\XR-Commander	ITM -- Intrusion Transceiver Module	x	x	x	x	x
2008\XR-Commander	RSM -- Rain Sensor Module	x	x	x	x	
2008\XR-Commander	SDARV -- Satellite Video Receiver	x	x	x	x	
2008\XR-Commander	AMP -- Amplifier	x	x	x	x	
2008\XR-Commander	HFM -- Hands Free Module	x	x	x	x	x
2008\XR-Commander	VES3 -- Last Row Screen	x	x	x	x	x
2008\XR-Commander	HSM -- Heated Seat Module	x	x	x	x	x
2008\ZB-Viper	ECM -- Engine Control Module	x	x	x	x	x
2008\ZB-Viper	OCM -- Occupant Classification	x	x	x	x	
2008\ZFP-Crossfire/NAFTA	ECM -- Engine Control Module	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	TCM -- Transmission Control Module	x	x	x	x	
2008\ZFP-Crossfire/NAFTA	ESP -- Electronic Stability Program	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	ORC -- AirBag/Occupant Restraint	x	x	x	x	
2008\ZFP-Crossfire/NAFTA	IC -- Instrument Cluster	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	TPM -- Tire Pressure Monitor	x	x	x	x	
2008\ZFP-Crossfire/NAFTA	BCM -- Body Controller	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	SKM -- SKIM/SKREEM/TPM	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	SLA -- Shift Lever Sensor Assembly	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	OCM -- Occupant Classification	x	x	x	x	
2008\ZFP-Crossfire/NAFTA	PTCM -- Power Top Control Module	x	x	x	x	x
2008\ZFP-Crossfire/NAFTA	CLP	x	x	x		x
2007\CS-Pacifica	ECM -- Engine Control Module	x	x	x	x	x
2007\CS-Pacifica	ABS -- Anti Lock Brakes	x	x	x	x	x
2007\CS-Pacifica	ORC -- AirBag/Occupant Restraint	x	x	x	x	
2007\CS-Pacifica	CGW -- Central Gateway	x	x	x	x	x
2007\CS-Pacifica	SAS -- Steering Angle Sensor	x	x	x	x	
2007\CS-Pacifica	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	
2007\CS-Pacifica	PLGM -- Power Liftgate Module	x	x	x	x	x
2007\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x
2007\DR-RAM	TCM -- Transmission Control Module	x	x	x	x	x
2007\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x
2007\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x	
2007\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x
2007\DR-RAM	CGW -- Central Gateway	x	x	x	x	x
2007\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x	
2007\DR-RAM	SAS -- Steering Angle Sensor	x	x	x	x	

2007\DR-RAM	RADIO -- Radio	x	x	x	x		
2007\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2007\DR-RAM	SUNR -- Sunroof	x	x	x	x	x	
2007\DR-RAM	EOM -- Electronic Overhead	x	x	x	x	x	
2007\DR-RAM	SDAR -- Satellite Radio	x	x	x	x		
2007\DR-RAM	AMP -- Amplifier	x	x	x	x		
2007\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
2007\DR-RAM	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2007\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2007\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\HB-Durango	SAS -- Steering Angle Sensor	x	x	x	x		
2007\HB-Durango	PTS -- Parktronics	x	x	x	x	x	
2007\HB-Durango	RADIO -- Radio	x	x	x	x		
2007\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2007\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2007\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2007\HB-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2007\HB-Durango	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2007\HB-Durango	EOM -- Electronic Overhead	x	x	x	x	x	
2007\HB-Durango	SDAR -- Satellite Radio	x	x	x	x		
2007\HB-Durango	AMP -- Amplifier	x	x	x	x		
2007\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2007\HB-Durango	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2007\HG-Aspen	ECM -- Engine Control Module	x	x	x	x	x	
2007\HG-Aspen	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\HG-Aspen	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\HG-Aspen	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\HG-Aspen	CGW -- Central Gateway	x	x	x	x	x	
2007\HG-Aspen	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\HG-Aspen	SAS -- Steering Angle Sensor	x	x	x	x		
2007\HG-Aspen	PTS -- Parktronics	x	x	x	x	x	
2007\HG-Aspen	RADIO -- Radio	x	x	x	x		
2007\HG-Aspen	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	

2007\HG-Aspen	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2007\HG-Aspen	DDM -- Driver Door Module	x	x	x	x	x	
2007\HG-Aspen	PDM -- Passenger Door Module	x	x	x	x	x	
2007\HG-Aspen	PLGM -- Power Liftgate Module	x	x	x	x	x	
2007\HG-Aspen	EOM -- Electronic Overhead	x	x	x	x	x	
2007\HG-Aspen	SDAR -- Satellite Radio	x	x	x	x		
2007\HG-Aspen	AMP -- Amplifier	x	x	x	x		
2007\HG-Aspen	HFM -- Hands Free Module	x	x	x	x		
2007\HG-Aspen	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007\HG-Aspen	HSM -- Heated Seat Module	x	x	x	x	x	
2007\JK-Wrangler	ECM -- Engine Control Module	x	x	x	x	x	
2007\JK-Wrangler	TCM -- Transmission Control Module	x	x	x	x	x	
2007\JK-Wrangler	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\JK-Wrangler	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\JK-Wrangler	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\JK-Wrangler	CGW -- Central Gateway	x	x	x	x	x	
2007\JK-Wrangler	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\JK-Wrangler	SAS -- Steering Angle Sensor	x	x	x	x		
2007\JK-Wrangler	RADIO -- Radio	x	x	x	x	x	
2007\JK-Wrangler	OCM -- Occupant Classification	x	x	x	x		
2007\JK-Wrangler	ASBS -- Automatic Sway Bar System	x	x	x	x		
2007\JK-Wrangler	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\JK-Wrangler	AMP -- Amplifier	x	x	x	x		
2007\SS-Sebring C	ECM -- Engine Control Module	x	x	x	x	x	
2007\SS-Sebring C	TCM -- Transmission Control Module	x	x	x	x	x	
2007\SS-Sebring C	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\SS-Sebring C	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\SS-Sebring C	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\SS-Sebring C	CGW -- Central Gateway	x	x	x	x	x	
2007\SS-Sebring C	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\SS-Sebring C	SAS -- Steering Angle Sensor	x	x	x	x		
2007\SS-Sebring C	RADIO -- Radio	x	x	x	x	x	
2007\SS-Sebring C	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\SS-Sebring C	DDM -- Driver Door Module	x	x	x	x	x	
2007\SS-Sebring C	PDM -- Passenger Door Module	x	x	x	x	x	
2007\SS-Sebring C	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2007\SS-Sebring C	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\SS-Sebring C	PTCM -- Power Top Control Module	x	x	x	x		
2007\SS-Sebring C	AMP -- Amplifier	x	x	x	x		
2007\SS-Sebring C	HFM -- Hands Free Module	x	x	x	x	x	

2007\SS-Avenger Sebring C	VES3 -- Last Row Screen	x	x	x	x	x	
2007\KA-Nitro	ECM -- Engine Control Module	x	x	x	x	x	
2007\KA-Nitro	TCM -- Transmission Control Module	x	x	x	x		
2007\KA-Nitro	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\KA-Nitro	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\KA-Nitro	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\KA-Nitro	CGW -- Central Gateway	x	x	x	x	x	
2007\KA-Nitro	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\KA-Nitro	SAS -- Steering Angle Sensor	x	x	x	x		
2007\KA-Nitro	PTS -- Parktronics	x	x	x	x	x	
2007\KA-Nitro	RADIO -- Radio	x	x	x	x	x	
2007\KA-Nitro	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\KA-Nitro	DMFR -- Door Module Front Right	x	x	x	x	x	
2007\KA-Nitro	DMFL -- Door Module Front Left	x	x	x	x	x	
2007\KA-Nitro	ESM -- Electronic Shifter	x	x	x	x	x	
2007\KA-Nitro	OCM -- Occupant Classification	x	x	x	x		
2007\KA-Nitro	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\KA-Nitro	AMP -- Amplifier	x	x	x	x		
2007\KA-Nitro	HFM -- Hands Free Module	x	x	x	x	x	
2007\KA-Nitro	VES3 -- Last Row Screen	x	x	x	x	x	
2007\KJ-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2007\KJ-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\KJ-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		
2007\CLX	ECM -- Engine Control Module	x	x	x	x	x	
2007\Charger Magn	TCM -- Transmission Control Module	x	x	x	x		
2007\CLX	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\CLX	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\Charger Magn	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\CLX	CGW -- Central Gateway	x	x	x	x	x	
2007\Charger Magn	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\CLX	PTS -- Parktronics	x	x	x	x	x	
2007\Charger Magn	RADIO -- Radio	x	x	x	x		
2007\CLX	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\Charger Magn	ACC -- Adaptive Cruise Control	x	x	x	x		
2007\CLX	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2007\Charger Magn	DDM -- Driver Door Module	x	x	x	x	x	
2007\CLX	PDM -- Passenger Door Module	x	x	x	x	x	
2007\Charger Magn	SCM -- Steering Column	x	x	x	x	x	
2007\CLX	ESM -- Electronic Shifter	x	x	x	x	x	
2007\Charger Magn	SUNR -- Sunroof	x	x	x	x	x	

2007/LX	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2007/LX	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2007/LX	AHBM -- Automatic High Beam	x	x	x	x	x	
2007/LX	EOM -- Electronic Overhead	x	x	x	x		
2007/LX	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007/LX	RSM -- Rain Sensor Module	x	x	x	x		
2007/LX	SDAR -- Satellite Radio	x	x	x	x		
2007/LX	AMP -- Amplifier	x	x	x	x		
2007/LX	HFM -- Hands Free Module	x	x	x	x	x	
2007/LX	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007/LX	HSM -- Heated Seat Module	x	x	x	x	x	
2007/LX	ECM -- Engine Control Module	x	x	x	x	x	
2007/LX	TCM -- Transmission Control Module	x	x	x	x	x	
2007/LX	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007/LX	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007/LX	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007/LX	CGW -- Central Gateway	x	x	x	x	x	
2007/LX	WCM/TPMS -- Wireless Control	x	x	x	x		
2007/LX	SAS -- Steering Angle Sensor	x	x	x	x		
2007/LX	RADIO -- Radio	x	x	x	x		
2007/LX	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2007/LX	OCM -- Occupant Classification	x	x	x	x		
2007/LX	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007/LX	SDAR -- Satellite Radio	x	x	x	x		
2007/LX	AMP -- Amplifier	x	x	x	x		
2007/LX	HFM -- Hands Free Module	x	x	x	x	x	
2007/LX	ECM -- Engine Control Module	x	x	x	x	x	
2007/LX	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007/LX	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007/LX	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007/LX	CGW -- Central Gateway	x	x	x	x	x	
2007/LX	WCM/TPMS -- Wireless Control	x	x	x	x		
2007/LX	RADIO -- Radio	x	x	x	x		
2007/LX	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007/LX	OCM -- Occupant Classification	x	x	x	x		
2007/LX	EOM -- Electronic Overhead	x	x	x	x	x	
2007/LX	SDAR -- Satellite Radio	x	x	x	x		
2007/LX	AMP -- Amplifier	x	x	x	x		
2007/LX	ECM -- Engine Control Module	x	x	x	x	x	
2007/LX	ABS -- Anti Lock Brakes	x	x	x	x	x	

2007\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2007\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\NM-Raider	RADIO -- Radio	x	x	x	x		
2007\NM-Raider	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\NM-Raider	OCM -- Occupant Classification	x	x	x	x		
2007\NM-Raider	EOM -- Electronic Overhead	x	x	x	x	x	
2007\NM-Raider	SDAR -- Satellite Radio	x	x	x	x		
2007\NM-Raider	AMP -- Amplifier	x	x	x	x		
2007\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2007\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2007\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2007\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\PM-Caliber	SAS -- Steering Angle Sensor	x	x	x	x		
2007\PM-Caliber	RADIO -- Radio	x	x	x	x		
2007\PM-Caliber	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2007\PM-Caliber	OCM -- Occupant Classification	x	x	x	x		
2007\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\PM-Caliber	SDAR -- Satellite Radio	x	x	x	x		
2007\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2007\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	
2007\PM-Caliber	ECM -- Engine Control Module	x	x	x	x	x	
2007\PM-Caliber	TCM -- Transmission Control Module	x	x	x	x	x	
2007\PM-Caliber	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2007\PM-Caliber	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\PM-Caliber	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\PM-Caliber	CGW -- Central Gateway	x	x	x	x	x	
2007\PM-Caliber	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\PM-Caliber	RADIO -- Radio	x	x	x	x		
2007\PM-Caliber	DDM -- Driver Door Module	x	x	x	x	x	
2007\PM-Caliber	PDM -- Passenger Door Module	x	x	x	x	x	
2007\PM-Caliber	OCM -- Occupant Classification	x	x	x	x		
2007\PM-Caliber	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\PM-Caliber	SDAR -- Satellite Radio	x	x	x	x		
2007\PM-Caliber	AMP -- Amplifier	x	x	x	x		
2007\PM-Caliber	HFM -- Hands Free Module	x	x	x	x	x	

2007\VB-Sprinter	ECM -- Engine Control Module	x	x	x	x	x	
2007\VB-Sprinter	TCM -- Transmission Control Module	x	x	x	x		
2007\VB-Sprinter	ABS -- Anti Lock Brakes	x	x	x	x		0001
2007\VB-Sprinter	ORC -- AirBag/Occupant Restraint	x	x	x			
2007\VB-Sprinter	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x		
2007\VB-Sprinter	TPM -- Tire Pressure Monitor	x	x	x	x		
2007\VB-Sprinter	BCM -- Body Controller	x	x	x	x	x	
2007\VB-Sprinter	CGW -- Central Gateway	x	x	x	x		
2007\VB-Sprinter	PTS -- Parktronics	x	x	x	x	x	
2007\VB-Sprinter	RADIO -- Radio	x	x	x	x		
2007\VB-Sprinter	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\VB-Sprinter	DDM -- Driver Door Module	x	x	x	x	x	
2007\VB-Sprinter	SCM -- Steering Column	x	x	x	x	x	
2007\VB-Sprinter	SBM -- Center Console / Switch Bank Module	x	x	x	x	x	
2007\VB-Sprinter	ESM -- Electronic Shifter	x	x	x	x	x	
2007\VB-Sprinter	BCH -- Booster Cabin Heater Module (ZHZ)	x	x	x	x	x	
2007\VB-Sprinter	ACH -- Auxiliary Cabin Heater (STH)	x	x	x	x	x	
2007\VB-Sprinter	TM -- Trailer	x	x	x	x		
2007\VB-Sprinter	AHLM -- Headlamp Leveling	x	x	x	x	x	
2007\VB-Sprinter	RCM -- Roof Control Module	x	x	x	x	x	
2007\VB-Sprinter	AEHM -- Auxiliary Electrical Heating Module	x	x	x	x		
2007\VB-Sprinter	CDC -- CD Changer	x	x	x	x		
2007\VB-Sprinter	HFM -- Hands Free Module	x	x	x	x		
2007\VB-Sprinter	PSM -- Universal/Special ECU	x	x	x	x	x	
2007\WVC-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2007\WVC-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2007\WVC-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\WVC-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\WVC-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\WVC-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2007\WVC-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\WVC-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2007\WVC-Grand Cherokee	RADIO -- Radio	x	x	x	x		
2007\WVC-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\WVC-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2007\WVC-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2007\WVC-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2007\WVC-Grand Cherokee	SCM -- Steering Column	x	x	x	x		
2007\WVC-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2007\WVC-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	

2007\WR-Grand Cherokee	TM -- Trailer		x	x			
2007\WR-Grand Cherokee	SUNR -- Sunroof	x	x	x	x	x	
2007\WR-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2007\WR-Grand Cherokee	EOM -- Electronic Overhead	x	x	x	x		
2007\WR-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\WR-Grand Cherokee	RSM -- Rain Sensor Module	x	x	x	x		
2007\WR-Grand Cherokee	SDAR -- Satellite Radio	x	x	x	x		
2007\WR-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2007\WR-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2007\WR-Grand Cherokee	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007\WR-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2007\WR-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2007\WR-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x		
2007\WR-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	
2007\WR-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2007\WR-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2007\WR-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2007\WR-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x		
2007\WR-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2007\WR-Grand Cherokee	RADIO -- Radio	x	x	x	x		
2007\WR-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2007\WR-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2007\WR-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2007\WR-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2007\WR-Grand Cherokee	SCM -- Steering Column	x	x	x	x		
2007\WR-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2007\WR-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2007\WR-Grand Cherokee	PLGM -- Power Liftgate Module	x	x	x	x	x	
2007\WR-Grand Cherokee	TM -- Trailer		x	x			
2007\WR-Grand Cherokee	SUNR -- Sunroof	x	x	x	x	x	
2007\WR-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2007\WR-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2007\WR-Grand Cherokee	RSM -- Rain Sensor Module	x	x	x	x		
2007\WR-Grand Cherokee	SDAR -- Satellite Radio	x	x	x	x		
2007\WR-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2007\WR-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2007\WR-Grand Cherokee	VES -- Vehicle Entertainment System	x	x	x	x	x	
2007\WR-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2006\DR-RAM	ECM -- Engine Control Module	x	x	x	x	x	
2006\DR-RAM	TCM -- Transmission Control Module	x	x	x	x	x	

2006\DR-RAM	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\DR-RAM	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\DR-RAM	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\DR-RAM	CGW -- Central Gateway	x	x	x	x	x	
2006\DR-RAM	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\DR-RAM	RADIO -- Radio	x	x	x	x		
2006\DR-RAM	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2006\DR-RAM	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x		
2006\DR-RAM	OCM -- Occupant Classification	x	x	x	x		
2006\DR-RAM	SUNR -- Sunroof	x	x	x	x	x	
2006\DR-RAM	EOM -- Electronic Overhead	x	x	x	x		
2006\DR-RAM	SDAR -- Satellite Radio	x	x	x	x		
2006\DR-RAM	AMP -- Amplifier	x	x	x	x		
2006\DR-RAM	HFM -- Hands Free Module	x	x	x	x	x	
2006\DR-RAM	VES -- Vehicle Entertainment System	x	x	x	x	x	
2006\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2006\HB-Durango	TCM -- Transmission Control Module	x	x	x	x	x	
2006\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2006\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\HB-Durango	SAS -- Steering Angle Sensor	x	x	x	x		
2006\HB-Durango	RADIO -- Radio	x	x	x	x		
2006\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2006\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2006\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2006\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2006\HB-Durango	PLGM -- Power Liftgate Module	x	x	x	x	x	
2006\HB-Durango	OCM -- Occupant Classification	x	x	x	x		
2006\HB-Durango	EOM -- Electronic Overhead	x	x	x	x		
2006\HB-Durango	SDAR -- Satellite Radio	x	x	x	x		
2006\HB-Durango	AMP -- Amplifier	x	x	x	x		
2006\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2006\HB-Durango	VES -- Vehicle Entertainment System	x	x	x	x	x	
2006\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2006\KJ-Liberty	ECM -- Engine Control Module	x	x	x	x	x	
2006\KJ-Liberty	TCM -- Transmission Control Module	x	x	x	x	x	
2006\KJ-Liberty	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\KJ-Liberty	SAS -- Steering Angle Sensor	x	x	x	x		

2000\EX	ECM -- Engine Control Module	x	x	x	x	x	
2000\Charger Magn	TCM -- Transmission Control Module	x	x	x	x	x	
2000\EX	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2000\Charger Magn	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2000\EX	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2000\Charger Magn	CGW -- Central Gateway	x	x	x	x	x	
2000\Charger Magn	WCM/TPMS -- Wireless Control	x	x	x	x		
2000\Charger Magn	PTS -- Parktronics	x	x	x	x	x	
2000\EX	RADIO -- Radio	x	x	x	x		
2000\Charger Magn	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2000\Charger Magn	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2000\EX	DDM -- Driver Door Module	x	x	x	x	x	
2000\Charger Magn	PDM -- Passenger Door Module	x	x	x	x	x	
2000\Charger Magn	SCM -- Steering Column	x	x	x	x	x	
2000\EX	ESM -- Electronic Shifter	x	x	x	x	x	
2000\Charger Magn	OCM -- Occupant Classification	x	x	x	x		
2000\EX	SUNR -- Sunroof	x	x	x	x	x	
2000\Charger Magn	PTIM -- Police/Taxi Interface Module	x	x	x	x	x	
2000\EX	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2000\Charger Magn	AHBM -- Automatic High Beam	x	x	x	x	x	
2000\EX	EOM -- Electronic Overhead	x	x	x	x		
2000\Charger Magn	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2000\EX	RSM -- Rain Sensor Module	x	x	x	x		
2000\Charger Magn	SDAR -- Satellite Radio	x	x	x	x		
2000\EX	AMP -- Amplifier	x	x	x	x		
2000\Charger Magn	HFM -- Hands Free Module	x	x	x	x	x	
2000\EX	VES -- Vehicle Entertainment System	x	x	x	x	x	
2000\Charger Magn	HSM -- Heated Seat Module	x	x	x	x	x	
2006\ND-Dakota	ECM -- Engine Control Module	x	x	x	x	x	
2006\ND-Dakota	TCM -- Transmission Control Module	x	x	x	x	x	
2006\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2006\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\ND-Dakota	RADIO -- Radio	x	x	x	x		
2006\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2006\ND-Dakota	OCM -- Occupant Classification	x	x	x	x		
2006\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2006\ND-Dakota	SDAR -- Satellite Radio	x	x	x	x		

2006\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2006\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2006\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2006\NM-Raider	TCM -- Transmission Control Module	x	x	x	x	x	
2006\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2006\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\NM-Raider	RADIO -- Radio	x	x	x	x		
2006\NM-Raider	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2006\NM-Raider	OCM -- Occupant Classification	x	x	x	x		
2006\NM-Raider	EOM -- Electronic Overhead	x	x	x	x		
2006\NM-Raider	SDAR -- Satellite Radio	x	x	x	x		
2006\NM-Raider	AMP -- Amplifier	x	x	x	x		
2006\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2006\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2006\NM-Raider	TCM -- Transmission Control Module	x	x	x	x	x	
2006\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2006\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2006\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\NM-Raider	RADIO -- Radio	x	x	x	x		
2006\NM-Raider	DDM -- Driver Door Module	x	x	x	x	x	
2006\NM-Raider	PDM -- Passenger Door Module	x	x	x	x	x	
2006\NM-Raider	OCM -- Occupant Classification	x	x	x	x		
2006\NM-Raider	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2006\NM-Raider	SDAR -- Satellite Radio	x	x	x	x		
2006\NM-Raider	AMP -- Amplifier	x	x	x	x		
2006\NM-Raider	HFM -- Hands Free Module	x	x	x	x	x	
2006\NM-Raider	ECM -- Engine Control Module	x	x	x	x	x	
2006\NM-Raider	TCM -- Transmission Control Module	x	x	x	x	x	
2006\NM-Raider	ABS -- Anti Lock Brakes	x	x	x	x	x	
2006\NM-Raider	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2006\NM-Raider	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2006\NM-Raider	CGW -- Central Gateway	x	x	x	x	x	
2006\NM-Raider	WCM/TPMS -- Wireless Control	x	x	x	x		
2006\NM-Raider	PTS -- Parktronics	x	x	x	x	x	
2006\NM-Raider	RADIO -- Radio	x	x	x	x		

2000VW-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2000VW-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2000VW-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2000VW-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2000VW-Grand Cherokee	SCM -- Steering Column	x	x	x	x		
2000VW-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2000VW-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2000VW-Grand Cherokee	OCM -- Occupant Classification	x	x	x	x		
2000VW-Grand Cherokee	TM -- Trailer		x	x			
2000VW-Grand Cherokee	SUNR -- Sunroof	x	x	x	x	x	
2000VW-Grand Cherokee	AHBM -- Automatic High Beam	x	x	x	x	x	
2000VW-Grand Cherokee	EOM -- Electronic Overhead	x	x	x	x		
2000VW-Grand Cherokee	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2000VW-Grand Cherokee	RSM -- Rain Sensor Module	x	x	x	x		
2000VW-Grand Cherokee	SDAR -- Satellite Radio	x	x	x	x		
2000VW-Grand Cherokee	AMP -- Amplifier	x	x	x	x		
2000VW-Grand Cherokee	HFM -- Hands Free Module	x	x	x	x	x	
2000VW-Grand Cherokee	VES -- Vehicle Entertainment System	x	x	x	x	x	
2000VW-Grand Cherokee	HSM -- Heated Seat Module	x	x	x	x	x	
2000VW-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2000VW-Commander	TCM -- Transmission Control Module	x	x	x	x	x	
2000VW-Commander	ABS -- Anti Lock Brakes	x	x	x	x	x	
2000VW-Commander	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2000VW-Commander	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2000VW-Commander	CGW -- Central Gateway	x	x	x	x	x	
2000VW-Commander	WCM/TPMS -- Wireless Control	x	x	x	x		
2000VW-Commander	PTS -- Parktronics	x	x	x	x	x	
2000VW-Commander	RADIO -- Radio	x	x	x	x		
2000VW-Commander	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2000VW-Commander	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2000VW-Commander	DDM -- Driver Door Module	x	x	x	x	x	
2000VW-Commander	PDM -- Passenger Door Module	x	x	x	x	x	
2000VW-Commander	SCM -- Steering Column	x	x	x	x		
2000VW-Commander	ESM -- Electronic Shifter	x	x	x	x	x	
2000VW-Commander	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2000VW-Commander	OCM -- Occupant Classification	x	x	x	x		
2000VW-Commander	TM -- Trailer		x	x			
2000VW-Commander	SUNR -- Sunroof	x	x	x	x	x	
2000VW-Commander	AHBM -- Automatic High Beam	x	x	x	x	x	
2000VW-Commander	ITM -- Intrusion Transceiver Module	x	x	x	x	x	

2000XR Commander	RSM -- Rain Sensor Module	x	x	x	x		
2000XR Commander	SDAR -- Satellite Radio	x	x	x	x		
2000XR Commander	AMP -- Amplifier	x	x	x	x		
2000XR Commander	HFM -- Hands Free Module	x	x	x	x	x	
2000XR Commander	VES -- Vehicle Entertainment System	x	x	x	x	x	
2000XR Commander	HSM -- Heated Seat Module	x	x	x	x	x	
2005\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2005\HB-Durango	TCM -- Transmission Control Module	x	x	x	x	x	
2005\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	0003, 0002, 0004
2005\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2005\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2005\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2005\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2005\HB-Durango	RADIO -- Radio	x	x	x	x		
2005\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2005\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2005\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2005\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2005\HB-Durango	OCM -- Occupant Classification	x	x	x	x		
2005\HB-Durango	EOM -- Electronic Overhead	x	x	x	x		
2005\HB-Durango	SDAR -- Satellite Radio	x	x	x	x		
2005\HB-Durango	AMP -- Amplifier	x	x	x	x		
2005\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2005\HB-Durango	VES -- Vehicle Entertainment System	x	x	x	x	x	
2005\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2005\EX Charger Magn	ECM -- Engine Control Module	x	x	x	x	x	
2005\EX Charger Magn	TCM -- Transmission Control Module	x	x	x	x	x	
2005\EX Charger Magn	ABS -- Anti Lock Brakes	x	x	x	x	x	0005, 0001, 0006, 0014
2005\EX Charger Magn	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2005\EX Charger Magn	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2005\EX Charger Magn	CGW -- Central Gateway	x	x	x	x	x	
2005\EX Charger Magn	WCM/TPMS -- Wireless Control	x	x	x	x		
2005\EX Charger Magn	PTS -- Parktronics	x	x	x	x	x	
2005\EX Charger Magn	RADIO -- Radio	x	x	x	x		
2005\EX Charger Magn	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2005\EX Charger Magn	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2005\EX Charger Magn	DDM -- Driver Door Module	x	x	x	x	x	
2005\EX Charger Magn	PDM -- Passenger Door Module	x	x	x	x	x	
2005\EX Charger Magn	SCM -- Steering Column	x	x	x	x	x	
2005\EX Charger Magn	ESM -- Electronic Shifter	x	x	x	x	x	

2005\EX- 2005\Charger Magn	OCM -- Occupant Classification	x	x	x	x		
2005\EX- 2005\Charger Magn	SUNR -- Sunroof	x	x	x	x	x	
2005\EX- 2005\Charger Magn	HIDT -- High Intensity Discharge Translator	x	x	x	x	x	
2005\EX- 2005\Charger Magn	EOM -- Electronic Overhead	x	x	x	x	x	
2005\EX- 2005\Charger Magn	RSM -- Rain Sensor Module	x	x	x	x		
2005\EX- 2005\Charger Magn	SDAR -- Satellite Radio	x	x	x	x		
2005\EX- 2005\Charger Magn	AMP -- Amplifier	x	x	x	x		
2005\EX- 2005\Charger Magn	HFM -- Hands Free Module	x	x	x	x	x	
2005\EX- 2005\Charger Magn	HSM -- Heated Seat Module	x	x	x	x	x	
2005\ND-Dakota	ECM -- Engine Control Module	x	x	x	x	x	
2005\ND-Dakota	TCM -- Transmission Control Module	x	x	x	x	x	
2005\ND-Dakota	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2005\ND-Dakota	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2005\ND-Dakota	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2005\ND-Dakota	CGW -- Central Gateway	x	x	x	x	x	
2005\ND-Dakota	WCM/TPMS -- Wireless Control	x	x	x	x		
2005\ND-Dakota	RADIO -- Radio	x	x	x	x		
2005\ND-Dakota	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2005\ND-Dakota	OCM -- Occupant Classification	x	x	x	x		
2005\ND-Dakota	EOM -- Electronic Overhead	x	x	x	x		
2005\ND-Dakota	SDAR -- Satellite Radio	x	x	x	x		
2005\ND-Dakota	AMP -- Amplifier	x	x	x	x		
2005\ND-Dakota	HFM -- Hands Free Module	x	x	x	x	x	
2005\WVC-Grand Cherokee	ECM -- Engine Control Module	x	x	x	x	x	
2005\WVC-Grand Cherokee	TCM -- Transmission Control Module	x	x	x	x	x	
2005\WVC-Grand Cherokee	ABS -- Anti Lock Brakes	x	x	x	x	x	0001, 0014
2005\WVC-Grand Cherokee	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2005\WVC-Grand Cherokee	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2005\WVC-Grand Cherokee	CGW -- Central Gateway	x	x	x	x	x	
2005\WVC-Grand Cherokee	WCM/TPMS -- Wireless Control	x	x	x	x		
2005\WVC-Grand Cherokee	PTS -- Parktronics	x	x	x	x	x	
2005\WVC-Grand Cherokee	RADIO -- Radio	x	x	x	x		
2005\WVC-Grand Cherokee	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2005\WVC-Grand Cherokee	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2005\WVC-Grand Cherokee	DDM -- Driver Door Module	x	x	x	x	x	
2005\WVC-Grand Cherokee	PDM -- Passenger Door Module	x	x	x	x	x	
2005\WVC-Grand Cherokee	SCM -- Steering Column	x	x	x	x		
2005\WVC-Grand Cherokee	ESM -- Electronic Shifter	x	x	x	x	x	
2005\WVC-Grand Cherokee	FDCM -- Final Drive Control/All Wheel Drive	x	x	x	x	x	
2005\WVC-Grand Cherokee	OCM -- Occupant Classification	x	x	x	x		

2005\WK-Durango	SUNR -- Sunroof	x	x	x	x	x	
2005\WK-Durango	AHBM -- Automatic High Beam	x	x	x	x	x	
2005\WK-Durango	EOM -- Electronic Overhead	x	x	x	x		
2005\WK-Durango	ITM -- Intrusion Transceiver Module	x	x	x	x	x	
2005\WK-Durango	RSM -- Rain Sensor Module	x	x	x	x		
2005\WK-Durango	SDAR -- Satellite Radio	x	x	x	x		
2005\WK-Durango	AMP -- Amplifier	x	x	x	x		
2005\WK-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2005\WK-Durango	VES -- Vehicle Entertainment System	x	x	x	x	x	
2005\WK-Durango	HSM -- Heated Seat Module	x	x	x	x	x	
2004\HB-Durango	ECM -- Engine Control Module	x	x	x	x	x	
2004\HB-Durango	TCM -- Transmission Control Module	x	x	x	x	x	
2004\HB-Durango	ABS -- Anti Lock Brakes	x	x	x	x	x	0003, 0002, 0004
2004\HB-Durango	ORC -- AirBag/Occupant Restraint	x	x	x	x		
2004\HB-Durango	MIC/CCN -- Mechanical Instrument Cluster	x	x	x	x	x	
2004\HB-Durango	CGW -- Central Gateway	x	x	x	x	x	
2004\HB-Durango	WCM/TPMS -- Wireless Control	x	x	x	x		
2004\HB-Durango	RADIO -- Radio	x	x	x	x		
2004\HB-Durango	HVAC -- Heat, Ventilation and A/C	x	x	x	x	x	
2004\HB-Durango	MSM -- Memory Seat/Memory Heated Seat	x	x	x	x		
2004\HB-Durango	DDM -- Driver Door Module	x	x	x	x	x	
2004\HB-Durango	PDM -- Passenger Door Module	x	x	x	x	x	
2004\HB-Durango	OCM -- Occupant Classification	x	x	x	x		
2004\HB-Durango	EOM -- Electronic Overhead	x	x	x	x	x	
2004\HB-Durango	SDAR -- Satellite Radio	x	x	x	x		
2004\HB-Durango	AMP -- Amplifier	x	x	x	x		
2004\HB-Durango	HFM -- Hands Free Module	x	x	x	x	x	
2004\HB-Durango	VES -- Vehicle Entertainment System	x	x	x	x	x	
2004\HB-Durango	HSM -- Heated Seat Module	x	x	x	x	x	

Special Function Table

0001	Bleed Brakes
0002	Bleed Brakes 2WD
0003	Bleed Brakes 4WD
0004	Bleed Brakes ABS only
0005	Bleed Brakes:LX
0006	Bleed Brakes:WK
0007	DPF Pressure Sensor Reset
0008	DPF Regeneration

0009	DPF Replacement
0010	DPF Reset Option
0011	Diesel Particulate Filter Replacement
0012	Display Diesel Particulate Filter Values
0013	Initialize ABS
0014	Initialize ABS Module
0015	Initialize ABS Non ESP
0016	New DPF Initialize
0017	Service Diesel Particulate Filter Regeneration